

CENTRAL INTELLIGENCE AGENCY

This material contains information affecting the National Defense of the United States within the meaning of the Espionage Laws, Title 18, U.S.C. Secs. 793 and 794, the transmission or revelation of which, in any manner to an unauthorized person, is prohibited by law.

S-E-C-R-E-T  
NO FOREIGN DISSEM

COUNTRY USSR

REPORT

SUBJECT Soviet Manuals on [redacted] Engine Instruments and Service of the TU-16 Aircraft

DATE DISTR. 20 December 1963

NO. PAGES 2

50X1-HUM  
50X1-HUM

REFERENCES [redacted]

DATE OF INFO.

PLACE & DATE ACQ.

50X1-HUM

THIS IS UNEVALUATED INFORMATION. SOURCE GRADINGS ARE DEFINITIVE. APPRAISAL OF CONTENT IS TENTATIVE.

[redacted] English-language Soviet manuals on the TU-16 aircraft (BADGER A) [redacted]

[redacted] None of the manuals [redacted] a date or place of publication.

50X1-HUM

Attachment No.

Title

50X1-HUM

1

Fuel Consumption Control Units and TU-16 Aircraft Engine Instruments, 72 pages and 84 figures.

50X1-HUM

3

TU-16 Aircraft, Aircraft Service Manual, Book II, Navigation Equipment, Autopilot, Oxygen, Electrical, Photo, and Radio Equipment, 261 pages and 181 figures.

4

TU-16 Aircraft, Aircraft Service Manual, Book I, General Servicing of Aircraft, Care and Maintenance of Airframe, Emergency and Rescue Appliances, Aircraft Controls, Landing Gear and Hydraulic Systems, Power Plants, Altitude Equipment, and Packing and Shipment of Separate Aircraft Units, 304 pages and 4 insets.

50X1-HUM

S-E-C-R-E-T  
NO FOREIGN DISSEM

GROUP 1  
Excluded from automatic  
downgrading and  
declassification

STATE DIA ARMY NAVY AIR NSA XXXX NIC OCR SAC

(Note: Field distribution indicated by "#")

50X1-HUM



Distribution of Attachments:



OSI: 2 sets  
ORR: 2 sets  
AIR: 2 sets  
Air/FTD: 5 sets (1 set previously forwarded)  
SAC: 1 set  
Army: 1 set  
Army/FSTC: 1 set  
Navy: 2 sets  
Navy/STIC: 2 sets  
DIA: 3 sets  
NSA: 6 sets


50X1-HUM



50X1-HUM

S-E-C-R-E-T  
NO FOREIGN DISSEM

**SECRET**  
NO FOREIGN DISSEM



50X1-HUM

## TU-16 AIRCRAFT

### AIRCRAFT SERVICE MANUAL

#### Book I

General Servicing of Aircraft, Care and Maintenance of Airframe, Emergency and Rescue Appliances, Aircraft Controls, Landing Gear and Hydraulic Systems, Power Plants, and Altitude Equipment, Packing and Shipment of Separate Aircraft Units

GROUP 1  
Excluded from automatic  
downgrading and  
declassification

**SECRET**

NO FOREIGN DISSEM

**SECRET**  
**NO FOREIGN DISSEM**



50X1-HUM

**Ty-16 AIRCRAFT  
SERVICE MANUAL**

**Book One**

**SECRET**  
**NO FOREIGN DISSEM**



~~SECRET~~  
~~NO FOREIGN DISSEM~~

50X1-HUM

**Ty-16 AIRCRAFT  
SERVICE MANUAL**

**Book One**

**Ground Servicing of Aircraft, Care and Maintenance of Airframe,  
Emergency and Rescue Appliances, Aircraft Controls, Landing Gear  
and Hydraulic Systems, Power Plants, and Altitude Equipment.  
Packing and Shipment of Separate Aircraft Units.**

~~SECRET~~  
~~NO FOREIGN DISSEM~~

SECRET  
NO FOREIGN DISSEM

The book contains 304 pages and 4 insets.  
Inset No.1 is inserted between pages 210 and 211, while  
insets Nos 2, 3, and 4 are between pages 228 and 229.


CONTENTS

	Page
<b>Chapter I</b>	
<b>GROUND SERVICING OF AIRCRAFT</b>	
1. Aircraft Towing . . . . .	7
Towing Gear . . . . .	7
General Instructions on Aircraft Towing . . . . .	8
Preparing for Aircraft Towing . . . . .	9
Towing Aircraft with Nose Forward . . . . .	9
Towing Aircraft with Tail Forward . . . . .	10
Directions on Towing Gear Operation and Maintenance . . . . .	11
2. Aircraft Covers . . . . .	11
Procedure to Be Used in Putting Covers on Aircraft . . . . .	13
Operating Instructions . . . . .	14
3. Aircraft Grounding . . . . .	14
General . . . . .	14
Grounding Equipment . . . . .	15
Operating Instructions . . . . .	15
4. Securing Aircraft on Parking Area . . . . .	16
Preparatory Operations . . . . .	16
Securing Aircraft . . . . .	16
5. Lifting and Lowering Aircraft by means of Hydraulic Hoists . . . . .	16
Hydraulic Hoists . . . . .	17
Mounting Hoists . . . . .	20
Lifting Aircraft . . . . .	20
Lowering Aircraft . . . . .	21
6. Positioning Aircraft in Line of Flight . . . . .	22
Preparatory Operations and Equipment . . . . .	23
Longitudinal Positioning of Aircraft in Line of Flight . . . . .	23
Transverse Positioning of Aircraft in Line of Flight . . . . .	23
7. Aircraft Leveling . . . . .	24
8. Ground Equipment for Supplying Aircraft with Fuel, Oil, Oxygen, Compressed Air and Power . . . . .	26
9. Auxiliary Equipment . . . . .	28
Hydraulic Jack for Replacement of Landing Gear Wheels . . . . .	28
Engine Servicing Ladder . . . . .	29
Stabilizer Servicing Ladder . . . . .	29
Storage and Care of Auxiliary Equipment . . . . .	29
Slings . . . . .	29
10. List of Ground Equipment Employed in Aircraft Servicing . . . . .	30
<b>Chapter II</b>	
<b>AIRCRAFT AIRFRAMES CARE AND MAINTENANCE</b>	
1. Prevention and Elimination of Corrosion . . . . .	35
Care of Aircraft Metal Surfaces . . . . .	35
Care of Individual Attachment Fittings . . . . .	36
Restoring Protective Coatings and Eliminating Corrosion . . . . .	37

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM



5 50X1-HUM

2. Care of Glass Panels . . . . .	42	4. Adjustment of Tension of Cables Connecting Main Control System with Antopilot Servo Units . . . . .	74
3. Special Directions . . . . .	43	5. Adjustment of Elevator Trim Tab Control System . . . . .	75
<b>CHAPTER III</b>			
<b>EMERGENCY AND RESCUE APPLIANCES, CARE AND MAINTENANCE</b>			
1. Ejection Seats . . . . .	45	6. Adjustment of System Used to Lock Rudder, Elevators, and Ailerons on Parked Aircraft . . . . .	76
Removal and Installation of Ejection Seats on Aircraft . . . . .	45	7. Adjustment of Rudder and Aileron Trim Tab (Servo Tab) Control Systems . . . . .	76
Loading and Unloading Ejection Guns . . . . .	48	8. Special Instructions . . . . .	77
Loading and Unloading Ejection Guns of Seats Ejected Downward from Aircraft . . . . .	49	Aircraft Lateral and Directional Instability, Methods of Correction at Manufacturing Plant . . . . .	77
Loading and Unloading Ejection Guns of Seats Ejected Upward from Aircraft . . . . .	49	Elimination of Lateral and Directional Instability of Aircraft Detected during Service . . . . .	79
Operating Instructions for Ejection Guns and Seats . . . . .	50	Determination of Aircraft Lateral and Directional Instability by Pilots during Flight . . . . .	79
Disassembly and Assembly of Ejection Gun of Seat Ejected Upward from Aircraft . . . . .	51	Measurements to Be Taken during Postflight Inspection in Case of Aircraft Lateral and Directional Instability . . . . .	80
Disassembly and Assembly of Ejection Gun of Seat Ejected Downward from Aircraft . . . . .	52	Correction of Lateral and Directional Instability in Accordance with Pilot's Reports and Measurement Results during Postflight Inspection of Aircraft . . . . .	80
Checking Operation of Ejection Guns after Assembly . . . . .	53	9. Wing Flap Control . . . . .	82
Charging Actuating Cylinder of Navigator-Radar Operator's Ejection Seat . . . . .	54	General . . . . .	82
2. Emergency Escape and Entrance Hatches . . . . .	55	Access Panels for Inspection of Flap Control and Its Units . . . . .	83
Jettisoning Emergency Escape Hatch Covers from Aircraft by Mechanical System . . . . .	55	Instructions on Servicing and Checking Control System . . . . .	83
Mounting Navigator's Emergency Escape Hatch Cover . . . . .	56	Control System Adjustment . . . . .	86
Mounting Cover of Pilot's Canopy Emergency Escape Hatch . . . . .	57	Adjustment of Limit Switch Mechanisms MKB-11 and MKB-2 . . . . .	86
Mounting Cover of Navigator-Radar Operator's Emergency Escape Hatch . . . . .	57	Adjustment of Y31-47 Flap Position Indicator . . . . .	88
Mounting Covers of Emergency Escape Hatches of Gunner-Radio Operator and Rear Gunner . . . . .	58	<b>CHAPTER V</b>	
Entrance Hatches . . . . .	58	<b>LANDING GEAR AND HYDRAULIC SYSTEMS, CARE AND MAINTENANCE</b>	
Instructions on Care and Maintenance of Entrance and Emergency Escape Hatch Covers . . . . .	58	1. Landing Gear . . . . .	90
3. Life Boats, Type MAC-5H . . . . .	59	Landing Gear Basic Specifications . . . . .	90
General . . . . .	59	Adjustment of Landing Gear Nose Leg . . . . .	92
Specifications and Complete Set of MAC-5H Life Boat . . . . .	59	Adjustment of Landing Gear Main Legs . . . . .	93
Packing Life Boats into Aircraft Containers . . . . .	60	Adjustment of Tail Skid . . . . .	93
Life Boat Faults Encountered during Service and Their Elimination . . . . .	62	Adjustment of Landing Gear and Tail Skid Light Signalling System . . . . .	96
Repair of Life Boat Hand Pump . . . . .	63	Wheel Operating Instructions . . . . .	97
Charging Life Boat Cylinder with Carbon Dioxide . . . . .	63	Charging Landing Gear Leg Shock Absorbers . . . . .	99
Use of Life Boat . . . . .	64	Lubrication . . . . .	99
<b>CHAPTER IV</b>			
<b>AIRCRAFT CONTROLS, CARE AND MAINTENANCE</b>			
1. Care of Aircraft Control Systems and Periodical Checks . . . . .	66	Faults and Remedies . . . . .	100
2. Access Panels to Control System Units . . . . .	72	2. Hydraulic Systems . . . . .	101
3. Adjustment of Main Aircraft Control Systems . . . . .	73	General . . . . .	101
Elevator Control System . . . . .	73	Main System Specifications . . . . .	102
Rudder Control System . . . . .	73	Brake System Specifications . . . . .	103
Aileron Control System . . . . .	74	Marking of Pipe Lines . . . . .	104
		Charging Main System with Oil . . . . .	105
		Charging Brake System with Oil and Removing Air from It . . . . .	107
		Access Hatches for Inspection of System Separate Units . . . . .	108
		Checking Landing Gear Actuating Mechanism . . . . .	110
		Checking Landing Gear Nose Leg Wheel Turning Mechanism . . . . .	110
		Checking Bomb-Bay Door Actuating Mechanism . . . . .	110
		Checking Brake System and Brake Adjustment . . . . .	111

SECRET

NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

50X1-HUM

- 6 -

3. Special Instructions . . . . .	Page 113
4. Faults and Remedies . . . . .	114
<b>Chapter VI</b>	
<b>POWER PLANTS, CARE AND MAINTENANCE</b>	
1. Special Directions . . . . .	119
2. Air System . . . . .	124
Charging System with Compressed Air from Ground Bottle . . . . .	124
Checking Air System on Ground . . . . .	124
3. Servicing Aircraft with Fuel and Oil . . . . .	127
Servicing Aircraft with Main Fuel . . . . .	127
Checking Automatic Fuel Gauge System C37C-601 . . . . .	131
Fuel Drainage . . . . .	136
Servicing Aircraft with Starting Fuel . . . . .	136
Servicing Aircraft with Oil and Draining Oil System . . . . .	136
4. Checking Fuel Jettison System on Ground . . . . .	137
5. Installation and Removal of Bag-Type Fuel Tanks, Inspection of Tanks on Aircraft, and Safety Precautions to Be Observed . . . . .	138
6. Faults and Remedies . . . . .	140
<b>Chapter VII</b>	
<b>ALTITUDE EQUIPMENT, CARE AND MAINTENANCE</b>	
1. Basic Specifications . . . . .	146
Pressurization Reducing Valve (PRV) . . . . .	146
Air Delivery Regulator (ADR) . . . . .	146
Air Flow Motor . . . . .	146
Automatic Pressure Regulator (APR-54) . . . . .	147
Reducer (H7610-10) on Hatch Pressurization Panel . . . . .	147
Pressure Gauge, Type MB-250-W, on Pressurization Panel . . . . .	148
Pressure Gauge, Type MB-10-W, on Pressurization Panel . . . . .	148
Pressurization System Desiccator (H7610-76) . . . . .	148
Two-Way Cock (H7610-100) of Hatch Pressurization System . . . . .	148
2. Access to Units and Pipe Lines . . . . .	151
3. Special Instructions . . . . .	152
4. Checking Equipment with Engines Inoperative . . . . .	152
5. Checking Equipment with Engines Running . . . . .	154
6. Faults of Pressurized Cockpits and Altitude Equipment Systems Encountered during Service . . . . .	156
7. Testing Front and Rear Pressurized Cockpits for Leakage . . . . .	165
8. Leakage Test and Calibration of AIR Valve together with Its Control Valve . . . . .	167
<b>Chapter VIII</b>	
<b>PACKING AND SHIPMENT OF SEPARATE AIRCRAFT UNITS</b>	
1. General . . . . .	170
2. Preparation of Units for Packing . . . . .	172
3. Packing Means . . . . .	173
4. Manufacture of Packing . . . . .	174
5. Packing Units . . . . .	175
6. Loading Packed Units . . . . .	178
7. Unloading Packed Units . . . . .	179

Chapter IX

GROUND SERVICING OF AIRCRAFT

1. AIRCRAFT TOWING

The aircraft is towed with the aid of towing gear, with its nose or tail forward.

Caterpillar tractors are employed as towing vehicles. When pulling out the aircraft to the compass swinging platform, as well as in other cases not covered by the respective Operating Instructions, trucks carrying 1 to 1.5 t ballast (depending on the weight of the aircraft in question) may be employed for this purpose.

Towing Gear

Tow-bar (Fig. 1) serves for coupling the aircraft to the tractor, when the aircraft is towed with the nose forward. The tow-bar is essentially a metal structure furnished with rubber shock absorber 4 safeguarding the aircraft against abrupt jerks during towing. The tow-bar is carried on adjustable bogey 8 fitted with two 300x125 mm tyres. Hinged to the tow-bar is swivel frame 7 designed for turning the aircraft nose wheel. The tow-bar is attached to assembly A on the nose strut, the swivel frame being secured to the extending end of the nose wheel axle. The ends of the axle are gripped by split straps 16 provided with trunnions 15 fitting into the axle butt ends.

To prevent trunnions 15 from coming out of the half-axles when the front wheels are abruptly turned, the trunnions are held in place by strainer 14. When the tow-bar is connected to aircraft assembly A, hinge 12 and retainer 13 are provided.

Movable strap 10 with coupling bolt 11 is designed for raising the bogey tyres prior to towing the aircraft and for lowering them when transporting the tow-bar itself.

The working surfaces of rod 2 and guide 17 are protected against dirt by tarpaulin boot 3. Tractor pull at the aircraft nose strut is limited by shear pin 9. The tow-bar is connected to the towing vehicle through the radius of eye 1 with a bolt.

The nose wheel control gear serves for changing the direction of aircraft movement when towing it wheel tail forward (Fig. 2). The control gear consists of tubular welded frame 3, two split straps 7 with trunnions 8 for gripping the extending ends of the nose wheel axle, and eye 1 for towing the control gear with the aid of a tractor. For manual turning of the nose wheels the control gear is furnished with tubular hand grips 2. Two wheels 6 are provided to ensure ease of transportation. With the control gear in the working position, trunnions 8 are

SECRET

NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

- 9 -

50X1-HUM

Table 1

Maximum Speed, Braking Time and Distance Values  
to Be Adhered to During Aircraft Towing

Aircraft load	Maximum towing speed, km/hr	Towing vehicle braking time (until stopped), sec.	Braking distance, m.
Maximum	10	5	9
Normal	10	4.5	8
No load	10	4	7

10. Whenever the tow-bar shock absorber is forced to its furthestmost positions due to an abrupt jerk or brake application, causing the shear pin to take up the impact, it is necessary to extract the shear pin from the tow-bar head and inspect it. The pin should be replaced by a new one if shearing is detected.

**CAUTION:** It is strictly prohibited to install a shear pin of a diameter larger than specified.

11. In the event both wheels of the main landing gear get into a pit, the aircraft should be pulled out by applying traction force to both of the main struts in turn. If only one of the main struts sinks, the aircraft should be pulled out by this strut.

12. In case the aircraft skids off the runway onto muddy ground while performing the landing run, it should be towed only after scraping off mud down to hard ground in order to provide tracks for the wheels.

13. Should it be necessary to slightly turn the aircraft, traction force must be applied to the outward strut in the direction of turn.

14. It should be always borne in mind that while turning the aircraft, both the nose and main landing gear struts have to withstand stresses; therefore, turning should be accomplished smoothly.

#### Preparing for Aircraft Towing

1. Make sure the external power sources are disconnected from the aircraft; see that the aircraft storage battery is cut off and the grounding wire with weight is removed into a special container within the nose strut compartment.
2. Make certain the nose wheel control button is depressed and locked by means of the safety thumb-piece.
3. Check pressure in the brake hydraulic system, which should be within 130-150 kg/sq.cm.
4. See that the aircraft is properly grounded. The grounding brushes on the main landing gear struts should touch the ground surface.
5. Check the towing gear for proper condition.
6. Make sure the aircraft parking brakes are released.

#### Towing Aircraft with Nose Forward

Aircraft towing with the nose forward (See Fig.1) is accomplished by the use of a tow-bar.

1. To attach the tow-bar to the aircraft:
1. Detach the tow-bar from the tractor and move it to the nose strut.
2. Remove strainer 14, release straps 15, extract trunnions 13 and fit them into the landing gear nose wheel axle.

connected to the extending ends of the nose wheel axles, and the control gear is drawn to seat 1 (See Fig.1) on the nose strut through special shock absorber 4. The shock absorber facilitates maintaining the control gear at a distance of about 1000 cm above the ground.

The towing cable is used to connect the towing vehicle to the aircraft, when towing the latter with the tail forward (See Fig.2).

When in the working position, the towing cable, as measured from the landing gear strut to the tractor towing yoke, is 24 m. long. Cable diameter is 19.5 mm.

Both branches of the cable are connected to the rigging units of the main landing gear struts by means of locking rigging brackets 9. Connection of the cable branches to the towing vehicle is accomplished through the use of towing jibs 11 and a load-carrying bolt. Each of the cable branches is fitted with uniformly spaced duralumin bosses 12 safeguarding the cable against damage, and clamps 10 serving to keep the cable suspended during aircraft towing.

#### General Instructions on Aircraft Towing

1. With fuel fully drained from the tanks, it is necessary that the nose portion of the aircraft be loaded with 400 to 450 kg ballast, to prevent the tail portion from dropping down.

The aircraft may be towed without any ballast in the nose portion, provided not less than 2000 lit. or 1000 lit. of fuel are contained in tanks No.6 or tank No.2 respectively.

2. Aircraft towing with the nose forward is performed with the aid of the tow-bar, whereas towing with the tail forward is accomplished by the use of the towing cable and the nose wheel control gear.

**CAUTION:** It is prohibited to move the aircraft with the tail forward by pushing the tow-bar, exclusive of the cases when the aircraft is positioned on the maintenance area or is moved to the hangar.

3. When towed by the nose strut along a concrete road, the aircraft may be loaded to any weight, whereas its weight should not exceed 65 t, if towed on hard rolled soil.

4. With the aircraft being towed, a pilot or a maintenance man should occupy the left pilot seat in order to apply brakes in the case of necessity.

5. The person in charge should be in front of the towing vehicle.

6. The direction of movement at starting should coincide with the direction of the nose wheels.

7. The aircraft should be towed smoothly, without abrupt jerks or stops. The aircraft brakes must not be applied during towing, except when the towing gear is ruptured, or when there is a danger of the aircraft hitting the towing vehicle due to inertia motion.

8. It is prohibited to pull the aircraft wheels out of pits or depressions by the nose strut.

9. The speed of aircraft towing on a straightway is not restricted and depends solely on the power of the towing vehicle, provided the way is free from any obstacles. However, if the aircraft is to be turned or the towing vehicle is to be abruptly braked or stopped during towing, the speed of towing, as well as braking time and distance should be as specified in Table 1.

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

3. Disconnect strap 8, and attach the swivel frame to trunnions 15.
4. Connect the tow-bar to the rigging fitting of the nose strut by means of hinges 12 and retainer 13.
5. Brace trunnions 17 with the help of the straps and install strainer 14. **Note:** Exercise care when connecting the tow-bar to the rigging fitting of the nose strut to avoid damage to the hydraulic actuator piping.
6. Couple the tow-bar to the tractor for which purpose release strap 10 and shift it along the tow-bar so as to allow the tyre of the adjustable bogey to be raised to a height of 60 cm or more (depending on the weight of the aircraft) above the surface of the ground or concrete runway.
7. Secure strap 10 on the tow-bar.
8. Take the chocks from under the landing gear wheels, take away the ladders and other ground equipment blocking the aircraft way.
9. Aircraft towing with the nose forward should be supervised by the following personnel: a technician walking in front of the tractor and responsible for the whole towing procedure, two maintenance men at the wing tips and one at the tail unit, responsible for the safety of movement, and one maintenance man occupying the left pilot seat whose function is to apply brakes in case of necessity. **Note:** Command **STOP** given by any of the supervising personnel should be carried out immediately.
10. After the aircraft has been brought to its destination, it is necessary either to place chocks under the landing gear wheels, or to apply parking brakes after the wheels have cooled down to the temperature of the surrounding air.
  - (a) Disconnect the tow-bar from the aircraft:
  - (1) Slacken strap 10 and lower bogey 8 until its tyres touch the ground. Then fasten strap 10 on the tow-bar.
  - (2) Disconnect the tow-bar from the towing vehicle.
  - (3) Detach the tow-bar from the nose strut rigging unit, for which purpose extract retainer 13.
  - (4) Release strainer 14, turn out the coupling bolts on straps 16, and remove them from trunnions 15. Move the tow-bar manually away from the aircraft; fasten the swivel frame on the tow-bar by means of strap 6.
  - (5) Remove trunnions 15 from the front wheel axle and fasten them on the tow-bar.
  - (6) Fit strainer 14 into the tow-bar trunnions and fasten them.
  - (7) Attach the tow-bar to the tractor.

Towing Aircraft with Tail Forward

Aircraft towing with the tail forward (See Fig.2) is accomplished with the aid of a cable, the movement being controlled by the nose wheel control gear.

To prevent the cable from getting under the wheels, both of its branches should be kept suspended making use of the hand grips. Care should be exercised when towing the aircraft, as abrupt straining of the cable may cause damage to the maintenance personnel.

To connect the cable and the control gear to the aircraft:

1. Pull the cable to the aircraft, connect its rigging brackets 9 to the rigging fittings of the main struts; secure the towing yoke to the tractor.
2. Attach the control gear to the nose strut; lift the free end of the gear by the hand grips, and fit shock absorber bracket 3 into the nose strut fork.
3. Take the chocks from under the wheels, take away the ladders and other ground equipment blocking the aircraft way.
4. After the aircraft is towed to and positioned on the designated area, it is

necessary either to place chocks under the landing gear wheels or to apply parking brakes after the wheels have cooled down to the temperature of the surrounding air. After that it is necessary to detach the cable and the control gear from the aircraft.

When the aircraft is towed with the tail forward the procedure should be supervised by the following personnel: a technician walking in front of the tractor and responsible for the whole operation, two maintenance men at the wing tips responsible for the safety of movement, three men at the control gear, two men at the cable, and one on the seat of the left pilot, his duty being to apply brakes, when required.

Directions on Towing Gear Operation and Maintenance

- When operating the towing gear:
1. See that:
    - (a) braces 5 (See Fig.1) are tight;
    - (b) all hinge and detachable joints are treated with lubricant **EMATEL-201** or **EX-30** and are free of any play;
    - (c) a pressure of 3.5 kg/cm<sup>2</sup> is maintained in the tow-bar tyres;
    - (d) the operating surface of the rod and the surface of its guide are always lubricated, and the operating surface of the rod guide is always protected with a cover.
  2. Do not allow guide 17 (See Fig.1) to be worn to a degree when a clearance of over 1 mm is formed between its end and rod 2.
  3. Once in two months treat the wheel bearings with lubricant **EX-30** or **EX-50**.
  4. Move the tow-bar on its own wheels with the swivel frame lifted and held against the tow-bar tube by the straps.
  5. Treat the trunnions fitted into the nose strut wheel axles with graphite lubricant.
  6. Keep the towing cable in a closed room or under a shed; treat it with lubricant **EMATEL-201**. Inspect the towing cable for defects at regular intervals; replace the cable if any of the strands are found to be ruptured.
  7. Once in every three months treat the nose wheel control gear axles and forks with lubricant **EX-30** or **EX-50**.
  8. When towing the aircraft, use the control gear with care to avoid abrupt turning of the landing gear nose wheels.
  9. Do not move the aircraft or turn the wheels by means of the control gear after the aircraft has been placed in position on the parking area.
  10. Keep the tow-bar in a closed room or under a shed.

2. AIRCRAFT COVERS (Fig.3)

Covers safeguard the aircraft and its equipment against dirt and sun rays. Individual covers are fitted on the following units and equipment:

1. Fuselage compartment 0-1 (up to frame No.12) and pressurized nose cabin.
2. Fuselage compartment 0-3 (between frames Nos 12 and 22).
3. Fuselage compartment 0-4 and engines (between frames Nos 22 and 36, and between frames Nos 36 and 50).
4. Aft portion of the fuselage (between frames Nos 50 and 64).
5. Pressurized rear cabin.
6. First detachable wing sections.
7. Second detachable wing sections.
8. Horizontal stabilizer.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

9. Main strut locks.  
 10. Main strut wheels.  
 11. Nose strut lock.  
 12. Nose wheels.  
 13. Pitot tube.  
 14. Barrels of movable cannons.  
 15. Engine nacelle air discharge shutters.

Ports for air supply into the fuel tank vent system, for engine breathing, and for ventilation of the pressurized rear cabin at low altitudes are closed on the ground by special plugs furnished with red warning flags.

**Note:** When closing the vent of the rear pressurized cabin, attach the plug cord to the tail "skid" (at its port side). Never pass the cord over the folded-dipole antenna of communication station PCP-701 to avoid damage to the surface layer of the antenna not protected with the covering.

The plugs for the above openings are tapered rods made of cotton lined with tarpaulin, attached to each of the plugs is a strap with a red flag. The strap allows quick removal of the plug without climbing up to the place of its installation in the aircraft. The red flag on the strap warns the maintenance personnel that the plug must be removed prior to starting the engine and preparing the aircraft for flight. Covers for Pitot tubes are made of tarpaulin and red warning flags are attached to them. Blanking covers for the air intake ducts and jet nozzles are made of duralumin and painted red. The air intake duct blanking cover conforms to the profile of the duct and has a rubber gasket along its contour to ensure a tight fit into the duct. For convenience's sake the blanking cover is furnished with two handles.

The jet nozzle blanking cover is circular in shape; it is provided with two handles and a cone fastened in the centre by means of rivets. The blanking covers should not be used for collecting fuel and oil sediment or for other non-specified purposes. The blanking covers should be kept clean; prior to be fitted into the engine the blanking covers must be wiped with dry clean cotton waste or cloth.

The turbo-starter blanking cover, when inserted in its proper place, is fitted with a duralumin casing. The blanking cover is painted red and has a handle for ease of installation and removal. It is secured to the engine nacelle by two bolts; its casing safeguards the starter exhaust pipe against foreign objects, and therefore must be fitted onto the turbo-starter blanking cover.

The cover for the engine cowling is essentially a duralumin shell lined with tarpaulin. The cover prevents dust, moisture, and foreign objects from getting under the engine cowling.

Aircraft fuselage covers are made of tarpaulin having flannel lining where it contacts canopy glass panels.

Covers for the wings are of silk cloth.

Covers for the landing gear wheels and struts are made of tarpaulin and are furnished with quick-fastening straps.

Covers for the cannons are made of tarpaulin impregnated with water-proof compound.

Prior to starting and accelerating the engines, the covers should be taken off the aircraft and the blanking covers removed from the engines.

When engine maintenance work is being performed in the front pressurized cabin on the ground, the automatic pilot handle should be fitted with a duralumin casing which is secured by two removable wing bolts. The casing has a flannel lining. The casing must be removed prior to flight.

The dome of remote-reading astro-compass AAE-B is covered on the ground with a protective metal casing.

The folded-dipole antennae of the aircraft are covered with special metal casings having flannel lining. The covers put on the aircraft should be properly tightened, for which purpose provision is made in the cover construction for rubber shock absorbers. The covers put on the aircraft are attached to one another by means of special hooks (See Fig.). Covers and tightening straps should not be allowed to become loose, as strong gusts of wind may cause flapping of a loose cover with resultant damage to the protective coating of the aircraft skin.

The covers must be clean and in good condition; particular attention should be directed to the cleanliness of the flannel lining. Covers removed from the aircraft should be kept in the container designed for storage of the ground equipment, or on racks. It is prohibited to drop the covers from the aircraft onto the ground or the concrete runway. Damp covers should be dried, torn ones must be repaired in due time.

**Procedure to Be Used in Putting Covers on Aircraft**

All fixtures and equipment employed for putting covers on and removing them from the aircraft must be kept clean and sound at all times. The covers should be put on the aircraft after its external surfaces are cleaned. Individual units of the aircraft should be covered in the following sequence:

1. Pitot tubes.
2. Cannon barrels.
3. Folded-dipole antennae.
4. Fuselage compartments G-2, G-3, front section of compartment G-4, and engine nacelles.
5. Fuselage compartment G-4 and rear pressurized cabin.
6. First detachable wing sections.
7. Second detachable wing sections.
8. Horizontal stabilizer.
9. Landing gear.

Prior to putting covers on the stabilizer and detachable wing sections, the rudder, elevator and ailerons should be locked and the landing flaps retracted. Never operate the control system after the covers have been put on the aircraft.

Due to large dimensions of the aircraft covers two to three maintenance men and ladders are required for each of the covers to be put on and tightened.

When covering the wing and stabilizer, the covers should be tightened along their edges prior to fastening the shock absorbers to ensure close fit of the cover to the aircraft surface. The landing gear wheels should be covered at all times. In sunny periods compartment G-2 must be protected with a silk cover, which prevents the organic glass from deterioration and allows checking of the units and instruments in the cabin.

To reduce the time required for covering the aircraft, the covers should be accurately rolled up so that they may be quickly spread out on the aircraft surfaces.

To this end, the covers of the detachable wing sections and tail unit should be taken off from the edges towards the centre; then they should be spread in the form of a single narrow band and rolled up proceeding from the fuselage towards the fairing. The flannel lining should be inside the roll.

Covering of compartment G-2 is performed by a crew of three: two of the maintenance men on service ladders smooth out and pull on the cover, while the third one supports the cover from above to prevent the rod antenna of radio-compass AFX-7 from being damaged.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 14 -

Covering of compartment 0-3 also requires three men; two of them (on service ladders) smooth out the cover on the fuselage and fasten the shock absorbers, while the third one works from above and attaches the cover to the cover of compartment 0-2 with the aid of metal hooks. Putting covers onto the front section of compartment 0-4 and onto the engine nacelles requires four men: one of them smooths out the cover on the fuselage and supports it, two of the maintenance men positioned so the engine nacelles smooth out the cover on the air intake, whereas the fourth one smooths out and fastens the shock absorbers from below.

Two men on ladders should be employed for putting the cover onto the rear portion of the fuselage, at the right and left sides, respectively. This cover is attached to the cover of compartment 0-4 with the aid of metal hooks; on the underside it is fastened by means of shock absorbers.

Covering of compartment 0-6 is carried out by three maintenance men: two of them smooth out and put on the cover, using ladders, whereas the third one (also perched on a ladder) attaches this cover to the fuselage cover by means of shock absorbers.

The stabilizer is covered by three men: two of them (on ladders) smooth out the cover, while the third (also on a ladder) fastens the shock absorbers on the underside.

Putting the cover on the wing is a job for three maintenance men: two of them smooth the cover from above and attach it to the fuselage cover, whereas the third one fastens the shock absorbers on the underside.

The landing gear wheels and struts are fitted with covers by a crew of two, the covers on the struts being fastened with the aid of special straps.

#### Operating Instructions

When putting the covers on or taking them off the aircraft, exercise care to avoid damage to the antistatics located on the stabilizer and the wing.

Covering of the aircraft in windy weather (with the wind above force 6) will call for more maintenance personnel. To prevent damage to the oxide film on the aircraft skin, use rubber or cloth mats and carpets, thoroughly clean the mats and carpets of dust, dirt, and oil.

Remove all stains and soot from the aircraft skin by using clean rags soaked in gasoline (containing no antiseptic) or in white spirit.

Aircraft glass panels should be wiped only with clean flannel.

#### 3. AIRCRAFT GROUNDING (Fig. 4)

##### General

During parking, taxiing, as well as in flight the metallic structures of the aircraft get charged with static electricity. If the aircraft structure is all bonded, collection and flow out of electric charges are not dangerous, as no spark discharges result.

In case the aircraft bonding is disturbed, that is, if individual sections of the aircraft are not reliably connected, there may arise conditions conducive for spark discharges between aircraft structural elements with different electric potential.

Besides, creating fire hazard where fuel vapours are present, such spark discharges interfere with operation of numerous radio equipments carried on the aircraft.

When the aircraft is being refueled, the fuel flowing along hoses gets

- 15 -

electrified due to friction. If the hose is not grounded, the static charge accumulated by the fuel (hose) may reach a magnitude sufficient for a spark discharge to take place. To prevent fire hazard in the course of aircraft refueling, it is necessary to ensure reliable grounding of the aircraft, the fuel dispensing gun and the refueling truck. A reliable electric contact between the fuel dispensing gun and the aircraft is of special importance. When such a contact is established, the static charge forced on the hose will pass into the aircraft structure and further into the ground.

An aircraft returning from the flight carries an electric charge of high potential. Cases are known when a person touching such an aircraft before it has been grounded was struck to death by the electric charge. To prevent such accidents, as well as to preclude the possibility of the aircraft catching fire due to a spark discharge likely to occur during refueling, the aircraft is provided with grounding equipment.

#### Grounding Equipment

This includes special wires (5 mm in diameter and 980 mm long) attached to each of the lower drives of the main landing gear bogeys with the aid of straps. Soldered to each of the wires is a 200 m. long cable, the free end of which has been unbraided to form a metal brush. During aircraft landing, towing, or parking the brushes of both cables are forced against the ground thereby eliminating the static electric charge built up on the aircraft. When on the maintenance area, the aircraft is also grounded with the aid of an electric cable connected to the aircraft structure. The cable terminates in a weight which is placed on the ground. Before flight the weights and electric cables are stored in special pockets located in the front pressurized cabin (at frame No. 12) and in the nose strut bay, at frame No. 14 (at port side, looking forward).

After the aircraft has been landed and taxied onto the taxiway, the navigator-radar operator should open the front pressurized cabin hatch door and drop down the grounding device. The ladder from an aircraft returning from a mission should not be lowered until the grounding device is dropped down.

It is prohibited to touch the aircraft which has returned from a mission, unless it is grounded.

The aircraft is furnished with special devices (antistatics) which allow static electricity to flow into the atmosphere during flight. The antistatics are arranged as follows:

- (a) on the fin (one);
- (b) on the stabilizer (two);
- (c) on the first detachable wing section (two);
- (d) on the second detachable wing section (four).

An antistatic is essentially a brush made of fine synthetic fibre treated with silver nitrate, impregnated with alcohol-glycerine mixture, and fitted into a tube fabricated of AlMn metal.

An antistatic protruding beyond the aircraft contours allows the charge to flow into the atmosphere.

#### Operating Instructions

To avoid emergency cases:

1. See that all antistatics are installed on the aircraft at all times and are charged with alcohol-glycerine mixture at regular intervals.
2. Check to see that the ends of the grounding brushes are always kept clean and in a position providing for their permanent contact with the ground irrespective of any possible variations in the aircraft load.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM



50X1-HUM

- 3. Check the cable and the weight for proper contact.
- 4. Make sure there is no oil under the brushes suspended from the main landing gear struts or under the grounding weight when they contact concrete or ground surface during aircraft parking.
- 5. Ground the refuelling truck and the fuel dispensing gun (Fig.5), when servicing the aircraft.

4. SECURING AIRCRAFT ON PARKING AREA

No provision has been made in the aircraft construction for any special fittings for securing the aircraft on the parking area. The aircraft is secured in a fixed position by means of chocks placed in front of and behind the main landing gear wheels. Should it become necessary, use may be made of the landing gear rigging fittings (to ensure more reliable fastening of the aircraft on the parking area).

Preparatory Operations

- To prepare the aircraft for parking:
  1. Place chocks in front of and behind the main landing gear wheels.
  2. Lock the aircraft controls, for which purpose move the locking handle on the horizontal panel of the left pilot forward until a characteristic click is produced; set the rudder and the ailerons in the neutral position, and shift the elevator control stick forward as far as it will go.
  3. Depress the pedals, manipulate the control wheel and the stick to make sure the aircraft controls are securely locked.
  4. Close the bomb bay doors, the HOGAS bay doors, the entrance hatches of the front and rear pressurized cabins, the entrance hatch of the rear non-pressurized cabin, the inspection and access panels.
  5. If the tanks contain no fuel, lead the front pressurized cabin (at frames Nos 3 and 6) with about 400 kg of ballast prior to putting covers on the aircraft.
  6. Remove service ladders.

Securing Aircraft

The aircraft secured on the parking area is diagrammed in Fig.6. Securing is accomplished with the aid of heavy rope. The aircraft parking area should be equipped with special metal rings securely imbedded in concrete and so arranged as to correspond to the position of the aircraft on the parking area as well as to the location of the attachment fittings on the aircraft.

**CAUTION:** Never secure the aircraft by its tail skid.

5. LIFTING AND LOWERING AIRCRAFT BY MEANS OF HYDRAULIC HOISTS

For checking the operation of the units controlling the retraction and extension of the landing gear, for carrying out cannon bore sighting, as well as for checking aircraft levelling, etc., the aircraft may be mounted on hydraulic hoists (Fig.7).

For lifting the aircraft with the aid of the hydraulic hoists, the following thrust points are provided:

- (a) two points in the lower section of the rear spar, at rib No.5 of the first detachable wing portion (at port and starboard sides). Prior to mounting the hydraulic hoists, the spar is fitted with thrust plates at these points (See Assy A);

- (b) end point in the tail portion of the fuselage, near the tail skid, under frame No.65 (See Assy F);
  - (c) one point in the front portion of the fuselage, under frame No.26. Aircraft lifting must be carried out on a concrete footing designed to withstand a specific pressure of not less than 7 kg/sq.cm.
- The hydraulic hoists may be employed for lifting an aircraft having not more than 23,000 lit. of fuel in the tanks, provided the speed of the head wind does not exceed 5 m/sec.
- The aircraft lifting procedure should be supervised by the chief technician.

Hydraulic Hoists  
(See Fig.7)

The following hydraulic hoists are employed for lifting the aircraft:  
1. Two hydraulic hoists 2 (32 t capacity each) fitted under the thrust plates in the rear spar of the first detachable wing portions.

- 2. Hydraulic hoist 3 (11 t capacity) fitted under frame No.65.
  - 3. Hydraulic hoist 1 (11 t capacity) fitted under frame No.26.
- Hydraulic hoist 2 fitted under the thrust plate in the rear spar of the wing consists of the following main parts:
- (a) hydraulic system;
  - (b) three posts;
  - (c) three bed plates with spherical supports;
  - (d) upper and lower links;
  - (e) front and rear wheels.

All main components are connected by means of bolts allowing hydraulic hoist disassembly for shipping purposes. Hoist assembly is facilitated by match numbers stamped on its detachable components. During assembly parts with identical numbers are assembled into units.

The hydraulic hoist power section (See Assy A) consists of the following main parts:

- (a) supporting head;
- (b) rod lead screw 4;
- (c) hoisting nut 5;
- (d) locking nut 7 with reversing mechanism;
- (e) rod and cylinder.

The hydraulic hoist operates in the following manner. With the aid of handles 6 and nut 5 lead screw 4 is driven out to the required height, but not over 400 cm, at which height the screw comes up against the stop. When the hydraulic fluid enters the cylinder, the rod goes up. It is retained in position by locking nut 7.

A clearance of 1.0 to 1.5 cm should be ensured between locking nut 7 and the thrust end face of the cylinder. The hydraulic hoist rod is forced down by a special reversing mechanism mounted on the locking nut. To bring the rod down, lower locking nut 7 until it rests against the cylinder, unlock screws 8 and turn them in as far as they will go, then rotate handles 6 counter-clockwise to bring the rod down. With the rod in the required position, set screws 8 in the initial position and lock them.

**Note:** Remove water and dirt, accumulating in the above-piston space, through the wash-out plugs.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

**Hoist Hydraulic System**  
(See Fig.7)

The hydraulic system of the hoist comprises:

- (a) power section;
- (b) pump 9;
- (c) reservoir 10 and safety valves.

Each of the hoists uses 12 lit. of hydraulic fluid AHF-10.

Pipe lines running from the pump to the reservoir and to the power section are made up of steel tubing.

The power section of the hoist is comprised of non-return valve 16, safety valve 15 and by-pass cock 17.

To lift the aircraft, screw cock 13 all the way out by turning it in the clockwise direction. As a result, cock 13 will open thereby allowing hydraulic fluid from the reservoir to be directed via the filter to the pump, whence it will be carried to the power section cylinder via the pipe line and non-return valve 16.

To lower the aircraft, slowly turn out cock 17, thereby opening it and connecting the cylinder with the return line; as a result, the hydraulic fluid will flow directly into the reservoir. The rate of aircraft lowering is controlled by cock 17. Should it become necessary to discontinue aircraft lowering, quickly turn cock 17 all the way in.

**Hoist Posts**  
(See Fig.7)

The hoist posts have spherical supports at their ends allowing the power section to be set vertically with the aid of a plumb. The position of the power section is adjusted by rotating the spherical support with the help of handle 20.

The spherical supports are hinged to the bed plates.

When the hoist is transported assembled, the bed plates are retained in the horizontal position by bolts 21 or by carriers. The hoist is mounted on three wheels. The front wheel mounted on a special truss is steerable. The fork of this wheel carries tow-bar 2) serving for connection of the hoist to a truck or to another hoist during shipment.

The two rear wheels of the hoist are mounted on a common bar.

Hoist 3 fitted under frame No. 66 differs from hoist 2 by its load-carrying capacity and in that it has a movable supporting head (See Assy E).

To prevent hoist 3 from overturning during aircraft lifting, its power section is furnished with a movable supporting head arranged in the aircraft longitudinal axis.

Hydraulic hoist 1 fitted under frame No.26 serves as a safety support during aircraft lifting. This hoist differs from hoist 3 in that it has axial support 24 instead of the head.

Hoists 1 and 3 are served with 10 lit. of hydraulic fluid AHF-10 each.

Technical data of the hydraulic hoists are presented in Table 2.

Table 2

Technical Data of Hydraulic Hoists Used for Lifting Aircraft

Technical data	Place of installation		
	Thrust plates on wing rear spar (See Fig.7, Ref.No.2)	Frame No.66 (See Fig.7, Ref.No.3)	Frame No.26 (See Fig.7, Ref.No.1)
Load-carrying capacity, kg	32,000	11,000	11,000
Minimum height of hoist, mm	2300	1800	1900
Maximum height of hoist, mm	3350	2980	2680
Screw travel, mm	400	230	230
Power cylinder rod travel, mm	650	950	950
Pressure of bed plates (450 mm in diameter) on ground when lifting fully loaded aircraft, kg/sq.cm.	6.5	4	4
Cylinder displacement, lit.	10.7	8	8
Reservoir capacity, lit.	13.3	10.3	10.3
Pressure in cylinder at maximum weight of aircraft, kg/sq.cm.	200	140	140
Effort on pump handle when lifting aircraft with rated load, kg	20	20	20
Weight of hoist, kg	~600	~400	~410
Number of hoists in set per 1 aircraft	2	1	1

**Preparation for Aircraft Lifting**

1. Set all switches in the OFF (BERRADPHERO) position.
2. Release the parking brakes and make sure the landing gear wheels are free.
3. In case landing gear operation is to be checked, see that the torsion links of the main landing gear struts do not carry screw clamps (Fig.8).
- Note.** If aircraft lifting is not connected with adjustment of the mechanisms controlling landing gear operation, the screw clamps may be left in position on the struts so as to decrease height of the aircraft lift.
4. Install the thrust plates on the rear spar, at rib No.5, for the main hoists (See Fig.7, Ref. No.2).
5. Make certain that the aircraft is properly grounded, and that the grounding wire is long enough to ensure a proper contact between the weight and the ground after the aircraft has been lifted.
6. In winter, clean the thrust plates of ice and snow.
7. Check to see that the holes in the spherical support adjusting screw necks are not clogged with dirt, which may affect vertical adjustment of the hoists.
8. Make sure the hydraulic hoists are in good repair by checking the reservoirs for the presence of hydraulic fluid, the joints for tightness, and the bed plates for proper attachment to the spherical support covers. Eliminate the defects detected.
9. Check the hoists for proper operation, for which purpose close by-pass cock 17 (See Fig.7) and swing the pump handle several times, making sure the hoist rod goes up.
10. Take the checks from under the wheels, remove the services ladders and other ground equipment which may interfere with the aircraft lifting.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 20 -

Mounting Hoists

Prior to lifting the hoists under the thrust points of the aircraft, proceed as follows:

1. Fully extend the hoist wheels.
2. Bring the hoists under the thrust points of the aircraft. Lower the hoists onto the bed plates, for which purpose bring their wheels to the extreme upper position.

**CAUTION:** Never start lifting the aircraft with the hoists positioned on the wheels.

3. Remove the casing from the hoist heads.
4. By rotating the lead screws of the hoists to be fitted under the wing rear spar and under frame No.66, bring the hoist rods up until they rest against the spherical surfaces of the thrust plates installed on the aircraft. Lift the support of the hoist to be fitted under frame No.26 until there is a clearance of 10 to 15 mm (See Fig.7, Ref. No.24) between the support surface and the aircraft skin.
5. Operate the pumps, and after making sure that the hoists are properly fitted under the respective thrust points of the aircraft, proceed adjusting the vertical position of the hoists, making use of the lower spherical support screws and the plumbs suspended from the hoists.

Lifting Aircraft

1. On command of the technician in charge of the lifting procedure, start bringing up the rods of the two main and the tail hoists; see that the rod of the tail hoist goes up at the same rate as the other two, to avoid imposing a too heavy load on the tail hoist.

2. When lifting the aircraft with the aid of two main and one tail hoists, the rod of the hoist fitted under frame No.26 should be extended in a manner allowing a 10 to 15 mm clearance to be always provided between the aircraft skin and the hoist support surface. This hoist serves as a safety device preventing the aircraft from tipping with its nose forward, therefore no load should be imposed on it during aircraft lifting.

The lifting procedure completed, the rod of the hoist fitted under frame No.26 will be taken up so that its support should closely contact the frame.

3. As the aircraft is being lifted, it is necessary to always shift the hoist locking nut down the rod, thereby keeping the rod all the time in the locked position to prevent it from coming down in case of hydraulic system failure. After the lifting procedure is completed, relieve the hoist hydraulic system.

4. If the landing gear is not to be extended or retracted, the aircraft should be lifted to a height ensuring a 50-mm clearance between the wheel tyres and the ground. In case the landing gear is to be checked, the clearance should amount to 100 mm. For the main landing gear bogey this clearance will be determined by the position of the front wheel couple, as the rear wheels are lifted higher than the front ones due to the action of the stabilizing shock absorber.

5. Having lifted the aircraft, check all hoists for proper locking.

Lowering Aircraft

(See Fig.7)

1. Make sure the service ladders and other equipment lying under the aircraft or near it do not interfere with aircraft lowering. Unlock the hoist rods, for which purpose take up the locking nuts.
2. Open by-pass cock 17 in the hoist fitted under frame No.26, and bring down the hoist rod together with aerial support 24.

- 21 -

Then mount the hoist onto the wheels and move it from under the aircraft.

3. On command of the technician in charge, start lowering the aircraft. To this end first open by-pass cocks 17 installed in the hoists fitted under the rear spar of the first detachable wing portion, at rib No.3. By-pass cock 17 in the hoist fitted under frame No.66 should be open only after the nose strut wheels touch the ground. From this moment on, aircraft lowering is accomplished with the aid of the three hoists.

**CAUTION:** If the above sequence of operations is not observed, simultaneous lowering of the rods in all of the three hoists before the nose strut wheels touch the ground may cause damage to aircraft skin at frame No.46.

4. After the hoist heads lose contact with the thrust points of the aircraft (a clearance is formed), fit the checks under the aircraft wheels and bring the hoist rods and screws all the way down.

If the rod is in the extreme lower position but the hoist head is still in contact with the aircraft thrust point, rotate hoist handle 6 counter-clockwise to take the hoist head down.

5. Mount the hoists on their wheels and move them from under the aircraft.
6. Cover the upper parts of the hoists with casings.
7. Remove thrust plates from the wing rear spar.

Operating and Maintenance Instructions

1. When lifting the aircraft with the purpose of checking operation of the landing gear control mechanism direct particular attention to the position of the serving supporting head of the hoist fitted under frame No.66, since careless installation of the hoist may lead to the tail skid hitting the hoist head with resultant damage to the electric mechanism.

2. When lifting the aircraft for removing the main landing gear wheels, fit the hoists under the wing rear spars in a manner allowing easy removal of the wheels.

3. When checking the mechanisms controlling landing gear extension and retraction, put the weight and the aircraft grounding wire into a special pocket, arranged in the nose strut bay, and drop down the grounding device from the cabin of compartment 0-2.

4. Keep the hoists clean.
5. Fill the hoists only with hydraulic fluid AMT-10.
6. Pour hydraulic fluid AMT-10 into the hoist reservoir, with the power cylinder rod depressed; see that the fluid does not contain any foreign matter capable of clogging the filter.

The minimum and maximum levels of the fluid in the reservoir are checked with the aid of a gauge rod attached to the filler plug.

7. It is recommended to check the condition of the hoist packing rings at six months' intervals.

8. Treat all threaded and rubbing surfaces with UNATEM-201 lubricant at regular intervals.

9. The hoist surfaces having no protective paint coating should be periodically coated with petrolatum.

10. During prolonged idle periods the face of the hoist power cylinder should be lubricated once a month, for which purpose the rod should be brought in the upper position after inserting 25 cu.cm. of hydraulic fluid AMT-10 into the cylinder (through the wash-out plugs).

11. Prior to moving the hoists from the storage area to the aircraft, first lubricate their rods and then bring them down.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 22 -

12. Water and dirt accumulating in the above-platen space of the hoist should be periodically discharged through the wash-out plugs.
13. The hoists should be transported about the airfield only on the wheels, with the bed plates locked.
14. Prior to fitting the hoist under the aircraft:
  - (a) use the red gauge to check that the reservoir contains the required amount of hydraulic fluid;
  - (b) check to see that the hoist operates properly, for which purpose rock the pump handle several times watching the rod to go up;
  - (c) manipulate the screws of the spherical supports to set the hoist in the vertical position, checking it against the plumb.
15. With the aircraft being lifted, the hoist must bear against its bed plates.
16. No leakage of hydraulic fluid is allowed in any of the hoist joints. Tighten up the joints if leakage has been detected.
17. The hoist may be transported only when it is in the vertical position. Should it be necessary to transport the hoist in an inclined or horizontal position, the hydraulic fluid should be first drained out.
18. If handles 6 (See Fig.7) seize during hoist head lowering, never try to overcome the difficulty by knocking on the handles to avoid their breakage.
19. See that the protective covers and the threaded portion of the hoist support are in good condition.
20. Close reservoir shut-off cock 13 (See Fig.7) when the hoist is inoperative.

#### 6. POSITIONING AIRCRAFT IN LINE OF FLIGHT

- The aircraft is positioned in the line of flight on the following occasions:
- (a) for checking the aircraft levelling data against the certificate;
  - (b) for gun bore sighting;
- Note:** The levelling points designed for gun bore sighting are marked with red spots encircled by blue bands.
- (c) for installing gyro-horizon AFD-2, turn indicator 37D-46, the instrument panels of both pilots, and Pitot tube TD-156;
  - (d) for weighing the aircraft.

The aircraft is positioned in the line of flight according to the levelling points provided on its units. The levelling points of the fuselage are arranged in the horizontal plane passing through the horizontal reference line of the aircraft. The levelling points are 3-cm diameter holes made on the fuselage sides and marked with 20-cm dia. red spots. Apart from these points, the fuselage underside has holes with threaded hex.7; the holes are arranged in the aircraft symmetry plane and are designed to receive the shackles of the plumb string. These holes are likewise marked with 20-cm dia. spots. The levelling points on the wing and the empennage are punched and marked with 20-cm dia. red spots. The linear dimensions determining the position of the levelling points of the wing and the empennage are so given as to take allowance for the deflection resulting from the weight of the construction of the aircraft mounted on three hydraulic hoists. Positioning of the aircraft in the line of flight should be accomplished in a closed building. The levelling data are checked on the aircraft carrying no crew, fuel or ammunition, and with the landing gear extended.

Placing the aircraft mounted on the hoists in the line of flight in field conditions is not allowed if the speed of the wind exceeds 5 m/sec.

#### Preparatory Operations and Equipment

1. Use four hydraulic hoists to lift the aircraft to a height allowing a clearance of not less than 30 cm to be provided between the wheel tyres and the ground.
  2. Position the tripod for the levelling instrument to the left or to the right of the aircraft in the vicinity of frame No.12. at a distance of 6 to 7 m. from its longitudinal axis, or in the vicinity of frame No.37 at a distance of 5 to 6 m.
- Having mounted the levelling instrument onto the tripod plate, fasten it with the check screw and then set it in the horizontal position, making use of the level. For checking horizontal adjustment of the levelling instrument, it is turned three times in succession through 120°; the levelling instrument tube should be moved to a new position smoothly to avoid disturbing the level adjustment.
3. Check the condition of the levelling pole. This pole carries a swivel head with a pointed stud and a clamping screw at one end and a plumb at the other. Depending on the height of a particular levelling point, the levelling pole length may be adjusted after loosening the clamping screws. When checking the levelling data of the aircraft the levelling pole should be held in a position allowing the stud point to enter the levelling point hole, while the pole proper must be set vertically (according to the plumb).

#### Longitudinal Positioning of Aircraft in Line

##### of Flight

(Fig.9)

Longitudinal positioning of the aircraft in the line of flight (so that the horizontal reference line comes to be arranged in the horizontal plane) is performed relative to points 30 and 31 on the fuselage surface (at frames Nos 21 and 55). by adjusting the height of the hydraulic hoist fitted under frame No.66.

**Note:** The position of points 29 and 32 relative to the horizontal plane should be measured with the aid of the levelling instrument when checking the aircraft levelling data; points 33, 34, and 35 should be measured when performing gun bore sighting.

#### Transverse Positioning of Aircraft

##### in Line of Flight

(See Fig.9)

Transverse positioning of the aircraft in the line of flight is carried out relative to points 10 and 10' by adjusting the height of the left-hand and right-hand hoists fitted under the respective detachable wing portions, where the rear spar axis crosses the axis of rib No.9. The aircraft position is checked against points 30 and 31 (located at the aircraft sides). The respective positions of these points relative to the horizontal plane must not differ by more than 2 cm. Levelling points 10 and 10' are located in the lower zones of the rear spar of the first detachable wing portions, on the axes of ribs No.4.

**Note:** When carrying out transverse positioning of the aircraft in the line of flight, it is necessary to remove the swivel head from the levelling pole.

Adjustment of the aircraft position with the aid of the hoists should be performed in a smooth manner.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

7. AIRCRAFT LEVELLING  
(See Fig. 9)

Checking the relative position of the airframe units by the levelling points is known as aircraft levelling. The procedure consists of the following two operations: checking the relative positions of the levelling points (as to their height) with the aid of the levelling instrument, and checking symmetry of some of the levelling points projected onto a horizontal surface (on the hangar floor, on the runway or on some concrete ground) with the help of plumbs and a measuring tape. Levelling is carried out only after positioning the aircraft in the line of flight.

The actual results obtained in measuring the relative positions of the levelling points should be within the values presented in the levelling data of each aircraft. These data are usually given on a special blue print which represents the main document to be consulted when checking the aircraft levelling data.

When levelling the aircraft, check the following:

1. Position of points 29 (29') and 32 (32') on the fuselage.  
Permissible displacement of points 29 (29') relative to points 30 and 31 should be within -10<sup>±</sup> mm, and points 32 (32') - within -26<sup>±</sup>10 mm.

2. Angle of setting and transverse position of the wing.

The angle of wing setting is determined by the elevation of levelling points 11, 14 and 16 on the wing rear spar over points 11, 13, 15 and 17 on the front spar, respectively. These data (in linear measurements) are given in Table 3.

Table 3  
Levelling Data Determining Angle of Wing Setting

Point Nos according to Fig. 9	Rib No. according to Fig. 9	Elevation, mm	Allowance, mm	Permissible difference between elevations between right and left wings, mm
10-11	4	0	26.5	8.5
12-13 <sup>2</sup>	7	25	27	7
9-13 <sup>2</sup>	7	12	27	7
14-15	13	21	25	6
16-17	24	15	24	4

Note: Column 3 contains elevation values of points 10, 12, 9, 14, and 16 over points 11, 13, 15 and 17 for the left and right wing respectively.

The transverse position of the wing is determined by lowering of points 9, 14 and 16 relative to point 10. The lowering values of these points (in linear measurements) are given in Table 4.

Table 4  
Levelling Data Determining Transverse Position of Wing

Point Nos according to Fig. 9	Rib No. according to Fig. 9	Lowering, mm	Allowance, mm	Permissible difference between lowering values for right and left wings, mm
10-10	7	24.5	23	3
9-10	7	37.3	24	4
14-10	13	236	28.5	8.5
16-10	24	575	217	17

Note: Column 3 contains the lowering values of points 12, 9, 14 and 16 relative to point 10 for the left and right wings.

3. Angle of setting and transverse position of the stabilizer.

The angle of stabilizer setting is determined by the elevation of points 21 and 23 on the rear spar over points 22 and 24 on the front spar respectively. These data (in linear measurements) are given in Table 5.

The transverse position of the stabilizer is determined by the elevation of point 23 over point 21, which should amount to 141<sup>±</sup>18 mm. The difference in actual elevation values for the right and left sides of the stabilizer should not exceed 18 mm.

Table 5  
Levelling Data Determining Angle of Stabilizer Setting

Point Nos according to Fig. 9	Rib No. according to Fig. 9	Elevation, mm	Allowance, mm	Permissible difference between elevation values for stabilizer right and left sides, mm
21-22	4	48.5	±4	4
23-24	14	25	±2	2

Note: Column 3 contains the elevation values of points 21 and 23 over points 22 and 24 respectively.

The aircraft units are checked for symmetrical position relative to the longitudinal axis after checking relative positions of the levelling points by height. The aircraft symmetry axis is represented by the straight line assumingly drawn between the plumbs suspended from points 1 and 2; points 0 and 3 should not deflect from the axis by more than 2 mm. Projections of the levelling points onto the horizontal plane, when checking the aircraft units for symmetrical arrangement, are determined with the aid of plumbs suspended from these points.

After laying out the aircraft axis of symmetry on the floor, the following should be checked:

1. Difference in distances A between points 3 and 16 projected on the floor to the right and to the left of the aircraft. This difference should not exceed 20 mm.
2. Difference in distances B between points 3 and 12 projected on the floor to the right and to the left of the aircraft. This difference must not exceed 15 mm.
3. Difference in distances C between points 3 and 23 projected on the floor to the right and to the left of the aircraft. This difference should not exceed 10 mm.
4. Difference in distances D between points 25 and 26 to the right and to the left of the aircraft. This difference should not exceed 20 mm.

Note: Point 26 is located at the end fairing of the fin; point 25 - on the stabilizer external skin at the intersection of the rear spar and rib No. 14.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 26 -

6. GROUND EQUIPMENT FOR SUPPLYING AIRCRAFT  
WITH FUEL, OIL, OXYGEN, COMPRESSED AIR AND POWER

Servicing the aircraft on the parking area or preparing it for flight involves filling its tanks with fuel and oil, charging the aircraft systems with hydraulic fluid AMN-10, air and oxygen, as well as supplying it with power from the ground sources.

Servicing the aircraft with fuel is performed by employing refuelling trucks, which deliver fuel through ten service tank fillers in the following sequence:

- Tank group V (service tank No.6, left and right);
- Tank group IV (service tank No.16, left and right);
- Tank group III (service tank No.10, left and right);
- Tank group II (service tanks Nos 4 and 3);
- Tank group I (service tanks Nos 2 and 5).

The amount of fuel delivered into a group of tanks is checked with the help of filler floats (See Fig.5).

Fuel delivery into the tanks of groups I, III, IV and V is effected via eight filler floats (two floats for each of the tank groups).

Tanks of group II: tank No.3 is furnished with a mechanical fuel level indicator mounted on the tank proper, whereas tank No.4 is filled through the front of tank group V. When the aircraft is serviced with fuel, the filler floats are inserted into the fillers of the tanks of the respective group. Each of the floats bears the number of the respective tank group stamped upon it and has a scale with three divisions, painted dark-green, yellow, and red. The dark-green colour denotes that the tank is empty, the yellow colour means that the tank is filled with fuel, and the red colour warns that the tanks are overfilled and that the fuel has entered the aircraft vent system. The floats should be always kept clean and stored in a row on special hooks.

Do not knock on the float body.

To accelerate aircraft refuelling, fuel may be delivered by two, three, or four refuelling trucks at the same time, with the above sequence of tank group filling duly observed. In case of urgent necessity, any order of tank filling is allowed, provided a hoist is fitted under frame No.66 to prevent the aircraft from pitching onto the tail skid due to displacement of the centre of gravity.

The fuel dispensing guns should incorporate filters with gauge No.0063 (8270 meshes per 1 sq.cm.). If the float pointer binds during fuel delivery into the tank, shift the pointer towards the green division. After the aircraft refuelling procedure is completed the tank fillers should be securely closed. For this, fit the plug into the tank filler and press it in the centre: marked with the word HAKHII (PRESS) thereby sinking the plug flush with the skin.

See that the sealing rubber on the filler plug is intact.

Filling of the tanks incorporated in the system of engine lubrication, turbo-starter starting, the main and emergency hydraulic systems is performed by a special servicing truck. The truck carries three tanks, not less than 100 lit. capacity each:

- (a) for starting fuel;
- (b) for hydraulic fluid AMN-10;
- (c) for MK-8 or transformer oil.

Each of the above tanks has a filler hose with a dispensing gun and a filter (gauge having 8270 meshes per 1 sq.cm.). Delivery of starting fuel, hydraulic fluid AMN-10, oil MK-8, or transformer oil into the aircraft tanks is effected with the aid of a hand pump. In case no special servicing truck is available,

the above systems are serviced with the help of a measuring bucket and a funnel with a gauge (8270 meshes per 1 sq.cm.).

Charging of the aircraft with liquid oxygen is accomplished by the use of a standard servicing truck carrying liquid oxygen, or Dewar flasks and a charging pipe. The charging pipe carries at its ends special attachment fittings with sealings for connection to the standard servicing truck and to the aircraft pipe union (at frame No.13, starboard).

For ease of transportation and stowage the pipe is split into two parts, the ends of each part being closed with plugs supplied with the pipe.

For charging the aircraft air system with compressed air a special cylinder bank is employed, comprising 3 to 5 compressed air cylinders, carried on a four-wheel cart (or on a truck) and mounted on two wooden supports (Fig.10). The cylinders are furnished with a common manifold and a pressure gauge for 150 kg/sq.cm. To prevent condensation in the cylinders from finding its way into the aircraft air system, the cylinders are mounted on the supports at an angle of 15 to 20°. Compressed air from the cylinder bank is fed into the aircraft air system via a flexible charging hose. The hose is connected to the pipe union of the aircraft air panel located at the left engine only after it has been blown with air.

When charging the air system, pressure is checked by the readings of the pressure gauge mounted on the cylinder bank hose. After the aircraft system has been charged to the required pressure, close the valves on the air panel of the left engine and on the cylinder bank manifold, loosen the union nut holding the hose to the manifold, bleed pressure from the charging hose and then detach the latter from the air panel of the left engine.

**CAUTION:** Do not detach the charging hose from the left engine air panel, unless air has been bled from the former.

In case a cylinder bank is not available, charge the aircraft with compressed air by employing compressed air cylinders arranged at an angle of 15 to 20°. Do not allow pressure in the cylinder bank or in individual compressed air cylinders to drop below 10 kg/sq.cm.

Prior to transporting the compressed air cylinders to the aircraft, fit them with safety rubber rings to safeguard the cylinders against bumps. Compressed air cylinders should be stowed on racks under a tent.

The cylinder bank is also employed for charging the wheel tubes, the stabilising shock absorber, and the landing gear shock absorbers. Prior to charging the wheel tubes, remove the nut holding the hose to the left engine air panel and install the wheel tube charger in its place (Fig.11).

**Note:** The charging hoses should be always kept clean. Do not twist the hoses or dent the facets of their union nuts. Careless handling of the charging hose will usually result in failure of the reference pressure gauge.

Power is delivered to the aircraft from a D.C., 27.5 - 28 V, 17-kW source. Each of the aircraft has a box for connection of the ground power source to the aircraft main and a set of cables. The cables and the box allow connection of one or two aircraft to the ground power source. The box has receptacles for connection of inspection lamps, solders, etc. To safeguard the box terminals against short circuits which are likely to occur due to moisture and dust, the box should be protected with a tarpaulin tent attached to a rigid frame.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 28 -

## 9. AUXILIARY EQUIPMENT

Hydraulic Jack for Replacement of LandingGear Wheels

The equipment designed for replacement of the landing gear wheels includes two hydraulic jacks, a rigging fitting and bolts for its attachment. For replacement of the nose wheel the hydraulic jack is fitted under the leg on the nose strut (Fig.12); to prevent the aircraft from rolling back chocks are fitted under the main landing gear wheels. With the aid of the hydraulic jack, the nose strut is brought to a height allowing wheel replacement to be carried out. For replacement of the main landing gear wheels, mounted on the front axle of the bogey, the jack is fitted under the special lug in the lower part of the bogey; in case the wheels mounted on the rear axle of the bogey are to be replaced, the jack should be fitted under the rigging fitting which is installed on the aircraft towing bracket (Fig.13) and is held in place by bolts. Having replaced the wheels, remove the rigging fitting and turn the bolts into the bracket holes.

Hydraulic jack data are as follows: capacity - 20,000 kg; minimum height - 290 mm; maximum height - 545 mm; operating pressure - 320 kg/sq.cm.

The pump of the jack (See Fig.12) is operated by means of cast rocker 1. The upper part of the rocker mounts handle 2, the lower part accommodates the axle and two spindles with rollers which actuate the jack pump plungers as handle 2 is being shifted in either position. The rocker has a removable axle with a lock.

Handle 2 is retained in the rocker recess by a pin with a lock. The jack pump operates as follows. When rocker 1 is displaced, one of the pump plungers forces the operating fluid into the power section of the jack, whereas the other plunger draws the fluid from the reservoir (See Fig.12).

While the plunger comes down, the operating fluid is forced through valve 9 into the pressure line and further into the power cylinder whose rod lifts the aircraft. Simultaneously, the space under the other plunger is filled with the operating fluid supplied from reservoir 4 via valve 3. When pressure comes to exceed 340 kg/sq.cm., safety valve 6 opens thereby bleeding excessive pressure into the suction line. The return travel of the power cylinder rod depends on the action of by-pass cock 10, which by-passes the operating fluid from the inner into the outer cylinder, when the aircraft is being lowered. As knob 8 of cock 10 is being turned in, ball 9 compresses spring 7 and opens the by-pass valve. Through the opening formed between the ball and the knob rod, oil from the inner reservoir flows via the duct into the outer reservoir, thereby allowing the rod to come to the lower position.

The jacks and the rigging fitting are stowed in a container.

When not in use, the jack should be covered with a hood to protect the power section from dust and sand.

Operating fluid (hydraulic fluid AM-10) is poured into the reservoir through a funnel with filtering gauze.

Engine Servicing Ladder

(Fig.14)

The servicing ladder is a collapsible metal structure. Its foot platform is mounted at a height of 3029 mm. The ladder hand rails are laid with rubber where the ladder is likely to contact the aircraft skin. Located under the foot platform is a special box for storage of soft footwear to be used when performing some operations on the aircraft skin. The servicing ladder is mounted on two wheels and

- 29 -

two supporting cones preventing the ladder from spontaneous rolling. The ladder is furnished with a scraper and brushes for cleaning shoes prior to climbing up.

Stabilizer Servicing Ladder

(Fig.15)

Apart from its direct purpose the ladder may also be employed for servicing the tail mount.

The foot platform of the servicing ladder is located at a height of 3300 mm; the height of the ladder complete with the hinged portion amounts to 3630 mm. For servicing the stabilizer on the underside hinge off ladder 4 and bring the servicing ladder under the stabilizer; then lift wheels 8 by means of screws 9 and set front upright 3 onto the supporting cones.

The servicing ladder can carry not more than three men at a time. To reach to the upper part of the stabilizer hinged ladder 4 should be set in the upper position, for which purpose:

- release the retainers of strut 5 in the lower part of ladder 1;
- set hooks 7 of strut 5 on the tube of front upright 3 and operate winch 10 to lift hinged ladder 4 to the upper position;
- lock the hinged ladder support on front upright 3.

Having adjusted hinged ladder 4, bring the servicing ladder to the stabilizer so that the upper part of the hinged ladder laid with canvas comes in contact with the stabilizer tip.

Then set upright 3 on the supporting cones.

Hinged ladder 4 can accommodate only one person.

Note: For ease of transportation, the servicing ladder can be readily disassembled; all its component parts are marked. The marking should be restored whenever it is found to be damaged.

On the aircraft parking ground the servicing ladder is transported by two men; the ladder should be mounted on four wheels, the trailing wheels being stival cones.

Over longer distances the servicing ladder is transported in a truck.

Storage and Care of Auxiliary Equipment

All auxiliary equipment employed for aircraft servicing should be kept in a closed building. All threaded joints and moving parts should be treated with UNATHM-201 or KB lubricant at regular intervals.

When using the servicing ladders, check the condition of the supporting cones, which should be properly sharpened, especially in winter time.

Slings

The aircraft ground equipment includes 13 sets of slings which, according to the list of the ground equipment following below, are designed for handling individual units of the aircraft. The slings allow an individual unit of the aircraft to be suspended in a manner most convenient for work or to be moved over short distances. The cables in a sling set are so arranged that the lift resultant passes through the centre of gravity of the aircraft unit, thereby causing the latter to occupy a definite position.

In some slings the cables are furnished with spacers manufactured in the form of bars or tubular welded triangles.

A sling set consists of the following component parts:

- A shackle for suspending the sling from the hook of a truck-mounted crane;

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 30 -

- 31 -

## 2. One or several cables and spacers.

## J. A fastening device or a grip.

Each sling set has a tag carrying instructions on the use of the given sling and the No. of the drawing according to which it has been manufactured.

Fig.16 illustrates arrangement of slings on individual units of the aircraft. Places for attachment of the sling lifting eyes on the surface of the detachable sections of the wing, fin, stabilizer, elevators, and rudder are marked with black rings, 20x30 mm in size.

When installing lifting eyes, see that the respective places on the surfaces of the unit in question are protected with glass rubber pads, safeguarding the skin against damage.

Do not employ slings for handling loads other than specified.

Should it be necessary to adjust the length of the sling cables with the aid of turnbuckles to make possible removal and installation of the engine, see that the ends of the bolts do not project beyond the check holes in the turnbuckle bushings.

The slings should be kept in a closed building; their cables should be treated with MRAYM-201 lubricant. Inspect slings for condition whenever using them and at regular intervals. In case of worn or ruptured strings in cables, dented or stripped threads on bolts, etc., recondition the parts or replace them by new ones if damaged beyond repair.

## 10. LIST OF GROUND EQUIPMENT EMPLOYED IN AIRCRAFT SERVICING

No.	Description	Drawing No.
<b>I. HOISTING DEVICES</b>		
1	Hydraulic hoist fitted under frame No.26	H9901-10
2	Hydraulic hoist fitted under frame No.66	H9904-10
3	Hydraulic hoist fitted under first detachable wing section	H9910-0
4	Hydraulic jack for replacement of wheels	H9942-40
5	Slings for engines	H9960-14
6	Slings for turbo-starter	H9960-39
7	Slings for detachable wing section with lifting eyes H9920-250, -251, -252, -253	H9920-89
8	Slings for stabilizer with lifting eyes H9931-102, -103	H9931-100
9	Slings for fin with lifting eyes H9934-1, -3	H9934-0
10	Slings for ailerons with lifting eyes H9933-4	H9933-0
11	Slings for landing flaps of detachable wing section with lifting eyes H9920-32, -34	H9920-31
12	Slings for rudder with lifting eyes H9933-31, -32	H9933-30
13	Slings for elevator with lifting eyes H9932-1, -2, -8	H9932-0
<b>II. AUXILIARY EQUIPMENT</b>		
<b>A. Air and Hydraulic Systems Service Equipment</b>		
14	Wheel tube charger	H9941-31
15	Wheel tube pressure gauge	H9941-41

16	Brake system pressure gauge	H9941-110
17	Flexible hose for charging air system (Fig.17)	H9941-5
18	Landing gear shock strut charger-and-pressure gauge	H9941-48
19	Charging pipe union for item H9941-5	H9904-210
20	Third damper replenishment unit (Fig.18)	H9842-0
21	Installation for flushing brake system with hydraulic fluid (Fig.19)	H9956-150
22	Track-counted hydraulic test unit (Fig.20) Hydraulic test unit includes: measuring instruments (design H9941-31; H9941-48), hose (H9941-5), and charging pipe unions (H9904-210, H9941-310, H9941-31)	H9956-0
<b>B. Aircraft Towing Facilities</b>		
23	Tow-bar	H9942-110
24	Nose wheel control gear	H9942-0
25	Cable	H9900-20
<b>C. Airframe Service Equipment</b>		
26	Stabilizer service ladder	H9931-0
27	Service ladder for first detachable wing section	H9920-0
28	Ladder for cabin of compartment Q-6	H9904-250
29	Stand with scrapers and brushes used for climbing into cabin of compartment Q-2	H9902-5
29a	Wheel chocks	H9941-0
29b	Telescopic ladder for inspection of rudder (Fig.21)	H9941-0
<b>D. Equipment for Mounting and Disassembling Aircraft Individual Units</b>		
30	Main landing gear wheel remover	H9941-700
31	Brake disc remover	H9941-360
32	Nose wheel remover	H9941-290
33	Wheel tyre remover	CS-01
34	Fixture for installing crew seats	H9973-21
35	Wing panel remover	H9920-120
36	Bogey for installation and removal of landing gear wheels	H9941-110
37	Screw clamp (spacer) for main strut torsion links	H9941-320
38	Screw clamp (spacer) for nose strut torsion links	H9842-70
39	Leveling pole	H9996-30
40	Engine counting cart	3563
<b>E. Equipment for Checking and Adjusting Systems</b>		
41	Calibration rheostat for regulating temperature of cabin glass panels on ground (Fig.22)	H7907-20
42	De-icer thermometer (Fig.23)	H7907-0
43	Unit for checking fuel system control equipment	H9972-10

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM

1	2	3	1	2	3
<b>F. Electric Equipment, Filling Equipment,</b>					
<b>Containers for Storage of Ground</b>					
<b>Equipment</b>					
44	Electric cable	H7211-31	83	Rubber mat for protection of aircraft skin against damage	H9999-63
45	Electric cable	H9972-30	84	Rubber mat to be used when working in fuselage tunnel	H9999-66
46	Pipe enclosed in cover H9999-460 for charging oxygen system	H9978-0	85	Blanking cover for air intake duct	H9969-42
47	Fuel indicator float	H9961-509	86	Blanking cover for exhaust pipe	H9969-45
48	Fuel indicator float	H9961-600	87	Blanking cover for access hole	H9969-60
49	Box for connection of power supply source	H9972-0	88	Plug for static pressure openings	H9977-10
50	Fuel drain hose	H9999-270	89	Plug for starter	H9968-1
51	Fuel drain hose	H9999-16	90	Casing for folded-dipole antenna	H9999-130
52	Funnel for oil	H9999-273	91	Plug for opening in wing leading edge	H9999-92
53	Funnel for hydraulic fluid AHF-10	H9999-28	92	Plug for opening in front part of fin	H9999-94
54	Funnel for inserting hydraulic fluid AHF-10 into brake system	H9996-300	93	Plugs for signal flare SRCP-39 release openings	H9999-435
55	Can, 15-lit. capacity	H9999-3	94	Plug for fuel jettison pipe	H9920-260
56	Bucket, 8-lit. capacity	H9999-400	95	Plug for engine nacelle blow-out connection	H9969-90
57	Bucket, 10-lit. capacity	H9999-20	96	Casing for rear folded-dipole antenna	H9999-150
58	Fan	H9941-380	<b>H. Armament Servicing Equipment</b>		
59	Container in bomb bay	H9999-350	97	Service ladder for special compartment of fuselage	H812-10
60	Container for storage of aircraft-carried tools and accessories	H9999-100	98	Service ladder for tail gun mount	H9504-500
61	Container for rigging	H9999-210	99	Ladder for special fuselage compartment	H812-30
<b>G. Covers and Plugs</b>			100	Dial and fixed index to read traverse of upper and belly gun turrets	H9981-580
62	Cover for fuselage compartment located between frames Nos 1 - 12	H9999-51	101	Fixture for setting protractor when measuring safe ranges	H9981-680
63	Cover for fuselage compartment located between frames Nos 12 - 22	H9999-52	102	Target for gun bore sighting (nose)	H9981-130
64	Cover for fuselage compartment located between frames Nos 22 - 36	H9999-75	103	Target for gun bore sighting (side front)	H9981-131
65	Cover for fuselage compartment located between frames Nos 36 - 50	H9999-76	104	Target for gun bore sighting (side rear)	H9981-132
66	Cover for fuselage compartment located between frames Nos 50 - 64	H9999-54	105	Target for gun bore sighting (tail)	H9981-133
67	Cover for tail gun mount	H9999-55	106	Fixture for levelling circular station mounting platform	H9981-710
68	Cover for horizontal tail	H9999-56	107	Fixture for levelling strut station platform	H9581-700
69	Cover for first detachable wing section	H9999-57	108	Fixture for setting belly turret in horizontal position	H9981-600
70	Cover for second detachable wing section	H9999-58	109	Fixture for setting optional protractor on tail gun mount	H9981-635
71	Cover for main landing gear strut locks	H9999-90	110	Hoist for belly gun mounts (Fig. 24)	H9981-0
72	Covers for main landing gear wheels	H9999-80	111	Slings for tail gun mount	H9980-0
73	Covers for nose wheels	H9999-81	112	Slings for upper gun mount	H9980-10
74	Cover for nose strut lock	H9999-88	113	Slings for lifting and turning special belly mount	H9981-650
75	Cover for Pitot tube	H9999-72	114	Ladder-stands for servicing upper gun mount (Fig. 25)	H9981-200
76	Cover for cannon barrels	H9999-89	115	Slings for armament	H9981-620
77	Cover for moving gun mount	H9999-451	116	Bracket for unit C-13 (checking operation of system A)	
78	Cover for aerial camera mount	H9999-452	<p><b>Notes:</b> 1. Safeguard the measuring instruments and the hose of hydraulic test unit H9956-0 against gasoline, oil, dirt, and moisture. After work wipe the instruments with a clean cloth and keep them in a case.</p> <p>2. Installation H9956-150 and test unit H9956-0 may be kept outside the building as they are furnished with protective casings.</p>		
79	Cover for antenna of range finder	H9999-454			
80	Cover for transponder antenna	H9999-455			
81	Cover for radio altimeter PB-2 antenna	H9999-456			

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

- 3. Wing panel remover H9920-120 and bogey H9941-110 for installation and removal of the landing gear wheels may be kept outside the building. All other equipment designed for mounting and dismounting of aircraft individual units should be kept in container H9999-210.
- 4. The moving components of the equipment referred to in Section D of the list should be treated with MILITARY-201 lubricant at regular intervals.
- 5. The equipment listed in Section F must be stored in a container.

Chapter II

AIRCRAFT AIRFRAME CARE AND MAINTENANCE

1. PREVENTION AND ELIMINATION OF CORROSION

When the aircraft is parked in the open for a long time, corrosion develops in the metal components of its structure due to atmospheric moisture, dust, and dirt.

Therefore, keeping the internal and external surfaces of metal components clean at all times, as well as timely removal of atmospheric moisture, is essential for protection of the aircraft against attacks of corrosion.

Proper maintenance prolongs the life of the aircraft and provides for preserving its flight characteristics.

The aircraft surfaces affected by exhaust gases, and the surfaces exposed to a temperature of over 100°C or contacting thermal insulation, as well as riveted and welded seams, joints, clearances, etc., should be constantly kept under close observation.

The structural components which are made of aluminum alloys and have no paint coating are usually protected by the anodic layer only; therefore, guarding of this layer against mechanical damage, dirt, and moisture is quite essential for prevention of corrosion.

Care of Aircraft Metal Surfaces

- 1. When parking the aircraft in the open, put on the covers for protection of metal surfaces against precipitation, icing, and mechanical damage.
- 2. If the aircraft is parked outside the hangar for long periods of time, subject the skin surfaces to thorough inspection twice a month in summer and once a month in winter, to see if there is any corrosion, and to take appropriate measures for its elimination.
- 3. Do not place metal objects, parts, and tools directly on the aircraft skin; see that no waste cotton or cloth soaked with oil or other chemical agents is left lying on the skin.
- 4. When working on the aircraft, use soft, clean mats, rubber mats, and soft footwear (rubber shoes with felt soles or other shoes having no metal nails in them) to guard the aircraft surface against mechanical damage; prior to entering the aircraft thoroughly clean the shoes of dirt.
- Before putting the mats on the aircraft thoroughly clean them of sand and dirt.
- 5. Do not employ metal brushes or scrapers for cleaning the aircraft surfaces.
- If an ice coating builds up on the aircraft surface, remove it by blowing the affected areas with hot air.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM

The temperature of the air used for removing ice from the surface of the pressurized cabin (3-2 and 3-6) should not exceed 35°C; other surfaces may be blown with air at a temperature of not over 120°C.

6. After every flight, especially after a high-altitude flight, proceed as follows:

- (a) open all hatches for airing the aircraft, and extend the wing flaps;
- (b) remove oil stains, splashes and soot by using clean cloth or waste cotton, soaked in clean gasoline B-70 or in white spirit; then wipe the surface with clean waste cotton;
- (c) remove dust and dirt from all accessible places by employing a vacuum cleaner or clean soft cloth slightly soaked in clean gasoline B-70 or in white spirit;
- (d) use special care when wiping the aircraft surfaces exposed to exhaust gases with clean soft cloth soaked in clean gasoline B-70 or white spirit. This procedure should be carried out after each engine starting or running.

7. It is very important that no electrolyte should be spilled on the aircraft metal surface; therefore exercise utmost care whenever removing storage batteries from or installing them in the aircraft; perform all operations pertaining to storage battery servicing outside the aircraft.

However, if some electrolyte does get on the metal surface, no matter what painted or not, immediately wash the affected area with a jet of water, repeat the procedure many times, after which wipe the surface with clean dry waste cloth or blow it with compressed air.

Keep the affected area under observation for a month and enter the result inspection in the aircraft Service Log.

Care of Individual Attachment Fittings

When proceeding in compliance with the Inspection Guide, do the following:

1. Inspect the coupling bolts in frames Nos 2, 12, 26, and 69, in the cant plane, detachable wing sections, and engine nacelles. For this, open the respect access panels or thermal insulation and check the bolts for damage and corrosion.
2. Inspect the control links and cables in the fuselage and detachable wing sections, opening the respective access panels for the purpose. Make sure the cables are free of broken strands and corrosion.
3. Check the airtite hoses and their fastenings for condition. Multiple criss on the surface layer of the hoses are allowed.
4. Inspect the exposed surfaces of the rods incorporated in the landing gear and tail skid shock absorbers; inspect the surface of the rails, oxygen cylinders and oxygen installations. The chrome-plated surfaces of the rods and rails must always be coated with petrolatum or other neutral lubricants (KH-50, KH-50, or HEMAN-201).

Lubricate these surfaces anew, if dry. Prior to flight remove lubricant from the chrome-plated friction surfaces. Inspect the following surfaces having no protective coatings: the universal joint of the nose landing gear brace strut, the cheeks of the main strut rod, etc.; see that they are properly lubricated.

5. Inspect the water drain holes and clean them, if clogged.

Restoring Protective Coatings and Eliminating Corrosion

All operations pertaining to application of paint coatings may be best of all performed in hangars. In dry and calm weather the work may be carried out on the airfield in which case the ground around the aircraft should be entered and the aircraft itself should be placed in a dust-protected area. When applying paint coatings the air temperature should not be below +12°C.

When an atomizer is employed for painting individual components inside the aircraft, use sheets of cardboard, plywood, and paper, or pieces of cloth to safeguard other parts having intact coatings against paint sprays.

For more rapid drying of the protective coatings (primer, enamel) local heating may be resorted to. Local heating may be effected by the use of reflector lamps and heaters AM-1 or MM. The heaters should be provided with flexible hoses allowing supply of warm air to the areas in question. The air must be heated to a temperature of 50-60°C. In the pressurized cabins paint coatings should be dried by air heated to a temperature not exceeding 45°C.

Before use, the protective compounds are diluted to the required viscosity with the aid of a diluent in compliance with the data presented in Table 6.

Table 6

Data Pertaining to Viscosity of Protective Compounds Diluted by Various Diluents

Nos	Name of protective compound	Name of diluent	Viscosity as measured by viscosimeter 33-36 (nozzle No.2), sec.	
			for atomizer	for brush
1	2	3	4	5
1	Primer AM-1	Gasoline B-70 or white spirit	6 - 10	15 - 20
2	Primer AM-7	1:1 mixture of xylene and white spirit, or xylene only	4 - 6	10 - 14
3	Primer AM-8	Xylene	4 - 6	12 - 20
4	Enamel A-100	Gasoline B-70	8 - 10	15 - 20
5	Enamel A-150	Gasoline B-70	8 - 10	15 - 20
6	Enamel A-26M	Gasoline B-70	8 - 10	15 - 20
7	Enamel KB-16	P-5	3.5 - 4.5	5 - 10
8	Enamel KB-19	P-5	3.5 - 4.5	5 - 10
9	Enamel A-67	Gasoline B-70	8 - 10	15 - 20
10	Enamel "Myap-25"	White spirit	10 - 25	15 - 20

The viscosity of the protective compounds is determined with the aid of viscosimeter 33-36. The viscosity of a compound is determined by the time period (sec.) during which 50 cu.cm. of the compound heated to a temperature of 20°C drain out of the funnel (nozzle No.2).

If viscosimeter 33-36 is not available the viscosity of diluted protective compounds may be determined by the following method.

Employ a brush or an atomizer to apply a layer of protective compound onto a glass or metal strip, 10x15 cm. in size, set at an angle of 45°; then check to see whether the compound spreads on the surface evenly.

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

Table 7

Materials Used for Restoring Protective Coatings

Material	Grade	Colour	Viscosity as measured by viscosimeter 43-36 or B3-4, sec.			Drying time, hr			
			as delivered	for brush	for atomiser	at 12-17°C	at 18-35°C	at 60-70°C	at 90°C and over
1	2	3	4	5	6	7	8	9	10
Primer	AM-1	Yellow	35 - 45	15 - 20	6 - 10	40	24	4	3
Same	AM-8	Same	-	12 - 20	4 - 6	8	6	2	-
Enamel	A-149	Steel	20 - 31	15 - 20	8 - 12	30	22	4	-
Same	A-154	Dark green	20 - 31	15 - 20	8 - 12	30	22	4	-
Same	XB3-16	Gray	5 - 10	5 - 10	3.5 - 4.5	24	16	-	-
Same	XB3-19	Aluminum	4 - 10	5 - 10	3.5 - 4.5	24	16	-	-
Same	A-26W	Black	18 - 30	15 - 20	8 - 12	36	24	5	-
Same	A-67	Red	20 - 31	15 - 20	8 - 12	30	22	4	-
Varnish	135-T	Clear	-	-	13 - 15	-	2	4	-
Preparation	102-T	Same	-	-	-	-	-	-	-
Bicarbonate	No. 7640	Same	-	-	-	-	-	-	-
Gum grease	-	-	-	-	-	-	-	-	-
Petrolatum	-	-	-	-	-	-	-	-	-
Gasoline <sup>x)</sup>	E-70	Clear	-	-	-	-	-	-	-
Xylene <sup>x)</sup>	-	Same	-	-	-	-	-	-	-
White spirit <sup>x)</sup>	-	Same	-	-	-	-	-	-	-
Lubricant	LIATHIN-201	White	-	-	-	-	-	-	-
Magnesium oxide	-	-	-	-	-	-	-	-	-
Chromic anhydride	-	Reddish-brown	-	-	-	-	-	-	-
Sulphuric acid	-	Clear	-	-	-	-	-	-	-

<sup>x)</sup> For diluting enamel and primers 1:1 mixtures of these compounds are used.  
 3. Using an atomiser apply two layers of varnish 135-T. Each of the varnish layers should be dried for 24 hours at a temperature of 12 - 35°C; for 18 hours at 36 - 50°C; or for 4 hours at 60 - 70°C.

**Note:** As a provisional measure, the part surfaces with damaged coatings may be protected against corrosion by treating them with petrolatum. The layer of petrolatum should be periodically renewed.  
 Petrolatum is removed with gasoline; primer and varnish are applied as directed above.

Varnish 135-T is prepared by mixing it with preparation 102-T, 39 gr of the preparation being added to each kg of the varnish. After adding preparation 102-T

If no runs or beads are developed on the surface to which the protective compound has been applied, the viscosity of the compound may be considered adequate.

All materials employed for restoration of protective coatings and for removal of corrosion should comply with the Specifications.

The list of materials used for the purpose is given in Table 7.

**Part 5: Edge of Aluminum Alloy**

In case corrosion (white powder) is detected on the internal framing components and on the inner side of the skin, treat the affected areas in the following manner:

1. Wipe the areas in question with waste cotton or cloth soaked in clean gasoline or white spirit.
2. Clean with hair, grass, or bristle brush. If traces of corrosion are still present after the above treatment, rub the surface with waste cloth soaked in gasoline and powdered with emery dust No. 220.
3. Wipe the cleaned area first with waste cotton or clean cloth soaked in clean gasoline or white spirit, and then with clean dry waste cotton.
4. Apply a layer of primer AM-1 or AM-8 onto the cleaned surface, using an atomiser or a brush. The viscosity values of these primers, as measured by viscosimeter 43-36 (nozzle No. 2), should be as follows: for primer AM-1 - 6 - 10 sec. and 15 - 20 sec. when applied with an atomiser and a brush respectively; for primer AM-8 - 4 - 6 sec. and 12 - 20 sec. respectively.
5. Dry the AM-8 primer coating for 5 hours at a temperature of 12 - 17°C; for 4 hours at a temperature of 18 - 27°C; or for 3 hours at 28 - 35°C. Primer AM-1 should be dried for 36 hours at a temperature of 12 - 17°C; for 24 hours at 18 - 35°C; or for 4 - 5 hours at 50 - 70°C.
6. Using an atomiser or a brush apply enamel A-154 to the primed surface if the part is accommodated in the pressurized cabin (compartments 0-2 and 4-6) or a layer of primer AM-1 or AM-8 containing 5 to 8 per cent aluminum powder, then dry the obtained coating. When drying primer AM-1 or AM-8 follow the directions of Point 5. Enamel A-154 should be dried for 36 hours at 12 - 17°C; for 24 hours at 18 - 27°C; or for 6 hours at 60 - 70°C.

**CAUTION:** Never use leaded gasoline for cleaning the area attacked by corrosion.

For restoring the 135-T varnish coating on the skin panels, treat the affected areas as follows:

1. Thoroughly rub the surface with bristle brushes amply treated with turpentine.
2. Wipe dry with clean cloth.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

thoroughly stir the mixture with an aluminum blade for 5 to 7 min., then add 13 gr of siccativ No.7640 and stir the mixture again for 10 to 15 min.  
Prior to adding preparation 102-T into varnish 135-T dilute it with the equal amount of xylene. In case preparation 102-T has thickened, heat it to a temperature of 40 to 50°C prior to adding it to the varnish.

- CAUTION:** 1. Varnish should be prepared just before being used, since the ready compound may be used for 4 hours only.
2. Prior to use filter the varnish through two layers of gauze.
3. Varnish should be prepared outside the building or in a vented cabinet; the man preparing the varnish should use helmet C-1 or a breathing mask and wear rubber gloves.
4. In case preparation 102-T gets on the skin, wash the affected place with 5 - 10 per cent solution of ammonia or rub it with a cotton wad soaked in acetone. Then wash the skin with warm water and soap.

Parts Made of Magnesium Alloys

In case corrosion is detected on the surface of the parts or skin panels fabricated of magnesium alloys, proceed as follows:

1. Remove corrosion products by cleaning the areas exceeding the affected spots by 5 to 10 mm to bright metal using a scraper or emery cloth.
2. Rub the cleaned area repeatedly with cloth or cotton waste soaked in clean gasoline E-70 or in white spirit, then wipe it with dry clean cloth.
3. Treat the affected area with a solution of the following composition:
 

Magnesium oxide . . . . .	8.9 gr
Chromic anhydride . . . . .	45 gr
Sulphuric acid (sp.gr. 1.84) . . . . .	0.6 - 1.0 cu.cm.
Water . . . . .	1000 cu.cm.

Apply the solution with a cotton wad attached to a glass or wooden stick. Use a dry cotton wad to remove excess solution from the area not subject to the treatment.

- Dry the part surface treated in the above manner for 30 min.
4. Employ an atomizer or a brush to coat the affected area with two layers of primer AM-8 or AM-1 containing 5 per cent aluminum powder HAK-4 or HAK-3. Dry each layer of primer AM-8 for 5 hours at a temperature of 12 - 17°C, or for 4 hours at 18 - 35°C; in the case of primer AM-1 each of the layers should be dried for 48 hours at a temperature of 12 - 17°C, or for 36 hours at 18 - 35°C.
  5. Using an atomizer or a brush apply a coat of coloured enamel to the affected area. Give the inner framing components and the inner side of the skin a coat of enamel A-152; apply a layer of enamel EB-16 and a layer of enamel EB-19 successively to the skin outside. Enamel A-152 on the inner framing components may be substituted by an enamel of a different colour (to match the colour of the component in question), such as black enamel A-26M, steel enamel A-142, red enamel A-67, etc.
  6. Dry the EB-16 enamel coat for 5 hours at a temperature of 12 - 17°C, or for 4 hours at 18 - 35°C; the drying time for enamel EB-19 amounts to 12 hours and 8 hours at a temperature of 12 - 17°C and 18 - 35°C respectively; enamels A-142, A-152, A-26M, and A-67 require 48 hours for drying at a temperature of 12 - 17°C, or 36 hours at 18 - 35°C.

**CAUTION:** As in the case of aluminum alloy parts, it is strictly prohibited to employ leaded gasoline E-70 for surface cleaning purposes.

7. As a provisional measure, the areas with damaged coating may be protected against corrosion, especially in winter, when it is not possible to use varnishes in the open air, by coating the surface with a layer of gum grease heated to 60 - 100°C. Prior to giving the affected area a coat of varnish (when the ambient air temperature is not less than 12°C), the gum grease should be removed with gasoline, and primer and enamel applied as laid down in Points 4, 5, and 6.
8. The oxidizing solution is prepared as follows.

First mix magnesium oxide with a small amount of water in a beaker until a sealiquid consistency is obtained. Then add 400 to 500 cu.cm. of water and introduce chromic anhydride by small amounts in cold surroundings, stirring the mixture all the while. Keep stirring the mixture until the magnesium oxide is completely dissolved (until turbidity disappears). After this add the specified amount of water, sulphuric acid, and thoroughly stir the resulting mixture.

- Notes:** 1. The mixture should be kept in a closed glass vessel.  
2. 100 cu.cm. of the solution are required for oxidizing 0.2 to 0.25 sq.m. area.

Parts Made of Ferrous Metals

If corrosion (rust) or damaged protective coating is detected on steel parts, exclusive of the parts having chrome plating, such as shock absorbers, landing gear, rails, etc., treat the affected areas in the following manner:

1. If the part is painted, first remove the paint coating from the affected area by rubbing it with cotton waste soaked in special remover CE.
2. Remove rust by using rigid hair, grass, or bristle brushes, or emery cloth No.170.
3. Rub the surface first with cloth or cotton waste soaked in clean gasoline E-70, and then with clean dry cloth or cotton waste.
4. Apply a layer of primer AM-8 or AM-1 using a brush or an atomizer. Dry the AM-8 primer layer for 5 hours at a temperature of 12 - 17°C, or for 4 hours at 18 - 35°C; primer AM-1 requires 48 hours at a temperature of 12 - 17°C, 36 hours at 18 - 35°C, or 5 to 6 hours at 70 - 60°C for drying.
5. Using a brush or an atomizer, apply a layer of coloured enamel to match the colour of the part in question (for instance, the colour of enamel A-142 matches the colour of the landing gear cylinder). Then dry the enamel layer for 48 hours at a temperature of 12 - 17°C, for 36 hours at 18 - 35°C, or for 5 to 6 hours at 70 - 60°C.

**CAUTION:** When eliminating corrosion never use a file, remove PMA, or leaded gasoline.

Whenever the landing gear shock absorbers get covered with a coat of reddish-brown rust, rub the affected area with clean cloth, soaked in gasoline E-70, until the rust is removed. Then coat the affected area with dehydrated petrolatum. Keep the area under close observation.

If deep corrosion (in the form of black pits) develops on the landing gear shock absorbers, resulting in leakage of hydraulic fluid through the sealings, the shock absorbers and actuating cylinders should be replaced by new ones.

**CAUTION:** Never employ leaded gasoline for cleaning the affected areas.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

— 42 —

Should corrosion be detected on the chrome-plated parts, perform the following operations:

- (a) clean the affected area with emery powder EG-200 - 220 applied to cloth or cotton waste soaked in gasoline B-70;
- (b) rub the area with cloth or cotton waste soaked in gasoline B-70 and then with clean cloth or cotton waste;
- (c) wipe the surface with cloth soaked in drying oil preheated to 50 - 60°C or in oil MSH;
- Then dry it for two hours at a temperature of not less than 12°C.
- (d) rub the area with cloth soaked in gasoline until the drying oil film is completely removed. If the surface has been treated with oil MSH, remove the latter with dry cloth.

2. CARE OF GLASS PANELS

When the aircraft is parked on the airfield, the glass panels of the cabins should be fitted with covers for protection against the effect of the sun rays, atmospheric precipitation, as well as against mechanical damage and dirt. The covers should have clean soft flannel lining. Prior to putting covers on the glass panels do not fail to thoroughly clean their lining of dirt, dust, and sand.

The covers should be washed at regular intervals. When putting the covers on, take care to prevent the glass panels from being damaged by the metal fastenings and other parts. After rain the covers should be removed from the glass panels and dried.

When carrying out repairs on the aircraft:

- (a) protect the organic glass panels by special casings or thick paper glued up with petrolatum;
- (b) see that no solvents get on the organic glass (such as ethyl alcohol, remover PBA, gasoline remover, etc.), which may cause dimming of the glass panels.

Throughout the entire service period of the aircraft make visual inspection of the glass panels on the inside and outside at the termination of each flying day. While doing so, check to see that the glass panels are clean and free of chips, cracks, or scratches. Direct special attention to condition of glass panels in side blisters where they curve from the flange to the sphere.

In case dirt gets on a glass panel, wash the latter with water (delivered from a watering pot or wrung out of wet cloth). After washing wipe the glass dry with clean cotton waste moving the latter in a circular manner and pressing slightly against the glass surface; after that air the glass until it is completely dried.

If the glass becomes grease-stained, rub it first with a dry cloth and then with paste BHAM-2.

In case paste BHAM-2 is not available, rub the glass with a cloth soaked in soapy water (3 to 5 per cent solution), and then with cloth soaked in clean water; finally, wipe the glass dry.

**CAUTION:** Never rub the panels of organic glass with paper or other rough or contaminated materials. Do not employ wool or silk fabrics either, as they tend to form static charges on the glass due to rubbing.

Deep scratches, chips, or cracks are the cause for replacement of the glass. The following defects on the organic glass panels are allowable:

- (a) hair scratches;

— 43 —

- (b) shallow scratches and notches not forming a net;
- (c) minute surface cracks ("silver") in the form of interrupted chains not exceeding 60 mm in length, with individual cracks up to 6 mm in length. Not more than three chains are allowed on one glass panel.

**Note:** Defects listed in Item (c) are not allowed on the side blisters. A dimmed blister should be replaced.

Removal of deep scratches and "silver" from the surface of organic glass panels by means of emery cloth with subsequent polishing is not allowed, since such treatment will affect optical properties of the glass.

If numerous notches and hair scratches are developed, the organic glass should be polished with paste BHAM-2. Polish the glass manually, using a cotton wad, which should be first moved along the scratches, then across the scratches, and finally in a circular manner, applying slight pressure. Do not rub the glass for a long time on one particular area to avoid heating the surface.

**CAUTION:** 1. It is prohibited to use pastes other than specified.

2. Prior to polishing the glass check to see that its surface is clean and free of hard particles which may cause additional scratches and notches during polishing.

Every 50 flying hours, but not less than once every three months, perform routine inspection of the blisters; enter the results of inspections in the aircraft Service Log. Prior to inspecting the blister, remove its external fillet and the fairing.

**Note:** The rubber profile of the fairing and the fillet may cause a frosted strip and a depression on some sections or throughout the blister length.

Such defects on the blisters are allowed. They call neither for repair nor for measurement of the depression depth.

3. SPECIAL DIRECTIONS

When carrying out preflight and postflight inspections of the airframe, check on the following points (besides performing the operations prescribed in the Inspection Guide):

1. Condition of the rivets and screws in the vicinity of the upper gun mount. See that no rivets or screws are loose or missing.
2. Condition of the surface of the tubular control links where they run under the guide rollers. If the tube surface is found to be worn to a depth of 0.5 mm, turn the tube about its longitudinal axis through 180° to preclude further damage to the link.
3. Play in the hinged joints of the control links. If any play is detected in the above joints, replace worn hinge bolts by new ones.
4. Engagement of the hooks and supports of the mechanism jettisoning the navigator's hatch door (after every three flights). Inspection of hooks and supports should be made through the inspection ports located in the front section of the hatch door.
5. Reliability of the locking devices in the link joints and condition of the supporting rollers. Make sure that the link tubes are not worn under the guide rollers and that the link hinged joints are free of play. If a link is

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

— 44 —  
found to be worn to a depth of 0.5 mm, turn it about the longitudinal axis through 180°; replace hinge bolts, if play is detected in the hinged joints of the links.  
6. After every three flights check the hooks and supports of the hatch door jettison mechanism for proper engagement. Engagement is considered to be correct, if the hook roller is properly seated in the support recess. The hooks and supports are inspected through the ports located in the front section of the hatch door armored wall.

— 45 —  
Chapter III

EMERGENCY AND RESCUE APPLIANCES  
CARE AND MAINTENANCE

1. EJECTION SEATS

Ejection seats enable the aircrew to abandon the aircraft in the air at any speed.

All the ejection seats are provided with safety devices which prevent ejection with the emergency hatches unjettisoned, with the seats in the intermediate positions and during parking.

To prevent ejection in the first two cases interlocking devices are fitted which are incorporated in the seats.

To prevent ejection in the third case (during parking) a ground safety device (a bolt with a tag) is provided. This device is removed prior to take-off and is mounted immediately after landing.

If employed correctly, the ejection seats are absolutely safe when working in cockpits on the ground, while in the case of emergency in the air they ensure safe bailing out for the crew.

Removal and Installation of Ejection Seats  
on Aircraft

During service it is necessary to remove periodically the ejection seats from the aircraft so as to replace the explosive charges and main springs of the ejection guns, to clean the ejection guns and perform other work.

To perform maintenance operations and care of the pilot's ejection gun remove only the movable (during ejection) part of the seat without the carriage and the armored back plate.

For maintenance operations and care (charging, cleaning, etc.) of the ejection guns of the navigator's, navigator-radar operator's, radio operator's, and rear gunner's seats, remove the seats from the aircraft. Access to the ejection guns of the navigator's and navigator-radar operator's seats is ensured by removing the cover of the hatches on the seat movable frame.

On the radio operator's and rear gunner's seats the ejection guns are easily accessible.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 46 -

Removal and Installation of Pilot's Ejection  
Seat Movable Part (without carriage  
and armoured back plate)  
(Fig. 26)

1. Remove cable 7 connecting the interlocking pin of the ejection gun to the canopy cover. For this disconnect the cable from the flexible pin locking the safety pin of the ejection gun (the flexible pin should be left in its place).
2. Remove the canopy cover.
3. Unscrew four bolts of bracket 9 securing the ejection gun to the armoured back plate.
4. Move the seat back as far as it will go and fix it in this position.
5. Connect the transverse member of the safety harness by the bottom of the seat and by means of a crane remove the movable part of the seat from the aircraft through the canopy hatch.
6. Unload ejection gun 5.

The installation of the ejection seat movable part on the aircraft is the reverse of the procedure described in Items 1 - 6.

After the movable part of the ejection seat has been installed, check the seat interlocking system. In the extreme rear position of the seat its locking pin must be depressed flush with the rail wing (Fig. 27). In all intermediate positions when pulling the blind the locking pin should engage the cam on the axle of the blind drum over not less than 3 mm (Fig. 28).

Removal and Installation of Pilot's Ejection Seat  
(with carriage and armoured back plate)  
(See Fig. 26)

1. Remove cable 7 connecting the interlocking pin of the ejection gun with the canopy cover. Disconnect the cable from the flexible pin locking the safety pin of the ejection gun leaving the pin in its place.
  2. Remove the canopy cover.
  3. Move the ejection seat to the extreme front position. Connect transverse member No. 2671 to the armoured back plate. Engage the hook of the crane cable (goose-neck crane No. 78967) in the transverse member and tighten up the cable.
  4. Unscrew the rear bolts securing horizontal rail 12 (nearest to the aircraft centre line) guiding the carriage. Move the seat to the extreme rear position, then unscrew the front bolts securing this rail.
  5. Slightly incline the seat in relation to the aircraft side and remove the rail from under the seat. Lower the seat and shift it to the aircraft centre line so that the rollers of the lower carriage get out of the second guide rail.
  6. Lift the seat with the crane and remove it from the aircraft through the canopy hatch supporting it with both hands so that the seat does not touch the other parts.
  7. Unload the ejection gun.
- The installation of the seat on the aircraft is the reverse of the procedure described in Items 1 - 7.

Removal of Navigator's Seat  
from Aircraft  
(Fig. 29)

- Before removing the seat from the aircraft:
- (a) screw in the ground interlocking bolt which prevents accidental ejection on the ground;
  - (b) disconnect the snap hook of cable 8 interlocking the ejection gun with the cover of the emergency hatch from the ear on the cover;
  - (c) remove the hatch cover.
- To remove the seat from the aircraft:
1. Place the seat to the ejection position, setting it in the direction of flight and moving it back as far as it will go.
  2. Supporting the seat with both hands remove the quick-release bolt securing the ejection gun to the fuselage bracket.
- Carefully lower the seat along the guide rails supporting it with both hands and remove it from the aircraft through the emergency hatch. This operation must be carried out by three men at least.
3. After the seat has been removed from the aircraft, unload its ejection gun.

Installation of Navigator's Seat  
on Aircraft  
(Fig. 30)

1. Install device 7 on the bracket securing the ejection gun to the fuselage frame.
2. Pass cable 6 of the winch through the roller and connect its free end to lock 5.
3. Pass the free end of cable 4 of the device through the hole in the upper bracket of the seat sliding frame and connect it to lock 5.
4. Using winch 2 lift the seat along the guide rails to the position marked by the device.
5. Remove device 7 supporting the seat by hand.
6. Insert the quick-release bolt raising the seat until the holes in the racket mesh with those in the ejection gun.

Removal of Navigator-Radar Operator's Ejection  
Seat from Aircraft  
(See Fig. 31)

- Prior to removing the seat from the aircraft do as follows:
- (a) screw in the ground interlocking bolt of the ejection gun;
  - (b) disconnect the snap hook of the cable interlocking the ejection gun with the hatch cover from the cover eye;
  - (c) remove the hatch cover.
- To remove the seat from the aircraft:
1. Secure the seat to the bracket on the sliding frame by means of the stop in its backrest.
  2. When on the seat, open the valve mounted at the bottom of frame No. 12 and lower the seat to the extreme lower position.
  3. Remove the quick-release bolt supporting the seat with the hands from

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM



50X1-HUM

below. Carefully lower the seat onto the guide rails and remove it from the aircraft through the entrance hatch. This operation requires four men at least.

- Unload the ejection gun.

Installation of Navigator-Radar Operator's Seat on Aircraft  
(See Fig. 30)

- Mount device 11 on the seat sliding carriage.
- Pass cable 6 of the winch through the roller and connect its free end to lock 5.
- Pass the free end of device cable 4 under the seat and connect it with lock 5.
- Using winch 2 lift the seat along the guide rails to the position permitted by the device.
- Remove the device supporting the seat by hand.
- Insert the quick-release bolt lifting the seat until the holes in the sliding carriage mesh with those in the ejection gun.

Removal from and Installation of Radio Operator's and Rear Gunner's Seats on Aircraft  
(Figs 32 and 33)

The seats of the radio operator and of the rear gunner are installed on the aircraft and removed from it in the same manner as the navigator's seat. When installing the seats, pass the cable of the lifting device under the lower brackets of its headrest.

Loading and Unloading Ejection Guns

Loading and unloading, as well as other maintenance operations, should be carried out outside the aircraft.

All the seats are provided with the system interlocking the ejection guns with the hatch covers, therefore, prior to removing the seats from the aircraft it is necessary to disconnect this system and only after this remove the seat.

For this purpose disconnect the snap hook joining the interlocking cable to the eye on the hatch cover, leave the hatch cover interlocking pin in its place and secure the cable in position on the seat so as to avoid accidental pulling out of the pin.

When removing the seat from the aircraft, the ground interlocking bolt must be screwed in its place.

Loading and unloading the ejection guns must be performed far from the aircraft in a specially prepared place by specially trained personnel.

When carrying out maintenance operations, the seats should be placed on a stand constructed in the form of guide rails so that the ejection gun is in a vertical position.

**CAUTION:** When unloading and loading ejection guns, observe the following rules:

- carry out the work only in a special room or in a place intended for this purpose on a special device;

- the seats must be fixed in position on the device;
- the operations should be performed by personnel specially trained for work with ejection seats; presence of unauthorized persons is prohibited;
- the operator carrying out the work should occupy a position at the side of the seat at all times.

Loading and Unloading Ejection Guns of Seats Ejected Downward from Aircraft  
(Fig. 34)

The ejection guns of the seats ejected downward should be loaded and unloaded outside the aircraft on the seats removed from it.

The ejection guns of these seats should be unloaded in the following order:

- Remove the piston locking together with the ejection gun head.
- Open the ball lock for which purpose press its piston to the extreme upper position lifting it by the splint pin in the end piece (Fig. 35).

**Note:** Prior to opening the ball lock of the ejection guns in the navigator's and navigator-radar operator's seats, remove the covers of the hatches located on the sliding frames from the rear.

- Move the outer cylinder upward by 200 or 300 mm.
- Using special wrench 6 (Fig. 36) unscrew the piston from the head and raise it (Fig. 37). The explosive charge will remain in the ejection gun head. In all ejection seats the piston is turned off counter-clockwise.
- Remove the explosive charge from the seat of the ejection gun head and put it into a special box with sockets for storage of explosive charges.

Loading and Unloading Ejection Guns of Seats Ejected Upward from Aircraft  
(Fig. 38)

The ejection guns of the seats ejected upward should be loaded as follows:

- Loosen lock nut 10 and unscrew union nut 11. This done, detach the firing mechanism on which safety pin 5 should be mounted, locked, and sealed.

**Note:** If arming pin 6 was not mounted, after the firing mechanism has been removed, press off striker 3 by a metal pin with a diameter not in excess of 6 mm through hole 1 and insert the arming pin into the part of the rod of striker 3. Mounting the arming pin is shown in Fig. 39.

- Connect the explosive charge (MK-T) with the firing mechanism for which purpose turn the firing mechanism with the firing pins upward. The lower end face of the explosive charge indicator must be depressed flush with the firing mechanism plane. The red bush of the indicator must project by 5 mm beyond the firing mechanism head surface.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 50 -

3. Insert the locking pin of the firing mechanism into the socket of the bottom of the explosive charge case and by turning the explosive charge insert the flange of its case into the grooves of the firing mechanism lugs as shown in Fig.40.

4. Insert the explosive charge into inner cylinder 22 (See Fig.38) of the ejection gun and mount the firing mechanism so that its lugs enter the special splines in the inner cylinder. Mounting the firing mechanism is shown in Fig.41.

5. By means of union nut 11 and the lock nut tightly connect the firing mechanism with inner cylinder 22 (See Fig.38).

6. Connect the ejection control wiring to arming pin 6 and the cable interlocking the ejection gun with the canopy cover to the tab of safety pin 5. Unloading the ejection gun is the reverse of the procedure described in Items 1 - 6.

The presence of the explosive charge is checked as indicated in Fig.42. If the ejection gun is loaded, the indicator bush is not depressed and project from the firing mechanism body approximately by 5 mm.

**CAUTION:** It is strictly prohibited to carry out any work on the ejection gun without the safety pin fitted in the firing mechanism, locked, and sealed.

#### Operating Instructions for Ejection Guns and Seats

In view of the fact that ejection seats are very important as a means of rescue of the aircrew in case of emergency, it is necessary to regularly check the condition of their most vital units and mechanisms and carry out the following instructions:

1. Each time after installation of the seat on the aircraft screw into the ejection lever system the ground interlocking bolt (a bolt with a tab) which prevents accidental ejection on the ground.

Before flight these bolts should be unscrewed by the mechanic responsible for ejection seats.

After the aircraft has landed and the aircrew has left the aircraft, the mechanic responsible for ejection seats should enter the aircraft first and screw the ground interlocking bolts on each seat.

Only after this has been done are the rest of the technicians permitted to enter the aircraft.

**Note:** The ground interlocking bolts of the seats should be unscrewed from the ejection lever system only before taxiing for the start after the crew members take their seats.

2. When pulling out the shoulder straps, it is necessary to pull at both straps simultaneously.

3. Take care that the strap adjusting mechanism does not pull in the shoulder straps sharply.

4. When throwing back the back plate on the seats of the navigator, navigator-radar operator, radio operator, and rear gunner, first release the shoulder strap adjusting mechanism or pull out the straps.

5. Each time after installation of the seats on the aircraft connect the cables joining the pins of the ejection guns with the covers of the hatches or

of the canopy. Check the interlocking pin for correct mounting and reliable operation by jettisoning the hatch and canopy covers three times.

On the seats of the navigator, navigator-radar operator, and pilots jettisoning the hatch covers and the canopy should be checked three times from the air system and three times mechanically.

The results of checking should be entered into the aircraft Service Log.

6. The safety harness and foot clamps automatic unlock mechanism AU-3 should be checked for 1.5-sec. operation.

If the aircraft is not to fly for more than one month, release the power springs of the automatic unlock mechanism. For this purpose remove the flexible pin, thereby enabling the mechanism to operate.

7. The free end of the AU-3 mechanism cord should be secured to the aircraft frame.

8. To ensure reliability of the ejection gun operation, it is necessary to clean and lubricate it regularly, as well as to replace the main spring and the explosive charge.

To clean ejection guns remove them from the seats and disassemble.

#### Disassembly and Assembly of Ejection Gun of Seat Ejected Upward from Aircraft

Before beginning the work, make sure that the ground interlocking bolt and the pin interlocking the ejection gun with the canopy cover are fitted in position.

To remove the ejection gun from the seat, do as follows:

1. Remove the seat without the carriage and the armoured back plate.

2. Unload the ejection gun.

3. Remove the ejection gun from the seat disconnecting the upper journal attachment bolts.

The ejection gun should be disassembled as follows:

1. Remove the inner cylinder by pressing off the ball lock piston with a cleaning rod (from the side of the cartridge chamber) or by pulling it from the outside with a hook secured to the tail piece.

2. Unscrew the shock absorber sleeve loosening the stop screw for the purpose and detach it from the outer cylinder together with the mid cylinder.

3. Detach the shock absorber sleeve from the mid cylinder and remove the bush with the rubber shock absorber from the sleeve.

4. Unscrew the ball lock body loosening for this its lock nut and detach it from the outer cylinder. Check whether the paronite gasket is intact.

5. Disassemble the firing mechanism. For this:

(a) remove the safety pin and the arming pin;

(b) unscrew the four attachment screws of the firing mechanism head;

(c) using a drift drive the rod of the explosive charge indicator out of the lower bush;

(d) detach the firing mechanism head from the body, remove the striker and the main spring.

6. Disassemble the ball lock. For this press off the piston, drive the dowel out of the tail piece and detach the lock parts. Check whether the aluminum gasket is present and in good repair.

7. Clean all the parts of the ejection gun from the old lubricant. Clean the cylinders by means of a sponge.

8. Check all the parts of the ejection gun by subjecting them to a thorough outside inspection.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

**Note:** On detecting damage in one of the cylinders replace the entire ejection gun.

9. Apply a thin layer of the WATM-201 lubricant to all the friction surfaces of the ejection gun parts and to the springs of the firing mechanism and the ball lock.

**CAUTION:** Excessive lubrication of the parts may cause failure of the ejection gun.

Assembly of the ejection gun is the reverse of the procedure described in Items 1 - 6.

**Note:** Use a special mandrel for convenience of assembly of the sleeve with the mid cylinder.

2. To assemble the sleeve with the mid cylinder:
  - (a) mount a spring seal in the sleeve and straighten it out in the groove by inserting a mandrel into the sleeve from above;
  - (b) connect the upper end of the mid cylinder with the bush and the rubber shock absorber fitted on it flush with the mandrel;
  - (c) move the sleeve with the spring seal over the mid cylinder and detach the mandrel.

3. The accessories for cleaning and the tools for disassembly and assembly of the ejection gun are shown in Fig. 36.

4. The data concerning inspections, disassembly and assembly, cleaning, firing, replacement of explosive charges and other maintenance operations must be entered in the Certificate of the ejection gun along with the date of the fulfillment of the work and the name of the person who performed the operation. The entry should be signed by the operator.

Disassembly and Assembly of Ejection Gun of Seat Ejected Downward from Aircraft

Prior to disassembly of the ejection gun make sure that the ground interlocking bolt and the pin interlocking the seat with the hatch cover are fitted in position.

To remove the ejection gun from the seat, proceed as follows:

1. Remove the seat from the aircraft.
2. Unload the ejection gun.
3. Throw back the safety handle on the seat and by pressing the arming handle pull out the arming pins of the ejection gun.
4. Disconnect the bolts securing the journals on the firing head and remove the ejection gun from the seat.
  - Disassemble the ejection gun as follows:
    1. Remove the outer cylinder.
    2. Unscrew the upper unit securing the ejection gun to the fuselage frame having loosened the lock nut.
    3. Remove the splint pins from the striker roller mounting spindles and remove the rollers.
    4. Turn out the screws securing the lower cover of the firing head and remove it.
    5. Remove the strikers and the main springs.
    6. Clean all the parts of the ejection gun from the old lubricant.

50X1-HUM

Clean cylinders with the aid of sponges.  
7. Check all the parts of the ejection gun for serviceability by thorough outward inspection.

**Note:** On detecting damage in one of the cylinders, replace the entire ejection gun.

8. Apply a thin layer of the WATM-201 lubricant to all the friction surfaces of the ejection gun parts, main springs, and the ball lock spring.

**CAUTION:** Excessive lubrication of the parts may cause failure of the ejection gun.

Assembly of the ejection gun is the reverse of the procedure described in Items 1 - 5.

- Note:**
1. Use special wrench 4 for mounting arming pins (See Fig. 36).
  2. The data concerning inspections, cleaning, firing, replacement of explosive charges and other maintenance operations must be entered in the ejection gun Certificate along with the date of the fulfillment of the work and the name of the person who carried out the operation. The entry should be signed by the operator.

Checking Operation of Ejection Gun after Assembly

Each time after assembly of the ejection gun it is necessary to:

1. Check by hand mutual displacement of the cylinders until the closing of the ball lock. The cylinders must move smoothly without jamming.
2. Check the ball lock for reliable closing by pulling out the inner cylinder with an effort of 20 to 30 kg and by turning it round.
3. Load the ejection gun with an inert-loaded cartridge or with a dummy primer (explosive charge bottom part).
4. Install the ejection gun on the seat and check the operation of the ejection system and of the ejection gun by firing the inert-loaded cartridge or the dummy primer three times. During each check both primers should be broken but not pierced through.

In case the ejection gun fails once at least, disassemble the firing head (firing mechanism), examine its parts paying special attention to the striker and the main spring, check the strikers for protrusion and test the ejection gun again by firing it six times.

If during this test the ejection gun fails again, replace the main spring and fire the inert-loaded cartridge three times.

After firing clean the parts of the ejection gun from carbon deposit and cover them with a thin layer of the WATM-201 lubricant.

- Note:**
1. When checking the ejection gun, measure the protrusion of the striker beyond the surface of the firing head. The strikers must project:
    - (a) by  $1.9 \pm 0.1$  mm in the ejection guns of the seats ejected from the aircraft downward;

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



**Note:** On detecting damage in one of the cylinders replace the entire ejection gun.

9. Apply a thin layer of the LIATIM-201 lubricant to all the friction surfaces of the ejection gun parts and to the springs of the firing mechanics and the ball lock.

**CAUTION:** Excessive lubrication of the parts may cause failure of the ejection gun.

Assembly of the ejection gun is the reverse of the procedure described in Items 1 - 6.

**Note:** Use a special mandrel for convenience of assembly of the sleeve with the mid cylinder.

2. To assemble the sleeve with the mid cylinder:
  - (a) mount a spring seal in the sleeve and straighten it out in the groove by inserting a mandrel into the sleeve from above;
  - (b) connect the upper end of the mid cylinder with the bush and the rubber shock absorber fitted on it flush with the mandrel;
  - (c) move the sleeve with the spring seal over the mid cylinder and detach the mandrel.

3. The accessories for cleaning and the tools for disassembly and assembly of the ejection gun are shown in Fig. 36.

4. The data concerning inspections, disassembly and assembly, cleaning, firing, replacement of explosive charges and other maintenance operations must be entered in the Certificate of the ejection gun along with the date of the fulfillment of the work and the name of the person who performed the operation. The entry should be signed by the operator.

Disassembly and Assembly of Ejection Gun of Seat Ejected Downward from Aircraft

Prior to disassembly of the ejection gun make sure that the ground interlocking bolt and the pin interlocking the seat with the hatch cover are fitted in position.

To remove the ejection gun from the seat, proceed as follows:

1. Remove the seat from the aircraft.
2. Unload the ejection gun.
3. Throw back the safety handle on the seat and by pressing the arming handle pull out the arming pins of the ejection gun.
4. Disconnect the bolts securing the journals on the firing head and remove the ejection gun from the seat.
  1. Remove the outer cylinder.
  2. Unscrew the upper nut securing the ejection gun to the fuselage frame having loosened the lock nut.
  3. Remove the splint pins from the striker roller mounting spindles and remove the rollers.
  4. Turn out the screws securing the lower cover of the firing head and remove it.
  5. Remove the strikers and the main springs.
  6. Clean all the parts of the ejection gun from the old lubricant.

50X1-HUM

Clean cylinders with the aid of sponges.

7. Check all the parts of the ejection gun for serviceability by thorough outward inspection.

**Note:** On detecting damage in one of the cylinders, replace the entire ejection gun.

8. Apply a thin layer of the LIATIM-201 lubricant to all the friction surfaces of the ejection gun parts, main springs, and the ball lock spring.

**CAUTION:** Excessive lubrication of the parts may cause failure of the ejection gun.

Assembly of the ejection gun is the reverse of the procedure described in Items 1 - 5.

- Note:**
1. Use special wrench  $\Phi$  for mounting arming pins (See Fig. 36).
  2. The data concerning inspections, cleaning, firing, replacement of explosive charges and other maintenance operations must be entered in the ejection gun Certificate along with the date of the fulfillment of the work and the name of the person who carried out the operation. The entry should be signed by the operator.

Checking Operation of Ejection Guns after Assembly

Each time after assembly of the ejection gun it is necessary to:

1. Check by hand actual displacement of the cylinders until the closing of the ball lock. The cylinders must move smoothly without jamming.
2. Check the ball lock for reliable closing by pulling out the inner cylinder with an effort of 20 to 30 kg and by turning it round.
3. Load the ejection gun with an inert-loaded cartridge or with a dummy primer (explosive charge bottom part).
4. Install the ejection gun on the seat and check the operation of the ejection system and of the ejection gun by firing the inert-loaded cartridge or the dummy primer three times. During each check both primers should be broken but not pierced through.

In case the ejection gun fails once at least, disassemble the firing head (firing mechanics), examine its parts paying special attention to the striker and the main spring, check the strikers for protrusion and test the ejection gun again by firing it six times.

If during this test the ejection gun fails again, replace the main spring and fire the inert-loaded cartridge three times.

After firing clean the parts of the ejection gun from carbon deposit and cover them with a thin layer of the LIATIM-201 lubricant.

**Note:** 1. When checking the ejection gun, measure the protrusion of the striker beyond the surface of the firing head. The strikers must project:

- (a) by  $1.9 \pm 0.1$  mm in the ejection guns of the seats ejected from the aircraft downward;

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- (b) by 1.4 to 1.8 mm in the ejection guns of the seats ejected from the aircraft upward.
2. Measure the striker protrusion by means of a vernier caliper. In case the striker protrusion is less than required which may occur when foreign matter gets between the striker flange and the head body, it is necessary to disassemble the firing head and clean its parts.
  3. To remove the fired case of the explosive charge from the ejection gun of the seat ejected from the aircraft upward, press off the striker upward with a screw driver and insert the arming pin in position.

Charging Actuating Cylinder of Navigator-Radar Operator's Ejection Seat  
(Figs 43 and 44)

During service hydraulic fluid may leak out of the actuating cylinder of the navigator-radar operator's seat and out of its hydraulic lock. The amount of hydraulic fluid required for normal operation of the actuating cylinder is determined by the distance between the bottom of the compensating cylinder piston and the top of the hydraulic lock. This distance is equal to  $229.5 \pm 0.5$  mm at 15°C.

In the event of slight leakage (the reference size of 229.5 mm is somewhat increased) charge the hydraulic cylinder as prescribed in Items 6 and 7. The actuating cylinder should be charged with the AM-10 hydraulic fluid on a stand, the key diagram of which is shown in Fig. 45 in the following manner (See Fig. 43):

1. Instead of plugs 4 screw in special adapters. Deliver hydraulic fluid at a pressure of 20 to 30 kg per sq. cm. from the stand into hydraulic lock angle 9 and pump it through both adapters in turn completely extending and retracting the rod of the actuating cylinder.  
Release pressure from the angle.
2. Mount the actuating cylinder with the rod upward and by delivering the hydraulic fluid through the adapter completely extend the rod of the actuating cylinder.
3. Turn the actuating cylinder over with the rod down and by delivering the hydraulic fluid to the cylinder through the other adapter completely retract the rod of the actuating cylinder.
4. Repeat the cycles of pumping the hydraulic fluid through the actuating cylinder until air is completely evacuated from both cavities of the cylinder. This done, screw plugs 4 in position without tightening them up.
5. Mount the actuating cylinder with the charging connection upward and deliver hydraulic fluid under a pressure of not more than 15 kg per sq. cm. into it through the charging connection of the hydraulic lock until air is completely evacuated from the cylinder through plugs 4.
6. Tighten up plugs 4 and holding the rod of the actuating cylinder in a completely retracted position, fill the compensating cylinder of the hydraulic lock with hydraulic fluid to full capacity delivering it through the charging connection.
7. Set the required distance between the bottom of the compensating cylinder piston and the hydraulic lock top with the rod of the actuating cylinder completely retracted. For this purpose mount the actuating cylinder with the charging

connection downward and pressing the charging connection valve, let out the excessive amount of hydraulic fluid.

Note: With every increase or decrease of temperature by 6°C the reference distance of  $229.5 \pm 0.5$  mm increases or decreases respectively by 1 mm approximately.

After charging and mounting the navigator-radar operator's seat actuating cylinder on the aircraft, check it for proper functioning and adjust the rate of lifting and lowering of the seat. For this purpose build up a pressure of 150 kg per sq. cm. in the air system and three times lift and lower the seat. During the check the ejection seat must move up and down smoothly without jerks and jamming. The seat movement must cease on setting the handle of the air cock to the neutral position.

The time required for lifting and lowering the seat with a gun on it must be equal to 2 or 5 seconds and is regulated by throttle needles 10. When screwing out the needle, the time decreases, and vice versa.

The locks opening the way to oil in the hydraulic lock open before the lift cavity of the actuating cylinder is filled with air at a pressure which can balance the weight of the seat with the man sitting on it. Therefore, when the seat is rising from an intermediate position, it may first lower to 30 mm for a short time.

Storage of Live Explosive Charges

- When storing and handling live explosive charges, follow the rules:
1. Live explosive charges should be stored at depots in a clean dry room in tightly closed boxes with recesses for each explosive charge.
  2. It is strictly prohibited to file the explosive charge cases, to rub the explosive charge primer and strike the case.
  3. The explosive charge cases must have no outside defects: dents, scratches, scores, traces of corrosion, etc. It is strictly prohibited to use explosive charges with such defects and explosive charges which have been exposed to rain.
  4. Explosive charges are issued only to persons who are specially authorized to attend to ejection seats and who must sign for the explosive charges issued to them in a special acceptance register.
- Storing explosive charges in the aircraft at the crew working places is strictly prohibited.

2. EMERGENCY ESCAPE AND EXITS HATCHES

Jettisoning Emergency Escape Hatch Covers from Aircraft by Mechanical System

When removing the ejection seats from the aircraft prior to jettisoning the hatch covers, make sure that the ground interlocking bolt of the seat is fitted in position, the pin interlocking the ejection gun with the hatch cover is mounted on the seat and is connected to the hatch cover by means of a cable.

Prior to checking the hatch cover jettisoning mechanism (recovery), pressurize the hatches as follows:

- (a) open the reducing valve on the pressurization system panel. Air pressure in the system should be  $4-0.2$  kg per sq. cm. as indicated by the low-pressure gauge;
- (b) open the cock for air supply to the hatch pressurization hoses.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 56 -

When jettisoning the hatch covers only for the purpose of the removal of ejection seats from the aircraft, the hatches are not to be pressurized. To protect the hatch covers from damage when checking the mechanical and air systems, the covers should be jettisoned on a mat or a tarpaulin panel stretched over the frame of a special cart.

To jettison the fuselage hatch covers from the aircraft by means of the mechanical system, carry out the following operations:

1. Disconnect the snap hook of the ejection gun interlocking cable from the eyelot on the hatch cover; the pin of the interlocking device should remain in its place.
2. Set the ejection seat to the position for ejection.
3. Remove the safety device from the hatch cover remover handle.
4. Command CLEAR HATCHES and on receiving the answer HATCHES CLEARED press the remover handle. The hatch cover jettisoned, the air from the pressurization hose must be let out into the atmosphere. The cover must fall out of the hatch without jamming under the action of its own weight.

Check jettisoning the pilots' canopy covers from the mechanical system in the following manner:

1. Disconnect the snap hook of the ejection gun interlocking cable from the eyelot on the cover.
2. Press down the canopy cover jettison handle.
3. By slightly tapping on the cover from the inside of the cockpit knock it out of the canopy hatch edging.

**Notes:** 1. When checking the jettisoning of the pilots' canopy covers, two persons should be outside the cockpit (one should be on a ladder the other - on the fuselage) to support the cover and remove it from the canopy.

2. The covers of the emergency escape (extruder) hatches in the fuselage and on the pilots' canopy should be jettisoned by applying an effort of not more than 20 kg to the handle on an equaling two thirds of the handle length (from its axis of rotation). The effort applied to the handle to jettison the rear summer's hatch cover should not exceed 30 kg.

#### Mounting Navigator's Emergency Escape Hatch Cover

(Fig. 46)

Prior to mounting the navigator's hatch cover on the aircraft, it is necessary to open the hatch on the cover skin and by turning lever 6 as indicated by the arrow to disengage front hooks 11 from stops 10.

To mount the hatch cover, perform the following operations:

1. Wipe the pressurization hose with talcum powder and place it into the groove of the hatch edging.
2. Engage the rear dowels of the cover in the respective sockets on the hatch edging.
3. Close the cover raising it by the front rib. In the closed position the cover should enter the hatch flush with the outside contour of the aircraft, the pin of bell crank 5 should enter the slit of mechanical system lever 6. Then press down handle 2 to the jettisoning position. At this movement of handle 2 lever 6 will turn in the direction of the arrow shown in Fig. 46.

- 57 -

4. Through the hatch on the cover skin raise the transverse member connecting hooks 11 with each other and engage the hooks in the stops on the hatch edging.

Raise the transverse member with a wooden support so as not to damage its protective coating.

5. Move handle 2 to the upper position corresponding to cover closing and move stops 10 located on one common axle 9 close under the rollers mounted on the hook tail pieces. Roll cranks 15 must thrust against the stop on the cover and lock the mechanism in the fixed position. The position of the hinge should be checked from the inside of the cockpit.

6. Check the hatch cover for proper installation by the notches on lever 6 and on the bracket securing it to the cover.

If the hatch cover is mounted correctly, these notches should match.

7. Close the hatch on the cover skin.

#### Mounting Cover of Pilots' Canopy Emergency Escape Hatch

(Fig. 47)

To mount the cover of the pilots' canopy hatch, perform the following operations:

1. Wipe the pressurization hose with talcum powder and place it into groove of the hatch edging.
2. Move handle 3 to the lower position.
3. Mount the cover on the dowels of stops 26 and press the cover to the hatch edging; the dowels must enter the holes of brackets 25.
4. Turn clamps 12 so that their holes match the holes in supporting brackets 10. The ends of clamps 12 must enter the holes of bearing plates 13.
5. Move handle 3 to the upper position supporting clamps 12. Front stops 11 will fix clamps 12 in position.
6. Raise hooks 17 so that their holes line up with dowels 19 which must be previously engaged in shackles 16. Then, pressing the cover from top in its mid part pull out stop 24. At this moment under the action of spring 21 lock dowels 19 enter the holes of hooks 17.

#### Mounting Cover of Navigator-Radar Operator's Emergency Escape Hatch

(Fig. 48)

Prior to mounting the cover of the navigator-radar operator's hatch:

1. Open the hatch on the hatch cover skin.
2. Release hooks 18 from stops 15 by moving rod 8 in the direction of the arrow shown in Fig. 48.
3. Move handle 1 upward to the cover jettison position.
4. Wipe the pressurization hose with talcum powder and place it into the hatch edging groove.

To mount the hatch cover, perform the following operations:

1. Move fixed stops 12 of the hatch cover under stops 13 on its edging. The pin of rod 8 must enter the open slit of lever 17.
2. Turn handle 7 so as to withdraw rear dowels 18 into the cover.
3. Through the hatch on the cover skin raise transverse member 15 connecting hooks 14 with each other and fix the hooks by stops 13.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

- 3. Raise the transverse member by means of a wooden support so as not to damage its protective coating.
- 4. Move handle 1 to the lever closed position and move stops 16 under the rollers of hooks 14 connecting at the same time the shackle of the winch cable to the dowel of mechanism 5.
- 5. The lever of bell crank 10 must assume the fixed (dead) position which should be checked from the inside of the cockpit.
- 6. Close handle 7; dowels 18 will enter their recesses on the hatch edging and the cover must close flush with the aircraft skin.
- 7. Check the hatch cover for proper mounting by the notches on bell crank 10 and lever 9.
- 8. Close the hatch on the cover skin.
- 9. Open the hatch. Check to see that the hatch cover in the open position does not thrust with its front edge against the fuselage skin which is ensured by adjusting the length of cable 4 of winch 2.

- 1. Wipe the pressurization hoses with talcum powder and place them correctly into the hatch edging grooves so that the hose is not jammed when the doors and covers are closed.
- 2. Each time after closing the entrance hatch of the front pressurized cockpit unlock the winch drum.
- 3. The hatch door jettison handles of the mechanical and air systems must be locked and sealed at all times.
- 4. The handles of the air system cocks of all hatch covers and the handles of the mechanical system of jettisoning the pilots' canopy covers and the gunner-radio operator's hatch cover should be locked with soft steel wire, 0.5 mm in diameter.
- 5. The handles of the mechanical system of the navigator's, navigator-radar operator's, and rear gunner's hatch covers should be locked with copper wire, 0.5 mm in diameter.

Mounting Covers of Emergency Escape Hatches of Gunner-Radio Operator and Rear Gunner

(Figs 49 and 50)

Prior to mounting the covers of the emergency escape hatches of the gunner-radio operator and the rear gunner on the aircraft, open the hatches for access to the mechanical systems.

The covers of the emergency escape hatches of the navigator's and navigator-radar operator's emergency escape hatches.

After the covers have been mounted on the aircraft, check them for correct and reliable locking by their locks. For this, by means of a wrench turn the pivot of the bell cranks with hooks for stopping the engaged parts. If the stop is in the correct position, red levers 9 (See Fig.49) and 6 (See Fig.50) designed for locking the engaged parts will thrust against the cover plane. This done, seal the guide.

Entrance Hatches

The entrance hatches open against the air stream from the cockpit and from the outside of the aircraft by means of handles. The handle for opening the hatch from the cockpit is located on the top of the cover, while that for opening the entrance hatch from the outside is depressed in the cover flush with its skin.

In the open position the entrance hatch cover of the rear pressurized cockpit is held by a duralumin plate which is folded when the hatch closes.

The entrance hatch of the front pressurized cockpit is held open by the winch cable. After the hatch has been closed by the winch, it is necessary to unlock the winch drum so that when jettisoning the hatch cover, the winch cable is tensioned.

Instructions on Care and Maintenance of Entrance and Emergency Escape Hatch Covers

- 1. During service perform care and maintenance operations as follows:
  - (a) Apply periodically the GHAITH-201 lubricant to the locks, hinges, friction surfaces of pivots, and sealed connections.
  - (b) Remove the old lubricant with gasoline and apply fresh lubricant.

3. LIFE BOATS, TYPE MAC-5H

General

Pneumatic life boats, type MAC-5H, are group means of rescuing the aircrew in case the aircraft alights in water.

The aircraft is provided with two life boats placed in special containers on the port side (Fig.51). One of the life boats in the container located between frames Nos 12 and 15 is intended for the aircrew members of the front cockpit; the other life boat located in the container between frames Nos 62 and 63 is intended for the aircrew members of the rear cockpit.

Each life boat is designed to accommodate five men.

Specifications and Complete Set of

MAC-5H Life Boat

- 1. Overall dimensions of the life boat with the sail installed on it:
  - (a) length . . . . . 290 ± 5 cm.
  - (b) width . . . . . 140 ± 3 cm.
  - (c) height (complete) . . . . . 239 cm.
  - (d) draft (keel included) . . . . . 70 cm.
- 2. Life boat load-carrying capacity . . . . . 500 kg
- 3. Weight of life boat fully equipped . . . . . 30 kg
- 4. Life boat side compartments charger . . . . . carbon dioxide delivered from boat cylinder
- 5. Amount of dehydrated carbon dioxide for charging boat cylinder:
  - (a) in summer . . . . . 1350 gr
  - (b) in winter . . . . . 1600 gr
- 6. Life boat speed when oar-driven (in the calm) . . . . . 3 km/hr
- 7. Life boat speed under sail (depending on wind velocity) . . . . . 4 to 12 km/hr
- 8. Maximum permissible wind velocity with life boat going under sail . . . . . 13 km/hr
- 9. Life boat set includes (amount in pieces):
  - (a) sail . . . . . 1
  - (b) oars with rubber rings . . . . . 3
  - (c) extension for mast with rigging (of two parts) . . . . . 1

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



(d) cylinder with CO <sub>2</sub> for inflation of boat sides . . . . .	1
(e) hand pump with hose for inflation of bottom and seat . . . . .	1
(f) sea anchor for reducing speed of life boat drift . . . . .	1
(g) scoop . . . . .	1
(h) water-proof bag for holding emergency radio, first-aid kit, and compass . . . . .	1
(i) rubber plugs . . . . .	4
(j) connector cord with snap hook . . . . .	1
(k) case with repair material and spare parts . . . . .	1 set per several life boats
(l) packing case . . . . .	1

Packing Life Boats into Aircraft Containers  
(Fig. 52)

- Prior to packing the life boat into the aircraft container:
1. Examine the life boat and make sure it is in good repair. Servicesability of the boat is checked against the guaranteed service life.
  2. Check the presence of the protective clamp on the cylinder cock.
  3. Make sure that the guaranteed term of the cylinder operation (marked on the upper spherical part of the cylinder) has not expired.
  4. Weigh the cylinder and make sure that it contains the required amount of carbon dioxide. The amount of carbon dioxide contained in the cylinder is determined as the difference between the weight of the cylinder with carbon dioxide and the weight of the empty cylinder with the cock.
  5. Check to see that the nut of the rod with the striker on the Ivanov coil is screwed on the rod so that after the connecting clamp is fitted in the nut slit (with the two-arm lever in the lower position), this clamp does not get out of the slit and at the same time does not compress the rod spring.
  6. Secure the cylinder in position in the life boat pocket and connect the cylinder pipe union with the life boat two-piece by means of the union nut located on the two-piece.
  7. Remove all the equipment except the cylinder from the life boat.
  8. Unroll the life boat on a flat surface and completely unscrew the lock nuts on the cocks of its sections.
  9. By rolling up the life boat toward its rear and press out air from its sections, then unroll the life boat again to prepare it for placing into the aircraft container.
  10. Fully screw up the lock nuts on the section cocks which open when the life boat is unrolled.
  11. To prevent the life boat from being inflated during flight, carefully remove the air remaining in the side sections, inflated seat, and bottom by means of a hand pump. For this screw one end of the pump connector hose into the body of the pump suction valve and its other end on the cocks of the sections, inflated seat, and bottom in turn.

50X1-HUM

Just after screwing the tip of the pump connector hose on the cock of the life boat section, unscrew the lock nut of the cock together with the hose by two or three turns. After the air has been removed from the section screw up the lock nut again as far as it will go and then unscrew from it the tip of the pump connector hose.

**CAUTION:** After the air has been evacuated from all the sections of the life boat, remove the pump connector hose from the suction valve and connect it to the delivery valve.

11. Place the oars, extension, pump, sail, and cone plugs into the nose pocket of the life boat. This done, lace up the pocket.
12. Put food and water (or distiller), the first-aid kit, and signs of signaling into the water-proof bag. Then secure the water-proof bag to the loops on the life boat by means of pins.
13. Lay out the life boat on a flat surface again.

**Note:** Lay out the life boat which is to be placed into the first container with the bottom up and the life boat which is to be placed into the rear container with the bottom down.

14. Fold the sides of the life boat body to the centre so that the width of the folded life boat is equal approximately to 750 mm and roll up the life boat.

15. Prior to placing the life boat into the aircraft container, check the container cover remote control for proper functioning.

During the check pay attention to the correctness of the control adjustment when the container cover is open and the correctness of the cylinder cock operation. The cylinder cock must operate immediately after the locks of the container cover have been opened.

The succession of operations of the locks and the cock should be checked by bringing the remote control into operation from the seats of the aircraft members with the container cover open and the empty cylinder without the boat placed into the container.

16. After the operation of the container locks and the cylinder cock has been checked, place the life boat into the container and connect the snap hook of its connector cord to the container eye.

Connect the cable of the cylinder cock remote control to the fork of its lever having previously passed it through the guide hole in the cock bracket. To prevent the cable ball from jumping out, tie it up with two threads No. 10.

17. Remove the protective clamp from the rod of the cylinder cock.

18. Prior to closing the container cover check whether there is free space for the cock lever taking into consideration its movement (throwing back) when the cover is being open.

19. Secure the container cover in position.

- For this purpose:
- (a) fit the cover hinges over the studs in the box base;
  - (b) press the covers.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

(c) pull and then let go the cover (it serves also as a handle) of the auxiliary hatch.

**CAUTION:** Pull the cable of the auxiliary hatch smoothly because a strong pull at the cable may cause the cock of the life boat cylinder to operate.

20. Check the lock for reliable closing and the closed container cover for correct position relative to the fuselage contour.

The locks are checked for correct closing by the position of the lock indicator.

21. Seal the slots between the container cover and the fuselage skin with tape, type *HTL*.

22. Install seals on the container cover remote control handles.

Life Boat Faults Encountered During Service and Their Elimination

The following faults may be encountered during service: punctures, separation of parts, small tears, stiff movement of the pump piston and its ineffective operation.

In the event of such faults the life boat can be repaired in the unit.

To repair the tears, proceed as follows:

1. Slightly clean the damaged portion of the life boat with glass paper, wipe it with a clean piece of cloth soaked in gasoline and dry during 5 minutes.  
2. Cut a patch of the required size from the rubberized cloth included in the life boat group set and treat it in the same manner as the damaged portion on the life boat. Round off the patch corners.

3. Apply a thin layer of rubber cement No. 4508 to the cleaned portion of the life boat and the patch (the cement is included in the repair set). Then in 10 or 15 minutes apply a second layer of cement and in another 10 or 15 minutes apply a third layer.

4. Keep the parts covered with cement in the air till gasoline contained in the cement has completely evaporated (the cement must not stick to the fingers).

5. Place a patch on the damaged portion of the life boat and roll it tightly with a cylindrical object.

6. Reinforce the life boat portion under repair by fitting another patch of the same material over the first one. The second patch should overlap the first one by 20 or 30 mm.

The second patch is prepared and cemented in the same manner as the first one.

In case separated seams are detected, thoroughly wash the surfaces of the seams and parts with gasoline and then coat them with cement and proceed as prescribed above.

After the repair, check (after 24 hours) the life boat for strength and tightness in the following manner:

1. Evacuate the cylinder with carbon dioxide.  
2. By means of the hand pump charge the life boat compartments with air so that pressure in the boat sides, inflated seat, and bottom is equal to 80 mm of mercury (465 km. per hour by the speed indicator).  
Keep the life boat under this pressure during four hours and then examine it carefully.

The life boat is considered to be fit for service after the repair if air

50X1-HUM

pressure in its compartments decreases during 3 hours not more than to 50 mm of mercury (370 km. per hour by the speed indicator) and in the inflated seat not more than to 40 mm of mercury (355 km. per hour by the speed indicator).

After the repair record the results of inspection and check in the life boat Service Log.

Repair of Life Boat Hand Pump

During service defects in the hand pump may arise. They are detected by stiff movement of the piston or by ineffective operation of the pump. The defects may be caused by improper lubrication of the piston leather cups.

Disassemble the defective piston and fill the cylinder recesses between the piston cups with oil, mark *W3*.

To disassemble the pump, carry out the following operations:

- (a) remove the upper cover of the pump;
- (b) remove the rod with the piston;
- (c) unlock the end face screw securing the piston to the rod;
- (d) remove the piston.

Assembly of the pump is the reverse of the procedure described in

Items 1 - 4.

Charging Life Boat Cylinder

with Carbon Dioxide

To charge the life boat cylinder with carbon dioxide, it is necessary to have the following tools and equipment:

- (a) pump for charging the cylinders with carbon dioxide. In case a pump is not available, the life boat cylinder can be charged from the transportation cylinder with carbon dioxide;
- (b) special wrench for the nut of the Ivanov cock (supplied with the cock);
- (c) set of standard wrenches of the following sizes: 42, 30, 22, 20, 16, and 12 mm;
- (d) tube of red copper 6x2 mm in size and 2 m. long with union nuts at the ends for the cocks of the transportation cylinder and the cylinder to be charged;
- (e) scales with a set of weights up to 10 kg accurate within 10 gr;
- (f) screw driver;
- (g) standard capsules for the Ivanov cock.

Prior to charging the cylinder make sure that the guaranteed term of cylinder service life and that of storage of carbon dioxide in the transportation cylinder have not expired, that is the cylinder and the carbon dioxide are fit for service.

The cylinders are charged with dehydrated carbon dioxide. To charge the cylinder, proceed as follows (Fig. 53):

- 1. Unscrew nut 9 of the rod on the Ivanov cock.
- 2. Using a special wrench and a screw driver unscrew nut 11 with capsule 2 and then replace the damaged capsule by a new one.
- 3. Pour 15 gr of 96° rectified alcohol into the cylinder.
- 4. By means of a special wrench and a screw driver screw the plug with the capsule into the cock socket as far as it will go. Weigh the cylinder together with the wrench.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

5. Connect the cock of the cylinder to be charged to that of the transportation cylinder through the pump or directly, by means of a separate pipe.

**Note:** When delivering carbon dioxide from the transportation cylinder to the cylinder being charged, the transportation cylinder should be installed with the cock downward. The cock of the cylinder being charged should be below that of the transportation cylinder.

6. Open the transportation cylinder cock. If charging is done by means of a pump, open the shut-off cock of the pump distributing pipe.

7. Unscrew the nut with the capsule by 3 or 4 turns and put the cylinder on the scales.

After the cylinder has been filled with carbon dioxide to the required weight, screw up the nut with the capsule so far as it will go and screw up the shut-off cock of the pump distributing pipe.

8. Disconnect the cylinder from the pipe line and weigh the cylinder again together with the wrench. If there is excessive amount of carbon dioxide, release part of carbon dioxide into the atmosphere.

9. Unscrew the special wrench from the cock of the charged cylinder and make sure that there is no leakage of carbon dioxide.

**Note:** Check the cylinder for leakage after its cock has completely turned out, that is approximately in two hours, when the cock has assumed the ambient temperature. To perform the leakage test cover the cock with soapy water and watch for bubbles. The appearance of air bubbles is indicative of leakage.

10. Screw up the gland nut and mount the protective clamp on the cock. Having charged the cylinder of the life boat, make a corresponding entry in the Service Log.

Use of Life Boat

Life boats are dropped after alighting when the aircraft has stopped sailing on water just before the aircrew members abandon the sinking plane.

To drop the life boat, sharply pull out the handle. This will cause the container to open and will put the cylinder with carbon dioxide into action.

The life boat becomes inflated with gas, gets out of the container and is held near the aircraft by the connector cord.

If prior to the sinking of the aircraft the life boat is not disconnected from the aircraft by someone of the aircrew, after complete sinking of the aircraft the strap fastening the connector cord to the life boat will break and the life boat will remain afloat.

**CAUTION:** It is not recommended to jump into the life boat from the aircraft so as not to damage the life boat bottom.

After the aircrew members get into the life boat, check whether its compartments are fully inflated with gas and, if necessary, pump air into the corresponding compartments by means of the hand pump and charge the inflated seat and the bottom with air.

To pump air into the side compartments, the inflated seat, and the life boat bottom, proceed as follows:

- (a) take the hand pump out of the life boat luggage compartment and screw one end of its connecting hose into the charging pipe union and its other end into the cock of the life boat compartment to be charged;
  - (b) screw out the cock of the boat compartment to be inflated by two turns;
  - (c) charge the compartment with air so that on pressing the casing with the thumb, the casing caves inward but slightly;
  - (d) screw up the cock as far as it will go;
  - (e) disconnect the connecting hose of the hand pump from the cock.
- On detecting a hole in the life boat casing choose a conical plug corresponding to the size of the hole. By energetically screwing the plug into the hole, close the latter so that no air bubbles come out of it.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

Chapter IV  
AIRCRAFT CONTROLS  
CARE AND MAINTENANCE

1. CARE OF AIRCRAFT CONTROL SYSTEMS  
AND PERIODICAL CHECKS  
(Fig. 54)

An aircraft in service should be constantly checked for condition of its control systems. Periodically, when carrying out scheduled maintenance operations as well as during preflight and postflight inspections, perform the following operations:

1. Check the rudder, elevators, ailerons and their trim tabs (servo tabs) angular and linear deflections comparing the data obtained with the data in Table 6.

Table 6  
Angular and Linear Deflections of Aircraft  
Control Surfaces

Name of control surface	Direction of deflection	Angle of deflection, deg.		Deflection in linear size, mm	
		value	tolerance	value	tolerance
Elevator	Upward	25	- 1	112	- 12
	Downward	12	- 1	144	- 12
Elevator trim tab	Upward	12	- 2	36	- 6
	Downward	8	+ 1	24	+ 3

	1	2	3	4	5	6
Rudder		To the right To the left	25	- 1	137	- 18
Trim tab used as rudder servo tab		To the right To the left	15°40'	+ 1 - 2	61	+ 4 - 8
Rudder trim tab		To the right To the left	7	± 1	28	± 4
Ailerons		Upward Downward	15	- 1	238	- 16
Trim tab used as aileron servo tab		Upward Downward	15°30'	± 20'	15	± 1
Aileron trim tab		Upward Downward	5	± 40'	17	± 2

Notes 1. The angular and linear deflections of the rudder, elevators, ailerons and trim tabs are to be measured at their trailing edges at the bases of the ground-adjustable trim tabs. The control surfaces should be checked for deflection as follows: the ailerons and their trim tabs - at their inner faces, the elevators - at their inner faces, with the trim tabs in the neutral position, the elevator trim tabs - at the outer faces, the rudder - at the lower face, and its trim tab - at the upper face.

2. With the aileron deflection close to its maximum value, the trim tab used as a servo tab should deflect by 15°±1 mm; with the aileron deflection close to its minimum value, the trim tab should deflect by 15°±1 mm.

CAUTION: Prior to adjusting the ailerons and rudder do not fail to read the entries in the aircraft Service Log pertaining to the additional operations performed on these control systems. The description of these operations is to be found in Section 8 "Special Instructions" of this Chapter.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

2. Check the rudder, elevators, ailerons and their trim tabs for proper responses:

- (a) when the control columns are pulled back, the elevator should go upward, and when they are pushed forward, the elevator should move downward;
- (b) when the aileron control wheel is turned to the right (clockwise), the right-hand aileron should go upward and the left-hand aileron - downward; when the aileron control wheel is turned to the left (counter-clockwise), the right-hand aileron should go down, whereas the left-hand one should move upward;
- (c) when the right-hand pedals of each panel are pushed forward (in the direction of flight), the rudder should deflect to the right, and when the left-hand pedals are pushed forward, the rudder should deflect to the left;
- (d) when the rudder and ailerons are deflected by the mechanical system, the trim tabs (servo tabs) should automatically move in the direction opposite to that of the rudder and ailerons;
- (e) when the mechanical control wheel upper part is moved forward, the trim tabs of the elevators should go up, and when the wheel upper part is pulled back, trim tabs should move down;
- (f) when the knobs of the elevator trim tab electric control system switches are pushed forward, the trim tabs should go upward, and when they are pulled back the trim tabs should go down (the switch knobs are located on the thickened spoke of the pilots' control wheels);
- (g) when the rudder trim tab electric control switch knobs located on the wall panels are moved to the right, the rudder trim tab should move to the left, and when the knobs are moved to the left, the trim tab should go to the right. With the trim tab in the neutral position, the signal lamp on the instrument board of the left pilot (in the R.H. lower portion) should be on;
- (h) when the aileron trim tab electric control switch knobs located on the wall panels are moved to the right, the trim tabs should move as follows: that of the R.H. aileron - downward; that of the L.H. aileron - upward; when the knobs are moved to the left, the R.H. aileron trim tab should move upward and that of the L.H. aileron should go downward. With the trim tabs in the neutral position, the signal lamps on the instrument board of the left pilot (in the R.H. lower portion) and on the synchronizing panel (behind the seat of the left pilot) should be on;
- (i) the movement of the elevators and rudder in the mechanical system is limited by stops on the quadrant bell cranks located at frame No.69, whereas the movement of the ailerons is restricted by stops arranged on the brackets of the bell cranks located at wing ribs No.16;
- (j) when the stops located on the extreme lower position, the control column should touch the stops located on the middle stands of the foot control assembly;
- (k) the movement of the elevator trim tabs (in the control wheel mechanical system) is restricted by ball stops on the cable located at frames Nos 61 to 63 and resting against the tuxolite plate on frame No.62;
- (l) the movement of the trim tabs of the rudder, elevators and ailerons in the electric control systems is restricted by limit switches arranged as follows: those for the rudder and aileron trim tabs - in the electric mechanisms; those for the elevator trim tabs - on the column of the distributing drums on the rear cable upper panel;
- (m) when the handles of the locking systems are placed in position LOCKED (ЗАКЛЮЧЕНО), the rudder, elevators, and ailerons should be fixed without knocks and appreciable play in the following positions:
  - (1) the elevator should be fixed in the downmost position; in this position the control columns should rest on the front stops and the clearance between them and the instrument boards should be at least 32 mm;

- (2) the rudder should be fixed in the neutral position and the pedal quadrants should be lined up;
  - (3) the ailerons should be fixed in the neutral position; in this position both control wheels should be turned to the right (clockwise) through an angle of 8°;
  - (a) when the elevator trim tabs are in the neutral position, the pointers of their position indicators on the panels should stand against zero, and the pointer flicker in both directions should be equal;
  - (c) when the handles of the rudder, elevator, and aileron locking systems are placed in position UNLOCKED (ОТКЛЮЧЕНО), there should be a clearance of 3 mm between the faces of the locking pins and the nearest moving parts of the control system to be locked;
  - (p) with the rudder, elevators, and ailerons moved to any position, their trim tabs should deflect as indicated in Table 8.
3. The cables of the aileron control system which pass under the pilots' cabin floor, the cables connecting the autopilot servo units, the cables of the rudder, elevator, and aileron locking system, as well as the cables of the elevator trim tab control system, should be tightened as indicated in the Charts (Figs 55, 56, 57, and 58). The tension of the cables running from the autopilot servo unit drums in the rudder and elevator control systems should be checked in accordance with the data given in Fig.59.
4. The friction forces in the mechanical control systems must not exceed 7 kg in the elevator system, 10 kg in the rudder system, 5 kg in the aileron system, and 2.5 kg in the elevator trim tab system.
- The friction force measuring diagrams for these systems are given in Figs 60, 61, 62, and 63. The friction forces should be measured by means of a reference dynamometer. During the test the controls (control wheel, pedals, etc.) should be moved gradually from the initial to the extreme positions. The efforts required for starting the system at the beginning are not taken into account. The mean value of three measurements is taken as the resultant friction force value.
5. Check the condition of lubricant in the hinge joints and fairleads.
- During service the following components should be always coated with a thick layer of the GRAYM-201 lubricant only:
- (a) all hinge joints of the rods and bell cranks and the connections of the rods;
  - (b) the cable fairleads. The recess of the fairlead unit of the rudder, elevator, and aileron control rods should be completely filled with lubricant;
  - (c) the entire cable length;
  - (d) the pulleys of the rod guiding supports;
  - (e) the cable grooves in the pulleys, cable drums, and quadrants;
  - (f) the spherical supports of the aileron control mechanisms and the aileron carrier pins entering the supports.
6. Check the bell cranks, drums and pulleys for easy and smooth rotation within the entire working range of displacement of these parts. This range should ensure such a deflection of the rudder, elevators, ailerons, and trim tabs (servo tabs) as indicated in Table 8.
7. Check the position of all moving and rotating parts of the aircraft control systems with respect to the framework and equipment. When moving, these parts must be clear of the aircraft framework and equipment. During the check see that the following clearances are retained:
- (a) at least 3 mm between the cables and stationary parts of the aircraft structure in the spaces between the cable supports, and at least 2 mm between the

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

— 70 —

same elements at a distance of up to 100 mm from the places where the cables run off the pulleys. In places where the cable connecting parts may touch each other or touch the framework of the aircraft, the cable connecting elements should be enclosed in leather covers;

(b) at least 5 mm between the rods of the rigid control system and the aircraft framework in the spaces between the rod supports, and at least 2 mm between these elements at a distance of up to 100 mm from the support. If the support is a bell crank, this clearance should be ensured at all working positions of the bell crank;

(c) at least 5 mm between the control moving parts and the moving parts of any other assembly.

**Note:** The cable is allowed to touch textolite parts, but must have no bends.

8. Check the clearances between the moving parts on the foot control assemblies, as well as between these parts and the stationary parts. The clearance in these places should be not less than 3 mm, except:

(a) the clearance between the pedals and the side stamped carriers of their suspension. This clearance should not be less than 1.5 mm;

(b) the clearances between the quadrant bell cranks of the pedals and the bolt nuts on the lower arms of the cast control bell cranks of the L.G. wheel braking valves. This clearance should be at least 2 mm;

(c) the clearance between the pedal quadrant bell cranks and the control column tubes. This clearance should not be less than 5 mm.

9. Check the clearances between the beads of the cable control pulleys and the restricting sheaths or the part of the brackets that prevents the cables from running off the pulleys. The clearances in these places should be:

0.15 to 0.8 mm for 2.5-mm dia. cables;

0.15 to 1.0 mm for 3.5- and 4.5-mm dia. cables;

0.15 to 2.5 mm for 8-mm dia. cables.

The side clearances between the pulleys and the webs of their brackets should not be less than 0.5 mm.

10. Check the clearances between the tubes of the rigid control rods and the control pulleys of their supports. When the tube is pressed to two pulleys, the clearance between this tube and the third pulley should be within 0.15 - 1.0 mm (Fig. 64). In case this clearance exceeds the indicated value, replace one of the three pulleys by a pulley of a larger diameter. In doing so, observe the following:

at a clearance of 1.1 mm the diameter of a new pulley should exceed that of the replaced pulley by 1.8 mm;

at a clearance of 1.2 mm, by 2.1 mm;

at a clearance of 1.3 mm, by 2.4 mm.

After installation of a new pulley the clearance should be within 0.15 - 0.6 mm.

11. Check the clearance between the tubular rivets of the rods and the pulley of their supports with the rudder and elevator moved to the extreme positions. This clearance should be at least 3 mm.

12. Check the rod tubes for "cold hardening" and longitudinal dents on the surface under the support control pulleys. "Cold hardening" up to 0.5 mm deep is permissible. In the case of deeper "cold hardening", turn the tube through 180° on its axis. In case "cold hardening" on both opposite sides of the tube is deeper than 0.5 mm in one section, replace the rod by a new one.

13. Check the condition of the cables throughout their length. There should be no torn strands. In places where the cables bend over the pulleys, in the plastic "eyes", on the textolite collars or where the cables touch the textolite facing, the cable surface may have minor chafing and "cold hardening". Do not fail to bend the chafed and "cold hardened" cable sections and check them for torn strands. A cable with torn strands should be replaced by a new one.

14. Check the condition of the aileron control cables running under the floor of the pilots' cabin. Such checks should be performed at least after every 50 flying hours. After 100 flying hours replace these cables by new ones regardless of their condition.

15. Check the position of the cables with respect to the plane of their control pulleys. In places where the cables run off the pulleys and the quadrant bell cranks, the permissible misalignment of the cables with respect to the plane of their control pulleys is up to 2° (3.5 mm over a distance of 100 mm). In this case the cable must not touch the pulley beads (Fig. 65). Excessive misalignment of a cable should be remedied by placing washers under the pulley bracket footing. In places where the cables run off the drums of the autopilot servo units, as well as off the pulleys connected by cables with the drums of the autopilot servo units, a misalignment of up to 4° is permissible.

16. Check the condition of the control pulleys in the cable systems. The pulleys may be chafed on the inner surfaces of the beads of the cable grooves, but the thickness of the beads on their outer diameter should be not less than 0.6 mm on pulleys for 2.5-mm dia. cables and not less than 1 mm on pulleys for 3.5- and 4.5-mm dia. cables.

Should textolite exfoliation or binding in ball bearings be detected, replace the pulleys by new ones.

17. Check the position of the cables in the grooves of the drums, pulleys and quadrants. The cables should make a tight fit with the grooves of the drums and quadrants. The grooves should be well greased.

18. Check the condition of the threaded cable lugs. They should be turned into the couplings to an equal length, and not more than three threads may protrude beyond the coupling face.

19. Check the condition of the rubber covers on the universal joints of the elevator trim tab control mechanism. The covers should have no holes through which the lubricant could leak out.

20. Check the hinge joints of the rods and bell cranks as well as the rivet joints of the rods for play. There should be no appreciable play or knocking. Should any play or wear of the hinge bolt be detected during the inspection of the joint, replace the bolt. If hole expansion is detected in the rod forks, replace the rods or press-fit bushings into the forks.

21. Check the condition of the universal joints of the rudder, elevator, and elevator trim tab control mechanisms. In the case of play (knocks) in these joints, replace the joints by new ones.

22. Check to see that there is no excessive play in the locking pins of the mechanism serving to adjust the pedals to the height of the pilot. Permissible diametral play in the quadrant recesses is 0.4 mm.

23. Check the trailing edges of the trim tabs for play, which must not exceed 3.5 mm. The play is measured with dynamometer A9883-0 with an effort of 4 kg applied to the base of the ground-adjustable trim tab opposite the rod attachment levers.

24. Check the condition of the chrome-plated rods of the rigid control fairlead assembly. There should be no traces of brass on the rod working stroke per-

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 72 -

tions. Should brass traces be detected, replace the rubber sealing rings in the fairlead assembly. Brass traces are the result of the rod rubbing against its brass bushing which testifies to considerable wear of the rubber sealing rings and to side play of the rod.

25. Check the condition of the rubber cores of the cable fairleads. Worn cores should be replaced by new ones. The recess of the new core should be filled with fresh grease.

26. Check the condition of the bonding strips. During operation of the control systems these strips are allowed to touch the adjacent components of the aircraft structure without embracing the projecting parts of the latter and without interfering with the movement of the control systems on their working strip portions.

Bonding strips with broken wires over 25% should be replaced by new ones.

27. Check the tightening of the attachment bolt nuts of the supports of the control columns, foot control assemblies and elevator trim tab control assembly as well as the tightening of the nuts of all the brackets and supports of the rigid and cable controls. The nuts should be well tightened, and the castellated nuts cottered. The attachment must be tight and have no play.

28. Check the tightening of the bolts of the split and hinge joints of the cables and rods of all the control systems. The bolts should be well tightened, and their nuts cottered. The cable turnbuckles should be locked with wire.

29. Check the condition of the anticorrosive coating and paint of the parts. Damaged coating should be promptly restored.

#### 2. ACCESS PANELS TO CONTROL SYSTEM UNITS

To inspect and adjust separate units of the aircraft control systems arranged under the floor of the pilots' front pressurized cabin between frames Nos 5 and there are access panels located on the longitudinal and lateral beams of the fuselage framework. Access to the aileron control quadrant bell crank located at frame No 8 is ensured by removal of the L.H. pilot's seat. The cables of the engine control panels are inspected through access holes located on the panel vertical walls. The control elements behind frame No. 9 are examined from the side of the entrance hatch door.

Access to the control linkage between frames Nos 12 and 56 is ensured by access panels in the fuselage skin and by holes made in the vertical walls of the beams. The removable panel located on the vertical wall of the L.H. beam between frames Nos 46 and 49 provides for removal and installation of the rigid control elements arranged between frames Nos 26 and 56. Removal and installation of the rudder, elevator, and aileron control rods between frames Nos 12 and 26 are done through an access panel in the compartment of the L.O. nose leg.

The cable and rigid control linkage between frames Nos 56 and 69 is not covered and is open for inspection.

The rudder and elevator control systems, as well as the elevator trim tab control system located above the upper panel of the rear pressurized cabin, can be inspected with the components of the stabilizer and fin fairings removed. Recoverable side panels on the fin tail provide access to the rudder universal joint shaft. The rudder trim tab (servo tab) control system units are accessible through access panels and fairings on the fin and on the rudder. The elevator trim tab control system elements located inside the elevator are examined through access panels and also with the trim tab actuating mechanism fairings removed.

- 73 -

50X1-HUM

The aileron controls in the first detachable wing sections are examined through access panels located in the upper skin behind the spar, through cuts made in the wing above the trailing edge, with the engine nacelle covers removed, and with the main landing gear doors open.

The controls of the ailerons and their trim tabs (servo tabs) in the second detachable wing sections are accessible through access panels located in the skin lower surface, through removable panels in the vicinity of the ailerons, and with the aileron trim tab control rod fairings removed.

#### 3. ADJUSTMENT OF MAIN AIRCRAFT CONTROL SYSTEMS

##### Elevator Control System

The elevator control system is adjusted as follows:

1. Place the elevator in the neutral position and fix it with screw clamps.
2. Place the control columns in the neutral position (in this position the column tubes are inclined forward by  $1^{\circ}30' + 15'$ ) and fix them to the pedal attachment tubes.
3. Connect the control system rods to each other and to the bell cranks.
4. Place the control system bell cranks in the neutral position, for which purpose, adjust the length of the rods by means of their threaded ends.
5. Adjust the position of the stops on the quadrant bell crank at frame No. 69. To this end, release the elevators and control columns and move the elevators up and down to the extreme positions indicated in Table 8.
6. Check the elevators for correct movement to the extreme positions, then lock the adjustable rod ends, cotter the nuts of the hinge bolts and put in place the aircraft bonding strips removed during adjustment.
7. Measure the friction force in the control system (See Fig. 60). It should not exceed 7 kg.

##### Rudder Control System

The rudder control system is adjusted as follows:

1. Lock the control system quadrant bell crank located at frame No. 69.
2. Place the rudder in the neutral position along the rear edge of the fin tail fairing, for which purpose adjust the length of the rod so as to connect the upper arm of the quadrant bell crank with the bell crank which is linked with the rudder universal joint shaft.
3. Adjust the position of the stops on the quadrant bell crank, for which purpose move the rudder to the left- and right-hand extreme positions indicated in Table 8.
4. Place the foot control pedals in the neutral position. In this position the pedals set into the similar regulating holes of the quadrants should be aligned. Secure the pedals in the neutral position by placing a wooden plank between the foot control assembly and the pedals.
5. Interconnect the control system rods and connect them to the bell cranks.
6. Place all control system bell cranks in the neutral position, adjusting the length of the rods by means of their threaded ends.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

7. Check the rudder for correct movement to the extreme positions, for the purpose release the pedals and unlock the quadrant bell crank, then lock the adjustable rod ends, cotter the nuts of the hinge bolts and put in place the aircraft bonding strips removed during adjustment.
8. Measure the friction force in the control system (See Fig. 61). It should not exceed 10 kg.

Aileron Control System

The aileron control system is adjusted as follows:

1. Place the wheels of the control columns in the neutral position. In this position the axis of the spoke with the arrow should be parallel to the tube of the control column. Make sure through the inspection ports in the control column heads, that the middle link of the geared chain (with its shaft cottered) is located along the control column centre line.
2. Connect the cables coming out of the control columns with the cables of the quadrant bell crank on frame No. 8.
3. Place the quadrant bell crank in the neutral position by adjusting the length.
4. Lock the control system bell crank located at frame No. 33 and connect with the quadrant bell crank by means of rods.
5. Release the control column wheels and by means of the threaded ends adjust the length of the rods at the fairlead assembly to place the control column so that they are inclined to the right (clockwise) by an angle of  $8 \pm 1^\circ$ .
6. Tighten the cables in accordance with the data given in Fig. 55.
7. Place the ailerons in the neutral position and fix them with screw clays.
8. Connect the aileron control rods to the bell crank located on the L.H. at frame No. 33.
9. Place the control system intermediate bell cranks on the rear wing spar in the neutral position adjusting the length of the rods by means of their three ends.
10. Release the bell crank at frame No. 33. Then move the ailerons up and down in turn on the left and right wings to the extreme positions indicated in Table 8 to adjust the position of the stops at the bell cranks located in the vicinity of ribs No. 16.
11. Check the extreme positions of the ailerons, then lock the adjustable threaded ends of the rods, cotter the nuts of the hinge bolts and put in place the aircraft bonding strips removed during adjustment.
12. Measure the friction force in the control system (See Fig. 62). It should not exceed 5 kg.

4. ADJUSTMENT OF TENSION OF CABLES CONNECTING MAIN CONTROL SYSTEMS WITH AUTOPILOT SERVO UNITS

Tension of the cables of these systems is adjusted as follows:

1. Adjust cable tension in accordance with the data given in Figs 56 and 57 keeping the drums of the servo units in the neutral position.
2. Actuate the main system controls to check the rudder, elevators and ailerons for correct movement to the extreme positions with the autopilot cut off.

3. Measure the effort required for servo unit drum slipping with the autopilot operating. The heads of the bolts securing the cables to the quadrants should face the aircraft centre line.

Note: Adjustment of the servo units of the autopilot is described in the respective Section of Chapter "Electric Equipment", see "Ty-16 Aircraft. Service Manual", Book II.

5. ADJUSTMENT OF ELEVATOR TRIM TAB CONTROL SYSTEM

This system is adjusted as follows:

1. Place the trim tabs in the neutral position. Then connect by means of cables the trim tab actuating mechanism drums located in both halves of the elevator with the drums of the distributing column on the upper panel of the rear cabin. The ends of the cables running from the mechanism drums should be of equal length and come off the drum in the middle.

Note: If one or both trim tabs cannot be placed in the neutral position, disconnect their mechanism from the trim tab control horns and place the trim tabs in the neutral position by screwing in or out the threaded ends of the mechanism. If adjustment of the mechanism threaded ends does not ensure exact placing of the trim tabs in the neutral position, then place washers of the required thickness between the drum body footing and the spar wall.

2. Connect the cables of the distributing column drums and of the trim tab actuating mechanisms and adjust their tension in accordance with the data given in Fig. 58.

3. Check the trim tabs for correct movement to the extreme positions (See Table 8), turning the distributing column drums by the cables.

4. Place the trim tab actuating mechanisms on the L.H. and R.H. pilots' panels in the neutral position. The trim tab position indicator pointers should stand against zero and have equal play in both directions, whereas the cables should run off in the middle of the drums.

5. Connect all the system cables between the panel and distributing column drums and adjust their tension in accordance with the data given in Fig. 50.

6. Check the trim tabs for maximum deflection according to Table 8, as well as the limiting of the control system travel by the ball restrictors placed at the textolite collar on frame No. 62.

Note: On replacing a cable with restricting balls upset the balls on the new cable so that they approach the textolite collar on frame No. 62 when the trim tabs are in the extreme positions.

7. Cotter the nuts of the cable bolt joints and the restricting shafts. Then lock the turnbuckles.

8. Put leather covers in place and connect the cables located at frames Nos 9 and 56 and in both halves of the elevator.

Note: Adjustment of the limit switches of the JT-11 electric mechanism is described in Chapter "Electrical Equipment", see "Ty-16 Aircraft. Service Manual", Book II.

9. Measure the friction force in the control system (See Fig. 63). It should not exceed 2.5 kg.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

76  
6. ADJUSTMENT OF SYSTEM USED TO LOCK RUDDER, ELEVATORS,  
AND ALLERONS ON PARKED AIRCRAFT

This system is adjusted in the UNLOCKED position as follows:

1. Use shims to assure a clearance of  $3^{11}$  mm between the faces of the locking mechanism pins and the locking recesses on the sliding elements of the control systems of the elevators, rudder (chrome-coated plates on the quadrant bell at frame No. 69) and ailerons (the shackle on the upper arm of the L.H. bell at frame No. 33).
2. Fix the locking handle on the L.H. pilot's panel in the UNLOCKED position.
3. Connect all cables of the locking system and adjust their tension consecutively in accordance with the data given in Fig. 57. Adjust also the tension of the rudder, elevator, aileron, and engine throttle control locking cables.
4. Check the operation of the system, seeing that:
  - (a) in the locked position the pins enter the respective recesses on the elements of the locked system. When varying loads are applied to the pedals, wheels, rudder, elevators or ailerons with the system locked, there should be no knocks in the joints of the locking pins due to play. Deflection of control elements due to resilience is permissible;
  - (b) with the system unlocked, the clearance between the faces of the lock pins and the sliding parts of the system to be locked is within  $3^{11}$  mm;
  - (c) the locking handle is securely fixed in the front and rear extreme positions.
5. Grease the nuts of the cable bolt joints and the restricting shafts, in lock the cable turnbuckles.
6. Put the leather covers on the cable joints located between frames Nos. 1 and 34 and at frame No. 56.

7. ADJUSTMENT OF RUDDER AND ALLERON TRIM TAB (SERVO TAB)  
CONTROL SYSTEMS

The rudder and aileron trim tab (servo tab) control systems are adjusted with the trim tabs and the rods of the trim tab control electric mechanisms (EM-100A-36 and EM-100A-60) in the neutral position. This is done as follows:

1. Connect the electric mechanism rod with the bell crank.
2. Put the rods in place retaining the trim tabs in the neutral position.
3. Check the deflection angles of the trim tab used as a servo tab when the rudder or aileron is moved to the extreme positions. This should be done in compliance with Table 8. If the rudder deflection angles to the right and to the left and the aileron deflection angles upward and downward are correspondingly equal, the deflection angles of their trim tabs (servo tabs) should also be equal.

**Note:** The proportion between the deflection angles of the aileron trim tab (servo tab) and the aileron should be observed most carefully, otherwise the pilot may experience appreciable load difference in the control system when the aircraft is banked to the right or left. If the trim tab deflection angles are not equal at equal deflection angles of the rudder or ailerons on both sides, this defect should be removed by reducing or increasing the length of the rods by means of their threaded ends. Adjustment should be performed with the trim tab in the neutral position.

4. Check the movement of the trim tab to the extreme positions from the electric mechanism. In doing so observe the data given in Table 8. This check is done with the rudder and ailerons in the neutral position and when they are moved to their extreme positions in both directions.

**Note:** Adjustment of the electric control system and electric mechanism limit switches is described in Chapter "Electrical Equipment", see "F-16 Aircraft, Service Manual", Book II.

5. Grease the hinge bolts, lock the adjustable rod ends and put in place the aircraft bonding strips removed during adjustment.

## 8. SPECIAL INSTRUCTIONS

Flying tests performed at the Manufacturing plant have shown that some of the serial aircraft issued by the plant do not possess at first the sufficient lateral and directional stability which is then ensured during the finishing process at the plant airfield. Such defects may also occur during service of the aircraft due to distortion of profiles or shape of both airframe assemblies and aircraft controls.

This Section contains description of various defects in aircraft lateral and directional stability detected at the Manufacturing plant, as well as the recommended methods of their remedy. Besides, instructions are given here on correction of these defects in the course of aircraft service.

Aircraft Lateral and Directional Instability,  
Methods of Correction at Manufacturing Plant

During flying tests at the Manufacturing plant additional operations are performed on some serial aircraft to ensure normal lateral and directional stability. These operations are based on the reports of the test pilots. Description of these additional operations is entered in the aircraft Service Log. Prior to checking adjustment of the aircraft control system in service do not fail to read the entries in the Service Log pertaining to the operations performed on the aircraft control system.

Flying tests at the Manufacturing plant have revealed the following defects in the control system of some aircraft:

1. The aircraft tends to bank with the ailerons and their trim tabs in the neutral position. This phenomenon takes place at high and low speeds of the aircraft only.
2. The aircraft acquires lateral stability only after deflecting to a certain extent the control column wheel from the neutral position, with no load from the ailerons felt on the control wheel, i.e. when the ailerons are moved to some distance from the neutral position.
3. Considerable difference in loads on the control wheel when the aircraft is banked to the right and to the left. This difference results from unequal aerodynamic compensation of the ailerons.
4. Total loads on the control wheel from the ailerons at all permissible flight operating conditions are too great or too small.
5. The aircraft tends to turn (to yaw) when the rudder and its trim tab are in the neutral position.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

The above defects are partially or completely eliminated at the Manufacturing plant depending on the flying test results. This is done by the following methods.

The tendency of the aircraft to bank is eliminated by balancing the aircraft in flight using the aileron trim tabs (the aileron trim tab neutral position indicating lamps may be dead). The flight over, adjust the operation of the aileron trim tab neutral position indicating lamps by the balancing position of the trim tabs detected in flight.

Deflection of the control column wheels from the neutral position is remedied only if this deflection exceeds 8° in straight-and-level flight at maximum ratings (height H = 0.6H<sub>max</sub>, speed V<sub>ind</sub> = 550 km/hr, and height H = 0.85H<sub>max</sub>; speed V<sub>ind</sub> = 500 km/hr); since a larger deflection of the control wheel will make aircraft control too difficult. The defect is remedied by creating "acissors" on the ailerons (the left-hand aileron is deflected downward and the right-hand aileron - upward from the neutral position, or vice versa) within the deflection range of 2-8 mm as measured along the trailing edges.

Relative equalizing of the different load values exercised on the control wheel, when the aircraft is banked to the right or to the left, is achieved by reducing to some extent the maximum upward deflection of the servo tab of the aileron which goes down when a bank causing "smaller" load on the wheel is performed, i.e. the "smaller" load bank is given some additional load. For instance, if it is easier to bank the aircraft to the right than to the left, it is necessary to reduce maximum upward deflection of the servo tab of the left-hand aileron, which goes down during a right-hand bank. Conversely, when it is necessary to bank the aircraft to the left, reduce servocompensation of the right-hand aileron which goes down during the bank. The upward movement of the servo tabs may be decreased when equalizing the loads on the control wheel up to 15 mm. In performing this operation, see that the trim tabs remain in the neutral position when the ailerons are neutral.

Other recommended steps for equalizing the load on the wheel are:

- (a) increase of the width of the slot between the aileron front edge which goes down when a "heavier" bank is performed and the trailing edge of the wing by a value of up to 6 mm as measured along the lower part of the wing profile;
  - (b) change in degree of inner aerodynamic compensation of the aileron due to partial closing of the special parts in the aileron front portions. This will result in increase of the inner compensation on the aileron which goes down when a "heavier" bank is performed. Depending on the difference of the loads, the ports on this aileron may be completely closed.
- Aileron control at excessive load on the control wheel can be made easier by closing the ports on the aileron front portions.
- To make aileron control "heavier" when the load on the control wheel is too small, displace the covers of the special parts to open the through holes made in the aileron front portions. Arrangement of the holes and the degree of hole opening should be the same on both ailerons.

The tendency of the aircraft to turn (to yaw) is eliminated depending on its intensity as follows:

- (a) a turn of the aircraft, which can be eliminated in flight by deflecting the rudder trim tab by 2-3 mm, is remedied by bending the adjustable trim tab by 1 mm in the same direction in which the trim tab was deflected during flight. The neutral position of the trim tab, with the rudder in the neutral position, should be retained;
- (b) a turn of the aircraft, which can be eliminated in flight by deflecting the rudder trim tab by 4 mm and more and which causes displacement of the right-

50X1-HUM

pedal by 40 to 60 mm with respect to the left-hand one, is remedied by displacing the neutral position of the trim tab by 3 mm in the direction of its motion during flight.

All operations performed in order to eliminate one or several defects must be duly registered in the Service Log of the given aircraft.

If a defect or defects recorded in the Service Log occur during the aircraft service again, then it is necessary first of all to check whether the control components are still in the positions recorded in the Service Log. If the aircraft control system components are in positions other than those set during adjustment, or if deformation is found on the adjustable trim tabs, repeat adjustment of the controls and recondition the adjustable trim tabs in strict compliance with the entries made in the Service Log.

Elimination of Lateral and Directional Instability of Aircraft Detected during Service

Minor deformation of the airframe elements due to unpredictable aerodynamic loads or due to rough landings, etc. may be the cause of lateral and directional instability described in this Section. These deficiencies may also develop on aircraft when replacing their ailerons, rudder, as well as their trim tabs. Elimination of defects in aircraft balancing should be accomplished in the same way as during the test flights at the Manufacturing plant airfield (See Section 8).

This Section deals with the methods of determining and correcting the defects in aircraft balancing. The defects in aircraft balancing are reported by the pilots and discovered by measuring the positions of the trim tabs and control wheels during the postflight inspection of the aircraft.

Determination of Aircraft Lateral and Directional Instability by Pilots during Flight

Instability is determined by the pilot in a horizontal straight flight at intermediate ratings in the following way:

1. When the pilot finds out that the aircraft tends to bank spontaneously, he should first of all determine the direction of the bank, balance the aircraft by the aileron trim tabs, and land the aircraft with the trim tabs deflected. After landing do not place the trim tabs in the neutral position until the angle of deflection is measured.
2. If during flight the balanced position of the aircraft is assumed only when the control wheel is turned by more than 8° from the neutral position, the pilot should make a mark on the upper part of the control column (Fig. 66) corresponding to the position of the control wheel in balanced flight and note the direction in which the control wheel was turned. Then on the ground it is necessary to determine by the marks the angle of control wheel deflection at which the aircraft assumes its balanced position in flight.
3. When the pilot finds out that there is a considerable difference in the loads on the control wheel in banking the aircraft to the right and to the left under the given flight conditions, the pilot should note the direction of the bank at which a smaller effort is required.
4. If it is discovered during flight that the loads in the aileron control system are too large or too small as the aircraft is banked, the pilot must determine whether the effort required is excessive or insufficient under the given flight conditions (for instance, the loads from the ailerons are too large, aileron control is difficult, aileron control is very difficult, etc.).
5. If the aircraft tends to turn spontaneously under the given flight condi-

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 80 -

tions, the pilot must eliminate this turn by actuating the rudder trim tab. Note the direction of the turn, and land with the trim tab deflected. If it has been found out in eliminating the aircraft spontaneous turn by moving the trim tab that the displacement of the right-hand pedals with respect to the left-hand ones exceeds 40 to 50 mm, the pilot must visually determine the actual amount of pedal displacement. After landing the rudder trim tab must not be placed in the neutral position before measuring the angle of trim tab deflection in flight.

Measurements to Be Taken during Postflight Inspection  
in Case of Aircraft Lateral and Directional Instability

If one or several of the above-mentioned deficiencies in aircraft lateral and directional stability have been revealed in flight, and the pilot has followed the instructions prescribed in the previous Section, then the following operations must be performed during the postflight inspection:

1. If the aircraft tends to bank spontaneously, measure the linear deflection of the trim tabs and ailerons, at which the aircraft has no bank.
2. If in lateral balancing the aircraft requires excessive deflection of the control wheel (above  $8^\circ$ ), measure the distance between the marks made on the head of the control column (Fig. 67).
3. If the aircraft tends to turn spontaneously, measure the amount of linear deflection of the rudder trim tab at which there is no spontaneous turn of the aircraft in flight.

Notes: 1. Measurements under Items 1, 2, and 3 should be accomplished with the aileron and rudder control systems locked. With the systems in this position, check the neutral position both of the ailerons and of the rudder. The neutral position of the rudder should be checked also in case there are no complaints of the pilot about the aircraft directional instability.

2. If the pilot reports about a difference in the loads at the right and left banks, measure carefully the linear deflection of the trim tabs (servo tabs) of the right-hand and left-hand ailerons at maximum deflections of the ailerons, as well as linear maximum deflections of the ailerons proper.

3. If the pilot reports about difficulties in aileron control, check the aerodynamic compensation elements for pressure tightness.

4. Should considerable deviations from the adjustment standard in the aileron and rudder control systems or bad deformation of adjustable trim tabs be found during the measurements and examination of the aircraft, repair the defects on the rudder or its trim tabs following the technical data of the aircraft and special notes in the aircraft Service Log, after which perform a test flight.

Correction of Lateral and Directional Instability in Accordance  
with Pilot's Reports and Measurement Results  
during Postflight Inspection of Aircraft

On the basis of the pilot's report and results of the measurements taken during the postflight inspection of the aircraft, as well as on the basis of the results of the checking operations indicated in the previous paragraph, eliminate the detected faults in lateral and directional stability of the aircraft using the following methods:

- 81 -

50X1-HUM

1. An excessive deflection of the control wheel from the neutral position (above  $8^\circ$ ) in lateral balancing of the aircraft is eliminated by creating "scissors" on both ailerons. This is done by deflecting the ailerons within  $\pm 8$  mm (Fig. 69), with the control system locked and the control columns in the neutral adjustment position (in this position the control columns are inclined to the right in the clockwise direction by an angle of  $8 \pm 1^\circ$ ). The "scissors" on the ailerons are created by adjusting the threaded ends of the aileron control system rods located in the wells of the right- and left-hand legs of the main landing gear, bearing in mind that half a turn of the threaded end deflects the aileron by 2.5 - 3 mm.

Note: In creating aileron "scissors" to eliminate control wheel deflections, do not immediately deflect the ailerons by the maximum value of  $\pm 8$  mm; deflect the ailerons gradually (creating first "scissors" of, say,  $\pm 2.5$  to 3 mm), and check each time their effectiveness in flight.

In determining the deflection angle of the control wheels on the basis of the results of measuring the distance between the marks, bear in mind that  $1^\circ$  of angular deflection of the control wheel corresponds to 0.83-mm linear displacement of the mark along the circumference of the control wheel hub.

The linear deflection of the control wheel to the right or to the left in the air should not exceed 6.7 mm by the marks, which corresponds to a maximum deflection angle of  $8^\circ$  of the control wheel.

2. The loads on the control wheel when banking the aircraft to the right or to the left are equalized by reducing the deflection of the servo tab which goes upward when performing a bank with a smaller effort. If the pilot feels that it is more difficult to bank the aircraft to the left than to the right, it is necessary to reduce the upward deflection of the servo tab of the left aileron which is deflected downwards. At reverse relation of loads on the control column reduce the upward deflection of the right-hand aileron servo tab.

The upward deflection of the servo tabs on the ailerons deflected downwards is reduced by shortening the servo tab control system rods. The thread of the rod ends has a pitch of 1 mm. Permissible shortening of the rods is 0.5 to 3 mm which corresponds to 0.5 - 3 turns of the rod end.

In this case the linear deflection of the servo tabs upward may be reduced to 15-2 mm.

Note: In reducing the upward deflection of the servo tab see that, with the ailerons in the neutral position, the tabs also retain their neutral position.

3. Normal total load on the control column from the ailerons is ensured in the following way.

Aileron control can be made "heavier" with the help of special lids installed in the aileron leading edges and used for regulating the area of through holes in the ailerons (Fig. 70). Opening of the holes makes control "heavier". This is achieved by setting the hole lids in one of the three regulating positions.

The number of holes drilled, as well as the extent to which the holes are opened under one, two or three lids, is determined by the pilot's estimation of the aileron control ease.

Note: In the course of aircraft service aileron control may become "heavier" as the pressure tightness of the elements of the aileron internal sero-

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

82

dynamic compensator is impaired. Aileron control can be made "easier" by reducing gradually the number of opened holes which are to be plugged one by one on each aileron asymmetrically to the aircraft axis (Fig. 71) or by reducing the hole area for which purpose the holes are covered with lids. The hole area should be reduced equally on each aileron and asymmetrically with respect to the aircraft axis. After placement of the internal compensator elements on the aircraft, aileron control may become too "easy" and it may be necessary to open the previously closed holes or set the lids in the initial position for aileron control "heavier".

8. Aircraft tendency to turn spontaneously is eliminated in the following ways:

(a) a turn of the aircraft, which can be counteracted in flight by deflection of the rudder trim tab up to 2 mm is eliminated by bending the ground-adjustable trim tab up to 1 mm in the direction of trim tab deflection during flight. The neutral position of the trim tab must be retained;

(b) a turn of the aircraft, which can be eliminated in flight by deflection of the trim tab above 2 mm and displacing the pedals above 40 mm but less than 60 - 100 mm with the aircraft balanced, is eliminated by shifting the neutral position of the rudder trim tab up to 3 mm in the direction of its deflection during flight (Fig. 72). With the trim tab in its new neutral position, the tail lamp on the left-hand pilot's instrument board should be on.

To shift the neutral position of the trim tab by 3 mm, the threaded end of the rod connecting the bell cranks on the fin spar with the rudder must be screwed in or out by half a turn.

All additional operations on aircraft controls performed during service should be recorded in the aircraft Service Log.

9. WING FLAP CONTROL

General

The landing flap system is controlled with the aid of electric mechanisms. The flap drive electric mechanisms (set MKB-31) are included into a tubular transmission which actuates eight jacks. Each of the two inner and two outer halves of the wing.

The flap position indicators, type J3B-47, are located on the instrument boards of both pilots and are electrically connected to the transmitter mounted in the transmission and driven by the transmission through the can of the mechanism of the MKB-2 limit switches. This mechanism switches on the warning lamp which operates if the flaps are not extended during take-off or landing of the aircraft.

The supply circuits to the MKB-31 electric mechanisms of the flap drive transmission are broken by the mechanism of the MKB-11 limit switches.

The flap control system layout (on the right wing outer panel) is shown in Fig. 73.

83

50X1-HUM

Access Panels for Inspection of Flap Control and Its Units

The units of the wing flap control system are located on the wing rear spar. The gear supports of the guide rails are mounted in the tail parts of the first and second wing detachable sections.

To get at the control system units it is necessary first of all to extend the flaps and open the cargo compartment doors.

Access to the electric mechanisms of the MKB-31 set, located on the upper part of the centre plane to the left of the aircraft axis, is possible through the cargo compartment and through the access panel in the fuselage top skin. To operate the MKB-31 electric mechanism by hand, remove the fasteners (items 107) along with the beam on which they are mounted.

Access through the flap control is ensured: in the first wing detachable section - through the access panels in the top skin and through the access panels in the skin of the wing trailing edge above the flaps, as well as through the access panels in the skin for the jacks and guide rails; in the second wing detachable section - through the cuts and access panels in the skin of the wing trailing edge above the flaps.

Instructions on Servicing and Checking Control System

1. Flaps retracted:

(a) the flaps should conform to the wing contour. Permissible flap deflections are shown in Fig. 74;

(b) the flap trailing edges should be properly tightened by the rear locks;

(c) the pointer of the main (left) flap position indicator, type J3B-47, should read zero;

(d) no twisting of the transmission is permissible. Transmission twisting is determined by the marks with the inscription J3B (upper stop) made on the left side of the MKB-31 set reduction gear body and on the sliding part of the transmission. When the flap is being retracted, the transmission must stop 30 to 180° short of the mark made on the reduction gear body.

2. Flaps completely extended:

(a) the flaps should deflect through an angle of 35 ± 1° or, if linear measurements are taken in points A, B, and B (Figs 75 and 76), by 1052.5 ± 2.5, 1066.5 ± 5, and 982 ± 5 mm respectively;

(b) the distance between the contact point of the rear pulleys of the guide rails and the rear cut of the rail at ribs Nos 4 and 5 must not be less than 40 mm, and at ribs Nos 8, 11, and 14 must not be less than 45 mm;

(c) the pointer of the main (left) flap position indicator, type J3B-47, should read the actual deflection angle of the flaps accurate within ± 1°;

(d) no twisting of the transmission is permissible. Transmission twisting is determined by the marks with the inscription J3B (lower stop) made on the right side of the MKB-31 set reduction gear body and on the transmission sliding part. The transmission must stop 30 to 180° short of the mark on the reduction gear body;

(e) setting the flaps to the maximum extended position must be accompanied by slight knock on the stops of one or several jacks.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

3. Control system operates on the ground at a circuit voltage of 26 - 28 V.
- the time required for extending the flaps with both MKB-3M electric mechanisms operating must not exceed 25 sec., and the current consumed must not exceed 155 A;
  - the time required for retracting the flaps with both MKB-3M electric mechanisms operating must not exceed 25 sec., and the current consumed must not exceed 160 A;
  - the time required for extending the flaps with one MKB-3M electric mechanism operating must not exceed 50 sec., and the current consumed must not exceed 80 A;
  - the time required for retracting the flaps with one electric mechanism operating must not exceed 50 sec., and the current consumed must not exceed 85 A.

4. In breaking the supply circuit to both electric mechanisms of the MKB-3M set when the flaps approach their extreme positions, the mechanism of the MKB-11 limit switches should stop the transmission in positions indicated in Items 14 and 24. The microswitches must operate simultaneously, permissible difference being  $40^\circ$  of transmission shaft turn.

5. The warning horn should operate within the following ranges of flap deflection angles: from  $0$  to  $19_{-1}^0$  and from  $23_{-1}^0$  to  $35_{+1}^0$ . The limit switches of the MKB-2 mechanism should cut off the warning horn within flap deflection angle from  $19_{-1}^0$  to  $23_{-1}^0$  and switch it on in all other working positions.

6. All along the flap deflection angle range the JMN-47 position indicator should read the actual deflection angles of the wing flaps accurate within  $\pm 1^\circ$ .

**Notes:** 1. The time required for the system to operate for extension and retraction of the flaps, as well as the current consumed, should be checked five times employing both electric mechanisms of the MKB-3M set simultaneously or each electric mechanism separately.

2. The time of operation of the limit switches of the MKB-11 and MKB-2 mechanisms as well as the readings of the flap position indicator on the instrument board of the left-hand pilot, should be checked by extending and retracting the flaps five times. The testing conditions are to be set in conformity with the data given in the Certificate of the MKB-3M set.

3. The results of the tests described in Items 3, 4, 5, and 6 should be entered in the aircraft Service Log.

7. During extension and retraction the flaps should move without jarring or jerks. In the case of sharp noise check the movement of the carriages.

8. The carriage pulleys with needle bearings should rotate smoothly (without binding).

9. The felt brushes on the covers of the carriage pulleys should always be in good condition; giving up old brushes and installation of new ones should be done with glue 88.

10. The chrome-plated working surfaces of the rails should be dry and clean.

11. During service check regularly the condition of the lubricant, bearing in mind that:

- the bodies of the jack heads should be filled with lubricant to  $2/3$  of their capacity;

- the lubricant in the oilers of the transmission bearings, jacks, and on the legs of the jack sliding nuts in the joints with the flap control horns should be changed in due time;
- the rubber covers on the universal joints of the transmission shaft should be filled with lubricant, airtight, and tightly clamped by the rings.

12. During service the play and clearances in the aircraft control system should remain within the following limits:

- the clearances between the sliding and rotating parts of the flap control system and the structural elements of the aircraft framework must not be less than 3 mm in all working positions of the parts;

- the clearances between the rails and the carriage side pulleys must not exceed 1 mm;

- the total two-side clearance between the flange rests at the transmission joints located between ribs Nos 3 and 4, 10 and 11, as well as between the faces of the bearing bushes must be 0.5 to 3.3 mm;

- the flap play measured at the trailing edges and originating due to the clearance in the worm pair (jack - carriage) must not exceed 5 mm with the flaps in any position;

- the diametral clearance between the steel coupling of the transmission shaft and the bronze bush of the bearing must not exceed 0.7 mm;

- the transmission spline joints may have a circumferential play of not more than 0.2 mm and a diametral play of up to 0.13 mm;

- certain wear of hinges in the universal joints of the transmission is permissible; this wear is due to an increase in the hole diameter and a decrease in the bolt diameter. The clearance in the universal joint must not exceed 0.085 mm;

- certain wear of holes and bolts is permissible in the bolt joints of the transmission shafts. The originating diametral clearance must not exceed 0.1 mm.

13. Perform at regular intervals the following checks on the wing flap jacks:

- check the torque value on the spline driving shaft which ensures movement of the nut in the horizontal position without jack loading. This value should not exceed 20 kg-cm;

- check the angular clearance in the meshed bevel gears. It should not exceed  $1^\circ$  or, when linear measurements are taken, it should not be more than 1.74 mm over an arc of 100 mm;

- measure the axial play in the ball joint between the screw and the sliding nut. It should not exceed 0.45 mm;

- measure the run-out of the sliding nut. When measured at the eyes of the forked tube, it should not exceed 0.8 mm.

14. The transmission shafts, load-carrying struts, attachment side braces of the guide rails, as well as the guide rails, should be inspected systematically and checked for cracks.

**Note:** During the examination pay special attention to the edges of the holes for transmission joint flange bolts located between the MKB-3M set and the first jack. To examine the hole edges from both sides of the hole it is necessary to turn off the nuts and knock the bolts out of the hole by 4 - 5 mm.

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

- 86 -

15. The main parts and units of the control system are repaired or replaced when the following defects are discovered:

- (a) knocks in the hinges of the universal and bolt joints of the transmission;
- (b) deformation and cracks on the lands of the carriage frames;
- (c) cracking and exfoliation of the transmission bearing bronze bushes;
- (d) deformation of the forked tube of the jack sliding nuts and appearance of dents, scores, and cracks on the tube;
- (e) deformation of links of the jack sliding casings and appearance of cracks, dents, and scores;
- (f) cracks and exfoliation on the flanges of the jack limit stops and on the can surfaces;
- (g) deformation of transmission spline joints and chipping of spline working surfaces;
- (h) mechanical damage on steel distance sleeves and bronze bushes in the joints between the jacks and the flap pivots, on the hinge joint bolts, carriage rollers and on the bolts of the joints between the transmission shafts and the steel couplings where they slide in the bearings.

#### Control System Adjustment

Adjustment of the control system which, when operated by the hand drive, must extend the flaps to the given angle, with the sliding nuts of one or several jacks resting on the lower stops, includes adjustment of the limit switches (MKB-11 mechanism) in the supply circuit of the MIB-3M electric mechanisms, adjustment of the limit switches (MKB-2 mechanism) in the supply circuit of the warning horn, as well as adjustment of the FJM-47 flap position indicator.

#### Adjustment of Limit Switch Mechanisms MKB-11 and MKB-2

The position of the transmission, with the flaps fully extended, when the sliding nuts of the jacks are on the rear ("lower") stops, is determined by alignment of the notches marked FJM (lower stop) and located on the transmission shaft end on the R.H. side of the MIB-3M electric mechanism reduction gear body, whereas the position of the transmission, with the flaps fully retracted, when the sliding nuts of the jacks are on the front ("upper") stops, is determined by alignment of the notches marked FJB (upper stop) and located on the transmission shaft end on the L.H. side of the reduction gear body.

During adjustment the flaps are deflected manually with the aid of brace bit 9813-120 placed on the hand drive of the MIB-3M mechanism after removal of the heaters of item No. 107 along with the beam on which they are mounted.

**CAUTION:** In adjustment of the MKB-11 limit switch mechanism closely follow the data given in the previous Subsection.

#### Adjustment of MKB-11 Limit Switch Mechanism Position in Retracting Flaps

1. Place dial 9813-135 on the transmission shaft and indicating pointer 9813-131 on the attachment bracket of the alleron servo unit (Fig. 77).
2. Open the cover of the MKB-11 limit switch (Fig. 78), slacken six screws securing the can discs that control the flap retracted position, and connect a tester (a bell or a signal lamp) to the limit switch circuit.

- 87 -

50X1-HUM

3. Set the flaps to the retracted position according to the notches.
4. Give the transmission 3 or 4 revolutions for flap extension.
5. Turn the caps of the discs (in the MKB-11 limit switches) which control flap retraction into a position at which the limit switches break the circuits. The limit switches must break the circuits when the transmission is turned by an angle not exceeding 40°. Then tighten the attachment screws of the can discs.
6. Fully extend the flaps and then retract them again from the MIB-3M electric mechanisms. In extending and retracting the flaps check the operation of the limit switches and the position of the flaps during retraction, as well as the position of the transmission by the FJB (upper stop) notches.

**Note:** 1. If the flaps cannot be fully retracted, determine the number of transmission shaft revolutions by which they are short of the required position and readjust the limit switches. To this end, reduce the number of transmission revolutions made during the preliminary adjustment by the number of revolutions required for putting the flaps in the correct position.

Adjustment of the MKB-11 limit switches for flap retraction is considered satisfactory, if during three retractions of the flaps by means of two MIB-3M electric mechanisms, the requirements under items 1 and 4 of Subsection "Instructions on Servicing and Checking Control System", Section 9, are complied with.

2. After extending or retracting the flaps by means of two MIB-3M electric mechanisms make a 5-min. interval to allow the mechanisms to cool down; when the flaps are retracted or extended by means of one electric mechanism, make a 10-min. interval.

3. After five cycles (extension-retraction) performed from two MIB-3M electric mechanisms or after two complete cycles performed from one electric mechanism, make an interval to allow the electric mechanisms to cool down completely.

7. After adjustment make notches with inscriptions RB (upper cutout) on the transmission sliding portion and on the left-hand side of the reduction gear body of the MIB-3M not to fix the position when the tester (a bell or a signal lamp) cut into the circuit indicates the breaking moment of the limit switch.

#### Adjustment of Position of MKB-11 Limit Switch Mechanism in Flap Extension

1. Ease off six screws securing the can discs that control the flap extended position and connect a tester (a bell or a signal lamp) to the circuit of the limit switches.
2. Set the flaps in the extended position by the FJM (lower stop) notches.
3. Give the transmission 3 or 4 revolutions for flap retraction.
4. In the MKB-11 limit switches turn the can discs controlling flap extension to a position at which the limit switches break the circuits. The circuits of the upper and lower electric mechanisms should open when the transmission is turned to an angle not exceeding 40°. Then tighten the can disc screws.
5. Retract the flaps and extend them once more with the aid of the electric mechanisms. In extending and retracting the flaps check the operation of the limit switches, the flap deflection angle, and the position of the transmission with respect to the FJB (lower stop) notches.

SECRET

NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

- 88 -

**Notes:** 1. If the flaps cannot be fully extended, determine the number of transmission revolutions by which they are short of the required position and readjust the limit switches. To this end, reduce the number of transmission revolutions made during the preliminary adjustment by the number of revolutions required for putting the flaps in the correct position.

Adjustment of the MKB-11 limit switches for flap extension is considered satisfactory if during three extensions of the flaps by means of two MKB-3H electric mechanisms a slight knock is heard at least on one of the jacks when the flap reaches the lower stop and if the requirements under Items 1 and 4 of Subsection "Instructions on Servicing and Checking Control System", Section 9 are complied with.

2. For intervals between the flap operating cycles (to cool the electric mechanisms) see the Notes in the previous Subsection.

6. After adjustment make notches with inscriptions EH (lower cutout) on the transmission sliding part and on the right-hand side of the reduction gear body of the MKB-3H electric mechanism to note the position when the tester (a bell or a signal lamp) indicates the breaking moment of the limit switches.

7. Cut the tester (a bell or a signal lamp) out of the limit switch circuits, lock finally the screws securing the can discs that control the extension and retraction of the flaps, close the cover of the MKB-11 limit switches housing, lock it and seal.

8. Remove dial 9813-135 from the transmission shaft and indicating pointer 9813-131 from the servo unit bracket.

#### Adjustment of MKB-2 Limit Switch Mechanism

1. Before attaching the MKB-2 switch on the transmission (before drilling the hole for the attachment bolt in the case of shaft replacement), place the link roller of the F3H-47 flap position indicator into the recess of the can on the axle of its worm gear drive and set the flaps in the fully retracted position.

2. Deflect the flaps by an angle of  $19_1^{\circ}$  according to the protractor.

3. Remove the cover of the MKB-2 limit switch, connect the tester (a bell or a signal lamp) to the circuit, release three screws securing the can disc of the signal horn circuit and turn the disc to a position at which the circuit opens (as indicated by the tester).

4. Place the flaps at an angle of  $23_1^{\circ}$  according to the protractor.

5. Release the three screws securing the second can disc and turn it to a position at which the restrictor closes the signal horn supply circuit (also determined by the tester). This done, tighten the disc screws, put the switch cover in place, lock and seal it.

6. Check the operation of the MKB-2 switches by extending and retracting the flaps three times by means of the MKB-3H electric mechanisms. Adjustment of the limit switches should ensure that the signal horn is cut out when the flaps are deflected through an angle of  $19_1^{\circ}$  to  $23_1^{\circ}$  and cut in in all the other positions of the flaps.

#### Adjustment of F3H-47 Flap Position Indicator

1. Retract the flaps.
2. Remove the cover from the linkage of the F3H-47 indicator transmitter.
3. Back out the axial screw securing the F3H-47 indicator linkage carrier.

- 89 -

50X1-HUM

4. Align the pointer of the indicating instrument on the L.H. pilot's board with division "0" on the instrument dial, for which purpose turn the hexahedron of the transmitter axle of the F3H-47 indicator.

5. Secure the axial attachment screw of the F3H-47 indicator carrier on the transmitter axle. Check to see that the carrier of the F3H-47 indicator transmitter, when turned clockwise, does not overlap or thrust against the inner stop of the transmitter within angles of  $90^{\circ}$  to  $100^{\circ}$ . If the carrier travel is limited, readjust the indicator.

6. Check the instrument on the L.H. pilot's board for correct readings by deflections of the flap. When performing this check, employ linear measurements to define exactly the flap deflection angles for which purpose refer to Table 9.

**Note:** Less accurate adjustment of the F3H-47 indicator can be performed with the aid of a protractor fitted with a rubber attachment piece. The protractor should be so mounted that the plane of its dial is located in the plane of the flap ribs (Fig. 79).

The difference between the readings of the instrument on the L.H. pilot's board and the actual flap deflection angle must not exceed  $\pm 1^{\circ}$ .

**Note:** In case the difference between the instrument readings and the actual flap deflection angles determined by linear measurements exceeds  $\pm 1^{\circ}$ , replace the can of the MKB-2 limit switch.

The main instrument serving to determine the position of the wing flaps is the F3H-47 indicator arranged on the board of the L.H. pilot. Should the readings of the F3H-47 indicator on the L.H. pilot's board considerably differ from those of the L.H. pilot's board, calibrate the former in accordance with the latter.

Table 9

Angular Deflections of Flaps and Their Corresponding Linear Deflections as Measured at Reference Point B (Fig. 75)

Flap deflection angle, degr.	Flap linear deflection, mm	Flap deflection angle, degr.	Flap linear deflection, mm	Flap deflection angle, degr.	Flap linear deflection, mm
1	29.5	13	379	25	725
2	58.5	14	408	26	753.5
3	88	15	437	27	782
4	117	16	466	28	810.5
5	146.5	17	495	29	839
6	176	18	524	30	867.5
7	204.5	19	562.5	31	895.5
8	234	20	581.5	32	923.5
9	263	21	610	33	951.5
10	292	22	639	34	979
11	321	23	668	35	1006.5
12	350	24	696.5		

SECRET

NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM



CHAPTER V

LANDING GEAR AND HYDRAULIC SYSTEMS  
CARE AND MAINTENANCE

1. LANDING GEAR

Landing Gear Basic Specifications

Landing Gear Main Leg (Fig. 80)

Full travel of the shock absorber rod	450 ± 2 mm
Shock absorber hydraulic fluid	AMT-10 mixture
Amount of hydraulic fluid in the shock absorber pipe and with the shock absorber fully compressed (when charged up to the level of the oil drain)	about 10,000 cm <sup>3</sup>
Nitrogen pressure in the shock absorber when the latter is released at aircraft normal all-up weight	15 kg/sq.cm
Permissible compression of the shock absorber at any aircraft all-up weight	200 to 300 mm
Collapsible strut deflection	8 to 10 mm
Elevation of the axis of side links 3 (Fig. 83) of the strut lock relative to the axis of rotation of crank 5, with the lock closed and the links tightened	0.5 to 1 mm
Clearance between nut 1 (Fig. 84) and the shoulder of bush 3 on the rotating cylinder, with the leg extended	2 to 3 mm
Clearance between nuts 4 and 5 of the rotating cylinder (See Fig. 84)	not less than 0.5 mm
With the wheels in the neutral position, the additional damper charging indicator at any ambient air temperature must project beyond the end face of the body tip	not in excess of 1 mm or must be short of it
Angle of wheel turn to the left and to the right from the neutral position	40° ± 30°
Nominal air pressure in the wheel tubes	6 kg/sq.cm
Wheel tube compression at parking	30 ± 5 mm

50X1-HUM

Backshift of the wheel axle when the aircraft is placed in the line-of-flight position (the backshift is measured from the plumb dropped from the strut axis of rotation)	300 ± 8 mm
Total backlash in the rigid connections (of the follow-up system) between the reducer on frame No. 13 and the bell crank on the shock absorber cylinder pivot	not in excess of 1 mm (the backlash is checked by means of special device No. 6360/0279)

Landing Gear Main Leg (Fig. 81)

Full travel of the main shock absorber rod	350 ± 2.5 mm
Shock absorber hydraulic fluid	AMT-10 mixture
Amount of hydraulic fluid in the shock absorber (when charged up to the level of the charging connection hole, with the shock absorber completely compressed)	about 17,000 cm <sup>3</sup>
Nitrogen (Specification TY UM 4200-54, 2nd grade) pressure in the shock absorber when the latter is released	36 kg/sq.cm
Shock absorber compression at parking at any take-off weight of the aircraft	230 to 280 mm
Nominal air pressure in the wheel tubes	8.5 kg/sq.cm
Wheel tube compression at parking at any take-off weight of the aircraft	80 ± 5 mm
Stabilising shock absorbers	
- rod full travel at compression	425 ± 2 mm
- rod full travel at extension	135 ± 1 mm
- hydraulic fluid	AMT-10 mixture
Amount of hydraulic fluid in the shock absorber (when charged up to the level of the charging connection, with the shock absorber inclined towards the aircraft tail, with the connection looking forward at an angle of 18°)	800 cm <sup>3</sup>
- nitrogen pressure during charging, with the shock absorber released	75 to 80 kg/sq.cm
Leg stagger when placing the aircraft in the line-of-flight position (as measured from the plumb dropped from the axis of rotation of the frame-to-wing attachment fitting to the bogey attachment hinge)	290 ± 7 mm
Bogey tilt (forward) in relation to the horizon line when placing the aircraft in the line-of-flight position	4°10' ± 1°30'
Permissible deflection in the shock absorber-to-frame attachment hinge	± 5 mm

Tail Skid (Fig. 82)

Shock absorber full travel	185 mm
Hydraulic fluid	AMT-10 mixture

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 92 -

Amount of hydraulic fluid in the shock absorber (when charged up to the level of the charging connection hole, with the shock absorber completely compressed) ..... 1800 cu.cm.  
 Nitrogen pressure in the shock absorber when the latter is released .....  $10 \pm 0.5$  kg/sq.cm.  
 Deflection (directed towards the aircraft tail) in the connection of the forked brace with the shock absorber ...  $28_{-5}$  mm  
 Permissible clearance between the skid in the retracted position and the fuselage contour ..... 2 mm

Adjustment of Landing Gear Nose LegAdjustment of Strut Lock  
(See Fig. 83)

The strut lock should be adjusted in case the clearance determining elevation of the axis of side link 3 in relation to the axis of rotation of crank 5 and adjusted by means of eye 7 on the rod of lock cylinder 6 is other than 0.5 to 1 mm. If this clearance is ensured the rod of hydraulic cylinder 6 should bear against the stop, i.e. it should be fully drawn out, while the strut (with the landing gear extended) should be deflected by 8 to 10 mm

- Notes:
1. Deviation from the size of 0.5 - 1 mm may cause the landing gear leg to collapse spontaneously.
  2. To check the size of 0.5 - 1 mm there are special holes in the centre of link 3 and corresponding holes in the centre of crank 5.
  3. The deflection (8 to 10 mm) of the strut is measured by special device No. H9998-275 included in the spare set.
  4. To adjust the strut lock the aircraft should be jacked.

Adjustment of Hydraulic Actuating Cylinder  
(See Fig. 84)

The hydraulic actuating cylinder of the landing gear nose leg (not provided with a lock) is adjusted so as to ensure proper straightening of the leg strut when the leg is extended and correct up-locking of the leg during retraction.

The actuating cylinder is adjusted by nut 1 by means of which the amount of the rod travel is changed during the extension of the leg and by eye 2 which regulates the total length of the actuating cylinder during the retraction of the leg.

To ensure reliable operation of the up-lock, the length of the actuating cylinder with the leg completely retracted must ensure lifting of the leg hinge till it rests against the surface of the lock body eye.

To ensure full travel and proper locking of the strut during leg extension there must be a clearance of 2 to 3 mm between nut 1 and the shoulder of bush 3 in the head of the cylinder. To maintain this clearance during service, see that the clearance between check nuts 4 and 5 is not less than 0.3 mm.

Adjustment of Door Actuating Mechanism  
(Fig. 85)

The door actuating mechanism is adjusted so that with the leg retracted the doors do not project beyond the fuselage well contour and there is a clearance of 10 mm at least between the doors and the landing gear wheels.

The doors are adjusted by eccentrics 1 mounted on link motions 2 and controlled by eyes 4 on rods 3.

- 93 -

50X1-HUM

The adjusting eccentrics are mounted so that at the moment the strut roller (See Fig. 81, Ref. No. 8) emerges from link motion 2, door actuating mechanism rods 3 thrust against levers 5. The doors in the retracted position are made tight by means of adjustable eye 4 on rods 3.

Note: Excessive shortening of rods 3 might bring about wedging of the wheels by the doors and prevent the leg from being up-locked.

If during extension or retraction the wheels catch at the doors, it is necessary to accelerate the opening of the doors. For this turn lever 5 in the direction of the aircraft tail by one slit relative to the link motion axis and respectively shorten rods 3 by means of adjustable eye 4.

Note: The hydraulic actuating cylinder and the door actuating mechanism should be adjusted simultaneously.

Adjustment of Lock  
(Fig. 86)

The lock should be adjusted so that with the lock closed the clearance between the head of adjusting screw 1 and rod 4 amounts to 1 mm. If this clearance is not ensured, the lock cannot be closed; the clearance exceeding 1 mm, the lock cannot be opened. The upper plane of hook 3 with the lock closed should project by  $0.5 \pm 0.1$  mm in relation to the lock body stop. If this condition is not observed the leg will fail to get locked.

Adjustment of Follow-Up System  
(Fig. 87)

In the follow-up system there must be ensured clearances between the end faces of slide 1 in the extreme positions along its travel and the vertical planes of the aperture in shock absorber transverse member 2.

The system is adjusted by changing the length of control rod 3 when screwing its upper eye 4 in or out. After the adjustments have been made, employ device 656A/0279 to check the total clearance in the links from the reducer to the ball crank on the shock absorber pivot. Its value must not exceed 1 mm.

Adjustment of Landing Gear Main Leg  
(Fig. 81)

The landing gear main legs should be adjusted:

- (a) when the amount of the landing gear stagger is changed;
- (b) if the angle of the bogey tilt is changed;
- (c) if deflection in the binged connection of the shock strut with the landing gear attachment frame is changed;
- (d) in case the landing gear fails to get up-locked.

The landing gear stagger (290  $\pm$  7 mm) is adjusted by changing the length of strut 2 by means of upper eye bolt 3.

The bogey tilt angle ( $10^{\circ} \pm 1^{\circ}30'$ ) is adjusted by changing the length of control rod 6 by means of the lower eye bolt on this control rod.

Deflection in the binged connection of the shock strut with the landing gear attachment frame ( $\pm 5$  mm) is adjusted by hydraulic actuating cylinders 4, whose length is changed by screwing the eye bolts on the rods of these cylinders in or out. The deflection should be checked by device No. 626.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

- 91 -

The landing gear up-locking is adjusted by struts 2 and hydraulic actuating cylinders 4.

In the completely retracted position strut eye 8 must be promptly up-locked. If the eye fails to get up-locked the lock is in good repair, lengthen strut 2 and shorten actuating cylinders 4 (if strut lengthening alone is not sufficient). Take care to see that the landing gear stagger and the deflection of the hinged connection of the shock absorber with the landing gear attachment frame adjusted previously are not disturbed. The landing gear stagger and the hinged connection deflection should be within their tolerance limits.

Excessive shortening of control rod 6 may hinder up-locking the leg as the bogey will rest too early against the rubber stop on the lower torsion link and will wedge the mechanism. This being the case, lengthen control rod 6 by means of its lower eye bolt so that, with the landing gear in the retracted position, the bogey rests against the rubber stop without preloading it. When doing so, take into consideration that, with the landing gear extended, the angle of the bogey tilt should be within its tolerance limits.

With the landing gear extended, both actuating cylinders must get locked by the ball locks simultaneously.

The landing gear main leg attachment lock is adjusted in the same way as the nose leg attachment lock.

#### Adjustment of Door Actuating Mechanism (Fig. 88)

The doors of the landing gear main leg wells are closed during the retraction and extension of the legs by means of a mechanism with two link motions.

With the landing gear retracted, the door tightness may be increased by shortening all the four control rods connecting the reducers with the doors. Take into consideration that excessive shortening of the door control rods might prevent up-locking the landing gear legs.

For preliminary adjustment of the door actuating mechanism the control rods, levers and link motion arms must have the following initial length:

- (a) control rods: Ref.No.2 - 698 mm; Ref.No.11 - 840 mm; Ref.No.6 - 1002 mm; Ref.No.8 - 1035 mm, and Ref.No.10 - 840 mm;
- (b) the arm of lower link motion 1 - 145 mm; the arm of upper link motion 1 connected to control rod 6 - 132 mm, and the arm of upper link motion 7 connected to control rod 8 - 135 mm;
- (c) lever 3 of the front reducer connected to control rod 2 - 156 mm; lever 5 connected to control rod 6 - 135 mm, and lever 9 of the rear reducer connected to control rod 8 - 157 mm.

With control rods 2 disconnected from lower link motion 1 and spring 3, a correctly adjusted mechanism should freely and without jamming move from one extreme position to the other, that is to the door open and closed positions, the force applied to the door ends amounting to 20 - 30 kg.

After the preliminary adjustment of the mechanism for closing and opening of the doors, it is necessary to retract the landing gear by hand without disconnecting control rod 2 and spring 3, by means of the hand pump of the ground stand for hydraulic tests or the hand hydraulic pump, type HP-01, and adjust the roller on the landing gear bogey so that it enters the jaw of upper link motion 7.

- 95 -

50X1-HUM

The bogey roller entering the link motion jaw is adjusted by resetting the bracket with the roller over the oval hole in the bracket on the landing gear bogey.

When the roller emerges from the link motion the doors must completely open while the reducer bell cranks must reach the stops.

After the bogey roller entering and emerging from the jaw of upper link motion 7 have been adjusted, connect control rod 2 to lower link motion 1 adjust the bogey roller for entering and emerging from the jaw of the lower link motion.

**Note:** To avoid damage to disconnected control rod 2, when adjusting the roller entering the upper link motion jaw, tie the control rod so that it cannot catch at other structural elements during movement.

During the operation of the door actuating mechanism the rollers must be in contact with the link motion throughout their entire width all the time. The displacement of the roller axis in relation to the link motion axis must not exceed  $\pm 2$  mm.

During the landing gear retraction and extension there must be a clearance of not less than 30 mm between the wheels and the doors.

The adjusted mechanism must be checked by opening and closing the doors after spring 3 has been connected to it.

With the landing gear legs retracted, the doors must be closed with a certain degree of tightness which is regulated by the length of the control rods and levers on the reducers.

With the landing gear legs extended, loose fit between the doors and the fairing contour is permitted. The distance between the door and the fairing contour over the joint should be from 5 to 10 mm.

During flight with the landing gear extended, the permissible distance between the main doors and the fairing contour does not exceed 30 mm. This should be checked by examining the doors from the gunner's cabin.

**Note:** After the final adjustment of the door actuating mechanism retract and extend the landing gear legs once or twice from the main hydraulic struts.

#### Adjustment of Landing Gear Main Leg Extension Mechanical Indicator (Fig. 89)

To adjust the main leg extension mechanical indicator entch the moment of the emerging of indicator pin 1 (on the upper skin of the wing) with the moment of complete extension of the main legs and set the end-piece of eccentric 2 so that at the moment of the landing gear complete extension the end-piece presses off pawl 4 of quadrant 3.

To set the end-piece in this position loosen the coupling bolt securing the eccentric on the axle and set the end-piece in the required position. Then tighten up the coupling bolt.

#### Adjustment of Tail Skid (Fig. 82)

The adjustment of the tail skid should ensure the following: in the EXTENDED (ВЫПЯНО) position - panel 1 should keep within the fuselage contour and in the RETRACTED (ВНУТРИ) position - the hinged connection of the journals

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 96 -

of shock absorber 6 with fork 7 should deflect backward by 28.5 mm. In the event of this deflection eye 5 of extension rod 3 rests against the rubber buffer on frame No.66. This is achieved by screwing eye 5 in and out, that is by changing the length of the MI-250 electric mechanism control rod. The deflection in the hinged connection of the journals of shock absorber 6 with fork 7 should be checked by means of device No. 96813.

- Notes:** 1. When applying force by hand, 2-10-mm resilient play of the shock absorber is permitted in the journals.  
2. With the skid retracted, the permissible protrusion of its parts beyond the fuselage contour does not exceed 2 mm.

#### Adjustment of Landing Gear and Tail Skid Light Signalling System

The adjustment of the light signalling system indicating the position of the landing gear nose leg consists in adjusting the moment of operation of the limit switches, types EK-2-140B and EK-4A.

The operation of the switch, type EK-2-140B, installed on the strut of the landing gear nose leg must cause the lamp to flash which indicates the landing gear leg extension. The operation of the switch, type EK-4A, installed on the landing gear nose leg up-lock indicates the retraction of the leg.

The limit switch, type EK-2-140B, must operate at the moment the leg is fixed by the lock in the completely extended position in which the strut deflection reaches the required value and the strut gets locked.

The moment of operation of the EK-2-140B switch is adjusted by screw 2 (Fig.90) as follows:

- unscrew check nut 3 and turn out screw 2 so that the switch rod can move quite freely;
- turn on screw 2 so that the switch operates with a click;
- turn on screw 2 by 2.5 or 3 turns more corresponding to a length of 2 or 2.5 mm and lock it. After this the rod must have a free travel of 2.5 or 3 mm.

The limit switch, type EK-4A, of the landing gear nose leg must operate at the moment the leg gets up-locked and lever 5 (See Fig.86) presses its rod.

The moment of operation of the EK-4A switch is adjusted by changing the length of its rod when screwing the latter in or out.

The moment of operation of the switches, types EK-4A and EK-2-140B, is indicated by a click and flashing of the warning lamp.

To adjust the switch, type EK-4A, turn out the screw of its rod by 1.5 or 2 turns.

After the switch has operated (clicked) the rod must not project beyond the switch by 1 or 1.5 mm. This done, lock the rod screw.

In this position the rod must have a free travel of 4 or 5 mm (the travel of the auxiliary device button being taken into consideration).

The operation of the landing gear main legs light signalling system is ensured by the adjustment of the limit switches, type EK-4A, located on the transverse members of the shock absorbers (for controlling the main leg extension) and on the up-locks (for controlling the main leg retraction).

The operation of the switches, type EK-4A, controlling the landing gear main leg extension must take place at the moment the actuating cylinders are locked by the ball locks.

- Notes:** The correctness of locking the actuating cylinders by the ball lock is determined (with the main leg extension and retraction system adjusted) by deflection in the hinged connection of the shock absorber with the landing gear attachment frame. This deflection must be equal to 2-5 mm.

- 97 -

50X1-HUM

The operation of the switches, type EK-4A, controlling retraction of the landing gear main legs must take place at the moment the legs become up-locked and levers 6 (See Fig.96) press the switch rods.

The moment of operation of the main leg switches, type EK-4A, is adjusted in the same manner as that of the nose leg switch, type EK-4A. The additional moment of the switch adjustment, with the landing gear legs extended, is adjusting screw 3 (Fig.91) mounted on the lever bracket of the control rod tilting the landing gear bogey.

The adjustment over, the switch adjusting screws must be locked with nuts and wire, then sealed and painted red with enamel A-67, while the rod nuts should be oiled, the cotter pin ends being spread along the circumference. The threaded portion of the rod screw should be also painted red with enamel A-67. The pilots are not provided with the light signalling system indicating the position of the tail skid. The tail skid is controlled only in the RETRACTED position by the light signalling system in the rear cabin (by one lamp in the electric panel of the gunner and the gunner-radio operator). This light signalling system is not adjusted. The limit switch, type EK-4A, mounted on the left-hand side of the landing gear nose leg up-lock switches on the electric mechanism, type E-250, for retraction and extension of the tail skid.

The extreme positions of the tail skid during retraction and extension are secured by the MI-250 electric mechanism.

The moment of operation of the EK-4A switch connected to the MI-250 electric mechanism is adjusted in the same manner as that of the EK-4A switches of the landing gear nose and main leg light signalling system.

- Notes:** 1. The moment of operation of the light signalling system limit switches of the landing gear nose leg (in the retracted and extended positions) and that of the main legs (in the retracted position only) can be adjusted both when the aircraft is on the landing gear wheels and when it is jacked.  
2. The moment of operation of the light signalling system switches of the landing gear main legs in the extended position must be adjusted only when the aircraft is on the wheels. If this adjustment is made with the aircraft jacked, the switch rods will move from the pressure levers due to backlash in the landing gear joints and the warning lamps will go out or blink during taxiing when the aircraft is on the wheels.

#### Wheel Operating Instructions

The bogeys of the landing gear main legs have eight wheels, 1100x330B. Each of the wheels is provided with two hydraulic brakes. The nose leg has two wheels, 900x275B.

The compression of the landing gear wheel tubes is measured as follows:  
(a) on the nose leg wheels - by the distance from the parking ground to the lower point of the outer contour of the wheel rim along the vertical line passing through the wheel axis. With the wheel tube compressed by 30 mm, this distance is equal to 82 ± 5 mm;

(b) on the main leg wheels - by the distance from the parking ground to the lower point of the outer contour of the brake collar along the vertical line passing through the wheel axis. This distance must be equal to 262 ± 5 mm when the wheel tube is compressed by 80 mm.

The difference in the amount of air pressure in the wheel tubes must not exceed 0.25 kg per sq.cm.

It is not recommended to release pressure from warmed wheel tubes and, with further cooling, their pressure will decrease below the rated value.

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

50X1-HUM

During circular flights with 30-min. intervals between landings and with application of brakes, during take-off under side wind conditions, and during continuous taxiing with brakes applied, the wheels might get overheated and fire. In these cases when the wheel brakes are applied with short intervals and there is not enough time for the brakes to cool down, take particular care of the condition of the wheels. The wheel brake collar temperature must not rise above 300°C (the temperature of the brake collar is determined by the colour of temperature indicating rods).

It is permitted to perform take-offs and landings with brakes applied in the following cases only:

- during circular flights with the landing gear extended - for not less than 10 min. so as to cool down the wheels;
- in case the landing load on the wheel and landing speed are not in excess of those indicated in the Pilot's Instructions;
- during landing run - not earlier than 5 sec. after the nose leg wheel touch the ground;
- if the ambient air temperature is not in excess of 20°C.

If the ambient air temperature exceeds 20°C, if the length of the runway does not allow to apply the brakes with delay (5 sec. after the nose leg wheel touch the ground), and if in flights the pilot is to master take-off and landing with retraction of the landing gear, increase the intervals between subsequent landings so as to keep within the permissible temperature range for the wheels.

In winter conditions the interval between subsequent take-offs and landings can be reduced as compared to the recommended interval (10 min.) while the number of subsequent take-offs and landings can be increased provided the wheel temperature is kept within the permissible limits.

If after each landing the wheels are cooled down with water or compressed air approximately to the ambient air temperature, it is permitted to increase the number of subsequent take-offs and landings.

During service regularly check the clearance between the brake shoes and brake collars with the wheels released. This clearance must be not less than 0.5 mm.

In case this clearance is less than 0.5 mm or equals zero (this might take place as a result of brake jamming or expansion of the expander tube), drain a certain amount of brake fluid through the drain plugs and recheck the clearance. In case the clearance is still less than 0.5 mm, replace the expander tube.

The wheel brake shoes should be replaced if their wear in the radial direction exceeds 5 or 6.5 mm and the thickness of the worn out shoe over the edges is equal to 11.5 mm.

Replace all the worn out brake shoes by a set of new ones. New shoes should freely move in the grooves of the brake cups. The brake with new shoes should freely enter the wheel brake collar. When the brake is completely fixed but not connected to the hydraulic system, the clearances between the shoes and the collar should be not less than 0.5 mm.

When disconnecting the pipe lines of the brake hydraulic system, see that the hydraulic system is clean and that no fluid gets onto the brake shoes and collars.

When dismantling the wheels and carrying out routine maintenance operations check to see that the bolt connections of the brake collars are properly tightened up. Loose nuts should be tightened up by means of a standard wrench.

Clamping nuts on the axle of the landing gear main leg wheel must first be tightened up till clearance in the bearings is taken up and braking is felt when the wheel is rotated by hand, then the nuts should be unscrewed by 1/3 of a turn so as to obtain the required operating clearances in the bearings. At the start, when testing the engines, when examining the aircraft, and in other cases it is permitted to apply brakes at parking for not more than two hours. When doing so do not apply the brakes if the wheel brake collars are hot.

#### Charging Landing Gear Leg Shock Absorbers

The shock absorbers of the nose and main legs are charged with commercial nitrogen till the initial pressure is obtained as indicated in the landing gear specifications (See "Landing Gear Basic Specifications" above). The initial pressure is checked by means of a special device on the non-compressed shock absorber.

Parking compression values of the shock absorbers are also given in the landing gear specifications.

- Notes:
- When checking the amount of shock absorber compression during parking, it is necessary to take into consideration possible jamming of the shock struts. To avoid this swing the aircraft slightly.
  - Each time when the ambient air temperature drops check all the landing gear shock absorbers for compression and, if necessary, charge them additionally until the required pressure is obtained.
  - Take into consideration that during parking pressure in the stabilizing shock absorbers depends on the general compression of the shock struts.

The shock absorber compression is checked by the rod face and the dimensions given in Fig. 92.

The initial pressure in the stabilizing shock absorbers and in the tail skid shock absorbers (See "Landing Gear Basic Specifications" above) does not depend on the aircraft take-off weight.

#### Lubrication

All the hinged connections provided with oil cups should be lubricated with oil, grade IMAHM-201, by means of a grease gun.

The hinged connections of the landing gear frame with the wing units, the boggy-to-shock absorber attachment fitting, the hinged connections of the landing gear main leg strut, and the hinges of the nose leg strut lock should be also covered with oil, grade IMAHM-201.

Polished surfaces of the shock absorber rods, actuating cylinders and shimmy dampers should be covered with a thick layer of petrolatum or gun grease. Before each flight this grease should be removed.

The rod of the cylinder of the landing gear nose leg strut lock, the slide shaft in the transverse member of the nose leg shock absorber, the sleeves of the slide and the up-lock rods should be covered with petrolatum.

The wheel bearings should be smeared with lubricant, grade RK-50, in winter and summer. Fresh lubricant should be applied to the bearings after every 50 landings.

Each time when applying fresh lubricant to the wheel bearings or when the wheels are removed for some other reason, it is necessary to check the condition of the bearings; in case some damage is detected, replace the bearing.

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

The diagrams of landing gear lubrication are presented in Figs 93, 94, and 95.

Faults and Remedies

Fault	Cause	Remedy
1	2	3
1. The landing gear legs fail to get up-locked with the actuating hydraulic system operating normally	1. Wedging of the door actuating mechanism due to the fact that when moving during the leg retraction the doors come in contact with the wheels 2. The up-locks fail to open 3. During the landing gear extension the up-lock rod is jammed in the guide bush and the hook (latch) remains pressed off	Jack the aircraft and check the adjustment of the door actuating mechanism  Examine the landing gear up-locks and, if they are locked, unlock them Retract the landing gear legs from the ground and force out the rod completely. Measure the diameter of the rod near the conical-shaped taper which must be equal to 121. If the rod diameter exceeds this value, clean the rod with emery cloth so as to obtain the required dimensions. This done, release pressure and check to see whether the rod properly returns to the initial position. If the rod fails to do so, remove and check the lock Charge the stabilizer shock absorber to a normal pressure of 75 to 80 kg per sq. cm. Lubricate the hinge through the oil cups in the rod head eyes. If a fault persists after the lubrication, disassemble the hinge and examine its parts Remove the valve and check it on the hydraulic test stand
2. Nose leg vibration	1. The throttle valve fails (hydraulic fluid leaks through the valve)	

1	2	3
	2. One of the dampers fails due to: (a) wear of the packing on the piston (b) breaking of the piston from the rod (c) penetration of air into the damper (d) leakage in the additional damper and insufficient amount of hydraulic fluid in it 3. Axial play in the torsion link joints 4. Increase in the radial play in the pivot clamp 5. Play in the turning mechanism joint 6. Considerable axial play in the bearings of the landing gear attachment journals	Remove the damper in question and send it for repair Remove the damper and send it for repair Release the air Remove the damper and replace the packings  Eliminate the play by fitting washers Replace the bush in the clamp  Replace the links  Mount new bushes with enlarged shoulders in the fuselage units. File the shoulders so as to obtain normal axial play of 0.1 to 0.2 mm

2. HYDRAULIC SYSTEMS

General

The aircraft is provided with the main and brake hydraulic systems. Both hydraulic systems have a common line of air boosting and tank drainage which produces initial pressure thus ensuring normal conditions for the operation of the high-pressure pumps.

The main and brake hydraulic systems are composed of three principal groups of units connected to one another by means of pipe lines and flexible hoses:

- (a) oil delivery units;
- (b) units distributing and regulating the oil flow;
- (c) units converting oil pressure into mechanical energy.

The key diagrams of the main and brake systems are presented in Fig. 96. The systems use oil (mixture), grade AMP-10, as pressure fluid. The total capacity of the main and brake hydraulic systems equals 115 to 120 lit.

The main hydraulic system (Fig. 97) is used for normal (non-emergency) extension and retraction of the landing gear nose and main legs, for opening and closing of the bomb-bay doors, and for turning the wheels of the landing gear nose leg.

It consists of the oil delivery lines, control lines, drainage and boosting lines.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

— 102 —

The delivery lines are divided into high- and low-pressure lines; the control lines bring into operation the following units:

- (a) landing gear (retraction and extension);
- (b) bomb-bay doors (opening and closing);
- (c) landing gear nose leg wheels (turning to the left and to the right).

Pressure in the main hydraulic system is built up by high-pressure pumps which are driven by the aircraft engines, or by the SP-01 hand pump or ground hydraulic test stand 3783, with the engines at standstill.

Notes: Landing gear emergency retraction and extension and emergency closing of the bomb-bay doors are performed from the brake hydraulic system.

The brake system (Figs 98 and 99) is used for normal (main) and emergency braking of the landing gear main leg wheels, for emergency retraction and extension of the landing gear legs, and for emergency closing of the bomb-bay doors. The system consists of the oil delivery lines, control lines, and return, drainage and boosting lines.

The delivery lines, as in the main system, consist of low- and high-pressure lines, while the control lines bring into operation the following units:

- (a) landing gear main leg wheels during normal (main) automatic braking and during emergency braking (downstream of the pressure reducer this part of the line belongs to the normal brake system as well);
- (b) landing gear during emergency retraction and extension of the legs;
- (c) bomb-bay doors as an auxiliary means of closing the doors.

Pressure in the brake system is built up by means of a pump actuated by an electric motor. In emergency braking power is supplied by the hydraulic accumulator fed by the brake system pump.

The schematic diagram of pump drainage and tank boosting is presented in Fig. 100. Surplus pressure in the tanks is built up by the air taken from the eighth stage of the compressors of both engines. The required amount of boosting is maintained by the pressure regulator within 0.9 - 1.1 kg per sq.cm. The drain tank has a capacity of  $40 \pm 2$  lit. and is used as a reservoir for draining excessive oil in case the tanks of the brake and main systems are overflowed.

#### Main System Specifications

Total capacity of the system tank ..... 34 lit.  
Amount of oil filled into the tank after the system units and pipe lines have been filled with oil ..... 20 lit.  
Operating pressure in the delivery lines maintained by the high-pressure pumps at nominal r.p.m. and when their output changes from zero to 28 lit. per min. ...  $150 \pm 7.5$  kg/sq.cm.  
Nitrogen pressure in the hydraulic accumulator gas chamber during charging and with no pressure in the system .....  $120 \pm 3$  kg/sq.cm.  
Amount of oil in the hydraulic accumulator hydraulic chamber (at a pressure of  $150 \pm 7.5$  kg per sq.cm. in the hydraulic system) .....  $200 \pm 25$  cu.cm.  
Pressure for which the safety valve is adjusted ..... not less than  $170 \pm 3$  kg/sq.cm.  
Landing gear retraction time at the ambient air temperature of  $+20 \pm 10^\circ\text{C}$  ..... not in excess of 45 sec.

— 103 —

50X1-HUM

Landing gear extension time at the ambient air temperature of  $+20 \pm 10^\circ\text{C}$  ..... not in excess of 45 sec.  
Bomb-bay door opening time at the ambient air temperature of  $+20 \pm 10^\circ\text{C}$  ..... not in excess of 2 sec.  
Bomb-bay door closing time at the ambient air temperature of  $+20 \pm 10^\circ\text{C}$  ..... not in excess of 3 sec.  
Number of pumping cycles (pushing and pulling the handle):  
when opening the doors of the bomb bay ..... not in excess of 120  
when extending the landing gear ..... not in excess of 900

#### Brake System Specifications

Total capacity of the system tank ..... 40 lit.  
Amount of oil filled into the tank with the hydraulic accumulators charged to a pressure of 150 kg per sq.cm. and with the wheels braked during parking ..... 22 lit.  
Operating pressure in the oil delivery lines maintained by the pumping station (the output of the pumping station being 8 lit. per min.) .....  $150 \pm 5$  kg/sq.cm.  
Operation of the pressure switch, type RMA3-150, depending on the change of operating pressure in the system:  
(a) pressure at which the pumping station is cut off .....  $150 \pm 5$  and  $30 \pm 5$  kg/sq.cm.  
(b) pressure at which the pumping station is cut in .....  $120 \pm 5$  kg/sq.cm.  
(c) pressure at which the port warning lamp on the pilots' central instrument panel flashes up .....  $100 \pm 5$  kg/sq.cm.  
Pressure in the emergency hydraulic accumulator at which the CUM-130 oil pressure drop warning unit switches on the starboard red warning lamp on the pilots' central instrument panel ..... lower than  $130 \pm 5$  kg/sq.cm.  
Pressure of commercial nitrogen in the hydraulic accumulator gas chamber (of the main and emergency lines) during charging and with no pressure in the hydraulic system .....  $60 \pm 3$  kg/sq.cm.  
Amount of oil in the hydraulic chamber of each hydraulic accumulator (at a pressure of 150 kg/sq.cm. in the hydraulic system) ..... 7180 cu.cm.  
Pressure in the wheel expander tubes:  
(a) at normal (main) braking ..... 13 to 14 kg/sq.cm.  
(b) at emergency braking ..... 14 to 17 kg/sq.cm.  
(c) during parking ..... 11 to 12 kg/sq.cm.  
(d) maximum ..... 18 kg/sq.cm.  
Time of pressure increase in the wheel expander tubes ..... not in excess of 1.5 sec.  
Time of wheel brake release ..... not in excess of 1 sec.  
Time of landing gear emergency retraction ..... not in excess of 200 sec.

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM



Time of landing gear emergency extension ..... not in excess of 180 s  
 Time of bomb-bay door emergency closing ..... not in excess of 10 s

**Note:** Check the time necessary for emergency retraction and extension of the landing gear and for closing the bomb-bay doors at the ambient air temperature of  $\pm 20 \pm 10^\circ\text{C}$ .

**Marking of Pipe Lines**

For identification purposes each pipe line has the following marking in places of joints: the drawing number, the number of the pipe line according to its purpose and the number of the pipe. The marking is done with black paint on coloured cambric tapes cemented to the pipes. The pipes bearing even numbers are located on the port side of the aircraft, while those bearing odd numbers are located on the starboard side.

**Note:** On pipes less than 150 cm long the numbers are stamped on a special circular tally which is fitted over the pipe.

Example of pipe marking: H5601-101-10-8, where H5601-101 is the drawing number;

10 is the number of the pipe line (landing gear emergency extension);  
 8 is the number of the pipe (on the aircraft port side).  
 Marking of pipe lines is given in Table 10 below.

Table 10

Marking of Hydraulic System Pipe Lines

No.	Number of line	Purpose of line	Colour of marking
1	2	3	4
<b>A. Pipe Lines of Landing Gear and Bomb-Bay Door Normal (main) Control Hydraulic System</b>			
1	00	Supply of engine pumps and hand pump	Black
2	0	Reservoir return	
3	1	Drainage	
4	6	Landing gear retraction	
5	7	Landing gear extension	
6	8	Building-up pressure in system	
7	15	Opening of bomb-bay doors	
8	16	Closing of bomb-bay doors	
9	17	Wheel turning to the right	
10	18	Wheel turning to the left	
<b>B. Pipe Lines of Wheel Brake Normal (main) Control, Landing Gear Emergency Control, Bomb-Bay Door and Wheel Brake Emergency Control Hydraulic System</b>			
11	2	Building-up pressure in normal (main) brake control system	Green

50X1-HUM

1	2	3	4
12	4	Brake system reservoir return	Green
13	5	Wheel normal (main) braking (odd numbers - landing gear starboard leg line; even numbers - landing gear port leg line)	
14	3	Building-up pressure in brake emergency control system	
15	9	Landing gear emergency retraction	Red
16	10	Landing gear emergency extension	
17	14	Bomb-bay door emergency closing	

On the aircraft the table of pipe line marking is arranged on the inside of the bomb-bay starboard door.  
 The material of which the pipe is made can be determined by the colour of the pipe: steel pipes are painted grey, pipes of the AlMg material are covered with primer mixed with aluminum powder.

**Charging Main System with Oil**

- To charge the main system with oil:
1. Jack the aircraft.
  2. Open the hatch above the tank (the hatch is located on the aircraft upper skin between frames Nos 31 and 32) and unscrew the plug on the tank filler.
  3. Insert a funnel with a gauge into the tank filler, cover the funnel with a clean piece of silk cloth and fill the tank with 28 or 30 lit. of oil.
  4. Plug the tank filler and close the hatch over the tank.
  5. Connect stand 3783 to the inboard supply panel and build up a pressure of 150 kg/sq.cm. in the system.
  6. Retract and extend the landing gear three or five times by operating in turn the slide valves (buttons) of the landing gear main control cock.
  7. Place jack P9918-0 under the landing gear nose leg strut, release air (or nitrogen) pressure from its shock absorber, and disengage the centring device by compressing the shock absorber by 120 or 150 mm.
  8. Move the nose wheels from one extreme position to the other not less than four or five times, opening the air vent valve on the eye of the rod which serves down at the given moment. At this the air will pass out of the cylinder lower recess through the open valve.
  9. Remove the jack from under the landing gear nose leg strut and charge the shock absorber with commercial nitrogen to a pressure of  $15^{+3}$  kg/sq.cm.
  10. Close and open the bomb-bay doors not less than five times.
  11. Check the amount of oil in the tank (the tank must contain 20 lit. of oil) and if necessary drain the excessive oil or add the required amount of oil.

**Charging Brake System with Oil and Removing Air from It**

- To charge the brake system with oil:
1. Unscrew the cover of the tank filler.
  2. Fill 38 lit. of oil into the tank through a funnel with a gauge (or charge the tank by means of the stand).

SECRET  
NO FOREIGN DISSEM

- 106 -

3. Screw up the filler cover.
4. Cut in the pumping station and charge both hydraulic accumulators to a pressure of  $150 \pm 2$  kg/sq.cm.
5. Add some oil to the tank so that the latter contains 26 to 30 lit.
6. Compress in turn the normal (main) brake valves, type JT-50, on the panels of both pilots' posts.
7. Compress the emergency brake valve, type JT-39.
8. Add some oil to the tank so that the latter contains 26 to 30 lit.

**Note:** The line from the wheel tubes to the tank may be filled with oil "from bottom to top" through the air vent valves of the expander tubes.

During the replacement of units and draining of oil from the system air penetrates into it. The presence of air is particularly dangerous in the lines from the brake valves, type JT-50, to the expander tubes, because this part of the system is of a single-line type.

Air is evacuated from the lines through the air vent valves on the wheel outer brakes first with the JT-50 valves compressed and then with the JT-39 valves compressed. Opening of the air vent valves and compression of the brake valve are performed in turn until sprays of oil not containing air appear from the open air vent valves. This done, add some oil to the tank so that the latter contains 22 lit.

Air can be evacuated from the lines by pumping the system from bottom to top as well. For this:

1. Remove the caps from the outer brake air vent valves of the port leg front pair of wheels.
2. Connect the hoses of stand No.1530 to the pipe unions of the open air vent valves and pump 3 or 4 lit. of oil from the tank of the stand to the aircraft tank.

**Note:** When pumping over oil, check the level of oil in the tank; see that it does not exceed the rated value. Each time drain the excessive amount of oil through the drain pipe into some reservoir.

3. Close the air vent valves of the outer brakes on the port leg front pair of wheels and open the similar valves on the rear pair of wheels of the same leg.
4. Connect the hoses of stand No. 1530 to the open air vent valves and pump 3 or 4 lit. of oil to the aircraft tank.
5. Close the air vent valves of the outer brakes on the port leg rear pair of wheels.
6. Repeat Operations 1, 2, 3, 4, and 5 in relation to the starboard leg wheels.

After air has been evacuated from the system, check the level of oil in the tank and the operation of the brakes. For this purpose:

1. Switch on the pumping station and charge both hydraulic accumulators to a pressure of  $150 \pm 2$  kg/sq.cm.
2. By means of adapters B9941-110 screw the reference pressure gauges into the valves located on the collapsible pipe line of both landing gear legs.
3. Compress the normal (main) brake valves and set them to the parking brake position. Pressure in the expander tubes must be equal to 11 or 12 kg/sq.cm., while the amount of oil in the tank should be 22 lit. If necessary, add oil to the tank or drain excessive amount of oil.
4. Release the parking brake.

- 107 -

50X1-HUM

5. Press the pedals as far as they will go; at this pressure in the wheel expander tubes must be equal to 13 or 14 kg/sq.cm.
6. Compress the emergency brake valves, type JT-39; pressure in the wheel expander tubes must reach 14 to 17 kg/sq.cm.

**Note:** Pressure difference in the wheel expander tubes on the port and starboard legs must not exceed 1 kg/sq.cm.

If the results obtained during the check do not comply with the Specifications of the system repeat the procedure to evacuate air from the system.

#### Access Hatches for Inspection of System Separate Units

Most of the hydraulic system units are located in places easily accessible for maintenance and inspection.

The arrangement of units and hatches ensuring access to them (Fig.101) is given in Table 11 below.

Table 11

Unit	Access Hatch
1. Brake valves, type JT-50, main and brake hydraulic system pressure gauges, type MP-250U, needle-type throttle valves upstream of pressure gauges	Access and inspection directly from cabin of fuselage compartment 0-2. Central panel is provided with special hatch for inspection of units belonging to it
Pilots' central panel with units belonging to it: landing gear normal (main) and emergency controls, landing gear nose leg turning control, emergency brake valve, type JT-39, emergency brake system switch Hand pump, type MP-01, and throttle valve of frame No.11	Access and inspection with cover of pressurized hatch in bottom of frame No.12 removed. Units panel, type H5606-0, is provided with easily opening cover
2. Brake system tank, drainage system tank, solenoid-operated slide valve, type PA-49, hydraulic switches, type JT-34, brake system hydraulic accumulators, hydraulic system valve panel, type H5606-0, with following units belonging to it: pumping station (465K), brake system line filter, pressure switch, type H4NS-150, pressure warning unit, type CHM-130, hydraulic accumulator of main hydraulic system, safety valve, brake system pressure release valve, and non-return valve	Access and inspection with cover of mounting hatch 2 over centre plane removed
3. Main hydraulic system tank, cooler	

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

50X1-HUM

Unit	Access Hatch
4. Main hydraulic system panel, type H5606-100, with following units belonging to it: line filter, pressure regulator, bomb-bay door controls, shut-off cock, non-return valve, and ground supply pipe union	Access and inspection of bomb-bay doors open. Panel H5606-100 is located at starboard side at frame 19 and is provided with access opening cover.
5. Pumps (units 425-22), by-pass flow restrictors, non-return valves in delivery line running from pumps	Access and inspection of engine cool upper shutters open
6. Pressure reducers, type VI-53, with shuttle valves; landing gear main leg hydraulic actuating cylinders with slide valve distributors mounted on them; locks fixing landing gear in retracted position, and double-action valves	Access and inspection of landing gear fairing cover open
7. Dampers and throttle valve of landing gear nose leg turning control system	Open access units are mounted on landing gear nose leg
8. Landing gear nose leg hydraulic actuating cylinder, locks fixing leg in retracted and extended positions, drain valve, pressure regulator at frame No.19.	Access and inspection of nose leg well. To examine pressure regulator, remove well casing

Note: The hydraulic system pipe lines and flexible hoses are chiefly checked for inspection. In closed-up places they are inspected through hatches and removable panels.

Checking Landing Gear Actuation Mechanism

To check the landing gear actuation mechanism, lift the aircraft by the hydraulic actuating cylinders so that the distance between the wheels and the surface of the parking ground is 100 to 150 cm.  
Connect a special stand provided with a pump having an output of not less than 30 lit. per minute to the main hydraulic system panel. Prior to connecting the hoses of the stand thoroughly clean their terminations. Cut in the stand pump and build up pressure in the main hydraulic system.

Landing Gear Retraction

Bring oil pressure in the main hydraulic system to 145 - 157 kg/sq.cm. as indicated by the pressure gauge and make sure that the handwheel controlling the turning of the landing gear nose leg wheels is in the neutral position and that its push button is depressed and locked. Then, open the control cap, press the RETRACTION button as far as it will go and turn it home clockwise then release the button; at this the button must remain depressed.

Note: On pressing the RETRACTION button all the three green warning lamps of the landing gear extended position must go out, oil pressure in the system must first drop to 70 - 100 kg/sq.cm. and then increase with the landing gear retraction. At the moment all the three red warning lamps of the landing gear retracted position must go out, oil pressure in the system must be 120 kg/sq.cm. and then increase to 145 - 157 kg/sq.cm. (maximum pressure built up by the stand).

Keep the system under this pressure during 5 sec. after the last green warning lamp has flashed up, turn the RETRACTION button home counter-clockwise and release it. The button must return to the neutral (upper) position.  
Note: With the landing gear retracted, the tail skid position green lamps must be on.

Landing Gear Extension

Make sure that oil pressure in the main hydraulic system is equal to 145 - 157 kg/sq.cm. as indicated by the pressure gauge and that the RETRACTION button is in the neutral (upper) position.  
Smoothly press the smaller EXTENSION button without moving the larger button and keep it pressed for 2 or 3 sec. Then, still pressing the smaller button, press the larger button as far as it will go, turn it home clockwise and release both buttons. At this the smaller button must return to the neutral (initial) position, while the larger button must remain depressed. Make sure that the smaller button has returned to the initial position.  
When the larger button is locked and the smaller button has returned to the initial position the landing gear retracted red warning lamps must go out; pressure in the system must first drop to 70 to 100 kg/sq.cm. and then increase. After all the three landing gear extended green warning lamps flash up, pressure in the system must sharply rise to 145 - 157 kg/sq.cm.  
Keep the system under this pressure for 10 sec. after the last green warning lamp has flashed up and turn the landing gear extension larger button counter-clockwise as far as it will go. The button must return to the neutral (upper) position.  
CAUTION: When performing this operation as well as in other cases take care not to press the smaller EXTENSION button. This may cause unlocking of the nose leg strut and retraction of the leg. Therefore, after all the operations have been performed, close the control cap, lock it with wire and place a stop under the smaller EXTENSION button.

Landing Gear Emergency Retraction and Extension

The landing gear retraction and extension from the emergency system is effected in the same way as from the main hydraulic system. Prior to pressing the emergency control buttons make sure that the landing gear normal control buttons are in the neutral (upper) position.

Checking Landing Gear Mechanism

During the retraction and extension of the landing gear check the following:  
1. Rise of landing gear retraction from the main and brake systems.  
2. Rise of landing gear extension from the main and brake systems.  
3. Maximum pressure during landing gear retraction which must not exceed 130 kg/sq.cm. from the main system and 150 kg/sq.cm. from the brake system.  
4. Maximum pressure during landing gear extension which must not exceed 130 kg/sq.cm. from the main system, 110 kg/sq.cm. from the emergency system, and 60 kg/sq.cm. from the hand pump.  
5. Operation of the ball locks of the main leg actuating cylinders. The locks must operate promptly both during the normal (main) and emergency extension and retraction of the legs.

SECRET

NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

To check the actuating cylinder for proper locking by the ball lock, its head is provided with a special hole closed with a plug.

If the actuating cylinder is locked, the lock cone projecting by 3 mm will be seen in the hole (after the plug has been removed from it); if the actuating cylinder is not locked, the lock cone does not project (the hole is completely open).

6. Operation of the landing gear light signal system.

7. Number of cycles - pumpings during landing gear extension from the hand pump. The number of cycles must not exceed 900.

**CAUTION:** The landing gear retraction and extension must be performed at a command of the person supervising the work. This person must be outside the aircraft and must observe the preparation of the aircraft and the work of the personnel. The ground supply stand should be cut in and off at his order.

Checking Landing Gear Nose Leg Wheel Turning Mechanism

To check the landing gear nose leg wheel turning mechanism, the aircraft should be jacked.

It is necessary to place Jack P9918-0 under the head of the nose leg rod and then release air pressure from the shock absorber and disengage its control device by compressing the shock absorber by means of the jack by 120 or 150 mm.

**Note:** To compress the shock absorber screw clamps may be used.

Prior to connecting the ground supply stand make sure that its hoses are clean; build up a pressure of 145 to 157 kg/sq.cm. in the main hydraulic system; to put the wheel control into action, move away the safety "tab" locking the panel button and then move the button upward. After this the system is read for operation.

The angle of wheel turn is proportional to that of the handwheel turn. The wheels must turn smoothly (without jerks). When the handwheel is not being turned, the wheels must not move spontaneously and the handwheel must be automatically locked in any position. The handwheel should not move under the action of the pressure exerted by the non-response system. The time required for the wheels to turn from one extreme position to the other must not exceed 5 sec. The central neutral position of the control panel handwheel should correspond to the wheel position along the aircraft longitudinal axis with the deflection angle accurate within 15°. The control handwheel play must not exceed 15°.

The amount of torque for rotation of the valve handwheel during the turning of the wheels must not exceed 60 kg-cm; the handwheel must move smoothly.

On pressing the button the wheel servo control must be cut off in no more than 0.5 sec. The tension of the follow-up system cables must be equal to 30 ± 5 kg; the difference in cable tension in the static condition and during the movement of the system must not exceed 8 kg.

The check over, depress the valve button and lock it with the "tab".

Checking Bomb-Bay Door Actuating Mechanism

When checking the bomb-bay door actuating mechanism, the main hydraulic system may be fed by:

- (a) a special stand connected to the units panel located at frame No. 34 (the hoses from the stand should be let through the hatch in the starboard door);
- (b) the hand pump, type HP-01;
- (c) pumps (units 435-B9) with the engine operating.

prior to checking the mechanism switch on the control and signal system circuit breakers.

The tactical control of the bomb-bay doors is performed from one or two tumblers mounted on the starboard panel of the navigator-bombardier, while the door emergency opening is performed simultaneously with bomb release from a separate tumbler mounted on the port panel of the navigator-bombardier or from the tumbler mounted on the left pilot's instrument board.

When the system de-energized, the doors are opened from the storage batteries by means of the tumbler mounted on the left pilot's side panel.

The auxiliary closing of the doors can be performed from the brake system by means of the tumbler mounted on the pilots' central panel. The doors having been closed, do not switch off the tumbler earlier than in 6 sec.

During the opening and closing of the doors check the following:

- (a) operation of the ball lock fixing the doors in the closed position;
- (b) the time required for opening and closing the doors from the main system (not more than 2 sec. for opening and not more than 3 sec. for closing), from the emergency system (not more than 3 sec. for opening), and from the auxiliary system (not more than 10 sec. for closing).

When closing the doors from the hand pump the required number of cycles (pumpings) must not exceed 120;

- (c) correct operation of the slide valve distributor;
- (d) operation of the light signal system.

Checking Brake System and Brake Adjustment

The operation of the brake system should be checked during the emergency retraction and extension of the landing gear, during the bomb-bay door closing from the auxiliary control, and during the normal and emergency wheel braking.

The time required for charging two hydraulic accumulators of the brake system to a pressure of 150 kg/sq.cm. must not exceed 140 sec.

During the charging of the hydraulic accumulators check the characteristic operating duties of pumping station 465X indicated in the Specifications and determined by the adjustment of the HMB-150 oil pressure switch, as well as pressure (130 ± 2 kg/sq.cm.) at which the emergency hydraulic accumulator pressure drop warning lamp goes out. The current consumed by pumping station 465X must not exceed 180 A.

**Note:** Pumping station 465X must not operate continuously on the ground under normal operating conditions for more than one hour; after this the pumping station must be completely cooled prior to the next starting.

The main and emergency hydraulic accumulators, when charged to capacity, should ensure 10 braking cycles each.

The amount of air pressure in the hydraulic accumulator gas chamber during charging is determined by sending a short electric pulse from the pumping station forced switching tumbler.

The hydraulic system must be previously discharged to zero.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 112 -

Air pressure in the hydraulic accumulator gas chamber should be checked first with the emergency hydraulic accumulator switched off and then with the accumulator switched on.

The indications of the MAIN BRAKING (ОСНОВНОЕ ТОРМОЖЕНИЕ) and EMERGENCY BRAKING (АВАРИЙНОЕ ТОРМОЖЕНИЕ) pressure gauges at which a smooth pressure increase begins will correspond to the pressure in the hydraulic accumulator gas chamber. To accurately measure pressure during charging of the hydraulic accumulator use a pressure gauge screwed into the charging valve.

With the brake system in good repair, pressure drop from 150<sup>±2</sup> to 120<sup>±3</sup> kg/sq.cm. during not less than 45 min. is permitted.

**Note:** During charging of the hydraulic accumulator from zero to 150 kg/sq.cm. pressure in it will drop more rapidly as a result of cooling of nitrogen which is warmed up on compression. Therefore, measure the time after 5 or 6 operations of the HJ13-150 oil pressure switch.

To check the brake adjustment, connect four pressure gauges (instruments H9941-310) to the brake line after the pressure reducers. The line is provided with special valves for connecting the pressure gauges. When pressing the pedal pressure in the wheel expander tubes should be proportional to the pressure applied to the pedals. Pressure in the expander tubes should increase within 1/6 to 1/4 of the pedals full travel and reach 13 or 14 kg/sq.cm. when they are pressed as far as they will go.

With each pedal pressed as far as it may go, the force applied to it must not exceed 85 kg.

**Note:** The moment of the beginning of the valve braking action is adjusted by screwing in the thrust screw on the pedal lever. During braking the pressure difference as indicated by the pressure gauges of the port and starboard struts must not exceed 1 kg/sq.cm. with the pedals fully pressed.

If effort applied to the pedals is relieved smoothly, pressure in the expander tubes should decrease gradually, and at the moment the pedals are 1/6 or 1/4 short of the stop the pressure should drop to zero.

The parking brake in action must ensure a pressure of 11 to 12 kg/sq.cm. in the expander tubes.

The interaction of the brake pedals of both pilots must meet the following requirements:

- if the right pilot presses his pedals without intending to brake and creates a pressure of up to 5 kg/sq.cm. in the wheel expander tubes, this must not prevent the left pilot from fully pressing his pedals and creating an operating pressure of up to 13 - 14 kg/sq.cm. in the expander tubes;
- if with the right pedals pressed, a pressure of up to 5 kg/sq.cm. is built up in the expander tubes and the left pilot sharply releases his pedals from the fully compressed position, pressure in the expander tubes must drop to 5 kg/sq.cm.

Wheel braking must begin at a pressure of not over 1.5 kg/sq.cm. in the expander tubes; release must take place not later than in one second after the pressure applied to the brakes has been relieved.

To check the wheel automatic braking, disconnect the inertia transmitter (anti-skid detectors), type JA-24. From the wheels without breaking the electric circuit, and by closing the circuit with sharp movements of the transmitter shaft check by the pressure gauges pressure drop in the expander tube from each transmitter in turn.

At this, the pressure relief slide valve, type PA-49, must operate promptly and reliably ensuring pressure drop in one second at the most.

- 113 -

50X1-HUM

After the brake automatic device has operated pressure in the expander tubes must increase during 1.5 sec. at least. This time depends on the diameter of the hole in the flow restrictor mounted in the pipe line upstream of the brake valves, type JT-50. The lamp on the pilots' central instrument board must flash up at each closing of the JA-24 transmitter circuit.

**Note:** The PA-49 valve must not be energized for more than two minutes.

When a pressure over 8 kg/sq.cm. is built up in the brake valve line, the hydraulic switches, type JT-34, must close the circuit of the PA-49 valves; at a pressure less than 4 kg/sq.cm. they should open the circuit. On disconnecting the automatic brake tumbler located on the pilots' central panel the brake automatic device must stop operating.

During emergency braking check to see that:

(a) the brake system is isolated from the main system with the shut-off valve closed;

(b) the shuttle valve on the pressure reducers can be switched over reliably;

(c) during the first braking, with the handles pressed as far as they will go and the charging valve closed, pressure in the wheel expander tubes amounts to 14 - 17 kg/sq.cm.;

**Note:** Prior to braking pressure in the system must be equal to 150<sup>±2</sup> kg/sq.cm.

(d) after the release of the handles the time required for wheel release does not exceed 1.5 sec.;

(e) the effort required to turn the "tab" of the emergency hydraulic accumulator charging shut-off cock does not exceed 10 kg.

## 3. SPECIAL INSTRUCTIONS

When carrying out preflight and postflight inspections of the landing gear and hydraulic systems, follow the "Inspection Guide No. 2H, Part I" and the below instructions:

1. When examining the collapsible strut of the landing gear nose leg, check the following:

- locking of hinged connections;
- strut lock. When the lock is closed, there should be no clearance between the stops of the front link and the strut flat truss. The strut must be deflected by 8 or 10 mm, while the lock side links (See Fig.83) must be in such a position that their axes of symmetry are above the axis of rotation of the crank by 0.5 to 1 mm.

2. When examining the pipe lines located in the fuselage compartments between frames No. 5, 9, 13, 15, and 24, check to see that the pipes are clear of one another and of the metal parts of the aircraft. The clearance between separate pipes in a bunch must be not less than 2 mm; in separate places it is permitted to reduce this clearance to 1.5 mm at straight sections and to 1 mm at bent sections. In places of bending where it is impossible to maintain the required clearance, cover the pipes with two or three layers of insulating tape for a length of 40 mm.

SECRET  
NO FOREIGN DISSEM

4. FAULTS AND REMEDIES

No.	Fault	Cause	Remedy
1	2	3	4
MAIN HYDRAULIC SYSTEM			
1	Time required for landing gear retraction exceeds the normal value, time required for landing gear extension being normal	The valve of the flow restrictor located at frame No.11 is jammed	Replace the flow restrictor
2	Time required for landing gear extension exceeds the normal value, time required for landing gear retraction being normal	The choke of the flow restrictor located at frame No.11 is clogged	Replace the flow restrictor
3	Time required for landing gear extension and retraction exceeds the normal values	(a) The slide valve distributor of the nose leg or one of the main legs is leaky. Oil flows from the main system tank into the brake system tank (b) The pump output is insufficient (units 435-B0)	(a) Replace the defective oil valve distributor  (b) Replace the pump
4	Spontaneous turning of the nose leg and the control handwheel after pressure has been relieved	The resistance of the brake spring of the nose leg control handwheel is insufficient	Unscrew the attachment nut and remove the control handwheel. Extend the brake spring and place under it a washer not more than 4 mm thick. Assemble the panel and check the landing gear nose leg turning control system
5	On the aircraft raised by hydraulic jacks the landing gear nose leg does not stop and continues to turn spontaneously upon the control handwheel is stopped	The flow restrictor of the additional damper is clogged, which is determined by the effort required to move the damper rod disconnected from the leg	Replace the additional damper

1	2	3	4
6	Spontaneous switching off nose leg control system	The rod of the control panel button is improperly locked. The efforts required for depressing and pulling out the button do not correspond to the rated value (the effort should not exceed 9 kg for depressing the button and 5 kg for pulling out the button)  Incorrect adjustment of the pumps (units 435-B0)	Tighten up the adjusting screw of the stop so as to obtain the normal efforts required for depressing and pulling out the button
7	Oil pressure in the main system built up by the pumps (units 435-B0) is higher or lower than normal pressure	(a) Air pocket in the line feeding oil to the pressure gauge (b) Pressures built up by separate pumps (units 435-B0) are unequal	Adjust the pump and check pressure in the main system with the engines running  (a) Drain a small amount of oil from the line (b) Adjust the pumps to equalize pressure
8	Pointer of the pressure gauge measuring pressure in the main system flickers	(c) The resistance of the flow restrictor in the line feeding oil to the pressure gauge and located in front of the left pilot's instrument board is insufficient	(c) Screw up the flow restrictor pin to stop the pointer flicker
9	The bomb-bay doors fail to get opened from the emergency system	(a) The supply circuit of the BMC-1 door emergency opening switch is de-energised or the switches are faulty (b) With the BMC-12 electromagnet de-energised, the door main control lets oil pass into the door closing line. To check for this fault, disconnect the hose supplying oil to the door closing line from the hydraulic actuating cylinder and build up pressure in the system. The appearance of oil through the hose open end testifies to a faulty control	(a) Check the circuit and the BMC-1 switch  (b) Replace the door main control

SECRET

NO FOREIGN DISSEM

1	2	3	4
10	The bomb-bay doors fail to get opened both from the main and brake systems	With the electromagnet de-energized, the door auxiliary closing control (of the brake system) lets oil pass into the door closing line	Open the doors by releasing pressure from the brake system. Replace the door auxiliary closing control
11	The bomb-bay doors fail to remain in the closed position after closing	(a) The 885-1 door auxiliary or emergency opening switch is energized at all times (b) The spring is weak and the ball lock of the door actuating mechanism fails to get locked (c) The stop of the door emergency opening mechanism is worn out (d) The doors are too tight  <b>Note:</b> With the actuating cylinder in good repair and the emergency mechanism cocked, the ball lock should get locked at a pressure of 70 to 80 kg/sq.cm. built up by the hand pump and should open from the normal control at a pressure of 25 to 30 kg/sq.cm.	(a) Check the circuit  (b) Replace the actuating mechanism  (c) Replace the stop  (d) Reduce the tightness
BRAKE HYDRAULIC SYSTEM			
1	Pumping station 465K gets switched off and on at pressures which do not meet the Specifications	The pressure switch, type HHS-150, is mis-adjusted	Replace the pressure switch, type HHS-150
2	The telltale lamp of the brake system emergency control flashes at pressure lower than 128 kg/sq.cm. or higher than 135 kg/sq.cm.	The pressure drop warning unit, type CH-130, is misadjusted	Replace the pressure drop warning unit, type CH-130
3	Pumping station 465K fails to get switched off. Pressure in the system is less than 150 kg/sq.cm.	The safety valve of panel H5606-0 is mis-adjusted. The valve opens at pressure less than 160 kg/sq.cm.	Replace the valve

1	2	3	4
4	The efforts required for pressing and releasing the parking brake exceed the rated value	The parking brake mechanism is misadjusted	Adjust the parking brake mechanism
5	The system hydraulic accumulator fails to ensure 10 cycles of wheel braking	(a) Wear of the brake shoes exceeds the permissible value (4 mm) (b) The hydraulic accumulator is insufficiently charged with air. To check the degree of charging the hydraulic accumulator with air, release pressure in the system to zero and effect a short pressure pulse by actuating the tumbler switching on pumping station 465K. Pressure built up in this way will correspond to the degree of charging the hydraulic accumulator with air (c) Presence of air in the system	(a) Replace the brake shoes  (b) Charge the hydraulic accumulator with air to $60 \pm 3$ kg/sq.cm.
6	On pressing the pedals the wheels fail to get braked	The circuit of the brake automatic unit is shorted (the brake automatic unit warning lamp on the pilots' central instrument board is on)	(c) Check the electric circuit
7	The brake automatic unit has failed (the wheel tyres may get damaged)	(a) The wiring is faulty (b) The JT-34 switch has failed (c) The JA-24 transmitters have failed	(a) Check the wiring (b) Replace the JT-34 switch (c) Replace the JA-24 transmitters
8	Time required for emergency retraction and extension of the landing gear exceeds the rated value	(a) Voltage in the aircraft mains is insufficient (b) The output of pumping station 465K has decreased due to a damage to the contact of the aims jumper and that of the "to frame" connection	(a) Increase voltage in the aircraft mains (b) Check the wiring

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

1	2	3	4
9	The effort required for turning the emergency system charging shut-off cock exceeds the rated value	(c) The flow restrictor or choke is clogged (d) The output of pumping station 465X is insufficient  The effort exceeds 10 kg as measured by the dynamometer	(c) Replace the flow restrictor (d) Replace the pumping station  Replace the cock
10	Pressure in the drain tank fails to drop	The valve releasing pressure in the tank is jammed	Eliminate jamming or replace the valve
11	Rapid pressure drop in the system	Oil passes into the return line through: (a) the brake valve, type JI-92 (b) the relief valve of panel R5606-0 (c) the solenoid-operated valve of the bomb-bay door emergency control  Most often this fault may be detected by listening. If it is impossible to detect the fault in this way, disconnect the return line  Leakage in the return line with the unit in the neutral position indicates that the unit in question is faulty	Replace the defective units
12	On pressing the pedals, the wheels are braked with great delay	Air pocket in the brake line	Evacuate air from the system by pumping oil through the wheel expander tubes into the tank

50X1-HUM

Chapter VI

POWER PLANTS CARE AND MAINTENANCE

1. SPECIAL DIRECTIONS

The preflight and postflight inspections of the power plants are performed in accordance with Inspection Guide No.2R, Part I, and the following additional directions:

1. The amount of main fuel delivered to the aircraft tanks during refuelling is checked (with the aircraft mains de-energized) by using refuelling floats (Fig.102), contained in the equipment set furnished with every aircraft.
2. When inspecting the engine air intake duct, check the duct-to-compressor housing sealing (Fig.103).
3. When inspecting the brackets and the attachment fittings of the cowls and covers, make certain that the frame and the skin are free of any defects. Check to see that the nuts holding the cowl frame, and the cover attachment fittings are securely locked.
4. Check the attachment of the engine mount brace strut to the engine and to fuselage load-carrying frames Nos 43 and 46. All locking nuts on the engine mount brace struts should be securely tightened and locked by locking washers. Tightening of the locking nuts on the engine mount brace struts should not be resorted to unless absolutely necessary, as their repeated locking may lead to leakage of the locking washer tabs, which will call for disassembly of the brace strut adjustable units and for engine levelling.

When checking the units, see that no load is imposed on engine mount brace strut No.7, which testifies to the fact that the engine has been levelled properly.

*Note:* With the engine at standstill, brace struts Nos 4, 5 and 6 may be slightly rocked by both hands.

5. Check the position of the pipe lines in the bulkhead openings. The distance between the pipe line and the edges of the hole should not be less than 1.5 mm per side; the pipe line should be rigidly secured.

*Note:* The clearance between the pipe lines and the fixed components of the engine nacelle frame should not be less than 5 mm, whereas clearances between the pipe line and the moving components of the control links must not be less than 10 mm. A clearance of 3 to 6 mm is allowed at a distance of not over 150 mm from the pipe line attachment. In some places rubber hoses are allowed to contact flat or rounded (to not less than 4 mm radius) smooth frame components.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 120 -

6. Check the electric circuits controlling the isolating valves and warning button lamps of the fire-fighting system, proceeding as follows:

(a) switch on signal circuit breaker A30-5 mounted on the right-hand panel. Circuit breaker A30-10 - CO<sub>2</sub> BOTTLE CONTROL (ЖИВАВЕРЖЕ БАУТОНАКІ CO<sub>2</sub>) located on the same panel should be switched off;

(b) cut in the switch mounted on the fuel supply control board and carrying the inscription FIRE-FIGHTING SYSTEM (ПОЖИВОНОЖ. СИСТЕМА);

(c) press successively all the button lamps located on the fuel supply control board FIRE WARNING PANEL (ЖИВАВЕРЖЕ ПОЖАВА НА КАБОЛІТЕ).

If the electric circuit is serviceable, the button lamps should light up;

(d) cut out and then cut in the FIRE-FIGHTING SYSTEM switch. The button lamps must remain on.

The fire-fighting system will be ready for operation as soon as circuit breaker A30-10 (CO<sub>2</sub> BOTTLE CONTROL) mounted on the right-hand panel is switched on.

**Note:** When the engine compartment button lamps are pressed, the engine blow-off band closes the ports; the engine control lever set against the CUT-OFF (ОТОВ) stop causes the shutter in the branch pipe supplying air to the cowl to close. Closing of the ports is accompanied by a click, whereas closing of the shutter may be observed by the action of the control cylinder located on the branch pipe.

7. Check fuel gauge system COTO-609, proceeding as follows:

(a) switch on the following circuit breakers mounted on the right-hand panel: A30-2 with the inscription FUEL CONSUMPTION CONTROL (ЖИВАВЕРЖЕ ПАКІОН ТОУЛІБА); A30-5 with the inscription AUTOMATIC FUEL CONSUMPTION (АВТОМАТ. ПАКІОН ТОУЛІБА); A30-2 with the inscription CONTROL OF SERVICE PUMPS OF TANKS NOS 6 AND 16 (ЖИВАВ. ЖЕЛІВН. ДОУІАЖІ КАНОВ No. 6 + 16); A30-2 with the inscription MEASURING FUEL IN TANK GROUP (ЖЕЛІВН. ТОУЛІБА ПІВІВІ); and A30-2 with the inscription FUEL PUMP AND SHUT-OFF COCK SIGNALLING SYSTEM (ЖИВАВЕРЖ. ТОУЛІБ. КОМІ Н КОЖАВ. ЖПАВЖ);

(b) switch on inverter NO-4500 and check voltage in the A.C. mains, which should amount to  $115 \pm 1$  V;

(c) switch on both circuit breakers LEFT, RIGHT (ЖЕЛ., ЖПАВ.) arranged on the fuel supply control board, under the inscription SWITCHING FUEL CONSUMPTION CONTROL UNIT (ЖЕЛІВН. АВТОМАТ. ПАКІОН ТОУЛІБА), and set the circuit breaker located under the inscription CONTROL (ЖИВАВЕРЖЕ) in the AUTOMATIC (АВТОМАТ) position;

(d) switch on both circuit breakers A30-5 (LEFT, RIGHT) FUEL GAUGE SUPPLY (ЖЕЛІВН. ТОУЛІБОНЕЖОС) located on the right pilot instrument board, and push the buttons on the fuel gauge indicators to shift their pointers to the zero position. Then, by shifting the knobs of each fuel gauge switch (Ж-7 onto the terminals TOTAL, 1 GROUP, 2 GROUP, 3 GROUP, 4 GROUP, and 5 GROUP (ЖАВІА, 1-р., 2-р., 3-р., 4-р., 5-р.)) read the amount of fuel in each of the tank groups off the indicator inner scale, and the total amount of fuel per engine off the outer scale. Then, check the results obtained against the readings of the refueling truck fuel gauges;

(e) check both (right and left) amplifiers ЖА-08, operating in parallel, by de-energizing them in turn. Continuous burning of the pilot lamps on the fuel supply control board will indicate that the amplifier energized at the time is sound;

- 121 -

50X1-HUM

(f) check to see that automatically controlled booster pumps are properly started during aircraft refuelling. With the engine at standstill, operation of the pumps is checked aurally as well as by the indications of the green pilot lamps mounted on the fuel supply control board; with the engine running, pump operation may be checked by the indications of the green lamps only;

(g) check fuel consumption manual control by setting the circuit breaker, located on the fuel supply control board under the inscription CONTROL, in the MANUAL (ЖИВАВЕРЖЕ) position. If circuit breakers A30-5 for manual control of the I, II, III, and IV tank groups are kept in the OFF (ЖИВАВЕРЖЕ) position, the pilot lamps will go out. Then by cutting in circuit breakers A30-5 of each of the I, II, III, and IV tank groups in succession, check the operation of the respective pumps aurally as well as by the indication of the green pilot lamps;

(h) having checked the measuring section of the fuel gauge system and determined the precise amount of fuel contained in the aircraft tanks (both total amount and amount contained in each of the tank groups), set the pointers of fuel gauges PTC-16 against the divisions corresponding to the total indications of the fuel gauges (for each of the power plants).

8. Check the fuel shut-off cocks for tightness and proper operation; check the respective signalling devices.

The tightness of the fuel shut-off cocks is checked by means of electric pressure gauge ЖМВ-5, which measures fuel pressure upstream of pumps ЖВЖ-15. With the booster pumps inoperative, the pressure gauge pointer should read zero; with the pumps running and the fuel shut-off cocks closed, the pressure gauge readings should remain the same.

9. To prepare the engine for starting:

(a) fit checks under the landing gear wheels;

(b) thoroughly clean the ground in front of the aircraft of foreign objects, dirt, and dust; in summer time the ground should be watered;

(c) drain fuel sediment (1.5 to 2 lit.) through the drain cocks of the groups of tanks filled with fuel. Having drained the sediment, close the cocks and lock them prior to each flight;

(d) connect the aircraft mains to the power supply source, and check voltage which should be within  $27.5 \pm 2.7$  V;

(e) check air pressure in the aircraft air system, which should not be less than 80 kg/sq.cm.;

(f) open the ports by actuating the engine air blow-off band and close the cowl covers.

To open the ports by the air blow-off band, turn on circuit breaker A30-5, FUEL SUPPLY COCK (ЖИВАВЕРЖЕ. ЖПАВ) located on the left pilot instrument panel, push the button on the engine, and turn off the wing nut on the stud, simultaneously checking the operation of the cowl shutters mechanism;

**Notes:** 1. The air blow-off band should open the ports only after all operations have been performed and inspection completed to prevent foreign objects from finding their way into the engine compartment.

2. Engine starting after completion of scheduled maintenance or repair work should be done with the cowl covers open to allow inspection of the pipe lines and individual assemblies on the running engine, as well as to check engine adjustment.

(g) check the engine control system by shifting the respective control levers

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 122 -

from the CUT-OFF stop to the maximum speed stop and backwards. If the control system has been properly adjusted, the levers will move smoothly (without jamming or jerks); no play is allowed in the control system. With the engine control lever set against the idle rating stop, the indicator of the NH-28 pump lever should be between the extreme notches of the idle rating sector.

When the engine control lever is set in the CUT-OFF or TAKE-OFF (BURN) position, the pump lever should closely contact the respective stops, whereas the engine control lever should be capable of travelling additionally by at least 5 mm.

The positions of the CUT-OFF and TAKE-OFF stops are checked prior to each flight, the CUT-OFF stops being checked both on the running and inoperative engines, while the TAKE-OFF stops - on the inoperative engines only. The positions of the engine control lever are checked for proper agreement with the positions of the NH-28 fuel pump lever indicator on the CUT-OFF stop in the following cases: when the idle rating r.p.m. has changed; when the engine is not motoring over at starting, or smokes after it is stopped; a change in the engine maximum rating r.p.m. also calls for the above check.

(h) check the turbo-starter exhaust pipe shutters for proper operation, proceeding as follows:

- switch on circuit breaker A3C-25 and two circuit breakers A3C-15 mounted on the circuit breaker panel of the left pilot and incorporated in the engine starting system;

- turn on the master switches (2M-45) mounted on the engine starting panel; make sure the pilot lamps light up and the exhaust pipe shutters are fully open;

**CAUTION:** Do not start the engine, unless the turbo-starter exhaust pipe shutters are fully open.

- turn off the master switches thereby causing the shutters to close and the pilot lamps to go out;

- (i) check pressure in the brake hydraulic system by the readings of pressure gauge NH-250H.

Apply the parking brakes.

10. When starting the engines, check the changes taking place in the turbo-starter and engine characteristics.

11. Inspect the engine nacelles on the outside and inside for damage on the frame components or skin; check to see that the inspection hatches and the cowl covers are closely fitted and securely locked; make certain no foreign objects are left in the nacelles; see that there are no fuel or oil runs on the cowl covers or on the engine housing.

In case traces of fuel or oil are detected, or some foreign objects are found in the nacelle, the engine, its units and pipe lines must be subjected to a more thorough inspection; check the air blow-off band and its control mechanism units for damage; make sure the inspection doors of the three external covers of the nacelle are intact.

12. Inspect the engine attachment fittings, making sure there are no cracks or corrosion on the engine mount rods and assemblies; check to see there are no loose bolts or defective joints. When carrying out the inspection, bear in mind that brace strut No.7 should freely turn in the hinges, and that peening may develop on the rods under loose bolt heads and nuts.

13. When replacing the engine control system cables, or tightening them up, refer to the respective data presented in Fig.104.

14. When inspecting the hoses and pipe lines running inside the engine

- 123 -

check the high-pressure line hoses (especially those of the 50X1-HUM) for proper condition.

In case "sweating" or minor damage is detected on the high-pressure lines, check whether they are fit for further service at high pressure, with the engine running.

Leaky joints in the pipe lines should be eliminated by replacing the sealing rings. After replacing the sealing rings, tighten the union nuts by turning them through 60°-10°, in case the pipe diameter amounts to 24 mm, or through 50°-10°, with the pipe diameter exceeding 24 mm.

Start tightening up the nut after it comes against the bearing surface of the pipes to be connected.

15. Should it become necessary to start the engine with the cowl open, the air blow-off band should open the ports just before starting.

Never start the engine with the ports closed by the air blow-off band.

16. The engine oil system tanks hold 35 lit. of oil each. The amount of oil in the tank is measured with the aid of a dip stick connected to the filler cap.

**CAUTION:** When fitting the filler cap complete with the dip stick in position, take care to avoid misalignment or displacement of the cap so as not to affect its tightness. With the engine running, oil will squirt out of the tank filler, if the cap is not tight.

After filling the tanks with oil:

- (a) deliver oil to the pipe line upstream of the engine pump through the main cock (the cock clear opening being 10 mm) located on the supply line till the oil stream does not contain any air bubbles;

- (b) crank the engine to fill the system with oil and to eliminate air locks, as well as to check oil pressure in the system by means of electric pressure gauge NH-4P (oil pressure should not be less than 0.5 kg/sq.cm. at an engine speed of 500 to 600 r.p.m.).

**CAUTION:** Prior to cranking the engine, run the starter 1 or 2 times until its speed reaches 8000 - 15,000 r.p.m. (depending on the rise of gas temperature in the exhaust pipe) with the purpose of burning the remaining oil.

Having cranked the engine, drain the oil through the cock (having a clear opening of 8 mm) located on the oil sump of the lower drive;

- (c) check the amount of oil in the tanks by using a dip stick, and replenish the tanks with oil preheated to a temperature of 60 - 80°C (each tank should contain 30 lit. of oil).

17. If the main fuel filter is to be dismantled and the filtering assembly is to be extracted, proceed as follows:

- (a) drain all fuel from the filter through the drain cock, having lifted by its upper cover with the filtering assembly to let in the air;

- (b) dismantle the filter, with the fuel shut-off cocks closed;
- (c) fit a cap onto the outlet port of the filtering assembly, and cover the filter housing with cloth to keep off dirt;

- (d) when handling the filtering elements, use special tongs (Fig.106) and protective caps to prevent foreign matter and dirt from getting into the elements.

- (e) clean the filtering elements with a fine hair brush when washing them (Fig.107).

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

— 128 —

## 2. AIR SYSTEM

When inspecting the air system refer to "Inspection Guide No.2H, Part 1" besides check the following:

1. Condition of the flexible hoses (see that they are not damaged, twisted or crumpled at the bends).

2. Clearances between the pipe lines and fixed components of the aircraft frame, as well as between the pipe lines and moving parts.

The clearances should not be less than 5 mm and 10 mm respectively.

In some places clearances are allowed to be reduced to 3 - 6 mm, provided the place is not farther than 150 mm from the point of the pipe attachment.

3. Air pressure in the bottles by the readings of pressure gauges MB-250a arranged as follows:

- in the left pilot cabin, at frame No.7;
- on the hatch pressurization board located on the right pilot air panel at frame No.6;
- in the navigator's cabin, at frame No.4, starboard side.

Charging System with Compressed Air  
from Ground Bottle

To charge the system with compressed air delivered from ground bottles, proceed as follows:

1. Close all the cocks and remove the cap from the charging connection.

2. Bring the bottles under the port engine, connect the charging hose to one of the bottles, blow it with compressed air, and then connect the hose (with the system shut-off cock 215K closed) to the aircraft charging connection located on the left air panel, at frame No.43. The ground bottles should be arranged on a support in an inclined position, with the valves pointing upwards.

3. Make sure the drain cocks of the oil traps on the air panels of the starboard and port engines are closed.

4. Open the system shut-off cock located on the air panel; then open the valve of the ground bottle and watch the aircraft pressure gauges indicating an increase in the air system pressure.

5. The system should be charged to a pressure of 100 - 140 kg/sq.cm. As soon as the specified pressure is built up, close the shut-off cock on the air panel, then close the valve on the ground bottle, detach the charging hose, and fit the cap onto the charging connection.

**CAUTION:** 1. Prior to detaching the charging hose, with the ground bottle valve and the system shut-off cock closed, bleed pressure from the hose by loosening the union nut on the bottle valve by 0.5 - 1 turn.

2. The aircraft is allowed to be flown, provided the minimum pressure in the air system is not below 80 kg/sq.cm., engine starting on the ground requires a pressure of not less than 60 kg/sq.cm.

Checking Air System on Ground

Checking the air system includes:

1. General inspection of the entire system for tightness, which is performed after the aircraft is equipped with all special installations, reducing valves (units 436), pressure control units AV-2 (units 200H), and after the compressed air consumers have been cut off. To check the general tightness of the system it is necessary to charge the system to a pressure of 140 kg/sq.cm. and to

— 129 —

50X1-HUM

maintain this pressure for 30 min., without opening the consumer cocks. The tightness of the system may be considered adequate, if pressure within the above period drops to 110 kg/sq.cm. The pressure drop in the system is indicated by aircraft pressure gauges MB-250a; the readings may somewhat differ but they must not be below 110 kg/sq.cm.

In case one of the pressure gauges reads a pressure that is below 110 kg/sq.cm., find out the cause of air leakage from the system and eliminate it.

2. Checking the shut-off valves incorporated in the cabin pressurization line for proper operation.

To check the shut-off valve control equipment:

(a) watch pressure gauge MB-250a located on the right pilot air panel (Fig.108) to see that the pressure in the system amounts to not less than 50 kg/sq.cm.

(b) open the shut-off cock of reducer H7610-10; pressure gauge MB-10a

should read the following pressure values:

• 0.9 kg/sq.cm., with pressure upstream of the reducer equal to 50 kg/sq.cm.;

• 0.6 kg/sq.cm., with pressure upstream of the reducer amounting

to 100 kg/sq.cm.;

• 0.2 kg/sq.cm., with pressure upstream of the reducer equal to 150 kg/sq.cm.

• 0.1 kg/sq.cm., with pressure upstream of the reducer equal to 200 kg/sq.cm.

The shut-off cock of reducer H7610-10 and pressure gauge MB-10a are located

on the right pilot air panel;

(c) open the cocks controlling the shut-off valves in the pressurization line, and check aurally the operation of the shut-off valves arranged on the engines (the shut-off valve should produce a click). The shut-off valve control cocks are located on the right pilot panel mounting the equipment designed for control of cabin pressurization and of the wing de-icing devices, whereas the shut-off valves are mounted on the flanges of the engine compressor middle housings;

(d) close the control cocks causing the air from the shut-off valves to be bled into the atmosphere via the control cocks;

(e) after repeating the operations described in Points (c) and (d), keep the control cocks open for 15 min. having closed the cock of reducer H7610-10. Within this period of time, pressure drop, as indicated by pressure gauge MB-10a, should not exceed 1 kg/sq.cm.;

(f) close the shut-off valve control cocks.

3. Checking the hatch doors and the pilot canopies for proper tightness.

To check the hatch doors and the pilot canopies for tightness, proceed as follows:

(a) close the access hatches and set all jettison control handles in the CLOSED (ЗАКРЫТО) position;

(b) open the shut-off cock of reducer H7610-10 and shut-off cock HATCH PRESSURIZATION (ПЕРЕКРЫВАНИЕ ДВЕРЕЙ) arranged on the right pilot air panel. Having ascertained that the pressurization hoses are being filled with air, keep the cocks open for 1.5 to 2 min. until pressure ceases to rise, which is indicated by pressure gauge MB-10a, then close the cock of reducer H7610-10;

(c) keep the pressurization hoses under pressure for 15 min. During this period of time, pressures drop in the hoses, as measured by pressure gauge MB-10a, should not exceed 1 kg/sq.cm.;

(d) close cock HATCH PRESSURIZATION and open the access hatches.

4. Checking the wing de-icing devices shut-off valve controls. To check the controls:

(a) open the cock of reducer H7610-10 and the cock controlling the shut-off valves of the wing de-icing devices. This should cause the shut-off valves on the engines to operate (which is evidenced by a click). The shut-off valves are

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

mounted on the flanges of the compressor rear housings, whereas the control cock is arranged on the pressurization and wing de-icing devices panel;

(b) close the control cock; the air from the shut-off valves should be bleeding through the control cock;

(c) after repeating the operations described in Points (a) and (b), keep the control cock open for 15 min. having closed the cock of reducer H7610-10. Pressure drop as read by pressure gauge MB-10a should not exceed 1 kg/sq.cm.;

(d) close the cock controlling the wing de-icing devices.

5. Checking the air blow-off band and engine cowl shutter controls. For checking these controls:

(a) by the readings of pressure gauge MB-250a arranged on the left pilot's side make sure that the pressure in the system amounts to 100 - 140 kg/sq.cm.;

(b) open upper covers Nos 2 and 3 of the cowls to gain access to the air blow-off band control button arranged on the engine and to observe the operation of the blow-off band control mechanism;

(c) press the blow-off band control button, with circuit breaker AEN COCK (BOEZHIM: KHAL) mounted on the left pilot circuit breaker panel turned on, then screw the wing nut off the stud. This will bring the solenoid-operated air cock to action, whereas the cowl shutters will close;

(d) release the blow-off band control button. The band and the cowl shutter should open;

(e) open and close the bands and the shutters, repeating the procedure two times; check the respective control mechanisms for prompt operation; make sure the band and the cowl shutters operate synchronously; check the air system for leakage aurally;

(f) press the blow-off band control button and screw the wing nut onto the stud.

**CAUTION:** When checking the operation of the mechanisms controlling the air blow-off band and the cowl shutters, take care to see that no foreign matter finds its way into the engine compressor through the air blow-off ports. Guard the cowl shutters against damage.

6. Checking the engine de-icing devices control controls. To check the controls (a) ascertain (by the readings of pressure gauge MB-250a mounted on the left pilot's side) that the pressure in the system amounts to not less than 60 kg/sq.cm.;

(b) open the engine de-icing devices control cock, arranged on the right pilot's board. This should cause the control mechanism cylinder to open the throttle valve on the engine, thereby allowing heated air to flow into the de-icing devices;

(c) close the control cock. This should make the control mechanism cylinder close the throttle valve on the engine, thereby causing the air from the control system to be bled through the control cock. Repeat the above check twice;

(d) check the cock controls for tightness, for which purpose set the control cock in the OPEN (OTKRYTO) position, and watch pressure gauge MB-250a mounted on the left pilot's side to read pressure drop in the system during 15 min. In case of adequate tightness of the controls, the pressure drop should not exceed 5 kg/sq.cm.;

(e) close the control cock.

3. SERVICING AIRCRAFT WITH FUEL AND OIL

50X1-HUM

Servicing Aircraft with Main Fuel

1. Main fuel grades used by engines YI-3U are referred to in the performance data of the power-plants.

2. Prior to delivering main fuel into the aircraft tanks, de-aerogise the engine main, ground the aircraft and the refuelling truck, and check the condition of the fuel to be delivered into the aircraft tanks; make sure the refuelling truck is sealed and the fuel sediment is drained off.

3. If the refuelling truck system incorporates a compound filter (felt with silk cloth) and a strainer in the fuel dispensing gun (having 4000 meshes per sq.cm.), fuel may be supplied directly into the aircraft tanks. When proceeding in this manner, take care to see that the refuelling truck filters are checked in due time and are kept in good repair.

4. The maximum amount of fuel delivered into the tanks is checked against control set by the readings of the refuelling float. Refuelling floats (Dvgn H9961-500 and H99-600) are incorporated in every aircraft equipment set and are designed to stop fuel delivery into the tank groups with the purpose of preventing fuel surflow (See Fig.102).

When a tank group is filled partly the amount of fuel to be delivered into the tanks is checked by the readings of the refuelling truck flow meter.

5. The order of tank filling (Fig.109) (the reverse order of fuel consumption from the tanks) is presented in Table 12, whereas the data pertaining to checking the amount of fuel delivered into the tanks are given in Table 13.

Table 12

Order of Tank Group Filling

No. of tank filling	Port side				Starboard side				
	No. of tank belonging to group	Tank group capacity, as measured by refuelling float, lit.	No. of tank furnished with filter	Marking of tank group float	No. of tank group and order of tank filling	No. of tank belonging to group	Tank group capacity, as measured by refuelling float, lit.	No. of tank furnished with filter	Marking of tank group float
I(1)	5 (left)	2700	6(left)	"5 group"	V(1)	6(right)	2700	6(right)	"5 group"
II(2)	12 - 16 (left)	3050	12(left)	"3 group"	IV(2)	12 - 16 (right)	3050	12(right)	"3 group"
III(3)	7 - 11 (left)	5850	7(left)	"3 group"	III(3)	7 - 11 (right)	5850	7(right)	"3 group"
II(4)	4	3350	4	"2 left group"	II(4)	3	3150	3	
I(5)	1 and 2	6900	2	"1 left group"	I(5)	5	7200	5	"1 right group"

Notes: 1. Tank No.3 has a level indicator housed in the tank proper.  
2. Tank groups V, IV, and III (at the aircraft port and starboard sides) have one refuelling float each.

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

3. Total capacity of the aircraft fuel tanks amounts to 43,800 lit.  
 4. Order of tank group filling is indicated for each of the aircraft sides by the numbers in brackets.

**Table U**  
 Data to Be Referred to while Checking Amount of Main Fuel Delivered into Aircraft Tanks by Means of Fuel Gauge System C370-60H and for Checking System C370-60H Proper

Amount of fuel delivered into aircraft tanks, lit.	No. of tank group	No. of tank in group	Colour of pilot lamp in system C370-60H					Tanks with booster pump running		
			blue		green			No. of tank in group	pump type	
			number of lamps	No. of tank in group	number of lamps	No. of tank in group	number of lamps			
1	2	3	4	5	6	7	8	9	10	
Tanks filled to capacity:										
14,100	I	1, 2, and 5	1	I	4	I	4	2 and 5	Normal	
6500	II	4 and 3	1	II	2	II	2	4 and 3	Normal	
11,700	III	7 - 11 (right and left)								
6100	IV	12 - 16 (right and left)			2	III	2	16 and 16	Stand-by	
5400	V	6 right and 6 left								
<b>Total . . . 43,800</b>										
0	I	1, 2, and 5	1	I	4	I	4	2 and 5	Forced	
6500	II	4 and 3	1	II	2	II	2	4 and 3	Normal	
11,700	III	7 - 11 (right and left)								
6100	IV	12 - 16 (right and left)			2	III	2	16 and 16	Stand-by	
5400	V	6 right and 6 left								
<b>Total . . . 29,700</b>										
0	I	1, 2, and 5	1	I	4	I	4	2 and 5	Forced	
0	II	4 and 3	1	II	2	II	2	4 and 3	Normal	
11,700	III	7 - 11 (right and left)	1	III	2	III	2	10 and 10	Normal	
6100	IV	12 - 16 (right and left)			2	IV	2	16 and 16	Stand-by	
5400	V	6 right and 6 left								
<b>Total . . . 23,200</b>										

50X1-HUM

1	2	3	4	5	6	7	8	9	
0	I	1, 2, and 5	1	I					
0	II	4 and 3	1	II					
0	III	7 - 11 (right and left)	1	III	2	III	2	10 and 10	Forced
6100	IV	12 - 16 (right and left)	1	IV	2	IV	2	16 and 16	Normal
5400	V	6 right and 6 left			2	V	2	6 and 6	Stand-by
<b>Total . . . 11,500</b>									
<b>Example No. 1</b>									
(a) fuel remaining in aircraft tanks: 6600 <sup>+400</sup> <sub>-200</sub>									
(b) fuel supplied:									
0	I	1, 2, and 5	1	I					
0	II	4 and 3	1	II					
0	III	7 - 11 (right and left)	1	III	2	IV	2	16 and 16	Normal
1200 <sup>+400</sup> <sub>-200</sub>	IV	12 - 16 (right and left)	1	IV	2	V	2	6 and 6	Stand-by
5400	V	6 right and 6 left							
<b>Total . . . 13,200</b>									
<b>Example No. 2</b>									
(a) remaining fuel: 6600 <sup>+400</sup> <sub>-200</sub>									
(b) fuel supplied:									
0	I	1, 2, and 5	1	I					
0	II	4 and 3	1	II					
0	III	7 - 11 (right and left)	1	III					
0	IV	12 - 16 (right and left)	1	IV					
5400	V	6 right and 6 left			2	V	2	6 and 6	Stand-by
<b>Total . . . 12,000</b>									
<b>Example No. 3</b>									
0	I		1	I					
0	II		1	II		Dead			
0	III	All tanks	1	III			2	16 and 16	Normal
0	IV		1	IV			2	6 and 6	Stand-by
0	V								
<b>Footnote: 1. For checking fuel gauge system C370-60H it is necessary to</b>									

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 130 -

- turn on two circuit breakers 430-2, three circuit breakers 424, four change-over switches controlling amplifier supply and the change-over switch controlling the stand-by booster pumps of tank group IV.
2. Filling some tank group to capacity (as read off the refuelling float dial) and switching on fuel gauge system C370-60M afterwards will be accompanied by starting the booster pumps of the tank group in question as well as of the preceding tank group, no matter whether it contains fuel or not. In this case the pumps of the tank group filled with fuel will run at a nominal duty, whereas the empty tank group pumps will operate at a forced duty.
  3. The booster pumps of tank group I will be cut off as soon as the amount of fuel in tank No.4 diminishes to 2450<sup>±</sup>250 lit., and in tank No.3 to 2250<sup>±</sup>250 lit.
  4. The booster pumps of tank groups I and II stop when the amount of fuel in tank group III decreases to 5000<sup>±</sup>250 lit.
  5. The booster pumps of tank groups I, II, and III are put out of operation when the amount of fuel in tank group IV decreases to 2300<sup>±</sup>250 lit.
  6. The booster pumps of tank group V start running as soon as fuel in tank groups I and II is used up and the amount of fuel in tank group III is reduced to 2500<sup>±</sup>150 lit.
  7. With the fuel amount in tank group IV decreased to 600<sup>±</sup>200 lit. or less, the red pilot lamp lights up and keeps glowing thereby indicating that the amount of fuel left is sufficient for 30 min. of flight.
  8. When the amount of fuel in tank group V decreases to 1600<sup>±</sup>100 lit. or less, the red pilot lamp light up and keep glowing thereby indicating that the amount of fuel left is sufficient for 30 and 15 min. of flight.

With the fuel completely used up or drained off, the tanks should be filled starting from group V; in case not all of the fuel has been consumed, those tank groups should be filled first which require replenishment.

6. The amount of fuel to be supplied into the aircraft tanks depends on the mission to be fulfilled. The unit engineer calculates the amount of fuel required, proceeding from the flight graph. The amount of fuel held by all of the tank groups as well as by the individual tank groups is indicated by the fuel gauges of the C370-60M system.

The difference between the calculated amount of fuel required and the amount actually contained in the aircraft tanks will represent the amount of fuel to be added.

**CAUTION:** 1. If some tank group is to be filled to capacity, never fail to deliver the specified amount of fuel into it, since operation of the C370-60M automatic equipment will be affected in case some of the fuel is transferred to the next tank group.

2. No extra fuel should be supplied into the tanks to prevent fuel from being spouted out of the tank vent system.

7. Prior to servicing the aircraft with fuel place special protective walks on the upper surface of the wing.

- 131 -

This done, check to see that the fuel dispensing guns and floats are 50X1-HUM on the aircraft skin around the filler caps, ground the fuel dispensing gun and open the tank filler plugs by pressing the filler button carrying the inscription PRESS (HAWM) (Fig.110). This will cause the spring to force the filler plug out of the shell.

8. Insert the refuelling floats into the tank fillers and proceed delivering fuel into the tanks.

The float pointer (See Fig.102) will tell if the given tank group is filled to capacity or not.

The pointer setting against letter II denotes that the specified amount of fuel (by volume) has been delivered into the tank group.

Tank No.3 is furnished with a permanent fuel level indicator accommodated in the tank proper. With tank No.3 filled up, word FULL (HOHPO) appears in the top hole (Fig.111).

**CAUTION:** Do not allow rain water or snow to find their way into the tank fillers.

9. Having serviced the aircraft with fuel, remove the refuelling floats from the tanks, close the tank fillers, and connect the aircraft mains to the ground power supply source for checking fuel gauge system C370-60M. Then turn a lever 00-4500 and fuel gauge system C370-60M to check the system automatic equipment for proper operation and the fuel gauges for correct readings, proceeding from the actual amount of fuel delivered into the tanks.

Set the pointers of fuel flow meter indicators PTC-16 of each engine against the divisions corresponding to the amount of fuel contained in the tank groups.

If prior to refuelling the aircraft fuel was completely drained off from the fuel system, expel air from the pipe lines carrying fuel to the engines, proceeding as follows:

- (a) set control system circuit breaker AUTOMATIC-MANUAL (ASTOMAT-PYHOE) in the MANUAL position;
- (b) start the booster pumps of the tank groups from which fuel is to be led to the engines;
- (c) turn out the plugs located upstream of pumps IH-28 and IH-15 of both engines;
- (d) open the fuel shut-off cocks and drain fuel through the pipe unions of pumps IH-28 and IH-15 till the issuing jet of fuel contains no air bubbles;
- (e) close the fuel shut-off cocks, turn in and lock the plugs upstream of pumps IH-28 and IH-15.

#### Checking Automatic Fuel Gauge System C370-60M

Automatic fuel gauge system C370-60M ensures definite sequence of fuel consumption from the tanks (in compliance with the aircraft balancing requirements), as well as measuring the amount of fuel in the tank groups, the two functions of the system being not dependent on each other. Automatic control of the fuel consumption from the tanks is accomplished through the use of two (right and left) amplifiers VAT-52-5 connected in parallel. Should the automatic equipment fail, provision is made in the system for controlling the fuel consumption manually.

Data relating to the sequence of fuel consumption from the tanks are presented in Table 14. Fuel is consumed from the tanks in a sequence providing

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 132 -

for preservation of the aircraft balance within the permissible limits both in flight and at landing.

**CAUTION:** To avoid discharging the aircraft storage batteries, the C37C-6N system should be turned on with only one engine running, or when the aircraft mains is connected to the ground power supply source.

The C37C-6N system is checked when measuring the amount of fuel left in the tanks and after servicing the aircraft with fuel.

To check the system proceed as follows:

1. Make sure that the aircraft mains is energized and that the following circuit breakers mounted on the right-hand panel are switched on: A3C-2 (fuel consumption control), A3C-5 (fuel consumption automatic control), A3C-2 (control of the stand-by pumps of tanks Nos 6 and 16), A3C-2 (measuring fuel in a tank group), and A3C-2 (left-hand and right-hand fuel pump signalling system).
2. Switch on inverters DD-4500 to obtain 115 V A.C.
3. Switch on the circuit breaker mounted on the fuel supply control panel and controlling automatic fuel consumption; set circuit breaker AUTOMATIC-MANUAL in the AUTOMATIC position.

4. Check the measuring equipment of the system, for which:

- (a) switch on two circuit breakers A3C-5 controlling the supply circuit of the fuel gauges and mounted on the right pilot instrument board;
- (b) press the buttons located on the system fuel gauge indicators which will cause the indicator pointers to set in the zero position;
- (c) shift the handles of the HI-7 switches from the OFF to the TOTAL, 1 GROUP, 2 GROUP, 3 GROUP, 4 GROUP, and 5 GROUP positions, and read the amount of fuel in each of the tank groups off the inner scale; read the total amount of fuel per each engine off the outer scale;
- (d) compare the data obtained with the actual amount of fuel delivered (as measured by the refuelling truck fuel flow meter) making allowance for the system fuel gauge error. This error should not exceed  $\pm 4$  per cent of the rated value read off the fuel gauge indicator scale.

**Note:** As the PA-3U engine uses two grades of fuel (fuel T-1 and TC-1), it should be taken into account that the system fuel gauge indications will be 6 per cent less when the aircraft is serviced with fuel TC-1. Therefore, the fuel gauge error (with the aircraft tanks containing fuel TC-1) will amount to -2 to -10 per cent of the rated value, the readings being taken off the fuel gauge indicator scale.

5. Check right-hand and left-hand amplifiers JAT-52-5 for proper functioning. For this, de-energise each of the amplifiers in turn; continuous glowing of the blue pilot lamps on the fuel supply control panel (with the amplifier energized) indicates that the amplifier is in sound condition.

6. Make sure the booster pumps start operating automatically in due time, with the definite amount of fuel contained in the aircraft tanks. If the engines are at standstill, the operation of these pumps is checked aurally and also by the indications of the green pilot lamps mounted on the fuel supply control panel. Data pertaining to the indications of the pilot lamps (blue and green) and operation of the pumps with regard to the amount of fuel delivered or still remaining in the tanks are given in Table 14.

**Note:** 1. With the fuel consumption controlled automatically, the manual control switches should be set in the OFF position.

- 133 -

50X1-HUM

2. The booster pumps of tank group IV are not capable of automatic starting, therefore, they should be started manually by switching on the circuit breaker with the inscription STAND-BY PUMPS (STAND-BY PUMPS DOWN).
3. The booster pumps of tank group V are checked for proper operation by switching on manual control circuit breaker A3C-5 (controlling tank group IV) and by switching on circuit breaker STAND-BY PUMPS which will result in starting the booster pumps of tank groups IV and V.
4. The signalling system functions in the same manner no matter whether the booster pumps are controlled manually or automatically.
7. Check the booster pumps for proper manual control by switching over circuit breaker AUTOMATIC-MANUAL from the AUTOMATIC to the MANUAL position. With circuit breaker A3C-5 (manual control of the booster pumps) set in the OFF position, the green pilot lamps on the fuel supply control panel should go out. Switch on the booster pumps of the tank groups in turn manually and check them for proper operation aurally and by the indications of the green pilot lamps.
8. After checking the system and finding the exact amount of fuel (total and each of the tank groups), set the pointers of fuel flow meters PTC-16 against the divisions corresponding to the total amount of fuel (per each engine) as read by the fuel gauges, or ascertain that the fuel flow meter pointers are set in positions conforming to the readings of the system fuel gauges.

To set the pointers of fuel flow meters PTC-16 in correct positions, set the fuel flow meter switches in the ON position, and bring their pointers to the required divisions with the aid of the adjusting screw located in the lower part of the fuel flow meter indicators. Fuel flow meter PTC-16 indicates the amount of fuel remaining in the tank groups supplying the given engine, provided the fuel is fed to the engine in question only.

**CAUTION:** In the case of fuel leakage from the system, or fuel delivery to the engine via the cross-feed line, fuel flow meters PTC-16 will not read the actual amount of fuel remaining in the aircraft tanks.

SECRET  
NO FOREIGN DISSEM

Table 4

Sequence of Fuel Consumption from Aircraft Tanks as Controlled by Automatic System CFF-60K

Sequence of fuel consumption tanks	Fuel consumed from tanks				Pilot lamps glowing				Booster pumps switched on or off				
	amount of fuel consumed by system fuel gauge, PFD-16, lit.	amount of fuel consumed by system fuel gauge, PFD-16, lit.	amount of fuel consumed by system fuel gauge, PFD-16, lit.	amount of fuel consumed by system fuel gauge, PFD-16, lit.	blue tank No. of sequence	green tank No. of sequence	red tank No. of sequence	yellow tank No. of sequence	blue tank No. of sequence	green tank No. of sequence	red tank No. of sequence	yellow tank No. of sequence	
1	20,000	7200	20,000	7200	9	10	11	12	13	14	15	16	17
1	I 1, 2 6900				I	I	I	I	16 right and 16 left	16 right and 16 left	16 right and 16 left	16 right and 16 left	16 right and 16 left
2	I 1, 2 2500-150	13,390-150	2500-150	13,390-150	2	I, II	I	I	2, 5	2, 5	2, 5	2, 5	2, 5
2	II 4 2450-250	12,450-250	2500-250	12,450-250	2	II	II	II	16 right	16 right	16 right	16 right	16 right
3	II 4 2450-250		2500-250	2500-250	2	I, II	II	II	3, 4	3, 4	3, 4	3, 4	3, 4
3	II 4 2500-150		2500-150	2500-150	2	I, II	II	II	16 right and 16 left	16 right and 16 left	16 right and 16 left	16 right and 16 left	16 right and 16 left
4	II 4 2500-150	10,250-150	2500-150	10,250-150	3	I, II, III	II	II	3, 4	3, 4	3, 4	3, 4	3, 4
4	III 7-11 5000-250	150-250	5000-250	9500-250	3	I, II, III	III	III	10 right and 10 left	10 right and 10 left	10 right and 10 left	10 right and 10 left	10 right and 10 left
5	III 7-11 5000-250		7-11 5000-250	5000-250	3	I, II, III	III	III	16 right and 16 left	16 right and 16 left	16 right and 16 left	16 right and 16 left	16 right and 16 left
6	III 7-11 5000-250		7-11 5000-250	5000-250	3	I, II, III	III	III	10 right and 10 left	10 right and 10 left	10 right and 10 left	10 right and 10 left	10 right and 10 left
6	III 7-11 250-15	4400-15	7-11 250-150	4300-150	4	I, II	II	II	10 right and 10 left	10 right and 10 left	10 right and 10 left	10 right and 10 left	10 right and 10 left
7	IV 12-16 2500-250	3400-250	12-16 2500-250	3300-250	4	III, IV	IV	IV	15 right and 15 left	15 right and 15 left	15 right and 15 left	15 right and 15 left	15 right and 15 left
7	IV 12-16 600-200	1700-200	12-16 600-200	1600-200	4	I, II, III	IV	IV	6 right and 6 left	6 right and 6 left	6 right and 6 left	6 right and 6 left	6 right and 6 left
8	V 6 1600-100	0-100	6 1600-100	1600-100	4	I, II, III	IV	IV	16 right and 16 left	16 right and 16 left	16 right and 16 left	16 right and 16 left	16 right and 16 left

\*The pilot lamp lights up indicating fuel reserve for 30 min. of flight.  
 \*\*The pilot lamp lights up indicating fuel reserve for 15 min. of flight.  
 Note: With the aircraft tanks filled to capacity, the pointers of fuel flow meters PFD-16 should be set against the 20,000 or 25,000 lit. division.

50X1-HUM

SECRET  
NO FOREIGN DISSEM

Fuel Drainage

Fuel may be discharged from the system either through the common drain cock located on the pipe lines in the engine compartments at frame No. 37, or through the drain cocks arranged as follows: in the bottom of tanks Nos 2, 3, 5, and 6 (right and left), on the pipe lines immediately aft of the booster pumps of tanks Nos 4, 6 (right and left), and 10 (right and left) (See Fig. 109), and on the fine fuel filters.

Fuel from the entire system, as well as from individual tank groups, may be drained through the common drain cocks with the aid of the booster pumps, whereas individual tank groups may be emptied by gravity through the drain cocks mounted in the bottom of the tanks and on the pipe lines. In case the booster pumps are employed for partial drainage of the system, the fuel remainder may be drained through the drain cocks of the respective tank groups; if the system is being drained completely, remove the fuel remainder through the drain cocks installed on the cross-feed line, on the sump of the non-return valve of tank No. 3, and the fine fuel filters.

When fuel is being drained with the aid of the booster pumps, the automatic equipment of the C370-60H system may be checked for proper functioning.

**CAUTION:** When draining fuel, open the filler plugs of the tank groups located in the wing.

Servicing Aircraft with Starting Fuel

Starting fuel is inserted into the tank of the starting system through a funnel furnished with a fine gauge (10,000 meshes per 1 sq.cm.).

Deliver 20 lit. of starting fuel into the tank prior to every flight. Before filling the tank, check the starting fuel against the Certificate, clean the funnel, rub the skin around the filler cap, and take off the cap. When filling the tank to capacity, close the filler.

Starting fuel drainage from the tank is accomplished through the cock arranged on the pipe line running to right engine pump RHP 10-3H. The cock is situated to the lower part of engine nacelle frame No. 2.

Oil System  
Servicing Aircraft with Oil and Draining

The grades of oil used for lubrication of the Ph-3H engine and the G-300-7H starter are referred to in the engine performance data.

The oil system of the aircraft is replenished by the oil servicing truck, furnished with a strainer (8100-10,000 meshes per 1 sq.cm.) and an oil dispensing gun with a gauge (8100-10,000 meshes per 1 sq.cm.) or having a funnel fitted with a fine gauge (10,000 meshes per 1 sq.cm.). Prior to delivering oil, check it against the Certificate to see whether it conforms to the Specifications.

When filling the oil system for the first time after the engine has been installed in the aircraft, or after draining the system, and also when servicing the system with oil at the ambient air temperature below -40°C, preheat the oil to 60 - 80°C. The oil system capacity amounts to 30 lit. After the engine running test check the oil level in the tank and replenish oil to bring its level to the 25 - 30 lit. mark on the dip stick.

Check the oil level in the tank after every flight, and replenish oil to

50X1-HUM

5 - 30 lit.; check oil consumption by each engine, which should not exceed 1.5 kg/hr.

- CAUTION:**
1. Whenever it is found after flight that oil has not been consumed from the system, or the oil level in the tank has gone up, check to see whether the oil contains fuel; make sure the fuel-cooled oil cooler is intact.
  2. Prior to starting the engine, check to see that the oil level in the oil tank has not decreased.

The oil system is drained in the following cases: prior to dismantling the oil system, or parts of its components; when the ambient air temperature is below -40°C; or when changing oil at the specified intervals. The oil is drained through three drain cocks: the cock of the engine lower drive oil sump, the cock installed on the supply line, and the cock mounted on the pipe line connecting the fuel-cooled oil cooler to the oil tank.

4. CHECKING FUEL JETTISON SYSTEM ON GROUND

Fuel jettisoning is resorted to whenever the flying weight of the aircraft is to be reduced prior to performing emergency landing. On these occasions fuel is discharged as follows: from tanks Nos 1, 2, and 5 - with the aid of the booster pumps through the fuel jettison cocks located on tanks Nos 2 and 5, and through the pipe line serving for aircraft refueling in flight; from tanks Nos 7-16 (port and starboard) fuel is drained by gravity through the fuel jettison cocks mounted on tanks No. 16. The respective cocks and valves are operated by compressed air. The controls of the fuel jettison system are arranged on the left pilot panel.

Operating pressure in the air system controlling the cocks and valves serving for fuel jettisoning amounts to 60 kg/sq.cm.

**NOTE:** The fuel jettison cocks and valves will yield to a pressure of 30 kg/sq.cm., but in this case they may open but partially.

Checking the fuel jettison system during preflight and postflight inspections of the powerplants consists in checking the cocks and valves as well as the air lines of the fuel jettison control system for tightness.

When checking the fuel jettison system, proceed as follows:

1. Check to see that pressure in the system (as read by pressure gauge B-252A mounted on the port side, at the left pilot panel) amounts to not less than 60 kg/sq.cm. If pressure in the system is below the specified value, boost-charge the system making use of a ground compressed air bottle.
2. In case tanks Nos 1, 2, and 5 contain fuel, run the respective booster pumps in turn for 3 to 5 min; making sure no fuel leakage shows up in the pipe line located at the tip fairing of the left wing and serving for aircraft refueling in flight; check to see that there is no fuel in the above pipe line when opening the drain cock mounted on the fuel jettison junction line at the fuel jettison cock of tank No. 5.
3. After flight, check to see whether there are any fuel runs at the access panels under the fuel jettison valves of right-hand and left-hand tanks No. 16.
4. When servicing the aircraft with fuel or checking the amount of fuel remaining in the tanks prior to refueling, with tank group III empty and tank group IV filled to capacity, check by the readings of the fuel gauges whether fuel from the filled tank group flows into the empty tank group through the fuel jettison valve located between the tanks.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 138 -

5. INSTALLATION AND REMOVAL OF BAG-TYPE FUEL TANKS,  
INSPECTION OF TANKS ON AIRCRAFT, AND SAFETY PRECAUTIONS  
TO BE OBSERVED

## General

1. With the ambient air temperature below 0°O, the tanks to be installed in the aircraft should be left for 15 to 18 hours in a warm room at a temperature of + 15 to + 18°O or preheated for 1.5 to 2 hours with dry air delivered into the tanks through a filter and having a temperature of 30 to 40°O. After preheating, the tank is to be immediately installed in the aircraft, so as not to allow its walls to cool down to below 0°O.
2. If the tank is installed in or removed from the aircraft at sub-zero air temperatures, a housing of covers should be arranged at the place of tank installation to protect the respective surfaces of the fuselage or wing. The housing should be heated for two hours with warm air delivered from ground installation H111 or H11-44-II, the temperature of the outgoing air being not in excess of + 40°O.
3. Prior to installing or removing a fuel tank, the aircraft should be cut off the power supply source, grounded, and mounted on hydraulic jacks.

Safety Precautions to Be Observed when Installing,  
Removing and Inspecting Bag-Type Fuel Tanks

1. Handling the bag-type fuel tanks may be entrusted only to personnel well acquainted with the safety regulations.
2. When carrying out some operations inside the tank, do not fail to observe the following safety measures:
  - (a) stand on a clean, soft mat, wear a clean overall, slippers made of cloth, and a gas mask with the hose led out;
  - (b) use copper-plated tools having no sharp edges, place the tools on the mat;
  - (c) employ an explosion-proof, sealed electric lamp (type PH-100) supplied with voltage not exceeding 24 - 36 V;
  - (d) the person inside the tank should be kept under constant observation so that timely medical aid could be rendered as soon as possible in case of intoxication caused by fuel vapours.

## Inspection of Bag-Type Fuel Tanks on Aircraft

To inspect the bag-type fuel tanks on the aircraft perform the following operations in the recommended sequence:

1. Drain fuel from all the tank groups.  
See that no fuel gets on the external surface of the tanks. If some fuel does get on the above surface, wipe the respective areas dry with a clean rag and blow with dry air.
2. Mount the aircraft onto hydraulic jacks.
3. Remove aircraft frame panels barring access to the tank mounting hatches.
4. Fit a dummy panel having an opening to provide access to the tank mounting hatch under each of the tanks; the dummy panel will prevent sagging of the tank bottom or bending of the mounting hatch frame, which is likely to be caused by the man climbing into the tank.

- 139 -

50X1-HUM

- Secure the dummy panel with 12 bolts (6 bolts at each of the panel sides) with load-carrying profiles of the frame, making use of the bolts which have been removed from the frame panel dismantled.
5. Back out the bolts, holding down the tank mounting hatch cover, then lift up the cover, inspect it, and place into the respective recess of the rack. To avoid deforming the cover, remove the bolts in the following manner:
    - first slacken the bolts by turning each bolt by 3 to 4 revolutions, using a socket wrench;
    - then remove the bolts by hand or with a socket wrench. When removing the remaining bolts, press the cover against the tank.

**CAUTION:** Care should be exercised when removing the cover to prevent fuel remaining in the tank from being spurted in the face of the maintenance man.

6. Remove remaining fuel from the tank by using a clean lintless wad or chamois leather, then wipe the tank dry.
  7. Prior to inspecting the tank, ventilate it for 12 to 24 hours, and then heat it for 30 min. with dry filtered, compressed air.
  8. Thoroughly inspect the internal surface of the tank and all its joints for the following defects:
    - (a) mechanical damage (punctures, tears, etc.);
    - (b) contamination of the surface with paint, oil, and other agents;
    - (c) bands attaching tank hoops coming off the inner layer;
    - (d) fringing of band edges and eyes fastening the hoops; fringing or rupture of strings attached to the eyes;
    - (e) lint on the bands and on the internal surface of the tank;
    - (f) flanges of the tank fittings coming off the tank walls;
    - (g) edges of the kerosene-resistant layer coming off the tank walls around the flanges of the tank fittings;
    - (h) swelling of rubber laid in the protected wall of the tank under the normal kerosene-resistant layer.
  9. After completion of the tank inspection and prior to closing the mounting hatch, enter the date of inspection and the operations performed in the tank certificate, ascertain that the tank is clean and does not contain any foreign objects, make a corresponding entry in the Certificate.
- Operations pertaining to installation and dismantling of the tanks should be carried out as laid down in Ty-16 Aircraft, Repair Manual, Part I, Book 2.
- Having completed the operations pertaining to fuel tank opening, lower the aircraft and remove the jacks.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



6. FAULTS AND REMEDIES

No.	Fault	Cause	Remedy
1	System is not tight (as indicated by left pilot pressure gauge MB-250a), with consumers out off	<p>1. Leaky safety valve (unit 438) on frame No. 13, at left spherical bottle (3-lit. capacity at 150 kg/cm.) located in nose wheel bay (Fig. 112)</p> <p>2. Leaky safety valve of reducer PB-60 located at starboard side in fuselage compartment 0-2 at frame No. 9</p> <p>3. Leaky reducer 669200/5 installed at starboard side in fuselage compartment 0-2 at frame No. 9</p> <p>4. Leaky drain cock of moisture trap located at starboard side in fuselage compartment 0-2 at frame No. 9</p> <p>5. Cannon mount air supply system is not tight</p> <p>6. Leaky solenoid-operated air cock 252800 incorporated in engine fire-fighting system</p> <p>7. Leaky cock controlling engine de-icing system</p> <p>8. Leaky fuel jet-tison control cock</p> <p>9. Air leakage through joints of pipe lines running from non-return valve 998A of left spherical bottle (3-lit. capacity at 150 kg/cm.), located in nose wheel bay, to control cock</p>	<p>Air leakage can be detected aurally. Repair safety valve</p> <p>Air leakage can be detected aurally. Repair reducer</p> <p>Air leakage through reducer can be detected aurally. Replace reducer</p> <p>Air leakage can be detected aurally: (a) close drain out if open (b) replace moisture trap and drain cock</p> <p>Eliminate air leakage by tightening up joints</p> <p>Replace cock</p> <p>Replace cock</p> <p>Replace cock</p> <p>Air leakage can be detected with the aid of soapy water applied to pipe line joints. Eliminate leakage by tightening up respective joints</p>

1	2	3	4
2	System is not tight (as indicated by left pilot pressure gauge MB-250a), with engine de-icing device control cock turned on	<p>1. Air leakage through joints of pipe lines incorporated in engine de-icing device valve control system</p> <p>2. Air leakage from cylinder of throttle valve control mechanism</p>	<p>Air leakage is detected by applying soapy water to pipe line joints. Eliminate leakage by tightening up pipe line nipple joints</p> <p>Replace cylinder</p>
3	System is not tight (as indicated by right pilot pressure gauge MB-250a) with consumers out off and cock of reducer located on right pilot air panel open	<p>1. Leaky safety valve (unit 438) on frame No. 31 at right spherical bottle (3-lit. capacity at 150 kg/cm.) located in nose wheel bay (See Fig. 112)</p> <p>2. Leaky moisture absorber housing mounted on frame No. 12</p> <p>3. Leaky safety valve of reducer H7610-10 located on right pilot air panel (Fig. 113)</p> <p>4. Leaky gland in cock of reducer H7610-10 located on right pilot air panel</p> <p>5. Leaky shut-off valve mounted on right pilot air panel</p> <p>6. Air leakage through joints of pipe lines running from non-return valve 998A of right 3-lit. bottle located in nose wheel bay to control cock</p> <p>7. Air leakage through wing de-icing device shut-off valve control cock, or through one of cocks controlling cabin pressurization shut-off valves</p>	<p>Air leakage is detected aurally. Replace safety valve</p> <p>Replace moisture absorber</p> <p>Replace reducer</p> <p>Replace reducer</p> <p>Close shut-off valve; if air leakage does not stop, replace valve</p> <p>Air leakage is detected by applying soapy water; eliminate leakage by tightening up pipe line joints</p> <p>Replace defective cock</p> <p>Leakage is detected by applying soapy water. Eliminate leakage by tightening up joints</p>
4	System is not tight (as indicated by right pilot pressure gauge MB-250a), with cock	<p>1. Air leakage through joints of shut-off valve control pipe lines</p>	<p>Leakage is detected by applying soapy water. Eliminate leakage by tightening up joints</p>

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM

1	2	3	4
5	controlling wing de-icing device shut-off valves turned on System is not tight (as indicated by right pilot pressure gauge MB-250a), with cabin pressurization valve control cocks turned on	2. Damaged diaphragm in wing de-icing device shut-off valve 1. Air leakage through joints of cabin pressurization valve control pipe lines 2. Diaphragm of cabin pressurization shut-off valve is damaged	Replace valve  Leakage is detected with the aid of soapy water; eliminate trouble by tightening up joints  Replace shut-off valve
6	System is not tight (as indicated by right pilot pressure gauge MB-250a), with cock controlling hatch pressurization open, and aircraft entrance hatches closed	1. Hatch pressurization hose is damaged 2. Air leakage through pressure relief valve incorporated in pressurization hose 3. Air leakage through joints of pipe lines delivering air to hatch pressurization hoses	Replace defective hose  Tighten up joint or replace valve  Tighten up joints
7	System is not tight (as indicated by Navigator's pressure gauge MB-250a), with consumers out off	Air leakage through joints of pipe lines running from non-return valve 998A4 of 4-lit. capacity bottle located in hydraulic panel compartment to control cocks	Air leakage is detected by application of soapy water; eliminate leakage by tightening joints
8	Pressure drops in pipe lines running along starboard side, with air being consumed from pipe lines running along port side	Non-return valve 998A4 of right-hand 3-lit. bottle (Fig. 114) is sticky	Replace non-return valve
9	Engine compressor blow-off band fails to close ports when control button is pressed	1. Air system is not charged with air 2. Air leakage through safety valve (unit 436) mounted on pipe line serving both for charging 3-lit. ca-	Charge air system using ground bottle Replace safety valve

1	2	3	4
10	When system is being charged from ground bottle, air flows from charging line to line running from compressor AK-150H to bottles	Non-return valve of port engine pressure control unit ANV-2 (unit 208B) is binding	Pressure in oil trap of left-hand air panel is indicative of defective valve. Replace pressure control unit
11	System is charged with air from compressor AK-150H at too slow rate both on ground (with engines running) and in flight irrespective of engine rating (Fig. 115)	1. Drain cocks of engine air panel oil traps are not closed tightly 2. Adjustment of low-pressure reducer (unit 436) is disturbed  3. Pressure control unit ANV-2 (unit 208B) is out of adjustment, which causes compressor to permanently run idle when pressure in system is below 155 <sup>±</sup> 5 kg/sq.cm.	Close drain cocks  Check low-pressure reducer technical characteristics against Certificate data. Replace reducer if some discrepancy is found. Check new reducer prior to installing it  Try out each engine in turn, and determine time required for charging bottles to see which pressure control units is out of adjustment. Replace defective pressure control unit  Check technical characteristics of low-pressure reducer against Certificate data; replace reducer if some discrepancy is detected
12	System is charged by compressors AK-150H at low rate in flight at high altitudes and at normal rate at low altitudes	Low-pressure reducer housing (unit 436) is not tight; as a result, reducer fails to operate properly at high altitude (See Fig. 115)	

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

— 144 —

1	2	3	4
13	System is charged at low rate by compressors AM-150H both on ground with engines running, and in flight at engine speed exceeding that at which engine compressor air blow-off band closes ports	<p>1. Air leakage through ducts of solenoid-operated air cock 2512800 mounted in engine</p> <p>2. Air leakage through swivel angle of solenoid-operated air cock 2512800 due to dry or damaged gaskets</p> <p>3. Air leakage from air blow-off band control cylinders, or from engine cowl shutters control cylinders</p>	<p>Air leakage can be detected aurally when control button is pressed thereby causing air blow-off band and cowl shutters to close. Replace solenoid-operated cock</p> <p>Replace solenoid-operated cock</p> <p>Air leakage is detected aurally, or with the aid of soapy water applied to joints and vent holes, with cock 2512800 open. Replace leaky units</p>
		FUEL SYSTEM	
1	With aircraft parked for prolonged periods, fuel flows through cantilever vent pipes	<p>1. One or more tank groups arranged in wing are overfilled with fuel</p> <p>2. Intertank fuel jettison valve is leaky</p> <p>3. Non-return valve of tank group IV is leaky</p> <p>Fuel jettison valve of tank No. 16 is not tight</p> <p>One of cocks for fuel jettison from tank group I is leaky</p>	<p>Check refuelling procedure by indications of refuelling floats and refuelling truck flow meter.</p> <p>Drain excess fuel</p> <p>Replace valve</p> <p>Replace valve</p> <p>Replace valve</p> <p>Replace cock</p>
2	Fuel leaks through fuel jettison valve of tank No. 16		Replace valve
3	With booster pumps of tank group I running, fuel flows from pipe line serving for aircraft refuelling in flight (located in wing tip fairing)		Replace cock
4	Unequal amounts of fuel are consumed from similar groups of tanks	Cross-feed valve is open	Close cross-feed valve. Prior to each flight check to see that cross-feed valve is closed and is not leaky

— 145 —

50X1-HUM

1	2	3	4
5	Amount of fuel in reserve tank group increases (as indicated by fuel gauge)	Non-return valve of reserve tank group is leaky	Replace valve
6	Pilot lamp of tank group from which fuel has been fed to engines in flight keeps glowing after it is switched off and next tank group starts feeding fuel to engines	Vent connection of pressure warning unit CR-37Y is fitted with cap	Take rubber cap off vent connection of pressure warning unit CR-37Y
7	Fuel flows from vent hole of booster pump CR-1 (unit 461)	Gland packing of pump CRH-1 is leaky	Replace booster pump
8	Fuel spurts from vent pipe of fuel jettison control cock	Gland packing of fuel jettison cock of tanks Nos 5 or 2 is leaky	Replace leaky cock

SECRET  
NO FOREIGN DISSEM

~~SECRET~~  
NO FOREIGN DISSEM

50X1-HUM

**Chapter VII**  
**AIRWORTH EQUIPMENT, CARE AND MAINTENANCE**

**1. BASIC SPECIFICATIONS**  
**Pressurization Reducing Valve (PRV)**

(Fig. 119)

Maximum permissible pressure at the valve inlet (with the valve closed) .....	not in excess of 5 kg/sq.cm. (abs.)
Pressure at the reducer outlet .....	not in excess of $1 \pm 0.35$ kg/sq.cm. (abs.)
Amount of air passing through the valve .....	not less than 150 kg/hr
Pressure at the outlet at which the safety valve opens .....	$1.6 \pm 0.05$ kg/sq.cm. (abs.)

**Air Delivery Regulator (ADR)**  
(Fig. 120)

Amount of air passed by the regulator into the cockpit .....	up to 500 cu. m/hr
Amount of air passing through the pressurization reducing valve (PRV) with the regulator butterfly valve completely open .....	up to 500 cu. m/hr
Amount of air passing through the turbo-cooler (TC) with the regulator butterfly valve completely open .....	up to 250 cu. m/hr
The delivery regulator control lever is locked in the extreme and any intermediate positions.	in the extreme and any intermediate positions.

**Air Flow Meter**

Transmitter, type FBY-46y .....	Venturi tube
Indicator .....	diaphragm differential pressure gauge

Conventional volumetric units for which the indicator scale is graduated and numbered ..	from 0 to 10
Division value of the indicator scale .....	50 cu. m/hr
Pressure differential corresponding to the operating measurement range .....	33 to 293 mm of mercury
Flow meter temperature range .....	from $+50$ to $-60^{\circ}\text{C}$
Marking of the indicator connections:	
(a) on the total-pressure connection of the indicator and on the wide-section connection of the Venturi tube .....	letter A

(b) on the static connection of the indicator and on the narrow-section connection of the Venturi tube .....

**Automatic Pressure Regulator (APR-54)**

Surplus air pressure in the pressurized cockpit from the ground to an altitude of 20,000 m. with air consumption of up to 1000 kg/hr .....	not in excess of 25 mm of mercury.
Constant absolute pressure in the cockpit maintained by the regulator with air consumption from 50 to 1000 kg/hr:	
(a) at altitudes from 1800 - 2000 to 3700 - 4700 m. (at the combat rating) .....	596 $\pm$ 15 mm of mercury
(b) at altitudes from 1800 - 2200 to 6450 - 7850 m. (at the normal rating) .....	
Constant pressure differential between the cockpit and the atmosphere maintained by the regulator:	
(a) at altitudes from 3700 - 4700 to 20,000 m. (at the combat rating) .....	147 $\pm$ 15 mm of mercury
(b) at altitudes from 6450 - 7850 to 20,000 m. (at the normal rating) .....	294 $\pm$ 15 mm of mercury
Rate of pressure change when changing over from the normal to the combat rating .....	20 mm of mercury per sec.
Rate of pressure change when changing over from the combat to the normal rating .....	1.5 to 5 mm of mercury per sec.
Rate of pressure increase in the pressurized cockpit at permissible vertical speed of descent and change of air delivery from 50 to 1000 kg/hr .....	5 mm of mercury per sec.
Amount of air leakage through the regulator at surplus pressure of 235 mm of mercury in the cockpit ..	not in excess of 65 lit./min.
Solenoid D.C. operating voltage (at the combat rating) .....	27 $\pm$ 2.7 V
Current in the solenoid circuit .....	0.45 $\pm$ 0.03 A

**Reducer (R7610-10) on Hatch**  
**Pressurization Panel**  
(Fig. 121)

Reduced pressure at the reducer outlet:	
(a) at a pressure of 150 kg/sq.cm. at the reducer inlet .....	$4 \pm 0.2$ kg/sq.cm.
(b) at a pressure of 100 kg/sq.cm. at the reducer inlet .....	$4 \pm 0.9$ kg/sq.cm.
(c) at a pressure of 50 kg/sq.cm. at the reducer inlet .....	$4 \pm 0.6$ kg/sq.cm.
Pressure at which the reducer safety valve begins to open .....	6 kg/sq.cm.

~~SECRET~~  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

148

Pressure at which the reducer safety valve is completely open ..... 7 kg/sq.cm.

Pressure Gauge, Type HP-250-II, cm  
Pressurization Panel  
(Fig. 122)

Maximum permissible pressure ..... 250 kg/sq.cm.  
Pressure operating range ..... 0 to 150 kg/sq.cm.  
Pressure at which the pressure gauge must remain gaight ..... 250 kg/sq.cm.  
Permissible measurement error within pressure operating range:  
(a) at air temperature of  $+20 \pm 5^\circ\text{C}$  .....  $\pm 10$  kg/sq.cm.  
(b) at air temperature of  $+50$  to  $60 \pm 5^\circ\text{C}$  .....  $\pm 15$  kg/sq.cm.  
Vibration overload withstood by the pressure gauge ..... not in excess of 2.5 g

Pressure Gauge, Type HP-10-II, cm  
Pressurization Panel  
(Fig. 122)

Maximum permissible pressure ..... 10 kg/sq.cm.  
Pressure operating range ..... 0 to 6 kg/sq.cm.  
Pressure at which the pressure gauge must remain gaight ..... 10 kg/sq.cm.  
Permissible measurement error within pressure operating range:  
(a) at air temperature of  $+20 \pm 5^\circ\text{C}$  ..... 0.4 kg/sq.cm.  
(b) at air temperature of  $+50$  to  $60 \pm 5^\circ\text{C}$  ..... 0.6 kg/sq.cm.  
Vibration overload withstood by the pressure gauge ..... 2.5 g

Pressurization System Desiccator  
(H7610-78)

The desiccator is charged with silica gel, type HGM.

The term of the silica gel service is 25 flying hours. After this term has expired, the silica gel should be dried at  $100^\circ\text{C}$  for 20 minutes to be then used again in the desiccator.

Two-Way Cook (H7610-100) of Hatch  
Pressurization System

Time during which pressure is released from the packing hoses through the cook ..... 3 to 3 sec.  
Pressure for which the cook spring is calibrated ..... 1 kg/sq.cm.  
Pressure at which air passes into the hatch packing hoses ..... 3 kg/sq.cm.

149

Units and Reference Instruments of Aircraft  
Altitude Equipment

50X1-HUM

No.	Description of unit	Type of unit	Purpose of unit	Quantity
1	2	3	4	5
<b>Cockpit Pressurization and Heating System</b>				
1	Shut-off valve	H7601-895	Switching on and off pressurized cockpit pressurization system and wing nose de-icer system	4
2	Non-return valve of cockpit pressurization system	H7601-300	Ensuring air flow in one direction	3
3	Supply valve	H7601-611	Distributing air stream coming from engine compressor between lines running to turbo-cooler and to pressurization reducing valve (PRV)	2
4	Turbo-cooler (TLT)	Item 1245	Cooling and reducing pressure of air delivered to pressurized cockpits from engine compressor	2
5	Pressurization reducing valve	PRV	Reducing pressure of air delivered to pressurized cockpits to $1 \pm 0.35$ kg/sq.cm. (abs.)	2
6	Air delivery regulator	H7601-885	Regulating amount of air delivered into cockpit	2
7	Air flow motor	FBY-46y	Measuring amount of air delivered into cockpit	2
8	Cockpit air pressure automatic regulator	APA-54	Ventilation of cockpits at low altitudes and maintaining pressure in cockpits at preestablished value at high altitudes	2
9	Combination pressure valve (KRV)	H7601-50 H7601-185	Regulating cockpit pressure by hand, emergency pressure release in cockpits and performing function of safety valve	2
10	Control valve	H7601-240	KRV combination valve control	2

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

1	2	3	4
11	Cockpit emergency pressure release valve	H7601-465	HEH combination valve control at emergency pressure release in cockpits from left pilot and rear gunner
12	Electric heater	Item 107	Warming up air delivered to glass of navigator's, pilot's, and gunner-radio operator's canopies
13	Cockpit air temperature regulator	TPPER-45 (TPPER-4821)	Control of supply valves H7601-631 by means of electric motors, type MPT-1
14	Cockpit thermometer	TD-45	Measuring air temperature in cockpits
15	Non-return (vacuum) valve	H7601-371 H7601-308	Equalizing cockpit air pressure with the atmospheric pressure so as to protect cockpits from damage
16	Slide valve	H7601-575	Control of compressed air delivery to recess of shut-off valve H7601-495
<u>Cockpit Atmospheric Air Ventilation System</u>			
17	Atmospheric air intake with electric motor, type N3R-2	H7611-50	Atmospheric air delivery to front cockpit at low altitudes
18	Cockpit ventilation cock	H7601-530	Control of atmospheric air delivery to rear cockpit
<u>Hatch Pressurization System</u>			
19	Deaerator	H7610-78	Deaerating air coming into system
20	High-pressure gauge	MB-250-4	Measuring air pressure in system upstream of reducer H7610-10
21	Reducer	H7610-10	Reducing air pressure in system from 150 to 4 kg/sq.cm.
22	Low-pressure gauge	MB-102	Measuring air pressure in system aft of reducer H7610-10
23	Two-way cock	H7610-100	Reducing air pressure coming from reducer to hatch sealing hoses from 4 to 3 kg/sq.cm. and releasing pressure from sealing hoses on opening or jettisoning hatch covers
24	Hatch pressurization cock	652200A-14	Delivering air into hatch sealing hoses

1	2	3	4
<u>Control Instruments</u>			
25	Altitude and pressure differential gauge	FBHU-15	Determining cockpit altitude and pressure drop between cockpit and atmosphere
26	Thermometer	TFD-48	Measuring temperature of air coming into front cockpit
<u>2. ACCESS TO UNITS AND PIPE LINES</u>			
To ensure access to certain units and pipe lines of the altitude equipment during inspection it is necessary to dismantle other units.			
<u>Cockpit Pressurization and Heating System</u>			
To ensure access to the following units of this system:			
1. To the pipe lines running along the starboard side between frames Nos 7 and 10, remove:			
- PCB-70 station remote control panel;			
- aircraft interrogator-responder control panel;			
- YC9-II receiver control panel;			
- hatches on the right pilot's panel.			
2. To the valve control pipe lines located along the starboard side between frames Nos 10 and 12, remove:			
- thyatron interrupters located on the operator's starboard rack;			
- PCB-70 station dynamotor located on the operator's starboard rack.			
3. To the shut-off valve control pipe lines located under the floor along frame No. 9, open the floor and remove the P-2 block of the P-2 station.			
4. To the valve control pipe lines located between frames Nos 15 and 21, do as follows:			
- open the hatch located on the top of the 0-3 fuselage compartment between frames Nos 15 and 17;			
- remove fuel tank No. 1;			
- open the hatches on the starboard side of the container of fuel tank No. 1.			
5. To the pipe lines and the combination and vacuum valve installations located on the bottom of frame No. 69 in the second pressurized cockpit, remove the radio operator's seat.			
6. To the valve control pipe line and to the shut-off valves located in the engine nacelle, open the third liner lower cover and the third outer lower cover of the nacelle.			
All the other units and pipe lines of the system are easily accessible.			
<u>Hatch Pressurization System</u>			
To ensure access to the following units of this system:			
1. To the hatch pressurization pipe line laid on the starboard side between frames Nos 6 and 11, remove:			
- PCB-70 station remote control panel;			
- aircraft interrogator-responder control panel;			
- YC9-II receiver control panel;			
- right pilot's seat;			
- side hatch cover on the right pilot's panel;			
- thyatron interrupters and the PCB-70 station dynamotor on the operator's starboard rack.			

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

- 152 -

2. To the reducer on the hatch pressurization panel, remove the pressurization panel.

3. To the two-way cock of the rear pressurized cockpit entrance hatch, open the hatch of the starboard ammunition belt feed mechanism.

All the other units and pipe lines of the system are easily accessible.

### 3. SPECIAL INSTRUCTIONS

Pre-flight and post-flight inspections of the equipment should be performed in compliance with the "Inspection Guide No. 21", part I and the following additional instructions:

1. Prior to flight check clearances between the rods of the two-way cocks and the levers shown in Fig. 123.

The clearances of the entrance hatch cocks should be checked with the entrance doors closed.

2. Prior to flight check the outlet slots in the branch pipes and clearances between the branch pipes and the pilots' canopy glass shown in Fig. 124.

### 4. CHECKING EQUIPMENT WITH ENGINES OPERATIVE

#### Checking Hatch Pressurization System

1. Close the entrance hatches and the emergency escape hatches of the pressurized cockpits.

2. Check the device interlocking the two-way hatch pressurization air cock with the hatch cover jettisoning mechanism taking into consideration that the clearances between the cock rods and the levers must be not less than 1.5 mm.

3. Make sure by the high-pressure gauge on the hatch pressurization panel that there is a pressure of 120 to 150 kg/sq.cm. in the system before the reducer.

4. Open the HIGH-PRESSURE LINE (СЕТЬ ВЫСОКОГО ДАВЛЕНИЯ) reducer cock.

5. Make sure by the low-pressure gauge that there is a pressure of 0.5 to 0.2 kg/sq.cm. in the system behind the reducer.

6. Open the HATCH PRESSURIZATION (ПРЕПЯТСТВУЮЩИЙ ВХОДУ) cock. Pressure after the reducer must first drop sharply and then, with the sealing hoses being charged with compressed air, gradually increase to a value indicated in Item 5.

7. Examine the hatch pressurization system of the front and rear cockpits.

8. After the sealing hoses have been filled with compressed air and the system has been examined, close the reducer cock and measure the time of pressure drop in the system from 4 to 3 kg/sq.cm. which must be not less than 20 minutes. Pressure drop should be checked by the low-pressure gauge located on the hatch pressurization panel.

9. Release pressure from the entrance hatch sealing hoses. For this first close the hatch pressurization cock, then in the front cockpit pull out the mechanism ring and in the rear cockpit press the entrance hatch cover emergency jettisoning lever to whose axle a can is secured. The can presses the rocker of the two-way air cock. To prevent the rear cockpit entrance hatch cover emergency jettisoning before pressure is released from its sealing hose, the hinge lever with a roller on the hatch mechanism must be pushed back.

Pressure in the sealing hoses must decrease to zero during 3 to 5 seconds. Check the pressure drop by the hatch pressurization panel pressure gauge with the hatch pressurization cock open.

10. Restore the interlocking of the two-way cocks with the mechanism designed

- 153 -

50X1-HUM

releasing pressure from the sealing hoses of the entrance hatches and the pressure of 4 to 0.5 kg/sq.cm. in the system.

### Checking Cockpit Pressurization and

#### Heating System

1. Check for leakage the combination valve (KHL) control system in the front and rear pressurized cockpits. For this:

(a) in both cockpits set the control valves to the maximum pressure drop position by rotating their knobs to the left as far as they will go and seal the valves in this position;

(b) set the cockpit emergency pressure release valves to the CLOSED position by pulling out their buttons as far as they will go;

(c) by means of the KHV-3 device build up pressure in the KHL valve control lines corresponding to 600 km/hr as measured by the airspeed indicator; at the same time deliver air to the front cockpit via the drain pipe unions on frame No. 12 and to the rear cockpit via the drain pipe unions on frame No. 69;

(d) close the KHV-3 device delivery cock and measure air leakage from the valves by the speed change. The permissible amount of leakage must correspond to that of not more than 20 km/hr as measured by the airspeed indicator during 5 minutes.

2. Check the level of oil in the turbo-coolers and if necessary add the required amount of oil. Turbo-coolers are charged with oil, grade KHB-122-14, contained in the spare parts set. Oil must be filled not later than 1.5 or 2 hours before the turbo-cooler starts operating.

3. Check the front cockpit ventilation air intake butterfly valve for opening and closing.

For this purpose:

(a) connect the aircraft mains to the ground power supply sources and (b) on the starboard electric panel switch on the cockpit low altitude ventilation circuit breaker;

(c) switch on the cockpit low altitude ventilation switch located on the pilot's electric panel for opening the air intake butterfly valve and hold it pressed for 15 or 20 seconds. During this time the air intake butterfly valve (at frame No. 12) must be completely open;

(d) switch on the cockpit low altitude ventilation switch for closing the butterfly valve; after 15 or 20 seconds it must get closed flush with the fuselage skin.

4. Check the air supply regulator levers (PMB) for smooth travel and prompt locking in various positions. After checking set the regulator levers to the CLOSED position.

5. Check the slide valves located on the shut-off valve control panel (See Fig. 118, Ref. No. 8) for smooth travel and prompt locking in various positions.

6. Check the electric part of the automatic pressure regulator, type APT-54, for proper operation in the following manner:

(a) switch on the circuit breaker;

(b) set the switches located on the instrument boards of the right pilot and left operator to the COMBAT RATING (БОЕВОЙ РЕЖИМ) position. At this a specific click must be heard which is indicative of solenoid operation;

(c) set the switches to the NORMAL RATING (НОРМАЛЬНЫЙ РЕЖИМ) position.

SECRET

NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

- 155 -

7. Make sure that the pointers of the instruments: **PEV-46y** air flow meters, **FBHM-15** altitude and pressure differential gauges, **TP-48** thermometers are at zero.

8. Check the electric heaters (items 107) in the front and rear cockpits. For this do as follows:

- switch on the circuit breakers in both cockpits;
- switch on the electric heaters by means of the switches mounted on the pilots' upper electric panel and on the radio operator's electric panel;
- check by feel air temperature at the glass of the pilots', navigator's, and radio operator's canopies; take into consideration that with the ventilator operative the air is cool, while on switching on the heaters the air becomes warm.

#### 5. CHECKING EQUIPMENT WITH ENGINE RUNNING

1. Check compressed air delivery to the cockpit from the starboard and port engines separately and from both engines together. For this do as follows:

- open the **HIGH-PRESSURE LINE** cock located on the hatch pressurization panel and make sure that in the cockpit pressurization system there is a pressure of 120 to 150 kg/sq. cm. before the reducer and  $0.5 \pm 0.2$  kg/sq. cm. after the reducer;
- set the **RIGHT (PARAM)** slide valve handle on the shut-off valve control panel to the **OPEN** position;
- set the automatic circuit breakers of the **TPTRM-45H** thermostats in both cockpits to the **ON** position;
- advance the starboard engine to 4100 r.p.m.;
- set the **REHNM-45** switches on the right pilot's instrument board and the radio operator's panel to the **HOT (TOPRUM)** position. Then press the switches and hold them pressed for 30 to 45 seconds. During this time the air valve shutters must pass from one extreme position to the other. The check over (in 30 to 45 seconds) release both switches;

(c) by the air flow meters, type **PEV-46y**, make sure that with the **FHB** regulator closed, no air is delivered to the cockpits;

(g) by slowly moving the **FHB** regulator lever forward check the consumption of air delivered to the cockpits. On moving the regulator lever, the pointers of the **PEV-46y** air flow meters must smoothly move clockwise thus indicating air consumption in conventional volumetric units of the air flow meter. With the **FHB** regulator completely open and with air delivered through the **PEH** reducing valve, that is when hot air is delivered, the normal consumption is 5 to 7 units;

**CAUTION:** With free air temperature exceeding  $+20^{\circ}\text{C}$ , hot air delivery through the **PEH** valve must not continue for more than one minute.

(h) by the **TP-48** thermometer indicator located on the right pilot's instrument board check the temperature of air delivered to the cockpits. At 4100 r.p.m. and with air consumption being 5 to 8 units per each cockpit, the temperature of air coming into the front cockpit should be within 50 to 90 $^{\circ}\text{C}$  depending on the free air temperature. The temperature of air passing into the rear cockpit is determined by feel by the temperature of air passing out of the branch pipes as well as by a change in the cockpit thermometer indications;

- set the **REHNM-45** switches on the right pilot's instrument board and the radio operator's panel to the **COLD** position for 30 to 45 seconds. Then one

minute after the shutter has assumed a new position the **TP-48** thermometer indicator must show decrease in the temperature of air delivered to the front cockpit to  $+25^{\circ}\text{C}$  and lower, while the **PEV-46y** air flow meter must indicate decrease in air delivery to 3 or 4 units;

- Prior to changing over the **REHNM-45** switches from the **HOT** to the **COLD** position by means of the **FHB** regulator reduce the amount of hot air delivered to the cockpits to 3 or 4 units so as to avoid sharp changes of pressure in the cockpits due to different capacities of the turbo-coolers and the **PEH** valves. After the **REHNM-45** switches have been set in the **COLD** position, completely open the **FHB** regulator;
- If, when bringing the **REHNM-45** switches to the **COLD** position, air consumption and temperature do not change as indicated in Item (1), shut off air delivery to the cockpit for a short time and then open the **FHB** regulator again.

- set the **REHNM-45** switches in the **AUTOMATIC (AVTOMAT)** position;
- set the **TPTRM-45H** thermostats for 15 or 20 $^{\circ}\text{C}$ . If the air temperature in the cockpits becomes lower than the temperature the thermostat is set for, the **TP-48** thermometer must indicate an increase in the temperature of air delivered to the cockpits as the cockpit is pressurized through the **PEH** valve. In case the temperature exceeds the temperature for which the thermostat is set, the **TP-48** thermometer must indicate a decrease in the temperature of air delivered to the cockpits, the cockpits being pressurized through the turbo-coolers;
- set the **RIGHT** slide valve handle on the control panel in the **CLOSED** position; air delivery to the cockpit must cease;
- close the air supply regulator.

2. Check cockpit pressurization from the port engine as prescribed in Item 1, parts (a) to (g).

3. Check cockpit pressurization simultaneously from the starboard and port engines in the following manner:

- open the shut-off valves of both engines by setting the handles of the cockpit pressurization slide valves to the **OPEN** position;
- check the consumption and temperature of air coming into the cockpits with the **FHB** regulator completely open. Air consumption through the **PEH** valve must be from 8 to 10 units as indicated by the flow meter and through the **TPV** turbo-cooler from 4 to 6 units. When changing over air delivery from the **PEH** valve to the **TPV** turbo-cooler the temperature of air delivered to the cockpits must decrease.

**CAUTION:** 1. At free air temperature over  $+20^{\circ}\text{C}$  follow the instructions given in the **CAUTION** above.

2. To prevent the air flow meter indicator from falling, see that not more than 10 units (500 cu.m/hr) of air pass through the **PEH** valve.

3. Change over air delivery from the **PEH** valve to the **TPV** turbo-cooler and vice versa by pulses regulating air delivery by means of the **FHB** regulator butterfly valve.

4. Check two or three times the upper blister heater by setting the heater shut-off cock located in the navigator-radar operator's cockpit in the **OPEN** and **CLOSED** positions in turn; all the while check by feel the temperature of air coming out of the branch pipes of the manifold in the blister.

5. Check the wing de-icer system as follows:

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

(a) turn the de-icer slide valve on the shut-off valve control panel to the left by 90°;  
 (b) by means of the TYP-13 thermostat indicators check whether the air stream comes to the wing nozzles; the temperature must increase to +100° and higher as shown by the indicators. The temperature exceeding +100° by the indicators, close the shut-off valves on the engine.

**CAUTION:** 1. Open the wing de-icer shut-off valves for not more than one or two minutes. It is strictly prohibited to open the valves for a longer period of time as prolonged hot air delivery causes burning of the protective coating in the wing nozzles and corrugation of the wing nose skin.  
 2. With the engine running when the system is not checked, see that the shut-off valve control slide valve is in the CLOSED position at all times and that the TYP-13 thermometer on the right pilot's instrument board does not indicate temperature increase.

**6. FAULTS OF PRESSURIZED COCKPIT AND AIRTRIM EQUIPMENT SYSTEMS ENCOUNTERED DURING SERVICE**

No.	Fault	Cause	Remedy
1	The cockpit fails to get pressurized. There is no pressure in the sealing hoses of the hatch covers	1. Air leakage in the connections of the hatch pressurization system pipe lines 2. Damage to the hatch sealing hoses 3. Air leakage through the reducer packing gland 4. Jamming due to corroded reducer valve 5. Air leakage from the sealing hose because the rod of the two-way cock pressurization valve is pressed by the pressure releasing lever 6. Air leakage from the sealing hose due to	1. By means of soap water determine leaky connections and tighten them up 2. Remove the damaged hose and repair or replace it 3. Remove the reducer and replace its packing gland 4. Remove the reducer and eliminate the valve defect by means of emery cloth or replace the reducer 5. Adjust the clearance (1.5 - 2 mm) between the lever of the pressure release mechanism and the valve rod by screwing the entrance hatch stop in or out (See Fig. 117, Ref. No. 21) or by filling the lever lug Remove and disassemble the valve. Wash the

50X1-HUM

1	2	3	4
2	The system shut-off valves fail to open	Jamming at low temperatures or due to corrosion of the rod in the valve guide  7. No air pressure is built up in the cooling hose due to wedging of the cock valve caused by freezing or corrosion  1. There is no pressure in the pipe lines of the valve control system due to air leakage in the pipe connections  2. Wedging of the shut-off valve rods due to freezing, scoring or corrosion (See Fig. 118, Ref. Nos 16 and 20)	valve parts with gasoline, grade B-70, then wipe them and, if necessary, remove traces of corrosion on the rod by means of emery cloth. After the cock has been assembled, check its valve for smooth movement  7. Check the cock for leakage. No leakage of air delivered through the cock side pipe union at pressures of 0.2, 2, and 5 kg/sq.cm. is permitted. The cock valve must open at air delivery through the upper pipe union at a pressure of 1 kg/sq.cm.  1. Check the pipe connections for leakage by means of soapy water and tighten up the connections till the fault is eliminated  2. Remove and disassemble the valve. Clean the corroded and scored rods with emery cloth, then wash the valve parts with gasoline, grade B-70, and wipe them. The valve assembled, check it for smooth movement and spherical valve 21 (See Fig. 118) for leakage at a pressure of 6 kg/sq.cm. The time during which pressure in the tank (15 lit. capacity) drops from 6 to 5 kg/sq.cm. must be not less than 5 min. At air pressure of 6 kg/sq.cm. before the spherical valve, open it with air delivered to rubber diaphragm 15 via pipe union 22 at a pressure of 4 kg/sq.cm. On opening the valve a pop should be heard. The

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

- 158 -

1	2	3	4
		3. The diaphragm of shut-off valve 17601-495 is torn (See Fig. 118 4, Ref. No. 15)	check over, mount the valve in position 3. Remove and disassemble the valve and replace its rubber diaphragm. After the valve has been assembled, check the valve recess above the diaphragm for leakage under pressure (4 kg/sq. cm.) of air delivered through pipe union 22 (See Fig. 118). Under this pressure applied for not less than 10 min. the recess must be gastight. Calibrate the reducer. In case it is impossible, replace the reducer.
3	Pressure downstream of the reducer does not correspond to the rated value	The reducer is not properly calibrated	
<p><b>Note:</b> After the replacement or checking of separate units on the test stand check the gastightness of the entire system under a pressure of 4 kg/sq. cm. The time during which pressure in the system decreases from 4 to 2 kg/sq. cm. is indicative of the system gastightness; it must be not less than 15 min.</p>			
COCKPIT PRESSURIZATION SYSTEM			
1	From an altitude of 1800 to 2200 m. no surplus pressure is created in the cockpit	1. Premature opening of the HGV valve, leakage in its control valve or in the emergency pressure release valve	1. If during the flight after pulling out the control valve more than 400 and pressing the emergency pressure release valve, no fault persists, check the valves for leakage after the flight. If the valves are leaky, remove them, disassemble, grind them to fit the seats and test them for tightness and proper calibration on a special stand. In case the stand is not available, replace the defective valves 2. Tighten up the leak pipe line connections or replace the damaged pipe. This done, test the entire system for leakage 3. Remove the valve, disassemble and replace
		2. Leakage in the pipe lines connected to HGV valve	
		3. Failure (tear) of the HGV valve diaphragm	

- 159 -

50X1-HUM

1	2	3	4
		4. Jamming at various temperatures or caused by scores and corrosion of the HGV valve movable parts and of the control valve	the damaged diaphragm. This done, test the valve for leakage and check its calibration on a special stand. If the stand is not available, replace the valve 4. Remove and disassemble the valve; clean the places affected by corrosion and scores. This done, wash the valve parts with gasoline, grade E-70, wipe them and cover the movable parts with lubricant, grade UMATYI-201. The valve assembled, check it for smooth movement, leakage, effort required to open the valve, and proper calibration using a special stand. If the stand is not available, replace the valve
		5. Glogging of the calibrating hole of the APR-54 regulator connecting the control unit and the cockpit	5. Remove the regulator, scavenge it with air and check it in the pressure chamber. If the fault persists, replace the regulator 1. Tighten up yokes and nuts in the connections of the pipes 2. Remove the regulator and plug the pipe union of its damper. Build up a pressure of 0,3 kg/sq. cm. in the regulator by delivering dry air to it through the pipe union of the three-way cock. If at this pressure
2	Change in surplus pressure in the cockpit according to altitudes falls to correspond to the schedule. The defect is determined by the YBNA-15 altitude and pressure differential gauge, with the three-way APR-54 regulator in the correct position both at the normal and combat ratings	1. Leakage in the connections of the APR-54 regulator pipes connecting the control unit and the damper to the atmosphere 2. Leakage of the APR-54 regulator valve	
<p><b>Note:</b> 1. Defective HGV valves and their defective control valves are replaced in sets only, as these units are calibrated on the stand simultaneously. 2. Methods of checking the HGV valve and its control valve for leakage, effort required for opening the valve and calibration are described below.</p>			

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

— 160 —

1	2	3	4
3	Unstable operation of the APH-5A regulator at one and the same altitude both at the normal and combat ratings	<ol style="list-style-type: none"> <li>1. The regulator is misadjusted</li> <li>2. Leakage in the body of the regulator or solenoid</li> <li>3. Pressure cutting in of the RKH valve because the valve is misadjusted in relation to the APH-5A regulator</li> </ol>	<p>the valve is leaky, replace it</p> <ol style="list-style-type: none"> <li>3. Remove the regulator and check it in the pressure chamber having plugged the pipe union connecting the damper to the atmosphere. If during the test pressure in the pressure chamber changes according to altitudes in compliance with the schedule, its valve should be replaced. If the pressure chamber is not available, replace the regulator</li> <li>1. Replace the APH-5A regulator</li> <li>2. Replace the APH-5A regulator</li> <li>3. Remove the APH-5A regulator and the RKH valve together with its control valve to check it on the stand or in the pressure chamber. If the adjustable parameters of both the valve and the regulator coincide, readjust the RKH valve to increase pressure drop keeping within the range of 0.43 - 0.46 kg/sq.cm. so that the new value of pressure drop does not differ from the maximum drop maintained by the APH-5A regulator by more than 0.01 - 0.02 kg/sq.cm. In case the stand and the pressure chamber are not available, replace the RKH valve set or the APH-5A regulator</li> </ol>
4	At altitudes from 0 to 1800 - 2200 m, the surplus pressure exceeds 30 mm of mercury (0.04 kg/sq.cm.)	<ol style="list-style-type: none"> <li>1. Loss of vacuum in the silphion of the APH-5A regulator control unit</li> <li>2. Damaged (torn) diaphragm of the pressure</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace the regulator</li> <li>2. Replace the regulator</li> </ol>

— 161 —

50X1-HUM

1	2	3	4
5	Combat rating falls to get cut in	<p>release valve of the APH-5A regulator</p> <ol style="list-style-type: none"> <li>1. Poor contact or break in the supply circuit of the APH-5A regulator solenoid</li> <li>2. Inter-turn short circuit of the APH-5A regulator supply circuit</li> <li>3. Jamming of the APH-5A regulator solenoid armature</li> </ol>	<ol style="list-style-type: none"> <li>1. Ring out the regulator solenoid supply circuit and determine the place of break</li> <li>2. Ring out the solenoid supply circuit and on detecting short circuit replace the defective regulator</li> <li>3. Replace the regulator</li> </ol>
6	The cockpit fails to get pressurized	<ol style="list-style-type: none"> <li>1. Leakage in the riveted seams of the cockpit skin</li> <li>2. Separation of thickel packing or butter over the glass edging</li> <li>3. Wear of the cable packing gland</li> <li>4. Leakage in the plug connectors</li> <li>5. Leakage in the through pipe unions of the pipe lines</li> </ol>	<ol style="list-style-type: none"> <li>Test the cockpit for air leakage so as to detect leaky places</li> </ol>
UNITS REGULATING COCKPIT TEMPERATURE AND PRESSURE			
1	Air temperature in the cockpits cannot be regulated. When changing over the 2HMI-45 switches on the right pilot's instrument board or on the gunner-radio operator's panel to the HOLD position, only hot air continues to come into the cockpit and vice versa	<ol style="list-style-type: none"> <li>1. Jamming of the supply valve shutter due to wear or damage to its axle or broken teeth of the drive quadrant</li> <li>2. Failure of the MPT-1 electric motor of the shutter caused by poor contact in the plug connectors or by breakage of the wiring</li> <li>3. Failure of the MPT-1 electric motor</li> </ol>	<ol style="list-style-type: none"> <li>1. Remove and disassemble the valve. If it is impossible to eliminate the fault, replace the defective valve</li> <li>2. Ring out the wiring, clean the contacts and restore the electric motor supply circuit</li> <li>3. Replace the faulty electric motor</li> </ol>
2	Air temperature in the cockpits cannot be regulated automatically when the 2HMI-45 switches are set in the AUTOMATIC position	<ol style="list-style-type: none"> <li>1. Poor contact in the plug connector of the 2HMI-45 thermostat its supply circuit</li> <li>2. Failure of the 2HMI-45 thermostat</li> </ol>	<ol style="list-style-type: none"> <li>1. Ring out the wiring, clean the contacts of the plug connectors and restore the supply circuit</li> <li>2. Replace the faulty thermostat</li> </ol>

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

1	2	3	4
3	Considerable air leakage through the packing gland of the supply valve shutter axle	Wear of the shutter axle packing gland	Replace the defective packing gland, when assembling the shutter apply graphite lubricant to its side
<u>Pressurization Reducing Valve (PRV)</u>			
1	On shifting the shutter of the supply valve to the HOT position by the WPT-1 electric motor air fails to come into the cockpit	1. Wedging caused by freezing (at low temperatures of free air) or by corrosion of the plug cock of the valve. Glogging of the valve jet for the same reasons 2. Tear of the valve diaphragm	1. Replace the valve
2	Intensive flow of hot air under increased pressure into the cockpit	Failure of the valve syphon, the valve does not react to air pressure increase in its outlet	2. Replace the valve Replace the valve
3	Insufficient air delivery to the cockpit	Boiling of the filter	Remove the filter and wash it in clean gasoline, grade B-70. After washing dry the filter
<u>Turbo-Cooler (TC)</u>			
1	The turbo-cooler fails to decrease the temperature of air delivered to the cockpit and does not reduce its pressure to 1 kg/sq.cm.	Damage to the bearings and failure of the turbine	Replace the faulty unit
2	Intensive flow of cold air into the cockpit	Improper control of the air stream from the engines due to damaged diaphragm of the flow restrictor mechanism or that of the air expansion regulator	Replace the faulty unit
3	Oil spurring through the turbine packing gland	Damage to the turbine packing gland	Replace the faulty unit
<u>Air Delivery Regulator (ADR)</u>			
1	When operating the regulator lever air delivery checked by the FVY-46y flow meter does not change	1. Break of the control cable 2. Wedging of the regulator butterfly valve	1. Replace the brake cable or the entire unit 2. Repair or replace the defective regulator
2	With the regulator closed, the FVY-46y flow meter indicates air flow in the cockpit	Displacement of the ball securing the control cable in position on the sheave	Place the ball into the seat and cotter it

1	2	3	4
1	Spontaneous opening or closing of the regulator in flight	Loosening caused by vibrations of the regulator lever locking device	Remove the cotter pins and tighten up the lever axle nut compressing the spring washers
<p>The defects affecting the mounting of the butterfly valve and adjustment of cables can be eliminated without removing the regulator. The tension of the cables controlling the butterfly valve is adjusted so that on bringing the control lever forward the handwheel of the butterfly valve axle rotates counter-clockwise (as viewed from the regulator axle end face) and on bringing the lever backward it rotates clockwise. The tension of the cables must ensure:</p> <p>(a) complete opening and closing of the butterfly valve;                  (b) with the butterfly valve in the extreme positions, the lever must not reach the end of the control panel slot;                  (c) pressure applied to the lever must not exceed 3 kg.</p>			
<u>Air Flow Meter (AFM)</u>			
1	With air delivered to the cockpit, the flow meter pointer moves to the left (counter-clockwise)	1. Dents, cracks and other damage detected on the Venturi tube 2. Leakage in the pipe lines running from the Venturi tube to the indicator or to the flow meter body 3. Glogging of the flow meter static or total-pressure pipe lines 4. Glogging of the holes in the pipe unions of the Venturi tube 5. Failure of the aneroid or of the indicator transmission link	1. Remove the tube and dress it or replace by a new one 2. Check the pipe line connection for leakage and the pipe lines for proper connection with the instrument 3. Disconnect the pipe line connecting the transmitter and the indicator and scavenge it with compressed air 4. Clean and scavenge the holes in the pipe unions 5. Replace the faulty indicator
<u>WING DE-ICER SYSTEMS</u>			
1	The system shut-off valves fail to open	See the shut-off valves of the hatch pressurization system above	See the shut-off valves of the hatch pressurization system above
2	With the wing de-icer system switched on, the WPT-1 thermostat indicator does not react to temperature changes	1. Break in the connecting wires or thermocouple supply circuit 2. The ends of the thermocouple or those	1. Using a probe check the supply circuit and connecting wires to detect damage. 2. Check the ends of the thermocouple and wires

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 164 -

1	2	3	4
		of the connecting wires are shorted	
		3. The thermometer indicator is faulty	3. Replace the defective indicator
3	The pointers of the AP-13 thermometer indicators move to the left from zero when air temperature in the thermometer transmitter zone is positive and exceeds the ambient air temperature	Wrong polarity in the connection of wires to the thermocouples or in the plug connector	Check the connection of wires to the thermocouples and in the plug connector by current polarity and resolder their ends, if necessary
4	The pointer of the AP-13 thermometer indicator moves with jerks or the indicator reads low	Poor contact in places where the wires are connected to the thermocouples or in the plug connector	Clean or resolder the defective contacts
<b>Pressurized Cockpits</b>			
1	Air leakage through the glass of the cockpit canopy	1. Glass attachment bolts are loose 2. Thickol putty comes off 3. Rubber gaskets show from under the glass	1. Tighten up the bolts with calibrated wrenches 2. Apply thickol putty to places where it has come off 3. Reassemble the glass attachment, place new rubber gaskets When replacing the gaskets, fit each glass attachment bolt in its place Replace the old flanges
2	Air leakage through the rubber flanges (H600-68) sealing the hoses which feed the tail cannon mount	Damage to the rubber sealing flanges	Replace the old packing rubber. Glue new rubber with cement No. 88
3	Air leakage through the rubber packing of the hatches and sliding panels located on frame No. 12 and in fuselage compartment 6-6	Cracks and wear of the packing rubber	Replace the old packing rubber. Glue new rubber with cement No. 88
4	Air leakage through the joints of fuselage compartments 6-1 and 6-2	Loosening of clamp bolts	Tighten up the bolts by means of a torque indicating wrench
5	Air leakage through the fairleads of the	Wear of the rubber inserts of the fairleads	Tighten up the covers of the fairleads. If after the

- 165 -

50X1-HUM

1	2	3	4
			tightening of the cover air leakage perils, replace the inserts
6	Air leakage through the pressure seal of the attachment fork of the entrance hatch in fuselage compartment 6-6	Wear of the sealing rubber washer	Remove the entrance hatch door, dismantle its skin to obtain access to the fork nut and place a new washer under the fork
7	Air leakage through the pressurization valve of the entrance hatch in fuselage compartment 6-6	Deterioration of the sealing rubber cap (H7610-56)	Remove the valve from the aircraft. Drill out the rivets and remove the cap; fit a new cap riveting it with AM PM rivets and then fit the valve in position. If a spare rubber cap is not available, replace the defective valve
8	Air leakage through the entrance hatch doors and emergency escape hatch doors	No pressure in the sealing hoses	Build up pressure in the hoses to detect leaky places
9	Air leakage through the riveted seams of the cockpit skin	Loosening of the riveted seams	Tighten up the rivets of the seams
10	Air leakage through the AP-54 automatic pressure regulator	The AP-54 regulator attachment yoke is overtightened	Loosen the yoke so that the bolt torque does not exceed 10 kg-cm, as indicated by the torque indicating wrench
<b>7. TESTING FRONT AND REAR PRESSURIZED COCKPITS FOR LEAKAGE</b>			
CAUTION: When testing the cockpits for leakage observe the following precautionary measures:			
1. The testing panel must have a protective barrier.			
2. Blisters and pilots' and navigator's canopy glass should be provided with protective gauzes.			
3. Hatch covers, canopy sliding panels and covers may be opened only after surplus pressure has been released from the cockpit.			
Prior to testing the cockpit proceed as follows:			
1. Disconnect the static-pressure pipe line from the JER-3 (or JER-15) altitude and pressure differential gauges located on the right pilot's instrument board and on the gunner-radio operator's panel. Plug the instrument connections and disconnected ends of the pipes.			
2. Remove the following instruments and units:			
- all the oxygen breathing apparatus, type MI-24;			
- all the pressure gauges, type M-1000;			
- CHY-10 interphone communication amplifiers in the front cockpit;			
- inverters of the PCB-70 station and the J-600 amplifier in the front and rear cockpits;			

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- altitude and speed units from the KCH-48 (or KCH-63) instrument set in the front and rear cockpits;
  - panels A-2 (mounted on some of the aircraft) in the front and rear pressurized cockpits.
- Then plug the holes connecting the above-mentioned instruments and units with the atmosphere.
3. Set the three-way cock of the APH-54 automatic pressure regulator to the CLOGKD position.
  4. Set the knobs of the control valves, included in the KCH valve sets (N7601-240), on the right pilot's and radio operator's panels for pressure drop of 0.4 kg/sq.cm.
  5. Pull up the cockpit emergency pressure release valve button located on the left pilot's panel and near the gunner-radio operator's seat as far as it will go.
  6. Plug the container heater pipe line of fire-fighting cylinders H6600-209/21 on the bottom of frame No. 12 on the aircraft where this pipe line is connected to the bottom of this frame.
  7. Retain the shutters of the KCH pressure combination valves located on the bottom of frames Nos 12 and 69 in the open position with special supports.
  8. Close the HATCH PRESSURIZATION cock mounted on the right pilot's pressurization panel.
  9. Close the air delivery regulator.
  10. Close the air intake delivering atmospheric air to the front cockpit at low altitudes and the rear cockpit ventilation cock.
  11. Remove the plugs from the pipe unions delivering air for the leakage test and from the pipe unions used to measure pressure in the cockpits (the pipe unions are located on the bottoms of frames Nos 12 and 69) and then connect them to the hoses from the test stand with the low-pressure compressor and pressure gauges (Fig. 125).
- The test stand hoses are connected to the cockpits as follows:
- (a) to the front cockpit pipe unions - through the hatch in the floor of fuselage compartment #3, through the hatch at the landing gear nose leg or through the inspection hatch located on the fuselage starboard side between frames Nos 12 and 13;
  - (b) to the rear cockpit pipe unions - through the hatch of technical compartment #5.
12. Connect the hatch pressurization system to the compressed air bottle at a pressure of 4 kg/sq. cm. The hose from the ground compressed air bottle used for hatch pressurization is connected through the reducer for 4 kg/sq. cm. to the following pipe unions:
    - (a) in the front cockpit to the through pipe union mounted on frame No. 12 (from which pipe No. 58-1 must be previously disconnected) or to the through pipe union located at frame No. 62a (having previously disconnected pipe No. 58-11 from it);
    - (b) in the rear cockpit to the through pipe union located at frame No. 62a having previously disconnected pipe No. 58-10 from it.
  13. Close and fix in position the pilots' canopy sliding panels, the cover of the hatch on frame No. 12 and the covers of the entrance and the emergency escape hatches in compartments #2 and #5.

50X1-HUM

14. Pressurize the entrance and emergency escape hatches and the pilots' canopy covers delivering compressed air to the sealing hoses from the ground air bottle. Deliver air through reducer 12 until a pressure of 4\* 0.3 kg/sq. cm. is built up in the system checking pressure downstream of the reducer and in the pipe lines by pressure gauges 13 and 15 (See Fig. 125).
- If during the test a person is present in the front cockpit and the aircraft air system is under pressure, pressure in the sealing hoses can be built up by opening the cock on the pressurization panel, with the entrance hatch doors in both cockpits closed.
- The procedure of testing the cockpits for leakage is as follows:
1. Start the low-pressure compressor (KCH-1 or any other type).
  2. Open air supply cocks 1 and 7 on the test stand; pressure release cock 6 should be closed. Slowly, at a rate not exceeding 5 m/sec. as indicated by the climb-and-descent indicator of the stand, bring air pressure in the cockpit to 0.1 kg/sq. cm. checking it against pressure gauge 9 and 10 of the stand.
  3. Carry out a thorough examination of the cockpit which is under a pressure of 0.1 kg/sq. cm. Mark the places where leakage of air from the cockpit is detected so as to eliminate the defects after pressure is released from the cockpit.
- If on supplying air to the cockpit the pressurization, release pressure from the cockpit do not indicate pressure, stop pressurization, release pressure from the cockpit and resume the test after the fault is remedied.
- Places of air leakage are detected both from the outside and from the inside of the cockpit with surplus pressure in the cockpit not exceeding 0.1 kg/sq. cm. It is recommended to detect leaky places by listening using a rubber pipe, one end of the pipe should be put to the inspector's ear, while its other end - to the glass, sealings, bolted connections and riveted seams.
- When during the test the men are in the cockpit they must check the readings of the instruments measuring the static and total pressure. The deflection of these instruments pointers at surplus pressure in the cockpit testifies to the leakage of the instruments or pipes.
- Only one cockpit can be tested for leakage from one stand at a time. In winter prior to leakage test the cockpit should be warmed up with warm air from the ground heaters to a temperature of +15 to 25°C. In summer it is not permitted to test the cockpit for leakage when it is sunlit and when the free air temperature exceeds +25°C.
4. By slowly increasing air supply to the cockpit bring its pressure to 0.4 kg/sq. cm. This done, close stand cock 7 (See Fig. 125) and measure the time of pressure drop in the cockpit from 0.4 to 0.1 kg/sq. cm.
- Cockpit gastightness is considered to be satisfactory if this time is not less than 12 minutes for the front cockpit and 6 minutes for the rear cockpit.
- If the time of pressure drop in the cockpit is less than the above values, release air from the cockpit, increase cockpit pressurization in places where air leakage is detected and then retest it for leakage.
8. LEAKAGE TEST AND CALIBRATION OF KCH VALVE TOGETHER WITH ITS CONTROL VALVE
- After the faults have been eliminated, test the KCH valve together with its control valve for leakage, determine the force required to open the valve and then calibrate it on the stand together with its control valve.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 168 -

The gastightness of the valve set is checked under surplus pressure of 140 mm of mercury (about 0.2 kg/sq.cm.) of air delivered to the HCU valve and to the control valve. Both valves of the set are considered to be gastight if in the course of 5 minutes pressure drop in them does not exceed 10 mm of mercury. The force required to open the HCU valve is determined at surplus air pressure of 37 to 85 mm of mercury (depending on the free air temperature) acting upon its diaphragm.

The test stand (Fig. 126) on which the HCU valve and its control valve are calibrated is provided with:

- sealed reservoir with a capacity of 5 cu. m.;
- air flow meter (Venturi tube B7607-62 and FBI-46y flow meter indicator);
- two reference pressure gauges (mercury and mechanical);
- low-pressure compressor, type HCU-1 (or of another type), with an output of up to 500 cu. m/hr;
- connecting pipe lines.

- Calibration of the valve set includes:
- manual adjustment of pressure in the reservoir by means of the valves;
- maintenance of constant (maximum) pressure drop in the reservoir;
- checking emergency pressure drop in the reservoir.

To calibrate the valves:

1. Mount both valves on the test stand and connect them by pipe lines.
  2. Close the sealed reservoir and connect the hose from the compressor to it.
  3. By rotating the control valve knob clockwise set it in the zero position.
  4. Deliver compressed air from the compressor to the stand reservoir at air consumption of 250 to 500 cu. m/hr and build up in it a pressure of not more than 0.4 kg/sq.cm. as indicated by the pressure gauges (mercury or mechanical).
  5. By rotating the control valve knob counter-clockwise adjust pressure drop in the reservoir to 0.2, 0.3, 0.4, and 0.45 \* 0.03 kg/sq.cm.
  6. Check the stability of valve operation for 2 or 5 minutes throughout the entire delivery range and at all pressure drops (See Item 5).
- The valve operation is considered to be satisfactory if pressure variations in the reservoir do not exceed 2 mm of mercury during 2 seconds at least.
- The HCU valve is adjusted by turning the adjusting screw in or out.
7. At pressure drops of 0.2, 0.3, and 0.45 kg/sq.cm. check pressure drop in the reservoir with air delivery shut off. This being the case, pressure in the reservoir drops sharply, but this drop should not exceed 60 mm of mercury.
  8. Check the operation of the HCU valve acting as a safety valve. For this set the knob of its control valve to the maximum pressure drop position and make sure that pressure in the stand reservoir does not exceed 0.45 \* 0.03 kg/sq. cm. at any air consumption within 250 - 500 cu. m/hr.
  9. Check the operation of the control valve at emergency pressure release in the following manner:
    - (a) adjust pressure in the reservoir to 0.4 kg/sq.cm. (294 mm of mercury);
    - (b) stop compressed air delivery to the reservoir;
    - (c) pull up the control valve red button as far as it will go;
    - (d) measure the time of pressure drop in the reservoir from 0.4 kg/sq. cm. to zero. With the valve operating properly, this time should not exceed 6 to 9 seconds and the residual pressure in the reservoir should not exceed 20 mm of mercury. In case the time of pressure drop exceeds 6 to 9 seconds, it is necessary to slightly loosen the adjusting screw of the HCU valve; when doing so adhere to the instructions given in Item 6 concerning the stability of valve operation.
- After the stability of valve operation has been obtained in compliance with the

- 169 -

50X1-HUM

Specifications, lock the adjusting screw with wire, type KOK-0,8, and screw the emergency pressure release head as far as it will go and lock it with a pin. Drill a new hole for the pin, if necessary.

After locking it is advisable to retest the valves as prescribed in Items 1 to 9.

After the cockpits have been tested for leakage:

1. Release the remaining pressure from the cockpit through cock 6.
2. Disconnect the stand hoses from the cockpit bottom and plug the pipe unions in the bottom; lock and seal the plugs.
3. Release pressure from the sealing chambers of the entrance hatches (prior to opening the entrance hatch doors):
  - (a) in the front cockpit - through the pressure release pipe union on the bottom of frame No. 12.

Pressure released, fit the pipe union plug in position, lock and seal it; (b) in the rear cockpit - through the pipe union in the starboard recess of the ammunition belt feed mechanism.

For this remove the cover of the ammunition belt feed mechanism recess, disconnect from the through pipe union pipe line 47-5 running to the side pipe union of the two-way air valve located in the recess.

After pressure has been released, connect pipe line 47-5 to the through pipe union, lock and seal the connection.

**NOTE:** On aircraft of earlier make which are not provided with pipe unions for pressure release from the sealing chamber of entrance hatch

- \*-2 open the hatch carefully with the aid of two or three men.
- \*. Mount the removed instruments in position and connect the lines. Remove stop plugs and supports.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

Tab 50X1-HUM

Chapter VIII  
PACKING AND SHIPMENT OF SEPARATE AIRCRAFT UNITS

1. GENERAL

During service separate aircraft units are to be transported to repair shops or units. The condition of the units to be transported depends on the quality of dismantling and corrosion-preventive treatment of the unit, the quality of packing, as well as on the organization of loading operations in points of delivery and destination.

When the dimensions of the first and the second detachable parts of the wing taken separately do not fit into the overall dimensions and the shape of cargo for the rolling stock (Fig. 127). Therefore, when shipped by railway the first detachable part of the wing is packed without the a/case, landing gear fairing, engine nacelle, air intake, and flap, while the second detachable part of the wing is packed without the a/case, aileron, and flap. Figs 127 through 134 show overall dimensions and the shape of packing of aircraft main units for their transportation by railway. Aircraft units to be transported should be processed so as to ensure their proper condition during shipment and short-term storage. Packing for aircraft units protects them against the elements and mechanical damage. The way the units are packed is of great importance especially when the units are to be turned over during packing.

When carrying out loading operations, take into consideration the fact that the stress-carrying elements of packing are the lower longitudinal bars and those of containers are the floor and the lifting eyes.

When shipping aircraft units by railway, by truck or by special sledge driven by a tractor, take particular care to see that they are securely attached to the flat car, car or sledge to prevent the load from being displaced or turned over.

Table 16 gives a list of aircraft units which can be shipped, types of packing, approximate weights and overall dimensions of packed units. Using this table as a guide, choose cranes for loading operations.

To transport all the units of the aircraft structure by railway, it is necessary to have ten two-axle and three four-axle flat cars.

To transport separate aircraft units, choose the amount of rolling stock and the use of the overall dimensions given in Table 16.

List  
of Aircraft Units which Can Be Shipped.  
Packing, Overall Dimensions and Approximate Weights  
of Packed Units

No.	Aircraft unit	Number of units on aircraft	Number of units in packing	Type of packing	Overall dimensions of packing, mm	Weight of one unit, kg	Gross weight of unit in packing, kg
1	2	3	4	5	6	7	8
1	Front pressurized cockpit	1	1	Carcass	2500x2750x6100	3150	4000
2	Fuselage nose section	1	1	Carcass	2700x3000x6300	670	1500
3	Fuselage tail section	1	1	Carcass	2750x3150x20100	4350	7500
4	Rear pressurized cockpit	1	1	Carcass	2250x2100x4000	1730	2300
5	First detachable wing part without nose, landing gear main leg fairing, flap and engine nacelle	2	1	Carcass	1600x2900x8000	2400	5300
6	First detachable nose of first detachable wing part	2	2	Box	1000x600x1400	6	80
7	Second detachable nose of first detachable wing part	2	2	Box	1000x1100x5550	87	625
8	Landing gear main leg fairing	2	1	Carcass	1500x1600x6000	200	450
9	Flap of wing first detachable part	2	2	Container with detachable panels	1130x1930x3520	50	250
10	Second detachable wing part without flap and aileron nose	2	2	Carcass	2100x3650x13900	1650	5000
11	First detachable nose of second detachable wing part	2	2	Box	710x860x6730	80	600
12	Second detachable nose of second detachable wing part	2	2	Box	540x730x5530	50	350
13	Aileron	2	2	Carcass	830x1770x6550	100	600
14	Flap of second detachable wing part	2	2	Container with detachable panels	1150x2130x7500	96	350

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



1	2	3	4	5	6	7	8
15	Stabilizer	2	2	Carcass	1650x2700x3500	400	200
16	Fin	1	1	Carcass	800x3200x7000	350	100
17	Rudder	1	1	Carcass	600x1800x5700	106	375
18	Elevator	2	2	Carcass	800x1320x7100	70	575
19	Engine nacelle	2	2	Carcass	1880x2000x5500	275	450
20	Air intake front part	2	2	Carcass	1800x1800x2800	90	50
21	Landing gear main leg strut	2	2	Carcass	1000x1340x2700	500	150
22	Landing gear main leg bogey with wheels	2	1	Carcass	1200x1200x2400	1100	150
23	Landing gear nose leg with wheels	1	1	Carcass	1000x1050x2680	400	800
24	Dust and lower part of engine nacelle	2	2	Carcass	1900x2400x5540	140.75	875
25	Rear adapter of engine nacelle	2	2	Carcass	1250x1280x830	25	225

2. PREPARATION OF UNITS FOR PACKING

Each aircraft unit to be packed must be completed with all parts and processed.

The availability of all parts belonging to the unit is checked against the Reference List or the Packing List. In doing so check whether the unit is free from mechanical damage, corrosion and damage to varnish coatings. Then the unit should be processed. A correctly processed unit can be stored during one year under proper conditions.

Prior to packing, clean the skin of large units and the surfaces coated with varnish and paint from dust and dirt with dry pieces of cloth or with hair brushes; large units are not subjected to special processing.

The outer surfaces of the unit parts of aluminum alloys, copper, brass, bronze, oxidized ferrous metals and metals with cadmium, zinc, nickel or chrome coatings should be processed.

The surfaces to be processed must be previously cleaned thoroughly from dust and dirt. To clean metal surfaces, use gasoline, grade B-70, without antiknock component. Clean such surfaces by wiping them with pieces of cloth or hair brushes soaked in gasoline. This done, dry the cleaned surface at ambient air temperature for 10 or 20 minutes or blow it with dry compressed air. Oxidized parts of parts of ferrous metals should be processed with gun grease. The surfaces of parts of aluminum alloys, copper, brass, bronze and the surfaces having cadmium, zinc, nickel or chrome coating should be processed with dehydrated petrolatum. Gun grease and petrolatum are applied to the surface with a hair brush or a sprayer. If necessary (at low air temperature), it is permitted to dilute dehydrated petrolatum and gun grease with spindle oil No.2 or No.3 in the following volumetric formula: dehydrated petrolatum - 70 per cent, oil or gasoline, grade B-70, without antiknock component - 30 per cent. The mixture should be of required viscosity or warmed up to a temperature of 110 or 120°C.

The viscosity of gun grease diluted with gasoline or of dehydrated petrolatum as indicated by the viscosimeter, type 93-36 (nozzle No.2), must be as follows: for the brush - 15 or 20 seconds, for the sprayer - 8 or 12 seconds. After processing the metal assemblies of the units should be wrapped in paraffined paper.

50X1-HUM

All the holes in parts and assemblies communicating the inner recesses with the atmosphere should be closed with plugs, rubber caps or tied up with several layers of cloth. The oxygen system pipe lines must be plugged; their processing with lubricants is strictly prohibited. The surfaces of organic glass are protected from mechanical damage either by covering them with a layer of gelatine consisting of 100 gravimetric parts of gelatine, 40 gravimetric parts of glycerine and 250 or 300 gravimetric parts of water, or by cementing paper to the glass.

All the materials used for processing must comply with State Standard ГОСТ. Besides this, lubricants and chemical agents must be accompanied by the Laboratory Certificate concerning their condition and stating whether they comply with the Specifications. The date of preparation of lubricants and chemical agents should be also put down in the Certificate, so that they should be used not later than in one day after they are prepared.

Lubricants which have been used once can be used again for processing purposes after being filtered, a processed unit completed with all the parts and packed with the documents is packed in a special carcass packing, a container or a box.

3. PACKING MEANS

To pack separate aircraft units the following packing means are employed:

- carcass packing (the unit to be packed is protected with a cover);
- containers;
- boxes.

A carcass packing has a horizontal frame of longitudinal bars connected to each other by cross-beams. Fixed to the frame are supports covered with felt. The support ends are provided with uprights supported by braces. Secured to the upright are retaining supports and eye bolts for the bracing wire ropes by means of which the packed unit is fastened to the truck body, flat car or sledge. On the top the packed unit is covered with tarpaulin which is fastened to the horizontal frame by means of planks and nails. The overall dimensions of the unit packed in the carcass packing are almost not increased, the unit is securely fastened and may be stored in this condition for a short time.

The container is a sectional structure consisting of separate shields connected by bolts. The container floor is a wooden frame covered with boards and water-proof paper. The container walls consist of bars and are covered with water sheets from the inside and with moisture-proof paper. The container top is a wooden frame covered with boards and protected with rubberoid or tar paper from the outside. The top is slightly inclined for draining water. Fastened to the container floor is one or several supports covered with felt. The unit to be packed is first securely fastened to the floor supports after which the container side and end face walls are mounted. If necessary, additional retaining supports or bars are mounted, and then after checking the unit for secure attachment the container top is mounted and fixed with bolts. An assembled container has special lifting eyes and transverse members to be lifted by means of a crane. The container somewhat increases the overall dimensions of the unit to be packed, therefore, it is not used for packing large-size units. The container has the following advantages: simplicity of packing, reliability of attachment, convenience of shipment and longer storage period as compared with the carcass packing.

Boxes are designed for packing units of comparatively small overall dimensions and weight (e.g. the noses of the first and second detachable wing parts) and are manufactured of six lattice board shields covered from the inside with

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

- 175 -

3-mm veneer. Table 17 gives the sections of boards used for boxes and the space between them depending on the box length.

Table 17

Sections of Boards and Gaps between Them

Box length, mm	Board section, mm	Space between boards, mm
Up to 1500	20x50 (x70)	50 - 70
1500 - 2500	20x80 (x100)	80 - 90
Over 2500	20x100 (x120)	80 - 100

Five shields of the box without the cover are connected to one another by means of nails and are covered from the inside with water-proof paper fixed in position by means of veneer planks; 4x25. After the unit has been packed in the box and secured there, the cover is also protected with water-proof paper from the inside should be fastened with nails.

#### 4. MANUFACTURE OF PACKING

To manufacture the packing, use wood meeting the requirements of second-grade saw-timber and birch veneer. Saw-timber used for packing should be stored at depots, should be free from mould and through cracks. The humidity of boards and bars should not exceed 20 or 30 per cent. The wood must be sawn correctly, wood finishing defects should not affect more than 200 mm per one meter of length.

To cover the supports, use commercial felt with humidity not exceeding 5 per cent of weight without the smell of rot.

Use roofing felt or tar paper for insulating purposes.

Roofing felt used for covering the containers from the outside should meet the Specifications.

Used as packing materials are: wadding, felt or alignin.

The packing materials must be dry and clean.

Steel, grades 2 and 3, is used for welded parts and lifting eyes of the container; steel, grade 10, is used for strips and other metal binding.

#### Requirements for Packing

1. Packing must be manufactured in strict compliance with the drawings and Specifications.

2. Manufactured parts of packing must be stored under the shed.

3. The main bars are bound with a straight joint lock.

The joints of the floor, wall and top boards must be positioned so that in one cross-section they are arranged not less than in every two boards; the joints must be located on cross-beams. The boards used for manufacture of containers of boxes should be shaped from the outside.

4. The supports must be thoroughly covered with commercial felt and sack cloth. Prior to covering the supports with sack cloth, the commercial felt should be fixed with nails.

5. Veneer sheets on the walls are secured with nails to the frames along all the bars and braces; the nail pitch over the sheet edges does not exceed 150 mm.

either seams the nail pitch should not exceed 250 mm. The sheet is 50x1-HUM  
over an over a lap of 50 to 60 mm.

6. The seams of roofing felt on the top must run along its slope with an overlap of 100 mm. The edges of the outer covering are fastened in position by means of planks on the inside so as not to prevent water from running down. Use of roofing felt for the inner covering of the top is not permitted. Moisture-proof paper is secured with veneer planks by means of nails. The joints of moisture-proof paper must have an overlap of 150 to 200 mm and be secured with an additional veneer plank.

7. Holes in the wood for bolts must exceed the bolt diameter by 1 or 2 mm. The recess for the head of the countersunk bolt must correspond to the head diameter.

8. Coach bolts and screw nails must be screwed only by means of a wrench and a screw driver.

9. All metal parts must have anti-corrosive coatings.

10. To protect tubercoid from damage, fit protective strips in places where the lifting eyes of the container are located.

11. All the projecting nails must be bent.

12. Marking on the boxes must be clear. The size of the letters and figures should be 50 to 100 mm. The outside surfaces of the container and box end face should bear the following inscriptions: gross weight, No. of the container and TOP, DO NOT TURN OVER. Besides this, secured to one of the container end face walls is a frame for the Packing List which is sealed after packing. The box should be sealed at four sides. In places where seals are fitted, recesses 10 mm deep are drilled. The seals are fixed in position by means of a steel strip with nails. On the outside surface of the box or container a tally is stamped or secured. The tally indicates the date, the guaranteed period of storage of processed parts and assemblies and the date of reprocessing. A copy of the tally is packed together with the Packing List.

#### 5. PACKING UNITS

##### General

The prepared packing should be placed on a ground specially prepared for this purpose. To pack units of considerable weight, use hoisting devices of corresponding load-lifting capacity. The flaps of the first and the second detachable wing parts, airerons, elevator, rudder, landing gear fairings, engine nacelles, air inlets, noses of the first and second detachable wing parts should be lifted manually. The packing of these units is shown in Figs 136 through 149.

##### Packing Front Pressurized Cockpit

To place the front pressurized cockpit into the carcass packing, it is necessary to have a special hoisting device and a crane with a load-lifting capacity of not less than 3 tons.

The hoisting device is a rod (tube) to the ends of which cables are attached. The cables are covered with soft straps and provided with locks to secure the units along frames Nos 5 and 11. The position of the front pressurized cockpit in the carcass packing and means of its attachment are shown in Fig. 150.

##### Packing Fuselage Nose Section

The fuselage nose section is placed into packing by means of a special hoisting device and a crane with a load-lifting capacity of not less than one ton. The hoisting device for the nose section is similar to that for the front pressurized cockpit.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 176 -

The fuselage nose section is secured with bands over frames Nos 13 and 25. The position of the nose section in the crass packing and the means of its attachment are shown in Fig. 151.

#### Packing Fuselage Tail Section

The fuselage tail section is placed into packing by means of a special hoisting device and a crane with a load-lifting capacity of not less than 5 tons. The hoisting device is a cigar-shaped tubular truss, 10270 mm long, to the ends of which the bell cranks are fastened at the top and at the bottom. Attached to each upper bell crank are two pairs of cables connected to the hoisting ring through the bell cranks. The bell cranks distribute the load so that both cables are equally loaded. Connected to the lower bell cranks are cables covered with felt and provided with locks. The cables serve to secure the unit along frames Nos 33 and 56. The position of the fuselage tail section in the packing and the means of its attachment are shown in Fig. 152.

#### Packing Rear Pressurized Cockpit

The rear pressurized cockpit is placed into packing by means of a special hoisting device and a crane with a load-lifting capacity of not less than 2 tons. The hoisting device is a rod (tube) to the ends of which are secured (at the top) cables running to the hoisting ring. Connected to the hoisting device ends from below are a cable with a snap hook on one side, and a cross tube joined to the cables covered with soft straps and provided with locks on the other side.

The unit is secured with straps along frame No. 75. From the other side of the rod the snap hook is fastened to a special rigging unit secured by five bolts in the upper part of split frame No. 69. The position of the rear pressurized cockpit in the packing and the means of its attachment are shown in Fig. 153.

#### Packing First Detachable Wing Part

Prior to packing the first detachable part of the wing without the flap, the engine nacelle, the landing gear fairing, air intake and noses after being detached from the aircraft should be put from the horizontal to the vertical position with the front spar downward. This operation and placing the first detachable wing part into the packing are performed by means of a special hoisting device and a crane with a load-lifting capacity of not less than 3 tons. To put the first detachable wing part from the horizontal to the vertical position, place two bars with a section of 200x250 mm and 6 m. long on the floor and place on them the unit in the horizontal position by means of the transverse member included in the aircraft ground equipment net. Then, bolt the beams with lifting eyes to the fittings of the first detachable part of the wing in its split joint at the second spar. The lifting eyes of the beams are gripped by the suspensions of the hoisting device which is a truss provided with braces and a hoisting ring. By means of the crane the unit is put into the vertical position and placed into the packing. The position of the unit in the packing and its attachment are shown in Fig. 154.

#### Packing Second Detachable Wing Part

After being detached from the aircraft but prior to being placed into the packing the second detachable part of the wing without the aileron, flap, nose

- 177 -

50X1-HUM

The fuel system pipe line should be turned with the front spar downward. The operation of turning the unit (the second detachable part of the wing) and placing it into the packing is carried out by means of a special hoisting device and a crane with a load-lifting capacity of not less than 3 tons. The hoisting device for turning and placing the unit into the packing presents two tubular trusses, each provided with two special units which grip the second detachable part of the wing by its rigging units located on ribs Nos 10 and 15. Securable part of the trusses are two cables running along the rollers secured to the end of the rod is connected to the lifting eye by means of cables. When turning the unit, the rollers on the rod get self-aligned to fit the unit centre of gravity both in the horizontal and vertical positions. The position of the unit in the packing and its attachment are shown in Fig. 155.

#### Packing Stabilizer

Place the stabilizer in the packing on the rib with the nose looking down. The unit can be put from the horizontal to the vertical position by means of a special hoisting device and a crane with a load-carrying capacity of not less than 0.5 ton or manually if the hoisting device is not available.

The hoisting device is a tubular truss provided with three special units which grip the stabilizer by its rigging units. Secured to the tubular truss are two cables. Rollers are attached to the rod of the hoisting device connected to the hoisting ring by means of cables. When turning the unit from the horizontal to the vertical position, the rollers moving over the cables get aligned to fit its centre of gravity with the unit both in the horizontal and vertical positions. The position of the unit in the packing and its attachment are shown in Fig. 156.

#### Packing Fin

Place the fin in the packing with the nose looking down. Put the fin from the vertical position on the nose and place it into the packing by means of a special hoisting device and a crane with a load-lifting capacity of not less than 0.5 ton or manually in case the hoisting device is not available. The hoisting device for the fin is a rod provided with a clamp to be secured to the crane hook and with two rollers fixed in position on the rod cantilever. Running along the fin are two cables terminating in two pairs of bushes. The bushes are fitted over the dovels of the fin rigging units and are prevented from being displaced in the longitudinal plane by means of locking pins. The fin suspended in this manner can be easily turned with the nose down and placed in the packing. The position of the fin in the packing and its attachment are shown in Fig. 157.

#### Packing Landing Gear Nose Leg with Wheels

Place the landing gear nose leg with the wheels by means of a hoisting device and a crane with a load-lifting capacity of not less than 0.5 ton. The hoisting device presents a hoisting ring to which two cables are secured. The cables pass through the rubberized hoses and terminate in snap hooks. In case the hoisting device is not available, the landing gear nose leg can be placed on the crass lower frame manually and fixed in position as shown in Fig. 158.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

— 178 —

Packing Buggy and Landing GearMain Leg

The main leg bogey is rolled manually on the carcass frame, placed in position in the support and fixed as shown in Fig. 159.

Packing Landing Gear Main Leg Shock Absorber

Pack the landing gear main leg shock absorber by means of a hoisting device and a crane with a load-lifting capacity of not less than 0.5 ton. The hoisting device for lifting the shock absorber is similar to that for lifting the landing gear nose leg. The position of the shock absorber in the packing and its attachment are shown in Fig. 160.

6. LOADING PACKED UNITS

Packed units are placed on trucks, sledges or flat cars with the aid of a hoisting device or a tractor by means of poles and cables.

Fig. 161 shows a container with a hoisting device which has four cables 1 terminating in snap hooks 4 fixed to hoisting ring 3. The container is gripped by lifting eyes 2 and by means of a crane is loaded on any means of transport. Fig. 162 shows a schematic diagram of loading the container on the sledge prevented from being moved and turned over at the moment of loading by two stands 2 and block 1. Loading is carried out as follows: place two poles 3 on the edge of the sledge and place blocks 4 on the sledge frame parallel to the poles; secure the container with cable 5 passed through lifting eyes 6 and attach it to the tractor. The container is loaded on a flat car in the same manner as it is loaded on the sledge. The difference is that the flat car need not be protected from being displaced or turned over. Loading the units in carcass packing is shown in Fig. 163.

To load units in carcass or shield packing by means of a crane, it is necessary to have special hoisting devices which differ from each other in size and location of their parts depending on the weight and overall dimensions of packed units. Fig. 164 shows the schematic diagram of loading the unit in carcass packing by means of a hoisting device having rectangular frame 1 at the corners of which plates 2 are welded. Cables 3 are a load-carrying link between plates 2 and clamp 4. Cable 5 secures the unit in position. The unit in carcass packing placed on a flat car (Fig. 165) is aligned to fit the centre of the flat car and fixed to it in the following manner: to prevent the unit from moving, blocks 1 measuring 100x100x500 mm are secured to the flat car floor from both sides of each corner of the lower frame with nails, 6x200 mm; to prevent the unit from turning over during the movement of the flat car, bracing wire ropes 2 of annealed wire, 3 mm in diameter, made up of six separate wires twisted together. The fuselage tail section exceeds the length of a four-axle flat car, therefore, the neighbouring flat cars must have spaces free from cargoes corresponding to the length of the projecting part of the tail section with the allowance for the train turns. When transported by truck (Fig. 166) or sledge (Fig. 167), packed units are secured in position approximately in the same way as when transported by flat car.

— 179 —

50X1-HUM

7. UNLOADING PACKED UNITS

Packed units can be unloaded from various means of transport by means of special hoisting devices and a crane (See Fig. 164). In case these means are not available, use cables and tractors or winches. When the packed unit slides along the poles, the packing must be kept from overturning by means of securing wire ropes (See Figs 162 and 163).

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

— 181 —




FIG. 1. 50X1-HUM AIRCRAFT WITH NOSE FORWARD  
1 - engine; 2 - fuel; 3 - heat; 4 - shock absorber; 5 - heater; 6 - wiper; 7 - wheel; 8 - wheel; 9 - wheel; 10 - main cabin; 11 - cockpit  
12 - battery; 13 - resistor; 14 - resistor; 15 - resistor; 16 - split spring; 17 - rod guide.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

182




FIG. 2. CABLE CONTROL SYSTEM FOR TOWING AIRCRAFT WITH TAIL FORWARD AND TOWING CABLE  
 1 - cable; 2 - roller; 3 - roller; 4 - roller; 5 - roller; 6 - roller; 7 - roller; 8 - roller; 9 - roller; 10 - roller; 11 - roller; 12 - roller; 13 - roller.

183

50X1-HUM




FIG. 3. DIAGRAM SHOWING ARRANGEMENT OF COVERS ON AIRCRAFT

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

— 184 —




FIG. 4. DISCHARGERS AND AIRCRAFT GROUNDING DEVICES  
1 - grounding cable with weight; 2 - antenna; 3 - discharge unit base.

— 185 —

50X1-HUM





FIG. 5. GROUNDING OF FUEL DISPENSING GUN DURING AIRCRAFT REFUELLING  
1 - fuel dispensing gun; 2 - base; 3 - grounding cable; 4 - grounding terminal; 5 - fuel level indicator.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

186



187

50X1-HUM




FIG. 6. AIRCRAFT SECURED ON PARKING AIRFIELD. 1 - main wheel; 2 - main wheel; 3 - main wheel; 4 - main wheel; 5 - main wheel; 6 - main wheel; 7 - main wheel; 8 - main wheel; 9 - main wheel; 10 - main wheel; 11 - main wheel; 12 - main wheel; 13 - main wheel; 14 - main wheel; 15 - main wheel; 16 - main wheel; 17 - main wheel; 18 - main wheel; 19 - main wheel; 20 - main wheel; 21 - main wheel; 22 - main wheel; 23 - main wheel; 24 - main wheel.

FIG. 7. AIRCRAFT HYDRAULIC HOISTS. 1 - hoist; 2 - hoist; 3 - hoist; 4 - hoist; 5 - hoist; 6 - hoist; 7 - hoist; 8 - hoist; 9 - hoist; 10 - hoist; 11 - hoist; 12 - hoist; 13 - hoist; 14 - hoist; 15 - hoist; 16 - hoist; 17 - hoist; 18 - hoist; 19 - hoist; 20 - hoist; 21 - hoist; 22 - hoist; 23 - hoist; 24 - hoist.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

— 188 —




FIG. 8. ATTACHMENT OF SCREW CLAMPS TO LANDING GEAR STRUTS.  
1 - base strut screw clamp 2 - pin for screw clamp.

— 189 —




FIG. 9. AIRCRAFT LEVELLING DIAGRAM

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM




FIG. 10. CART-MOUNTED CYLINDER BANK FOR COMPRESSED AIR DELIVERY TO AIRCRAFT AIR SYSTEM, LANDING GEAR WHEEL TUBES, STABILIZING SHOCK ABSORBER AND LANDING GEAR SHOCK ABSORBER




FIG. 11. WHEEL TUBE CHARGER  
1 - red knob; 2 - belt for bleeding air pressure.

50X1-HUM




FIG. 12. HYDRAULIC JACK FOR REPLACEMENT OF LANDING GEAR WHEELS  
1 - rocker; 2 - handle; 3 - section valves; 4 - reservoir and power section; 5 - delivery valves; 6 - safety valve; 7 - springs; 8 - knob; 9 - ball; 10 - bypass valve.




FIG. 13. FITTING HYDRAULIC JACKS UNDER MAIN STRUT BOGEY WHEN REPLACING WHEELS

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

— 192 —




FIG. 14. ENGINE SERVICING LADDER




FIG. 15. STABILIZER SERVICING LADDER  
1 - ladder; 2 - foot platform; 3 - front upright; 4 - hinged ladder; 5 - strut; 6 - cable; 7 - support hooks; 8 - self-locking wheels; 9 - screws; 10 - winch.




FIG. 16. ARRANGEMENT OF LIFTING EYES AND SLINGS ON INDIVIDUAL UNITS OF AIRCRAFT

— 193 —

50X1-HUM




FIG. 17. FLEXIBLE HOSE FOR CHARGING AIRCRAFT AIR SYSTEM




FIG. 18. NOSE STRUT THIRD DAMPER REPLENISHMENT UNIT




FIG. 19. DIAGRAM OF INSTALLATION FOR FLUSHING BRAKE SYSTEM OF LANDING GEAR WHEELS  
1 - adaptor for wheel pipe unions; 2 - hoses; 3 - pressure gauge 10" x 1/2"; 4 - reservoir; 5 - cut-off cock; 6 - hand pump HP-01; 7 - non-return valve; 8 - line filter AUP-263N.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 20. DIAGRAM OF HYDRAULIC TEST UNIT  
 1 - reduction gear; 2 - variable capacity pump; 3 - pressure gauge for 250 lb/sq. cm.; 4 - line filter; 5 - check; 6 - non-return valves.




FIG. 21. TELESCOPIC LADDER FOR INSPECTION OF RUDDER





FIG. 22. CALIBRATION RHEOSTAT FOR REGULATING CABIN GLASS PANELS TEMPERATURE ON GROUND




FIG. 23. DE-CER THERMOMETER  
 1 - thermocouple; 2 - thermocouple transducer; 3 - wire; 4 - wire; 5 - plug; 6 - bush; 7 - thermometer dial.




FIG. 24. HOIST FOR BELLY GUN MOUNTS




FIG. 25. LADDER-CRANE FOR SERVICING UPPER GUN MOUNT

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 26. FIXED PART OF STARBOARD PILOT'S EJECTION SEAT  
 1 - lower carriage; 2 - lock handle; 3 - emergency handle; 4 - guide rails; 5 - ejection gun; 6 - stop; 7 - cable interlocking ejection seat with canopy cover; 8 - bracket locking seat in position; 9 - bracket fastening ejection gun to armoured back plate; 10 - armoured back plate; 11 - ball crank; 12 - horizontal rails; 13 - seat recoiling cylinder.




FIG. 27. POSITION OF LOCKING PIN IN EXTREME REAR POSITION OF SEAT  
 1 - cam; 2 - locking pin.




FIG. 28. POSITION OF LOCKING PIN IN INTERMEDIATE POSITION OF SEAT  
 1 - cam; 2 - locking pin.




FIG. 29. SLIDING FRAME OF NAVIGATOR'S EJECTION SEAT  
 1 - horizontal rails; 2 - vertical guide rails; 3 - sliding frame; 4 - bracket fastening ejection gun to fuselage; 5 - quick-release ball; 6 - ejection gun; 7 - bracket securing seat to sliding frame; 8 - cable interlocking ejection gun with aircraft emergency hatch cover.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

— 198 —




FIG. 31. INSTALLATION OF NAVIGATOR-RADAR

- 1 - seat
- 2 - base for starting movement of
- 3 - seat
- 4 - seat
- 5 - seat
- 6 - seat
- 7 - seat
- 8 - seat
- 9 - seat
- 10 - seat
- 11 - seat
- 12 - seat
- 13 - seat
- 14 - seat
- 15 - seat
- 16 - seat
- 17 - seat
- 18 - seat
- 19 - seat




FIG. 32. INSTALLATION OF GUNNER'S EJECTION SEAT

- 1 - base
- 2 - base
- 3 - base
- 4 - base
- 5 - base
- 6 - base
- 7 - base
- 8 - base
- 9 - base
- 10 - base
- 11 - base
- 12 - base
- 13 - base
- 14 - base
- 15 - base
- 16 - base
- 17 - base
- 18 - base
- 19 - base




FIG. 33. DEVICE FOR REMOVAL AND INSTALLATION OF EJECTION SEAT ON AIRCRAFT

- 1 - base
- 2 - base
- 3 - base
- 4 - base
- 5 - base
- 6 - base
- 7 - base
- 8 - base
- 9 - base
- 10 - base
- 11 - base
- 12 - base
- 13 - base
- 14 - base
- 15 - base
- 16 - base
- 17 - base
- 18 - base
- 19 - base

— 199 —

50X1-HUM




FIG. 34. EJECTION GUN OF SEAT EJECTOR FROM AIRCRAFT DOWNWARD

- 1 - base
- 2 - base
- 3 - base
- 4 - base
- 5 - base
- 6 - base
- 7 - base
- 8 - base
- 9 - base
- 10 - base
- 11 - base
- 12 - base
- 13 - base
- 14 - base
- 15 - base
- 16 - base
- 17 - base
- 18 - base
- 19 - base




FIG. 35. INSTALLATION OF GUNNER'S EJECTION SEAT

- 1 - base
- 2 - base
- 3 - base
- 4 - base
- 5 - base
- 6 - base
- 7 - base
- 8 - base
- 9 - base
- 10 - base
- 11 - base
- 12 - base
- 13 - base
- 14 - base
- 15 - base
- 16 - base
- 17 - base
- 18 - base
- 19 - base




FIG. 36. INSTALLATION OF RADIO-OPERATOR'S EJECTION SEAT

- 1 - base
- 2 - base
- 3 - base
- 4 - base
- 5 - base
- 6 - base
- 7 - base
- 8 - base
- 9 - base
- 10 - base
- 11 - base
- 12 - base
- 13 - base
- 14 - base
- 15 - base
- 16 - base
- 17 - base
- 18 - base
- 19 - base

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

200



FIG. 35. DISENGAGEMENT OF EJECTION GUN BALL LOCK




FIG. 37. SEAT EJECTED FROM AIRCRAFT DOWNWARD (PISTON OF EJECTION GUN IS SCREWED OUT OF HEAD AND LIFTED)

1 - piston; 2 - ejection gun head.




FIG. 36. TOOLS FOR DISASSEMBLY, ASSEMBLY, AND CLEANING OF EJECTION GUNS  
1 - cleaning rods; 2 - brushes for cleaning ejection gun cylinders; 3 - screw drivers; 4 - wrench for fitting arming pins to ejection gun heads of seats ejected from aircraft downward; 5 - wrench 5 - 12 - 14; 6 - wrench for ejection gun heads of seats ejected from aircraft downward; 7 - wrench for lock nut securing firing mechanism to inner cylinder of ejection gun (TCGA-1000); 8 - wrench for lock nut securing body of ejection gun ball lock; 9 - wrench for lock nut of lower attachment yoke; 10 - hook for pulling off piston of ejection gun ball lock; 11 - dischargers; 12 - mandrel for assembly of ejection gun.

201




FIG. 38. TELESCOPIC EJECTION GUN, TYPE TCM-1850, OF SEATS EJECTED FROM AIRCRAFT UPWARD

1 - bolt for cocking firing mechanism; 2 - firing mechanism body; 3 - striker with two firing pins; 4 - nut spring; 5 - safety plug; 6 - arming pin; 7 - roller; 8 - indicator showing presence of explosive charge in cylinder; 9 - firing mechanism head; 10 - lock nut; 11 - nut fastening firing mechanism to inner cylinder; 12 - bolt for indicator showing presence of explosive charge; 13 - upper attachment yoke with journals; 14 - spring-loaded seal; 15 - shock absorber bush; 16 - rubber shock absorber; 17 - sleeve; 18 - lock nut; 19 - lower attachment yoke with journals; 20 - outer cylinder; 21 - mid cylinder; 22 - inner cylinder; 23 - nut for lower gases; 24 - bolts of ball lock; 25 - aluminum gasket; 26 - ball lock spring; 27 - ball lock body; 28 - crutch shoulder; 29 - lock nut; 30 - ball lock piston.




FIG. 39. FITTING ARMING PIN THROUGH PORT IN ROD OF EJECTION GUN FIRING MECHANISM STRIKER




FIG. 40. JOINING EXPLOSIVE CHARGE WITH EJECTION GUN FIRING MECHANISM




FIG. 38. TELESCOPIC EJECTION GUN, TYPE TCM-1850, OF SEATS EJECTED FROM AIRCRAFT UPWARD

19 - lower attachment yoke with journals; 20 - outer cylinder; 21 - mid cylinder; 22 - inner cylinder; 23 - nut for lower gases; 24 - bolts of ball lock; 25 - aluminum gasket; 26 - ball lock spring; 27 - ball lock body; 28 - crutch shoulder; 29 - lock nut; 30 - ball lock piston.




FIG. 41. MOUNTING FIRING MECHANISM WITH EXPLOSIVE CHARGE ON EJECTION GUN




FIG. 42. CHECKING EXPLOSIVE PRESENCE OF EXPLOSIVE CHARGE IN EJECTION GUN HEAD

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

202




FIG. 43. HYDRAULIC LOCK OF NAVIGATOR-RADAR OPERATOR'S SEAT ACTUATING CYLINDER  
1 - non-return valve; 2 - adaptor; 3 - tube; 4 - plug; 5 - tube; 6 - lock; 7 - charging pipe union; 8 - piston; 9 - screw-in angle; 10 - dovetail-type nozzle.




FIG. 44. NAVIGATOR-RADAR OPERATOR'S SEAT ACTUATING CYLINDER  
1 - pipe union; 2 - outer cylinder; 3 - master rod; 4 - singular pipe union; 5 - eye fastening actuating cylinder rod; 6 - seat sliding carriage; 7 - tube delivering air to recess of seat actuating cylinder; 8 - head; 9 - pipe union delivering air for lowering seat; 10 - pipe union delivering air for raising seat.

203




FIG. 45. KEY DIAGRAM OF BENCH FOR CHARGING NAVIGATOR-RADAR OPERATOR'S SEAT ACTUATING CYLINDER WITH AIR.  
A - air supply each (22300A); 2 - pressure gauge with scale for 250 lb/sq. in.; 3 - pressure gauge with scale for 25 lb/sq. in.; 4 - shut-off valve with scale for 25 lb/sq. in.; 5 - pressure gauge with scale for 25 lb/sq. in.; 6 - shut-off valve with scale for 25 lb/sq. in.; 7 - pressure gauge with scale for 25 lb/sq. in.; 8 - shut-off valve with scale for 25 lb/sq. in.; 9 - pressure gauge with scale for 25 lb/sq. in.; 10 - filter; 11 - head pump; 12 - pressure gauge with scale for 25 lb/sq. in.; 13 - unit for 100" 10 hydraulic fluid.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 46. MECHANICAL SYSTEM OF JETTISHING NAVIGATOR'S EMERGENCY HATCH COVER  
1 - safety device; 2 - handle; 3 - bell crank; 4 - link; 5 - bell crank; 6 - lever; 7 - cylinder; 8 - spring; 9 - cylinder of hatch cover (jettishng air system); 10 - roller; 11 - spring; 12 - roller; 13 - roller; 14 - latch cover; 15 - ball crank.




FIG. 47. MECHANICAL SYSTEM OF JETTISHING COVER OF PILOT'S CANOPY EMERGENCY HATCH  
1 - supporting air tank; 2 - handle; 3 - bell crank; 4 - lever; 5 - cylinder; 6 - spring; 7 - cylinder of hatch cover (jettishng air system); 8 - roller; 9 - roller; 10 - roller; 11 - link; 12 - link; 13 - link; 14 - link; 15 - link; 16 - link; 17 - link; 18 - link; 19 - link; 20 - link; 21 - link; 22 - link.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM

206




FIG. 45. MECHANICAL SYSTEM OF JETTISONING COVER OF NAVIGATOR-RADAR OPERATOR'S EMERGENCY HATCH

1 - handle; 2 - winch for raising hatch cover; 3 - cable of hatch cover jettisoning mechanical system; 4 - winch cable; 5 - mechanism disconnecting winch cable; 6 - handle for opening hatch cover from cockpit inside; 7 - handle for opening hatch cover from outside; 8 - end; 9 - lever; 10 - ball crank; 11 - cylinder of hatch cover jettisoning air system; 12 - fixed stop on cover; 13 - stop on hatch edging; 14 - hook; 15 - intermediate member; 16 - stop; 17 - lever; 18 - dowel.

207




FIG. 46. MECHANICAL SYSTEM OF JETTISONING COVER OF REAR GUNNER'S EMERGENCY HATCH

1 - handle; 2 - cable; 3 - handle for opening hatch cover from cockpit inside; 4 - handle for opening hatch cover from outside; 5 - intermediate member; 6 - stop; 7 - handle for opening hatch from inside; 8 - stop; 9 - lever; 10 - ball crank; 11 - cylinder of hatch cover jettisoning air system; 12 - fixed stop on cover.

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

209

50X1-HUM




FIG. 50. MECHANICAL SYSTEM OF JETTISONING COVER OF GUNNER-RADIO OPERATOR'S EMERGENCY HATCH

- 1 - handle; 2 - rod; 3 - hatch depressurization valve; 4 - wedge; 5 - hinge bell crank;
- 6 - lever; 7 - stops; 8 - lever; 9 - support; 10 - hooks; 11 - transverse member; 12 -
- pin.




FIG. 51. LIFE BOAT CONTAINER IN BOBSAL PIN

- 1 - lid; 2 - lock pin; 3 - auxiliary hatch; 4 - container cover.

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

50X1-HUM

210





FIG. 55. IVANOV GEAR OF SYNCHRONIZING LIFE BOAT, TYPE DAU-501.

1 - pipe which for connection of valve to cylinder neck; 2 - capsule; 3 - packing gasket; 4 - valve; 5 - nut; 6 - rod nut; 7 - screw; 8 - screw; 9 - screw; 10 - screw; 11 - screw; 12 - rear main lever.




SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

Inset No. 1



- STABLS:
- Aileron control
  - Rudder control
  - Elevator control
  - Elevator trim tab control
  - Locking elevators, rudder, and ailerons on parked aircraft


FIG. 54. CONTROL SYSTEMS OF ELEVATOR, RUDDER, AILERONS, TRIM TABS AND SERVO TABS AND LOCKING SYSTEM OF ELEVATOR, RUDDER AND AILERONS ON PARKED AIRCRAFT.  
 1 - ampule and linear deflections of aileron, its trim tab or servo tab (for letter - with aileron deflected to extreme positions); 2 - ampule and linear deflections of rudder, its trim tab or servo tab (for letter - with rudder deflected to extreme positions); 3 - ampule deflections of control column; 4 - neutral position of aileron control wheel; 5 - ampule and linear deflections of elevator, its trim tab or servo tab (for letter - with elevator deflected to extreme positions).

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

Inch No. 1



- SYMBOLS:**
- Aileron control
  - Rudder control
  - Elevator control
  - Elevator trim tab control
  - Locking elevators, rudders and ailerons on parked aircraft

**FIG. 54. CONTROL SYSTEMS OF ELEVATOR, RUDDER, AILERONS, TRIM TABS AND SERVO TABS AND LOCKING SYSTEM OF ELEVATOR, RUDDER AND AILERONS ON PARKED AIRCRAFT**

1 - angular and linear deflections of aileron, its trim tab or servo tab (for letter - with a/c on deflected to extreme positions); 2 - angular and linear deflections of rudder, its trim tab or servo tab (for letter - with rudder deflected to extreme positions); 3 - angular deflections of control column; 4 - neutral position of aileron control wheel; 5 - angular and linear deflections of aileron, its trim tab or servo tab (for letter - with aileron deflected to extreme positions).

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

213




FIG. 34. CHART SHOWING PRELIMINARY TENSION OF CABLES CONNECTING AUTOPILOT SERVO UNIT WITH ELEVATOR, AILERON CONTROL SYSTEM.

1 - autopilot servo unit cables (including cables running from servo unit through) 2 - cables running from aileron control system.




FIG. 35. CHART SHOWING PRELIMINARY TENSION OF AILERON CONTROL SYSTEM CABLES RUNNING THROUGH PILOTS' CABIN.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




FIG. 58. CHART SHOWING PRELIMINARY TENSION OF ELEVATOR TRIM TAB CONTROL CABLES




FIG. 57. CHART SHOWING PRELIMINARY TENSION OF ELEVATOR, RUDDER AND AILERON LOCKING SYSTEM CABLES ON PARK

1 - cables, not including mechanism;  
 2 - cables of main linkage engaged at frames No 20 to 48; 3 - cables of main linkage engaged at frames No 9 to 20.

50X1-HUM




FIG. 59. MEASURING PRELIMINARY TENSION OF CABLES RUNNING FROM DRUMS OF AUTOPILOT ELEVATOR AND RUDDER SERVO UNITS




FIG. 61. MEASURING FRICTION FORCE IN RUDDER CONTROL SYSTEM  
1 - pedal; 2 - pulley; 3 - dynamometer.




FIG. 60. MEASURING FRICTION FORCE IN ELEVATOR CONTROL SYSTEM  
1 - control wheel; 2 - dynamometer; 3 - control column.




FIG. 62. MEASURING FRICTION FORCE IN AILERON CONTROL SYSTEM  
1 - control wheel; 2 - pulley; 3 - dynamometer.




FIG. 63. MEASURING FRICTION FORCE IN ELEVATOR TRIM TAB CONTROL SYSTEM  
1 - control wheel; 2 - pulley; 3 - dynamometer.

SECRET  
NO FOREIGN DISSEM




FIG. 64. MEASURING CLEARANCE BETWEEN PULLEYS OF GUIDE SUPPORTS AND TUBULAR ROD




FIG. 65. DETERMINING CABLE MISALIGNMENT ON CONTROL PULLEYS




FIG. 66. MARKS ON CONTROL WHEEL MADE BY PILOT DURING FLIGHT TO DETERMINE DEFLECTION ANGLE OF CONTROL WHEEL WHEN CHECKING LATERAL BALANCING OF AIRCRAFT




FIG. 67. LINEAR DISPLACEMENT OF MARKS ON CONTROL WHEEL MEASURED DURING POST FLIGHT INSPECTION




FIG. 68. AILERON "SCISSORS" MADE TO ELIMINATE DEFLECTION OF CONTROL WHEEL




FIG. 69. AILERON LEADING EDGE #17H HOLES FOR MAKING AILERON CONTROL "HEAVIER"



SECRET  
NO FOREIGN DISSEM

216




FIG. 70. AILERON LEADING EDGE AND LID'S REGULATING AREA OF THROUGH HOLES IN AILERON LEADING EDGE

217

50X1-HUM




FIG. 71. FLUID FOR CLOSING HOLES IN AILERON LEADING EDGES

FIG. 72. FLAP CONTROL SYSTEM ON RIGHT OUTER WING PANEL.

1 - lift-rod right-hand angular reduction gears; 2 - mechanism for flap deflection; 3 - electric mechanism of UDC-3N; 4 - transmission tubes (to flap horn); 5 - interlocking points of transmission tubes (to flap horn); 6 - interlocking points of transmission tubes (to flap horn); 7 - flap horn; 8 - universal joints of transmission shafts; 9 - transmission tubes (to flap horn); 10 - flap horn; 11 - plates for flaps; 12 - plates for flaps; 13 - plates for flaps; 14 - plates for flaps; 15 - side struts of flap valve; 16 - transmission intermediate mechanism; 17 - gear; 18 - flap valve; 19 - flap valve; 20 - flap valve; 21 - flap valve.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 74. PERMISSIBLE DEFLECTION OF FLAPS IN RETRACTED POSITION

FIG. 75. LOCATION OF POINTS A, B, AND C SERVING TO CHECK FLAP LINEAR DEFLECTION




FIG. 76. MEASURING FLAP LINEAR DEFLECTION checked in points A, B, and C when deflecting flap through 25° (Fig. 75) a - linear deflection checked in points A, B, and C b - linear deflection checked in points A, B, and C when deflecting flap through 25° (Fig. 75)




FIG. 77. ARRANGEMENT OF INSTRUMENT FOR MEASURING TWISTING ANGLE OF TRANSMISSION SHAFT 1 - reduction gear of MID-31 set; 2 - transmission shaft; 3 - dial; 4 - pointer; 5 - nutrunner after servo unit attachment bracket.




FIG. 78. MECHANISM OF MKB-11 LIMIT SWITCHES 1 - transmission shaft; 2 - cam disc adjusting screws; 3 - cam disc; 4 - limit switch actuating screws; 5 - limit switches (reflex pointing to switches left); 6 - adjusting notches with inscription 'UPPER STOP' on transmission shaft and on MID-31 mechanism bracket; 7 - reduction gear of MID-31 set.




FIG. 79. PROTRACTOR WITH RUBBER ATTACHMENT FOR CHECKING Y31-47 FLAP POSITION INDICATOR 1 - protractor; 2 - Y31-47 indicator.




FIG. 81. LANDING GEAR MAIN LEG 1 - hydraulic actuating cylinder; 2 - shock absorber eye; 3 - shock absorber; 4 - heavy tilting control rod; 5 - landing gear attachment frame; 6 - shock absorber cylinder; 7 - shock absorber eye; 8 - shock absorber; 9 - shock absorber eye; 10 - shock absorber.




FIG. 82. LANDING GEAR NOSE LEG 1 - link of red actuating mechanism; 2 - shock absorber; 3 - landing gear attachment frame; 4 - heavy tilting control rod; 5 - landing gear attachment frame; 6 - shock absorber cylinder; 7 - shock absorber eye; 8 - shock absorber; 9 - shock absorber eye; 10 - shock absorber; 11 - shock absorber; 12 - shock absorber eye.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 82. TAIL SECTION 1 - bush with steel pin; 2 - nut; 3 - eccentric rod; 4 - lower designed for operation and direction of tail; 5 - eccentric rod; 6 - shock absorber fork.




FIG. 83. LOCK OF LANDING GEAR NOSE LEG COLLAPSIBLE STRUT 1 - stop mechanism; 2 - lock engaging link; 3 - eccentric; 4 - crank; 5 - lock hydraulic cylinder; 6 - adjustable eye of lock hydraulic cylinder; 7 - roller of struts closing and opening door.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




FIG. 84. END-PIECE OF LANDING GEAR NOSE LEG HYDRAULIC ACTUATING CYLINDER CONNECTED TO LOCK  
1 - nut limiting travel of actuating cylinder rod; 2 - adjustable eye; 3 - bush of cylinder head; 4 - eye check nut; 5 - check nut.




FIG. 85. LANDING GEAR NOSE LEG WELL DOORS ACTUATING MECHANISM  
1 - adjusting eccentric; 2 - link motion; 3 - control rod; 4 - adjustable eye; 5 - lever.




FIG. 86. UP-LOCK OF LANDING GEAR NOSE AND MAIN LEGS  
1 - adjusting screw; 2 - latch; 3 - hook; 4 - rod; 5 - limit switch, type BK-44; 6 - pressure lever.




FIG. 87. POSITION OF LANDING GEAR NOSE LEG FOLLOW-UP SYSTEM WITH SLIDER IN EXTREME POSITION. SCHEMATIC DIAGRAM  
1 - slider; 2 - shock absorber transverse member; 3 - follow-up system control rod; 4 - control rod adjustable eye.

50X1-HUM

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

— 224 —




FIG. 88. ACTUATING MECHANISM OF LANDING GEAR MAIN LEG DOORS SCHEMATIC DIAGRAM  
 1 - lower link section; 2, 6, 8, 10, and 11 - control link; 3 - front reducer (lower); 4 - front reducer (upper); 5 - upper link section; 7 - rear reducer (lower); 9 - rear reducer (upper).

— 225 —

50X1-HUM




FIG. 89. LANDING GEAR MAIN LEG EXTENSION MECHANICAL INDICATOR  
 1 - indicator plate; 2 - eccentric; 3 - quadrant; 4 - pawl.  
 A - retracted position; B - extended position.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

— 226 —




FIG. 90. LIMIT SWITCH, TYPE BK-2-140B, OF LANDING GEAR NOSE LEG  
1 - limit switch, type BK-2-140B; 2 - adjusting screw; 3 - check nut.





FIG. 91. LIMIT SWITCH, TYPE BK-44, OF LANDING GEAR MAIN LEG  
1 - limit switch, type BK-44; 2 - check nut; 3 - adjusting screw.

— 227 —

50X1-HUM



17. MEASURING AMOUNT OF COMPRESSION OF KDD GEAR NOSE AND MAIN LEG SHOCK STRUTS.  
SCHEMATIC DIAGRAM  
A - nose leg strut; B - main leg strut.





FIG. 93. SCHEMATIC DIAGRAM OF LANDING GEAR NOSE LEG LUBRICATION  
1 - points at which lubricant, grade IDIATN-201, is applied; 2 - points at which lubricant, grade HK-50, is applied.



18. SCHEMATIC DIAGRAM OF LANDING GEAR LEG LUBRICATION  
1 - points at which lubricant, grade IDIATN-201, is applied; 2 - points at which lubricant, grade HK-50, is applied.





FIG. 95. SCHEMATIC DIAGRAM OF TAIL SKID LUBRICATION  
1, 2, and 3 - points at which lubricant, grade IDIATN-201, is applied.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

FIG. 9. KEY DIAGRAM OF MAIN AND GRANT HYDRAULIC SYSTEMS.

1 - intake valve; 2 - pressure relief valve; 3 - check valve; 4 - main valve; 5 - pressure relief valve; 6 - pressure relief valve; 7 - pressure relief valve; 8 - pressure relief valve; 9 - pressure relief valve; 10 - pressure relief valve; 11 - pressure relief valve; 12 - pressure relief valve; 13 - pressure relief valve; 14 - pressure relief valve; 15 - pressure relief valve; 16 - pressure relief valve; 17 - pressure relief valve; 18 - pressure relief valve; 19 - pressure relief valve; 20 - pressure relief valve; 21 - pressure relief valve; 22 - pressure relief valve; 23 - pressure relief valve; 24 - pressure relief valve; 25 - pressure relief valve; 26 - pressure relief valve; 27 - pressure relief valve; 28 - pressure relief valve; 29 - pressure relief valve; 30 - pressure relief valve; 31 - pressure relief valve; 32 - pressure relief valve; 33 - pressure relief valve; 34 - pressure relief valve; 35 - pressure relief valve; 36 - pressure relief valve; 37 - pressure relief valve; 38 - pressure relief valve; 39 - pressure relief valve; 40 - pressure relief valve; 41 - pressure relief valve; 42 - pressure relief valve; 43 - pressure relief valve; 44 - pressure relief valve; 45 - pressure relief valve; 46 - pressure relief valve; 47 - pressure relief valve; 48 - pressure relief valve; 49 - pressure relief valve; 50 - pressure relief valve; 51 - pressure relief valve; 52 - pressure relief valve; 53 - pressure relief valve; 54 - pressure relief valve; 55 - pressure relief valve; 56 - pressure relief valve; 57 - pressure relief valve; 58 - pressure relief valve; 59 - pressure relief valve; 60 - pressure relief valve; 61 - pressure relief valve; 62 - pressure relief valve; 63 - pressure relief valve; 64 - pressure relief valve; 65 - pressure relief valve; 66 - pressure relief valve; 67 - pressure relief valve; 68 - pressure relief valve; 69 - pressure relief valve; 70 - pressure relief valve; 71 - pressure relief valve; 72 - pressure relief valve; 73 - pressure relief valve; 74 - pressure relief valve; 75 - pressure relief valve; 76 - pressure relief valve; 77 - pressure relief valve; 78 - pressure relief valve; 79 - pressure relief valve; 80 - pressure relief valve; 81 - pressure relief valve; 82 - pressure relief valve; 83 - pressure relief valve; 84 - pressure relief valve; 85 - pressure relief valve; 86 - pressure relief valve; 87 - pressure relief valve; 88 - pressure relief valve; 89 - pressure relief valve; 90 - pressure relief valve; 91 - pressure relief valve; 92 - pressure relief valve; 93 - pressure relief valve; 94 - pressure relief valve; 95 - pressure relief valve; 96 - pressure relief valve; 97 - pressure relief valve; 98 - pressure relief valve; 99 - pressure relief valve; 100 - pressure relief valve.



SECRET  
NO FOREIGN DISSEM





SECRET  
NO FOREIGN DISSEM

50X1-HUM

Inset No.3




FIG. 97. MAIN HYDRAULIC SYSTEM ARRANGEMENT DIAGRAM


1 - needle-type check valve (H5810-810); 2 - pressure gauge (P/N: 250); 3 - pilots' control panel (H5504-0); 4 - landing gear nose leg actuating cylinder (H4203-0); 5 - slide valve distributor (H5810-200); 6 - hydraulic system panel (H5104-0) on frame No. 15; 7 - hand pump (H510-1); 8 - non-return valve (H5310-200); 9 - landing gear nose leg wheel turning control damping actuating cylinders (H4204-0); 10 - throttle cock (H5805-100); 11 - flow restrictor (H5810-810); 12 - actuating cylinder of landing gear nose leg collapsible strut lock (H4202-0); 13 - landing gear nose leg attachment lock (H4102-0); 14 - safety valve (H5810-0); 15 - cooler (H5501-380); 16 - tank (H5502-0); 17 - hydraulic system panel of frame No. 23 (H5502-100); 18 - non-return valve (H5810-210); 19 - constant flow restrictor (H5810-220); 20 - pump (with 423P4); 21 - bomb-bay door actuating mechanism (H5800-0); 22 - slide valve distributor (H5810-200); 23 - landing

gear main leg actuating cylinders (H4103-0); 24 - slide valve distributors with hydraulic lock (H5810-160); 25 - landing gear normal (main) controls (H5855-150); 26 - landing gear nose leg wheel turning control panel (H5802-0); 27 - hatch lock valve (H5810-39); 28 - landing gear emergency controls (H5855-150A); 29 - non-return valve (H5810-210); 30 - emergency A - high-pressure delivery line; B - low-pressure delivery line; C - landing gear retraction and extension control line; D - bomb-bay door control line; emergency brake line in pilots' control panel; E - landing gear nose leg wheel turning control line; E - return line.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

Frame No. 18 50X1-HUM



Frame No. 4

FIG. 98. BRAKE HYDRAULIC SYSTEM ARRANGEMENT DIAGRAM  
(BETWEEN FRAMES NOS 4 AND 18)

- 1 - needle-type throttle valves (H5810-020); 2 - normal (main) brake valves (VT-92) on starboard side; 3 - emergency brake pressure gauge (MF-250); 4 - normal (main) brake line pressure gauge (MF-250); 5 - pilots' control panel (H5804-0); 6 - landing gear nose leg actuating cylinder (H4203-0); 7 - slide valve distributor (H5810-200); 8 - emergency line pressure accumulator (H5803-0); 9 - main hydraulic accumulator (H5803-0); 10 - brake system tank (H5602-400); 11 - hydraulic switches (VT-34); 12 - solenoid-operated slide valve (TA-49); 13 - flow restrictor (H5810-700); 14 - hydraulic system panel (H5606-100) at frame No. 33; 15 - landing gear nose leg attachment lock (H4104-0); 16 - nose leg collapsible strut lock actuating cylinder (H4202-40); 17 - normal (main) brake valves (VT-92) on port side; 18 - non-return valve (H5810-210); 19 - main hydraulic system down-collapsible strut lock actuating cylinder (H4202-40); 20 - line filter (H5812-50); 21 - non-return valve (H5810-210); 22 - pumping station (445); 23 - straight valve (H4500-05) in piece of piping hydraulic accumulator (H5803-50); 24 - line filter (H5812-50); 25 - straight split valves (CTM-130); 26 - shut-off cock (H5810-254); 27 - oil pressure switch (LNG-150); 28 - elbow split joints; 29 - emergency hydraulic accumulator pressure drop warning unit (CTM-130); 30 - emergency hydraulic accumulator pressure drop warning unit (CTM-130); 31 - safety valve (H5810-251); 32 - straight split valves (CTM-130); 33 - wheel normal (main) brake line; 34 - wheel emergency brake line; 35 - landing gear emergency retraction and extension line; 36 - high-pressure delivery line; 37 - low-pressure delivery line; 38 - wheel normal (main) brake line; 39 - wheel emergency brake line; 40 - landing gear emergency retraction and extension line; 41 - return line.


SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

Inset

Frame No. 18

50X1-HUM



Frame No. 4

FIG. 98. BRAKE HYDRAULIC SYSTEM ARRANGEMENT DIAGRAM (BETWEEN FRAMES NOS 4 AND 18)

1 - needle-type throttle valves (H5810-820); 2 - normal (main) brake valves (ST-92) on starboard side; 3 - emergency brake pressure gauge (11[-250]; 4 - normal (main) brake line pressure gauge (11[-250]); 5 - pilot's control panel (H5804-0); 6 - landing gear nose leg actuating cylinder (H4203-0); 7 - slide valve distributor (H5810-200); 8 - emergency hydraulic accumulator (H5803-0); 9 - main hydraulic accumulator (H5803-0); 10 - brake system tank (H5607-000); 11 - hydraulic switches (ST-34); 12 - solenoid-operated slide valve (F3-40); 13 - flow restrictor (H5810-780); 14 - hydraulic system panel (H5803-0); 15 - brake system tank (H5607-000) set frame No. 33; 16 - landing gear nose leg attachment lock (H4104-0); 17 - nose leg valve (F3-40); 18 - non-return valve (H5810-210); 19 - main hydraulic system damp-collapse strut lock actuating cylinder (H4203-0); 20 - normal (main) brake valves (ST-92) on port side; 21 - non-return valve (H5810-210); 22 - pumping station (465#); 23 - straight valve (6650/65); in places of pipe joints; 24 - emergency hydraulic accumulator pressure drop warning unit (CTM-130); 25 - shut-off cock (H5810-254); 26 - oil pressure switch (11N3-150); 27 - elbow split valve (H5810-25); 28 - safety valve (H5810-25); 29 - straight split valves (6550000).

A - high-pressure delivery line; B - low-pressure delivery line; C - wheel normal (main) brake line; D - wheel emergency brake line; E - landing gear emergency retraction and actuator line; F - return line.

SECRET NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

229

50X1-HUM




FIG. 18. HYDRAULIC SYSTEM ARRANGEMENT DIAGRAM (BETWEEN FRAME NO. 18 AND LANDING GEAR MAIN LEG)

- 1 - hydraulic system pump (H4504/10) located at frame No. 23; 2 - bomb-bay door actuating filter (H4317/20); 3 - filter (H4317/20); 4 - solenoid distributor (H4504/10); 5 - solenoid distributor (H4504/10); 6 - outside solenoid distributor (H4504/10); 7 - solenoid distributor (H4504/10); 8 - solenoid distributor (H4504/10); 9 - solenoid distributor (H4504/10); 10 - solenoid distributor (H4504/10); 11 - solenoid distributor (H4504/10); 12 - solenoid distributor (H4504/10); 13 - solenoid distributor (H4504/10); 14 - solenoid distributor (H4504/10); 15 - solenoid distributor (H4504/10); 16 - solenoid distributor (H4504/10); 17 - solenoid distributor (H4504/10); 18 - solenoid distributor (H4504/10); 19 - solenoid distributor (H4504/10); 20 - solenoid distributor (H4504/10); 21 - solenoid distributor (H4504/10); 22 - solenoid distributor (H4504/10); 23 - solenoid distributor (H4504/10); 24 - solenoid distributor (H4504/10); 25 - solenoid distributor (H4504/10); 26 - solenoid distributor (H4504/10); 27 - solenoid distributor (H4504/10); 28 - solenoid distributor (H4504/10); 29 - solenoid distributor (H4504/10); 30 - solenoid distributor (H4504/10); 31 - solenoid distributor (H4504/10); 32 - solenoid distributor (H4504/10); 33 - solenoid distributor (H4504/10); 34 - solenoid distributor (H4504/10); 35 - solenoid distributor (H4504/10); 36 - solenoid distributor (H4504/10); 37 - solenoid distributor (H4504/10); 38 - solenoid distributor (H4504/10); 39 - solenoid distributor (H4504/10); 40 - solenoid distributor (H4504/10); 41 - solenoid distributor (H4504/10); 42 - solenoid distributor (H4504/10); 43 - solenoid distributor (H4504/10); 44 - solenoid distributor (H4504/10); 45 - solenoid distributor (H4504/10); 46 - solenoid distributor (H4504/10); 47 - solenoid distributor (H4504/10); 48 - solenoid distributor (H4504/10); 49 - solenoid distributor (H4504/10); 50 - solenoid distributor (H4504/10); 51 - solenoid distributor (H4504/10); 52 - solenoid distributor (H4504/10); 53 - solenoid distributor (H4504/10); 54 - solenoid distributor (H4504/10); 55 - solenoid distributor (H4504/10); 56 - solenoid distributor (H4504/10); 57 - solenoid distributor (H4504/10); 58 - solenoid distributor (H4504/10); 59 - solenoid distributor (H4504/10); 60 - solenoid distributor (H4504/10); 61 - solenoid distributor (H4504/10); 62 - solenoid distributor (H4504/10); 63 - solenoid distributor (H4504/10); 64 - solenoid distributor (H4504/10); 65 - solenoid distributor (H4504/10); 66 - solenoid distributor (H4504/10); 67 - solenoid distributor (H4504/10); 68 - solenoid distributor (H4504/10); 69 - solenoid distributor (H4504/10); 70 - solenoid distributor (H4504/10); 71 - solenoid distributor (H4504/10); 72 - solenoid distributor (H4504/10); 73 - solenoid distributor (H4504/10); 74 - solenoid distributor (H4504/10); 75 - solenoid distributor (H4504/10); 76 - solenoid distributor (H4504/10); 77 - solenoid distributor (H4504/10); 78 - solenoid distributor (H4504/10); 79 - solenoid distributor (H4504/10); 80 - solenoid distributor (H4504/10); 81 - solenoid distributor (H4504/10); 82 - solenoid distributor (H4504/10); 83 - solenoid distributor (H4504/10); 84 - solenoid distributor (H4504/10); 85 - solenoid distributor (H4504/10); 86 - solenoid distributor (H4504/10); 87 - solenoid distributor (H4504/10); 88 - solenoid distributor (H4504/10); 89 - solenoid distributor (H4504/10); 90 - solenoid distributor (H4504/10); 91 - solenoid distributor (H4504/10); 92 - solenoid distributor (H4504/10); 93 - solenoid distributor (H4504/10); 94 - solenoid distributor (H4504/10); 95 - solenoid distributor (H4504/10); 96 - solenoid distributor (H4504/10); 97 - solenoid distributor (H4504/10); 98 - solenoid distributor (H4504/10); 99 - solenoid distributor (H4504/10); 100 - solenoid distributor (H4504/10).

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

231




FIG. 100. PUMP DRAINAGE AND TANK BOOSTING ARRANGEMENT DIAGRAMS  
 1 - drain tank (H15602-100); 2 - pressure regulator (H15810-700); 3 - pressure gauge; 4 - air flow restrictor (H15810-250); 5 - brake hydraulic system tank (H15602-400); 6 - drain valve (H15810-400); 7 - main hydraulic system tank (H15602-0); 8 - pump (unit 45539); 9 - non-return valve (H15810-270); 10 - air intake flange.




FIG. 101. ARRANGEMENT OF ACCESS HATCHES FOR INSPECTING HYDRAULIC SYSTEM UNITS AND PIPE LINES  
 1 - hatch between frames Nos 12 and 26; 2 - hatch above centre plane; 3 - inspection hole of main hydraulic system tank oil gauge; 4 - hatch over filler of main hydraulic system tank; 5 - panel above engine air intake duct; 6 - hatches on wing middle part; 7 - engine cowling inner from shutter; 8 - engine cowling outer from shutter; 9 - landing gear nose leg wall doors; 10 - bomb-bay doors; 11 - hatch on landing gear; 12 - landing gear main leg front doors; 13 - landing gear main leg rear doors.




FIG. 102. RING JOINING AIR INTAKE DUCT TO ENGINE COMPRESSOR HOUSING  
 1 - air intake duct front flange; 2 - air intake duct rear flange; 3 - non-return valve; 4 - non-return valve; 5 - air intake duct rear flange; 6 - air intake duct rear flange; 7 - stop.




FIG. 103. FUEL TANK FLOAT  
 1 - fuel float; 2 - tank shell; 3 - filler pipe; 4 - fuel float; 5 - fuel float; 6 - fuel float; 7 - fuel float; 8 - fuel float; 9 - fuel float; 10 - fuel float; 11 - fuel float; 12 - fuel float; 13 - fuel float.

SECRET

NO FOREIGN DISSEM

NO FOREIGN DISSEM




FIG. 104. ENGINE CONTROL SYSTEM CABLE PRE-TENSION VERSUS AIR TEMPERATURE (WITH ALLOWANCE AMOUNTING TO ±2.5 KG)




FIG. 105. FINE FUEL FILTER (REMOVING COVER WITH FILTERING ASSEMBLY)




FIG. 106. TONGS FOR WASHING FILTERING ELEMENTS




FIG. 107. WASHING FILTERING ELEMENT AND CLEANING IT WITH HAIR BRUSH




FIG. 108. RIGHT PILOT AIR PANEL  
1 - air pressure gauge MB-250; 2 - cock of reducer H 7610-10; 3 - air pressure gauge MB-10; 4 - hatch pressurization system shut-off cock.

SECRET  
NO FOREIGN DISSEM

SECRET NO FOREIGN DISSEM

50X1-HUM

234

235




FIG. 109. KEY DIAGRAM OF ENGINE MAIN FUEL SYSTEM (UNITS AND PIPE LINES ARRANGED IN FUSELAGE AND RIGHT WING)

1 - tank No.1; 2 - tank No.2; 3 - filler; 4 - cock for jettisoning fuel from tanks Nos 1 and 2; 5 - pipe for filling system with fuel; 6 - tank No.6 (left); 7 - tank No.6 (right); 8 - engine cross-feed valve; 9 - tank No.7; 10 - tank No.8; 11 - tank No.9; 12 - tank No.12; 13 - non-return valve of tank group III; 14 - non-return valve of tank group IV; 15 - tank No.11; 16 - tank No.12; 17 - tank No.13; 18 - tank No.14; 19 - tank No.15; 20 - tank No.16; 21 - fuel jettison valve; 22 - aircraft fuel booster pump 31H-T (unit 461) of tank group IV; 23 - aircraft fuel booster pump 31H-T (unit 461) of tank group IV; 24 - engine fuel booster pump 1H-T (unit 453); 25 - fuel flow meter transmitter PTC-10; 26 - fuel cooled oil cooler (unit 62); 27 - main line fuel filter; 28 - electric pressure gauge transmitter 1H-T; 29 - measuring fuel pressure westream of pumps 1H-2831 and 1H-1531; 30 - pumps 1H-2831 and 1H-1531; 31 - pumps 1H-2831 and 1H-1531; 32 - fuel pressure warning unit 1H-1017; 33 - non-return valves of tank No. 3; 34 - tank No. 3; 35 - tank No. 4; 36 - cock for jettisoning fuel from tank No. 5; 37 - pipe for filling system with fuel; 38 - drain cock; 39 - tank No. 3; 40 - drain cock; 41 - aircraft fuel booster pump 31H-T of tank No. 2; 42 - fuel jettison valve.




FIG. 110. FILLER WITH QUICK-RELEASE PLUG

1 - push-button; 2 - push-button spring; 3 - plug spring; 4 - plug; 5 - locking bell; 6 - plug body; 7 - valve with gasket; 8 - filler body; 9 - pipe union for draining condensate and excess fuel.

SECRET NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

— 236 —




FIG. 111. FILLER OF TANK No. 3 WITH FUEL LEVEL INDICATOR  
 1 - filler body; 2 - quick-release plug; 3 - rocker with inscription FULL (HOLD); 4 - dip hole;  
 5 - pipe; 6 - cable; 7 - branch pipe; 8 - tank No. 3; 9 - lever; 10 - float; 11 - baffle.

Frame No. 26

— 237 —




FIG. 112. SAFETY VALVE (UNIT 438)






FIG. 113. REDUCER H7610-10  
 1 - high-pressure chamber; 2 - low-pressure chamber;  
 3 - diaphragm; 4 - spring; 5 - valve; 6 - spring;  
 7 and 9 - pipe unions; 8 - safety valve; 10 - thrust-off cock.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM



1 - shut-off valve; 2 - pipe line; 3 - non-return valve; 4 - supply valve; 5 - TXV turbo-cooler expansion regulator; 6 - TXV turbo-cooler flow restrictor mechanism; 7 - air cooler; 8 - TXV turbo-cooler ventillation regulator; 9 - TXV turbo-cooler heating manifold; 10 - electric heater; 11 - electric heater blower heating manifold; 12 - electric heater blower heating manifold; 13 - electric heater blower heating manifold; 14 - pipe line applying air to heating manifold; 15 - electric heater blower heating manifold; 16 - electric heater blower heating manifold; 17 - PIB air delivery regulator; 18 - PIB air delivery regulator; 19 - PIB air delivery regulator; 20 - PIB air delivery regulator; 21 - PIB air delivery regulator; 22 - PIB air delivery regulator; 23 - PIB air delivery regulator; 24 - PIB air delivery regulator; 25 - PIB air delivery regulator; 26 - PIB air delivery regulator; 27 - PIB air delivery regulator; 28 - PIB air delivery regulator; 29 - PIB air delivery regulator; 30 - PIB air delivery regulator; 31 - PIB air delivery regulator.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM

241

240




FIG. 117. HATCH PRESSURIZATION KEY DIAGRAM  
 1 - detector; 2 - high-pressure gauge, type MB-200-3; 3 - reducer; 4 - low-pressure gauge, type MB-10-0.5; hatch pressurization cock; 5 - detector; 6 - hatch pressurization recovery cock; 7 - regulator; 8 - hatch sealing base; 9 - right pillar's hatch sealing base; 10 - left pillar's hatch sealing base; 11 - lever for releasing pressure from hoses during parking; 12 - mechanism for releasing pressure from hoses during parking; 13 - cock; 14 - lever for releasing pressure from hoses during parking; 15 - mechanism for releasing pressure from hoses during parking; 16 - cock; 17 - cock; 18 - cock; 19 - cock; 20 - cock; 21 - cock; 22 - cock; 23 - cock; 24 - cock; 25 - cock; 26 - cock; 27 - cock.




FIG. 118. COCKPIT PRESSURIZATION AND WING DEICER SYSTEM SHUT-OFF VALVE CONTROL ARRANGEMENT DIAGRAM  
 1 - pipe line; 2 - detector; 3 - detector; 4 - hatch pressurization system control cock; 5 - low-pressure gauge; 6 - reducer; 7 - high-pressure gauge; 8 - cockpit pressurization system control cock; 9 - cockpit pressurization system control cock; 10 - cockpit pressurization system control cock; 11 - cockpit pressurization system control cock; 12 - wing deicer system shut-off valve; 13 - drain pipe union; 14 - cock; 15 - cock; 16 - cock; 17 - cock; 18 - cock; 19 - cock; 20 - cock; 21 - cock; 22 - cock; 23 - cock; 24 - cock; 25 - cock; 26 - cock; 27 - cock; 28 - cock; 29 - cock; 30 - cock; 31 - cock; 32 - cock; 33 - cock.

SECRET NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




FIG. 119. PRESSURIZATION REDUCING VALVE (PKH)  
1 - piston; 2 - body; 3 - reducing valve; 4 - filter;  
5 - jet.




FIG. 120. AIR DELIVERY REGULATOR (PTRB)  
1 - control lever; 2 - sheaves; 3 - cable; 4 - turnbuckle; 5 - sheave;  
6 - valve body; 7 - butterfly valve; 8 - axle; 9 - rivet; 10 - glands;  
11 - ring; 12 - nut; 13 - sheave; 14 - nut.




FIG. 121. REDUCER H7610-10  
1 - body; 2 - valve; 3 - diaphragm; 4 - springs; 5 - lock nut; 6 - handle;  
7 - gland; 8 - safety valve.




FIG. 122. HATCH PRESSURIZATION PANEL  
1 - knob of reducer H7610-10; 2 - hatch pressurization cock; 3 - high-pressure gauge, type MB-250-15; 4 - low-pressure gauge, type MB-10a.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 123. MECHANISM FOR RELEASING PRESSURE FROM HATCH SEALING HOSES (STANDARD)  
1 - lock; 2 - interlocking lever; 3 - two-way cock; 4 - interlocking lever; 5 - pressure lever for releasing pressure from hoses; 6 - pressurization valve rod.




FIG. 124. OUTLET SLOTS IN BRANCH PIPES AND CLEARANCES BETWEEN BRANCH PIPES AND PILOTS' CANOPY GLASS  
1 - branch pipe on cover; 2 - branch pipe on front glass; 3 - branch pipe on side glass; 4 - glass.




FIG. 125. STAND FOR TESTING COCKPITS FOR LEAKAGE. SCHEMATIC DIAGRAM  
1 - straight-way cock; 2 - drain cock; 3 - filter; 4 - pressure gauge for 10 kg/sq.cm.; 5 - safety valve; 6 - cockpit pressure release cock; 7 - straight-way cock; 8 - climb-and-descent indicator; 9 - pressure gauge for 1.5 kg/sq.cm.; 10 - mercury pressure gauge; 11 - reference pressure gauge; 12 - reducer; 13 - pressure gauge for 10 kg/sq.cm.; 14 - KB-5 cock; 15 - pressure gauge for 10 kg/sq.cm.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 126. STAND FOR CALIBRATION OF KNX COMBINATION PRESSURE VALVE TOGETHER WITH ITS CONTROL VALVE. SCHEMATIC DIAGRAM  
 1 - heated reservoir; 2 - control valve; 3 - pressure gauge; 4 - reservoir safety valve; 5 - KNX combination pressure valve; 6 - shut-off cock; 7 - Venturi tube; 8 - air flow meter.




FIG. 127. OVERALL DIMENSIONS AND SHAPE OF ITEMS TO BE TRANSPORTED BY ROLLING STOCK  
 No. 1-II - overall dimensions and shape of items allowed for handling throughout the railway network; No. 0 - overall dimensions and shape of items allowed for handling on intermetropolitan through railway lines.




FIG. 128. DIMENSIONS AND SHAPE OF PACKED FRONT PRESSURIZED COCKPIT AS RELATED TO DIMENSIONS OF RAILWAY CAR




FIG. 129. DIMENSIONS AND SHAPE OF PACKED FUSELAGE NOSE SECTION AS RELATED TO DIMENSIONS OF RAILWAY CAR




FIG. 130. DIMENSIONS AND SHAPE OF PACKED FUSELAGE TAIL SECTION AS RELATED TO DIMENSIONS OF RAILWAY CAR




FIG. 131. DIMENSIONS AND SHAPE OF PACKED REAR PRESSURIZED COCKPIT AS RELATED TO DIMENSIONS OF RAILWAY CAR

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM




FIG. 132. DIMENSIONS AND SHAPE OF PACKED FIRST DETACHABLE WING PART AS RELATED TO DIMENSIONS OF RAILWAY CAR




FIG. 133. DIMENSIONS AND SHAPE OF PACKED SECOND DETACHABLE WING PART AS RELATED TO DIMENSIONS OF RAILWAY CAR




FIG. 134. DIMENSIONS AND SHAPE OF PACKED STABILIZER AS RELATED TO DIMENSIONS OF RAILWAY CAR




FIG. 135. DIMENSIONS AND SHAPE OF PACKED FIN AS RELATED TO DIMENSIONS OF RAILWAY CAR




FIG. 13A. CONTAINER FOR PACKING FLAP OF FIRST DETACHABLE WING PART

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

Ref. No.	Description	Quantity	Material	Size, mm
1	2	3	4	5
1	Bars	8	Pinewood	60x60x1650
2	Same	2	Same	60x60x1800
3	Same	6	Same	60x60x3320
4	Braces	12	Same	40x40x1290
5	Bars	2	Same	100x120x520
6	Same	4	Same	40x40x1170
7	Same	6	Same	60x60x1002
8	Same	4	Same	60x90x1130
9	Floor (shield)	1	Same	20x1002x3320
10	Shackles	4	St. 5 (x 16)	L = 248
11	Bars	4	Pinewood	60x60x1630
12	End face walls	2	Veneer	4x1002x1630
13	Bolts	8	St. 5	M12x1.75; L = 140
14	Bars	2	Pinewood	60x67x3320
15	Same	2	Same	25x50x3320
16	Nails	-	State Standard FOCT 4028-48	1.4x20; 2.5x50; 3x70
17	Top (shield)	1	Pinewood	20x1130x3370
18	Bars	4	Same	60x120x1150
19	Bolts	8	St. 5 (x 22)	M12x1.75; L = 180
20	Nuts	28	St. 5 (x 22)	M12x1.75; L = 10
21	Washers	40	Steel 10 (x 2 mm)	12x35
22	Support	1	Pinewood	60x100x882
23	Benches	2	Pinewood	100x160x200
24	Covering	1	Commercial felt (8 x 10 mm) State Standard FOCT 6618-52	0.75 sq.m.
25	Same	1	Sackcloth	1 sq.m.
26	Benches	2	Pinewood	60x100x120
27	Support	1	Same	60x100x882
28	Bolts	4	St. 5 (x 22)	M12x1.75; L = 100
29	Same	4	St. 5 (x 22)	M12x1.75; L = 130
30	Clamps	4	St. 3 (x 6)	50x325
31	Star paper	1	State Standard FOCT 1887-51	17.7 sq.m.
32	Rubberoid	1	State Standard FOCT 2165-51	5.3 sq.m.
33	Blocks	2	Pinewood	20x20x1100
34	Same	2	Same	20x20x180

1	2	3	4	5
35	Gate	1	Veneer	4x145x145
36	Planks	8	Pinewood	10x30x775
37	Same	2	Veneer	4x30x1700
38	Side walls	2	Same	4x1670x3320
39	Eye bolts	4	St. 3 (x 12)	M12x1.75; L = 265
40	Bars	2	Pinewood	60x60x930
41	Vent	1	Steel 10 (x 0.6)	240x324
42	Boss	1	Pinewood	80x100x160
43	Same	1	Same	60x90x100

Note: Designations in brackets in the column "Material" in Figures 135 through 161 stand for:  
 x - round;  
 s - hexahedral;  
 mx - hexahedral calibrated;  
 a - sheet.

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM



50X1-HUM

— 252 —

— 253 —




FIG. 137. CONTAINER FOR PACKING FLAP OF SECOND DETACHABLE WING PART


Ref. No.	Description	Quantity	Material	Size, mm
1	2	3	4	5
1	Flank	1	Veneer (δ = 4 mm)	20x88,000
2	Blocks	14	Pinewood	60x60x1840
3	Same	4	Same	40x40x1240
4	Walls	2	Veneer (δ = 4 mm)	1860x7500
5	Bars	6	Pinewood	60x60x7500
6	Walls	2	Veneer (δ = 4 mm)	1022x1820
7	Blocks	4	Pinewood	60x60x1820
8	Same	6	Same	60x60x1020
9	Same	4	Same	60x60x1390
10	Same	2	Same	100x120x7500
11	Ruberoid	1	State Standard ГОСТ 2165-51	11 sq.m.
12	Boards	12	Pinewood	20x100x7550
13	Bars	7	Pinewood	60x120x1150
14	Same	2	Same	60x60x7500
15	Bolts	6	Steel 45 (st 22)	M12x1.75 L = 200
16	Washers	32	St. 5 (st 30)	28x14
17	Bolts	10	St. 5 (st 22)	M12x1.75 L = 140
18	Boards	10	Pinewood	20x110x7500
19	Bolts	4	Steel 45 (st 22)	M12x1.75 L = 180
20	Planks	2	Pinewood	20x25x140
21	Rye bolts	2	St. 3 (st 12)	L = 182
22	Gets	1	Veneer (δ = 4 mm)	145x145
23	Boards	10	Pinewood	20x110x7500
24	Bolts	6	St. 5 (st 22)	M12x1.75 L = 200
25	Rings	4	St. 3 (st 16)	L = 248
26	Clamps	4	St. 3 (st 6)	50x34x5
27	Bolts	4	St. 5 (st 22)	M12x1.75 L = 140
28	Planks	2	Pinewood	20x20x180
29	Bars	24	St. 5 (st 22)	M12x1.75 L = 10
30	Bolts	4	St. 5 (st 22)	M12x1.75 L = 100
31	Supports	2	Pinewood	30x100x1022
32	Bars	2	Same	60x60x1560
33	Block	1	Same	60x60x1022
34	Boards	6	Same	20x100x1022
35	Bars	7	Same	60x70x1150
36	Vent	1	Roofing iron (δ = 0.6 mm)	240x324
37	Bars	2	Pinewood	60x60x800
38	Same	2	Same	60x60x1730
39	Covering	1	Commercial felt State Standard ГОСТ 6418-52	1 sq.m.

SECRET

NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM



50X1-HUM

1	2	3	4	5
40	Nails		State Standard ГОСТ 4028-48	2.5x50; 1/4x20; 3x70
41	Boards	6	Pinewood	20x120x1022
42	Covering	1	Sackcloth	1 sq.m.
43	Boards	8	Pinewood	20x100x1022
44	Planks		Veneer (δ = 4 mm)	20x88,000
45	Boards	2	Pinewood	25x50x5020
46	Bars	24	Pinewood	40x40x1440
47	Same	2	Same	60x60x850
48	Stops	2	Same	50x60x90
49	Washers	4	St. 5 (K 35)	34x13
50	Tar paper	1	State Standard ГОСТ 1887-51	39 sq.m.
51	Gaskets	3	Veneer	4x150x1650






FIG. 13. CARCASS PACKING FOR ALLECON.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

Ref. No.	Description	Quantity	Material	Size, mm
1	Cover	1	Canvas, type AN-1, article 38) State Standard FOOT 351-41	
2	Boards	4	Pinewood	20x100x830
3	Walls	—	State Standard FOOT 4028-48	4x100
4	Blocks	2	Pinewood	100x150x1650
5	Same	8	Same	50x100x100
6	Braces	4	Pinewood	80x100x100
7	Blocks	4	Same	60x80x100
8	Same	2	Same	100x150x550
9	Same	2	Same	60x80x830
10	Same	2	Same	100x100x830
11	Same	2	Same	100x150x1500
12	Braces	4	Same	80x100x1000
13	Stand	1	Same	80x100x1430
14	Walls	—	State Standard FOOT 4028-48	2x90
15	Plank	1	Veneer	5x30x15,000
16	Supports	2	Pinewood	20x350x830
17	Covering	—	Commercial felt (δ = 10 mm) State Standard FOOT 5015-52	80xL to fit the place of installation
18	Walls	2	Veneer	2x180x90
19	Blocks	8	Pinewood	80x80x200
20	Stand	1	Same	80x150x1580




FIG. 19. CARCASS PACKING FOR ELEVATOR

SECRET

NO FOREIGN DISSEM

50X1-HUM

— 258 —

— 259 —

Ref. No.	Description	Quantity	Material	Size, mm
1	2	3	4	5
1	Blocks	11	Pinewood	80x80x800
2	Same	2	Same	80x80x1410
3	Same	2	Same	80x80x1220
4	Same	2	Same	100x100x7100
5	Same	2	Same	80x80x1130
6	Boards	2	Same	20x120x2220
7	Blocks	2	Same	80x80x1030
8	Boards	2	Same	20x120x6360
9	Same	2	Same	20x120x2250
10	Blocks	2	Same	80x80x850
11	Boards	2	Same	20x120x2250
12	Nails	—	State Standard ГОСТ 4028-48	4x100
13	Cover	1	Canvas, type ANH-1, article 38) State Standard ГОСТ 351-41	
14	Blocks	2	Pinewood	80x80x650
15	Board	1	Same	20x120x840
16	Same	1	Same	20x120x800
17	Same	1	Same	20x120x1300
18	Boards	5	Same	20x120x840
19	Covering	1	Commercial felt (δ = 10 mm) State Standard ГОСТ 6418-52	1 sq.m.
20	Coverings	2	Veneer (δ = 3 mm)	120x1850
21	Shields	4	Pinewood	20x250x800
22	Coverings	2	Veneer	3x120x1600
23	Shields	4	Pinewood	20x300x800
24	Boards	4	Same	20x120x800




FIG. 140. CARCASS PACKING FOR RUDDER

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

260

261

Ref. No.	Description	Quantity	Material	Size, mm
1	2	3	4	5
1	Stands	2	Pinewood	80x80x1200
2	Braces	2	Sane	20x120x1670
3	Bars	2	Sane	100x100x5700
4	Stands	2	Sane	80x80x1330
5	Braces	2	Sane	20x120x2200
6	Klocks	2	Sane	20x120x4570
7	Board	1	Sane	20x120x640
8	Stands	2	Sane	80x80x1615
9	Braces	2	Sane	20x120x2340
10	Stands	2	Sane	80x80x1700
11	Klocks	9	Sane	80x80x600
12	Braces	2	Sane	80x80x2080
13	Nails	2	Sane	3x50
14	Cover	1	State Standard FOOT 4028-48	Canvas, type ANI-1, article 383
15	Supports	3	Pinewood	20x200x600
16	Covering	1	Commercial felt (δ = 10 mm)	0.4 sq.m.
17	Covering	1	State Standard FOOT 6418-52	0.5 sq.m.
18	Supports	3	Sackcloth (δ = 25 mm)	150x600
19	Nails	-	State Standard FOOT 4028-48	4x100
20	Board	1	Pinewood	20x120x2170
21	Boards	2	Sane	20x120x600
22	Boards	1	Sane	20x120x1230
23	Nails for tar paper	-	State Standard FOOT 4028-48	2x40
24	Plank	1	Pinewood	53x12,600




FIG. 141. CARCASS PACKING FOR LANDING GEAR FAIRING

SECRET  
NO FOREIGN DISSEM


SECRET  
NO FOREIGN DISSEM

50X1-HUM

262

263

Ref. No.	Description	Quantity	Material	Size, mm
1	Bases	3	St.3 (n 8)	30x80
2	Ribs	6	St.3 (n 5)	30x65
3	Bolts	3	St.3 (n 22)	M12x1.75; L = 40
4	Bars	4	Pinewood	100x120x1500
5	Washers	3	St.3 (n 2)	14x28
6	Support	1	Pinewood	80x325x1500
7	Nuts	3	St.3 (n 22)	M12x1.75
8	Pins	6	St.3 (n 12)	L = 120
9	Nuts	6	St.3 (n 22)	M12x1.75
10	Washers	6	St.3 (n 2)	14x28
11	Support	1	Pinewood	80x280x1500
12	Bars	2	Pinewood	100x120x6000
13	Cover	1	Canvas, type ANB-1, article 838 State Standard FOCT 351-41	100x120x6000
14	Brackets	3	St.3	30x39x70
15	Covering	1	Commercial felt (δ = 10 mm) State Standard FOCT 6418-52	0.5 sq.m.
16	Nails	-	State Standard FOCT 4028-48	2x60
17	Planks	2	Pinewood	5x30x15,000
18	Nails	-	State Standard FOCT 4028-48	2x30
19	Saws	-	State Standard FOCT 4028-48	4x120
20	Bars	8	Pinewood	4x60x100



Ref. No.	Description	Quantity	Material	Size, mm
1	Blocks	2	Pinewood	80x120x500
2	Nails	3 kg	State Standard FOCT 4028-48	4x110
3	Pins	16	St.3 (n 12)	M12x1.75; L = 130
4	Nuts	32	St.3 (n 22)	M12x1.75
5	Washers	32	Steel 10 (n 2)	4x14
6	Cheek plates	4	St.3	6x100x211
7	Bars	4	Pinewood	100x120x1880
8	Ribs	8	St.3	6x23x180
9	Base	8	St.3	6x100x100
10	Cheek plates	4	St.3	6x100x89
11	Ribs	8	St.3 (n 11)	6x23x60
12	Nuts	8	St.3 (n 11)	M6x1
13	Washers	8	Steel 20 (n 1.5)	18x7
14	Cotter pins	8	State Standard FOCT 397-54	1.5x15
15	Washers	16	M6 (n 2)	25x10
16	Bushes	8	M6 (n 18)	h = 9
17	Bolts	8	St.3 (n 16)	H6x1; L = 60
18	Nails	0.1 kg	State Standard FOCT 4028-48	2x25
19	Plank	1	Pinewood	10x30x15,000
20	Cover	1	Canvas, type ANB-1, article 383 State Standard FOCT 351-41	

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM




FIG. 143. CARCASS PACKING FOR AIR INTAKE FRONT PART




FIG. 144. CARCASS PACKING FOR ENGINE NACELLE REAR ADAPTER

Ref. No.	Description	Quantity	Material	Size, mm
1	Stops	8	Pinewood	100x100x200
2	Longitudinal bars	2	Same	120x150x2800
3	Braces	4	Same	50x50x300
4	Stands	4	Same	80x80x1530
5	Bracing wire rope	1	Steel 10 (# 3), annealed	60 m.
6	Boards	1	Pinewood	20x2800x1800
7	Cover	1	Canvas, type MIL-1, article 383 State Standard TUCT 351-41	
8	Nails	-	State Standard TUCT 4028-48	3x60
9	Plank	1	Veneer	5x30x9200
10	Cross-beams	2	Pinewood	80x100x1800
11	Clamps	2	Same	40x100x1800
12	Covering	1	Commercial felt (δ = 10 mm)	2.6 sq.m.
13	Clamps	4	Pinewood	80x80x50
14	Block	1	Same	80x80x2140
15	Boards	2	Same	60x100x600
16	Nails	-	State Standard TUCT 4028-48	2x40
17	Eye bolts	8	St.3 (# 12)	M12x1.75; L = 175
18	Nuts	14	St.3	M12x1.75
19	Washers	14	St.3 (# 2)	14x25
20	Nails	-	State Standard TUCT 4028-48	5x125
21	Eye bolts	6	St.3 (# 12)	M12x1.75; L = 100

Ref. No.	Description	Quantity	Material	Size, mm
1	Bars	3	Pinewood	100x150x1075
2	Same	3	Same	100x100x1050
3	Same	6	Same	30x170x700
4	Corner plates	4	Veneer (δ = 10 mm)	280x280
5	Bars	2	Pinewood	60x25x100
6	Gaskets	4	Commercial felt State Standard TUCT 6418-52	10x100x100
7	Bars	2	Pinewood	150x160x4300
8	Blocks	8	Same	60x140x300
9	Corner plates	4	Veneer (δ = 10 mm)	300x330
10	Nails	-	State Standard TUCT 4028-48	5x175
11	Same	-	State Standard TUCT 4028-48	5x150
12	Cover	1	Canvas, type MIL-1, article 383 State Standard TUCT 351-41	
13	Nails for tar paper	-	State Standard TUCT 4028-48	2x25
14	Corner plates	2	Veneer	10x280x80
15	Planks	2	Same	5x30x11,000
16	Bar	1	Pinewood	100x100x3400
17	Gaskets	12	Commercial felt State Standard TUCT 6418-52	10x100x350

SECRET

NO FOREIGN DISSEM

**SECRET**

**NO FOREIGN DISSEM**



50X1-HUM

— 266 —

— 267 —




FIG. 144. CHASSIS PACKING FOR DUCT AND LOWER PART OF HACHELLE

Ref. No.	Description	Quantity	Material	Size, mm
1	Braces	2	Pinewood	40x80x950
2	Blocks	2	Same	150x150x550
3	Stands	4	Same	80x80x900
4	Blocks	4	Same	100x120x2400
5	Same	8	Same	80x100x150
6	Boards	8	Same	80x40x950
7	Braces	8	Same	80x100x1300
8	Stands	4	Same	80x100x1670
9	Cover	1	Canvas, type ANN-1, article 383 State Standard FOOT 351-41	
10	Ruts	4	St.3 (ex 22)	110x1.5; L = 8
11	Washers	4	St.5 (n 2)	12x24
12	Blocks	2	Pinewood	100x120x2400
13	Bolts	4	St.3 (n 17)	110x1.5; L = 220
14	Boards	2	Pinewood	30x250x2400
15	Eye bolts	4	St.3 (n 16)	L = 275
16	Ruts	4	St.3 (ex 27)	116x2
17	Washers	4	St.5 (n 3)	18x34
18	Boards	2	Pinewood	40x100x2480
19	Covering		Commercial felt (δ = 10 mm) State Standard FOOT 6418-52	0.3 sq.m.
20	Covering		Sackcloth	0.6 sq.m.
21	Walls		State Standard FOOT 4028-48	2x40
22	Plank	1	Pinewood	5x30x12,000
23	Walls		State Standard FOOT 4028-48	4x120

**SECRET**  
**NO FOREIGN DISSEM**

NO FOREIGN DISSEM



269 50X1-HUM




FIG. 14A. BOX FOR PACKING FIRST DETACHABLE NOSE OF FIRST DETACHABLE WING PART

Ref. No.	Description	Quantity	Material	Size, mm
1	Support	1	Pinewood	40x70x1500
2	Same	2	Same	40x70x90
3	Boards	28	Same	20x70x1348
4	Same	4	Same	20x70x808
5	Same	4	Same	20x70x748
6	Braces	2	Same	20x70x1050
7	Same	4	Same	20x70x950
8	Boards	6	Same	20x70x788
9	Handles	2	Same	20x70x988
10	Boards	6	Same	20x70x948
11	Braces	4	Same	20x70x1130
12	Boards	12	Same	20x70x900
13	End face walls	2	Veneer	4x70x900
14	Upper wall	1	Same	4x94x1348
15	Side walls	2	Same	4x74x1348
16	Lower wall	1	Same	4x74x1348
17	Tar paper	1	State Standard FOOT 1897-51	6.5 sq. m.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM



50X1-HUM




FIG. 10. 50X1 HUB FRAME SECOND DETACHABLE PART OF FIRST DETACHABLE HUB PART.

Ref. No.	Description	Quantity	Material	Size, mm
1	2	3	4	5
1	Top (shield)	1	Pinewood	20x90x5548
2	Bars	6	Same	30x120x918
3	Support	1	Same	50x60x930
4	Boards	10	Same	20x120x1380
5	Side walls	2	Veneer	4x90x5508
6	Boards	2	Pinewood	20x120x5508
7	Support	1	Same	35x50x930
8	Boards	5	Same	20x120x5508
9	Ruberoid	1	State Standard FOCT 2145-51	8 sq.m.
10	Bars	2	Pinewood	30x70x5508
11	Support	1	Same	30x50x930
12	Covering	1	Commercial felt (δ = 10 mm) State Standard FOCT 6418-52	0.5 sq.m.
13	Covering	1	Beckeloth	0.5 sq.m.
14	Support	1	Pinewood	35x50x930
15	Lower wall	1	Veneer	4x90x5508
16	Planks	2	Veneer	4x30x1018
17	Boards	4	Pinewood	20x120x924
18	Handles	2	Same	20x120x1018
19	Boards	4	Same	20x120x738
20	Planks	2	Veneer	4x30x5556
21	Bruces	10	Pinewood	20x120x1330
22	Boards	12	Same	20x120x1011
23	Nails	4	State Standard FOCT 4028-48	1.4x20; 2.5x50;
24	Support	1	Pinewood	3570
25	Same	1	Same	50x60x930
26	Boards	10	Same	35x50x930
27	End face walls	2	Veneer	20x120x978
28	Boards	6	Pinewood	20x120x978
29	Bruces	5	Same	20x120x1383
30	Planks	12	Veneer	10x30x500
31	Tar paper	1	State Standard FOCT 1887-51	21 sq.m.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM





FIG. 144. BOX FOR PACKING FIRST DETACHABLE NOSE OF SECOND DETACHABLE WING PART


Ref. No.	Description	Quantity	Material	Size, mm
1	2	3	4	5
1	Top (shield)	1	Pinewood	20x680x6738
2	Boards	2	Same	30x70x6698
3	Same	3	Same	20x120x6698
4	Lower wall	1	Veneer	4x530x6698
5	Boards	8	Pinewood	20x120x6698
6	Side walls	2	Veneer	4x79x6698
7	Boards	2	Pinewood	20x120x5778
8	Same	16	Same	20x120x6698
9	Handles	2	Same	20x120x758
10	Boards	8	Same	20x120x678
11	Same	7	Same	20x120x1100
12	Same	8	Same	20x120x530
13	End face walls	2	Veneer	4x630x770
14	Boards	14	Pinewood	20x120x1200
15	Same	4	Same	20x120x438
16	Same	4	Same	20x120x848
17	Support	1	Same	50x70x530
18	Ear	1	Same	50x60x530
19	Support	1	Same	50x70x530
20	Same	1	Same	50x60x530
21	Same	1	Same	50x70x530
22	Same	1	Same	50x60x530
23	Planks	2	Veneer	4x20x778
24	Same	2	Same	4x20x758
25	Same	16	Same	10x30x360
26	Covering	1	Commercial felt (δ = 10 mm) State Standard FOOT 6418-52	0.5 sq.m.
27	Bars	8	Pinewood	30x120x16
28	Rubberoid	1	State Standard FOOT 2165-51	5 sq.m.
29	Tar paper	1	State Standard FOOT 1837-51	22 sq.m.
30	Covering	1	Sackcloth	1 sq.m.
31	Nails	-	State Standard FOOT 4028-48	1.4x20; 2.5x50; 3x70

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



— 275 — 50X1-HUM



Ref. No.	Description	Quantity	Material	Size, mm
1.	2	3	4	5
1	Nails	-	State Standard ГОСТ 4028-48	1.4x20; 2.5x50; 3x70
2	Tar paper	1	State Standard ГОСТ 1827-51	22 sq.m.
3	Boards	3	Pinewood	20x120x5498
4	Lower wall	1	Veneer	4x560x5498
5	Boards	6	Pinewood	20x120x5498
6	Side walls	2	Veneer	4x554x5498
7	Handles	2	Pinewood	20x120x5578
8	Boards	14	Same	20x120x728
9	Same	2	Same	20x120x548
10	Same	7	Same	20x120x508
11	Braces	6	Same	20x120x330
12	Boards	6	Same	20x120x60
13	End face walls	2	Veneer	4x560x530
14	Braces	12	Pinewood	20x120x1060
15	Boards	4	Same	20x120x268
16	Same	4	Same	20x120x708
17	Support	1	Same	50x70x460
18	Same	1	Same	50x60x460
19	Same	1	Same	50x70x460
20	Same	1	Same	50x60x460
21	Same	1	Same	50x70x460
22	Same	1	Same	50x60x460
23	Planks	2	Veneer	4x20x542
24	Same	2	Same	4x20x548
25	Same	14	Pinewood	10x30x275
26	Covering	1	Commercial felt (δ = 10 mm) State Standard ГОСТ 6418-52	0.5 sq.m.
27	Same	1	Sackcloth	0.5 sq.m.
28	Huberoid	1	State Standard ГОСТ 2165-51	5 sq.m.
29	Top (shield)	1	Pinewood	20x510x5538
30	Ears	2	Same	30x70x5498
31	Same	7	Same	30x120x448

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM




FIG. 106. CARCASS PACKING FOR FRONT PRESSURIZED COCCYFIT

Ref. No.	Description	Quantity	Material	Size, mm
1	Plank	1	Pinewood	20x40x16,000
2	Nails	-	State Standard ГОСТ 4028-48	3x40
3	Blocks	6	Pinewood	150x150x150
4	Sense	2	Pinewood	200x150x5500
5	Eye bolts	4	St.3 (# 16)	M16x2, L = 300
6	Nuts	4	St.3 (# 27)	M16x2
7	Washers	4	Steel 20 (# 3)	ø 46/18
8	Blocks	2	Pinewood	150x200x2220
9	Block	1	Sense	100x250x2500
10	Clamps	6	Ready-made part	
11	Wire	-	St.3 (# 3)	L = 21,600
12	Blocks	2	Pinewood	150x200x2500
13	Corner plates	2	Veneer	8x600x500
14	Blocks	2	Pinewood	150x150x2000
15	Sense	2	Sense	150x150x900
16	Sense	1	Sense	100x200x2500
17	Sense	2	Sense	150x150x600
18	Nails	-	State Standard ГОСТ 4028-48	5x175
19	Cover	-	Canvas, type АНУ-11 article 353 State Standard ГОСТ 351-61	
20	Pins	4	St.3 (# 12)	L = 195
21	Nuts	4	St.3 (# 22)	M12x1.75
22	Washers	4	Steel 20 (# 3)	ø 34/12
23	Thrust angle	1	St.3 (100x100x10 mm)	L = 2500
24	Boards	8	Pinewood	20x150x2500
25	Blocks	2	Sense	150x150x600
26	Bolts	6	St.3 (# 14)	M8x1.75; L = 50
27	Covering	-	Commercial felt (δ = 20 mm) State Standard ГОСТ 6418-52	0.5 sq.m.
28	Sense	1	Veneer	4x190x2500
29	Nails	-	State Standard ГОСТ 4028-48	3x40
30	Boards	8	Pinewood	20x150x2500
31	Covering	1	Veneer	4x240x1200
32	Blocks	2	Pinewood	150x150x1500
33	Washers	13	Steel 20 (# 2)	ø 4x14
34	Pins	7	St.3 (# 12)	M12x1.75; L = 150
35	Nuts	13	St.3 (# 22)	M12x1.75
36	Pins	6	St.3 (# 12)	M12x1.75; L = 350
37	Nuts	6	St.3 (# 14)	M8x1.25
38	Washers	6	Steel 20 (# 2)	22x9

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM



278

279

50X1-HUM




FIG. 191. CARCASS PACKING FOR FUELAGE NOSE SECTION

Ref. No.	Description	Quantity	Material	Size, mm
1	Bars	4	Pinewood	120x120x800
2	Corner plates	4	Veneer	5x400x500
3	Bars	4	Pinewood	120x160x2800
4	Same	5	Same	120x120x2700
5	Same	2	Same	150x200x6000
6	Short bars	8	Same	120x120x150
7	Bars	4	Same	120x160x1100
8	Same	2	Same	100x160x950
9	Wire	2	Steel 10 (#3), annealed	L = 40 m.
10	Boards	4	Pinewood	80x120x2700
11	Cover	1	Canvas, type AMI-1, article 38) State Standard IOCT 351-41	
12	Plank	1	Veneer	4x30x18,000
13	Nuts	14	St. 3 (n 27)	M16x2; H = 112
14	Washers	14	Steel 10 (n 3)	17x25
15	Eye bolts	4	St. 3 (n 16)	M16x2; L = 325
16	Bars	4	Pinewood	120x160x1000
17	Same	2	Same	120x160x2700
18	Shields	4	Same	25x500x2700
19	Nails	-	State Standard IOCT 4028-48	1, 4x20; 2, 5x50; 3x70
20	Boards	2	Pinewood	5x150x2700
21	Bars	2	Same	10x160x2700
22	Eye bolts	2	St. 3 (n 16)	M16x2; L = 265
23	Covering	1	Commercial felt (S = 10 mm) State Standard IOCT 6418-52	1 sq. m.
24	Washers	24	Steel 10 (n 2)	17x35
25	Bolts	8	St. 3 (n 14)	M8x1.25; L = 130
26	Gaskets	2	Veneer	6x170x1900
27	Bolts	8	St. 5 (n 14)	M8x1.25; L = 45
28	Nuts	16	St. 5 (n 14)	M8x1.25; L = 6
29	Washers	16	Steel 10 (n 2)	9x20
30	Plugs	2	Veneer	4x2600
31	Bar	1	Pinewood	120x160x2700
32	Band	1	M5 (n 0,8)	12x600
33	Gasket	1	Veneer	6x220x950
34	Covering	1	Backcloth	1, 25 sq. m.
35	Nails	-	State Standard IOCT 4028-48	6x200
36	Bands	4	M5 (n 0,8)	12x1800
37	Eye bolts	2	St. 3 (n 16)	M16x2; L = 275


SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

— 280 —

— 281 —



Ref. No.	Description	Quantity	Material	Size, mm
1	2	3	4	5
1	Wire	2	Steel 10 (P3), annealed	L = 18,000
2	Bars	10	Pinewood	120x160x2720
3	Same	8	Same	120x160x2800
4	Same	4	Same	120x160x2700
5	Same	2	Same	200x250x13,270
6	Same	2	Same	160x200x1600
7	Nails		State Standard	2x40
8	Wire	2	Steel 10 (P3), annealed	L = 30 m.
9	Boards	2	Pinewood	80x150x2700
10	Plug	1	Veneer (δ = 4 mm)	Ø2500
11	Bars	2	Pinewood	120x160x2720
12	Eye bolts	4	St.3 (n 16)	L = 295
13	Coverings	6	Commercial felt (δ = 10 mm) State Standard	300x800
14	Shields	4	Pinewood	25x350x2720
15	Nuts	16	St.3 (n 22)	M12x1.75; H = 10
16	Washers	16	Steel 10 (n 2)	Ø34/18
17	Pins	8	St.3 (n 12)	L = 440
18	Boards	4	Pinewood	15x250x2400
19	Band	1	M16 (n 0.8)	12x7000
20	Plug	1	Veneer (δ = 4 mm)	Ø2250
21	Bolts	16	St.3 (n 16)	L = 360
22	Nuts	66	St.3 (n 27)	M16x2; H = 13
23	Washers	50	Steel 10 (n 2)	35x18
24	Plates	4	St.3 (n 5)	200x500
25	Screw nails	24	State Standard	6x65
26	Cover	1	Canvas, type AMB-1, article 353	9.2x32.8 m.
27	Boards	4	Pinewood	50x150x2720
28	Wire	8	Steel 10 (P3), annealed	19,200
29	Coverings	4	Veneer (δ = 4 mm)	220x800 (two layers)
30	Same	2	Same (δ = 6 mm)	170x2500
31	Same	2	Commercial felt (δ = 6 mm) State Standard	250x2000
32	Covering	1	State Standard	6418-92
33	Bars	4	Sackcloth	2.0 sq.m.
34	Bar	1	Pinewood	100x100x500
35	Board	1	Same	120x150x1000
			Same	80x160x1000

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



1	2	3	4	5
36	Bars	2	Same	
37	Same	2	Same	120x120x3500
38	Same	4	Same	120x160x2720
39	Pipes	1	Same	160x160x1000
40	Welds	1	Same	15x30x40,000
41	Bolts	-	State Standard FOOT 4028-85	5x150
42	Eye bolts	4	St. 3 (n 14)	MExl. 25; L = 130
43	Same	4	St. 3 (n 16)	L = 375
44	Pins	4	St. 3 (n 16)	L = 275
45	Bolts	4	St. 3 (n 16)	L = 310
46	Nuts	8	St. 3 (n 14)	S = 45
47	Washers	12	St. 3 (n 14)	MExl. 25; H = 6,5
		12	Steel 10 (n 1,5,	20x9

50X1-HUM




FIG. 153. CARCASS PACKING FOR REAR PRESSURIZED COCKPIT

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

Ref. No.	Description	Quantity	Material	Size, mm
1	Cover	1	Canvas, type ANH-1, article 383 State Standard FOCT 351-41	
2	Bolts	6	St. 3 (n 11)	M6x1; L = 25
3	Planks	2	St. 3 (n 6)	180x190
4	Wire	-	Steel 10 (#3), annealed	L = 75,000
5	Bars	6	Pinewood	80x100x1050
6	Same	2	Same	80x100x1000
7	Same	2	Same	120x150x2250
8	Same	4	Same	80x100x150
9	Same	2	Same	150x200x9000
10	Plank	1	Same	10x30x12,500
11	Nails	-	State Standard FOCT 4028-48	2x25
12	Eye bolts	17	St. 3 (n 12)	M12x1.75; L = 207
13	Nuts	6	St. 3 (n 22)	M12x1.75
14	Washers	6	St. 3 (n 3)	14x34
15	Gasket	1	Commercial felt (δ = 10 mm) State Standard FOCT 6418-52	200x2500
16	Sheet	1	Veneer (δ = 5 mm)	120x2430
17	Nails	-	State Standard FOCT 4028-48	2x30
18	Boards	12	Pinewood	40x150x2000
19	Blocks	2	Same	80x100x1100
20	Same	2	Same	80x100x500
21	Boards	2	Pinewood	40x150x1700
22	Blocks	2	Same	80x100x400
23	Base	1	St. 3	8x150x2250
24	Channel	1	St. 3 (No. 10)	L = 2250
25	Pin	4	St. 3 (n 16)	M16x2; L = 220
26	Nuts	8	St. 5 (n 27)	M16x2
27	Washers	8	St. 3 (n 3)	18x34
28	Gasket	1	Commercial felt (δ = 10 mm) State Standard FOCT 6418-52	200x1800
29	Sheet	1	Veneer (δ = 5 mm)	120x1700
30	Block	1	Pinewood	120x150x2250
31	Gaskets	2	Veneer (δ = 5 mm)	120x150
32	Bolts	8	St. 3 (n 16)	M8x1.25; L = 45
33	Nuts	8	St. 5 (n 14)	M8x1.25
34	Washers	8	St. 3 (n 1.5)	9x18
35	Plate	1	St. 3	8x200x1100





FIG. 154. CARCASS PACKING FOR FIRST DETACHABLE WING PART

SECRET  
NO FOREIGN DISSEM



NO FOREIGN DISSEM



266

287

50X1-HUM

Ref. No.	Description	Quantity	Material	Size, mm
1	Cover	1	Canvas, type ANJ-1, article 303, State Standard FOCT 351-81	910x11,000
2	Channels	2	St. 3 (No. 14)	L = 1280
3	Same	2	St. 3 (No. 14)	L = 1534
4	Corner plates	2	St. 3 (No. 8)	350x350
5	Channels	2	St. 3 (No. 14)	L = 1000
6	Same	1	St. 3 (No. 14)	L = 1650
7	Plate	1	St. 3 (No. 6)	130x1650
8	Gasket	1	Rubber, grade 3826 (Specifications 77 MM 1166-89 and 838-89)	3x130x1650
9	Plate	1	St. 3	20x60x230
10	Plank	1	Veneer	4x30x20,000
11	Channels	2	St. 3 (No. 14)	L = 1560
12	Same	2	St. 3 (No. 14)	L = 1534
13	Nails	-	State Standard FOCT #028-88	5x175
14	Washers	30	Steel 10 (No. 3)	17x30
15	Pins	12	St. 5 (No. 16)	M16x2; L = 260
16	Same	14	St. 5 (No. 16)	M16x2; L = 370
17	Bars	2	Pinewood	200x250x6000
18	Channel	1	St. 3 (No. 14)	L = 1650
19	Plate	1	St. 3 (No. 2)	130x1650
20	Gasket	1	Rubber, grade 3826 (Specifications 77 MM 1166-89 and 838-89)	3x130x1650
21	Plates	2	St. 3 (No. 8)	90x100
22	Eye	2	St. 3	20x60x100
23	Wire	1	Steel 10 (No. 3)	L = 50 m.
24	Channels	2	St. 3 (No. 14)	L = 1670
25	Same	2	St. 3 (No. 14)	L = 2160
26	Bars	3	Pinewood	120x150x1800
27	Boards	4	Same	60x250x1800
28	Plate	1	St. 3	20x60x244
29	Same	1	St. 3 (No. 8)	130x1650
30	Channel	1	St. 3 (No. 14)	L = 1650
31	Gasket	1	Rubber, grade 3826 (Specifications 77 MM 1166-89 and 838-89)	3x130x1650
32	Nuts	57	St. 3 (No. 27)	M16x2; L = 12
33	Bolt	1	St. 3 (No. 27)	M16x2; d = 16; L = 85
34	Same	1	St. 3 (No. 32)	M20x2.5; d = 22; L = 85
35	Nut	1	St. 3 (No. 32)	M20x2.5; L = 16

1	2	3	4	5
36	Bolts	2	St. 3 (No. 27)	M16x2; L = 65; d = 16
37	Same	12	St. 3 (No. 27)	M16x2; L = 50; d = 16
38	Same	2	St. 3 (No. 27)	M16x2; L = 65; d = 16
39	Same	2	St. 3 (No. 22)	M12x1.75; L = 55; d = 14
40	Nuts	2	St. 3 (No. 22)	M12x1.75; L = 10

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM




FIG. 133. CARCASS PACKING FOR SECOND DETACHABLE WING PART

Ref. No.	Description	Quantity	Material	Size, mm
1	Pins	3	St. 3 (x 12)	H12x1.75; L = 210
2	Planks	1	Pinewood	10x40x26,400
3	Block	1		120x160x2100
4	Wire	1	Steel 10 (#3), annealed	L = 6000
5	Block	1	Pinewood	200x200x2100
6	Wire	1	Steel 10 (#3), annealed	L = 28,000
7	Blocks	3	Pinewood	150x150x2100
8	Saws	2		200x250x11,100
9	Boards	4	Sawn	50x250x3350
10	Blocks	4	Sawn	100x100x2700
11	Saws	3	Sawn	160x160x3000
12	Saws	2	Sawn	50x250x2100
13	Nails	-	State Standard ГОСТ 4028-68	5x175
14	Cover	-	Canvas, type АИВ-1, article 35 State Standard ГСОТ 351-41	
15	Pins	8	St. 3 (x 12)	H12x1.75; L = 440
16	Eye bolts	2	St. 3 (x 12)	H12x1.75; L = 175
17	Boards	4	Pinewood	50x150x210
18	Blocks	2	Sawn	120x160x340
19	Pins	4	St. 3 (x 14)	H14x2; L = 240
20	Nuts	8	St. 5 (x 22)	H14x2
21	Pins	4	St. 3 (x 20)	H20x2.5; L = 240
22	Nuts	16	St. 5 (x 32)	H20x2.5
23	Eye bolts	6	St. 3 (x 12)	H12x1.75; L = 200
24	Nuts	19	St. 5 (x 22)	H12x1.75
25	Washers	26	St. 5 (x 2 mm)	14x28
26	Bolts	4	St. 3 (x 26)	H14x2; L = 70
27	Saws	4	St. 3 (x 38)	H20x2.5; L = 65
28	Plate	1	St. 3 (x 8)	200x2100
29	Channel	1	St. 3 (No. 12)	L = 2100
30	Pins	4	St. 3 (x 12)	H12x1.75; L = 460
31	Covering	1	Commercial felt (δ = 8 mm) State Standard ГСОТ 6418-52	1 sq.m.
32	Coverings	2	Veneer (δ = 5 mm)	H12x160x1700
33	Block	1	Pinewood	50x150x2100
34	Boards	10	Sawn	4x100
35	Nails	-	State Standard ГОСТ 4028-68	
36	Covering	1	Beckcloth	15 sq.m.

SECRET

NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM



50X1-HUM




FIG. 13A. CARCASS PACKING FOR STABILIZER

Ref. No.	Description	Quantity	Material	Size, mm
1	Block	1	Pinewood	60x120x1650
2	Pin	16	St.3 (x 12)	L = 350
3	Washers	32	Steel 20 (x 3)	3x2x4
4	Nuts	16	St.3	M12x1.75
5	Blocks	2	Pinewood	100x200x1650
6	Same	2	Same	150x120x2000
7	Same	8	Same	50x100x120
8	Same	2	Same	120x150x1100
9	Corner plates	2	Veneer	8x300x300
10	Blocks	2	Pinewood	100x100x1300
11	Same	2	Same	100x100x850
12	Block	1	Same	60x120x1650
13	Same	2	Same	150x150x1650
14	Same	2	Same	150x200x8800
15	Corner plates	2	Veneer	5x400x350
16	Bolts	8	St.5 (x 30)	L = 220
17	Nuts	22	St.3	M12x1.75
18	Washers	22	Steel 20 (x 3)	93x/14
19	Bolts	16	St.5 (x 20)	L = 150
20	Nuts	16	St.3	M10x1.5
21	Washers	16	Steel 20 (x 3)	28x12
22	Coverings	4	Veneer	5x190
23	Same	1	Beckcloth	2.5 sq.m.
24	Same	1	Commercial felt (δ = 10 cm) State Standard TOCT 6413-52	2 sq.m.
25	Supports	6	Pinewood	40x150x1650
26	Blocks	3	Same	120x150x1650
27	Supports	2	Same	40x150x1650
28	Block	1	Same	150x150x1650
29	Rye bolts	12	St.3	M12x1.75; L = 175
30	Wire	1	Steel 10 (x 6), annealed	
31	Blocks	4	Pinewood	80x100x1650
32	Same	4	Same	100x100x1000
33	Cover	1	Canvas, type AN-1, article 381 State Standard TOCT 351-A1	
34	Blocks	8	Pinewood	50x100x120
35	Same	2	Same	120x150x2100

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 17. CARCASS PACKING FOR PIN

Ref. No.	Description	Quantity	Material	Size, mm
1	Bars	2	Pinewood	100x120x1980
2	Boards	10	Same	20x150x3000
3	Bolts	2	St. 3 (n 27)	M16x2; L = 65
4	Angles	8	St. 3 (75x75x8)	L = 120
5	Flock	1	Pinewood	100x150x200
6	Same	2	Same	100x100x2700
7	Same	2	Same	10x120x2400
8	Fins	16	St. 3 (n 12)	M12x1.75; L = 175
9	Cover pattern	1	Canvas, type AUM-1, article 38, State Standard TOCT 351-41	L = 8
10	Bushes	8	M20 (n 30)	18x35
11	Washers	16	AR (n 2)	100x100x800
12	Bars	2	Veneer	6x250x250
13	Corner plates	4	Pinewood	120x120x550
14	Bars	2	Same	100x100x500
15	Same	5	State Standard TOCT 4028-48	3x50; 5x175
16	Nails	1 kg	Commercial felt (δ = 10 mm) State Standard TOCT 6418-52	0.5 sq.m.
17	Covering	1	Same	0.5 sq.m.
18	Same	1	Veneer	5x160x500
19	Gaskets	2	St. 3 (n 27)	M16x2; L = 60
20	Bolts	2	St. 3 (n 27)	M16x2; L = 12
21	Nuts	4	St. 3 (n 8)	120x120
22	Plates	8	Pinewood	100x120x350
23	Bars	2	St. 5 (n 12)	M12x1.75; L = 250
24	Eye bolts	4	St. 5 (n 22)	M12x1.75; L = 10
25	Nuts	24	Steel 10 (P3), annealed	12x25
26	Wire	1	Pinewood	120x120x300
27	Washers	24	Same	100x100x1000
28	Bars	2	Same	180x160x550
29	Same	4	Same	M12x1.75; L = 265
30	Same	2	Pinewood	100x120x300
31	Eye bolts	4	St. 5 (n 12)	
32	Bar	1	Pinewood	

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

- 294 -

- 295 -




FIG. 14. CARCASS PACKING FOR LANDING GEAR NOSE LEG

Ref. No.	Description	Quantity	Material	Size, mm
1	Cross-beams	3	Pinewood	120x150x1000
2	Longitudinal bars	2	Same	120x150x2500
3	Stands	2	Same	120x120x750
4	Blocks	3	Same	80x100x1000
5	Gaskets	3	Commercial felt State Standard FOCT 6418-52	10x90x560
6	Blocks	2	Pinewood	60x80x120
7	Braces	4	Same	100x120x500
8	Stands	2	Same	120x150x1000
9	Nails	-	State Standard FOCT 4028-48	5x175
10	Cover	1	Canvas, type 417-1, article 33 State Standard FOCT 351-41	
11	Plank	1	Vanzer	5x30x2400
12	Eye bolts	2	St. 3 (x 12)	412x1.75; L = 100
13	Nuts	2	St. 3	412x1.75
14	Washers	2	St. 3 (x 2)	14x25
15	Nails	-	State Standard FOCT 4028-48	2x40
16	Bracing wire ropes	2	Steel 10 (#3), annealed	L = 9000
17	Covering		Seckcloth	0.05 sq.m.
18	Nails		State Standard FOCT 4028-48	2x30
19	Support	1	Pinewood	75x120x225

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM



50X1-HUM

296

297





FIG. 18. CARCASS PACKING FOR LANDING GEAR MAIN LEG BOGEY

Ref. No.	Description	Quantity	Material	Size, mm
1	Cover	1	Canvas, type AUI-1, article 383 State Standard FOOT 351-41	3600x800
2	Blocks	2	Pinewood	150x200x2400
3	Wire	1	Steel 10 (P3), annealed	L = 118,000
4	Blocks	4	Pinewood	150x200x1200
5	Gaskets	2	Commercial felt State Standard FOOT 6018-52	10x50x560
6	Plank	1	Pinewood	5x30x2200
7	Nails for tar paper	-	State Standard FOOT 4009-48	2x40
8	Nails	-	State Standard FOOT 4028-48	6x200

SECRET

NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM

299




FIG. 14A. CARCASS PACKING FOR LANDING GEAR MAIN LEG STRUTS

Ref. No.	Description	Quantity	Material	Size, mm
1	Bars	4	Pinewood	150x160x1200
2	Boards	3	Bams	80x120x1000
3	Wire	1	Steel 10 (n 3), annealed	70 m.
4	Pins	48	St. 5 (n 12)	M12x1.75; L = 290
5	Washers	96	Steel 20 (n 2)	3x14
6	Nuts	96	St. 3 (n 22)	M12x1.75
7	Boards	4	Pinewood	100x240x1000
8	Blocks	4	Bams	50x100x100
9	Eye bolts	14	St. 3 (n 12)	L = 175
10	Washers	14	Steel 20 (n 2)	3x14
11	Nuts	14	St. 3 (n 77)	M12x1.75
12	Blocks	4	Pinewood	50x100x100
13	Boards	26	Bams	20x100x1000
14	Nails	-	State Standard FOCT 4028-48	5x175
15	Blocks	2	Pinewood	150x200x1000
16	Cover	1	Canvas, type A12-1, article 383 State Standard FOCT 351-41	
17	Plank	1	Veneer	5x30x7400
18	Nails	-	State Standard FOCT 4028-48	2x25
19	Gasket	1	Commercial felt (δ = 10 mm) State Standard FOCT 6418-52	120x5000
20	Nails	-	State Standard FOCT 4028-48	2x25
21	Boards	4	Pinewood	60x100x550
22	Bars	2	Bams	150x200x2700

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 161. CONTAINER WITH HOISTING DEVICE  
1 - cables 2 - lifting eyes 3 - hoisting ring 4 - snap hook.




FIG. 162. LOADING CONTAINER ON SLEDGE BY MEANS OF TRACTOR.  
1 - sleds 2 - wheels 3 - rollers 4 - cables 5 - hoisting eye.

FIG. 163. LOADING UNIT IN CARGO PACKING ON PLAT CAR BY MEANS OF TRACTOR.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM



50X1-HUM

— 302 —




FIG. 164. LOADING UNIT IN CARCASS PACKING BY MEANS OF CRANE  
1 - frame; 2 - plates; 3 - cables; 4 - clasp; 5 - cables; 6 - shackles.




FIG. 165. PLACING TAIL SECTION IN CARCASS PACKING (COVER IS NOT SHOWN) ON FOUR-AXLE FLAT CAR AND SECURING IT IN POSITION  
1 - blocks; 2 - bracing wire rope.

— 303 —




FIG. 166. TRANSPORTING PACKED UNIT BY TRUCK




FIG. 167. TRANSPORTING PACKED UNIT BY SLEDGE

SECRET  
NO FOREIGN DISSEM

~~SECRET~~  
~~NO FOREIGN DISSEM~~



50X1-HUM

— 304 —

~~SECRET~~  
~~NO FOREIGN DISSEM~~

Declassified in Part - Sanitized Copy Approved for Release 2013/02/21 : CIA-RDP80T00246A070800100001-4

**SECRET**  
NO FOREIGN DISSEM

50X1-HUM

**SECRET**  
NO FOREIGN DISSEM

Declassified in Part - Sanitized Copy Approved for Release 2013/02/21 : CIA-RDP80T00246A070800100001-4

Declassified in Part - Sanitized Copy Approved for Release 2013/02/21 : CIA-RDP80T00246A070800100001-4

**SECRET**  
NO FOREIGN DISSEM



50X1-HUM

TU-16 AIRCRAFT  
TECHNICAL DESCRIPTION  
Book II  
BOMBING EQUIPMENT

GROUP 1  
Excluded from automatic  
downgrading and  
declassification

**SECRET**  
NO FOREIGN DISSEM

Declassified in Part - Sanitized Copy Approved for Release 2013/02/21 : CIA-RDP80T00246A070800100001-4

SECRET

NO FOREIGN DISSEM

50X1-HUM

**Ty-16 AIRCRAFT  
TECHNICAL DESCRIPTION**

**Book II**

**BOMBING EQUIPMENT**

SECRET

NO FOREIGN DISSEM

**SECRET**  
**NO FOREIGN DISSEM**



50X1-HUM

**Ty-16 AIRCRAFT**  
**TECHNICAL DESCRIPTION**


**Book II**

**Part 2**  
**BOMBING EQUIPMENT**

**SECRET**  
**NO FOREIGN DISSEM**

SECRET

NO FOREIGN DISSEM



50X1-HUM

CONTENTS

Chapter I. <u>General</u> .....	Page
Chapter II. <u>Instruments and Assemblies of Bombing</u>	5.
<u>Equipment</u> .....	14
Location of Control Instruments .....	14
Detachable Equipment .....	16
Description of Assemblies .....	17
Description of Instruments .....	32
Chapter III. <u>Door Control System</u> .....	40
Bomb-Bay Door Control System .....	40
Control System of Doors of Compartment	
for Communication and Signalling Equipment ..	56
Chapter IV. <u>Hoisting System</u> .....	60
EJL-473M Electromechanical Hoist System.....	61
Hoisting Beam .....	65
Movable Blocks .....	66
Two-Sheave End Blocks .....	66
Single-Sheave End Blocks .....	67
Hoisting Frame .....	67
Twin Guy for Hoisting $\Phi$ AE-3000 Bombs .....	67
Guides for Hoisting $\Phi$ AE-250 Bombs .....	67
HK3-53 Hoisting Hook .....	68
Bomb Hoisting Sling .....	68
Hoisting Sling Cables .....	68
Sheave Blocks to Hoist Bomb Racks .....	69
Mounting Bracket for EJL-473M Hoist .....	69

The Book contains 124 pages and 68 figures on 26 sheets.

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

	Page
<b>Chapter V. <u>Installation of Bomb Racks and Bomb</u></b>	
<u>Hoisting</u> .....	70
Installation of Bomb Racks .....	71
Hoisting Bombs to KJ-3 Bomb Rack .....	71
Hoisting Bombs to KJ-4 Bomb Rack .....	73
Equipment Installation and Stowing Ready for Changing the Base .....	74
Ground Set of Bombing Equipment .....	76
<b>Chapter VI. <u>Fuze Arming System</u></b> .....	77
Fuze Arming Wire .....	77
<b>Chapter VII. <u>Bombing Equipment Electrical Control</u></b>	
<u>System</u> .....	81
Bombing Equipment Electrical Wiring .....	91
Circuitry .....	93
<b>Chapter VIII. <u>Bonding of Bomb Equipment Units</u></b> .....	122

**Chapter I**  
**GENERAL**

The TV-16 aircraft is a high-speed long-range heavy jet bomber designed for bombing enemy strategic objects. For suspending and dropping bombs the aircraft has standard bombing equipment manufactured in accordance with the Specifications of the aircraft armament. For the purpose of bomb loading and dropping the aircraft is equipped with hoisting devices, bomb racks, actuating and interlock mechanisms of bomb release, bombsight, bomb release control instruments, and means of signalling and communication.

The OHE-11p bombsight, release control mechanisms, as well as a number of actuating and interlock mechanisms are mounted in the front pressurized cabin (See Fig. 1) within an easy reach of the navigator, the pilot and the navigator-operator.

The suspension devices, bomb racks, hoisting beams, bomb hoisting system and the bulk of actuating and interlock mechanisms are mounted in the bomb bay (See Fig. 2). The bomb bay is located in the fuselage between frames Nos 33 and 49. The aircraft is not equipped with means of external bomb suspension. The bombs are suspended from the fuselage bomb racks, groups 3 and 4, secured to the bomb bay sides. The set incorporates six group 3 racks KJ 3-488 with shackles Dep 3-48 and four group 4 racks KJ4-388 with shackles Dep 4-49.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM

The above racks serve to carry and drop bombs weighing from 250 to 3000 kg.

Table 1

Estimation of Aircraft Bomb Load

Nos	Bomb designation	Maximum number of bombs per aircraft
1	ΦAB-100 HB	24
2	ΦAB-250 M46	24
3	ΦAB-500 M46	18
4	ΦAB-3000 M46	2
5	3AB-100-114	24
6	CAE-100-90	16
7	ΦOTAB-100-80	24

There are 12 attachment assemblies on the beam and 12 attachment assemblies on the fuselage top booms for mounting the bomb racks in the bomb bay. The assemblies on the beams serve to secure the racks at the bottom while those on the booms serve to attach them at the top.

In addition to the above lightened attachment assemblies are provided for putting the racks in the stowed position.

Table 2

Combat and Stowed Positions of Bomb Racks

Nos	Combat position		Stowed position	
	Bomb suspension variants	type of bomb rack installed	Bomb rack row No.	type of attachment bomb rack assembly installed
1	1 and 2	KJ3	1	B and 14
			2	
			3	
			4	
2	4	KJ4	1 and 2	1 and 2
			6 and 8	
			11 and 12	
			5 and 7	
3	KJ3	KJ3	1	3 and 4
			2	
			3	
			4	
4	KJ4	KJ4	10 and 12	10 and 12
			5	
			B and 13	
			B and 13	

Note: The bomb racks which are put neither in the combat nor in the stowed positions are to be kept as detachable equipment.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




Table 3

Bomb Load Variants

Variant No.	Type of bomb rack	Number of bomb racks	Attachment assembly No.			Calibre and type of bombs on the racks	Number of bombs per row	Total weight of bombs loaded, kg
			1st row	2nd row	3rd row			
1	KJ3-488	2	1 and 2	11 and 12	CAE-100-90	8	1152	
			3	1 and 8	11 and 12	ΦOTAB-100-80	8	1920
			3	1 and 8	11 and 12	ΦAB-250 M46	8	5280
2	KJ3-488	3	1 and 2	6 and 8	11 and 12	ΦAB-500 M46	6	7713
			1	5 and 7	ΦAB-3000 M46	2	5966	

- 9 - 50X1-HUM

When fixed in the stowed position to the attachment assemblies of the rear row, the right-hand rack is mounted on the port side while the left-hand rack is installed on the starboard side. Hoisting of bomb racks is effected by the hoists, type БИ-47 3M. All the bomb racks of the same pattern are easy to detach or interchange.

In accordance with the given bomb load variants the KJ3-488 and KJ4-388 bomb racks can be mounted in one, two or three rows.

The attachment assemblies in the bomb bay provide for the following bomb load variants:

- Six four-shackle KJ3-488 bomb racks with the Дep 3-48 shackles to carry the following bombs: ΦOTAB-100-80, ΦAB-250 M46, ΦAB-500 M46; ΦOTAB and CAE-100-90.
- Two KJ4-388 bomb racks with the Дep 4-49 shackles to carry ΦAB-3000 bombs.

Bombs are hoisted to the bomb racks by means of БИ-47 3M electric hoists.

Bombs up to 250 kg can be lifted with one hoist; those from 500 to 3000 kg, with two hoists.

To hoist bombs and bomb racks the hoists are attached to the brackets installed on the bomb door butt ends. With bombs loaded in accordance with the bomb load variants, the bomb-bay dimensions provide a safety angle of bomb exit equal to 10° (See Fig. 3), the smallest clearance between the suspended bombs and the closed bomb-bay doors amounting to 30 mm and over. The clear openings of the bomb bay without and with the bomb racks mounted are 6674.5x1632 and 6674.5x1330 mm respectively.

The ONE-11p bombsight connected with the АИ-5-2M automatic pilot system and the РБИ-4 radar bombsight provides for bombing under any weather conditions (day or night).

The ONE-11p bombsight is used for sighting and releasing bombs in level flight at moving and stationary targets with an arbitrary approach to the target. When the target is visible,

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

the sighting is done with the assistance of the telescopic and collimator optical systems. When the target is not visible, use is made of the PBI-4 radar sight, sighting being effected relative to the image on the radar cathode-ray tube screen with the application of the sight computing mechanisms.

The aircraft has an electrical remote bomb release control system with combat and emergency circuits.

The combat bomb release control system has an independent electric wiring with terminals in the bomb rack actuating mechanisms.

The emergency bomb release control system, in its turn, can be divided into two types:

(a) emergency release with power supplied from the mains of the aircraft;

(b) emergency release with the mains of the aircraft de-energized, in which case power is supplied from the storage battery mounted in the aircraft.

Each type of emergency release control system has an independent electric wiring.

Table 4

Bomb Equipment Weight in Maximum-Range Flight with Bomb Load of 3000 kg (assumed for calculations)

Nos	Description of bomb equipment	Number of unit required	Weight of unit, kg	Bomb equipment weight on the ground, in flight, kg	Bomb equipment max. weight in flight, kg
1	2	3	4	5	6
1	ΦAB-250 suspended from KИ3-488 bomb rack	12	-	244.2	205.6
	(a) KИ3-488	4	42	168	168

1	2	3	4	5	6
	(b) shackles	12	3	36	36
	(c) hoists	2	19.2	38.4	
	(d) attachment bolts	8	0.2	1.6	1.6
2	ΦAB-500 suspended from KИ3-488 bomb rack	6		144.2	96.8
	(a) KИ3-488	2	42	84	84
	(b) shackles	4	3	12	12
	(c) hoists	2	19.2	38.4	
	(d) hoisting beam	1	9.0	9.0	
	(e) attachment bolts	4	0.2	0.8	0.8
3	ΦAB-3000 suspended from KИ4-388 bomb rack	1	-	220.95	87.05
	(a) KИ4-388 bomb rack	2	77.5	155	77.5
	(b) shackle	1	8.75	8.75	8.75
	(c) hoists	2	19.2	38.4	
	(d) hoisting beams	2	9.0	18.0	
	(e) attachment bolts	4	0.2	0.8	0.8

x) The bomb is suspended from one KИ4-388 bomb rack of the starboard side (attachment assemblies 5 and 7).

The combat bomb release control system is the principal one. Together with the bombsight, intervalometer and rack selector it makes the choice of train and interval.

The combat bomb release is ARMED only.

Bombs are released in train, one or two bombs per salvo,

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 12 -

depending on the position of the switch on the bottom bomb release panel, or selectively (non-automatic), one or two bombs per salvo.

The linear interval (spacing) between the bombs at combat release can be set on the 3CEP-49A electric intervalometer from 3.5 m. to 3.6 km. (ground speed ranging from 300 to 1300 km/hr).

The emergency release control provides for ARMED and SAFE release with electric power supplied from the aircraft mains, as well as from the battery.

In emergency bomb release all the bombs fall almost simultaneously, vertical interlocking of bomb shackle release units making the bombs fall from the KR3 bomb rack in succession of the stations starting with the bottom station as indicated in Figs 3 and 4. On the other hand, bomb release from the KR4 bomb rack is also performed almost simultaneously, but the succession is: from side to side, one bomb from each row.

In view of possible bomb collisions along the trajectory the combat release (or emergency ARMED release) of bombs with fuzes having no delayed cocking is forbidden.

The bombs can be released by the following crew members.

The N A V I G A T O R, who can perform:

- (a) combat release through the bombsight;
- (b) combat release by the KCE-49 bomb release button and the bombsight;
- (c) emergency armed and unarmed release by the switch on the bomb release control panel.

The P I L O T, who can perform:

- (a) emergency ARMED or SAFE release by the emergency bomb release switch and the ARMED-SAFE selector on the pilot's instrument board;
- (b) emergency ARMED or SAFE release from the bomb release control panel, with the mains being de-energized, and power supplied from the battery.

- 13 - 50X1-HUM

The NAVIGATOR-OPERATOR, who can perform:

Combat release by the KCE-49 bomb release button, in which case all the bombing data are determined by the navigator.

The sequence of releasing bombs, the bomb stations on the racks and the connection of bomb racks to the plug connectors are shown in Fig. 4.

Bomb release in pairs does not alter the release sequence (the indicated order being always preserved): bombs 1 and 2 will be dropped first, bombs 3 and 4 after them.

Nose and base fuzes are controlled mechanically. The aircraft has two sets of fuze arming rods, type VBII, designed for locking fuzes of vane and arming-pin type, as well as fuzes with the MUB delayed cocking mechanisms.

The electric hoists are controlled from a special portable panel which is incorporated in the set of the TCVI (the trolley of the hoist control system) ground equipment.

The mechanism opening and closing the bomb-bay doors has an electrical remote control system subdivided into normal, stand-by and emergency. The drive for opening and closing the bomb-bay doors is fed from the main and brake hydraulic systems. Moreover, provision is made for a mechanical opening of the bomb-bay doors with the help of a spring. The hydraulic system is duplicated by the mechanical bomb-bay door control system which guarantees the opening of the bomb-bay doors in any case.

The normal opening and closing of bomb-bay doors is accomplished by the navigator through the main control system. In the stand-by control system the bomb-bay doors are opened by the navigator and closed by the pilot. The emergency opening of the bomb doors as resulting from the emergency bomb release is effected by the navigator and the pilot.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 15 - 50X1-HUM

## Chapter II

INSTRUMENTS AND ASSEMBLIES  
OF BOMBING EQUIPMENTLocation of Control Instruments

All control instruments of the bombing equipment are located within an easy reach of the crew in the front pressurized cabin, as shown in Fig.1.

Navigator's Compartment

1. The ONE-11p optical bombsight is mounted on the autopilot course stabilizer.
2. Navigator's left-hand panel (Fig.5) is mounted on the port side of the aircraft between frames Nos 2 and 5. The panel comprises the bomb release control panel, 3CEP-49A intervalometer, bottom bomb release control panel, and navigator's automatic circuit breaker (ASC) panel.

Mounted on the bomb release control panel (Fig.6) are the following items: the station status indicator lights, the П-4 switch to check the indicator lights for proper operation, the BK2-142B button to check the presence of bombs (with the bomb-bay doors closed), the READY (POTOB) signal light, the B-45 emergency bomb release switch, the B-45 emergency ARMED (B3PFB) switch, the B-45 switch of the rear KИ3 bomb racks disengagement relay.

Mounted on the intervalometer are the indicator light of power supply to the 3CEP-49A intervalometer, METRE and KILOMETRE circuit switch, TRAIN (СЕРИЯ) and SELECTIVE (ОДНОВОЧНО) switch, interval knob, handle of bombs to be released or salvos, mounted on the bottom bomb release control panel (Fig. 7) are two 2B-45 relay switches 1 of the bomb release variant box and the B-45 salvo switch.

The navigator's automatic circuit breaker panel (Fig. 8) comprises the bombing equipment circuit breakers.

3. The navigator's right-hand control panel is mounted on the starboard side of the aircraft between frames Nos 2 and 4. The panel consists of the bomb door control panel and the navigator's circuit breaker panel.

Installed on the bomb-bay door control panel (Fig. 9) are the ПН-45 bomb door control switch, the CИИ-51 bomb door position indicator lights, the 2B-45 master bombing switch, the ARMED (B3PFB) position indicator light, the BH-45 bomb door stand-by control switch.

Installed at the top of the navigator's right-hand control panel is the automatic circuit breaker panel (Fig. 10).

The KCE-49 bomb release button is mounted on frame No. 2 above the navigator's right-hand control panel.

Pilot's Station

1. Mounted on the instrument board (Fig. 11) are the B-45 emergency ARMED (B3PFB) release switch, ARMED indicator light, navigator's B-45 emergency bomb release and ARMED circuit interlock switch.

The emergency bomb release control panel operating with the system being de-energized is mounted next to the engines starting box, at frame No.8. Installed on the panel are the B-45 ARMED (B3PFB) -SAFE (HEB3PFB) switch and the handle which opens the bomb-bay doors and releases bombs.

The BH-45 switch to open the bomb-bay doors on the ground

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

- 16 -

when the mains is de-energized is mounted at frame No. 9 next to the emergency bomb release control panel.

2. The BH-45 stand-by switch for closing the bomb-bay doors is mounted on the pilot's hydraulic control panel between frames Nos 6 and 7, along the aircraft axis.

#### N A V I G A T O R - O P E R A T O R ' S C O N T R O L P A N E L

1. The navigator-operator's instrument board (Fig. 13) is mounted on the port side of the aircraft between frames Nos 10 and 11. The KCE-49 bomb release button and the READY TO DROP (ГОТОВ К СБРАЧЬВАНИЮ) indicator light are mounted on the board.

2. The navigator-operator's electrical panel (Fig. 14) is installed on frame No.12, along the aircraft axis, on the navigator-operator's central control panel. Mounted on the electrical panel are the B-45 bomb-bay lighting switch, the A3C-5 circuit breakers of the bomb-bay reflector dipoles and the circuit breakers of the auxiliary compartment reflector dipoles.

#### D e t a c h a b l e E q u i p m e n t

The detachable equipment consists of the suspension equipment and the hoisting equipment.

The suspension equipment includes three right-hand and three left-hand bomb racks КД3-488 with the Дрп 3-48 shackles; two right-hand and two left-hand bomb racks КД4-388 with two right-hand and two left-hand shackles, type Дрп 4-49.

The hoisting equipment consists of four БН-473М electric hoists with cables 20 m. long, four brackets mounting the БН-473М hoists, hoisting frame, two right-hand and two left-hand КД3-547Н guides used for hoisting bombs, four ПК3-53 hoisting hooks, two frames with sheaves, two movable blocks,

- 17 - 50X1-HUM

atwin gwtwo two-sheave end pulleys, two one-sheave end pulleys, hoisting sling 3000; four sheaved blocks to hoist the bomb racks, a hoisting cable, 8 mm in diameter, and 14.8 m. long, a hoisting cable, 8 mm in diameter, and 13.75 m. long.

In addition to the above, the following ground equipment is provided: a service ladder, two catwalks, two trolleys of the ТСУЛ-473 hoist control system, six KV-50 universal keys, two bags for fuze arming rods, 24 devices, type H-116, for checking the Дрп 3-48 shackles, the БТ-500 trolley to carry ФАБ-250 and ФАБ-500 demolition bombs, the ЕТ3-49 trolley to carry ФАБ-3000 demolition bombs.

#### D e s c r i p t i o n o f A s s e m b l i e s

##### КД3-488 B o m b R a c k

The КД3-488 bomb rack (Fig. 15) is provided for carrying and releasing bombs.

The bomb rack is designed for one of the following bomb suspension variants: four bombs of 250-kg calibre or three bombs of 500-kg calibre.

The bomb rack is equipped with the following:  
five electromechanical bomb shackle release units ПБД-48;  
five arming mechanisms MBH-48;  
five interlock switch boxes БК-48М;  
one plug connector ПР28П7НН9.

The bomb rack set includes:

four shackles Дрп 3-48;  
two guides КД3-547Н;  
one key KV-50 to cock the ПБД-48 release unit.

The bomb rack is connected to the bomb release control electric circuit by means of the ПР28П7НН9 plug connector with the plug installed on the bomb rack and the socket on the side of the aircraft.

The bomb release (both combat and emergency) is effected

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 18 -

electromechanically. The bomb rack is furnished with all necessary equipment to ensure bomb release light indication, arming of the fuzes, automatic engagement of the shackle release units and arming mechanisms of respective stations (depending on the bomb load variant), group control of the latches during the bomb rack unloading, and an indication of the closed position of the latches.

The bomb rack consists of two shaped beams connected by means of three cross bars and a metal sheet.

The top and the bottom cross bars have two-sheave blocks each for bomb hoisting. Two tubes guiding the hoist cables are mounted between the bottom and the top sheaves on the back of the bomb rack.

The bottom and the middle cross bars are covered with steel plates, which protect the magnesium cross bars from damage and prevent jamming of the hoist cable. The shackles are held in the bomb rack by means of five pairs of latches mounted on each beam. Each latch unit consists of a catch, a pawl and a stop. The catch and the pawl are set on the same axle and connected by means of a spring. The pawls are interconnected by a linked rod, pivoted at the bottom to the control lever, whose nose rests against the roller of the lever connected to the unloading handle. The MBM-48 release units are mounted on the forward beam, against each group of the latches; the MBH-48 arming mechanisms are mounted on the aft beam, and the BK-48M interlock switch boxes are installed on the sheet. The mechanisms indicating the closed position of the latches are placed inside the beams. Each of them consists of two levers set on the same axle. One lever with a roller rests on the extension of the latch upper stop, the other one carries a signalling pin fixed flush with the beam (with latches being locked). Each beam on the back side of the bomb rack has a bracket, which serves to secure the shackle in the stowed position when the bomb rack is loaded with bombs of 500-kg calibre (when one of the shackles is not used).

- 19 - 50X1-HUM

The latches operate as follows.

When the rack is being loaded the shackle trunnions moving along the bomb rack grooves press against the catches, which turn together with the pawls, and withdraw the upper stops, providing the possibility for the shackle to pass upward. After the shackle trunnions have travelled 6 to 8 mm upward from the suspension axis, the supporting latches return to their working position. When the shackle lowers upon the supporting latches, the upper stops actuated by their springs pass beyond the rail surface thus fixing the shackle. During the loading the control handles of the latches are in their top position and the control rods have no effect on the latches.

During the unloading the latch control handle is brought to its bottom position and the control rods travel downward to turn the latch pawls. The pawls cock the supporting latch springs and press the upper stops to go beyond the rail edge thus permitting to lift the shackle upward. The upward movement of the shackle is limited by the upper stop extensions.

When the shackle is being lifted, the springs cocked by the pawls sink the supporting latches beneath the rail edges thus permitting to lower the shackle.

The bomb rack is secured to the aircraft structure by means of four attachment assemblies located on the back side of the rack.

To install the rack in the aircraft the top pair of pins must be inserted into the holes of the assemblies mounted on the top horizontal beam. To the lower horizontal beam the bomb rack is secured by means of the lower pair of assembly units and easy-to-remove bolts.

KJ3-488 Bomb Rack  
Circuit Diagram

The bomb rack circuit (Fig.16) provides for two independent kinds of bomb release: combat and emergency both ARMED (B3PHB)

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

and SAFE (HEB3PMB).

When the shackles are installed in the bomb racks, the interlock switch box contacts become closed which corresponds to their left-hand position in the diagram.

For the combat bomb release a current pulse passes from terminal 5 of the plug connector to the BK-48M interlock switch box of the bottom station, and then to contact 3 of the MBH-48 bomb shackle release unit.

The release unit operates, and as soon as the effect of the pulse is over, terminals 3 and 4 of the MBH-48 unit plug connector close. The coil winding of the unit is cut out from the circuit.

Next pulse passing through the interlock switch box and closed terminals 3 and 4 of the MBH-48 unit plug connector of the bottom station is fed to the top station of the bomb rack. Thus, the stations operate in succession until the bomb from the top station is dropped.

Depending on the bomb load variant, not all the stations may be loaded (load variant with demolition bombs, type QAE-500). In the latter case the shackles are removed from those stations, which do not carry bombs. The interlock switch box contacts are in the position indicated in the bomb rack circuit diagram.

The current pulse passes from terminal 5 of the plug connector to the interlock switch box of the bottom station. The release unit operates as is indicated in the preceding case. Next current pulse having passed through the closed contacts of the interlock switch box is fed to the top station release unit. Thus, the stations operate in turn until the bomb from the top station is dropped.

For emergency release power is supplied from plug connector terminal 4 to terminal 2 of the release unit emergency control, by-passing the interlock switch box. After the release unit has operated, contacts 2 and 1 close and the current passes to the next release unit. Thus, the stations

operate in turn until all the bombs are dropped.

Each bomb rack in the aircraft has its indicator light. When all the bombs from the bomb rack are dropped the light goes out. The signalling is effected in the following way: current from terminal 2 of plug connector 2 flows to terminals 2 of interlock switch boxes 3. From the interlock switch boxes it flows to terminal 2 of MBH-48 arming mechanism 1. When the shackle operates the shackle pin comes out and presses upon the MBH-48 arming mechanism pin. If the MBH-48 arming mechanism pin travels 3 mm, the MBH-48 contacts get in touch with the pin insulation and the signalling circuit becomes broken.

The bombs from the bomb rack may be released either ARMED (B3PMB) or SAFE (HEB3PMB). In the former case current from terminal 1 of plug connector 2 flows to terminal 1 of MBH-48 arming mechanism 1. The electromagnet operates and the longer arm of the mechanism core prevents the MBH-48 arming mechanism pin from further travelling.

When the shackle pin presses against the MBH-48 mechanism pin, the pin travel is limited to 3 mm, which provides for proper fixing of the ring of the YBH arming wire in the shackle.

In the latter case current is not supplied to the electromagnetic coil of the MBH-48 mechanism and the MBH-48 arming mechanism pin may travel 14 or 15 mm when pressed by the shackle pin. Such a distance is quite sufficient to let the ring of the YBH arming wire fall from the shackle.

KU3-488 Bomb Rack Main Data:  
Release unit-to-shackle minimum operating time ..... 0.025 sec.  
Bomb rack dimensions, mm ..... 1618x590x235

KU4-388 Bomb Rack

The KU4-388 bomb rack (Fig. 17) is intended for carrying and releasing bombs.

The bomb rack is designed to carry one bomb of 3000-kg calibre, or two bombs of smaller calibres.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

The KИ4-388 bomb rack has the following equipment:  
four electromechanical bomb shackle release units ПБЛ-48;  
four arming mechanisms MBH-48;  
four interlock switch boxes EK-48M;  
one plug connector ИP48И20ИИИ1;  
four sockets ИИ-И;  
two shackles Иep 4-49.

Note: When necessary, the KV-50 key is taken for use from the KИ3-488 set.

The bomb bay of the aircraft is equipped with four bomb racks (two right-hand and two left-hand racks).

The bomb release control is electromechanical (both combat and emergency).

The bomb rack is connected to the bomb release control system by means of the ИP48И20ИИИ1 plug connector. The bomb rack has a plug to be inserted into the socket placed on the side of the aircraft.

The bomb rack is furnished with all necessary equipment to ensure bomb release indication, bomb fuzes control, automatic cutting-in of the release units and arming mechanisms MBH-48 of the corresponding stations, depending on the bomb load variants, group control of the latches during the bomb rack unloading, and indication of closed position of the latches.

The bomb rack is a rigid frame consisting of the forward and aft beams connected by means of a duralumin sheet and two cross bars.

Mounted on the bottom and top cross bars are guiding sheaves for the bomb hoist cables. Two tubes mounted behind the sheet serve as conduits to bring the cables from the bottom to the top pair of sheaves.

The cross bars are equipped with steel coverings, which protect magnesium cross bars from damage and prevent the hoist cable from jamming in the cross bars.

In order to hold the shackles in the bomb rack four groups of latches are provided on the inner side of each beam.

The latch design and their operation are similar to the KИ3-488 bomb rack latches described above. The bomb rack is secured to the aircraft in the same way as the KИ3-488 bomb rack is.

..... KИ4-388 ..... Bomb Rack  
.....  
Circuit Diagram  
.....

The bomb rack circuit (Fig. 18) provides for two independent kinds of bomb release: combat and emergency which are accomplished either ARMED (B3PHB) or SAFE (HEB3PHB).

Combat Bomb Release

With the shackles placed in the bomb rack, the interlock switch box contacts close (which corresponds to their right-hand position in the diagram).

According to the accepted bomb load variants not all the stations of the bomb rack may be loaded. Bombs are suspended from the bomb racks in such a way that loaded are stations 2 and 4 as counted from the bottom.

For combat bomb release a pulse sent from the 3C5P-49A intervalometer through the rack selector to terminal 2 of the plug connector comes to the EK-48M interlock switch box of the bottom station. As the contacts of the bottom interlock switch box are closed, the pulse passes to the next interlock switch box. From the box current flows to terminal 3 of the ПБЛ-48 bomb shackle release unit. The unit operates, and after the pulse is over, terminals 3 and 4 of the ПБЛ-48 unit plug connector close. The coil winding of the unit gets disconnected from the circuit.

The second pulse sent to terminal 2 of the plug connector through the interlock switch box closed contacts, the ПБЛ-48 release units and terminal 1 of the bomb rack plug connector

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 24 -

passes to the bomb rack installed on the opposite side of the aircraft. Then the current pulse sent from terminal 8 of the bomb rack connector, through the interlock switch box closed contacts, passes to the terminal of the ПБД-48 release unit plug connector of the fourth station, thus making it operate.

The current pulse sent from terminal 8 of the bomb rack plug connector, through the interlock switch box closed contacts, the ПБД-48 release unit and terminals 13 of the bomb rack plug connector, actuates the ПБД-48 release unit of the fourth station of the opposite side. This is the way the bombs are released from each side in turn, one bomb from each row.

If the given bomb load variant leaves some bomb rack stations free, the vacant shackles should be removed. The interlock switch box contacts of these stations are in the position indicated in the bomb rack circuit diagram. The possibility is provided for the current to pass to the interlock switch box of the next station, by-passing terminal 3 of the ПБД-48 release unit.

Thus, the bomb shackle release unit of the station with the shackle removed will not operate and the bomb release time interval will not be affected.

#### Emergency Bomb Release

During the emergency bomb release power is supplied from terminal 10 of the plug connector to terminal 2 of the ПБД-48 release unit plug connector of the first station, by-passing the interlock switch box. The release unit operates and terminals 1 and 2 of the unit close. Then current is fed through the closed contacts of the release unit of the second station and terminal 11 to the bomb rack second station on the opposite side.

When current is supplied from terminal 12 of the bomb rack plug connector to terminal 2 of the third station release unit plug connector, the release unit operates and terminals 1

- 25 - 50X1-HUM

and 2 close. Then through the closed contacts of the third station release unit and terminal 9 power is supplied to the third station release unit of the rack on the opposite side.

When power is supplied from terminal 14 of the bomb rack plug connector to terminal 2 of the fourth station release unit plug connector, the unit operates and terminals 1 and 2 close. Then through the closed contacts of the fourth station release unit and terminal 15 power is supplied to the fourth station release unit of the bomb rack on the opposite side. In this way the emergency bomb release is effected (from each side in turn, one bomb from each row).

When the released bombs are ARMED, power is supplied to the terminals of the MBH-48 arming mechanisms through terminal 4 of the bomb rack plug connector. In this case all the MBH-48 arming mechanisms operate, and the shackle pin is limited to travel only 3 mm, which ensures a proper hold of the ring of the YBH arming wire in the shackle.

For the SAFE bomb release, power is not supplied to the MBH-48 arming mechanism magnet coil and the shackle pin may travel 15 mm and the ring of the YBH arming wire falls out of the shackle.

The bomb rack also sends signals indicating whether bombs are suspended. In this case power is supplied to the interlock switch boxes through terminals 3 of the plug connector and then to terminal 2 of the MBH-48 arming mechanism.

When the shackle operates, the pin of the MBH-48 arming mechanism travels 3 mm and disconnects the signalling contacts of the mechanism from the contact of the pin ring; they get to the insulated portion and the signalling circuit breaks.

#### Деп 3-48 --- Б о м б Ш а к л е

The Dep 3-48 bomb shackle (Fig.19) is a standard unit of the bomb equipment. The shackle is intended for carrying bombs of 50- to 500-kg calibre. The shackle provides ARMED or SAFE release of the bombs with the help of the ПБД-48 bomb shackle release unit and the MBH-48 arming mechanism.

The shackle is a frame holding a system of main and intermediate levers, rods and springs.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 26 -

The ends of the shackle have trunnions by means of which the shackle is held in the latches.

The bottom portion of the shackle has three carrying hooks, two sway braces and arming wire retainer 13.

Middle carrying hook 15 is intended to hold 50-kg and 100-kg bombs having one suspension lug.

Extreme carrying hooks 10 and 17 serve to hold 250-kg and 500-kg bombs having two suspension lugs.

The forward and aft sway braces are intended to prevent swaying and to stabilize bombs having one suspension lug.

The arming wire retainer is used for securing the ring of the YBN arming wire.

The bomb shackle frame has a necked tube for installing the H3-53 hoisting hook when hoisting a bomb.

Inside bomb shackle forward trunnion 1 a trigger pin is provided. When the MBH-48 release unit operates its pin strikes trigger pin 2, and the carrying hooks open (by gravity).

Inside the bomb shackle aft trunnion the arming wire retainer pin is located; it comes out of the trunnion when the carrying hooks open. When the MBH-48 arming mechanism is switched on, its pin prevents the movement of the retainer pin and the arming wire retainer of the bomb shackle remains closed and the arming wire ring is held in the retainer. The bomb is dropped set to ARMED (B3PHB).

When the MBH-48 arming mechanism is switched off, the arming pin of the bomb shackle makes a complete stroke to open the arming wire retainer which, in its turn, releases the arming wire ring. The bomb is then dropped set to SAFE (HEB3PHB).

#### Dep 4-49 Bomb Shackle

The Dep 4-49 bomb shackle (See Fig. 20) serves to carry and drop demolition bombs of 3000-kg calibre (ФAE-3000).

The shackle is controlled with MBH-48 electromechanical bomb shackle release unit 7 and MBH-48 arming mechanism 1.

- 27 - 50X1-HUM

The shackle consists of a rigid frame with trunnions projecting from the ends; the trunnions are intended to secure the shackle in the bomb rack latches. The arming wire retainer control mechanism is arranged in the forward section of the shackle. The mechanism consists of a system of levers, bars and springs. The carrying hooks control mechanism is located in the aft section.

The shackle rear boss has a stop to prevent the insertion of the bomb shackle into the bomb rack if the arrow direction on the shackle does not coincide with the direction of flight. The shackle is controlled with MBH-48 release unit 7. When the release unit pin strikes shackle pin 6, trigger lever 8 releases shift lever 5. Forward carrying hook 14 and aft carrying hook 9 connected by hook connecting link 11 get also free, and carrying hooks 10 and 15 open forced by the springs and the bomb weight.

When the bomb drops, forward carrying hook 15 lets rocking arm 13 turn about its axis. If the MBH-48 arming mechanism is OFF, pin 2 actuated by spring 3 makes a complete stroke of 13 or 14 mm. The same spring actuates rocking arm 13 and arming wire retainer 12 releases the arming wire ring, so the bomb drops SAFE (HEB3PHB).

If the MBH-48 arming mechanism is ON, the pin movement is limited to 3 mm, and retainer 12 does not release the arming wire ring. In this case the bomb drops ARMED (B3PHB).

#### MBH-48 Electromechanical Bomb Shackle Release Unit

The electromechanical bomb shackle release unit (Fig. 21) releases the bomb shackles. The electrical control of the release unit provides combat and emergency opening of the bomb shackles.

The steel case of the release unit houses an electro-magnet, a lever, a spring and a contact system. The contact

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 28 -

system of the MBH-48 release unit in conjunction with the EK-48H interlock switch boxes and the KBCB-48A bomb release variant box provides bomb release from the bomb rack in succession beginning with the bottom bomb.

The unit case has spline 3 provided for cocking the unit, a hole with releasing pin 4, and plug 5 whose socket is connected to the intervalometer circuit. When the release unit operates, releasing pin 4 opens the bomb shackle.

Operating voltage of the unit is  $27 \text{ V} \pm 10 \text{ per cent}$ . Minimum voltage to operate the release unit is 18 V. Voltage being 26 V at an ambient temperature of  $20^\circ\text{C}$ , current consumed by the electromechanical bomb shackle release unit is up to 6 A for the combat operation winding, and up to 9 A for the emergency operation winding. The distance for the pin travelling to operate the shackle is 14 or 15 mm. Effort exerted by the pin at the end of its stroke is 12 kg.

#### MBH-48 Arming Mechanism

The MBH-48 arming mechanism (Fig.22) operates in conjunction with the bomb shackles. It governs the leverage of the arming wire retainer and indicates bomb release.

The mechanism case 1 houses an electromagnet, pin 2 with a contact ring, and socket 3 to connect the mechanism to the electrical circuit.

The mechanism is controlled electrically. Operating voltage is  $27 \text{ V} \pm 10 \text{ per cent}$ . Minimum operating voltage is 18 V. Voltage being 24 V at an ambient temperature of  $20^\circ\text{C}$ , current consumed by the electromagnet is up to 0.2 A.

#### KI3-547H Guide

The KI3-547H guide facilitates the hoisting of 250-kg bombs to the KI3-488 bomb rack. The tongue of the guide is inserted into the bottom end of the beam of the KI3 bomb

- 29 - 50X1-HUM

rack and is secured with a special pin.

The aircraft is equipped with four guides (two right-hand and two left-hand).

The guide is a pressed shaped member whose bottom portion has steel rollers mounted on axles. In the process of hoisting the body of the bomb moves on the rollers and then slides along the steel covering of the shaped member to get into the rails of the bomb rack. After the bombs have been loaded, the guides are removed and put into a bag provided for the stowed position of the hoisting system parts.

#### H-116 Insertion Piece

The H-116 insertion piece is provided to check idle operation of the bomb shackles (without weights).

The aircraft is equipped with 24 insertion pieces, which are placed into the carrying hooks of the shackles. In the closed position of the carrying hooks the insertion pieces serve as suspension bands of the bombs.

The insertion piece consists of a U-shaped wire to the ends of which a steel rod is welded.

The insertion piece has a ring fastened to a cable. When the bomb release system is being checked the ring is secured to the arming wire retainer of the shackle.

#### Electrically Operated Signal Flare Launcher

General

The signal flare is used as a means of external signalling of the TV-16 aircraft.

For this purpose the aircraft is equipped with three electrically operated signal flare launchers (3KCH-39). Two launchers are installed on the starboard side between frames 20 and 22, and one launcher is installed on the port side between frames 21 and 22.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 30 -

The electrically operated launcher is designed to fire four standard signal cartridges. The launcher is charged with signal flare cartridges from the outside. The signalling is performed in four colours: red, yellow, green and white.

The launcher provides firing singly or in train, one cartridge after another with an interval of 0.05 sec. and more.

The launcher is remotely controlled by electro-pyrotechnical means and is fed from mains of  $27 \text{ V} \pm 10$  per cent. The control is effected from the signal flare control panel (NVP) placed on the navigator's right-hand control panel.

Previously installed 3KCP-46 launchers firing standard 26-mm cartridges whose flare proved invisible from the earth in high-altitude flights are replaced with more powerful launchers, type 3KCP-39, firing standard 39-mm cartridges.

The 3KCP-39 launchers differ from the 3KCP-46 launchers only in their calibre. The installation of the new launchers does not require any change in the wiring system of the aircraft.

#### Main Data of the 3KCP-39 Launcher

Number of tubes for signal cartridges launcher .....	4
Tube size .....	39 mm
Number of screws to secure launcher to aircraft .....	4
Securing holes diameter .....	5.2 mm
Interval for firing singly and in train .....	not less than 0.05 sec.
Power supply from aircraft mains .....	$27 \text{ V} \pm 10$ per cent

#### 3KCP-39 Launcher

The 3KCP-39 electrically operated launcher (Fig.23) for signal flare cartridges of 39-mm calibre consists of two main

- 31 - 50X1-HUM

parts: casing 1 and a set of tubes with magazine 5.

The launcher casing consists of a shoe and a box and protects the set of tubes and the magazine from dust and mechanical damage.

The box bottom part has flange 4 to secure the launcher to the aircraft structure. Digits 1, 2, 3 and 4 stamped on the box flange correspond to the tube numbers of the launcher.

The box top part has shoe 2 with a contact panel and plug connector 3, which connects the wiring from the signal flare control panel (NVP).

The set of tubes with the magazine consists of a launcher and a magazine. The launcher consists of four steel tubes fitted at top and bottom into duralumin frames.

The magazine is a shaped carbolite shoe with four sockets for the squib-initiated igniter. It serves to lock the launcher when it is loaded with signal flare cartridges.

The launcher and the magazine are hinged together and locked by means of a lock.

#### Signal Flare Control Panel

The navigator's right-hand control panel is equipped with three signal flare control panels (NVP), as indicated in Fig.24, in accordance with the number of the 3KCP-39 launchers. Each control panel is stencilled with letters A, B, and C, which corresponds to the designations of launchers A and B on the starboard side and launcher C on the port side of the aircraft.

Thus, each launcher has its own control panel.

The control panel is a metal case supporting four buttons and a switch. When the button head is turned, a colour indicator appears, which may be red, yellow, green or white, in accordance with the signal flare colour. The control panel buttons have digits 1, 2, 3 and 4, which correspond

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

-32-

to the launcher tube numbers.

The switch on the control panel turns the panel power supply ON or OFF.

#### ЗКЧН-39 Launcher Control

When the launcher is loaded with signal flare cartridges (the colour indications on the control panel buttons correspond to the flare colours in the tubes) and the control panel switch is ON, the launcher is ready for firing.

The launcher is fired by pressing the buttons of the control panel (Fig.25). When a button (or the buttons) is pressed, a current pulse through the plug connector and the contact panel is sent to the plate contacts of the magazine, and then to the filament of the squib-initiated igniter. The explosive charge is ignited and, forced by the explosion, the striker pushes out of the squib to break the signal flare cartridge cap and to fire the tube.

#### Description of Instruments

##### ЗСБ-49A Intervalometer

The ЗСБ-49A electrically-operated intervalometer (Fig.26) provides control of the ПБЛ-48 release units of the bomb rack in combat bombing. The ЗСБ-49A intervalometer is designed to send from one to eighty current pulses with 24 kinds of time intervals ranging from 0.04 to 10 sec.

The intervalometer is used in conjunction with the КБСБ-48A bomb release variant box, the ВУ-50 spark extinguishing device and the Б-45 salvo switch. The ЗСБ-49A intervalometer provides:

1. Automatic bomb release in train, by single bombs or in pairs per salvo, with number of bombs or salvos up to 80 in train, the ground spacing between single bombs or pairs

-33- 50X1-HUM

being from 3.5 m. to 3.6 km, and the aircraft ground speed ranging from 300 to 1300 km/hr.

The bomb equipment system of the aircraft permits the suspension of 24 bombs; therefore, no more than 24 pulses are used for releasing the bombs.

2. Non-automatic (selective) bombing, one bomb or salvo (two bombs per salvo) at arbitrary intervals depending on the frequency of the bomb release button pressing, or on the release circuit contacts matching in the ONE-11p optical bombsight.

3. Counting of bombs dropped.

The ЗСБ-49A intervalometer is mounted on the navigator's left-hand control panel (See Fig.6). The intervalometer is connected to the electrical system of the bomb release control by means of a seven-pin plug connector.

The face side of the intervalometer housing (Fig.26) is equipped with the following controls: the signalling light, counter unit knob with a pointer, dial indicating the number of bombs or salvos (pairs) per train, bomb spacing dial, interval switching knob, ground speed indicator dial, M. - KM. range switch and the TRAIN (СЕРИЯ) - SELECTIVE (ОДИННОЧНО) switch.

Signalling light 1 serves to indicate the intervalometer readiness to operate. When the device is prepared for selective (non-automatic) pulse sending, the light begins to shine after the TRAINSEL toggle switch is set to the SELECTIVE position, and continues to shine all the time. When the intervalometer is prepared for automatic operation (train pulse sending), the signalling light begins to shine when counter knob 4 is set on dial 3 to indicate the number of bombs (salvos) to be dropped in train, and goes out after the bombs are released.

The counter knob sets a given number of bombs or pairs per train on the dial. In order to set the counter for a given number of bombs or pairs per train, by turning knob 4 put the

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 34 -

pointer (connected to the knob) against the figure on the dial denoting the given number of bombs or pairs of bombs.

Dial 3, indicating the number of bombs or pairs of bombs, is intended to set the counter unit for a given number of bombs or salvoes (pairs). The dial has 80 divisions which correspond to the maximum number of pulses, sent out by the 3CEP-49A intervalometer to the bomb shackle release units.

Dial 7, indicating ground bomb spacing, serves to set the interval switch for a given ground spacing between the bombs or salvoes released. The dial has a two-digit designation: the inner one, made in m. (first range), and the outer, made in km. (second range). The first range is designated M. (metres), the second one - KM. (kilometres).

Knob 6 of the interval control switch sets a given ground spacing of bombs on bomb spacing dial 7. In order to set the interval it is necessary to turn the knob in such a way that the given ground spacing designated on the bomb spacing dial should coincide with respective ground speed mark.

The interval control knob has twelve fixed positions. Each fixed position corresponds to two time intervals: one is in the "metres" range, the other, in the "kilometres" range.

Dial 5, indicating the aircraft ground speeds, serves to set the bomb spacing knob with respect to the ground speed.

M. - KM. range switch 2 serves to switch the intervalometer for the operation in one of the two ranges. When the range switch is set to M the intervalometer will operate in the first range, i.e. it will send pulses to the outer circuit with time intervals of 0.04 to 0.5 sec. These intervals correspond to the bomb ground spacing in the "metres" (M) range of the bomb spacing dial. When the M. - KM. range switch is set in the "kilometres" (KM.) position, the intervalometer will operate in the second range, i.e. it will send pulses to the outer circuit with time intervals of 0.8 to 10.0 sec. These intervals correspond to the ground spacing in the

- 35 - 50X1-HUM

"kilometres" range on the bomb spacing dial 7.

TRAINSEL toggle switch 8 sets the intervalometer to operate automatically or selectively. If the switch is in the TRAIN position, the intervalometer will operate automatically until the whole train is released when the KCE-49 bomb release button is pressed.

If the switch is in the SELECTIVE position, the intervalometer may send only single pulses at each pressing of the KCE-49 bomb release button, or at the closing of the release circuit contacts in the ONE-11p bombsight.

#### KBCE-48A Bomb Release Variant Box

The KBCE-48A bomb release variant box (Fig. 27) is intended for distribution of the current pulses sent by the intervalometer to the NEJ-48 electromechanical bomb shackle release unit. The pulses are distributed between the bomb rack groups. The KBCE-48A box controls two groups of release units and permits to drop bombs singly or in pairs.

The KBCE-48A box is installed on the port side of the aircraft between frames 3 and 4. It comprises four electromagnetic relays, an eleven-pin plug connector, a plate, and a cover.

The electromagnetic relays are mounted on the plate.

The electromagnetic relays P<sub>1</sub>, P<sub>2</sub>, P<sub>3</sub> and P<sub>4</sub> (Fig. 28) are independently coupled. Each pair provides for electromechanical release unit control of a given bomb rack group, whose release units are connected in-series to the electric circuit.

The KBCE-48A box is connected to the aircraft mains by means of an eleven-pin plug connector.

Each relay pair of the KBCE-48A box is controlled by a separate switch, type 2B-45, installed on the navigator's panel. Power consumed by the KBCE-48A box does not exceed 20 W.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 36 -

## KBCB-48A Box Operation

One-Bomb-per-Salvo Bombing. B-45 salvo switch 3 on the navigator's bottom panel should be set to the one-bomb-per-salvo position (Fig. 28),

When the bomb shackle release units are cocked and switches 1 and 2 on the navigator's bottom panel are ON, the plus of the aircraft mains through pins B and B of the plug connector of the KBCB-48A box, contacts 8 - 10 and 18 - 20 is fed to electromagnet coils  $B_1 - A_1$  and  $B_3 - A_3$  of relays  $P_1$  and  $P_3$  and further through I and B pins of the plug connectors via the releasing electromagnet windings of the cocked release units is fed to the minus. Relays  $P_1$  and  $P_3$  will operate to bring the contacts to the left-hand position (Fig. 28 shows the contacts in the extreme right position). The bomb shackle release units do not operate, as the current in the releasing electromagnet windings is too weak due to the high resistance of windings  $B_1$  and  $B_3$  (voltage being 27 V, current in windings  $B_1$  and  $B_3$  is 0.2 A; in order to operate the release units current intensity should be 5 or 6 A).

The first current pulse from the 3CEP-49A intervalometer through pin I of the plug connector the KBCB-48A box, contacts 2 - 3, via the low ohmage winding  $A_1$  of relay  $P_1$  and pin I of the plug connector is sent to the first (by the order of operation) ПБЛ-48 release unit of the first bomb rack group. In these circumstances the release unit operates.

At the same time the current pulse through closed contacts 4 - 5 is sent to winding  $B_2$  of relay  $P_2$  and to the circuit minus through pin K of the plug connector of the KBCB-48A box. Relay  $P_2$  will operate to open contacts 8 - 10 and to close contacts 8 - 9. When contacts 8 - 9 close, power from switch 2 is supplied to winding  $A_2$  (relay  $P_2$ ) connected to minus through contacts 6 - 7 and 16 - 17 of relays  $P_1$  and  $P_3$  connected

in parallel. Contacts 8 - 10 will open and de-energize winding  $B_1$  of relay  $P_1$ ; the contacts of relay  $P_1$  will be held in a closed position by the current passing through winding  $A_1$  until the end of the power supply from the intervalometer actuating relay to the release unit. Relay  $P_1$  being de-energized, the contacts are brought to the right-hand position.

The armature of relay  $P_2$  will be held drawn in by the current flowing from switch 2 to the circuit minus through plug connector pin B, contacts 8 - 9, winding  $A_2$  of relay  $P_2$ , contacts 16 - 17 and via pin K of the plug connector of the KBCB-48A box.

The second current pulse is sent out to the ПБЛ-48 release unit (the one which is first to operate) of the bomb rack second group through pin I of the plug connector of the KBCB-48A box, contacts 2 - 1 and 12 - 13, through winding  $A_3$  and then via pin E of the plug connector to the release unit winding.

After the second pulse is over, relay  $P_3$  of the KBCB-48A box will release contacts 16 - 17 to open the negative circuits of windings  $A_2$  and  $A_4$  of both relays. Relays  $P_2$  and  $P_4$  simultaneously release contacts 8 - 9 and 18 - 19 to close contacts 8 - 10 and 18 - 20. Windings  $B_1 - A_1$  and  $B_3 - A_3$  of the four relays become energized again.

Relays  $P_1$  and  $P_3$  operate simultaneously and prepare the KBCB-48A boxes to a new operating cycle.

Thus, current pulses are distributed in turn between two control circuits of bomb shackle release units providing for one-bomb-per-salvo bombing for two groups of the bomb racks.

If all the bombs from one of the bomb racks are dropped, or one of switches 1 or 2 is in the OFF ( ВЫКЛЮЧЕНО ) position, the bombs will be dropped only from one group of bomb racks.

Two-Bombs-per-Salvo Bombing. The salvo switch is set to the two-bombs-per-salvo position (the switch contacts are

- 37 - 50X1-HUM

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

- 38 -

closed). When the bomb shackle release units are cocked and switches 1, 2 are ON, relays P<sub>1</sub> and P<sub>2</sub> of the KBCB-48A box operate and close contacts 2 - 3, 4 - 5, 6 - 7 and 12 - 13, 14 - 15, 16 - 17.

A current pulse is sent out to the release unit winding of the first bomb rack group through pin Γ of the KBCB-48A box plug connector, contacts 2 - 3, winding A<sub>1</sub> of relay P<sub>1</sub>, and then through pin Δ of the KBCB-48A box plug connector.

At the same time a current pulse is supplied from pin Γ to the release unit winding of the second group of bomb shackles through pin Η of the KBCB-48A box, salvo switch contacts, pin X of the KBCB-48A box plug connector, contacts 12 - 13, winding A<sub>2</sub>, relay P<sub>2</sub> and then through pin Z of the KBCB-48A box plug connector.

Thus, the pulse is simultaneously supplied through pin Γ to the first relay and through pin X to the third relay of the KBCB-48A box, which will provide a simultaneous supply of pulses to the two electromechanical bomb shackle release units.

#### Spark Extinguisher WY-50

The WY-50 spark extinguisher (Fig. 29) is intended to diminish sparking on the contacts of the electrical bomb release actuating relay. The WY-50 spark extinguisher is placed on the port side of the aircraft in the area of frame No. 4.

The WY-50 spark extinguisher consists of two main elements: a fixed capacitor, type KMET-100 μF, 250 V, and a D.C. electromagnetic relay with four groups of contacts.

Both of these elements are mounted on the same plate and are connected to the intervalometer by means of an eleven-pin plug connector. The spark extinguisher is protected by a cover.

Operating voltage does not exceed 18 V; power consumed is not over 10 W.

- 39 - 50X1-HUM

#### Spark Extinguisher Circuit Diagram and Operation

The capacitor (Fig. 30), intended to diminish sparking, is connected in parallel by a power contact of the intervalometer actuating relay. One lead is connected to plus through pin X, while the other one is connected to the intervalometer through pins 3 and Η.

Thus, self-inductance e.m.f. generated when the 3CEP-49A intervalometer actuating relay contacts are breaking will charge the capacitor. Consequently, the energy generated in the contact resistance diminishes, preventing burning of the contacts.

Electromagnetic relay 2 with contacts connected to terminals B, Γ, Δ and E is not used during the bombing equipment electric circuit operation.

#### Bomb Release Button KCB-49

The KCB-49 bomb release button is intended to switch on the intervalometer for train or selective bombing.

The bombing equipment circuit has two KCB-49 buttons; one of them is installed above the navigator's right-hand control panel, while the other is installed on the navigator-operator's instrument panel.

The KCB-49 bomb release button (Fig. 31) consists of base 3, block 5, wire 4, KB-6A switch 6, button 7 and cap 1. Wire ends are soldered to the switch leads and are tied with thread 2 to the block in order to prevent breaking in the soldered points.

Pressing the button closes the circuit. When the button is released the circuit opens. The button construction provides an instantaneous closing and opening of the contacts.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 41 - 50X1-HUM

## Chapter III

## DOOR CONTROL SYSTEM

Bomb-Bay Door Control System

The bomb-bay doors are provided with normal, stand-by and emergency control systems.

The normal bomb-bay door control is effected through a hydraulic drive operating from the main hydraulic system of the aircraft.

The stand-by bomb-bay door control is resorted to when the aircraft main hydraulic system is inoperative and is accomplished by coupled springs to open and by a hydraulic drive, operating from the aircraft hydraulic brake system, to close the door.

The emergency bomb-bay door control system is used for an emergency bomb release. It provides only for door opening and is accomplished by coupled springs.

The main units of the door control system are installed between frames Nos 33 and 49 (Fig. 32).

The forward reel on the rear side of frame No.33 is mounted on a steel shaft (installed on a bracket), on the bottom panel and the rear spar of the centre main plane. The reel (Fig. 33) is made of magnesium alloy M15-TA. It is a large disc with two grooves for the cable. On the back side of

the disc there is a sector lug of a smaller diameter with a cable groove and two arms with ball bearings (in the bottom and top right-hand portion). In the top portion of the disc a lever is bolted; the lever is stamped of aluminium alloy AK-6. The stamped lever is connected to hydraulic drive rod 1, the other two, to rods 5. Besides, the reel has a hole to attach the limit switch control rod.

The limit switches are assembled in a box installed in the bomb bay.

The opposite ends of the rods are secured by easy-to-remove hinge pins to the assemblies on the bomb-bay door butt ends.

The rear reel is mounted on the steel shaft, on the front side of frame No.49. The reel cast of magnesium alloy M15-TA has two grooves for the cable on the larger disc and two levers with ball bearings on the right-hand side (looking forward) and at the bottom, on the front side of the disc. The reel arms via the rods are connected to the attachment assemblies on the bomb-bay door rear butt ends by means of easy-to-remove pins.

Two connecting cables 3 run from the larger disc of the forward (driving) reel to the starboard side of the aircraft. A cable, 8 mm in diameter, running from the top portion of the disc, is connected with a cable of the same diameter running from the bottom portion of the rear reel disc. A cable, 4.5 mm in diameter, running from the bottom portion of the disc, is connected with a similar cable running from the top portion of the rear reel disc. This kind of cable connection makes both reels revolve in one direction. The turnbuckle connections of the cables are at frame No.44.

The pre-tension of the 8-mm cables amounts to 250 kg. It is measured with the TP-1 strain gauge.

The sheave blocks of connecting cables 4 are located on the right-hand side of the rear spar of the centre main plane and frame No.38, as well as on the starboard side at frame No. 49.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 42 -

Running from the bottom portion of the sector lug of the forward reel is cable 6, 8 mm in diameter. This cable passes round the sheaves mounted on the brackets which are fixed to the skin on the inner side of the bomb bay and on the engine side horizontal wall of the left beam, at frame No.36; it has a turnbuckle connection with the forward cross bar of two coupled springs 8 (See Fig.32). The rear cross bar of the springs (Fig.34) is bolted to a nipple which at its rear end has a hexagon joggle and an internal thread. The threaded end of the rod with the hexagon head is screwed into the nipple. The smooth cylindrical part of the rod enters an angular thrust ball bearing, its hexagon head being supported by the inner ring of the ball bearing. The ball bearing is pressed into a steel cup inserted into the conical portion of the hole in the bracket which is secured to the beam horizontal wall at frame No.40.

The springs are made of wire, 12 mm dia. The wire is of steel 50XΦA, heat-treated to acquire a strength of 150 - 180 kg/mm<sup>2</sup>.

The springs are wound in opposite directions of wire of the same lot and have identical heat treatment.

The principal use of the springs is the stand-by and emergency opening of the bomb-bay doors. In opening the doors through the normal control system (with the help of the hydraulic drive) the springs increase the speed of opening of the doors by adding to the force which draws out the hydraulic drive rod.

The initial total force applied by the springs to bomb-bay doors is from 1500 to 1650 kg while in the extreme open position (with the hydraulic drive rod fully extended) it amounts to 550 or 620 kg. Since the force of the springs is considerable it is dangerous to be within the reach of bomb-bay doors motion when the doors are opened or closed.

The disconnection of the hydraulic drive from the reel pin or from the bracket on the port side of the fuselage must

50X1-HUM

be done only when the doors are securely fixed in the open position with a spacer placed at the forward butt ends.

The bomb-bay doors are held in the CLOSED position by the ball lock of the hydraulic drive, their outer surface aligning with the shape of the fuselage.

With the bomb-bay doors in the OPEN position, the piston of the hydraulic drive reaches the stop and the rods take a position in which the axes of the bolts fastening them to the reel pin lie on a straight line connecting the axes of the bolts fastening the rods to the doors with the axis of the reel, or they lie farther than the straight line, i.e. farther than the "dead point". The distance between the door bottom edges (along the skin) at the forward and rear butt ends must equal 2070<sub>-100</sub>; the distance from the aircraft axis (determined by plumb weights hanging from the axes of rotation of the reels) to the door bottom edges must be 1035<sub>-50</sub>.

For adjusting the tension of the springs there is a mark made in red enamel on the front cross bar of the engine side. On the top edge of the left beam skin, on the engine side two more red marks are made pointing the OPEN and CLOSED positions for the forward cross bar of the springs.

The tension of springs 1 is adjusted by adjusting rod 7 of rear cross bar 6 and cable turnbuckle connection 4 of front cross bar 5.

Adjustment and inspection of these joints is done through two access holes in the fuselage skin above the left-hand beam, between frames Nos 36, 37 and 39. 40. The box for limit switches is mounted on frame No.33. The construction of the box installed in the aircraft of later make is shown in Fig. 35, 5. The box consists of housing 7, covers 22, 23, 24 and nine limit switches 1, 2, 3, 5 (two pcs), 6 (two pcs), 8 and 10.

The limit switches (eight of them are of BK2-142B and one of BK2-141B-type) are mounted in the box.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 44 -

50X1-HUM

Every cover is attached by means of a pin fixed in lugs 4 of housing 7 and has an actuating roller.

When the roller is pressed, the cover revolves around the axis of suspension and presses the limit switches stems to put them in the OFF position.

When the actuating roller is released, the cover returns to its original position. The roller is pressed against the cover by the contact wedges of carriage 11 connected via the rod with the forward control reel of the bomb-bay doors.

When the forward reel is revolving, the carriage performs a motion of translation and with its wedges 14, 15 and 16 via rollers 17, 18 and 19 presses against the corresponding covers. With the doors fully closed (Kinematic Diagram I), the carriage with its wedge 16 via roller 19 pushes cover 22 to bring limit switch 1 into the ON position which indicates that the doors are closed, the remaining switches being in a free position.

When the angle of the door opening is  $68 \pm 3^\circ$  (Kinematic Diagram II) the carriage with its wedge 15 presses cover 23 via roller 19 thereby switching on limit switch No.3 which interlocks the emergency bomb release circuit (with the aircraft mains de-energized). The remaining switches are free.

Switch 3 remains depressed until the bomb doors get fully open.

With the doors fully open (Kinematic Diagram III), carriage wedge 14 pushes cover 24 via roller 17 thus actuating the relay preparing the combat bomb release circuit to be closed by switches No.4 and No.5, open door indicator lights circuit to be closed by switch No.2, the autopilot interlocking relay ON position circuit to be closed by switch No.8, the emergency release ARMED circuit interlocking relay to be closed by switch No.9, and closing the emergency release relay by switches No.6 and No.7; in this instant limit switch No.3 is in the depressed position being held by roller 19 of cover 23.

Switch No.1 of the door closed position indication circuit is not pressed. A reliable closing of the relay preparing the combat and emergency release circuits is ensured by introducing two switches in each box; the switches are energized from the aircraft mains through independent wires equipped with circuit breakers (ACB).

With oval slots 9 the box is adjusted in the box lugs which provide for a vertical shifting of the box. The final position of the box is marked with red paint, the box being secured by screws. The limit switches are adjusted by screws 21 mounted on the covers.

During the adjustment the following should be achieved:

(a) 1.5 - 3 mm travel of each switch button after its tripping (which is indicated by a click), with covers depressed;

(b) operation of switches 5 prior to that of switches 6.

**Note:** Due to a delay in the current flow to the arming mechanism simultaneous operation of switches 5 and 6 is not permissible because the bombs would be released SAFE although the system has been prepared for emergency ARMED release.

The adjustment over, screws 21 are locked by wire 20.

In the aircraft of earlier make every box has seven limit switches of EK-2-1A2B type (See Fig. 35, A), the construction of the boxes being identical.

When pressed, the switches close the circuits of the bomb-bay door position warning lights during combat, emergency or top emergency bomb release.

The limit switches are mounted in such a way that when pressed by covers 22, 23 and 24 their limit screws 25 and 26 do not reach the edges of slot 27 leaving a space of 0.5 to 1.0 mm; the button of switches 5 and 6 (top button) must be pressed by 1 - 2 mm, the buttons of switches 1, 2 and 3 - by 1.5 - 3 mm, the button (bottom) of switch 6 - by 2 - 3.5 mm after its tripping (which is indicated by a click). The indicated positions of the covers must provide for an

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 46 -

50X1-HUM

additional free travel of at least 3 mm for switches 5 and 6 (top), at least 2 mm for switches 1, 2 and 3, and at least 1.5 mm for switches 6 (bottom).

**CAUTION:** The adjusted box must ensure the operation of switches 5 prior to that of switches 6. This is done by placing washers, 0.5 and 0.8 mm thick, between the housing and the bodies of switches 6.

A bench-tested box is mounted in the aircraft in such a way that, with the bomb-bay doors closed, limit screw 26 cannot reach the ends of the slot in angle-piece 27 leaving a margin of 0.5 - 1 mm.

When the bomb-bay doors are being opened switches 5 and 6 operate when the doors get 1650 mm apart.

If one of the limit switches is inoperative, the box must be dismantled, the switch replaced and checked in accordance with the requirements given in this Section. The mounting of the limit switch is determined correct when the free travel of its stem is within the required limits. The travel is checked as follows:

1. Push cover 24 to reach a position in which limit screw 26 is 0.5 - 1 mm short of the slot end.
2. Sink a feeler gauge, 1.2 mm thick, into the hole under switch 6 (top button) and make a mark on the feeler gauge.
3. Press the button with the feeler gauge as far as it will go and make a second mark on the feeler gauge.
4. Measure the distance between the two marks. It will be the free travel.
5. In a similar way measure the free travel of switches 5 (middle), 6 (top), and 3.
6. Make sure that a special 1.5-mm thick feeler can be put between the button on the cover and the button of switch 6 (bottom).
7. Determine the free travel of switches 1 and 2 in the manner described for switch 6 (bottom).

8. If the free travel is less than that tolerated, insert washers between the box and the switch case in accordance with the requirements outlined in the Caution of this Section.

**Note:** In this type of aircraft use must be made of only such limit switches which have a free travel of not less than 5 mm after tripping (click).

Hydraulic Drive of Bomb-Bay Door Control System

The hydraulic drive (Fig. 36) of the bomb-bay door control system serves to open and close the bomb-bay doors. The drive incorporates an actuating cylinder and an emergency mechanism. Elbow-shaped connection 42 connects the actuating cylinder with the line of closing. Elbow-shaped connection 21 connects the actuating cylinder with the line of opening. Ball lock sleeve 13 with spring 17 slides within the cylinder barrel. The sleeve end contacting the balls is centred. The other end of the sleeve has a bead which rests against the ring joggle of the body when the ball lock is closed. The sleeve chamber accommodates bush 12 with nut 15. The bush bead rests against the sleeve ring joggle and is secured by a retaining ring, which, being set in the sleeve groove, rests against the end of the bush and prevents it from travelling in the axial direction. In the groove of the outer surface of the bush a rubber ring is placed. By means of the bush and the nut the sleeve is connected with rod 16 which, with its ball-shaped end, enters the bush and rotates freely in the spherical seat of the nut. The sleeve spring permanently holds the sleeve in the locked position. Nut 18 has a fork-shaped slot where lever 20 is attached; one end of the lever is connected with rod 16, while the other is connected with the emergency mechanism rod fork. The hydraulic drive is secured to the eye-bolt of the second spar of the centre main plane with the help of fork 19.

The rod of actuating cylinder 6 is a tube whose one end

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 48 -

50X1-HUM

is threaded to eye-bolt 1, thus connecting the rod with the forward reel on frame No.33. Piston 7 is put on the rod other end and locked by check nut 9. The sealing between the piston and the cylinder face is effected through rubber ring 8. Fourteen equidistant radial holes for the lock balls are drilled in the piston. On the piston side the rod is blanked off with plug 10 having a rubber gasket. Check nut 9 and plug 10 are locked to the rod by a retaining ring. Cylinder 29 of the emergency mechanism is a tube with male threaded ends and with an external hexagon flange to receive a wrench for supporting the cylinder when nut 36 and cover 27 are screwed. From one side barrel 37 secured by captive nut 36 is inserted into the cylinder. T-piece 38 is screwed into the threaded hole of the barrel to attach the piping.

Fixed on rod 23 is piston 33 travelling in barrel 37. When the bomb doors close, stop 25 of the emergency mechanism is held by release lever 26. Spring 31 enclosed in the emergency mechanism cylinder rests with one of its ends against piston 35 whose one end rests against the bead on bush 32 and the other end bears against the wall of cover 27. The rod travel is limited by stop 28 and bush 32 bolted on the rod. Release lever 26 is bolted to two cheeks in the bottom portion of cover 27, one of its ends having a roller and the other having a lug. The release lever contacts stop 25 with its roller and is connected to spring 22 by its lug.

Fig. 36 shows a cocked position of the emergency mechanism (spring 31 is compressed).

Bracket 41 made of elektron units the actuating cylinder and the emergency mechanism to make them a single unit. The actuating cylinder and emergency mechanism are inserted in semi-circular recesses of the bracket and are secured by clamps. To prevent the bracket turning about the longitudinal axis of the actuating cylinder the bracket is mounted on a guide bar which fits in the grooves on the outside surface of the actuating cylinder and on the semi-circular surface of the bracket. Emergency and stand-by electric release units 39, type

3HC-1, are mounted and secured by pins to platforms on both sides of the bracket. The rod of each unit through a bell crank and a link is connected with emergency mechanism release lever 26. Spring 22 holds release lever 26 in a position that the lever bears against rod 23 of the emergency mechanism, while stop 25 of the rod rests on the roller.

Basic Specifications  
.....

Full travel of actuating cylinder piston .....	400 ± 0.5 mm
Full travel of emergency mechanism piston .....	28 ± 0.5 mm
Full travel of ball lock sleeve .....	8 ± 0.5 mm
Sleeve travel required to open ball lock .....	5.7 mm
Pressure required to open ball lock .....	from 6 to 9 kg/cm <sup>2</sup>
Back pressure required to close ball lock .....	at least 3.0 kg/cm <sup>2</sup>
Effort of electric release unit .....	not exceeding 12 kg

Normal Control of Bomb-Bay Doors

The normal control of the bomb-bay doors is effected by the IH-45 switch (Fig. 37), mounted on the bomb-bay door control panel at the navigator's station, and automatically, by the target-warning mechanism of the OHE-11p bombsight.

To open the bomb-bay doors the normal control system functions as follows.

The IH-45 switch being put in the OPEN (OTKPYT) position and held so until the lamp indicating the door opening lights up on the panel, voltage is supplied to the 3M-12 electromagnet of the main hydraulic valve of the bomb-bay door control. The electromagnet operates to shift the slide valve of the hydraulic control valve downward. The hydraulic fluid from the main hydraulic system via the control valve (Fig. 38)

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

and the slide valve distributor gets into the actuating cylinder. Since the piston, with the doors closed, is locked by the ball lock, the hydraulic fluid delivered to the actuating cylinder shifts the ball lock sleeve away from the piston and compresses the spring. The sleeve having been shifted, the balls locking the piston get released to move inside and unlock the piston, thereby enabling the latter to freely move and push the rod out of the cylinder. The rod moves out of the cylinder turning the forward reel. The turn of the forward reel (See Fig. 33) is transmitted to the aft reel by the connecting cables. When the two reels turn they make the rods attached to them open the bomb-bay doors.

The doors are fixed in the OPEN position by the rods as each pair of rods in conjunction with the reel makes a kinematic lock.

When the mechanism is in the normal operating position three hinges A, B, C (Fig. 39) lie in a straight line. The tolerable limit position of the mechanism is as follows: the deflection of the longer arm of the reel should not exceed 20 mm.

To close the doors by the normal control system the NH-45 switch is put to the CLOSED (ЗАКРЫТ) position and held so for 5 - 6 seconds after the door closing indicator light comes on. In this case voltage is also supplied to the 3M-12 electromagnet of the main hydraulic valve. The electromagnet operates to shift the slide valve of the hydraulic valve downward. To close the doors the hydraulic fluid from the main hydraulic system via the control valve and the slide valve distributor passes to the hydraulic drive (through the closing pressure delivery connection). The piston is forced to move and draws the piston rod into the cylinder. The piston rod turns the reels to close the bomb-bay doors.

With the doors closed, the piston with its rod drawn into the hydraulic cylinder is locked by the ball lock thus holding the bomb-bay door in the CLOSED position.

Simultaneously with the closing of the bomb doors the

twin springs of the stand-by and emergency bomb door control systems are cocked by the turn of the forward reel. When the bomb-bay doors are closed, the springs are permanently in the cocked position.

The automatic door control is effected through the target-warning mechanism of the OH5-11p bombsight. The target-warning mechanism warns of the approach of the bomb release point and at the same time sends a pulse into the 3M-12 electromagnet of the main hydraulic valve to open the bomb-bay doors. In this instant the system opens the doors in the same way as it does when controlled by the NH-45 switch.

Operation of 3M-12 Electromagnet

The 3M-12 double-acting electromagnet is designed to effect the remote control of the hydraulic system valve operating the bomb-bay doors.

The 3M-12 electromagnet (Fig. 40) comprises cylindrical housing 4 where core 5 with pressed-in rod 8 travels. Pull-in coil 3 and push-out coil 6 are arranged in the housing. Since the magnet is intended for operation in a single-wire system one lead of each coil winding is soldered to the housing, whereas the other is brought out to plug connector 11. Screwed into the housing on both sides are top cover 9 and bottom cover 2 which attract the core. The same covers secure the coils to the housing. To adjust the covers adjusting shims 7 are put on the coils.

When power is supplied to the winding of the pull-in coil, the core shifts from its middle position (located by the slide valve springs) to the bottom cover of the electromagnet thus pulling in the rod. When the pull-in coil is de-energized, the return of the core to the middle position is effected by the slide valve springs. When the winding of the push-out coil is energized, the core is attracted by the electromagnet top cover thus pushing out the rod.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

Basic Specifications of 3M-12 Electromagnet

Rated operating voltage .....	27 V
Double travel of core .....	14 + 0.29 mm
Initial tractive effort to move core from middle position in cold state, at 27 V and +20°C .....	at least 16 kg
Final tractive effort under above conditions .....	at least 25 kg
Tripping time .....	not over 1.5 sec.
Mode of operation .....	intermittent each winding being energized alternatively for 30 sec. (one cycle amounting to 1 min 16 cycles altogether)
Weight .....	not exceeding 1.8 kg

Stand-By Control of Bomb-Bay Doors

The stand-by control of the bomb-bay doors is accomplished through the twin springs to open and through the hydraulic drive of the hydraulic brake system to close the doors.

Door Opening

The bomb-bay doors can be opened through the stand-by control system only by the navigator whose door control panel is equipped with BH-45 switch 9 for the purpose (Fig. 37). When the switch is ON, it energizes 3MC-1 electric release unit 39 of the stand-by door opening system; the unit

50X1-HUM

is mounted on the hydraulic drive unit (See Fig. 36) and while operating turns release lever 26 which unlocks piston rod 23 connected to release spring 31. When expanding the spring pulls in piston rod 23 which by lever 20 and rod 16 pushes sleeve 13 away from the piston. So balls 11 can now move inside the piston and unlock it. When the hydraulic drive piston is unlocked, the forward reel, as well as the aft reel actuated by the coupled springs turn and open the bomb-bay doors. When the piston rod pushes out of the cylinder, it forces the hydraulic fluid from one chamber of the cylinder into the other (Fig. 41).

Door Closing

The stand-by system for closing bomb-bay doors is controlled by the BH-45 switch mounted on the pilots' central panel (See Fig. 37).

When the BH-45 switch is pressed voltage is supplied to the 3M-12 electromagnet of the stand-by hydraulic valve. The electromagnet actuates the slide valve of the hydraulic valve (See Fig. 42). In this case the hydraulic fluid is delivered into the hydraulic drive from the hydraulic brake system of the aircraft while the main system line is shut off from the supply line of the drive by the shuttle valve of the slide valve distributor.

Operation of the mechanical part of the system when the doors are closed is identical to that of the normal control system.

Simultaneously with the bomb-bay door closing spring 31 of the hydraulic drive release mechanism gets cocked (See Fig. 36).

The cocking is effected by hydraulic piston 33 of reverse loading as the hydraulic fluid flows into the hydraulic drive cylinder when the bomb doors close.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

Door Emergency Control

The emergency control of the bomb-bay doors ensures the bomb-bay door opening to release the bombs in emergency. In this case the system is controlled by the emergency release switches, or, with the aircraft mains de-energized, by the emergency release handle (See Fig. 37). When the emergency release switches on the pilot's instrument panel or the navigator's bomb release panel are turned on, power from the aircraft mains is supplied to the 3NC-1 electric release unit of the emergency bomb door opening. In case the emergency release handle on the pilot's panel is turned on, power to the electric release unit is supplied from the storage batteries. In both cases the electric release unit operates to open the doors. The doors are opened by the twin springs, similar to the case of stand-by opening system.

A simultaneous cut-in of the emergency bomb release circuits and of the electric release unit circuits of the emergency door opening system considerably reduces the time required to open the bomb-bay doors for dropping the load in emergency.

Operation of 3NC-1 Electric Release Unit

The main part of the 3NC-1 electric release unit (Fig. 43) is housing 7 which encloses coil 1A having two windings. The coil contains stop 13 and armature 4. The coil is closely pressed against the housing by cover 3 screwed to it from the rear. Secured to the front end of the electromagnet is terminal block 9 with contacts and two pins of the plug connector built in it. Block 9 is protected with cover 10. Armature 4 freely travels within the coil, sliding along two guides of stop 13 and along ring 6.

The 3NC-1 electric release unit operates similarly to a pull-in relay. When the electromagnet circuit is closed, armature 4, actuated by electromagnetic force, is pulled into

the coil. The electromagnet coil comprises the principal and auxiliary windings.

The principal winding is intended for starting current of a short duration; this current considerably exceeds the current required to hold the armature of the switched-on electromagnet. Consequently, the electric release unit is designed in such a way that the armature at the end of its travel cuts in the auxiliary winding thus opening contacts 11. In this instance an additional resistance is introduced in the electric circuit, the current considerably decreases thereby lowering power consumption for the whole period of the electromagnet operation. The armature remains in this position until the external circuit of the electromagnet is disconnected. As soon as the current in the electromagnet coil circuit is interrupted the armature actuated by the retracting spring returns to its original position. While pulled into the coil armature 4 kinematically connected with release lever 26 (See Fig. 36) releases piston rod 23.

Basic Specifications of 3NC-1 Electric Release

	Unit
Armature travel .....	8 ± 0.5 mm
Traction effort, at 24 V .....	at least 13.5 kg
Spring effort .....	from 0.5 to 1.0 kg
Power supplied .....	26.5 V, D.C.
Current, at 26.5 V	
(a) at the moment of cutting in .....	not over 12 A
(b) during operation .....	not over 2.2 A

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

Bomb-Bay Door Opening on the Ground  
(with Aircraft Mains De-Energized)

The aircraft bomb-bay door control system serves to open the bomb-bay doors on the ground with the aircraft electric system de-energized. The bomb-bay door control system is operated by a switch located on the pilot's control panel (Fig. 37).

In this case the bomb doors are opened by the springs after the 3MC-1 electric release unit of the stand-by system has operated. After turning on the switch, power for the 3MC-1 electric release unit is supplied from the aircraft storage battery system.

Basic Specifications of Bomb-Bay Door  
Control System

- Hydraulic fluid working pressure ..... 150 kg/cm<sup>2</sup>
- Bomb-bay door opening duration:
  - for normal control (by the hydraulic drive) not over 2 sec.
  - for stand-by control (by the spring) ..... not over 3 sec.
  - for emergency control (by the springs) .... not over 3 sec.
- Bomb-bay door closing duration:
  - for normal control (by the hydraulic drive) not over 3 sec.
  - for stand-by control (by the drive from the hydraulic brake system) ..... not over 10 sec.

Control System of Doors of Compartment for  
Communication and Signalling Equipment

The signal flare bomb (HOCAB) compartment door control system incorporates a two-way pneumatic drive, bell crank, rods and a spring.

The door control is effected only by the pneumatic drive from the aircraft pneumatic system with the assistance of the

pneumatic valve located on the navigator's right-hand control panel.

Similar to the bomb-bay doors the signal flare bomb compartment doors are locked in the CLOSED position by a ball lock mounted in the pneumatic drive cylinder.

The doors are opened in the manner given below.

When the pneumatic valve lever is set in the OPEN (OTKRYT) position (Fig. 44) and held so until the indicator light on the HOCAB colour flare bomb panel comes on to indicate that the doors are open, compressed air is supplied to the pneumatic drive cylinder through the pressure delivery connection. Since the pneumatic drive piston is locked by the ball lock (Fig. 45), the compressed air shifts ball lock sleeve 4 thereby compressing spring 3 of the sleeve. As a result, piston 6 under the air pressure starts moving because the piston-locking balls have fallen inside the piston.

Actuated by the piston the piston rod comes out of the cylinder, turning bell crank 2 (Fig. 46); rods 3 attached to bell crank 2 and to the door front edges open the bay doors.

The compartment doors are secured in the OPEN position by the rods which in conjunction with the bell crank make a kinematic lock. After the compartment doors have been opened, the pneumatic valve handle is set to the original (middle) position.

The HOCAB compartment door closing is carried out by setting the pneumatic valve handle in the CLOSED position and holding it so until the indicator light on the HOCAB colour flare bomb panel lights up to show the doors closed position.

In this case the compressed air is delivered into the pneumatic drive through the pressure delivering connection.

At the end of its travel length the pneumatic drive piston gets automatically locked by the ball lock. After the compartment doors have been closed, the pneumatic valve handle is again put to its original position.

Rated working pressure in the aircraft pneumatic system

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

equals 150 kg/cm<sup>2</sup>.

The duration of door opening and closing does not exceed 2.5 sec.

Pneumatic Drive of Doors of Compartment  
for Communication and Signalling Equipment

The pneumatic drive (See Fig. 45) serves to open and close the doors of the compartment for communication and signalling equipment. The pneumatic drive comprises an actuating cylinder, piston 6, piston rod 7, a ball lock and piping to supply compressed air to the cylinder.

Welded on the line-of-closing side is connection 12 through which compressed air is delivered to the cylinder; mounted in the cylinder is bush 9 which serves to guide the piston rod. The bush by its bead bears against the cylinder end and is fixed by special nut 10. Fitted in the groove on the outside surface of the bush is rubber sealing ring 11.

Screwed to the cylinder on the line-of-opening side is a ball lock.

The ball lock consists of housing 2, retracting spring 3 and sleeve 4.

Compressed air is delivered into the chamber of opening through connection 1 threaded into the ball lock housing.

Sleeve 4 travels inside the lock housing. The sleeve tongue holding the balls is bevelled. The other end of the sleeve has a bead by means of which it is held in the circular recess of the housing in the LOCK CLOSED (ЗАМОК ЗАКРЫТ) position.

Piston 6 with piston rod 7 travels inside the cylinder. The piston rod is a tube. Screwed to one of its ends is eye bolt 8 which secures the piston rod to the compartment door control bell crank at frame No. 49. The other end of the piston rod carries piston 6 secured with a nut. The sealing between the piston and the cylinder is effected through rubber sealing ring 5.

50X1-HUM

To lessen friction and to lubricate the cylinder face, felt gaskets 13 are placed in the ring grooves of the piston. Drilled in the piston are nine equidistant radial holes for the balls of the lock.

Basic Specifications

Pull travel of piston .....	162 ± 0.5 mm
Lock sleeve travel .....	6 ± 0.2 mm
Sleeve travel when ball lock is released .....	not over 4 <sup>+1</sup> mm
Piston rod axial clearance with piston	
LOCKED .....	not exceeding 0.25 mm
Ball lock release pressure .....	not over 5 kg/cm <sup>2</sup>

The compartment door open and closed position signal circuits are closed by microswitches mounted in the compartment. The microswitches are actuated by the rests screwed into the rocker. The brackets mount four microswitches, type EK2-142B (See Fig. 46).

Switch 5 is mounted independently and, when pressed, indicates that the compartment doors are closed. The other three switches are installed together on a common base and are intended for the following: switch 8 for blocking the circuit of combat release, switch 7 for blocking the circuit of emergency release, and switch 6 for indicating the door open position.

The switches are adjusted by the rests. The adjustment being completed, the additional travel of every switch button (after its tripping) should be at least 2 mm.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 61 -

50X1-HUM

## Chapter IV

## HOISTING SYSTEM

The hoisting system is intended to load and unload the aircraft with bombs.

The system is designed to hoist bombs from 250- to 3000-kg calibre.

Besides, the hoisting system provides hoisting of the bomb racks during their installation in the aircraft.

Bomb hoisting is performed with the assistance of the EN-473M electromechanical hoists in conjunction with special sheave blocks, hoisting slings, beams and other accessories. The electromechanical hoist system is remotely controlled and convenient in operation as it provides, for a quick loading of the aircraft with bombs.

The hoist system incorporates the following parts and assemblies:

Electromechanical hoists EN-473M .....	Req'd 2 sets
Hoisting beams .....	4 pos
Movable blocks .....	2 pos
Two-sheave end pulleys .....	2 pos
Single-sheave end pulleys .....	2 pos
Hoisting frame .....	1 pc
Twin guy .....	1 pc
Guides KИ3-547H .....	4 pos

Hoisting hooks ИК3-53 .....	2 pos
Hoisting slings .....	3 pos
Hoisting sling cables .....	2 pos
Hoist cable, 50 m. long .....	2 pos
Pulleys for hoisting bomb racks .....	4 pos
Hoist mounting brackets .....	4 pos

EN-473M Electromechanical Hoist System

The EN-473M electromechanical hoist system with its assemblies and units serves for hoisting and lowering bombs. The system comprises the following units:

Electromechanical hoists EN-473M .....	4
Rotary amplifier (amplidyne), type AMV-1 .....	4
Hoist system control boxes СУИ-473 .....	2
Control panels ИВИ-473 .....	2
Instrumentation and local power network flexible cables .....	2 sets

For convenience of operation the amplidyne, the control box and the instrumentation are mounted on a special hoist control system trolley, type ТСУИ-473, which is a part of the ground equipment.

When the electrical hoists are transported the control panel and the hoists are installed on the trolley; the flexible cables for connecting to the local power network are put into a special bag on the trolley and fixed with belts.

Power is supplied to the system from the aircraft mains via the receptacles placed in the junction boxes of the fuel pumps at frames No. 33 and 49, or from the ground power source.

During the process of hoisting or lowering bombs the bomb hoist control is accomplished by the operator from the ИВИ-473 control panel connected to the control box through a special flexible cable.

For the occasion of the system being de-energized the hoists are provided with accessories for manual operation.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 62 -

Basic Specifications

Hoist cable maximum allowable load .....	500 kg
Power consumed by the system at simultaneous operation of two hoists having a cable load of 500 kg each .....	no less than 4 kW
Power supply operating voltage .....	27 ± 2.7 V
Maximum hoisting speed when lifting loads up to 500 kg (electric drive) .....	no less than 4 m/min.
Minimum hoisting speed when lifting loads up to 500 kg (electric drive) .....	not exceeding 0.5 m/min.
Reducer-to-drum ratio:	
electrically driven .....	362
manually driven .....	14.6
Effort on manual drive crank when hoisting weight of 500 kg .....	15 kg
Cable travel speed when manually driven at n = 35 r.p.m. ....	1 m/min.
Length of hoist cables (for bombs hoisted to bomb racks) .....	20 m.
Cable diameter .....	5 mm
Weight of the set of hoists and control system ...	not exceeding 185 kg

EM-473M Electromechanical Hoist

The EM-473M hoist (Fig. 47) is a load-lifting machine operated by electrical and manual drives.

The hoist is designed for a maximum cable load of 500 kg. In hoisting bombs weighing above 500 kg a pulley block is used.

The hoist mechanism is mounted in a housing and consists

50X1-HUM

of a drive motor installed inside a drum, five pairs of spur gear wheels, one pair of bevel gears and friction clutches.

The friction clutch is mounted on the motor shaft to prevent the hoist cable from damage when the load is jammed. When the cable loading exceeds the allowable value the friction clutch slips. The hoist is equipped with an electromagnetic brake, which serves to hold the weight when the system is de-energized.

The cable is attached to the drum by the cable thimble and can be easily detached. When a bomb is hoisted or lowered, the hoist must be attached to the butt ends of the bomb-bay doors by means of a mounting bracket. The hoist is attached by three pins inserted in the holes of the bracket. One of the pins has a slit nut.

AMV-1 Rotary Amplifier

The AMV-1 rotary amplifier (amplidyne) is intended to supply current to the hoist drive motors. It is a unit consisting of a motor and a special generator which are mounted in a single housing and are set on a common shaft. Power to the amplidyne motor is supplied from the 27-V aircraft mains. The amplidyne is mounted on the TCVM-473 trolley.

CVM-473 Control Box

The control box is intended for electrical equipment and is installed on the TCVM-473 trolley. The plug connectors on the side walls of the box serve to connect the control box to the control system assemblies. The electrical equipment providing normal operation of the power supply circuit of the system is mounted inside the box.

IVM-473 Control Panel

The control panel provides for remote control of the hoist drive motors. The control panel consists of a magnesium

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 64 -

case accommodating potentiometer mechanisms which react to speed changes in the hoist electric motors while hoisting or lowering bombs, and also control the electromagnetic clutches of the hoist brakes.

The top portion of the case mounts two starting buttons and a STOP button. Both hoists can be controlled from the control panel either separately or simultaneously.

For convenience the control panel is attached to a shoulder strap allowing the operator to place the panel on his chest when hoisting bombs.

#### Instrumentation and Local Power Network Flexible Cables

The instrumentation and the local power network flexible cables serve to exercise control over the current and voltage and also to provide for power supply to the electrical hoists.

The instruments are installed on the TCYH-483 trolley panel; they are two ammeters measuring the current consumed by the hoist drive motors, and a voltmeter indicating the input voltage of the control box.

General Information on System of Electromechanical Hoists. The system of the EN-473M electromechanical hoist (Fig. 48) is a removable type of equipment.

In the process of bomb hoisting the TCYH-473 trolley is driven to the port side of the aircraft. The top cover of the trolley being opened, the nuts are unscrewed and the electric hoists removed.

Then the hoists are installed on the bomb-bay door butt ends, the control panel is removed from the TCYH-473 trolley and the feeder cables are connected to the hoist system units and to the aircraft mains. The hoist cables are laid on the hoisting pulleys in accordance with the load variant scheme adopted, and their ends are connected to the MK3-53 hoisting hooks or to the hoisting sling.

50X1-HUM

Pressing the START button on the control panel supplies power from the aircraft mains to the amplidyne motor.

Moving the control panel handle from the neutral position will cause either hoisting or lowering bombs. The rate of hoisting or lowering depends on the angle through which the handle is turned. To stop the hoisting or lowering the control panel handle should be returned to the neutral position.

If it is required to control two hoists simultaneously, both handles on the control panel should be smoothly turned in respective directions.

When the system is de-energized the hoisting or lowering may be effected manually.

In the latter case the manual drive crank is attached to the crank adapter of the hoist. The position of the crank with the load hoisted is safety-locked.

#### Hoisting Beam

To hoist bombs weighing over 500 kg, hoisting beams (Fig. 49) are installed on the top cross bars of two opposite bomb racks. The beams carry the weight and guide the cable during the process of hoisting.

The hoisting beam consists of two channels and two plates riveted together to form a box section. Rigid and elastic guides for the cables are mounted inside the beam. A rigid guide is a U-shaped member secured in the beam.

An elastic guide is a plate spring loosely set on an axle. The spring is supported by a coil spring set on the same axle.

The elastic guide (depending on the calibre of the bomb being hoisted) either fills the gap between the pulley and the rigid guide, or is pressed upward by the frame of the removable block set on the axle under the mark <sup>500</sup> 3000. The beam has two sheave blocks mounted on easy-to-remove bolts.

The middle portion of each beam has four holes to install

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 66 -

the sheave blocks in accordance with the scheme of hoisting. Each of the holes is designated with the calibre of the bomb to be handled.

A stamped boss is bolted to one of the beam ends. By an easy-to-remove bolt the boss is connected to the twin guy which is used when a high explosive bomb (AB-3000) is hoisted to the bottom latches of the rack.

Two brackets securing the beam to the bomb rack are bolted to each side of the beam. By special pins the beam is secured to the attachment assemblies of the bomb racks.

#### Movable Blocks

Movable block 1 (Fig. 50) serves to guide the hoisting sling travel and to form a pulley block. It is used when bombs up to 3000-kg calibre are hoisted.

The most important part of the movable block is the welded frame. Three pulleys, 77, 97 and 126 mm in diameter, are mounted on the axles between the frame cheeks. The frame prevents the hoist cable from slipping off the pulleys during hoisting.

#### Two-Sheave End Blocks

Two-sheave end block 4 (Fig. 50) serves to guide the cable travel and to form a pulley block. It is used when high explosive bombs from 250- to 3000-kg calibre are hoisted.

Two-sheave end block has a welded frame. One side of the frame has a hole to secure the block to the aircraft structure. Between the frame cheeks two pulleys, 77 and 97 mm in diameter, are set on the axles.

Mounted on the axle of the smaller pulley is a rocker to secure a cylindrical terminal of the cable.

Two-sheave blocks are secured to the aircraft structure on frame No.33 by easy-to-remove bolts.

- 67 -

50X1-HUM

#### Single-Sheave End Blocks

Single-sheave end block 6 (Fig. 50) serves to guide the cable travel when bombs of 500-kg calibre are hoisted.

The main part of the end block is the welded frame one side of which has a hole to secure the block to the aircraft structure.

A pulley, 77 mm in diameter, is held by an axle between the frame cheeks. Single-sheave end blocks are secured to the aircraft structure on frame No.49 by easy-to-remove bolts.

#### Hoisting Frame

Hoisting frame 3 (Fig.50) serves to guide the cable when the high explosive bomb, type AB-3000, is hoisted to the bottom station. The hoisting frame is welded of pipes and shaped members.

Bosses are welded to the ends of the larger pipe. Two pulleys, 86 mm in diameter, are set on the axles between the shaped members. For hoisting bombs the frame is installed on the latches of the K14-388 bomb rack.

#### Twin Guy for Hoisting AB-3000 Bombs

Twin guy 5 (Fig. 50) serves to guide the cable when the AB-3000 high explosive bomb is hoisted to the bottom station. The twin guy consists of a frame for pulleys and forks interconnected with cables. Two pulleys, 86 mm in diameter, are set on the axles on one end of the frame cheeks. The other end of the cheeks holds welded bushes securing the cable terminals. The opposite ends of the cables also secured in bushes are threaded to the forks. The forks serve to attach the twin guy to the hoisting beams with easy-to-remove bolts.

#### Guides for Hoisting AB-250 Bombs

K13-547H guides 2 (Fig. 50) facilitate bomb hoisting (250-kg calibre) to the bomb rack. Such bombs are hoisted

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

- 68 -

with a single cable. The guides are attached to the bomb rack beams. The guides are removed after the hoisting procedure.

#### HK3-53 Hoisting Hook

When hoisting bombs up to 500-kg calibre HK3-53 hoisting hook 7 is used (Fig. 50). The hoisting hook has a pawl which is inserted into the shackle neck and two seats for placing the bushes of the hoist cable ends.

#### Bomb Hoisting Sling

A special sling is used to hoist high explosive bombs, type FAB-3000.

On its ends the sling has sockets serving to secure the cylindrical terminals of hoisting cables.

The sling has marks made in red enamel which show a correct position of the sling relative to the suspension bands. The rest plates determine the position of the sling relative to the centre of gravity of the bomb. The front edge of the hoisting sling rest plates must be in the area of the arming retainer.

#### Hoisting Sling Cables

The hoisting sling cables, 8 mm in diameter, are intended to hoist the bombs, type FAB-3000. There are sling cables of two kinds: the first is called a long cable and is 14.8 m. long, and the second is called a short cable which is 13.75 m. long. The short cable is laid on the hoist system pulleys of that side of the aircraft where the bomb is to be hoisted. The long cable is laid on the opposite side.

In order to connect to the hoisting slings the hoisting sling cables have cylindrical terminals, 13 mm in diameter and 34 mm long. The cables are designated in the following

- 69 -

50X1-HUM

way: the long cable is lettered with A (long) and the short one is lettered with K (short).

#### Sheave Blocks to Hoist Bomb Bays

The hoisting sheave blocks guide the cable when the bomb rack is being hoisted. The main part of the block is the frame with a hook welded to it. A sheave, 92 mm in diameter, is placed on an axle between the frame cheeks.

To hoist the bomb rack the hooks of the sheave block are secured to the lugs located on the horizontal beam.

#### Mounting Bracket for EJL-473M Hoist

The mounting bracket serves to attach the electromechanical hoist to the butt ends of the bomb-bay doors.

The mounting bracket is welded of steel sheets and consists of the following parts:

- (a) pocket for the hoist front boss;
- (b) pulley to guide the cable;
- (c) rear assembly to secure the hoist;
- (d) three pins; two of them are fixed and the third has a slit nut and can move axially;
- (e) nuts and washers necessary to secure the rear

assembly of the mounting bracket to the electric hoist base.

The mushroom-shaped pin heads are inserted into the slots on the butt ends of the bomb-bay doors, the moving pin being secured with a nut. The mounting brackets are also used to put the hoists in the stowed position.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM

## Chapter V

### INSTALLATION OF BOMB RACKS AND BOMB HOISTING

The hoisting of bomb racks (Fig. 51) for their mounting in the aircraft is accomplished by the assistance of the BR-473M electromechanical hoists and the system of pulleys.

Every bomb rack is secured to four attachment assemblies of the aircraft. The pins of the top attachment assemblies of the bomb rack are inserted in the holes of the top fuselage boom, while the holes of the conical assemblies are matched with the holes in the beam of the bomb rack to receive easy-to-remove bolts.

The number and location of bomb racks are determined by the bomb suspension variants.

To show how the bomb racks must be arranged in accordance with a given bomb load variant there are patterns and bomb load variant tables on the inner skin of the starboard door of the bomb bay. Made in paint on the beam are assembly numbers and calibres of bombs to be hoisted. The right-hand bomb racks are mounted on the starboard side, while the left-hand racks are mounted on the port side. Alongside with the bomb racks which are installed for carrying bombs the unloaded bomb racks that could be used for other bomb load variants are fixed in the stowed position or removed from the aircraft.

For putting the bomb racks in the stowed position, the beam and the top fuselage boom are fitted with non-load-

carrying attachment assemblies at frames Nos 46 and 48. On these additional assemblies bomb racks are mounted as follows: the right-hand bomb rack is fixed on the port side, while the left-hand one is fixed on the starboard side.

The bomb racks mounted, the power supply bunched conductors from the aircraft mains are connected to the bomb rack plug connectors, the plug connector number being matched with the attachment assembly number.

The power supply bunched conductors of the aircraft mains are not connected to the plug connectors of the bomb racks put in the stowed position. They are attached to the sockets of the stowed position in accordance with their numbers.

#### Installation of Bomb Racks

To install the KJ3-488 and KJ4-388 bomb racks in the aircraft, the following should be done:

1. Install the BR-473M electromechanical hoist on the rear butt end wall of the bomb-bay doors.
2. Direct the cable from the hoist via the end pulley to the hoisting pulley and connect it to the adapter on the rack.
3. Hoist the bomb rack.
4. Bring the top pins of the bomb rack attachment into the holes of the assemblies on the horizontal fuselage boom. Install the bottom attachment assemblies of the bomb rack on those of the beam, align their holes and couple them with easy-to-remove bolts.
5. Connect the bomb rack plug connector to the aircraft mains.

Bomb racks can be hoisted simultaneously to both sides. The dotted line in Fig. 52 shows the hoist cable ready for hoisting bomb racks.

#### Hoisting Bombs to KJ3 Bomb Rack

The  $\Phi$ AB-250 bombs are hoisted to the KJ3-488 bomb rack by one BR-473M hoist installed on the mounting bracket on

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 72 -

the forward butt end of the bomb-bay door of the side which is to be loaded (Fig. 53).

To ensure a smooth entering of the bombs the K13-547H roller guides are installed on the bomb rack beams. First, loaded are the racks of the first row, then, of the second row, and, finally, of the third row. Mounted in the forward portion of the bomb bay is a two-sheave end block. The hoist cable from the hoist is directed via the two-sheave end block to the bottom and top pulleys of the bomb rack, then brought downwards and connected to the K13-53 hoisting hook, which is engaged with the bomb shackle neck.

The shackle is locked on the bomb by pressing the carrying hooks against the bomb lugs. The cable having been laid and connected with the hook, the bomb is hoisted by smoothly turning the handle of the control panel.

The hoisting of the  $\Phi$ AE-250 bombs can be done by two hoists to both sides simultaneously.

The dotted line in Fig. 53 shows the cable ready position for hoisting the  $\Phi$ AE-250 bombs.

The hoisting of the  $\Phi$ AE-500 bombs is performed by two hoists also mounted by means of the mounting brackets on the forward and aft butt ends of the bomb-bay doors of the side that is to be loaded (Fig. 53).

For arranging the hoist cables, a two-sheave pulley (in the fore portion of the bomb-bay) and a single-sheave pulley (in the aft portion of the bomb-bay) are provided.

The way of the cable from the front hoist is identical to that used for hoisting the  $\Phi$ AE-250 bomb.

From the rear hoist the cable runs via the single-sheave end pulley to the bottom and top pulleys of the bomb rack to come to the pulley of the hoisting beam.

The cable terminal is brought under the bomb body and inserted into the second socket of the K13-53 hoisting hook. This done, the bomb is hoisted by a slow turn of the handle of the control panel. The solid lines in Fig. 53 show the

cable arranged for hoisting the  $\Phi$ AE-500 bombs to the K13-488 bomb rack.

#### Hoisting Bombs to K14 Bomb Rack

To the K14 bomb rack bombs are hoisted by two hoists (Fig. 54).

Loading of the aircraft with bombs in accordance with the accepted bomb load variant is accomplished in two rows, the hoists being mounted on the rear butt ends of the bomb-bay doors to hoist the bombs of the first row and on the forward butt ends to hoist the bombs of the second row of the bomb racks. From the hoists the cables run via the sheaves of the end and movable blocks to make a pulley block with their terminals secured in the sockets of the two-sheave blocks. The hoisting sling cable, which runs along the side of the bomb rack under loading, passes round the larger sheave of the movable block, over the bottom and top pulleys of the bomb rack and runs downwards where its terminals are secured in the sockets of the hoisting sling.

The hoisting sling cable of the opposite side passes round the larger sheave of the movable block and then via the bottom and top sheaves of the bomb rack runs to the pulleys of the hoisting beam.

If it is necessary to change the cable motion, the switching device located on the top cross bar of the bomb rack should be operated.

With the switching device handle in the extreme top position, the cable runs to the hoisting beam pulleys, while in the extreme bottom position of the switching device handle sends the cable down to the hoisting sling.

Then the cable terminals pass round the bomb body to be secured in the hoisting sling sockets. The cables being arranged to form a pulley block, the bomb hoisting is started; for this purpose the handle of the control panel is slowly turned from the neutral position.

50X1-HUM

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 74 -

In loading the aircraft with bombs and in assembling the pulley block the crew must be guided by the load variant pattern riveted to the inner skin of the starboard bomb-bay door and by the set of bomb hoisting diagrams (photos) supplemented to the aircraft Service Log.

Besides, to hoist the bottom  $\Phi$ AE-3000 bomb use is made of the twin guy and hoisting frame (Fig. 55).

The twin guy is secured to the lugs on the hoisting beam by easy-to-remove bolts, while the hoisting frame is mounted on the latches of the second station of the bomb rack.

In this case, the hoisting sling cable ends from the top pulleys of the bomb rack on the opposite side are brought to the hoisting frame pulleys, then, via the pulleys of the twin guy are put under the bomb body and are fixed in the hoisting sling sockets. This done, the bomb is hoisted by slowly turning the handle on the control panel.

The second shackle of the bomb rack (which is not used) is put in the stowed position on the brackets mounted on the back on the bomb rack.

Equipment Installation and Stowing Ready  
for Changing the Base

The bombs hoisted, the hoisting system parts and units are put in two bags to place them on a special shelf (Fig. 56) on the starboard side of the compartment for communication and signalling equipment where they are secured by special belts.

The bags are designed to contain the following units: the KJ3-547H guides, two-sheave end block, one-sheave end block, MK3-53 hoisting hook, pulley to hoist bomb racks, hoisting sling 3000, 8-mm hoisting sling cable, movable block, twin guy, hoist crank, 5-mm hoisting cable, and the block fastening belt.

The face wall of the shelf has a name plate listing the hoist system units to be placed in the bags.

- 75 -

50X1-HUM

In the stowed position the hoisting beams remain mounted on the attachment assemblies of the bomb racks. Two hoists are put in the stowed position on the platform in the compartment for communication and signalling equipment next to the shelf for the hoist system units. The hoists are secured in the stowed position in the same way as in the working position. Two BIL-473M hoists of the hoist system set are mounted on the RCVJ-473 trolleys.

Installation of KJ3 and KJ4 Bomb Racks  
When Changing the Base

When the aircraft changes its base all the bomb racks and the hoist system equipment are to be put in the stowed position (Fig. 57). The bomb racks are put in the stowed position by means of the main and auxiliary attachment assemblies on the beam. First put in three rows are the KJ3 bomb racks, followed by the KJ4 bomb racks mounted in two rows.

The four hoist beams are installed on the top cross beams of the two opposite KJ3 and KJ4 bomb racks.

All the parts of the hoist system equipment are put in the two special bags and placed on the shelf in the compartment for communication and signalling equipment.

One set of the YBU fuze arming wire is put in a special case and suspended from the shackles of the KJ3 bomb rack (second and third row) on the starboard or port side.

The remaining fuze arming wire comprised in a single set is transported by railway.

Two hoists are installed in the stowed position in the compartment for communication and signalling equipment and the remaining two are mounted in the stowed position brackets in the rear portion of the bomb bay, on both sides.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

Ground Set of Bombing Equipment

The ground set of the bombing equipment is intended for use while working in the bomb bay (Fig. 58). The set comprises the catwalk and the service ladder.

The catwalk is a rigid platform the frame of which is made of shaped members located on the sides, riveted together with the assistance of transverse ribs and faced with duralumin sheets. For safety reasons the top surface of the platform has a checkered rubber lining. Riveted to both ends of the catwalk are welded brackets and tubes.

The tube of the welded bracket encloses an axle travelling in the longitudinal direction. Secured to the bottom end of the axle is a handle. To install the catwalk in the bomb bay the handles are depressed, the axle ends are inserted in the gap between the doors and the fuselage edges, and the catwalk is placed on the top bars of the bomb-bay doors.

The service ladder is a truss welded of steel tubes.

Chapter VI

FUZE ARMING SYSTEM

Fuze Arming Wire

YBI fuze arming wire is used in the aircraft to lock and control the fuzes of all the bombs available.

The arming wire provides locking of the following fuzes:

1. Standard vane-type fuzes having no delayed cocking mechanism (MJB) and also fuzes BJB-1, BJB-2 and BFB-1.
2. Vane-type standard and time fuzes (having MJB delayed cocking mechanisms) such as ANVB-1 with MJB-1 mechanism, AM-4 and AM-6 with MJB-2 mechanisms and TM-24A and TM-24B with the MJB-4 mechanisms.

Main Technical Data

Allowable effort on wire snap hook  
 when unlocking the fuze ..... up to 35 kg  
 Wire diameter ..... 3 mm  
 Inside diameter of arming ring of YBI  
 system ..... 28 mm

The following types of arming wire are used in the aircraft:

- (a) fuze arming wire Nos 1 and 2, double arm, non-folding;
- (b) fuze arming wire No. 6, double arm, folding.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 78 -

The fuze arming wire, which locks the fuzes of the bombs of 250- to 3000-kg calibre, is numbered. Fuze numbers for respective bombs are given in Table 5.

Service sets of fuze arming wire used in the aircraft are listed in Table 6.

Double-arm, non-folding fuze arming wire No.1 consists of wire 1 (Fig. 59), 3 mm in diameter, looped at several points. The loops limit the sliding of the S-shaped hook connected to a snap hook.

The arming ring serving to hold the wire in the bomb rack shackle arming retainer is placed in the double loop in the middle of the rod.

Put on the wire ends, between the loops, are S-shaped hooks connected to snap hooks. The snap hooks are provided for holding the arming forks locking the vanes of the fuzes used without the delayed cooking mechanisms МДВ-1, МДВ-2, or МДВ-4.

Each wire has a tag with the wire number stamped on it.

Unlike wire No.1, double-arm folding fuze arming wire No.6 has the forward and aft arms made separately and connected by means of the arming ring which allows them to be folded. The tag with the wire number is fixed to the double loop of the forward arm.

Table 5

Bombs whose fuzes can be locked with fuze arming wire YBII

Nos	Bomb designation	Fuze designation	Wire to be used, No.
1	2	3	4
1	3AB-100	АПУВ-1, AB-1Д/У, АДЛ-М, АПУВ-1 with МДВ-1, ВДВ-1, ВДВ-2	1
2	ФAB-250 M46, ФAB-500 M46	АПУВ-1, AB-1Д/У, АДЛ-М, АПУВ-1 with МДВ-1, ВДВ-1, ВДВ-2	2

50X1-HUM

1	2	3	4
3	CAE-100-90	TM-24, TM-24 with МДВ-4	1
4	ФAB-100-HB	АПУВ-1, AB-1Д/У, АДЛ-М, АПУВ-1 with МДВ-1, ВДВ-1, ВДВ-2, AM-A, AM-A with МДВ-2	1
5	ФAB-3000 M46	АПУВ-1, AB-1Д/У, АДЛ-М, АПУВ-1 with МДВ-1, ВДВ-1, ВДВ-2	6

Note: The bombs are equipped with fuzes in accordance with the Manuals and Instructions that exist in the Air Force.

Table 6

Sets of Fuze Arming Wire YBII and Their Application in Aircraft

Nos	Arming wire, No.	Quantity per set	Quantity per aircraft
1	1	24	48
2	2	24	48
3	6	4	4
4	Arming wire for flare bomb (CAE)	24	48
5	Arming fork	-	96

In the process of arming the bombs with fuzes having delayed cooking mechanisms (АПУВ-1 with МДВ-1, AM-A with МДВ-2, TM-24 with МДВ-4, ВДВ-1 and ВДВ-2) the cooking lugs of the delayed cooking mechanisms or fuzes are connected directly to the snap hook of the rod (Fig. 60).

If the bomb has one fuze, only one arm of the YBII wire is used; the other arm remains free.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 80 -

When the CAE-100-90 bombs are suspended, an additional piece of cable with a fork (Fig. 62) is connected to the snap hook of the tail arm to lock the tail fuze vane (Fig. 61).

The additional arming cable for flare bombs (CAE) consists of a double-folded 2-mm steel wire rope. The cable ends are pressed in a steel tube lettered CAE. One of the cable loops holds the snap hook.

When a bomb is dropped ARMED, the bomb shackle arming retainer holding the arming ring of the YBH wire remains closed. The lug (pin) of the delayed cocking mechanism becomes pulled out by the snap hook, and the bomb drops ARMED.

When a bomb is dropped SAFB, the bomb shackle arming retainer opens to release the arming ring of the YBH wire and the bomb drops together with the arming wire holding the fuzes in the SAFB position.

50X1-HUM

Chapter VII

BOMBING EQUIPMENT ELECTRICAL CONTROL SYSTEM

The bombing equipment electrical control system incorporates control assemblies, actuating and interlocking mechanisms, as well as communication and signalling facilities listed in table 7.

Table 7

Bombing Equipment Control System Assemblies and Their Location in Aircraft

Nos	Description	Type or index	Qty	Location
1	2	3	4	5
1	Bombsight with course stabilizer (set)	ONE-11p	1	Frame No.2, along aircraft axis
	Computer	11p-P	1	Frame No.2, port side
	Altitude unit	11p-B	1	Frame No.2, star-board side
	Air speed transmitter	IC-1200	1	Frame No.12, under central control panel

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 82 -

- 83 -

50X1-HUM

1	2	3	4	5	1	2	3	4	5
	Altitude transmitter	ДВ-15	1	At navigator-operator's station	4	Bottom bomb release panel (See Fig.7), incorporating:		1	Frames Nos 2 and 3, navigator's left-hand control panel
	Control box	11п-Y	1	Frame No.5, star-board side		Rack selector relay switch	2B-45	2	
	Dynamotor	YЭ-1с	1	Frame No.10, port side, under pilot's floor		Salvo switch	B-45	1	
	Electronic unit	11п-3	1	Frame No.11, port side, navigator-operator's desk	5	Bomb release variation box (See Fig. 27)	KBCE-48	1	Frames Nos 3 and 4, port side
2	Bomb release panel (See Fig.6), incorporating:		1	Frame No.3, navigator's left-hand control panel	6	Navigator's left-hand circuit breaker (ABC) panel (See Fig. 8)		1	Frames Nos 4 and 5, navigator's left-hand control panel
	Station status indicator lights	СМЛ-51 (red)	7		7	Bomb-bay door control panel (Fig.9), incorporating:		1	Frame No.3, navigator's right-hand control panel
	Packet-type switch	П-4	1			Bomb-bay door control switch	ПН-45	1	
	Station status indicator light	БК2-140В	1			Bomb-bay door open position indicator light	СМЛ-51 (green)	1	
	check button (with bomb doors closed)					Bomb-bay door closed position indicator light	СМЛ-51 (red)	1	
	READY TO DROP warning light	СМЛ-51	1			Master bombing switch	2B-45	1	
	Emergency release switch	B-45	1			ARMED indicator light	СМЛ-51 (red)	1	
	Emergency ARMED release switch	B-45	1			Bomb-bay door stand-by opening switch	ВН-45	1	
	KM3 rear bomb rack out-out relay switch	B-45	1						
3	Intervalometer (See Fig.26)	3CEP-49A	1	Frame No.3, navigator's left-hand control panel					

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 84 -

- 85 -

50X1-HUM.

1	2	3	4	5	1	2	3	4	5
8	Bomb release switch (button) (See Fig. 31)	KCE-49	1	Frame No.2, starboard side	14	Pilot's control panel (See Fig.12), incorporating		1	Frame No.8, port side
9	Navigator's circuit breaker (ABC) panel (See Fig.10)		1	Frames Nos 3 and 4, navigator's right-hand control panel	15	Emergency bomb release control panel with mains de-energised (See Fig.12), which comprises:		1	Frame No.8 pilot's control panel
10	Signal flare control panel, incorporating:		1	Frame No.3, navigator's right-hand control panel		Arming switch	B-45	1	
	Intervalometer feed and arming interlocking relay	PT-40	1			Emergency bomb-bay door operation switch	KB6-2A	1	
11	HOCAE compartment door control panel		1	Frame No.4, navigator's right-hand control panel		Emergency bomb release relay switch	KB6-2A	1	
12	HOCAE compartment door operation control valve (Fig.44)		1	Frame No.4, navigator's right-hand control panel	16	Switch to open bomb-bay doors on the ground with mains de-energized (See Fig. 12)	BH-45M	1	Frames Nos 8 and 9, pilot's control panel
13	Pilot's instrument panel (See Fig.11), incorporating:		1	Frames Nos 5 and 6, port side	17	Pilot's hydraulic control panel (Fig. 37) with bomb door stand-by closing switch	BH-45	1	Frames Nos 6 and 7, along aircraft axis
	Emergency ARMED release switch	B-45	1		18	Navigator-operator's instrument panel (Fig. 13), incorporating:		1	Frames Nos 10 and 11, port side
	ARMED warning light	CJH-51 (red)	1			Bomb release button	KCE-49	1	
	Emergency bomb release switch	B-45	1			READY TO DROP warning light	CJH-51 (white)	1	
	Navigator's arming circuit interlocking switch	B-45	1						

SECRET  
NO FOREIGN DISSEM



NO FOREIGN DISSEM

- 86 -

- 87 -

50X1-HUM

1	2	3	4	5	1	2	3	4	5	
19	Navigator-operator's electrical panel. (See Fig. 14), incorporating:			1	Frame No. 12 navigator-operator's central control panel, along aircraft axis	22	Interlocking system switch box (See Fig. 63), which comprises:		1	Frame No. 33, along aircraft axis
	Bomb-bay lighting switch	B-45		1		Bomb-release circuit interlocking switches (for working in the bomb bay)	2B-45		3	
	Circuit breaker of the bomb-bay reflector dipoles	A3C-5		2		Warning circuit interlocking switch (for working in the bomb bay)	B-45		1	
	Circuit breaker of the NOCAE compartment reflector dipoles	A3C-2, left-hand A3C-15, right-hand		1 1		23	Bomb release limit switch box, which includes:		1	Frame No. 33, along aircraft axis
20	Fuel pump distribution box with receptacle of EJ-473M hoist plug connector	MP48H2H19		1	Frame No. 33, starboard side	Combat bomb release limit switches	BK2-142B		2	
21	Hydraulic system assemblies panel (See Fig. 32), which incorporates:			1	Frames Nos 33 and 34, starboard side	Emergency bomb release limit switches	BK2-142B		2	
	Bomb-bay door operation solenoid (main hydraulic system)	3M-12		1		Bomb release interlocking limit switch (with mains de-energized)	BK2-142B		1	
	Stand-by system solenoid for bomb-bay door closing (hydraulic brake system)	3M-12		1		Bomb-bay door open position warning limit switch	BK2-142B		1	
						Bomb-bay door closed position warning limit switch	BK2-142B		1	
						Emergency ARMED release limit switch	BK2-142B		1	

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 88 -

- 89 -

50X1-HUM

1	2	3	4	5	1	2	3	4	5
24	Dome lamp with red light filter indicating bombing circuits interlocking while working in the bomb bay	KOC-45	1	Frame No.33, bomb-bay top part, along aircraft axis	ARMED release warning relay	PII-2		1	
25	Stand-by system solenoid to open bomb-bay doors (See Fig. 36)	ЭЛС-1	1	Frame No.33, on bomb-bay door hydraulic cylinder	Bomb release distribution box (Fig.66), comprising:			1	Frames Nos 36 and 37, bomb-bay top part, along aircraft axis
26	Emergency system solenoid to open bomb-bay doors (See Fig. 36)	ЭЛС-1	1		Rear row KИ3 bomb rack disengagement relay	PII-3		1	
27	Emergency bomb release distribution box with circuit de-energized (Fig.64), incorporating battery-operated emergency bomb release relay (with mains de-energized)	K-50И	1	Frames Nos 34 and 35 bomb bay on aircraft left-hand side	Combat bombing relay MBH-48 arming mechanisms power supply relay	PII-6 PII-2		2 1	
28	Emergency bomb release distribution box (Fig.65), comprising:				Fuel pump distribution box with receptacle of БИ-473M hoist plug connector on it	EP48PK2HT9		1	Bomb-bay frames Nos 48 and 49, starboard side
	Emergency bomb release relay	K-50И	2		ИОСАБ compartment door closed position limit switch	EK2-142B		1	Frame No.49 ИОСАБ compartment
	Relay of emergency bomb release control	PII-2	2		ИОСАБ compartment door open position limit switch	EK2-142B		1	Bracket of the door control rod bell crank
				Frames Nos 34 and 35, in bomb bay on starboard side	ИОСАБ release interlocking limit switch	EK2-142B		1	Frame No.49; ИОСАБ compartment
					ИОСАБ emergency release interlocking limit switch	EK2-142B		1	Bracket of door control rod bell crank

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 90 -

- 91 -

50X1-HUM

Bombing Equipment Electrical Wiring

1	2	3	4	5
35	Red dome lamp interlocking limit switch, with landing gear retracted	EK-44	1	Frame No.13, nose wheel well
36	Spark extinguisher	HY-50	1	Frames Nos 4 and 5, port side
37	Course stabilizer	AP-5-2M	1	Frames Nos 1 and 2, along aircraft axis
38	Bomb rack KИ3-488 plug connector: assemblies 1 - 2 3 - 4 assemblies 6 - 8 assemblies 11 - 12	ИP28П7ИИ9	1	Bomb bay, starboard side
39	Bomb rack KИ3-488 plug connector: assemblies 1 - 2 3 - 4 assemblies 6 - 8 assemblies 11 - 12	ИP28П7ИИ9	1	Frame No.36
40	Bomb rack KИ4-388 plug connector: assemblies 5 - 7 6 - 9 assemblies 10 - 12	ИP48П20ИИ1	1	Frame No.39
41	Bomb rack KИ4-388 plug connector: assemblies 5 - 7 6 - 9 assemblies 10 - 12	ИP48П20ИИ1	1	Frame No.44
			1	Bomb bay, port side
			1	Frame No.40
			1	Frame No.47
			1	Frame No.40
			1	Frame No.46

The control mechanisms and the actuating and interlocking mechanisms are connected by means of common bunched conductors made of wire, type БНБЛ, having red sheath.

Bunched conductors from the front cabin pass through the airtight connectors installed at the bottom of frame No.12 to be connected to the combat and emergency bomb release split junction boxes, as well as to other units of the bombing equipment. The combat and emergency bomb release bunched conductors and their junction boxes are arranged separately. The emergency release system wires provided for the occasion of the mains being de-energized have a separate layout and are laid along the aircraft starboard side; the wires are commutated in the emergency bomb release distribution box (designed for the mains being de-energized) placed on frame No.34, starboard side.

For the circuit breakers and their consumers see Table 8.

Table 8  
Circuit Breakers and Their Consumers

Nos	Types of circuit breakers	Feeders	Consumer
1	A3C-5	YII	Bomb-bay door opening stand-by control
2	A3C-5	YII	Bomb-bay door opening normal control
3	A3C-2	BJI	Combat bombing control
4	A3C-2	EM	Combat bombing control
5	A3C-5	CB	Station status indication
6	A3C-15	BI	Bombsight and course stabilizer power supply
7	A3C-15	BE	Combat bombing

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 92 -

- 93 -

50X1-HUM

## Circuitry

Nos	Types of circuit breakers	Feeders	Consumer
8	A3C-2	BD	KJ3 bomb rack rear row disengagement control
9	A3C-5	BP	Rack selector relay power supply
10	A3C-10	BB1	Combat ARMED release circuit control
11	A3C-10	BB2	Emergency ARMED release circuit control
12	A3C-2	BJ	Emergency bomb release control relay
13	A3C-2	BE	Emergency bomb release control relay
14	A3C-5	BA	Emergency bomb release control

Bombs are suspended from the KJ3 and KJ4 bomb racks which in accordance with the number of stations, are equipped with the ПБД-48 electrified bomb shackle release units having combat and emergency release windings, the MBH-48 arming mechanisms and the BK-48 interlock switches.

The wiring of all the above mechanisms and interlock switches is arranged on the bomb racks and connected to the aircraft mains through plug connectors.

The circuits of the electrical bomb release equipment receive power from the dual feed buses of the aircraft mains via the circuit breakers of the navigator's station and via the time-lag and glass tube fuses placed in the bomb bay.

The bomb release (both combat and emergency) is interlocked with the bomb-bay door position to avoid a casual bomb release, with the bomb-bay doors closed. The interlocking is accomplished in such a way that power is supplied to the bomb release circuit only when the bomb doors are opened.

All the TV-16 aircraft are divided into two groups according to the types of the bomb equipment circuits: aircraft having circuitry arranged as presented in Fig. 67 and in Fig. 68.

The difference between the bomb release control systems is as follows: the aircraft equipped according to Fig. 67 have the modifications listed below:

(a) switch 73, type B-45 (Fig. 68), to open the bomb doors with the mains de-energized;

(b) separate ARMED circuits for the combat and emergency systems;

(c) battery-operated bomb release circuit (with the mains de-energized) is equipped with two (instead of one) in-series relays 63 of the emergency bomb release;

(d) relay 8, type RT-40 (to interlock the bomb door closing circuit in the emergency bomb release), is removed (See Fig. 67).

The operation of the bomb release control system (Fig. 58) is described below.

The electrical bomb release control system provides:

1. Bomb release by the two fully electrified systems (combat and emergency). In addition, it is possible to perform an emergency drop by the system fed from the batteries when the aircraft generators are either cut out or inoperative. The latter system is independent of the combat and emergency drop systems.

2. ARMED release only by the combat system (with the ARMED circuit breaker ON); this is accomplished by an in-train release (by pairs) from the ONE-11p bombsight contacts, actuated by the navigator's and navigator-operator's bomb release buttons.

3. Emergency ARMED or SAFE bomb release by throw-over switches at the navigator's and left pilot's stations. Irrespective of the position of the switches at the navigator's

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 94 -

station the pilot may release bombs ARMED or SAFE, if necessary, (the navigator and the navigator-operator can perform combat ARMED drop if at the same time the pilot does not perform an emergency SAFE release).

4. ARMED or SAFE bomb release with the mains de-energized. The navigator can perform an emergency SAFE release with a single movement of his hand. In the same way the pilot performs an emergency or top emergency bomb release. An ARMED release is effected by the same switches with previously turning on the ARMED position of the emergency and the top emergency arming systems (by previously operating the special switch).

The opening of the bomb-bay doors is effected in such a way that they open prior to the bomb release from the stations.

5. Elimination of casual bomb release when the aircraft is parked, during take-off, flight or landing. In the combat bomb release system it is performed by the master bombing switch (intervalometer, ARMED release), the knob of number of bombs per train (when the ЗСЕР-49А intervalometer is set to the ТРАИН-СЕРИЯ position), bomb release variation box switches (КБС-48) and by the interlock system preventing bomb release with the bomb doors closed or lower stations unreleased. In the emergency and top emergency bomb release systems it is effected by means of interlocking, which prevents bomb release with the bomb doors closed, and also prevents higher-stationed bombs from falling upon the lower-stationed ones.

6. Indication of the bomb door position, station status, power supply of the combat bomb release system (the intervalometer, ARMED system), and indication of the combat release system readiness to drop bombs (READY light). The station status indication system of the bomb racks is electrically independent of the bomb release and bomb-bay door interlock systems.

7. Checking of warning lights operation by means of a packet-type switch.

8. Checking the station status of the bomb racks (with

- 95 -

50X1-HUM

the bomb-bay doors closed) by pressing the button on the navigator's panel.

9. SAFE drop of a bomb when it casually falls from the shackle.

10. Release of bombs (suspended in two rows) from the bomb racks of the rear row and then of the forward row by operating the КБС-48 bomb release variation box.

11. Safety protection for the crew during the work in the bomb bay by using the packet-type switch which cuts out all the circuits controlling bomb release and bomb door operation.

12. Automatic opening of the bomb-bay doors prior to bomb release by the ОПС-11p bombsight.

13. Battery power supply for opening the bomb-bay doors during the work on the ground.

#### Bomb-Bay Door Operation Control

The bomb-bay door control is accomplished through the normal, stand-by and emergency systems.

The normal door control system ensures an automatic opening initiated by the ОПС-11p optical bombsight; it also ensures the door opening and closing effected by means of ИР-45 switch 3 (See Figs 67 and 68) installed on the navigator's right-hand control panel.

The bomb-bay doors are actuated through a hydraulic drive from the aircraft main hydraulic system.

The stand-by control system provides for opening and closing of the bomb-bay doors in case the normal control system is faulty. The doors open when ИР-45 switch 1 on the navigator's right-hand control panel is pushed to ON; the doors closing is performed when ИР-45 switch 2 on the pilots' middle control panel is actuated.

In the stand-by bomb door control system the bomb doors are opened by the twin springs and closed by means of the hydraulic drive of the aircraft hydraulic brake system.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

The emergency bomb door control system ensures opening of the bomb doors for an emergency bomb release only. The emergency control system is subdivided into the emergency control system fed from the aircraft mains and the emergency control system with the aircraft mains de-energized (top emergency); in the latter case 3NC-1 solenoid 61 is fed from the aircraft storage battery. The emergency system fed from the aircraft mains opens the bomb-bay doors when emergency release switch 52 at the pilot's station (Figs 67 and 68) or switch 53 at the navigator's station is turned on; when the mains is de-energized the bomb doors are opened by switching on emergency bomb release control panel 65 and B-45 switch 73 installed at the pilot's station.

When the emergency bomb door control system is employed, the doors are opened by the twin springs.

Normal Control System

1. Automatic bomb door opening by means of the bombsight. The warning and bomb door opening mechanism (placed in the bombsight) operates after the bombsight has been set into operation and before the sighting angle gets equal to the dropping angle. A current pulse via contact II of the course stabilizer passes over the YII2 conductor to 3M-12 bomb doors opening solenoid 6 which switches the main hydraulic system valves over to the bomb door opening.
  - The time interval between the bomb door opening and the beginning of bomb release by the bombsight may vary (from 3 to 21.5 sec.) and fully depends on the time of the bomb fall.
  2. The bomb doors are opened or closed by shifting BH-45 switch 3 (Figs 67 and 68).
- When switch 3 on the navigator's right-hand control panel is set to the OPEN position, power from bus 42 is supplied to 3M-12 bomb-bay door opening solenoid 6 via the A3C-5A through the YII1 and YII2 conductors, switching the main

50X1-HUM

hydraulic system valves over to the bomb door opening position. When switch 3 is in the CLOSED position, power from bus 42 via the A3C-5A, the YII1, YII4 conductors and then via the closed contacts of the door closing circuit interlock switch 7, through the YII7 conductor passes to 3M-12 bomb-bay door closing solenoid 9. The solenoid switches the main hydraulic system valves over to the bomb door closing position.

Stand-By Control System

The bomb-bay doors are opened by turning on BH-45 switch 1 on the navigator's right-hand panel. When switch 1 is ON, power from bus 41 via the A3C-5A and the YII-1, YII-2 conductors passes to 3NC-1 stand-by bomb door opening solenoid 4; the solenoid operates and releases the lock of the hydraulic cylinder to make the springs installed on the aircraft port side open the bomb doors.

The bomb-bay doors are closed when BH-45 switch 2 on the pilot's central control panel is turned on. When switch 2 is ON, power from bus 41 passes to 3M-12 solenoid 5 of the stand-by bomb door closing via the A3C-5A circuit breakers and the YII1 and YII4 conductors and then via interlock switch 7 of the bomb doors closing circuit; the solenoid operates and shifts the valves to the position of closing the bomb-bay doors by means of the hydraulic brake system.

Emergency Control System

1. Opening of the bomb doors by emergency drop switches 52 and 53 (Figs 67 and 68).
- When navigator's emergency drop switch 53 or pilot's switch 52 are ON, power from bus 47 is supplied to 3NC-1 solenoid 61 of the emergency bomb door opening via the A3C-5A circuit breakers, the BA1 and BA2 conductors, the closed contacts of emergency bomb release control relay 59 and the BA5 conductor.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 98 -

The solenoid operates to release the lock of the hydraulic cylinder, and the doors, actuated by the springs, open.

2. Opening of the bomb-bay doors, with the mains de-energized, with the assistance of emergency release control panel 65.

When the handle of control panel 65 is turned, the contacts of the KB6-2A limit switches (in control panel box 65) close and power from the storage battery through the 3C and 3C6 conductors passes to 3MC-1 solenoid 61 of the emergency bomb door opening. The solenoid operates to release the lock of the hydraulic cylinder, and the bomb-bay doors open actuated by the springs.

3. Opening of the bomb-bay doors, with the circuit de-energized, by B-45 switch 73.

When switch 73 is ON, power from the storage battery through the 3C and VII2 conductors passes to 3MC-1 stand-by bomb door opening solenoid 4. The solenoid operates to release the lock of the hydraulic cylinder, and the bomb doors open actuated by the springs.

4. Emergency opening of the bomb doors both with the mains energized (by actuating switches 52 and 53) and with the mains de-energized (power supply from the battery) by actuating control panel 65 is interconnected with the emergency bomb release. The emergency opening of the bomb doors with network de-energized by B-45 switch 73 is used chiefly during operations on the ground. Switch 73 is installed in the aircraft of later make; the switch ensures opening of the bomb-bay doors during the work on the ground in case the aircraft mains is de-energized or when it is impossible to supply power to the whole aircraft system.

According to the bombing equipment circuit diagram the opening and closing of the bomb doors is coordinated with the operation of the limit switches of the combat and emergency bomb release circuits and the bomb door open and closed position warning circuits. All the limit switches

- 99 -

50X1-HUM

are mounted in a box and are installed on frame No.33 in the bomb bay along the aircraft axis.

When the bomb-bay doors begin to open limit switch 12 opens, and red light 17 indicating the closed position of the doors goes out. When the bomb-bay doors are fully open, they close the limit switches of the following circuits:

(a) switches 10 and 11 of the combat bomb release circuit;  
(b) switches 54 and 55 of the emergency bomb release circuit;

(c) switch 72 of the emergency ARMED bomb release circuit;  
(d) switch 62 of the emergency bomb release with the mains de-energized;

(e) switch 20 of the door open position warning circuit.

In these circumstances signal light 14 (green) comes on supplied from bus 41 through the A3C-5A circuit breaker and the CB-1 conductor.

When the bomb doors begin to close, combat bomb release limit switches 10 and 11, emergency bomb release switches 54 and 55, emergency ARMED bomb release switch 72, emergency bomb release switch 62 (for the mains de-energized), and switch 20 of the bomb-bay door open position warning break the circuits of bomb release and warning, thus preventing the bombs from being released when the bomb doors are partly or fully closed.

When the bomb doors are closed, limit switch 12 closes, and red light 17 indicating the closed position of the bomb-bay doors comes on. Limit switch 72 of the emergency ARMED release circuit is installed in the aircraft because the normal bomb release circuit is separated from the emergency release circuit.

#### Bomb-Bay Door Position Indication

To ensure safety for the personnel working in the bomb bay when the aircraft is on the ground, interlocking switches are provided on the bottom part of frame No.33; three of them are double switches, type 2B-45 (7), and one is ordinary, type

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 100 -

B-45 (46). The switches are linked with a common bar to provide for simultaneous operation. The switches are connected to the circuits of the windings of the PI-6 bomb release blocking relays and of the solenoid-operated valves for closing the bomb-bay doors. During the work in the bomb bay, the switches must be set to OFF.

When the work on the ground is over, it is necessary to turn on the switches, otherwise the bomb-bay doors will not close and the bomb release circuits will be open. The bomb bay is equipped with red dome lamp 56 which indicates that switches 7 and 60 are ON and the bomb release circuits are not cut out. The dome lamp burns while the aircraft is on the ground; the lamp "minus" is connected to the airframe via limit switch 58 connected to the nose landing gear. When the L.G. is retracted, the minus circuit breaks and the dome lamp goes out.

#### Station Status Indication

The electrical station status indication system affords the possibility to check the presence of bombs irrespective of the bomb release system used and the position of the bomb-bay door interlocking system. The station status indication system of the given bomb racks is of a group type. Lights 19 indicating the station status are installed on the navigator's bomb release panel and are arranged in accordance with the bomb rack location in the bomb bay.

When the bomb-bay doors are open and the bombs are suspended from the bomb racks, power from bus 41 is supplied to indicator light contacts 19 via the A3C-5A circuit breaker, the CB1 and CB4 conductors, through the closed contacts of button 31, conductor CB3, contacts of packet-type switch 16 and conductor CB2. The minus circuits of the lamps are connected to the airframe through the interlock contacts of the bomb racks loaded with bombs. Lights 19 indicating the

- 101 -

50X1-HUM

presence of bombs on the corresponding bomb racks glow red. When the bomb-bay doors close, combat bombing relay 13 operates to break power supply to the indicator lights. The lights go out.

When the bomb-bay doors are closed, the electric circuit permits to check the station status when button 31 on the navigator's bomb release panel is pressed.

When button 31 is pressed, power from bus 41 is supplied to indicator lights 19; power is supplied through the A3C-5A circuit breaker, and the CB1, CB3 and CB2 conductors. Consequently, the lights whose minus circuits are connected to the airframe by the interlock contacts of the loaded bomb racks light up to indicate the presence of bombs on the bomb rack.

Packet-type switch 16 is installed on the bomb release panel to check the proper operation of the lights indicating the station status, ARMED release, READY TO DROP position, and the open and closed positions of the bomb-bay doors. When the button of the packet-type switch 16 is pressed, the circuits of indicator lights 19, 17, 18, 15 and 14 will get connected to the airframe (the common minus), and the lights will flash up supplied from bus 41 through the A3C-5A circuit breaker and CB1, CB2, CB22, BB9 and BF40 conductors. The lights which do not flash when switch 16 is pressed are faulty.

Packet switch 16 is not used to check the indicator lights of the 3CEP-49A intervalometer, READY TO DROP light 37 on the navigator-operator's instrument panel and ARMED release light 57 on the pilot's instrument panel.

#### Combat and Emergency Bomb Release

Combat bomb release is carried out by:

1. The navigator, who operates KCE-49 extension-type bomb release button 34, or the ONE-11p bombsight; in the latter case bomb release is effected automatically when the

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

- 102 -

- 10

50X1-HUM

contacts of the bombsight close at the moment when the sighting and dropping angles get equal.

2. The navigator-operator, who operates KCE-49 extension-type bomb release button 35, the navigator effecting opening of the bomb-bay doors and providing all bomb release data in this case.

An emergency bomb release can be carried out by the navigator or by the pilot independently, by operating switch 52 on the pilot's instrument panel or switch 53 mounted on the navigator's left-hand control panel. The emergency release, with the mains de-energized, can be effected from control panel 65 mounted on the port side, at the pilot's station.

Bomb Release by Combat System

For dropping bombs by means of the combat system the following is necessary:

- switch ON the ONE-11p bombsight;
- switch ON master bombing switch 39 (See Fig.66) on the navigator's right-hand control panel; as a result, power is supplied to the 3CEP-49A intervalometer and to ARMED release indicator lamps 15 and 57 mounted on the navigator's right-hand control panel and on the pilot's instrument panel. The lamps must light up red.

Prepare the 3CEP-49A intervalometer for operation by setting the appropriate devices in the SELECTIVE or TRAIN positions, and the KCE-48 bomb release variation box by setting the two switches of the rack selector relay and the salvo switch for single bomb or in-pairs salvos.

Open the bomb-bay doors by pressing switch 3 on the navigator's control panel. When the bombsight is used, the bomb-bay doors get opened automatically.

With bomb-bay doors fully open and the combat bomb release limit switches 10 and 11 closed, the PI-6 relay of the combat bomb release system operates to prepare all the circuits for

releasing the bombs; in these circumstances the READY TO DROP indicator light at the navigator's and the navigator-operator's stations will light up.

Press the navigator's bomb release button 34 or the navigator-operator's button 35 to effect the bomb release. If the bombsight is used, the bomb release is effected automatically at the moment when the sighting and the dropping angles get equal.

After master bombing switch 39 is turned ON (on the navigator's right-hand control panel), ARMED release indicator lights 15 on the navigator's right-hand panel and 57 on the pilot's control panel light up being fed from bus 41 through the A3C-10A circuit breaker, BB1 and BB3 conductors, closed contacts of the intervalometer and ARMED release power blocking relay 38 (mounted on the signal flare control panel) through the BB-40 conductor, normally-closed contacts of relay 70 ARMED release indication circuit (mounted in the emergency bomb release distribution box), and through the BB42 conductor. The lights glow red, thereby indicating that the system is prepared for ARMED release.

At the same time through the second pole of the master bombing switch power is supplied to terminal E of the intervalometer from bus 41 through the A3C-15A circuit breaker, BE1, BE2 and BE3 conductors, closed contacts of the intervalometer and ARMED release power blocking relay 38.

This done, the 3CEP-49A intervalometer is prepared for selective or train operation. To prepare the intervalometer for selective pulsing it is enough to put the TRAINSEL switch in the SELECTIVE (ОДНОВОЧНО) position. The indicator light on the intervalometer lights up to show that the instrument is energized.

When the electric intervalometer is to be prepared for automatic operation (for in-train pulsing) the TRAINSEL switch is put in the TRAIN (ЦЕРНА) position (which will not enliven the intervalometer indicator light). Then the interval control

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 104 -

knob must be operated to set the required interval between the falling bombs while the counter knob must be set to indicate the number of bombs per train. When the number of bombs per train is set, the intervalometer indicator light flashes on showing that the instrument is ready for operation and burns white till the required train of bombs is dropped; then it goes out.

The intervalometer being ready, prepare the KECE-48 bomb release variation box for operation. When the switches of rack selector relay 44 are turned on the bomb release circuits and the circuit of the READY TO DROP indicator light at the navigator's and the navigator-operator's stations get ready for operation. Salvo switch 45 is used to set one-bomb or two-bomb salvos.

**Note:** 1. It is imperative to turn on both switches 44 to provide for the required succession of bomb release indicated in the diagram of release (Fig. 67).  
2. The operation of the KECE-48 bomb release variation box is described above.

The intervalometer and the KECE-48 bomb release variation box having been prepared, in the process of aiming the warning and bomb-bay door opening indication mechanism of the ONE-11p bombsight operates to send a pulse through terminal I of course stabilizer 33 and the Y12 conductor to the winding of bomb-bay door opening solenoid 6. In addition to the automatic bomb-bay door opening initiated by the bombsight, the doors can be opened by turning on switch 3, power being supplied from bus 41 through the A3C-5A circuit breaker to the winding of bomb-bay door opening solenoid 6. At the beginning of the door opening limit switch 12 of the bomb door closed position indication system breaks the circuit and the indicator light (red) on the navigator's right-hand control panel goes out (it lights up when the circuit breakers are switched on before the flight). With bomb-bay doors fully open, limit switch 20 becomes closed and bomb-bay door opening indication light 14 mounted on the navigator's right-hand panel lights up (green) fed from bus 41 via the A3C-5A circuit breaker and cB1 conductor.

- 105 -

50X1-HUM

At the same time limit switches 10 and 11 of the combat bomb release circuit close.

All the bomb release circuits are connected with the normally-opened contacts of two PI-6 relays 13 which are mounted in the combat bomb release distribution box. The two PI-6 relays ensure a reliable operation of the combat bomb release circuit since, in case one of the relays fails, power to the circuits is supplied via the contacts of the other relay connected in parallel.

As long as the bomb-bay doors are closed, the PI-6 relay windings are de-energized, their paralleled contacts are open and the load drop is impossible because the KECE-48 bomb release variation box is de-energized. But as soon as the bomb-bay doors are open, combat bomb release limit switches 10 and 11 mounted in the limit switch box at frame No. 33 close to supply power to windings of PI-6 relays 13 from bus 41 through the A3C-2A circuit breaker, B12, B13, B13 conductors and the contacts of interlocking switches 7 which must be on.

PI-6 relays 13 will operate, their contacts will close and the circuits will be ready for bomb release. Power is supplied:

1. From switches 44 of the rack selector relay through the BE6 and BE9 conductors to the navigator-operator's READY TO DROP indicator light 37 and further through the BE9 conductor, packet-type switch contacts 16 and the BE40 conductor to the navigator's READY TO DROP indicator light 18. The lights will flash white, thus indicating that the bomb release circuits are ready for operation.

2. From bus 41 through the A3C-5A circuit breaker, B11 and B12 conductors, contacts of the rack selector relay switches, B16 and B17 conductors, B and E contacts of the KECE-48 bomb release variation box to the bomb control selector relays contacted to ground through the NEI-48 bomb shackle release unit windings preparing the relays for operation.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 106 -

In this case the bomb shackle release units will not operate as the current in their windings is insufficient.

3. From bus 41 through the A3C-5A circuit breaker, CB1 and CB4 conductors, closed contacts of station status indicator check button 32 (with the bomb-bay doors closed), CB3 conductor, contacts of packet-type switch 16, and the CB2 conductor to station status indicator lights 19. The lights of the bomb racks carrying even a single bomb will burn red.

In further aiming, at the moment when the sighting and the dropping angles coincide, the bomb release automatic mechanism of the bombsight sends out a current pulse to terminal A of intervalometer 36.

The intervalometer begins to operate sending pulses from terminal B through the BE5 conductor to the selector relays. Depending on the position of salvo switch 45 and on the bomb load variant the selector relays will operate either separately or together sending current pulses through the BE7 and BE8 conductors, respectively to the windings of the ПБД-48 bomb shackle release units with one or two bombs being dropped per salvo.

The first pulse from the intervalometer sent out to the selector relay after the first bomb has been released simultaneously comes to the electromagnet of the KИV-2 camera controller, thus actuating the АФА-33M aerial camera and, through the BE-5 conductor, terminal K of the course stabilizer to the winding of the ONE-11p bombsight relay. The relay operates to release the cocked bomb release button, thereby de-energizing all the elements of the bombsight automatic release.

When bomb release control is effected manually, a short-duration pressing of the navigator's bomb release button 34, installed at frame No.2, starboard, or of bomb release button 35 mounted on the navigator-operator's panel, sends out a current pulse through the BH3 and BH6 conductors to terminal A of intervalometer 36. The intervalometer in its

- 107 -

50X1-HUM

turn will send pulses via the selector relays to the ПБД-48 release units through the BE5, BE7, BE8 conductors. This results in releasing the bombs in accordance with the bomb load variant.

#### Sequence of Bomb Rack Operation

1. With switches 1 and 2 of rack selector relay 44 turned ON, the KИ3-488 bomb rack (Figs 67 and 68) mounted in three rows (in train bombing, one bomb per salvo) are unloaded as follows.

The first current pulse from the intervalometer is sent through the BE5 conductor to terminal Г of the KBC5-48 bomb release variation box. Then, from terminal Д of the bomb release variation box through the BE7 conductor, terminal 5 of plug connector 26 to the ПБД-48 release unit of the forward right-hand bomb rack; this results in releasing the first bottom bomb.

The second current pulse from the intervalometer comes to terminal Г of the KBC5-48 bomb release variation box and from terminal E of the KBC5-48 box through the BE8 conductor, via the closed contacts of relay 43, through the BE27 conductor, terminal 5 of plug connector 25 is fed to the ПБД-48 bomb shackle release unit of the left-hand rear bomb rack, and the bottom bomb will be released.

The third current pulse, like the first one, via terminal 5 of plug connector 26 gets to the ПБД-48 release unit of the forward right-hand bomb rack. This results in releasing the bomb from the higher station.

The following current pulse, like the second one, through terminal 5 of plug connector 25 is supplied to the ПБД-48 release unit of the rear left-hand bomb rack. This results in releasing the bomb from the higher station.

The subsequent current pulses are supplied to the forward right-hand bomb rack and the rear left-hand bomb rack in turn until they are fully unloaded.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 108 -

The following current pulse from terminal Д of the KBCE-48 bomb release variation box through the BE7 conductor is sent to terminal 5 of plug connector 26. It passes through the unloaded bomb rack of the starboard side, the BE10 conductor, via terminal 5 of plug connector 21 to the ПБД-48 bomb shackle release unit of the forward left-hand bomb rack. This results in releasing the bottom bomb.

The following current pulse from terminal E of the KBCE-48 box is supplied through the BE8 conductor, via the closed contacts of relay 43 and through the BE27 conductor to terminal 5 of plug connector 25. Further, through the unloaded bomb rack of the port side, BE18 conductor, and terminal 5 of plug connector 31 it is fed into the ПБД-48 release unit of the right-hand rear bomb rack. This results in releasing the bottom bomb.

The subsequent current pulses are sent to the forward left-hand bomb rack and the rear right-hand bomb rack in turn, until they are fully unloaded.

When the forward left-hand and rear right-hand bomb racks are fully unloaded, the subsequent current pulse from terminal Д of the KBCE-48 box is supplied to the ПБД-48 release unit of the left-hand middle bomb rack through the BE7 conductor, unloaded racks of the forward row, the BE14 conductor, closed contacts of relay 43, BE24 conductor, terminal 5 of plug connector 23. This results in releasing the bottom bomb.

The following current pulse from terminal E of the KBCE-48 bomb release variation box is supplied to the ПБД-48 bomb shackle release unit of the middle right-hand bomb rack through the BE8 conductor, closed contacts of relay 43, BE27 conductor, unloaded racks of the rear row, BE19 conductor, closed contacts of relay 43, BE26 conductor, terminal 5 of plug connector 28. As a result, the bottom bomb is released.

The subsequent current pulses are sent to the middle left-hand bomb rack and to the middle right-hand bomb rack

- 109 -

50X1-HUM

in turn, until they are fully unloaded.

2. With switches 1 and 2 of rack selector relay 43 being ON, the unloading of the КД3-488 bomb racks mounted in three rows (in train bombing, two bombs per salvo) is as follows.

The first pulse from the intervalometer through the BE5 conductor passes to terminal Г of the KBCE-48 bomb release variation box and from terminal Д through the BE7 conductor, terminal 5 of plug connector 26 is fed into the ПБД-48 release unit of the forward right-hand bomb rack.

At the same time a current pulse from terminal Г through terminal И of the KBCE-48 box, BE28 conductor, contacts of switch 45, BE4 conductor passes to terminal X of the KBCE-48 bomb release variation box and, further, through terminal E, BE8 conductor, contacts of relay 43, BE27 conductor, terminal 5 of plug connector 25 to the ПБД-48 bomb shackle release unit of the rear left-hand bomb rack. Thus, the first current pulse is fed simultaneously into the release units of both the forward right-hand bomb rack and the rear left-hand bomb rack. As a result, the bottom bombs are released, one bomb from each bomb rack.

The subsequent current pulses will go on releasing bombs until both the forward right-hand bomb rack and the rear left-hand bomb rack are fully unloaded, in the manner described above.

The following current pulses are simultaneously supplied from the forward right-hand bomb rack to the forward left-hand one through the BE10 conductor, and from the rear left-hand bomb rack to the rear right-hand one through the BE18 conductor. This results in a simultaneous release of two bombs, one bomb from each bomb rack, until they are fully unloaded.

Then the middle left-hand and right-hand bomb racks start unloading, current pulses being simultaneously sent from terminals Д and E of the KBCE-48 bomb release variation box through the BE7 and BE8 conductors, and through the unloaded bomb racks of the corresponding group, i.e. the

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 110 -

- 111 -

50X1-HUM

middle left-hand bomb rack will get pulses through the right-hand and left-hand unloaded bomb racks of the forward row, while the middle right-hand bomb rack, through the left-hand and right-hand unloaded bomb racks of the rear row.

3. With switches 1 and 2 of rack selector relay 44 turned ON and the KИ3-488 bomb racks installed in two rows (in train bombing, one or two bombs per salvo), the order of unloading and the circuit operation is identical to that of the KИ3-488 bomb racks installed in three rows less the unloading of the bomb racks of the middle row.

Thus, the KИ3-488 bomb racks installed in two or three rows are divided into two groups according to the operation of the selector relays. When the KИ3-488 bomb racks are mounted in three rows, such a group as the forward right-hand and left-hand bomb racks plus the middle left-hand bomb rack receive current pulses from the relay which is connected via switch 1 of rack selector relay 44. The other group, namely, the rear right-hand and left-hand bomb racks plus the middle right-hand bomb rack, receives current pulses from the relay which is connected via switch 2 of rack selector relay 44. When the KИ3-488 bomb racks are mounted in two rows the forward right-hand and left-hand bomb racks receive current pulses from the relay which is out in via switch 1 of rack selector relay 44, while the rear right-hand and left-hand rear bomb racks receive pulses from the relay which is connected via switch 2 of rack selector relay 44.

If one of the bombs fails to drop, the further release of this group of bomb racks stops as the interlock switch of each station excludes the possibility of dropping the upper bomb on the lower one, while the interlock system of the bomb racks excludes the possibility of unloading the subsequent bomb racks. In this case the rest of the bombs can be released only by the emergency release control.

4. With the rear row of KИ3-488 bomb racks out out, the unloading of KИ3-488 bomb racks (in train bombing, one bomb

per salvo) is performed as follows.

When the rear row of KИ3-488 bomb racks is occupied by the KИ3-488 racks for the reflecting dipoles the rear row of KИ3-488 bomb racks is cut out by engaging switch 42 on the avigator's bomb release control panel. Upon turning on switch 42, power from bus 41 is supplied to the winding of relay 43 via the A3C-2A circuit breaker, and through the B01 and B02 conductors. The relay breaks the release circuit of the rear row of the KИ3-488 bomb racks.

The first current pulse from the intervalometer is sent to terminal F of the KBCB-48 bomb release variation box through the BE5 conductor, and then from terminal A of the KBCB-48 box through the BE7 conductor, and terminal 5 of plug connector 26 to the ПБД-48 bomb shackle release unit of the forward right-hand bomb rack. This results in releasing the bottom bomb.

From terminal E of the KBCB-48 bomb release variation box the subsequent current pulse through the BE8 conductor, contacts of relay 43, BE24 conductor, terminal 5 of plug connector 23 will pass to the ПБД-48 release unit of the rear left-hand bomb rack, thereby releasing the bottom bomb.

The subsequent current pulses are supplied to the forward right-hand and rear left-hand bomb racks in turn until they get fully unloaded. When the forward right-hand and rear left-hand bomb racks are unloaded, the subsequent current pulse from terminal A of the KBCB-48 bomb release variation box is supplied to the ПБД-48 bomb shackle release unit of the forward left-hand bomb rack through the BE7 conductor, unloaded bomb rack of the starboard side, BE10 conductor, and terminal 5 of plug connector 21. As a result, the bottom bomb is released.

The following current pulse from terminal E of the KBCB-48 bomb release variation box is fed into the ПБД-48 release unit of the rear right-hand bomb rack through the BE8 conductor, contacts of relay 43, BE24 conductor and the unloaded rear

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 112 -

left-hand bomb rack, BE25 conductor, and contacts of relay 43, BE26 conductor, terminal 5 of plug connector 28. As a result, the bottom bomb is released.

The subsequent current pulses are supplied to the forward left-hand and rear right-hand bomb racks in turn until they are fully unloaded.

5. With the rear row of the KИ3-488 bomb racks cut out, the unloading of the KИ3-488 bomb racks (in train bombing, two bombs per salvo) is identical to that of the KИ3-488 bomb racks mounted in three rows, i.e. the first current pulse is simultaneously sent out from terminals И and E of the KBCE-48 bomb release variation box to the ПЕД-48 release unit of the forward right-hand and rear left-hand bomb racks through the B57 and B58 conductors. The bomb shackle release units begin to operate simultaneously releasing two bombs, one from each bomb rack. The subsequent current pulses will release bombs similarly until the forward right-hand and rear left-hand bomb racks are fully unloaded. Then current pulses are simultaneously sent to the forward left-hand and rear right-hand bomb racks each time passing through the unloaded bomb rack of the respective group.

When unloading the KИ3-488 bomb racks mounted in three rows and in case a bomb fails to drop from one of the shackles of the rear (third) row bomb rack, the bomb release circuit will provide unloading of the four remaining bomb racks in the manner absolutely identical to that for the bomb racks mounted in two rows, if switch 42 is turned ON.

6. With switches 1 and 2 of rack selector relay 44 turned ON, the unloading of the KИ4-388 bomb racks mounted in two rows (in train bombing, one bomb per salvo) is as follows:

The first current pulse from the intervalometer through the B55 conductor passes to terminal Г of the KBCE-48 bomb release variation box and further from terminal И of the KBCE-48 box through the B57 conductor, terminal 2 of plug connector 27 to the ПЕД-48 release unit of the forward

right-hand bomb rack. The unit operates to release the bottom bomb. The second current pulse from terminal E of the KBCE-48 box will get to the ПЕД-48 release unit of the rear left-hand bomb rack through the B58 conductor, terminal 2 of plug connector 24.

As a result, the unit will release the bottom bomb.

The third current pulse from terminal И of the KBCE-48 bomb release variation box through the B57 conductor, terminal 2 of plug connector 27, unloaded station of the forward right-hand bomb rack, and from terminal 1 of plug connector 27, through the B511 conductor, terminal 2 of plug connector 22 is fed to the ПЕД-48 release unit of the forward left-hand bomb rack, as a result, the unit will release the bottom bomb.

The fourth current pulse from terminal E of the KBCE-48 box through the B58 conductor, terminal 2 of plug connector 24, unloaded station of the rear left-hand bomb rack, from terminal 1 of plug connector 24, B517 conductor, terminal 2 of plug connector 29 gets to the release unit of the rear right-hand bomb rack. The unit will operate to release the bottom bomb. The subsequent current pulses pass to the forward right-hand and rear left-hand, forward left-hand and rear right-hand bomb racks in turn until the racks are fully unloaded. Thus, every current pulse coming from the respective selector relay of the KBCE-48 bomb release variation box follows the path of the previous pulse of a given group of bomb racks plus the path to the ПЕД-48 release unit of the shackle whose bomb is going to be released.

7. With switches 1 and 2 of rack selector relay 44 turned ON, the unloading of the KИ4-388 mounted in two rows (emergency bomb release, two bombs per salvo) is as follows.

The first current pulse from the intervalometer is supplied through the B55 conductor to terminal Г of the KBCE-48 bomb release variation box and from terminal И through the B57 conductor, terminal 2 of plug connector 27 to the ПЕД-48 release unit of the forward right-hand bomb

- 113 -

50X1-HUM

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 114 -

rack. At the same time a current pulse from terminal F through terminal H of the KBCB-48 box, BE28 conductor, contacts of switch 45, and the BE4 conductor is sent to terminal X of the KBCB-48 box and, further, through terminal E, BE8 conductor; terminal 2 of plug connector 24, to the ПБД-48 release unit of the rear left-hand bomb rack. Thus, the first current pulse gets simultaneously to the ПБД-48 release units of the forward right-hand and rear left-hand bomb racks. The units operate to simultaneously release two bombs, one from each bomb rack. The second pulse also from terminals D and B of the KBCB-48 box through the BE7 and BE8 conductors, unloaded stations of the forward right-hand and rear left-hand bomb racks, BE11 and BE17 conductors, terminals 2 of plug connectors 22 and 29 are sent to the electromechanical drives of the forward left-hand and rear right-hand bomb racks. The units simultaneously release two bombs, one from each bomb rack. The subsequent current pulse will again be sent to the ПБД-48 release units of the forward right-hand and rear left-hand bomb racks following the whole path of the first and second current pulses, i.e. from terminal D of the KBCB-48 bomb release variation box through the BE7 conductor to terminal 2 of plug connector 27, first station of the forward right-hand bomb rack to terminal 1 of plug connector 27 through the BE11 conductor to terminal 2 of plug connector 22, first station of the forward left-hand bomb rack to terminal 1 of plug connector 22 through the BE12 conductor to terminal 19 of plug connector 27 and, further, to the ПБД-48 bomb shackle release unit of the forward right-hand bomb rack of the second station.

If there is no bomb on the second station and there is a bomb suspended from the third one, the current pulse will pass via the second station of the forward right-hand bomb rack, then via the second station of the forward left-hand bomb rack, through the BE20 conductor, terminal 8 of plug connector 27 to the release unit of the front right-hand bomb rack of the

- 115 -

50X1-HUM

third station. The current pulse simultaneously supplied from terminal B of the KBCB-48 box will follow a similar path through the rear row of bomb racks.

The subsequent current pulses follow the paths of the previous current pulses releasing bombs in the following order: the forward right-hand bomb rack, rear left-hand rack and then forward left-hand bomb rack, rear right-hand rack, etc.

Thus, the КД4-388 bomb racks mounted in two rows are divided similarly to the КД3-488 bomb racks into two groups depending on the selector relay operation. If one of the bombs fails to drop, the further unloading of this group of bomb racks (from both the combat and emergency circuits) stops as a result of the operation of the interlock switches of the bomb racks.

The unloading of the КД4-388 bomb racks mounted in one row (when bombing in train) can be effected only in a one-bomb salvo which corresponds to the release system circuit. When the КД4-388 bomb racks are installed in one row, current pulses are supplied through one circuit from the relay which is cut in by switch 1 of rack selector relay 44.

The electric circuit provides for the following order of unloading.

The first current pulse from terminal D of the KBCB-48 bomb release variation box through the BE7 conductor, terminal 2 of plug connector 27 is sent to the ПБД-48 shackle release unit of the right-hand rack.

The following current pulse also from terminal D of the KBCB-48 box reaches the circuit of the first pulse and from terminal 1 of plug connector 27 is fed into the ПБД-48 release unit of the left-hand rack through the BE11 conductor, terminal 2 of plug connector 22.

The subsequent current pulse is sent to the shackle release unit of the right-hand bomb rack, then to that of the left-hand rack, etc., until they are fully unloaded.

The circuit of the bombing equipment provides also means

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 116 -

- 117 -

50X1-HUM

for unloading the KJ3-488 bomb racks mounted in two and three rows, as well as the KJ4-388 racks mounted in two rows (first unloaded are the rear racks and then the front ones, and vice versa, depending on the way switches 1 and 2 of rack selector relay 44 are engaged). This kind of unloading is not recommended for the Ty-16 aircraft as it may involve a serious loss of longitudinal and lateral stability, causing considerable loads on the aircraft controls.

When bombs are released in a one-bomb salvo (both in selective and in in-train bombing) from the KJ3 and KJ4 bomb racks mounted in two rows and from the KJ3 racks mounted in three rows, the bombing equipment circuit does not preserve the succession of unloading indicated in the diagrams (See Fig. 4), in case the bomb doors are closed and opened in the intervals between the successive bomb releases.

The succession of unloading is broken if unloading is interrupted after a current pulse has been sent out from the selector relay which receives power through switch 1 of rack selector relay 44. When the bomb-bay doors are subsequently opened, the next current pulse is supplied to the bomb racks not from the relay receiving power through switch 2 of rack selector relay 44 (this could provide operation in accordance with the circuit diagram, see Fig. 4), but from the relay which receives power through switch 1 of rack selector relay 44. Thus, next racks to be unloaded are the same bomb racks which have already been unloaded. In this way, the sequence of unloading is violated.

Emergency Bomb Release

The bombing equipment circuit is intended for effecting an emergency bomb release either from the aircraft mains or from the aircraft storage battery system when the aircraft mains is de-energized.

For the emergency bomb release from the aircraft mains

the aircraft has emergency bomb release switches 53 on the navigator's bomb release control panel and switch 52 on the pilot's instrument panel. Both switches are under red protecting caps locked with a flaxen thread and a seal.

Emergency Bomb Release from Aircraft Mains

SAPF release. For emergency SAPF release it is necessary to turn on switch 52 at the pilot's station or switch 53 at the navigator's station. In this case power from bus 47 is supplied through the A3C-5A circuit breaker, BA1 and BA2 conductors to combat bomb release circuit interlock relay 38 which breaks the intervalometer and ARMED release circuits.

Simultaneously power from bus 47 is supplied through the A3C-5A circuit breaker, BA1, BA2 and BA5 conductors, normally-closed contacts of emergency bomb release control relays 59 to 3JC-1 emergency bomb door opening solenoid 61. The solenoid will unlock the hydraulic cylinder ball lock, and the bomb-bay doors will open. When the bomb-bay doors are open, limit switches 54 and 55 mounted in the limit switch box at frame No.33 close, power from bus 47 is supplied to the windings of emergency bomb release control relays 59 through the A3C-2A circuit breaker and B11, B11, B12 and B12 conductors.

Both relays will simultaneously open the feed circuit of 3JC-1 emergency bomb door opening solenoid 61 and will close the feed circuit of emergency bomb release relays 64.

Power from bus 47 through the A3C-5A circuit breaker, BA1 conductor, closed contacts of switches 52 and 53, BA2 conductor, closed contacts of relays 59, BA8 and BA9 conductors, closed contacts 7 of the emergency bomb release interlock switch is supplied to the windings of emergency bomb release relays 64.

Relays 64 operate, their contacts close to provide power supply from bus 48 through the 50A time-lag fuse, BH1 and BH2

SECRET NO FOREIGN DISSEM



NO FOREIGN DISSEM

- 118 -

- 119 -

50X1-HUM

conductors to the ПБЛ-48 release units of the bomb racks, to the emergency bomb release windings. This will result in an emergency SAFE bomb release.

To make the circuit operate reliably two relays 59 are connected in parallel in the emergency bomb release control circuit. If one of the relays is inoperative, power supply for an emergency bomb release is ensured by the other relay.

To avert a spontaneous emergency bomb release due to a displacement of the relay contacts resulting from the aircraft shock against the ground during the take-off or rough landing with bombs loaded, the emergency bomb release power supply circuit has two emergency release relays 64 connected in-series. For this purpose the contacts of one relay are arranged nosewise, while those of the other are set tailwise.

Simultaneously with solenoid 61 intervalometer and ARMED release power supply interlock relay 38 breaks the intervalometer and ARMED release circuits. As a result, the bombs will be released SAFE by the emergency system and the combat bomb release system will be disconnected from the emergency one.

When the navigator prepares the emergency ARMED bomb release circuit, the pilot, if necessary, can perform an emergency SAFE release by turning on gang switches 51 and 52 (switch 51 breaking the ARMED release circuit at the navigator's station, and switch 52 ensuring the emergency SAFE bomb release).

ARMED release. The pilot and the navigator can effect an emergency ARMED bomb release by setting switch 50 on the pilot's instrument panel to the ARMED position (emergency bomb release) or switch 49 with the inscription TURN ON FOR EMERGENCY ARMED RELEASE (ВКЛУЧИ ПРИ АВАРИЙНОМ СБРАСЫВАНИИ НА ВЗРЫВ) on the navigator's bomb release panel to the top position for ARMED drop. Switches 49 and 50 are under red protective caps and are provided with seals on a flaxen thread. When switches 49 and 50 are turned ON power from bus 47 through the A3C-10A circuit breaker, BB2 and BB4 conductors, closed contacts of indication system interlock switch 60, BB8 conductor is

supplied to ПИ-2 relay 70 mounted in the emergency bomb release junction box; the relay will close the power supply circuit of ARMED release indicator lights 15 and 57 at the navigator's and the pilot's stations.

The lights will flash up red to indicate that the system is prepared for an ARMED release. When one of the emergency bomb release switches (53 at the navigator's station or 52 at the pilot's station) is turned on, power from bus 47 through the A3C-5A circuit breaker, BA1, BA2 and BA5 conductors is supplied to emergency bomb door opening solenoid 61 to open the bomb doors.

As soon as the bomb doors are open limit switch 72 installed in the limit switch box at frame No.33 through the BB43 conductor closes the feed circuit of the winding of ПИ-2 relay 71 mounted in the bomb release junction box. The relay closes the MBH-48 arming mechanism feed circuit and simultaneously opens the combat ARMED release circuit. This will result in an emergency ARMED bomb release.

On the aircraft of earlier make power to the arming mechanisms (for combat and emergency bomb release) was supplied only through the ARMED release circuit. For a more reliable operation of the ARMED release circuit the combat and emergency systems of the aircraft of later make have independent ARMED release circuits. If the ARMED release circuit of the combat release system fails, the ARMED release is effected through the emergency system.

#### Battery-Operated Emergency Bomb Release System

In addition to the combat and emergency bomb release systems provision is made in the aircraft for an emergency bomb release by means of the system fed from the storage battery (if the aircraft mains is de-energized).

SAFE release. The aircraft mains being de-energized, the bomb release is accomplished by turning the handle of bomb

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 120 -

release device 65 mounted on the pilot's control panel. The contacts kinematically connected with the handle close the circuit supplying power from the storage battery through the 3C6 conductor to solenoid 61 of emergency bomb-bay door opening lock and through the 3C8 conductor. The bomb release interlock circuit limit switch closes the circuit of emergency bomb release relay 63, with circuit 62 de-energized. When the bomb-bay doors are opened by the system powered from the storage battery, power through the 3C conductor, closed contacts of relay 63, 3C2 and BH2 conductors is supplied to the MBH-48 release units. The units will release bombs set to SAFE.

As was the case in the emergency bomb release, the bomb release circuit, with the aircraft mains de-energized (power supplied from the battery), has two in-series relays 63 to avert the possibility of a spontaneous bomb release during the take-off or a rough landing, with the bombs loaded (a spontaneous release may occur due to the closing of the relay contacts as a result of bumps against the ground). For this purpose the contacts of one relay are set nosewise, while those of the other relay are set tailwise.

ARMED release. To release the bombs ARMED with the mains de-energized, the switch of device 65 designated ARMED (B3PHB) should be turned on. In this case, power is supplied from the storage battery through the 3C5 conductor to the MBH-48 arming mechanisms; then by turning the handle of the device the bombs are released ARMED.

#### Power Supply to Hoist System Units

When bombs are hoisted by the EH-473M electromechanical hoists, the hoists and control units are connected to a power source through receptacles 68 and 69 provided in the bomb bay on the fuel pump distribution boxes at frames Nos 33 and

- 121 -

50X1-HUM

49. When the hoists are attached to the bomb-bay door forward attachment units, they are connected to receptacle 68, when attached to the door aft attachment units, they are connected through receptacle 69. Power to receptacles 68 and 69 is supplied from buses 66 and 67 of the fuel pump distribution box via 100A time-lag fuses.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 123 -

50X1-HUM

## Chapter VIII

### BONDING OF BOMB EQUIPMENT UNITS

All the bomb equipment units are bonded, as the aircraft has a single-wire electric system (i.e. the airframe is used as a conductor of the system).

Bonding implies electrical connection of two or more metal parts either having casual electrical connection or insulated from one another; bonding is accomplished by means of low-resistance bonding strips and bolted or riveted joints.

A thoroughly made bonding not only provides for using the airframe as a return conductor of the electric system but also serves for the following purposes:

- (a) elimination of sparking (at the points of alternating electrical contacts) creating radio noise or even a source of fire (in the compartments containing fuel vapours);
- (b) elimination of localized heating and electro-chemical corrosion at the points of attachment since any local resistance to the passing electric current causes localized heating and electro-chemical corrosion affecting the mechanical properties of the aircraft assemblies and aircraft equipment;
- (c) provision of normal and steady operation of radio facilities in spite of considerable radio noise caused by the equipment (dynamotors, relays, electric motors and various electric automatic machines) due to effective screening, since the decreased ohmic resistance of the screen lowers the

noise voltages generated in a given section. Housings and casings of the equipment, boxes with covers, braiding of wires and bunched conductor sheathings serve as screens.

Note: Screening implies enclosing the current-carrying wires into screens made of electric conductive low-resistance materials to localize the electric noises generated by the wires or to protect the wires from the noise generated by other sources.

The riveted joints used in the aircraft ensure a sufficiently reliable electric contact between the connected parts due to the fact that the anodized coating of the rivet and the hole walls becomes broken in riveting. Bonding by riveting is used in the joints of the junction box attachment brackets, panels, KOC-45 dome lamp, WY-50 spark extinguisher, bomb rack attachment assemblies, etc., with the aircraft frame details.

Bolted joints are used for bonding the VQ-1c converter, bottom bomb release control panel, bomb-bay doors, signal flare control panel, limit switch boxes,


hydraulic system panels, emergency bomb release control panel (for the mains de-energized), JHC-1 solenoids, KOC-45 dome lamp, KBCE-48A bomb release variation box, WY-50 spark extinguisher, OHS-11p bombsight, 3CEP-49A intervalometer, KJ3-488 and KJ4-388 bomb racks.

The contacting surfaces of the bonded units at the points of attachment and the surfaces to support bolt heads or nuts should be thoroughly filed, i.e. their protective coating (anodized, varnished or painted surfaces) must be removed to provide a reliable electric contact between the bonded parts. Upon fixing the bolts the places which have been filed off must be recoated with clear varnish.

The computer, altitude-data unit, control box and the electronic relay unit are connected by bonding strips. The bonding strip terminals contacting the filled-off metallic surfaces are secured by screws and coated with red enamel. To bond the electronic relay unit use is made of a bonding jumper

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

- 124 -

of copper wire strip, П10x16. Bonding wire strip, П3x6, is used to bond the computer, altitude-data unit and the control box.

Screening bunched conductor braids are connected to the airframe by means of 548hc clamps (provided with metal padding) secured to aircraft structure parts (filed in these places for the purpose).




FIG. 1. ARRANGEMENT OF BONDING EQUIPMENT IN FRONT PRESSURIZED CABIN  
1 - emergency back relay; 2 - altimeter; 3 - altimeter; 4 - altimeter; 5 - altimeter; 6 - altimeter; 7 - altimeter; 8 - altimeter; 9 - altimeter; 10 - altimeter; 11 - altimeter; 12 - altimeter; 13 - altimeter; 14 - altimeter; 15 - altimeter; 16 - altimeter; 17 - altimeter; 18 - altimeter; 19 - altimeter; 20 - altimeter

SECRET  
NO FOREIGN DISSEM

~~SECRET~~  
NO FOREIGN DISSEM



50X1-HUM




FIG. 2. ARRANGEMENT OF BOMBING EQUIPMENT IN BOMB BAY  
 1 - Junction box (forward) of light; 2 - red color change lamp; 3 - emergency bomb release system junction box;  
 4 - KC13-488; 5 - multiple bomb rack; 6 - bomb release junction box; 7 - KC14-388 rack; 8 - battery;  
 9 - junction box (rear) of fuel pumps; 10 - fuel; 11 - bomb release junction box; 12 - KC14-388 rack; 13 - battery;  
 14 - KC14-388 rack; 15 - KC14-388 rack; 16 - KC14-388 rack; 17 - KC14-388 rack; 18 - KC14-388 rack; 19 - KC14-388 rack.





FIG. 3. DIAGRAM OF SAFETY ANGLES FOR QAG-250346 BOMB (IN EXIT FROM BOMB BAY)

~~SECRET~~  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




FIG. 2. ARRANGEMENT OF BOMBING EQUIPMENT IN BOMB BAY  
 1 - fuel tank box (forward) of fuel pump; 2 - fuel collector/dump line; 3 - emergency bomb release (1/2 inch diameter hole); 4 - bomb rack (left); 5 - bomb rack (right); 6 - bomb door (left); 7 - bomb door (right); 8 - bomb door (left); 9 - bomb door (right); 10 - bomb door (left); 11 - bomb door (right); 12 - bomb door (left); 13 - bomb door (right); 14 - bomb door (left); 15 - bomb door (right); 16 - bomb door (left); 17 - bomb door (right); 18 - bomb door (left); 19 - bomb door (right).




FIG. 3. DIAGRAM OF SAFETY ANGLES FOR QAG-25046 BOMB (IN EXIT FROM BOMB BAY)

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




FIG. 4. DIAGRAM SHOWING BOMB RELEASE SUCCESSION RACKS AND PLUG CONNECTOR NUMBERS. Figures in diamonds indicate plug connector numbers to the bomb rack. Figures not in the diamonds indicate the succession of releases. Dotted are the bomb racks in the stored position.





FIG. 5. NAVIGATOR'S LEFT-HAND CONTROL PANEL. 1 - Navigator's left-hand control panel; 2 - bomb release control panel; 3 - 300P-46A indicator; 4 - bomb release control panel.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM




FIG. 6. BOMB RELEASE CONTROL PANEL  
 1 - station status indicator lights; 2 - switch to check operation of lights; 3 - READY TO DROP indicator light; 4 - emergency bomb release switch; 5 - emergency ARMED release switch; 6 - switch of K43-488 rear bomb racks cut-out relay; 7 - station status indicator check button for checking up with bomb-bay doors closed.




FIG. 7. BOTTOM BOMB RELEASE CONTROL PANEL  
 1 - verification box relay switches; 2 - solenoid switch.





FIG. 8. NAVIGATOR'S LEFT-HAND CIRCUIT BREAKER PANEL

SECRET NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM



50X1-HUM




FIG. 9. BOMB-BAY DOOR CONTROL PANEL  
 1 - master bombing switch 2 - door control switches  
 3 - door open position indicator light; 4 - door closed position indicator light; 5 - ARMED warning light; 6 - switch of door stand-by opening circuit.




FIG. 11. PILOT'S INSTRUMENT PANEL  
 1 - emergency ARMED release switch protector; 2 - emergency ARMED release indicator light; 3 - protector of emergency release switch and navigator's ARMED release circuit interlock switch.




FIG. 10. NAVIGATOR'S RIGHT-HAND CIRCUIT BREAKER PANEL  
 1 - circuit breakers (A3C).

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM




FIG. 13. PILOT'S CONTROL PANEL  
1 - bomb door opening switch (with aircraft mains de-energized); 2 - emergency bomb release control panel (with aircraft mains de-energized); 3 - armng switch; 4 - emergency bomb release and door opening handle; 5 - engine starting box.




FIG. 13. NAVIGATOR-OPERATOR'S INSTRUMENT PANEL  
1 - READY TO DROP indicator light; 2 - bomb release but.




FIG. 14. NAVIGATOR-OPERATOR'S ELECTRIC PANEL

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM




FIG. 15. K13-43 BOMB RACK

1 - unloading handle; 2 - ПБД-43 bomb shackle release unit; 3 - steel plate; 4 - BK-42M interlock switch base; 5 - bomb rack plug connector; 6 - ДРЗ-43 bomb shackle; 7 - top attachment assembly; 8 - top cross bar; 9 - top pulleys and frame; 10 - MBH-48 arming mechanisms; 11 - latch; 12 - rear beam; 13 - bottom cross bar; 14 - forward beam; 15 - metal sheath; 16 - tubes for hoist cable guiding; 17 - bracket for ДРЗ-43 shackle stowed position; 18 - bomb rack bottom attachment assembly; 19 - bottom pulleys; 20 - stops; 21 - pawl; 22 - unloading handle link rod.





FIG. 16. K13-43 BOMB RACK CIRCUIT DIAGRAM

1 - MBH-48 arming mechanism plug connector; 2 - ПБД-43 plug connector; 3 - BK-42M interlock switch base; 4 - plug connector of ПБД-43 release unit.


SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM



**FIG. 17. K24-338 BOMB RACK**  
 1 - unloading handle; 2 - IIRJ-43 bomb shockle release unit;  
 3 - ERG-43 interface switch box; 4 - plug connector; 5 - top attachment assembly; 6 - top cross bar; 7 - rollers and frames;  
 8 - forward beam (roll) of bomb rack; 9 - cable control switch handle; 10 - IIRJ-43 shockle; 11 - plate; 12 - MDN-43 crating mechanism; 13 - latch; 14 - protecting plate; 15 - bottom cross bar; 16 - rear beam (roll) of bomb rack; 17 - metal sheets;  
 18 - cable guiding tubes; 19 - bomb shockle stored position; 20 - bottom attachment assembly of bomb rack;  
 21 - rotating system rollers; 22 - stop; 23 - pawl; 24 - unloading handle link rod.



**FIG. 18. K24-338 BOMB RACK CIRCUIT DIAGRAM**  
 1 - IIRJ-43 shockle release unit; 2 - IIRJ-43 crating mechanism; 3 - ERG-43 interface switch box; 4 - MDN-43 crating mechanism plug connector.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 19. **APP 3-48 BOMB SHACKLE (TOP - LOCKED, BOTTOM - UNLOCKED)**  
 1 - **APP 3-48** shackle; 2 - **APP 3-48** electromechanical bomb shackle release unit; 3 - **APP 3-48** release lever; 4 - intermediate lever; 5 - release lever; 6 - frame; 7 - arming mechanism; 8 - carrying hook; 9 - **APP 3-48** locking lever; 10 - **APP 3-48** locking lever; 11 - **APP 3-48** locking lever; 12 - **APP 3-48** locking lever; 13 - **APP 3-48** locking lever; 14 - **APP 3-48** locking lever; 15 - **APP 3-48** locking lever; 16 - **APP 3-48** locking lever; 17 - **APP 3-48** locking lever.




FIG. 20. **APP 4-48 BOMB SHACKLE (TOP - LOCKED, BOTTOM - UNLOCKED)**  
 1 - **APP 4-48** shackle; 2 - **APP 4-48** electromechanical bomb shackle release unit; 3 - **APP 4-48** release lever; 4 - intermediate lever; 5 - release lever; 6 - frame; 7 - arming mechanism; 8 - carrying hook; 9 - **APP 4-48** locking lever; 10 - **APP 4-48** locking lever; 11 - **APP 4-48** locking lever; 12 - **APP 4-48** locking lever; 13 - **APP 4-48** locking lever; 14 - **APP 4-48** locking lever; 15 - **APP 4-48** locking lever; 16 - **APP 4-48** locking lever; 17 - **APP 4-48** locking lever; 18 - **APP 4-48** locking lever.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




FIG. 21. MBH-48 ELECTROMECHANICAL BOMB SHACKLE RELEASE UNIT  
1 - case; 2 - mechanical trigger pin; 3 - slot for cocking the unit; 4 - releasing pin; 5 - plug; 6 - name plate.




FIG. 22. MBH-48 ARMING MECHANISM  
1 - case; 2 - arming pin; 3 - socket; 4 - name plate.




FIG. 23. MKCI-39 SIGNAL FLARE LAUNCHER  
1 - coating; 2 - shoe; 3 - plug connector; 4 - flange; 5 - set of tubes; 6 - screw.




FIG. 24. SIGNAL FLARE CONTROL PANEL (IDP)

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 25. CIRCUIT DIAGRAM OF 3KCI-39 LAUNCHER CONTROL  
 1 - set of tubes; 2 - 3KCI-39 launchers; 3 - signal flare cartridge; 4 - aquib-initiated igniter; 5 - plug connector; 6 - signal flare control panel; 7 - co-pilot's circuit breaker panel.




FIG. 26. 3CBF-49A INTERVALOMETER  
 1 - indicator - dial; 2 - M - KM range switch; 3 - dial indicating number of bombs or salvoes per train; 4 - counter knob; 5 - ground speed dial; 6 - interval control knob; 7 - ground bomb speeing scale; 8 - TRANSSEL toggle switch.




FIG. 27. 3KBCI-49A BOMB RELEASE VARIATION BOX

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 29. CIRCUIT DIAGRAM OF KCES-48A BOMB RELEASE VARIATION BOX  
1, 2 - 2B-43 switches; 3 - 8-43 solenoid.




FIG. 28. MV-50 SPARK EXTINGUISHER




FIG. 30. CIRCUIT DIAGRAM OF MV-50 SPARK EXTINGUISHER  
1 - capacitor; 2 - relay solenoid.





FIG. 31. KOS-49 BOMB RELEASE BUTTON (LONGITUDINAL SECTION)  
1 - cap; 2 - thread; 3 - base; 4 - wire; 5 - lock; 6 - switch; 7 - button.

SECRET  
NO FOREIGN DISSEM



NO FOREIGN DISSEM



50X1-HUM




FIG. 21. BOMB BAY DOOR CONTROL DIAGRAM  
 1 - forward reel; 2 - shifter; 3, 4 - connecting cables  
 5 - cable connecting forward reel with opening cable  
 6 - cable connecting forward reel with opening cable  
 7 - door opening cable; 8 - hook-shaped cable  
 9 - door opening cable; 10 - hook-shaped cable  
 11 - door opening cable; 12 - hook-shaped cable  
 13 - door opening cable; 14 - hook-shaped cable  
 15 - hook-shaped cable; 16 - hook-shaped cable




FIG. 22. KINEMATICS OF BOMB BAY DOOR CONTROL SYSTEM (FORWARD REEL REAR VIEW)  
 1 - hydraulic drive; 2 - forward reel; 3 - cables connecting forward and rear reels (connecting cable); 4 - cable connecting cable pulley; 5 - reel; 6 - cable connecting forward reel with opening cable; 7 - reel sector-shaped leg; 8 - hook door opening cable pulley.

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




FIG. 34. BOMB-BAY DOOR OPENING SPRINGS  
 1 - springs; 2 - bomb door opening cable; 3 - shears block;  
 4 - turnbuckle; 5 - front cross bar; 6 - rear cross bar;  
 7 - adjusting rod; 8 - cross bar attachment assembly.




FIG. 35. BOMB-BAY LIMIT SWITCH BOX  
 1 - bomb-bay door closed position indication switch No. 1; 2 - bomb-bay door open position indication switch No. 2; 3 - emergency bomb release circuit interlock switch No. 3, used with aircraft main de-energized; 4 - cover attachment lug; 5 - combat bomb release switch Nos. 4 and 5; 6, 7 - emergency bomb release switches Nos. 6 and 7; 8 - box housing; 9 - switch No. 9 of emergency ARMED release relay; 10 - attachment slip; 11 - automatic pilot interlock switch No. 8; 12 - carriage; 13 - axis of bomb-bay door control reel rotation; 14 - wedge of carriage to press cover; 15 - wedge of carriage to press cover; 16 - wedge of carriage to press cover; 17 - actuating roller on cover engaging switch; 18 - roller on cover engaging switch; 19 - roller on cover engaging switch; 20 - locking wheel; 21 - adjusting screw; 22, 23, 24 - covers; 25 - fastening screws; 27 - angle-blocks.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




FIG. 36. HYDRAULIC DRIVE  
1 - eye bolt; 2 - nut; 3 - cylinder; 4 - cover; 5 - piston; 6 - seal; 7 - nut; 8 - piston; 9 - seal; 10 - plug; 11 - ball; 12 - ball lock sleeve; 13 - nut; 14 - nut; 15 - nut; 16 - nut; 17 - nut; 18 - nut; 19 - nut; 20 - nut; 21 - nut; 22 - nut; 23 - nut; 24 - nut; 25 - nut; 26 - nut; 27 - nut; 28 - nut; 29 - nut; 30 - nut; 31 - nut; 32 - nut; 33 - nut; 34 - nut; 35 - nut; 36 - nut; 37 - nut; 38 - nut; 39 - nut; 40 - nut; 41 - nut; 42 - nut; 43 - nut; 44 - nut.




FIG. 37. BOMB-BAY DOOR CONTROL PANELS  
1 - pilot's panel; 2 - pilot's instrument panel; 3 - bomb-bay door control panel; 4 - bomb release panel; 5 - pilot's middle panel; 6 - bomb-bay door control panel; 7 - pilot's instrument panel; 8 - bomb-bay door control panel; 9 - stand-by bomb-bay door opening switch; 10 - stand-by bomb-bay door closing switch; 11 - emergency door opening and emergency bomb release switch; 12 - switch to open bomb-bay doors on the ground with aircraft main deenergized; 13 - handle for emergency bomb-bay door opening and emergency bomb release; 14 - switch of emergency bomb-bay door opening and emergency bomb release.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




FIG. 38. KEY DIAGRAM OF BOMB-BAY DOOR OPENING (NORMAL CONTROL)  
1 - hydraulic drive; 2 - slide valve distributor; 3 - stand-by bomb-bay door control system valve;  
4 - normal bomb-bay door control system valve.




FIG. 39. DIAGRAM OF BOMB-BAY DOOR CONTROL ROD KINEMATIC LOCK




FIG. 40. 3M-12 ELECTROMAGNET  
1 - coil frame; 2 - bottom cover; 3 - pull-in coil; 4 - housing;  
5 - core; 6 - push-out coil; 7 - adjusting shim; 8 - rod; 9 - top  
cover; 10 - locking screw; 11 - plug connector.

SECRET

**SECRET**  
**NO FOREIGN DISSEM**



50X1-HUM




FIG. 41. DIAGRAM OF BOMB-BAY DOOR OPENING (EMERGENCY AND STAND-BY CONTROL)  
1 - hydraulic drive; 2 - slide valve distributor; 3 - bomb-bay door stand-by control system valve;  
4 - bomb-bay door normal control system valve.






FIG. 42. DIAGRAM OF BOMB-BAY DOOR CLOSING (STAND-BY CONTROL)  
1 - hydraulic drive; 2 - slide valve distributor; 3 - bomb door stand-by control system valve;  
4 - bomb door normal control system valve.

**SECRET**  
**NO FOREIGN DISSEM**


**SECRET**  
NO FOREIGN DISSEM




**FIG. 43. 30C-1 ELECTRIC RELEASE UNIT**  
1 - washer; 2 - pin; 3 - cover (rear); 4 - armature; 5 - guiding bush; 6 - flng; 7 - housing; 8 - spring; 9 - contact block; 10 - cover (front); 11 - contact system; 12 - insulating pin; 13 - stop; 14 - coil.



**FIG. 45. PNEUMATIC DRIVE OF DOORS OF COMPARTMENT FOR COMMUNICATION AND SIGNALLING EQUIPMENT**  
1, 12 - connections; 2 - ball lock housing; 3 - springs; 4 - sleeve; 5, 11 - rubber gasket rings; 6 - piston; 7 - piston rod; 8 - eye bolt; 9 - bush; 10 - special nut; 13 - felt gasket.



**FIG. 44. IIOCAB COMPARTMENT DOOR CONTROL**  
1 - pneumatic valve; 2 - rods; 3 - bell crank; 4 - pneumatic drive; 5 - compartment door; 6 - IIOCAB panel; 7 - compartment door open position indicator light; 8 - compartment door closed position indicator light.



**FIG. 46. KINEMATIC SYSTEM OF IIOCAB COMPARTMENT DOOR CONTROL**  
1 - pneumatic drive; 2 - bell crank; 3 - rod; 4 - spring; 5 - compartment door closed position indicator switch; 6 - compartment door open position indicator switch; 7 - emergency bomb release circuit interlock switch; 8 - combat bomb release circuit interlock switch.

**SECRET**  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




FIG. 47. B/J-473M ELECTROMECHANICAL HOIST

1 - 507-500 motor; 2 - hoist cables; 3 - handle; 4 - housing; 5 - electric brake clutch switch; 6 - crank adapter; 7 - crank adapter cap; 8 - hoist power supply plug connector; 9 - hoist securing air nut handle; 10 - crank for manual operation; 11 - crank locking device.




FIG. 48. LAYOUT OF B/J-473M HOIST SYSTEM UNITS AND POWER SUPPLY CONNECTIONS

1 - B/J-473 control panel; 2 - B/J-473M electromechanical hoist; 3 - Pre-chance and block; 4 - hoist system power supply distribution box; 5 - hoist system cables; 6 - hoist system ground power supply source; 7 - 100V-473 cables; 8 - C/J-473 control box; 9 - local power source flexible cables.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




FIG. 49. BOMB HOISTING BEAM  
1 - pin; 2 - beam attachment bracket; 3 - hoisting bracket; 4 - beam hook; 5 - hoisting cable; 6 - beam end pulley; 7 - pin




FIG. 50. BOMB HOIST SYSTEM EQUIPMENT




FIG. 51. HOISTING SLING  
1 - hoisting sling cable securing socket;  
2 - rest plate; 3 - cables; 4 - stop.

SECRET  
NO FOREIGN DISSEM



SECRET

NO FOREIGN DISSEM




FIG. 53. DIAGRAM OF BOMB RACK HOISTING  
 1 - hoisting pulleys; 2 - hoist cables, 20 m. long; 3 - end blocks; 4 - electro-mechanical hoists, type BH-473M; 5 - bomb rack.




FIG. 54. DIAGRAM OF BOMB HOISTING TO K/D-423 BOMB RACK  
 1 - bomb bay door; 2 - K/D-83 bomb rack; 3 - hoisting beams; 4 - single-sheave and block; 5 - BH-473M electro hoist; 6 - BH-473M hoist cable, 20 m. long; 7 - bomb rack top pulley; 8 - BH-473M bomb checks; 9 - bomb rack bottom pulley; 10 - K/D-53 hoisting hook; 11 - two-sheave and block.




FIG. 55. DIAGRAM OF BOMB HOISTING TO BOTTOM STATION OF STARBOARD  
 K/D-83  
 1 - bomb rack; 2 - hoist cable, 20 m. long; 3 - BH-473M electro hoist; 4 - hoist cable, 20 m. long; 5 - BH-473M electro hoist; 6 - hoist cable, 20 m. long; 7 - hoist cable, 20 m. long; 8 - hoist cable, 20 m. long; 9 - hoist cable, 20 m. long; 10 - hoist cable, 20 m. long; 11 - hoist cable, 20 m. long; 12 - hoist cable, 20 m. long; 13 - hoist cable, 20 m. long; 14 - hoist cable, 20 m. long; 15 - hoist cable, 20 m. long.




FIG. 56. DIAGRAM OF BOMB HOISTING TO K/D-88 BOMB RACK  
 1 - hoist cable, 20 m. long; 2 - hoist cable, 20 m. long; 3 - hoist cable, 20 m. long; 4 - hoist cable, 20 m. long; 5 - hoist cable, 20 m. long; 6 - hoist cable, 20 m. long; 7 - hoist cable, 20 m. long; 8 - hoist cable, 20 m. long; 9 - hoist cable, 20 m. long; 10 - hoist cable, 20 m. long; 11 - hoist cable, 20 m. long.

50X1-HUM

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




FIG. 56. HOIST SYSTEM STORED PARTS AND UNITS

- 1 - bag for hoist system parts; 2 - strain 3 - electromechanical hoist, E1L-473M ;
- 4 - bracket for E1L-473M hoist stored position.




FIG. 57. BOMBING EQUIPMENT UNITS READY FOR CHANGING THE BASE

- 1 - hoisting bearing; 2 - E1L-473M electromechanical hoist; 3 - E1L-473M ;
- 4 - E1L-473M hoist ready to be changed; 5 - E1L-473M hoist ready to be changed; 6 - E1L-473M hoist ready to be changed; 7 - bomb rack for attachment assembly; 8 - bomb rack for attachment assembly; 9 - attachment assembly to hoist; 10 - easy-to-remove attachment belt.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




FIG. 58. CATWALK AND SERVICE LADDER, GENERAL VIEW  
1 - catwalk; 2 - service ladders; 3 - bomb-bay doors; 4 - beam.




FIG. 60. LOCKING OF AIVB-1 FUZE WITH MAB-1 DELAYED COCKING MECHANISM  
1 - YBI-1 arming wire; 2 - MAB-1 delayed cocking mechanism; 3 - AIVB-1 fuze.




FIG. 59. YBI ARMING WIRE (No. 1)  
1 - wire; 2 - arming ring; 3 - S-shaped ring; 4 - snap hook; 5 - number tag.




FIG. 61. YBI ARMING WIRE NO. 1 WITH ADDITIONAL LINK CABLE FOR FLARE BOMBS  
1 - arming wire; 2 - additional link cable; 3 - locking fork.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM




FIG. 62. ADDITIONAL LINK CABLE FOR FLARE BOMBS (CAB)  
1 - cable; 2 - tube; 3 - snap hook; 4 - locking fork.




FIG. 63. INTERLOCK SYSTEM SWITCH BOX




FIG. 64. DISTRIBUTION BOX OF EMERGENCY BOMB RELEASE (WITH MAINS DE-ENERGIZED) SYSTEM  
1 - K-50 emergency release relay.




FIG. 65. EMERGENCY BOMB RELEASE DISTRIBUTION BOX  
1 - K-50 emergency release relay; 2 - emergency release control relay; 3 - PIS-2 feed relay of ARMED release indication circuit; 4 - terminal block.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 66. BOMB RELEASE DISTRIBUTION BOX  
1 - PT-3 relay to cut out K/D-433 bomb rack of rear row; 2 - PT-6 relay of carbide release circuit; 3 - PT-2 feed relay of MSH-48 arming mechanism; 4 - terminal block; 5 - CT-5 fuse panel.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 66. BOMB RELEASE DISTRIBUTION BOX  
1 - relay to cut out K13-433 bomb rack of rear row; 2 - P11-6 relay of cockpit release; 3 - P11-2 feed relay of K13-433 wiring mechanism; 4 - terminal block; 5 - C11-5 fuse panel.

FIG. 67. BOMBING EQUIPMENT CIRCUIT DIAGRAM (AIRCRAFT OF EARLIER MAKE)


1 - BH-45 switch of stand-by bomb-door opening system; 2 - BH-45 switch of stand-by bomb-door door operation control switch, TB-45; 4 - 31C-1 solenoid of stand-by door opening system; 5 - 31-12 solenoid system; 6 - bomb door opening solenoid, 31B-12; 7 - bomb release circuit interlock switch, 2B-45 (used as 8 - PT-40 relay of emergency release bomb door closing circuit interlock system; 9 - bomb door closing solenoid; 10 - bomb door closing solenoid; 11 - bomb door closing solenoid; 12 - bomb-door door closed position indicator limit switch, BK2-142B; 13 - bomb door closed position indicator light, C111-51; 14 - bomb-door door open position indicator light, C111-51; 15 - ARMED release indicator light switch, 11-4; 17 - bomb door closed position indicator light, C111-51; 18 - navigator's READY TO DROP indicator light, C111-51; 19 - station status indicator light, C111-51; 20 - bomb-door door open position indicator limit switch, BK2-14

plug connector, assemblies 1-2, 3-4, portside; 22 - K14-388 bomb rack plug connector, assemblies 2-4, 23 - K14-433 bomb rack plug connector, assemblies 6-8, portside; 24 - K14-388 bomb rack plug connector, 25 - K14-433 bomb rack plug connector, assemblies 11-12, portside; 26 - K14-388 bomb rack plug connector, 27 - K14-388 bomb rack plug connector, assemblies 2-4, 5-7, starboard; 28 - K14-433 bomb rack plug connector, assemblies 6-8, starboard; 29 - K14-388 bomb rack plug connector, assemblies 10-12, starboard; 30 - K14-433 bomb rack plug connector, assemblies 11-12, starboard; 31 - station status (with bomb-door doors closed) check button, BK2-142B; 32 - master bombing switch, KCB-43; 33 - course stabilizer, A13-21; 34 - navigator's master bomb release button, KCB-43; 35 - master bombing switch, KCB-43; 36 - interometer, KCB-43; 37 - navigator/operator's READY TO DROP indicator relay of 31C1P-43A and ARMED feed circuit interlock system; 39 - master bombing switch, 2B-45; 40 - spare duplicate feed bus (navigator's left-hand circuit breaker panel); 42 - B-45 switch of rear K13-433 bomb rack; 43 - duplicate feed bus (navigator's right-hand circuit breaker panel); 44 - switch of rear K13-433 bomb rack; 45 - solenoid switch, I box, KCB-43; 47 - duplicate feed bus (navigator's right-hand circuit breaker panel); 48 - duplicate feed bus, ARMED release switch, B-45; 50 - pilot's emergency ARMED release switch, B-45; 51 - navigator's ARMED release switch, B-45; 52 - pilot's emergency bomb release switch, B-45; 53 - navigator's emergency bomb release switch, I release limit switch, BK2-142B; 54 - KOC-43 dome lamp indicating that the bomb release circuit and bomb rack are working in bomb bay; 57 - pilot's ARMED release indicator light, C111-51; 58 - BK-44 limit switch of de-energized; 59 - emergency bomb release control relay, P11-2; 60 - B-45 switch of indicator work in bomb bay; 61 - emergency bomb door opening solenoid, 31C-1; 62 - BK2-142B interlock limit switch de-energized; 63 - K-501 relay of emergency bomb release circuit with main de-energized; 64 - emergency bomb release control panel, with main de-energized; 65 - feed bus of fuel pumps distribution box on fuel pumps distribution box on frame No. 49; 66, 69 - plug connector socket to connect B11-431 to

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM



SECRET  
NO FOREIGN DISSEM






SECRET  
NO FOREIGN DISSEM

50X1-HUM

**WIREMENT CIRCUIT DIAGRAM (AIRCRAFT OF EARLIER MAKE)**

2 - BK-45 switch of stand-by bomb-bay door closing system; 3 - bomb-bay door closing solenoid of stand-by door opening system; 9 - 24-12 solenoid of stand-by door closing system; 7 - bomb release circuit interlock switch; 20-48 (used during work in bomb bay); 2 - closing circuit interlock system; 9 - bomb door closing solenoid; 10, 11 - combat bomb bay door closed position indicator light switch, BK2-1423; 13 - combat bomb release indicator light, CIL-51; 15 - ARMED release indicator light, CIL-51; 16 - pocket-type indicator light, CIL-51; 10 - navigator's READY TO DROP indicator light, CIL-51; 21 - bomb-bay door open position indicator light switch, BK2-1423; 21 - KIP-423 bomb rack

22 - KIP-4-323 bomb rack plug connector, assemblies 2 - 4, 5-7, 6-9, portside;  
23 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, portside;  
24 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, portside;  
25 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
26 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
27 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
28 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
29 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
30 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
31 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
32 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
33 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
34 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
35 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
36 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
37 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
38 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
39 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
40 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
41 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
42 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
43 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
44 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
45 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
46 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
47 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
48 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
49 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
50 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
51 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
52 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
53 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
54 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
55 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
56 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
57 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
58 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
59 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
60 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
61 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
62 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
63 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
64 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
65 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
66 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
67 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
68 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
69 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
70 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
71 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
72 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
73 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
74 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
75 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
76 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
77 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
78 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
79 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
80 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
81 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
82 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
83 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
84 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
85 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
86 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
87 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
88 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
89 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
90 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
91 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
92 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
93 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
94 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
95 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
96 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
97 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
98 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
99 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;  
100 - KIP-4-323 bomb rack plug connector, assemblies 10 - 12, starboard;




SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM



RELEASE DISTRIBUTION BOX  
1 - rack of rear row; 2 - P1-6 relay of cockpit release control mechanism; 4 - terminal block; 3 - C1-5 fuse panel.


FIG. 67. BOMBING EQUIPMENT CIRCUIT DIAGRAM (AIRCRAFT OF EARLIER MAKE)

1 - BH-45 switch of stand-by bomb-bay door opening system; 2 - BH-45 switch of stand-by bomb-bay door opening control switch, (B-45); 4 - 30C-1 solenoid of stand-by door opening system; 5 - 2B-12 solenoid system; 6 - bomb door opening solenoid, 3B-12; 7 - bomb release circuit interlock switch, 2B-45 (used as 8 - PT-40 relay of emergency release bomb door closing circuit interlock system; 9 - bomb door closing solenoid; 10 - emergency release bomb door closing circuit interlock switch, BK2-142B; 12 - bomb-bay door closed position indication limit switch, BK2-142B; 14 - bomb-bay door open position indicator light, CIL-51; 15 - ARMED release indicator light switch, B-4; 17 - bomb door closed position indicator light, CIL-51; 18 - navigator's READY TO DROP indicator light, CIL-51; 20 - bomb-bay door open position indication limit switch, BK2-142B; 21 - station status indicator light, CIL-51; 22 - K14-388 bomb rack plug connector, assemblies 2 - 4, starboard; 23 - K14-388 bomb rack plug connector, assemblies 6 - 8, portside; 24 - K14-388 bomb rack plug connector, assemblies 10 - 12, starboard; 25 - K14-388 bomb rack plug connector, assemblies 11 - 12, portside; 26 - K14-388 bomb rack plug connector, assemblies 13 - 14, starboard; 27 - K14-388 bomb rack plug connector, assemblies 15 - 16, portside; 28 - K14-388 bomb rack plug connector, assemblies 17 - 18, starboard; 29 - K14-388 bomb rack plug connector, assemblies 19 - 20, portside; 30 - K14-388 bomb rack plug connector, assemblies 21 - 22, starboard; 31 - station status (with bomb-bay doors closed) check button, BK2-142B; 32 - master bomb release button, KCB-4; 33 - course stabilizer, A15-2M; 34 - navigator's combat bomb release button, KCB-4; 35 - master bomb release button, KCB-4; 36 - intercom, 30BP-4A; 37 - navigator's READY TO DROP indicator relay of 30BP-4A and ARMED feed circuit interlock system; 39 - master bombing switch, 2B-45; 40 - emergency release switch, B-45; 41 - duplicate feed bus (navigator's left-hand circuit breaker panel); 42 - B-45 switch of rear K14-388 bomb rack (K14-388) cutout relay, P1-3; 44 - 2B-45 switch of rack selector relay; 45 - solenoid switch, 1 row bomb rack (K14-388) cutout relay, P1-3; 46 - 2B-45 switch of rack selector relay; 47 - duplicate feed bus (navigator's right-hand circuit breaker panel); 48 - duplicate feed bus, KCB-4; 49 - duplicate feed bus (navigator's emergency ARMED release switch, B-45); 51 - navigator's ARMED release switch, B-45; 52 - pilot's emergency bomb release switch, B-45; 53 - navigator's emergency bomb release switch, I release limit switch, BK2-142B; 56 - KOC-45 dome lamp indicating that the bomb release circuit and bomb bay door opening mechanism is blocked; 57 - pilot's ARMED release indicator light, CIL-51; 58 - BK-44 limit switch of door release circuit is blocked; 59 - emergency bomb release control relay, P1-2; 60 - B-45 switch of indicator work in bomb bay; 61 - emergency bomb door opening solenoid, 30C-1; 62 - BK2-142B interlock limit switch de-energized; 63 - K-3001 relay of emergency bomb release circuit with solenoid de-energized; 64 - emergency bomb release control panel, with solenoid de-energized; 66 - feed bus of fuel pumps distribution box on fuselage distribution box on frame No. 49; 68, 69 - plug connector socket to connect B-7-4731 to

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM


50X1-HUM



SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM


50X1-HUM.



SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM



SECRET


NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

**WIRING CIRCUIT DIAGRAM (AIRCRAFT OF LATER MAKE)**

- 1 - 43 switch of stand-by bomb-door closing system; 3 - bomb-door release switch of stand-by bomb-door opening system; 5 - 23-12 solenoid of stand-by bomb-door opening system; 6 - 23-12 solenoid of stand-by bomb-door opening system; 7 - bomb release circuit interlock switch, 20-45 fused during work in bomb bay; 8 - release limit switch, BK2-142D; 12 - bomb-door closed position indicator light, PIT-8; 14 - bomb-door open position indicator light, CMI-51; 15 - station status indicator light, CMI-51; 17 - bomb-door closed position indicator light, CMI-51; 18 - station status indicator light, CMI-51; 20 - bomb-door open position indicator light, CMI-51; 21 - 22 - KJ4-338 bomb rack plug connector, assemblies 3-4, parts/des; 24 - KJ4-338 bomb rack plug connector, assemblies 6-8, parts/des; 26 - KJ4-338 bomb rack plug connector, assemblies 11-12, parts/des; 25 - KJ4-338 bomb rack plug connector, assemblies 2-4, parts/des; 28 - KJ4-338 bomb rack plug connector, assemblies 10-12, 11-12, standard; 31 - station status (with bomb-door closed) check button, BK2-140B; 32 - AIT-5-21; 34 - navigator's combat bomb release button KCB-0; 35 - Interrelator, SCP-CA; 37 - navigator's emergency bomb release button (with active de-energized); 39 - master bombing switch, located ARMED feed circuit interlock system; 42 - B-45 switch of navigator's left-hand circuit breaker panel; 43 - duplicate of station status feed bus (navigator's circuit breaker right-hand panel); 43 - duplicate of station status feed bus (navigator's circuit breaker right-hand panel); 45 - selector switch; 50 - pilot's emergency ARMED release switch, B-43; 51 - navigator's emergency bomb release switch, B-43; 53 - navigator's emergency bomb release switch (with active de-energized); 55 - KCB-45 fuse lamp indicating that bomb release circuit and interlock system is armed; 59 - feed bus of fuel pumps; 62 - pilot's ARMED release indicator light, CMI-51; 63 - BK-44 limit switch; 64 - emergency bomb release control relay, PIT-3; 66 - B-45 switch of bomb door opening; 70C-1; 62 - bomb release interlock limit switch; 71 - relay of emergency bomb release (with active de-energized circuit); 72 - panel (with active de-energized); 65 - feed bus of fuel pumps; 66 - station status feed bus; 67, 68, 69 - plug connector socket to connect BU, WCB; 70 - station status feed bus; 72 - emergency ARMED release switch; 73 - bomb door opening with active de-energized.



SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 68. BOMBING EQUIPMENT CIRCUIT DIAGRAM (AIRCRAFT OF LATER MAKE)

1 - BH-45 switch of stand-by bomb-bay door opening system; 2 - BH-45 switch of stand-by bomb-bay door closing system; 3 - bomb-bay door operation control switch, (BH-45); 4 - 3/1C-1 solenoid of stand-by bomb-bay door opening system; 5 - 3A-12 solenoid of stand-by bomb-bay door closing system; 6 - bomb door opening solenoid, 7A-12; 7 - bomb release circuit interlock switch, BK2-142B; 8 - bomb bay door closed position indicator limit switch, BK2-142B; 9 - bomb bay door open position indicator light, C/IL-51; 10 - bomb bay door closed position indicator light, C/IL-51; 11 - ARMED release indicator light, C/IL-51; 12 - pack-type switch, P-4; 13 - bomb door closed position indicator light, C/IL-51; 14 - navigator's READY TO DROP indicator light, C/IL-51; 15 - station status indicator light, C/IL-51; 16 - bomb-bay door open position indicator limit switch, BK2-142B; 17 - K/4-388 bomb rack plug connector, assemblies 2-4, portside; 18 - K/4-388 bomb rack plug connector, assemblies 2-4, starboard; 19 - K/4-388 bomb rack plug connector, assemblies 11-12, portside; 20 - K/4-388 bomb rack plug connector, assemblies 11-12, starboard; 21 - K/4-388 bomb rack plug connector, assemblies 2-4, portside; 22 - K/4-388 bomb rack plug connector, assemblies 2-4, starboard; 23 - K/4-388 bomb rack plug connector, assemblies 11-12, portside; 24 - K/4-388 bomb rack plug connector, assemblies 11-12, starboard; 25 - K/4-388 bomb rack plug connector, assemblies 2-4, portside; 26 - K/4-388 bomb rack plug connector, assemblies 2-4, starboard; 27 - K/4-388 bomb rack plug connector, assemblies 2-4, portside; 28 - K/4-388 bomb rack plug connector, assemblies 2-4, starboard; 29 - K/4-388 bomb rack plug connector, assemblies 10-12, starboard; 30 - K/4-388 bomb rack plug connector, assemblies 11-12, starboard; 31 - station status (with bomb door closed) check button, BK2-140B; 32 - bomb-sight power supply resistor, 40K; 33 - course stabilizer, AT-5-21; 34 - navigator's combat bomb release button, KCB-49; 35 - navigator's combat bomb release button, KCB-49; 36 - intervalometer, KCB-49A; 37 - navigator's READY TO DROP indicator light, C/IL-51; 38 - PT-40 relay of intervalometer and ARMED feed circuit interlock system; 39 - master bombing switch, 2B-45; 40 - spark extinguisher, HY-50; 41 - duplicate feed bus (navigator's left-hand circuit breaker panel); 42 - B-45 switch of rear K/4-388 bomb rack output relay; 43 - K/4-388 rear bomb rack output relay, P/4-3; 44 - rack selector relay switch, 2B-45; 45 - active switch, B-45; 46 - bomb release variation box, KCB-49; 47 - duplicate feed bus (navigator's circuit breaker right-hand panel); 48 - duplicate feed bus; 49 - navigator's emergency ARMED release switch, B-45; 50 - pilot's emergency ARMED release switch, B-45; 51 - navigator's ARMED release circuit interlock switch, B-45; 52 - pilot's emergency bomb release switch, B-45; 53 - navigator's emergency bomb release switch, B-45; 54, 55 - emergency bomb release limit switch, BK2-142B; 56 - KOC-45 de-energ lamp indicating that bomb release circuit and bomb-bay door closing system are blocked (for work in bomb bay); 57 - pilot's ARMED release indicator light, C/IL-51; 58 - BK-44 limit switch of door lamp indicating that bomb release circuit is blocked; 59 - emergency bomb release control relay, P/4-2; 60 - B-45 switch of indication circuit interlocking (for work in bomb bay); 61 - emergency bomb door opening, 3/1C-1; 62 - bomb release interlock limit switch, BK2-142B (with main de-energized); 63 - emergency bomb K-50A relay of emergency bomb release (with main de-energized circuit); 64 - emergency bomb release relay, K-50A; 65 - bomb release control panel (with main de-energized); 66 - feed bus of fuel pumps distribution box on frame No. 33; 67 - feed bus of fuel pumps distribution box on frame No. 47; 68, 69 - plug connector socket to connect B/1-473J solenoid; 70 - ARMED release indicator relay, P/4-2; 71 - P/4-2 relay of MBH-43 arming mechanism feed line; 72 - emergency ARMED release limit switch, BK2-142B; 73 - B-45 switch of bomb door opening with main de-energized.

SECRET

NO FOREIGN DISSEM

Declassified in Part - Sanitized Copy Approved for Release 2013/02/21 : CIA-RDP80T00246A070800100001-4

**SECRET**  
NO FOREIGN DISSEM

**SECRET**  
NO FOREIGN DISSEM

Declassified in Part - Sanitized Copy Approved for Release 2013/02/21 : CIA-RDP80T00246A070800100001-4



SECRET  
NO FOREIGN DISSEM




FUEL CONSUMPTION CONTROL UNITS  
AND  
TU-16 AIRCRAFT ENGINE INSTRUMENTS

GROUP 1  
Excluded from automatic  
downgrading and  
declassification

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM

**FUEL CONSUMPTION  
CONTROL UNITS  
AND  
Ty-16 AIRCRAFT  
ENGINE INSTRUMENTS**

S-E-C-R-E-T  
NO FOREIGN DISSEM



50X1-HUM

CONTENTS

	Page
<u>Chapter I.</u> GENERAL INFORMATION ON FUEL SYSTEM OF T7-16 AIRCRAFT .....	5
1. Engine Fuel Supply System .....	5
2. Fuel Jettison System .....	6
<u>Chapter II.</u> FUEL CONSUMPTION CONTROL AND FUEL QUANTITY MEASURING EQUIPMENT CSTC-60R(ANT-88R).....	8
1. Fuel Gauge Measuring Equipment .....	8
Operating principle. Description of measuring equipment operation .....	8
Construction of fuel gauge units .....	13
Arrangement of fuel gauge set units on aircraft .....	18
Main technical characteristics of fuel gauge set CSTC-60R .....	18
Checking fuel gauge set operation on aircraft .....	19
2. Portable Fuel Gauge Tester JIME-1 .....	20
Tester description .....	21
Description of checking circuits .....	21
Tester operation .....	23
Tester main technical data .....	25
3. Procedure for Determining Reading Error of Fuel Gauges and Fuel Flow Meters on Aircraft .....	25
4. Operation of Fuel Gauges on Aircraft .....	27
5. Automatic Control of Fuel Consumption .....	29
Operating principle. Description of automatic equipment operation .....	29
Manual control of fuel consumption .....	34
Construction of fuel consumption control equipment units .....	35
Arrangement of fuel consumption control equipment on aircraft ...	38
Checking fuel consumption control equipment for proper operation on aircraft .....	39
Electric fuel gauge set CSTC-60M .....	40
Portable tester JIA-53-60 for checking automatic equipment of fuel gauge sets CSTC-60R and CSTC-60M .....	46
Operation of fuel system automatic equipment .....	50
<u>Chapter III.</u> ENGINE INSTRUMENTS.....	54
1. Instruments Indicating Temperature and Pressure .....	56
Three-pointer electric engine-gauge unit ENM-3P .....	56
Remote-reading pressure gauge SEM-3 .....	61
Thermoelectric thermometer TET-11 .....	63
Thermoelectric thermometer TET-29 .....	65

The book contains 72 pages. 6 inserts and 78 figures on 28 sheets are appended to the book.



- 4 -

Pressure signalling unit CR-2A .....	Page 65
2. Speed Measuring Instruments .....	66
Remote-reading electric tachometer TS-5-2 .....	66
Two-pointer remote-reading electric tachometer TS-45 .....	68
3. Total Fuel Flow Meter PFO-16 .....	69

Secret 50X1-HUM

CHAPTER I  
GENERAL INFORMATION ON FUEL  
SYSTEM OF T-16 AIRCRAFT

1. ENGINE FUEL SUPPLY SYSTEM

The PR-3M engines on the T-16 aircraft operate on fuel T-1, State Standard GOCT No.4130-49, or TC-1, State Standard GOCT No.7149-34. Fuel B-1 and TC-1 may be blended in any proportion.

The entire amount of fuel on the aircraft is held in 27 rubber tanks, comprising 10 groups, each engine being served by 5 tank groups. Should it be necessary, fuel may be delivered to any of the two engines from any tank group. Grouping of the tanks and respective capacity values are given in Table 1.

Table 1.  
 Tank grouping and capacity values

Group No.	Left engine			Right engine		
	Tank No.	Service tank No.	Tank group capacity, lit.	Tank No.	Service tank No.	Tank group capacity, lit.
I	1 and 2	2	6250	3	3	6350
II	4	4	3300	3	3	3150
III	7-11 (left)	10	3850 (right)	7-11 (right)	10	3850
IV	12-16 (left)	16	3050	12-16 (right)	16	3050
V	6 (left)	6	2700	6 (right)	6	2700

Arrangement of the fuel tanks and capacitance-type fuel gauge set CSTC-60M on the aircraft is shown in Fig.1. Tanks No. 7 - 16 are accommodated in the wings. The remaining tanks are located in the fuselage.

Each of the service tanks of the respective groups is furnished with booster pump SMH-T driven by electric motor MB-630T. Tanks No.2 and 3 are furnished with two booster pumps each, which provides for more reliable operation. By reference to Table 1, it will be seen that tanks No.2 and No.3 are the largest ones. Besides, these tanks are located at a greater distance from the aircraft centre of gravity than the other tanks. Therefore, if the booster pump located in one



50X1-HUM

of these tanks falls, no fuel will be drawn from the tank which is likely to cause displacement of the centre of gravity. To avoid this tanks No.2 and No.6 are furnished with two pumps each; the pumps run in parallel at the same rating.

The fuel from the tanks is delivered to the engines along the pipe lines under a pressure built up by the booster pumps (Fig.2).

Installed in the pipe lines between the tank groups are non-return valves, preventing fuel transfer from one tank group to another. The pipe lines from all five tank groups (for each engine) run to common fuel lines. The following equipment is installed in both of the common fuel lines:

- (a) one main dump valve 3; the valve is used for discharging fuel from all five tank groups of the given side;
- (b) one fuel shut-off valve 6 with electric mechanism MEX-2; fuel from the shut-off valves is delivered to low-pressure pumps 7 (unit 453 or MH-1A), mounted on the engines, and further, via transmitters 8 of fuel flow meters FTK-16, fuel-cooled oil coolers 9 (unit 62) and filter 10 to engine high-pressure plunger pumps MH-73-15.

The fuel shut-off valve (Fig.3) is of a valve type. It serves for cutting off the pipe line carrying fuel to the engine and may have, two positions: OPEN (OTKRYTO) and CLOSED (ZAKRYTO). With the aircraft positioned on the parking ground, the fuel shut-off valve should be closed.

Reset control of the fuel shut-off valve is accomplished by the use of electric mechanism MEX-2.

A cross-feed valve (Fig.4) is provided for connection of the two main fuel systems for the left and right engines. It is designed for feeding fuel from any tank group to each of the engines. By manipulating the valve it is possible to deliver fuel from any group of the right engine to the left engine, and vice versa. The valve may be set in two positions: OPEN (OTKRYTO) and CLOSED (ZAKRYTO). The valve is controlled by means of electric mechanism MEX-2.

The cross-feed valve may be open in the following cases:

- (a) when one of the engines stops; in this case fuel from the identical tank groups still be used by the running engine, which provides for preserving the aircraft balance;
- (b) when part of the fuel amount is lost (for instance, because of damage to one of the tank groups) or when there is a great difference between fuel amount held in the identical tank groups of the left and right engines; in this case the excess fuel is delivered to both engines; as soon as the proper balance in fuel distribution is obtained, the cross-feed valve is closed.

The switches for control of the fuel shut-off and cross-feed valves are mounted on the fuel supply panel. The open position of the fuel shut-off valves is indicated by green pilot lamps mounted on the same panel.

2. FUEL JETTISON SYSTEM

Provision has been made on the aircraft for jettisoning fuel from the first, third, and fourth tank groups. Fuel jettisoning is resorted to in the following cases:

- for unloading the aircraft prior to forced landing;
- for eliminating bank when landing with one of the wing tank groups still holding large amount of fuel.

The fuel jettison system incorporates the following equipment (Fig.5):

- (a) two main fuel jettison valves (cocks) 13 with telescopic connections, installed in tanks No.16; these valves are accessible through panels, located on the lower surface of the wing and fitted with pneumatic locks;

- (b) two valves 14, mounted on the flange joints between tanks No.11 and No.12;

- (c) two fuselage fuel jettison valves 9 and 12, mounted on frame No.26 (below) and at frame No.49 (over the beam on the right);

- (d) pneumatic switch 8, installed on the fuselage port side, at frame No.21;

- (e) valve 7 for control of fuel jettison. It is mounted on captain control panel 6.

Control of the fuel jettison system is accomplished with the aid of compressed air pressurized to 60 kg/cm<sup>2</sup>. When valve 7 is open, compressed air is delivered simultaneously to the pneumatic mechanisms of the four wing (14, 15) and two fuselage (9, 12) fuel jettison valves, to pneumatic switch 8 and to the locks of the panels located on the lower surface of the wing, below the fuel jettison valves. Fuel jettison from the wing tanks (from the third and fourth groups) is accomplished by gravity via valves 13 installed in tanks No.16. Fuel from the second group tanks (tanks No.1, No.2, and No.3) is jettisoned with the help of the booster pumps via the pipe line used for filling the fuselage tanks in flight. For this purpose, the main fuel pipe line is connected by means of special piping to the line serving for aircraft refuelling in flight; the connection is done after the pumps of tank No.2 (at frame No.26) and tank No.3 (at frame No.49).

The fuselage valves for fuel jettison are mounted in the above connecting pipes and are opened as soon as the fuel jettison control valve is set in the open position. During fuel jettison, fuel is delivered by the booster pumps from tanks No.1, No.2, and No.3 to the pipe line serving for aircraft refuelling in flight, to be carried to the terminal connection located in the tip fairing of the left wing. When the fuel jettison control cock is open, compressed air is delivered to the pneumatic switch, which starts the pumps of tanks No.2 and No.3, if they have been inoperative.

It takes about 11 min. to dump 11 tons of fuel from the first tank groups. Sixteen min. are enough to empty the third and fourth tank groups (in both wings) holding 12 tons of fuel. Thus, to jettison the maximum amount of fuel equal to 23 tons, about 16 min. will be required. Rate of fuel discharge will be reduced by the end, resulting in only 1.3 t of fuel being drained within the last 5 min. This is due to a decrease in the pressure head of fuel contained in the third group tanks, as a result of which fuel will flow at a slower rate via the side valves.

During flight tests of the system it has been found that the aircraft starts rolling to the left as soon as a jet of fuel begins to issue from the left wing tip fairing hole. This causes the ailerons to impose a load of about 5 to 7 kg on the control wheel. However the load is fully balanced by the trim tab.



50X1-HUM

$$C = \frac{\epsilon S}{d}$$

where C - is capacitance;  
S - is the effective area of the plates;  
 $\epsilon$  - is the specific inductive capacitance of the medium;  
d - is the distance between the plates.  
The capacitance of a cylindrical capacitor (Fig.8) is determined by

$$C = \frac{2\pi \epsilon l}{\ln \frac{R_2}{R_1}}$$

CHAPTER II

FUEL CONSUMPTION CONTROL AND FUEL QUANTITY MEASURING EQUIPMENT CSTC-60R (ART-88R)

The capacitance-type fuel gauge of the ART-88R type, modification CSTC-60R (or modernized set CSTC-60R) is designed for:  
(a) measuring quantity of fuel in the five tank groups (total amount) and in each of the groups separately;  
(b) automatic control of sequence of fuel consumption in flight;  
(c) automatic control of cocks for aircraft refuelling in flight;  
(d) indicating fuel reserve remaining for 30 and 15 min.  
The CSTC-60R set (Fig.6) includes:

- Indicators ..... 2 pieces
- Measuring equipment amplifiers JT-88 ..... 2 pieces
- Fuel consumption control unit amplifiers JAT-52-5 ..... 2 pieces
- Rotary Switches RT-7 ..... 2 pieces
- Main transmitters with signalling beams ..... 10 pieces
- Additional transmitters with signalling beams ..... 5 pieces
- Additional transmitters without signalling beams ..... 2 pieces

1. FUEL GAUGE MEASURING EQUIPMENT

Operating principle  
Description of measuring equipment operation

The measuring equipment provides for measuring fuel quantity;  
(a) in each of the tank groups feeding fuel to the pertinent engine (group measuring);  
(b) in all tanks feeding fuel to the given engine (total measuring).  
Each of the engines has its own equipment for measuring fuel quantity both in individual tank groups and in all tanks. The respective electric circuits of the right and left engine fuel measuring equipment are identical and are not connected to each other.  
The operating principle of the measuring system in question is based on conversion of a non-electric value (changing fuel level) into an electric value (respectively varying capacitance). This conversion is effected by the use of variable capacitance transmitters. As is known, capacitance between two flat plates (Fig.7) amounts to

If the flat plates are placed into a vessel (Fig.9) containing fuel (kerosene), capacitance between these plates will change as compared to capacitance between the plates surrounded by air, as air and kerosene have different specific inductive capacitance values. Fuel, air and water have the following specific inductive capacitance values:

- fuel, grade T-1 -  $\epsilon = 2.04$ ;
- fuel, grade TC-1 -  $\epsilon = 1.92$ ;
- air -  $\epsilon = 1$ ;
- water (cleaned) -  $\epsilon = 82$ .

Thus, capacitance value will be approximately two times as great when the interplate space is filled with fuel than when it is filled with air. Lowering of the fuel level in the vessel due to drainage will cause a corresponding reduction in the capacitance, as part of the interplate space will be filled with air.

The volume of fuel in the aircraft fuel system is proportional to fuel level in the tanks. However, the aircraft fuel tanks are of complex configuration which is dictated by structural considerations. Therefore, to ensure that changes in volume be proportional to variations in capacitance of the tubular capacitors (or to changes in the level), profiling is resorted to. For measuring the quantity of fuel in the tanks 17 variable capacitance transmitters are installed in the aircraft. The transmitters comprise a number of concentric tubes, which are profiled to ensure identical capacitance values per volume unit.  
Tube profiles are calculated proceeding from the curve showing dependence of fuel volume on its level, that is

$$V = f(H)$$

Table 2 presents relation  $V = f(H)$ . Fuel gauges CSTC-60R are calibrated in accordance with this table.



Table 2

No.	Volume, lit.	Height to transmitter flange, cm						
		I group, left	I group, right	II group, left	II group, right (tank No.)	III group, left and right	IV group, left and right	V group, left and right
1	0	2096	2120	1525	0	1035	784	1038
2	500	1796	1880	1293	54	887	968	884
3	1000	1586	1692	1114	170	815	488	706
4	1500	1416	1536	938	288	757	410	537
5	2000	1272	1408	757	400	702	332	374
6	2500	1160	1296	563	530	648	238	188
7	3000	1072	1188	310	714	593	71	0/2860
8	3500	948	1072	0/3360	771/3009	536	0/3100	
9	4000	944	964			465		
10	4500	736	850			409		
11	5000	624	740			334		
12	5500	504	628			247		
13	6000	376	516			64		
14	6500	236	388			0/6080		
15	7000	0/7095	220					

**Notes:** Fractional numbers denote filling of tank groups up to the flange of the upper transmitter. In the case of the transmitter incorporated in tank No. 3, the fractional number denotes that the tank is filled to the very top of the transmitter.

Transmitter capacitance is measured with the help of a self-balancing A.C. bridge.<sup>1</sup> The transmitter is connected into one of the bridge arms (Fig. 10). It consists of two resistors R<sub>1</sub> and R<sub>2</sub> (9 and 12), voltage divider R<sub>x</sub> (13) interposed between them, and two capacitances C<sub>0</sub> (7 and 11) and C<sub>x</sub> (6) representing the capacitance of the transmitter.

One of the bridge diagonals is supplied with voltage from the secondary winding of transformer 1, whereas the other diagonal incorporates an amplifier connected between points I and II. Decreasing of the fuel level in the tank will cause changes in capacitance C<sub>x</sub>, which will result in potential difference on bridge diagonals I and II. This potential difference is applied to the grid of the valve incorporated in the first amplification stage, comprising one half of twin triode 6H9C (3 and 10). The voltage amplified in the first stage is applied to the grid of the second amplification stage, arranged on the other half of the same valve.

<sup>1</sup> The self-balancing bridge employed for measuring transmitter capacitance is practically not affected by variations in mains voltage or in current frequency.

The voltage amplified in the second stage is applied to the grid of third amplification stage 4, which is located on twin triode 6H9C and represents a power amplifier. The anodes of the amplifying valves are supplied with rectified current. Valve 6H9C(2) is employed as a rectifier. From the third stage the voltage is fed to the primary winding of output transformer 5, whose secondary winding supplies voltage to the control winding of induction-type reversing electric motor 3H1-0.5(14) accommodated in the indicator.

The electric motor starts running, thereby turning the indicator pointer to the corresponding division and actuating the slider of voltage divider 13. Turning of the slider will cause the potential difference between points I and II to decrease, approaching zero. The bridge will start to come to a balance.

As the potential difference decreases to the zero, the bridge will be balanced causing the electric motor to stop, since no signal will be fed from the bridge to the amplifier input. Electric motor 3H1-0.5 will keep the indicator pointer in this position until the capacitance of the transmitter is once again altered due to a change in the fuel level of the given tank group. This will cause the bridge balance to be disturbed again, as a result of which the above events will be repeated. Bridge balance will be restored when:

$$\frac{1}{C_0} (R_1 + R'_x) = \frac{1}{C_x} (R_2 + R_x)$$

or

$$C_x = \frac{C_0 (R_2 + R_x)}{R_1 + R'_x}$$

where C<sub>x</sub> and R<sub>x</sub> represent variable values.

For group and total measurement of the fuel amount, each amplifier is furnished with two A.C. bridges A and B having some common elements and actuating the same indicator motor.

The common elements of the bridges are as follows: transmitters, voltage divider 13, power amplifier, and rectifier. When fuel is measured in a group of tanks, the transmitters of the respective group are connected into the arm of bridge A, causing the indicator pointer to read the fuel quantity in this group (on the inner scale).

In this case bridge B is disconnected from the system by the action of relay PH-6, incorporated in the amplifier.

When total amount of fuel is to be measured, the transmitters of all tank groups supplying the given engine are connected in parallel and into arm of bridge B. Now the indicator pointer will read the total amount of fuel contained in all the tank groups (on the outer scale of the indicator).

The operating principle of electric motor 3H1-0.5 depends on rotation of a magnetic field created by two currents of the stator windings dephased by 90°. Fig. 11 illustrates the motor windings arranged at an angle of 90° relative to each other.

Currents flowing in the coil windings will create magnetic fields running perpendicular to the plane of winding turns (currents flowing in the windings and subject to sinusoidal alterations are known to cause analogous alterations in the winding magnetic fields proportional to the currents in magnitude).

50X1-HUM

Curves A and B represent the currents of the respective windings. At certain instant the direction of current flowing in winding A is positive and it is maximum in value. Winding B at that instant is demagnetized. Therefore the magnetic field will be formed by the current of winding A only. This magnetic field is represented by vector OA. At following instant C current will flow both in winding A and in winding B, its intensity being the same in both windings and less than the maximum value. The total magnetic action of these two fields is represented by vector OD, which equals vector OA in value.

At instant E current in winding B will reach the maximum intensity, whereas in winding A current will be equal to zero at the same instant. The magnetic field created by the current flowing in winding B will be represented by vector OE which equals vectors OA and OD in value. At instant F current flowing in winding A will reach the maximum intensity but will become negative. At this instant current in winding B will be equal to zero. The magnetic field created by the current flowing in winding A will be represented by vector OA, which equals vectors OE, OD and OE in value. At instant H current will flow both in winding A and in winding B. The total magnetic action of these two fields is represented by vector OH, which equals vectors OA, OE, OE and OA, in value. At instant I current in winding B will reach the maximum value, whereas winding A will be demagnetized.

The magnetic field induced by the current flowing in winding B will be represented by vector OH, which equals vectors OA, OE, OE, OA, and OH, in value. Change taking place in the magnetic field indicates that within one period the magnetic field will turn through 360°, without altering its magnitude. The magnetic field rotates at a constant speed, which depends on the frequency of current fed to the windings.

The windings of electric motor HM-0.5 are supplied with 400 c.p.s. A.C. (consequently, the magnetic field turns through 360° within 1/400 sec.). To change the direction of rotation of the magnetic field, it is sufficient to alter the direction of current in one of the motor windings. The circuit diagram of motor HM-0.5 is presented in Fig. 28 (See Ref. No. 6).

The motor employs two windings: an excitation winding (terminals E and F) and a control winding (terminals S and T).

The excitation winding is supplied with current shifted by 90° in phase relative to the control winding current. To accomplish a 90° shift, a 0.2 μF capacitor is connected in series with the excitation winding. This capacitor is also utilized for reducing voltage from 115 to 30 V.

Rotation of the rotor is reversed by shifting the current phase in the control winding through 180°.

Changes in capacitance of the transmitters will cause respective variations in the phase of the signal sent from the bridge to the amplifier. For instance, when the tanks are being filled with fuel, capacitance of the transmitters will be increasing, whereas fuel consumption from the tanks will result in decreasing of the transmitter capacitance. The phase of the signal between points I and II will change accordingly (See Fig. 10). This will cause a change in the phase of current flowing in the control winding; as a result, the direction of motor rotation will be reversed.

As the indicator pointer turns in unison with the motor rotation, an increase in the transmitter capacitance will cause the pointer to travel in clockwise direction (indicating an increase in fuel amount), whereas decreasing capacitance will make pointer travel counter-clockwise (indicating a decrease in fuel amount).

Variations in the phase of the signal sent from the fuel gauge bridge can be observed with the aid of a voltmeter, connected in bridge diagonal BD (Fig. 12). With the bridge assuming balanced, the voltmeter connected between points a and d will read zero. If capacitance  $C_x$  increases (with the tanks being filled) the potential of point d will be lower than that of point a, since capacitive reactance  $X_{C_x}$  will be reduced. The voltmeter pointer will deflect. In case capacitance  $C_x$  decreases (with fuel being drawn from the tanks) the potential of point d will be higher than that of point a (the voltmeter pointer will deflect in the reverse direction). Thus, direction of current between points a and b will change by 180°, thereby shifting the voltage phase to the same degree.

#### Construction of fuel gauge unit

The measuring equipment of the fuel gauge set comprises the indicator, amplifier, transmitters, and change-over switch.

The indicator serves for reading both the total amount of fuel and amount of fuel contained in the individual tank groups of the aircraft fuel system. It consists of the following main units: two-phase induction motor HM-0.5; rheostat  $R_x$  rated for 1000 ohms; a reduction unit with gear ratio of 1:1500; a rheostat slide and a pointer mounted on the output shaft of the reduction unit.

The mechanical diagram of the indicator is illustrated in Fig. 13. The main components of the motor are the stator and rotor. Placed on the stator is the excitation winding and two control windings connected in series. The rotor is essentially a thin-walled aluminum sleeve possessing low inertia moment. The excitation winding is supplied with A.C. voltage of 30 V, frequency 400 c.p.s. The control windings are fed for short periods with A.C. voltage not exceeding 30 V and delivered from the secondary winding of amplifier output transformer 2 (See Fig. 10).

The maximum permissible current in the control windings should not exceed 110 mA whereas the maximum current in the excitation windings must not exceed 120 mA. Excitation winding resistance amounts to 700 ohms; resistance of each control winding is equal to 260±26 ohms.

Rotation of the engine rotor is transmitted to the output shaft through the medium of the reduction unit having a gear ratio of 1:300. The indicator pointer and the rheostat slide are attached to the reduction unit output shaft. The slide travelling on the rheostat serves for balancing the circuit. The range of the indicator scale amounts to 300°. The scale has two rows of notches. The outer row is designed for reading the total amount of fuel, the inner - for reading the amount of fuel in individual tank groups.

The outer scale (reading the total amount of fuel) is calibrated up to 26,000 lit. The inner scale is calibrated to read as much as 8000 lit. The indicator is illustrated in Fig. 14. The indicator is not furnished with a return spring, therefore the pointer may be deflected even though the fuel supply is cut off, or the circuit is out of order. To check the circuit, provision is made in the indicator construction for a zero setting check button. The circuit is checked by pushing the button (See Ref. No. 6 in Fig. 28), which causes D.C. negative input to be delivered to the excitation winding of relay RM-3, accommodated in the amplifier. The relay picks up thereby cutting off the transmitters (bridge variable arm  $C_x$ ) and connecting a capacitance whose magnitude equals the capacitance of the "dry" transmitters. With the button pressed, the indicator pointer should read zero; permissible error is not in excess of 2 per cent; after the button



is released, the pointer should return to the initial position. If pressing of the button does not cause the pointer to move, the circuit is either damaged or deenergized.

The indicator dimensions: dia. 80 mm, length 150 mm.  
Indicator weight 350 gr.

The amplifier serves for increasing the discharge voltage of the self-balancing bridge, and for delivery of the amplified voltage to the control windings of induction motor **HM-0.5**.

The amplifier consists of four valves (689C - 2 pieces, 6HTC, 6HSC), transformers **Tr<sub>1</sub>** and **Tr<sub>2</sub>**, relays **PI-3** and **PI-6**, four rheostats for adjustment of zero and maximum settings, button **TOTAL AMOUNT CHECK-UP** and button **GROUP CHECK-UP**.

All amplifier components are mounted on the inner and outer surfaces of the chassis, as well as on the inside of the front panel (Fig. 15).

LED to the outer side of the amplifier front panel are axes of four rheostats for adjustment of zero and maximum settings, button **TOTAL AMOUNT CHECK-UP** (4) (Fig. 16), button **GROUP CHECK-UP** (5), three-pin plug connector **HP** (6) for supply of A.C. voltage of 115 V, 400 c.p.s., and D.C. of 27 V, twelve-pin plug connector **HP-7** for connection of the amplifier to the fuel gauge circuit, and safety fuse **S** rated for 1A. The two right-hand rheostats (as viewed from the front panel side) are designed for adjustment of the zero and maximum settings, respectively, on the total amount scale, whereas the two left-hand rheostats serve for adjustment of the zero and maximum settings on the individual group scale.

Buttons **TOTAL AMOUNT CHECK-UP** and **GROUP CHECK-UP** serve for checking the reference points on the total amount and individual group scales. When one of these buttons is pressed, an additional permanent capacitance is connected in parallel with the "dry" transmitters (those of the fuel system containing no fuel). When button **TOTAL AMOUNT CHECK-UP** is pressed, a 6000 pF capacitor is connected in parallel with the transmitters, causing the indicator pointer to read 16,000 lit. Pressing of button **GROUP CHECK-UP** will cause a 2200 pF capacitor to be connected in parallel with the given tank group transmitter; as a result the indicator pointer will read 6000 lit. on the inner scale. The amplifier housing is secured to the bed plate by means of four shock absorbers 2710-29-2-6. The **7T-88** amplifier valve ratings are given in Table 3.

Table 3

7T-88 amplifier valve ratings

Valve type	U <sub>a1</sub> V	I <sub>a1</sub> mA	Anode dissipation rating		U <sub>a2</sub> V	I <sub>a2</sub> mA	Anode dissipation rating		U <sub>r1</sub> V	Main voltage V	Change-over switch handle position
			Actual, W	Specified, W			Actual, W	Specified, W			
689C	75	0.9	0.067	1.1	80	0.45	0.035	1.1	6.3	115	Group
	85	1.0	0.085	1.1	85	0.5	0.043	1.1	6.93	126.5	
6HTC	239	16.2	4.8	6.0	-	-	-	-	6.3	115	Group
	320	18.0	6.0	6.0	-	-	-	-	6.93	126.5	

Valve type	U <sub>a1</sub> V	I <sub>a1</sub> mA	Anode dissipation rating		U <sub>a2</sub> V	I <sub>a2</sub> mA	Anode dissipation rating		U <sub>r1</sub> V	Main voltage V	Change-over switch handle position
			Actual, W	Specified, W			Actual, W	Specified, W			
6HSC	300	13.0	-	-	-	-	-	-	6.3	115	Total
	310	20	-	-	-	-	-	-	6.93	126.5	
689C	75	0.9	0.037	1.1	80	0.52	0.04	1.1	6.3	115	Total
	80	0.95	0.046	1.1	85	0.57	0.048	1.1	6.93	126.5	
6HTC	239	13.0	4.33	6.0	-	-	-	-	6.3	115	Total
	320	18.0	5.99	6.0	-	-	-	-	6.93	126.5	

To connect the power supply negative wire, a conduit is provided on the amplifier housing.

The amplifier overall dimensions 245x176x250 mm, weight 4500 gr.

The amplifier with the bottom plate removed (bottom view) is shown in Fig. 17.

**Transmitters.** The transmitters comprise a set of concentric profiled tubes. The number of tubes varies from 3 to 5, which provides for obtaining considerable specific capacitance, that is capacitance referred to the unit of volume.

Connection of transmitter concentric tubes is illustrated in Fig. 18.

The transmitter consists of the following main parts (Figs 19 and 20): a head, a flange, profiled tubes, a signalling unit coil, a float, a guiding tube, a plug connector, and an earthing screw.

A clearance between the tubes is adjusted within 1.5 to 6 mm. To preserve a permanent clearance, the tubes are interlaid with insulating inserts, fabricated in organic glass (grade K-4).

The lower and upper sections of the transmitter are held with a grooved organic glass ring each. The ends of the transmitter tubes are fitted into the ring grooves.

The rings are fastened to the flange skirt on top and to the outer tube on bottom. Identical tubes (plates) of the transmitter are connected to each other by means of brass lobes, whereas the common ends are led via the guiding tube and the transmitter head to pins A and B of the plug connector. The ends of the signalling unit coils are likewise led via the same guiding tube. The signalling unit coil is not connected to the measuring equipment circuit; it is incorporated in the circuit of the equipment controlling fuel consumption.

To make the transmitter water-proof at the head end, a rubber gasket is inserted between the head and the flange. Besides, the entire head inside is filled with ceresine of grade U-75 or U-83. The transmitters are connected to the fuel gauge circuit with the aid of the following five-pin plug connector:

- A - common for all transmitters;
- B - connecting every group to the grid of the first valve of the measuring equipment amplifier;
- B - connected to the signalling coil (filling);
- Γ - connected to the signalling coil (upper);
- A - connected to the signalling coil (lower).



The main transmitters are 90 mm in diameter, the additional ones - 45 mm. To allow free passage of fuel into and out of the transmitter, the bottom plate of the latter is provided with ports. It will be noted that the transmitter of tank No.3 is installed with the head down. Therefore fuel enters into the transmitter through the drain hole.

Transmitter ratings are presented in Table 4. By reference to the Table it will be seen that the capacitance of the transmitters of one group amounts to 3300pF, whereas specific capacitance is equal to 0.37pF per lit. Initial transmitter capacitance of all five groups is identical. This arrangement allows the use of one indicator (measurement being performed by one bridge). For equalizing the initial capacitance of the transmitter, fixed trimmer capacitors of the KEO-3 or KEO-1 type are placed in its head. If the group incorporates the main and additional transmitters, the respective capacitances will amount to 2300pF and 1000pF. The total capacitance of the group transmitters is equal to 3300pF.

By reference to the transmitter tube connection diagram (See Fig.18) it will be seen that the outer tube (plate) is always soldered to terminal A, while the inner tube is connected to terminal B. This type of connection is provided for all of the transmitters, exclusive of transmitters incorporated in tanks No.7 and No.12, where connection is accomplished in the reverse manner. This arrangement provides protection against interference on the part of the signalling units. The signalling unit should be located on the outer tube which is not connected to the valve grid. The transmitters of tanks No.7 and No.12 have their signalling units arranged on the inner tube, therefore the connection has been accomplished in the reverse manner.

Table 4

СХЭ-601 Transmitter Rating

No. of tank and transmitter	Name of signal	Volume read, lit.	Distance of volume measurement, m		Distance from flange line to transmitter end, mm	Transmitter capacitance, pF	Transmitter weight, gr
			from surface	from center			
1	2	3	4	5	6	7	8
Tank No.2	Filling	6075	80				
	Lower	250	1820	10	7080	2060	3300pF
Tank No.3	Filling	7300	140				
	Lower	250	1940	13	7320	2060	3300pF
Tank No.4	Filling	3710	140				
	Upper	2700	440	30	3410	1509	3300pF
Tank No.3	Lower	250	1400				
	Filling	2920	676	300	3095	784	2300pF
Main	Upper	2320	464				
	Lower	295	117	55	440	196	1000pF

1	2	3	4	5	6	7	8	9
Tank No.7	Upper	5180	308	4177	3977	523	1000pF	1050
Tank No.10	Lower	360	516	59	4177	618	2300pF	1650
Tank No.12	Upper	2340	240	1820	3140	404	1000pF	850
Tank No.16	Fuel left	600	224	10	1870	333	2300pF	1150
Tank No.6	Fuel left	1600	298	25	2320	960	2300pF	2150
Main								
Additional				2320	2890	245	1000pF	600

Fig.21 shows attachment of the fuel gauge transmitters to the fuel tanks. Transmitter 1 is attached to tank flange 2 by means of four bolts. As the transmitters installed in tanks No.2, No.4, and No.5 are rather long, their ends are fitted into special sleeves secured to the bottom plates of the tanks (Fig.22).

Switch. Rotary switch HT-7 (Fig.23) serves for:  
(a) cutting in and out of power supply (115 V, 400 o.p.s.);  
(b) successive connection of transmitters, when checking amount of fuel in individual tank groups;  
(c) connection of all transmitters, when checking total amount of fuel;  
(d) connection of D.C. sinus (27 V) to the excitation winding of relay PH-6, when checking total amount of fuel.  
Rotary switch HT-7 is a wafer type consisting of five sections and having 7 fixed positions: OFF (ЗАЗЕРЖЕНО), TOTAL (СЧЕТА), 1, 2, 3, 4, and 5. With the switch handle set in the OFF position, the power supply is disconnected from the circuit; when the handle is set against 1, 2, 3, 4, and 5, the transmitters of the respective tank groups are connected into the circuit. With the handle set in the TOTAL position, all transmitters are connected in parallel for measuring the total amount of fuel in the tanks.

Switch HT-7 is connected to the circuit with the aid of a twelve-pin plug connector. Fig.24 diagrams the switch in the OFF position. Fig.25 diagrams the switch in the TOTAL position. Wafers II and III connect in parallel the transmitters of the tank groups, corresponding to positions 1, 2, 3, 4, and 5. The common outlet is connected to the measuring equipment amplifier via pin 11 of the plug connector. Wafers IV connect the sinus of D.C. voltage of 27 V to the winding of relay PH-6, arranged in the amplifier, in other words, it feeds the negative voltage from pin 3 to the amplifier via pin 9. Wafer V connects A.C. supply (115 V, 400 o.p.s.), that is voltage delivered to pin 1 is delivered to the amplifier via pin 2. Fig.26 illustrates the diagram of the switch set in position for checking fuel in the I tank group.

Wafer I connects the transmitter of the I tank group, that is, it connects pin 4 to pin 11.  
At the same time, wafers II and III disconnect the transmitters of the I tank group from other groups and from pin 11.  
Wafer IV delivers D.C. from the winding of relay PH-6, that is, it disconnects pin 3 from pin 9 thereby switching the amplifier over from the total amount to the individual group check-up.  
The A.C. supply circuit remains energized throughout the fuel measuring procedure.



When checking the amount of fuel in the II, III, IV, and V tank groups, wafers I connects the respective transmitters (in turn) to the amplifier, whereas wafers II and III cut the transmitters of the tank groups checked off the other groups.

Switches III-7 are installed near the indicators, on the instrument board of the right-seat pilot. The switch dimensions are as follows: diameter - 60 mm; length - 171 mm. Weight - 600 gr.

Arrangement of fuel gauge set units on aircraft

Arrangement of the fuel gauge set units on the aircraft is shown in Fig. 1. The transmitters are installed in the following tanks: No. 2, No. 3, No. 4, No. 5 (main and additional), No. 7 (main), No. 10 (additional), No. 12 (main), No. 16 (additional), No. 6 (main and additional).

The first and second tank groups of the left-hand engine and the first tank group of the right-hand engine accommodate one transmitter each. Each of the remaining tank groups incorporates two transmitters (main and additional), connects in parallel, as does the complex configuration of these tanks does not allow one transmitter to account for the entire amount of fuel measured.

Amplifiers 7T-6S are arranged on the right-hand rack of the navigator-radar operator. The indicators and switches are mounted on the instrument board of the right-seat pilot.

Presented in Fig. 27 is the cabling and wiring diagram of the fuel gauge set, showing arrangement of individual units on the aircraft.

Main technical characteristics of fuel gauge set CSTC-60A

The fuel gauge set should be capable of normal functioning at altitudes of 0 to 15,000 m. over the sea level, within the ambient air temperature range of -60°C to +30°C. Calibration error of the fuel gauge set at normal operating conditions should not exceed the values, presented in Table 5.

Table 5

Permissible calibration error of fuel gauge set at normal operating conditions

Scale point	Calibration error in per cent of indicator scale rated value
Zero .....	± 2.0
Other points .....	± 4.0

Notes 1. The extreme point on the given scale is taken to be the rated value of the indicator scale.  
2. The normal conditions involve:

- (a) temperature of  $20 \pm 5^\circ\text{C}$ ;
  - (b) voltage of 115 V;
  - (c) frequency of 400 c.p.s.;
  - (d) relative humidity from 30 to 80 per cent;
  - (e) aircraft positioned in level flight line.
- The fuel gauge set error at ambient air temperatures within the range of -60°C to +30°C should not exceed the values referred to in Table 6.

50X1-HUM

Table 6

Permissible error of fuel gauge set at ambient air temperatures within -60°C to +30°C

Scale point	Calibration error in per cent of indicator scale rated value	
	at -60 ± 5°C	at +30 ± 5°C
Zero .....	± 6.0	± 3.5
Other points .....	± 8.0	± 3.5

The fuel gauge set units should withstand vibration stresses combined with acceleration:

- (a) the indicator and switch - 1.5 g within the frequency range of 40 to 80 c.p.s.;
- (b) the amplifier - 2.5 g within the frequency range of 40 to 80 c.p.s.;
- (c) the transmitters - 4 g within the frequency range of 40 to 80 c.p.s.

All units of the fuel gauge set should withstand 10,000 impacts at 4 g, within the frequency range of 60 to 100 impacts per min.


The fuel gauge set should function normally when supplied from the aircraft A.C. power source rated at 115 V ± 10 per cent, 400 c.p.s.  $\pm 5\%$ , and D.C. power source rated at 27 V ± 10 per cent. Additional error of the fuel gauge set due to changes in voltage of A.C. amounting to ± 10 per cent should not exceed ± 10 per cent of the scale rated value.

Additional error due to changes in frequency amounting to  $\pm 5\%$  should not exceed ± 1 per cent of the scale rated value.

The transmitters of the identical tanks, the indicator, amplifier and the switch are interchangeable. After one of the fuel gauge units has been replaced, readjustment of the set is allowed.

Checking fuel gauge set operation on aircraft

The key diagram of fuel gauge set CSTC-60A is illustrated in Fig. 10. Measuring equipment amplifiers 7 are supplied with D.C. from the dual-feed busbar via circuit breakers AJC-2 (mounted on the respective panel of the right-seat pilot); A.C. of 115 V, 400 c.p.s. is fed to the amplifiers across 1A safety glass tube fuses (installed on the upper panel of the navigator). The amplifiers



are put in operation by switches 200-250, which are mounted on the instrument board of the right-seat pilot.

The checking procedure on the aircraft is performed as follows: circuit breaker 430-2 is turned on. Switch 111-7 is set in the TOTAL position, and the system is checked for proper operation after the valves have been heated up (in 1 to 3 min.). To check the circuit controlling total amount of fuel, press button 8 on the indicator housing. This should cause the indicator pointer to set against the zero point of the scale, permissible error being not in excess of  $\pm 400$  lit. Set the switch handle successively in each of the five group positions, taking care to check the circuit by pressing the indicator button whenever changing the position of the switch handle. The pointer should read zero, with permissible error not exceeding  $\pm 160$  lit.

To check the 16,000 lit. setting on the total amount scale, proceed as follows: set the switch handle in the TOTAL position. When button 26 (TOTAL AMOUNT CHECK-UP) on the amplifier front panel and the indicator button are pressed, the pointer should read 16,000 lit., the permissible error not exceeding  $\pm 960$  lit.

The extreme reading of the fuel gauge indicator on the individual group scale is checked in the same manner. In this case button 25 (GROUP CHECK-UP) located on the amplifier front panel should be pressed. Whenever the position of the switch handle is changed, the indicator pointer should read 6000 lit., with permissible error not exceeding  $\pm 320$  lit. (readings being taken off the indicator inner scale). If the zero and 16,000 lit. settings are found to be out of adjustment, carry out readjustment required. For this, remove cover ZERO SETTINGS and turn the axles of the two right-hand rheostats, marked with TOTAL, to make the pointer set against the zero of the indicator scale, with the indicator button kept pressed. Then press button TOTAL AMOUNT CHECK-UP and manipulate the right-hand rheostat to bring the indicator pointer to the 16,000 lit. mark. Proceed with the above adjustment until the indicator pointer sets against the scale zero, with the amplifier button released and the indicator button pressed (with permissible error not exceeding  $\pm 600$  lit.); with the amplifier and indicator buttons pressed, the pointer should read 16,000 lit. (with permissible error not exceeding  $\pm 960$  lit.). Adjustment of the fuel gauge against the reference settings of the indicator scale is shown in Fig. 29.

Adjustment of the 0 and 6000 lit. reference settings on the individual group scale is carried out with respect to one tank group, whereas all five groups are involved in checking the above reference settings. Should it be found that one or several tank groups are out of adjustment, manipulate the two left-hand rheostats, marked with GROUP until the indicator pointer (for each of the groups) sets against the scale zero with the amplifier button released and the indicator button pressed (permissible error not exceeding  $\pm 160$  lit.); with the amplifier and indicator buttons pressed, the pointer should set against the 6000 lit. reading of the scale (with permissible error not exceeding  $\pm 320$  lit.). Having adjusted the amplifier, close and seal cover ZERO SETTINGS.

2. PORTABLE FUEL GAUGE SYSTEM JUTE-1

The portable JUTE-1 unit is designed for testing capacitance fuel gauges in field conditions.

The unit provides for successive testing of the following principal elements of the fuel gauges:

- (a) transmitters for capacitance (both initial and maximum, when the transmitter is submerged into fuel up to the flange);
- (b) indicators for calibration errors;
- (c) amplifiers for proper operation;
- (d) marginal amount of fuel and other signalling units for proper operation.

Tester description

Tester JUTE-1 is accommodated in two cases: JUTE-1A and JUTE-1B. Case JUTE-1A encloses the entire measuring equipment of the tester. Fig. 30 illustrates the tester with the cover hinged off. The right wall of the tester case (Fig. 31) mounts plug connectors for connection of the amplifier, the indicator and the transmitter under check; three terminals for connection of the power supply source; and safety fuses rated for 1A.

The left wall of the case (Fig. 32) mounts four valves. Case JUTE-1B houses connecting bunched wires. Weight of case JUTE-1A does not exceed 14 kg; case JUTE-1B weighs 6 kg. The overall dimensions of the cases are 307x240x250 mm and 352x233x124 mm, respectively.

Description of checking circuit

Circuit for checking transmitter capacitance

Transmitter capacitance is checked with the aid of a self-balancing A.C. bridge (Fig. 33) one arm of which is represented by variable capacitor box  $C_1$ ; transmitter checked C (BEATA) being connected in parallel with the latter. Voltage between points C and A of the bridge amounts to 50 V. The self-balancing A.C. bridge consists of two adjustable resistors  $R_1$  and  $R_2$ , rheostat R and two capacitances  $C_0$  and  $C_1 + C_2$ , where  $C_0$  is the fixed capacitance and  $C_1 + C_2$  is the variable capacitance. To ensure that the circuit sensitivity and the bridge characteristics remain practically constant when checking various transmitters, the magnitude of variable capacitance  $C_1 + C_2$  should vary within 8000pF to 8500pF.

For this, when measuring the capacitance of transmitters  $C_2$  varying from 8500pF to 0, the magnitude of capacitances  $C_1$  on the capacitor box should be adjusted to 0 - 800pF respectively, so that total capacitance  $C_1 + C_2$  is within 8000 - 8500pF.

With the circuit arranged in this manner, the tester functions as follows: points C and A of the bridge are supplied with voltage from the second winding of transformer.

The self-balancing bridge is so adjusted with the aid of resistors  $R_1$  and  $R_2$ , that when capacitance  $C_1$  is equal to 8000pF, the bridge is balanced and the voltage between points A and B amounts to zero. In this case the slide of rheostat R is in one of its extreme positions, whereas the pointer of capacitance meter EE-55 will read zero.

To ensure maximum accuracy of reading, the scale of capacitance meter EE-55 has a narrow measuring range (from 0 to 5000pF). When the transmitter with capacitance amounting to  $C_2$  is connected into the circuit, the capacitance of the front arm increases, thereby affecting the bridge balance; as a result, some potential difference is applied to the amplifier input.



50X1-HUM

delivered to the control winding of induction motor HE-0.5 whose rotor is connected to the pointer of capacitance meter HE-53 and to the slide of rheostat R through the medium of the reduction gear.

The electric motor rotor displaces the slide of rheostat R towards the bridge balanced state. If connected capacitance  $C_x$  amounts to 500pF, that is  $C_1 + C_x = 8500pF$ , the rheostat slide R will be found in the other extreme position, whereas the pointer of capacitance meter HE-53 will set against the maximum mark of the scale. In case transmitter capacitance  $C_x$  is less than 500pF but exceeds 0, the bridge will become balanced at a capacitance amounting to  $C_1 + C_x$ , which is more than 8000pF, but less than 8500pF. The slide of rheostat R will occupy an intermediate position, while the pointer of capacitance meter HE-53 will set between the zero and the maximum marks of the scale, thereby reading value  $C_x$ . Should transmitter capacitance  $C_x$  exceed 500pF, the magnitude of capacitance  $C_1$  must be reduced until capacitance  $C_1 + C_x$  amounts to within 8000 - 8500pF. In this case the magnitude of capacitance  $C_x$  equals the difference between 8000pF and  $C_1$  (8000 -  $C_1$ ), plus the value indicated by capacitance meter HE-53. To avoid making any calculations when employing the tester, the difference between 8000pF and the actual values of capacitance  $C_1$  is marked on the scale of variable capacitance  $C_x$ . Therefore, transmitter measured capacitance  $C_x$  is found as a sum total of the capacitance indicated on the capacitor box scale and read off the scale of capacitance meter HE-53.

Circuit for checking calibration error of indicator.

The circuit for checking the indicator, illustrated in Fig. 34, represents a regular capacitance fuel gauge circuit employing one amplification channel. The circuit is essentially a self-balancing bridge, comprising two resistor arms  $R_1$  and  $R_2$  and R (R being the resistor of the indicator checked), and two capacitor arms. One capacitor arm is formed by constant capacitance  $C_0$ , the other - by variable capacitor box  $C_1$ . This box simulates the function of the transmitter incorporated in the self-balancing bridge circuit. The indicator under check is connected into the circuit in the same manner as it is connected into the fuel gauge circuit. Unbalancing of the self-balancing bridge is caused by variations in the box capacitance. The unbalancing voltage, increased by the three-stage amplifier, is delivered to the control windings of the motor accommodated in the indicator under check.

The electric motor rotor will cause the rheostat slide to move to a position, in which the bridge will become balanced. The self-balancing bridge should be so adjusted with the aid of resistors  $R_1$  and  $R_2$  as to cause the indicator rheostat slide to be moved to one of its extreme positions, with capacitance  $C_1$  amounting to 3500pF; the indicator pointer in this case should set against the zero mark of the scale.

With capacitance  $C_1$  increasing to 3500-500(A-1)pF, where A represents the numbered divisions of the indicator under check, the indicator rheostat slide will in the other extreme position, whereas the indicator pointer will set against the maximum division of the scale.

With the capacitance amounting to some intermediate value, the slide of rheostat R will be in an intermediate position, while the indicator pointer will read some intermediate value on the scale. Thus, all of the indicator numbered divisions are checked by varying the capacitor box capacitance between 3500pF and 3500 + 500 \* (A-1) pF. To check the indicator button for proper operation,

provision is made for relay PCM-2, which disconnects capacitance C (when the button is pressed) and connects capacitance  $C_2$  in its place. With the button pressed, the pointer of the indicator checked should set against the zero mark of the scale.

Checking amplifiers for proper functioning

The amplifier is checked with the aid of capacitor box  $C_1$  and additional capacitance  $C_2$ , which acts as an ordinary capacitance transmitter. Apart from the dummy capacitance, the amplifier checked is connected to an indicator through the medium of the tester. The check consists in the following: after the indicator is connected, and voltage is supplied to the amplifier, the buttons are pressed on the indicator and on the front panel of the amplifier (simultaneously); the indicator pointer should set against the reference mark of the scale.

Circuit for checking signalling units

The circuit for checking the signalling units of the transmitters (Fig. 35) represents a regular circuit of the fuel gauge automatic equipment employing no valves. It is essentially an A.C. bridge, the two arms of which are composed of resistors  $R_1$  and  $R_2$ , the other two arms being comprised of induction resistors  $R_1$  and  $R_2$ ; arm  $R_2$  is represented by the induction coil of the signalling unit checked. The automatic equipment bridge is adjusted with the aid of resistors  $R_1$  and  $R_2$  so that when the bottom plate of the float comes out of the signalling unit coil, the bridge is in the state of balance. As soon as the float bottom plate is drawn into the signalling unit coil, the resistance of arm  $R_2$  increases, thereby disturbing the bridge balance. The unbalancing voltage is fed to the excitation winding of the highly sensitive relay via the selenium rectifier. The relay operates thereby cutting in the pilot lamp. As one transmitter may accommodate up to three signalling units, the checking circuit incorporates switch  $H_2$  allowing successive connection of each signalling unit to the automatic equipment bridge, thereby providing for checking all the signalling units installed in the transmitter.

Tester operation

Prior to carrying out a check, set the switches in the OFF position, and connect the power supply as specified.

Checking transmitter capacitance

- Check transmitter capacitance, proceeding as follows:
1. By using bunched wire marked THIRD (ТРЕТИЙ), connect the transmitter to the plug connector marked TRANSMITTER (ПЯТЕРКА).
  2. Set switches  $H_5$ ,  $H_7$ ,  $H_{10}$ , and the shutter of switch  $H_3$  in the TRANSMITTER (ПЯТЕРКА) position.
  3. Set switch  $H_4$  at a capacitance value approximating the capacitance of the transmitter checked.
  4. Set switch  $H_{12}$  in the ON (ВКЛЮЧЕНО) position, wait for 2 to 3 min., then measure the capacitance of the transmitter. For this, turn the handle of



50X1-HUM

switch  $H_3$  until the pointer of capacitance meter indicator EB-53 sets against some division of the scale. The measured capacitance amounts to the value indicated on the scale of switch  $H_3$ , plus the value read by the indicator of capacitance meter EB-53.

Note: When checking a dual transmitter, first connect it to one seven-pin plug connector, then to the other.

Checking calibration error of indicators.

- The check should be carried out as follows:
1. Mount the transmitter checked on the retractable holder of the tester, and use bunched wires marked FIFTH (ПЯТЫЙ) to connect the transmitter to plug connector INDICATOR (УКАЗАТЕЛЬ).
  2. Set switches  $H_5$ ,  $H_7$ ,  $H_{10}$  and the shutter of switch  $H_3$  in the INDICATOR (УКАЗАТЕЛЬ) position.
  3. Set setnob  $H_1$ : (a) in the 1 position when checking single-pointer indicators and lower instruments of two-pointer indicators; (b) in the 2 position when checking the upper instruments of two-pointer indicators;
  4. Set switch  $H_{12}$  in the ON (ВКЛЮЧЕНО) position, wait for 2 to 3 min., and then proceed to adjust and check the indicator as follows:
    - (a) manipulate rheostat ADJUSTMENT OF INDICATOR SCALIS (РЕГУЛИРОВКА ШКАЛЫ УКАЗАТЕЛЯ) to make the indicator pointer set against the zero mark of the scale when switch  $H_3$  is set in the 1 position; with the switch set in a position corresponding to the amount of numbered divisions, including the zero division, the indicator pointer should set against the extreme numbered division of the scale;
    - (b) after adjustment of the zero and maximum settings of the scale, set switch  $H_3$  in intermediate positions (successively) and read the respective indications off the indicator scale.
- Note: When checking two-scale indicators, read the indications off the outer scale.

Checking amplifiers.

- Check the amplifiers, proceeding as follows:
1. Connect the amplifier to plug connector TO AMPLIFIER (К УСИЛИТЕЛЮ) by means of bunched wires marked SECOND (ВТОРОЙ), FOURTH (ЧЕТВЕРТЫЙ), or SIXTH (ШЕСТОЙ), SEVENTH (СЕДЬМОЙ).
  2. Mount the indicator having identical calibration with the amplifier, on the retractable holder, and connect it to plug connector INDICATOR (УКАЗАТЕЛЬ) by using bunched wires marked FIFTH (ПЯТЫЙ).
  3. Set the switches:  $H_1$  - in the 4 position;  $H_{10}$  - in the AMPLIFIER (УСИЛИТЕЛЬ) position;  $H_4$ ,  $H_6$ , and  $H_{11}$  - in the following positions:  $H_4$  - in the 4 position when relating both to total amount and individual group;  $H_6$  - in the 2 position, when relating to total amount, and in the 1 position when relating to individual group;  $H_{11}$  - in the TOTAL AMOUNT (СЪЕМА) position, when relating to total amount, and in the OFF (ВЫКЛ.) position, when relating to individual group.

4. Set switch  $H_{12}$  in the ON (ВКЛЮЧЕНО) position, wait for 2-3 min., then proceed to checking the amplifier. For this, turn the handle of switch  $H_3$  until the indicator pointer sets against some division of the scale.
5. Press the indicator button, which should cause the indicator pointer to travel towards the zero mark.
6. While keeping the indicator button pressed, press the amplifier button. In this case the indicator pointer should deflect towards the maximum reading of the scale.

Checking signalling units.

1. Connect the transmitter to plug connector TRANSMITTER (ПЕРЕДАЧ) by means of bunched wires THIRD (ТРЕТИЙ).
  2. Set the switches:  $H_3$  - in the SIGNALLING UNIT (СИГНАЛИЗАТОР) position;  $H_{10}$  - in the TRANSMITTER (ПЕРЕДАЧ) position;  $H_5$  - in the 1 position, when checking single-wire signalling units, and in the 2 position, when checking two-wire signalling units;  $H_2$  - in the B, T, or M positions depending on the wiring diagram.
  3. Set switch  $H_{12}$  in the ON (ВКЛЮЧЕНО) position, and perform the check. For this, arrange the transmitter at an angle of  $180^\circ$  to its normal operating position.
- With the transmitter in the normal operating position, pilot lamp TRANSMITTER SIGNALLING UNIT CHECK-UP (КОМПЛЕКС СИГНАЛИЗАТОРА НАЧЕКО) should keep burning, whereas with the transmitter turned through  $180^\circ$ , the lamp should go out. When checking the filling signalling units, the lamp should go out at the normal operating position of the transmitter, and should light up with the transmitter turned over.

Tester main technical data.

1. Tester error at normal conditions should not exceed:
  - (a)  $\pm 1.5$  per cent of the rated value of each measuring limit within the range of from 500 to 5500pF, when checking transmitter capacitances;
  - (b)  $\pm 0.5$  per cent of the rated value of the capacitor box capacitance (amounting to 8000pF), when checking the indicator.
2. Tester error at the ambient air temperature of from  $-40^\circ\text{C}$  to  $+50^\circ\text{C}$  should not exceed  $\pm 2.5$  per cent of the rated value of the measuring limit, when checking transmitter capacitance; when checking the indicators, the error should not be in excess of  $\pm 0.5$  per cent of the rated value of the capacitor box.
3. Additional error due to variation in the voltage of A.C. within  $\pm 10$  per cent of the rated value, and in the frequency (within  $\pm 5$  per cent) should not exceed  $\pm 1$  per cent.

PROCEDURE FOR DETERMINING READING ERROR OF FUEL GAUGES AND FUEL FLOW METER OF AIRCRAFT

The reading error of the fuel gauges and fuel flow meters is determined by means of check drainage of the fuel. The procedure is as follows:

NO FOREIGN DISSEM



50X1-HUM

1. Prior to determining the reading error, fuel gauge set CSTC-60R and fuel flow meter set FFC-16 are checked on a stand against the data indicated in the Certificate and Description.

2. Before filling the tanks with fuel, the pointer is checked both for proper zero setting and for reference mark settings on the individual group and total amount scales.

3. The aircraft is positioned in the line of flight on rigid supports (hydraulic jacks), with the fuselage axis inclined by + 4° relative to the horizon (elevation of the point at frame No.12 over the point at frame No.33 amounts to 1280 ± 10 mm).

4. The aircraft fuel system is filled to capacity (as indicated by the refuelling floats).

5. Drainage is accomplished at a rate of about 6000 lit. per hour, in 500 lit. portions, fuel being collected in calibrated containers, with the booster pumps controlled manually.

Prior to starting drainage, perform the following operations:

- (a) connect devices, incorporating cut-off cocks, into the engine fuel lines aft of the transmitters of fuel flow meters FFC-16, for measuring the amount of fuel drained;
- (b) turn off manual control circuit breaker AJC-5 and stand-by pump switch 2B-45, mounted on the pilot upper electrical panel; set switch AUTOMATIC-MANUAL ( AUTOMAT-PYRCHOE ) in the MANUAL ( PYRCHOE ) position; switch off stand-by pump circuit breaker AJC-2 mounted on the respective panel of the right-seat pilot;
- (c) switch on the power supply sources;
- (d) switch on inverter DU-4500;
- (e) switch on measuring equipment amplifiers FE-68 and automatic equipment amplifiers JAT-52-5;
- (f) check the amplifiers and indicators for proper operation by pressing the respective buttons;
- (g) set the pointers of the fuel flow meter indicators in a position corresponding to the actual amount of fuel in the tanks.

The drainage is carried out in the order of fuel consumption on the aircraft, by turning on circuit breakers AJC-5 of the respective tank group, or by turning on stand-by pump switch 2B-45 and successive switching of stand-by pump circuit breakers AJC-2 (when draining fuel from tank groups IV and V). The fuel is drained in 500 lit. portions, the readings being taken off the fuel gauge indicator scales (indicating both total amount of fuel and amount of fuel in individual tank groups) as well as off the fuel flow meter indicator scales. While draining the fuel, note (by the readings of the fuel gauges, fuel flow meters and the measuring instruments of the refueller) the amount of fuel at which the pilot lamps (blue ones) light up on the panel.

Having drained off the tank group, switch off the booster pumps. Enter the data obtained in a record illustrated below, to allow carrying out subsequent calculations and comparison of the actual fuel amount with the readings of the fuel gauges for estimating the error.

The permissible error values are given in Table 9.

RECORD OF CHECK FUEL DRAINAGE

Aircraft No. \_\_\_\_\_ engine \_\_\_\_\_ (left, right)

Fuel gauge set CSTC-60R No. \_\_\_\_\_

Nos	Portions drained	Actual amount left		Fuel gauge readings		Fuel flow meter readings	Reading error		
		tank group	total	tank group	total		tank group	total	Fuel flow meter readings

Signed by \_\_\_\_\_

4. OPERATION OF FUEL GAUGES ON AIRCRAFT

1. As it has been already stated in Chapter I, the FI-5H engine can use either fuels T-1 and TC-1 or blends thereof.

Specific inductive capacitances  $\epsilon$  for fuels T-1 and TC-1 somewhat differ (T-1 has  $\epsilon = 2.04$ ; TC-1 has  $\epsilon = 1.92$ ).

The indicator scale of fuel gauge CSTC-60R is calibrated for fuel T-1. Therefore, when the aircraft tanks are filled with fuel TC-1, the indicator will read an amount 6 per cent less than the actual amount of fuel delivered into the tanks, as transmitter capacitance (with the fuel level unchanged) will be less, when fuel TC-1 is put into the system.

Table 7 contains correction data for fuel gauge CSTC-60R to be used when employing fuel TC-1. By reference to the table it will be seen that the actual amount of fuel TC-1 held by the tanks somewhat exceeds (approximately by 6 per cent) the amount read by the fuel gauge indicator.



50X1-HUM

Table 7

Correction data for fuel gauge CSTC-60A  
 to be used when supplying fuel TC-1

Individual group scale		Total amount scale	
Amount of fuel TC-1 in group tanks	Readings of fuel gauge CSTC-60A	Amount of fuel TC-1 in tank groups	Readings of fuel gauge CSTC-60A
6000	7320	22000	20680
7500	7070	21000	19740
7000	6980	20000	18800
6500	6110	19000	17860
6000	5640	18000	16920
5500	5170	17000	15980
5000	4700	16000	15040
4500	4230	15000	14100
4000	3760	14000	13160
3500	3290	13000	12220
3000	2820	12000	11280
2500	2350	11000	10340
2000	1880	10000	9400
1500	1410	9000	8460
1000	940	8000	7520
500	470	7000	6580
		6000	5640
		5000	4700
		4000	3760
		3000	2820
		2000	1880
		1000	940

This discrepancy has been eliminated in fuel gauge sets of the CSTC-60M type, in which zero and maximum settings are adjusted independently. With the aircraft tanks empty, the personnel employing zero adjustment rheostats is capable of setting the pointer of the CSTC-60M fuel gauge indicator against the zero mark of the scale. Then, after the tanks are filled with the specified amount of fuel, maximum adjustment rheostats are used to set the indicator pointer against the respective division of the scale. The maximum adjustment rheostats do not affect the zero settings, which allows the fuel gauge to give correct readings after such an adjustment has been performed.

It is not possible to adjust fuel gauge set CSTC-60M in the above manner, as the zero and maximum marks of the scale are interconnected with respect to adjustment. Therefore, zero adjustment will be disturbed, when the indicator pointer is set against the division indicating the amount of fuel contained in the tanks.

2. The fuel gauge wiring on the aircraft has a capacitance which affects the readings of the indicator but slightly.

Due to the wiring capacitance, the readings of the fuel gauge seem to be increased by 100 to 150 lit., which may be neglected. Therefore, fuel gauge set CSTC-60A may be checked on a stand employing wiring of any length. It will be noted, however, that fuel gauge sensitivity is inversely proportional to the length of the wiring (slight oscillations of the indicator pointer are also possible).

7. AUTOMATIC CONTROL OF FUEL CONSUMPTION

To maintain the aircraft balance within the permissible limits, provision is made for automatic control of fuel consumption. The fuel is consumed in a definite sequence, starting from tank group 1.

The automatic equipment provides for:

- (a) control of the fuel pump starting sequence and duty depending on the amount of fuel contained in certain tank groups;
- (b) switching on pilot lamps indicating fuel remaining for 30 or 15 min. of flight.

The automatic equipment controlling fuel consumption comprises the following main units:

- amplifiers FAT-52-5 incorporated in fuel gauge set - 2 pieces;
  - float-type signalling units, accommodated inside fuel gauge transmitters - 16 pieces;
  - fuel pumps KM-7 (unit 461) - 12 pieces;
  - fuel pressure signalling unit CR-377 - 12 pieces;
  - fuel pump EM-45T - 2 pieces;
  - contactor K-50R - 14 pieces;
  - relay RM-10 - 10 pieces;
  - relay RM-6 - 1 piece;
  - resistor RC-10-5 - 10 pieces.
- The fuel consumption automatic equipment controls and signalling devices are mounted on the fuel supply panel, arranged on the aircraft cockpit ceiling between the pilot seats (Fig.36).

Operating principle. Description of automatic equipment operation

The fuel consumption automatic control equipment set includes two amplifiers connected to each other in parallel. Following below is the description of the operating principle of the fuel consumption automatic control equipment employing one amplifier, the operating principle of the automatic control equipment using two amplifiers being the same.

The sensitive elements of the automatic equipment are represented by the float-type induction signalling units, located at certain levels inside the transmitters. Arrangement of the signalling units inside the transmitters is shown in Fig.28 (ref. Nos 31 and 32).

The signalling unit consists of the coil and the float. The coil is hermetically sealed and has an open magnetic circuit. The float is provided with an iron bottom plate, made in the form of a bushing, which serves as a closing armature of the coil. When the float comes down, the magnetic circuit closes, thereby increasing the induction resistance. The coil sets as an arc of the unbalanced bridge (Fig.37).





The unbalanced A.C. bridge comprises two semi-windings of transformer I, one arm of resistor B, and signalling unit induction coil I. The automatic equipment bridge is supplied with power from the secondary winding of transformer I, whose primary winding is supplied with voltage of 115 V, 400 c.p.s., from the mains. From the bridge diagonal voltage is fed to the grid of valve 6HTC. Placed into the anode circuit of the above valve is relay FB3.

Changing fuel level in the tanks causes the bottom plate of the float to draw into the coil field thereby changing coil field resistance. The float lowering; this causes voltage on the grid of valve 6HTC to increase, which, in its turn, results in increasing of the anode D.C. component. Relay FB3 picks up with current amounting to 3.5 mA, thereby switching on the contactor of the respective booster pump.

Each of the fuel consumption automatic control equipment amplifiers consists of eight bridges. By reference to Fig.28, it will be seen that the outleads of the automatic control equipment amplifiers for the right and left engines are connected in parallel. This arrangement allows one amplifier to control the sequence of fuel consumption, if the other amplifier fails. The automatic equipment of the fuel gauge is energized either with D.C. (28 V) delivered via circuit breaker AX-9 (mounted on the circuit breaker panel of the right-seat pilot), or with A.C. (115 V) supplied via IA safety fuse CH-1 (mounted on the navigator upper electric equipment panel).

The automatic equipment controls are arranged on the fuel supply panel. The automatic equipment amplifiers are turned on by means of switches 200-250 (See Fig.28, Ref.No.12).

When describing the operation of the automatic equipment, it will be understood that all of the tank groups are filled with fuel. Switch "Automatic-Manual" ( "АВТОМАТ-РУЧНОЕ" ) is set in the "Automatic" ( "АВТОМАТ" ) position. As has been already stated, the fuel gauge transmitters of both engines accommodate 8 signalling units.

As to their functions, the signalling units may be subdivided into: a lower signalling unit, an upper signalling unit, and a fuel reserve signalling unit. The lower signalling unit operates when the amount of fuel left is equal to 250±150 lit., the upper one - when fuel level drops to a value given in Table 8, and the fuel reserve signalling unit operates when the amount of fuel left is sufficient for 30 or 15 min. of flight respectively.

The signalling units are arranged as follows: the lower signalling unit - in the transmitters of tanks Nos 2 and 3 (See Fig.28, Ref. No.32); the lower and upper signalling units - in the transmitters of tank No.4; the upper signalling unit - in the transmitters of tank No.3 (main); the lower signalling unit - in the transmitters of tank No.3 (additional); the upper signalling unit - in the transmitters of tanks No.7; the lower signalling unit - in the transmitters of tanks No.10; the upper signalling unit - in the transmitters of tanks No.12; the 30 min. fuel reserve signalling unit - in the transmitters of tanks No.10; the 15 min. fuel reserve signalling unit - in the transmitters of tank No.6 (main).

The fuel consumption automatic control equipment includes 12 pumps, which are capable of operating at the following three duties:  
First duty - idle (stand-by); outlet pressure at zero consumption not exceeding 0.8 kg/cm<sup>2</sup>.

Second duty - main (rated); outlet pressure at zero consumption amounting to 1.2 kg/cm<sup>2</sup>.  
Third duty - heavy duty; outlet pressure at zero consumption amounting to 1.4 - 1.6 kg/cm<sup>2</sup>.  
The pumps of the I, II and III tank groups operate at the rated duty; when the fuel level drops to 250±150 lit., the pumps pass over to the heavy duty, to draw the entire amount of fuel from the tank group in question.

Table 8

Amounts of fuel delivered into tanks and signalling unit operation ranges.

Tank group and No. of tank	Amount of fuel delivered	Signal for starting pump with fuel left amounting to, lit.	Signal for starting pump with fuel left amounting to, lit.	30 min. fuel reserve signal, lit.	15 min. fuel reserve signal, lit.	Refueling in air signal
I, left tank No.2	6250	250±150				
I, right tank No.3	6350	250±150				
II, left tank No.4	3300	250±150	2450±250			
II, right tank No.5	3150	250±150	2250±250			
III, left and right tanks Nos 7-11	3850	250±150	3000±250			
IV, left and right tanks Nos 12 - 16	3050	-	2300±250	600-200-100		
V, left and right tanks No.6	2700	-	-	-	1600±100	

The pumps of tank groups IV and V operate at idle duty throughout the flight. When fuel level in tank group III drops to 150±150 lit., the pumps of tank group IV pass over to the main duty, to allow fuel from tank group IV to be drawn earlier than from tank group V. Fuel from tank group V is drawn with the respective pumps operating at idle duty.

When the amplifiers are switched on (See Fig.28, Ref. No.13), relay 70-6 (See Fig.28, Ref. No.27) operates thereby starting the pumps of tank group I, which will run at the rated duty (the positive voltage is fed via terminal 1 for energizing contactors E-301). Besides, the negative voltage is delivered to the blue pilot lamp of tank group I (See Fig.28, Ref. No.14) via terminal 8.

<sup>1</sup> Ref. Nos placed in brackets refer to Fig.28.

As fuel is drawn from the tanks and the float reaches the coil of the lower signalling unit accommodated in transmitters Nos 2 and 3, the signalling unit sends a signal via terminal 1 to the grid of valve 6FTC. This causes the anode D.C. component to increase thereby energizing first relay PB3(27), which supplies the positive voltage via terminals 2 to contactors K-30A (36). As a result, the pumps of tank group II start running at the rated duty, whereas the pumps of group I are switched over from the rated duty to the heavy duty by connecting the resistor (39) rated for 3 ohms into the pump winding (34). The resistor is connected to the winding by the action of relay PH-2 (38).

Simultaneously, the blue pilot lamp of group II lights up (voltage being delivered via terminals 7).

Further fuel consumption is accomplished in the following sequence.

The upper signalling units of tank groups II (transmitters of tanks No.3, main, and No.4) operate, thereby disturbing the bridge balance; this will cause the anode current to increase. Second relay PB3 will pick up and open the positive wire (via terminals 1) supplying voltage to contactors K-30A of tank group I pumps.

The lower signalling units of tank groups II (transmitters of tanks No.4 and No.11) will energize third relay PB3. The relay will feed the positive pole via terminals 3 to contactors K-30A of tank group III pumps and to relay PH-2. The pumps of the third tank groups will run at rated duty. Relay PH-2 will connect a resistor rated for 3 ohms in series with the excitation windings of the second tank group pumps. Consequently, the pumps of tank groups II will run at heavy duty. Simultaneously, the circuit of the third tank group pilot lamp gets closed.

The upper signalling units of tank groups III (transmitters of tanks No.7) will energize fourth relay PB3. The relay will open the circuit running from terminal 2, thereby cutting off the pumps of the tank groups II. The lower signalling units of the third tank groups (transmitters of tanks No.10) will energize fifth relay PB3. The circuit closes at terminals 4 thereby energizing contactors K-30A and relay PH-2. The pumps of tank groups IV will change over from the stand-by to the main duty. The pumps of tank groups III will change over from the main to the heavy duty. Simultaneously, the pilot lamp of tank groups IV will be energized via terminals 9. The upper signalling units of tank groups IV (transmitters of tanks No.12) will operate thereby causing sixth relay PB3 to pick up. The relay will break the circuit running from terminal 3, thereby cutting off the pumps of tank groups III.

When energized, the signalling units (transmitters of tanks No.16) will cause the seventh relay to pick up thereby making its contacts close the circuit of the red pilot lamps indicating 30 min. fuel reserve (See Table 8).

The lower signalling units of tank groups V (transmitters of tanks No.16) will energize eighth relay PB3 whose contacts will close (via terminal 11) the circuit of the red pilot lamp indicating 15 min. fuel reserve.

Provision is made in the aircraft design for installing tanks No.17, No.18, and No.19 in the wings. In this case pumps III-4ST are mounted on tanks No.19. These pumps are started by the upper signalling unit of the third tank group. When fourth relay PB3 picks up the positive pole is connected to terminal 3, via the closed contacts of the relay (29); this causes pump III-4ST (33) to start, as a result of which fuel from tanks No.17, No.18, and No.19 will be transferred to tank group III (tank No.7). When sixth relay PB3 picks up, the circuit of the relay of pump III-4ST will be closed; as a result, the relay will pick up and open the circuit running from the terminal, thereby cutting off pump III-4ST.

The following features of the automatic system should be stressed:

(a) if one of the lower signalling units (both of the left and right engines) has failed to operate, the pumps of the respective tank group will continue to run, even though both of the upper signalling units of the next tank group have operated properly;

(b) if one of the upper signalling units has failed to operate, the pumps of the previous group will continue to run.

Suppose the lower signalling unit accommodated in the transmitter of tank No.2 has operated properly, whereas the lower signalling unit of tank No.3 has failed to operate so far. As a result, the signal from the transmitter of the second tank will be sent to the left amplifier, which, in its turn, will send a signal causing the starting of the next tank group II. The pumps of the first tank group will change over to the heavy duty. Now suppose the upper signalling unit incorporated in tank group II of the left engine (transmitter No.4) has operated. This will cause the left amplifier to send a signal for cutting off the pumps of the first tank group, however the pumps of the first tank group will run due to the signal sent by the right amplifier, the lower signalling unit of transmitter No.3 being inoperative. Therefore, the pumps of the first tank group will be stopped only after operation of both lower signalling units (accommodated in transmitters No.2 and No.3).

The following events will take place, if the lower signalling units accommodated in transmitters No.2 and No.3 operate properly, the upper signalling unit has operated in transmitter No.4 only, whereas that of transmitter No.3 is inoperative. In that case the pumps of tank groups I will continue to run until the upper signalling unit incorporated in transmitter No.3 operates also. This is necessary to provide for drawing fuel from the tank group, with the automatic equipment functioning. The pump operation is controlled by 12 pressure signalling units CM-3TY (40) installed on the aircraft. The fuel supply panel mounts 12 green lamps respectively. When the pump outlet pressure comes to exceed 0.3 kg/sq.cm., the respective pressure signalling unit CM-3TY operates thereby causing the green lamp to light up. The operating principle of the pressure signalling unit is based on the functional relation between fuel pressure and the deformation of the sensitive element represented by the membrane. Fuel pressure is taken up by the elastic corrugated membrane.

To reduce radio interference on the aircraft, a capacitor of the EE M-31 type (37) is connected in parallel to the circuit of each contactor K-50A.

Fuel jettisoning from tank groups II is accomplished with the aid of the booster pumps via the line used for filling the fuselage tanks in flight (See Chapter I).

Opening of the fuel jettison valve arranged on the left-seat pilot control panel will cause operation of the pneumatic switch (41). As a result voltage will be delivered to the winding of relay PH-2 (42), and the first tank group pumps will run at the rated duty. Thus, fuel jettison from tank groups II is effected by pumps 3UM-V.



Manual control of fuel consumption

Provision is made in the fuel consumption automatic equipment for manual control of fuel consumption. Switch (See Fig. 28, Ref. No. 17)<sup>1</sup> has two positions AUTOMATIC-MANUAL ( АВТОМАТ-РУЧНОЕ ).

Manual control may be accomplished in two ways:

- 1) with the automatic equipment amplifiers functioning, or
- 2) with the automatic equipment amplifiers cut out.

With the amplifiers functioning, the pumps are started in turn with the aid of circuit breakers АЖС (18) depending on the indications of the blue pilot lamps (14).

With the amplifiers cut out, the pumps are likewise started by manipulating circuit breakers АЖС (18) depending on the indications of the fuel gauges (the circuit breakers of the next tank groups are tripped on when about 250 lit. of fuel remains in the previous tank groups).

When controlled manually, the system functions as follows: with the switch (17) set in the "MANUAL ( РУЧНОЕ ) position, voltage stops flowing to relay РВ-6(19). The relay contacts connect wires F315, 14, 13, 12, 11, 10 to the circuit breakers (18).

The first two circuit breakers start the pumps of the first tank group, since the first tank group of each engine accommodates two pumps; the first circuit breaker starts the pumps of the left engine first tank group, whereas the second circuit breaker starts the pumps of the right engine first tank group.

The other circuit breakers start the pumps of tank groups II, III and IV. The pumps of tank groups IV and V are changed over (prior to take-off) to stand-by duty by the switch (21) (on aircraft starting from No. 201409, only the pumps of tank group IV are changed over to stand-by duty).

When the circuit breakers of tank groups IV are switched on, the respective pumps change over from stand-by to rated duty. The pumps of tank groups V run throughout the flight at stand-by duty, therefore they are not furnished with manual control circuit breakers. When starting the engines independently on the ground (with voltage supplied from the aircraft storage battery) fuel consumption is controlled manually, which does not involve starting of inverter ИО-4500, consuming current amounting to 200A.

In case the fuel pumps are controlled manually at engine starting, with some tank groups not filled with fuel, the automatic equipment should be put in operation as follows:

1. Set the switch AUTOMATIC-MANUAL in the MANUAL ( РУЧНОЕ ) position.
2. Turn on the switches AUTOMATIC FUEL CONSUMPTION ( АВТОМАТ. ПОТРЕБЛ. ).
3. Switch on the circuit breaker for manual control of the first filled tank group.
4. Start the engines.
5. Switch off the circuit breakers for manual control of the first filled tank group.
6. Switch on the circuit breakers for manual control of the last empty tank group.
7. Wait for 4 to 5 sec., then set switch AUTOMATIC-MANUAL in the AUTOMATIC ( АВТОМАТ. ) position.

<sup>1</sup> Figures placed in brackets denote Ref. No. in Fig. 28.

8. Switch off the manual control circuit breakers.  
The above recommendations are based on the following considerations. Electric motor МВ-650 actuating pump ВВВ-Т may be changed over to heavy duty from the rated duty only. The motor is not to be run at the heavy duty from the very starting, as this is associated with excessive starting current (over 300 A) which will result in burning of the brushes and slip ring.  
With all tanks filled, the pumps of the first tank groups start running at the rated duty. With some tanks being empty, the pumps of the previous empty tanks will start running at the heavy duty due to the operation of the empty tank lower signalling units. Therefore it is recommended to switch on the circuit breakers of the last consumed empty tank group; this will cause the pumps of the group in question to be run at the rated duty. When switch AUTOMATIC-MANUAL is set in the "AUTOMATIC" ( АВТОМАТ. ) position, the pumps of the last empty tank group will be changed over from the rated to the heavy duty.  
The manual control may be used for checking the operation of all the pumps on the ground.  
For use of manual control in flight, refer to Section OPERATION OF FUEL SYSTEM AUTOMATIC EQUIPMENT.

Construction of Fuel Consumption Control Equipment Units

Fuel booster pump ВВВ-Т

Pump ВВВ-Т is of an electric centrifugal type; it is designed to build up fuel pressure at the inlet side of the main engine pump ВВВ-В, and to enable the aircraft fuel system to function properly at high altitude.

Pump specifications

Designation .....	Unit 461
Pump drive .....	From electric motor МВ-650Т, mounted on common shaft with pump
Direction of rotation .....	Left-hand
Fluid handled .....	Fuel Т-1 or ТС-1
Operating duty .....	(a) Light (stand-by) (b) Main (rated) (c) Heavy
Permissible temperatures of ambient medium during pump operation .....	From +30° to - 60° C
Hydraulic resistance offered by non-operating pump, with fuel drawn through it at a rate of 10,000 lit /hr .....	Not over 0.4 cm Hg



**Pump operating position** ..... Vertical (with motor downward) or horizontal

**Dry weight of pump** ..... Not over 9200 gr

The booster pumps are mounted on the fuel tanks. On tanks No.2, No.3, No.5, and No.16 the pumps are arranged horizontally, on tanks No.4, No.10, and No.6 - vertically. Illustrated in Fig.38 is horizontally mounted pump.

Electric motor MB-650T is diagrammed in Fig.39. The electric motor is furnished with two excitation windings. One of the windings is used for the light (stand-by) duty, the other for the main (rated) duty. The pump is changed over to the heavy duty by connecting series resistor RO-10-3 rated for 3 ohms into the main duty excitation winding. This causes a rise in the electric motor speed, resulting in a pressure of 1.4 to 1.6 kg built up at the pump outlet.

Within the guaranteed service life of the pump, the electric motor is capable of running at heavy duty for 100 hours. Continuous operation at heavy duty should not exceed 1 hour, including 15 min. of operation at a flow rate of 7000lit/hr, and 45 min. at zero delivery. Electric motor MB-650T is a four-pole, short-circuit, multispeed machine.

Rated data of electric motor MB-650T.

Voltage ..... 27 V ± 10 per cent

Current consumed (not over):

(a) at rated duty ..... 34 A

(b) at stand-by duty ..... 19 A

Torque:

(a) at rated duty ..... 10 kg-cm

(b) at stand-by duty ..... 6 kg-cm

Speed of rotation:

(a) at rated duty ..... 6100<sup>±200</sup> r.p.m.

(b) at stand-by duty (not less than) ..... 4600 r.p.m.

The electric motor should start normally under load at the rated and stand-by duty, with the air temperature amounting to - 60°C and supply voltage to 20 V; the pumping unit of the pump should be primed with the fluid handled.

Relation of the pressure at the pump outlet from the rate of fuel consumption  $p = f(Q)$  is presented in Fig.40. The same fig. illustrates interrelation between the current consumed and the rate of fuel consumption  $I = f(Q)$ .

Amplifiers FAT-52-2

The amplifier is illustrated in Fig.41.

All amplifier components are arranged on the inner and outer sides of the mounting frame, and on the inside of the front panel. The amplifier consists of the following main components: four valves 6BT6, eight relays RB, transformer J, relay PB-6, intermediate relay PB-45, eight rheostats (rated for 3 kilohms),

eight capacitors, rated for 1μF, and nine capacitors rated for 0.2 μF. The slide axes of eight rheostats are led to the outside of the front panel. Besides, the front panel carries safety fuses 4 rated for 1A, and two twelve-pin plug connectors 3, type EP32712B31 and EP32712B1. The amplifier housing is furnished with bed plate 7 and shock absorber frame 8 mounting four shock absorbers 271049-2-6. Amplifier housing is bonded by means of wire 9. The amplifiers are installed on a special rack, at frame No.22. The amplifier dimensions: 212x172x220 mm. Weight - 4100 gr. The ratings of the valves used in amplifiers FAT-52-5 are given in Table 9.

Table 9

FAT-52-5 amplifier valve ratings.

Valve type	U <sub>a</sub> , V	I <sub>a</sub> , mA	Anode dissipation rating, W	Actual, W	Specified for 1 period	U <sub>c</sub> , V	Main voltage, V	Note
6BT6	200	6	1.2	3.0	6.3	115	FAT-52-7 amplifier valve ratings are similar to FAT-52-5 amplifier valve ratings	
	220	6.7	1.34	3.0	6.93	126.5		

Fuel gauge signalling units

The signalling units represent the sensitive elements of the automatic equipment. Arrangement of the signalling unit inside the transmitter is shown in Fig.19.

The signalling unit consists of a coil and a float. The coil is hermetically sealed and has an open magnetic circuit.

The ratings of the coil are as follows:

- Resistance R=330 - 390 ohms at 20°C.
- Inductive reactance L=0.16 H, with the iron core out and 0.37 H, with the iron core in.

Data pertaining to signalling unit operation are given in Table 6.

Transmitters CA-317

Transmitters CA-317 are essentially fuel pressure signalling units installed at the pump outlet lines. The key diagram of the pressure signalling unit is presented in Fig.42. Fuel pressure is taken up by corrugated membrane 1. Pressure changing from 0 to 0.3 kg/cm<sup>2</sup> causes deflection of rigid centre boss 2, which actuates contact spring 3, thereby opening contacts 4 and 5.



50X1-HUM

The above (first) pressure range is not used. When pressure reaches 0.35 kg/sq.cm., upper contact 6 touches contact 5 causing the pilot lamp to light up. This is the second pressure range. Adjusting screws 8 and 9 serve for setting proper gap between the contacts. This gap determines the time of signalling unit operation depending on fuel pressure changes.

CR-37F specifications

1. Operation of pressure signalling unit depends on two fuel pressure ranges:
  - (a) with pressure changing from 0 to 0.35±0.5 kg/sq.cm., the pilot lamp of the first pressure range lights up (the above pressure range is not employed on the T7-36 aircraft);
  - (b) when pressure changes from 0.35±0.05 to 2 kg/sq.cm., pilot lamp of the second pressure range lights up.
2. Signalling unit is capable of operation within a temperature range of from +50 to -60°C.
3. Signalling unit pilot lamp is rated for 3W, 27V±10%.
4. Signalling unit operating errors:
  - (a) at normal temperature ..... 30.05 kg/sq.cm.;
  - (b) at temperature of from +50 to -45°C ..... 30.075 kg/sq.cm.
5. Signalling unit has been made air-tight to satisfy the following requirements:
  - (a) no pressure drop occurs (as read by reference pressure gauge) in inlet section of signalling unit if air pressure of 2 kg/sq.cm. is maintained for 10 min.;
  - (b) with pressure of 300 mm Hg delivered simultaneously into static and dynamic systems, pressure drop for 1 min. does not exceed 8 mm Hg.
6. Signalling unit withstands excess pressure of 2 kg/sq.cm. within 5 min.

Arrangement of Fuel Consumption Control Equipment on Aircraft

Arrangement of the automatic equipment amplifiers on the aircraft is shown in Fig.1. Arrangement of the fuel booster pumps and pressure signalling units CR-37F is illustrated in Fig.2.

Layout of all units and elements incorporated in the electric circuit of the fuel consumption automatic control equipment is shown in the respective cable and wiring diagrams (Figs 4) and 44).

Apart from the pilots upper panel (the fuel supply panel) the aircraft accommodates 6 distribution boxes and one additional distribution box for the pumps of the left engine tank group I.

The distribution boxes are arranged on the aircraft as follows: the distribution boxes of the fuel pumps - at frame No.33 (right and left); the distribution boxes of the landing gear and the relays of the fuel pumps - in the landing gear left and right compartments; the distribution boxes of the fuel pumps - at frame No.49; the distribution boxes of the fuel gauges - at frame No.22; the additional distribution box of the fuel pump of tank No.2 - at frame No.24.

The distribution boxes enclose the following equipments: contactors E-50B and E-23A (for fuel transfer pump CR-4FT), relay PU-2 and PU-6, resistors DD-10-5, safety fuses EB-15 rated for 50 and 75A.

Checking Fuel Consumption Control Equipment for Proper Operation on Aircraft

The automatic equipment is checked by draining fuel from the aircraft tanks. Preparation for the check consists in the following. The pipe line is disconnected from high-pressure pump EB-15-28 and is connected to the drain pipe fitted with a shut-off cock (the drain pipe is furnished with a 15 mm nozzle). All tank groups are filled to capacity (as governed by the refuelling floats). Fuel drainage may be accomplished with the aircraft on the parking area. In this case the aircraft should be arranged on a concrete ground, to avoid banking. Draining proper should be carried out in the following sequence:

1. Switch on the following circuit breakers mounted on the right-seat pilot panel: FUEL FLOW METERS, LEFT AND RIGHT ( ПАРКОВИЩА, КВ. 8 UPAB.); FUEL CONSUMPTION CONTROL ( ПИТАНИЕ ПАКОВОИ ТОЛКА) ; FUEL CONSUMPTION CONTROL UNIT, LEFT AND RIGHT ( АСТУИЯ ПАКОВА ТОЛКА КВ. 8 UPAB.); STAND-BY PUMP CONTROL ( ПИТАНИЕ РЕЗЕРВНОГО ДУХА); FUEL PUMP SIGNALING SYSTEM ( ЧИТАНИЕ ТОЛКА ДОИ).
2. Switch on the automatic equipment amplifiers.
3. Set switch AUTOMATIC-MANUAL ( АСТУИЯ-РУКОВО ) in the AUTOMATIC ( АТОМАТ ) position.
4. Start draining fuel from the identical tank groups of both engines at the same time. Fuel should be let out at a rate of about 6000 lit./hr. As fuel is being drained, the readings of the fuel gauges and fuel flow meters should be registered, each time the booster pumps are successively started or cut off (as indicated by the green pilot lamps). The readings of the above instrument should be also registered whenever signal are sent by the right and left amplifiers (as indicated by the blue pilot lamps). As soon as the blue pilot lamp lights up, fuel drainage should be discontinued (by closing the fuel shut-off valves). The amplifier, sending the signal, is identified by switching off the automatic equipment amplifiers alternately. Then, the fuel is drained until the other amplifier sends the signal. Data pertaining to signalling unit operation are given in Table 8 (fuel gauge reading error being neglected). Therefore, when registering the fuel gauge readings at the moment of signalling unit operation, allowance should be made for the reading error of the fuel gauge set under test. Practically, it takes 4 hours to drain the aircraft tanks of fuel.

Checking of the automatic equipment without resorting to fuel drainage is performed with the aid of tester JMA-53-60. The procedure consists in checking the operation of the amplifiers and the automatic equipment wiring. The checking procedure on the aircraft is carried out as follows:

1. Detach the aircraft plug connectors from the amplifier or the unit.
2. Connect the aircraft automatic equipment to receptacles "3" and "7" of the tester, by using aircraft plug connectors AUTOMATIC EQUIPMENT ( АТОМАТКА ) and TRANSMITTERS ( ЛАТЕНА); connect tester plug connectors "4" and "6" to receptacles AUTOMATIC EQUIPMENT and TRANSMITTERS of the amplifier or unit checked.
3. Switch on voltage supply of 115 and 27V. This should cause the lamps mounted on the tester panel and marked VOLTAGE CHECK ( КОНТРОЛ НАПОНА), TANK GROUP I SWITCHED ON ( БЕЛ. I гр.) and BOOSTER PUMPS TANK GROUP I (ДО-1 гр.) to light up.

NO FOREIGN DISSEM

50X1-HUM

Simultaneously, the identical lamps mounted on the fuel supply panel should light up. The transmitter signalling units are checked for proper operation by connecting amplifier or unit plug connector TRANSMITTERS (BATHEM) to tester receptacle No.3. If the automatic equipment fails to operate properly, adjustment should be carried out. The adjustment (of relays FB3) is accomplished with the aid of eight rheostats led to the outer panel of the amplifier (Fig.45). The adjustable signal is checked by switching on and off the pilot lamp insulating operation of the pump (booster pump EI).

The automatic equipment is adjusted at a voltage of 103.5 and 126.5 V. The respective relay FB3 should pick up at 103.5 V and drop out at 126.5 V.

Electric fuel gauge set CSTC-60M

The transmitters, automatic equipment units, and switches of fuel gauge set CSTC-60M are interchangeable with the identical elements of fuel gauge set CSTC-60A no changes in the wiring system being required in that case. Interchanging of the amplifiers and indicators requires some alterations to be performed in the wiring system of fuel gauge set CSTC-60A, namely, two shielded wires should be installed to connect pin 7 of the amplifier plug connector to pin B of the indicator plug connector, and pin 8 of the amplifier plug connector to pin A of the indicator plug connector (See Fig.28).

- Fuel gauge set CSTC-60M includes:
- 1. Indicators ..... 2 pieces
  - 2. Amplifiers, type FT-60M ..... 2 pieces
  - 3. Automatic equipment units, type MAO-52-12 ..... 2 pieces
  - 4. Wafer type rotary switches RT-7 ..... 2 pieces
  - 5. Transmitters with signalling units ..... 15 pieces
  - 6. Transmitters without signalling units ..... 2 pieces

Fuel gauge set CSTC-60M operates on the same principle as fuel gauge set CSTC-60A. The principal features differentiating set CSTC-60M from set CSTC-60A are as follows:

1. The automatic equipment and refuelling amplifiers incorporate selenium rectifiers employing bridge circuits, instead of valves 6HTC. The signal from the bridge is delivered to the excitation winding of the highly sensitive electromagnetic relay.
  2. Provision is made in the measuring equipment circuit for separate adjustment of the scale zero and maximum settings. This is of great importance for proper operation of the equipment because the zero setting of the scale is not disturbed by adjustment of the scale maximum setting. When the aircraft fuel tanks are empty, the pointer is set against the zero division of the scale with the help of the adjustment rheostats. After the tanks have been filled, the pointer is set against the respective division of the scale, by using the rheostats serving for adjustment of the maximum settings. In the measuring equipment circuit of fuel gauge set CSTC-60M adjustment of the zero settings is dependent on adjustment of the scale zero settings.
- The automatic equipment bridge key diagram is shown in Fig.46. The bridge consists of variable inductance (signalling unit coil E), permanent inductance E, and adjustable resistor  $R_{a1} + R_2$ . The bridge is energized from the secondary winding of the transformer.

When the iron core (the front bottom plate) is introduced into the signalling unit coil field, full resistance Z of signalling unit coil E, changes. As a result, the balance of the bridge gets disturbed, and a potential difference appears at the bridge diagonal peaks, in points A and B; this potential difference is applied via the selenium rectifier, employing a bridge circuit, to the excitation winding of highly sensitive electromagnetic relay R. The relay picks up, and its contacts connect or disconnect the power supply from the excitation winding of booster pump contactor K-30A.

The key diagram of the amplifiers of the fuel gauge automatic equipment, type CSTC-60M, is illustrated in Fig.47. Automatic equipment unit MAO-52-12 is shown in Figs 48, 49, and 50.

By reference to Fig. 47 it will be seen that each of the automatic equipment units consists of eight bridges, a transformer and relay (PC1-2). The refuelling automatic equipment unit comprises four bridges. The operating principle of this automatic equipment is similar to that of the amplifiers incorporated in the CSTC-60A fuel gauge set.

The key diagram of the self-balancing bridge is illustrated in Fig.51.

The bridge circuit is supplied with voltage from the secondary winding of transformer 1 whose primary winding receives A.C. of 115 V, 400 c.p.s. The self-balancing bridge consists of two equal windings of transformer 1, capacitances  $C_1$  and  $C_2$ , comprising the other two arms of the bridge,  $C_2$  being the variable, and  $C_1$  - permanent capacitances of the transmitter. Voltage from the secondary winding of transformer 1 is applied to the diagonal CM of the bridge. At a certain magnitude of variable capacitance  $C_2$ , the bridge is in the balanced state, and the potential difference in points A and B of the bridge amounts to zero. As soon as the transmitter capacitance undergoes any changes due to changing of the fuel level in the tank, the balance of the bridge will be disturbed, as a result of which the potential in point B relative to point A will be changed. This potential difference will be applied to the amplifier input. Increased voltage will be delivered from the amplifier output to the control windings of electric motor MAO-0.5, which will move the slide of the voltage divider R to a position, in which the potential difference between points A and B becomes zero again. The indicator pointer moves in unison with the slide. Separate adjustment of the zero and maximum settings is performed as follows.

The respective adjustments are carried out by employing rheostats  $R_1$  and  $R_2$ . At the initial magnitude of the transmitter capacitance (with the aircraft tanks empty) the bridge is so adjusted with the aid of rheostat  $R_1$  that it becomes balanced when the slide of voltage divider R is shifted to one of the furthestmost positions, and the indicator pointer is set against the zero division of the scale.

By using rheostat  $R_2$ , the bridge may be so adjusted that it will become balanced when the slide of voltage divider R will be moved to the other extreme position, whereas the indicator pointer is set against the maximum division of the scale. Changing of resistance  $R_2$  is offset by the changing of resistance of rheostat R. This will not affect the potential in point B, hence adjustment of the zero settings is not dependent on adjustment of the maximum settings. However, readjustment of the zero settings will require the adjustment of the maximum settings as the potential in bridge point B will be changed.

S-E-C-R-E-T  
NO FOREIGN DISSEM



50X1-HUM

The key diagram of the fuel gauge measuring equipment amplifier is shown in Fig. 32.

The A.C. self-balancing bridge consists of two tapped windings of transformer I (tapping points "10-6" and "8-6"), permanent capacitance 20 or 23 (the first is used for checking the amount of fuel in a tank group, the aircraft tanks), and variable capacitance  $C_2$  of the transmitters.

Adjustment of the zero and maximum settings of the scale is accomplished with the aid of rheostats TANK GROUP ZERO 43 (RHEO PPHHMM) and TANK GROUP MAXIMUM 49 (RHEO PPHHMM) for checking amount of fuel in individual tank groups, and TOTAL AMOUNT ZERO 42 (RHEO CFFMM) and TOTAL AMOUNT MAXIMUM 44 (RHEO CFFMM) for checking total amount of fuel.

The purpose of the individual components of the amplifier is referred to below.

Capacitors 16, 27 and resistor 29 from the H-shaped filter for rectifying lamp 6H9C. Resistors 32, 34, 37, 39, and 40 are grid leaks (building up biases on the valve grids). Resistors 33, 36, and 41 are designed for reducing grid current in valves. Capacitors 46 and 27 serve for correcting the shape of the curve. Voltage divider X (rheostat) 49 serves for balancing the bridge. The function of resistor (coil) 47 is to increase the sensitivity of the equipment when checking the amount of fuel in the individual tank groups. Resistors (coils) 28 and 9 are the compensating ones, their function being to reduce the thermal error of the fuel gauge (the compensating resistor is fabricated in copper wire HES0, which is wound in bifilar manner). Capacitors 21, 25, and 26 serve as dividers, capacitor 13 serves for shifting the current phase by 90°. Capacitors 19 and 22 serve as substitutes when checking amount of fuel in individual tank groups or in all aircraft tanks.

Valve 3 is used when checking the amount of fuel in the individual tank groups, whereas valve 4 is incorporated in the circuit used for checking the total amount of fuel.

Amplifier 7T-605 with and without the housing is illustrated in Figs 33, 34, and 35.

Brief specifications of the fuel gauge set components are given in Tables 10 and 11.

The interconnection diagram of fuel gauge set CFC-60M is illustrated in Fig. 36.

**TABLE 10**  
**LIST OF SPECIFICATIONS OF FUEL GAUGE SET COMPONENTS**  
 OF CFC-60M EQUIPMENT  
 (See circuit diagram of fuel gauge measuring equipment, Fig. 32)

Ref. No. in Fig.	Description	Type or mark	Rating	Quantity
1	Transformers(I)			1
2	Transformers(II)			1

1	2	3	4	5
3	Valve	6H9C		1
4	Valve	6H9C		1
5	Valve	6H9C		1
6	Valve	6H9C		1
7	Relay	PH-6		1
8	Relay	PH-5		1
9	Coil		800 ohms (copper)	1
10	Switch	KB-6-A		1
11	Switch	KB-6-A		1
12	Plug connector	EP32J12H81		1
13	Plug connector	EP20J5H81		1
14	Tubular safety fuse	TK-45-1	1 A	3
15	Capacitor	KHEP-3-250-0.25-II-A	0.25 $\mu$ F; 250 V	1
16	Capacitor	KHEP-2-400-2-II-A	2 $\mu$ F; 400 V	1
17	Capacitor	KHEP-2-400-2-II-A	2 $\mu$ F; 400 V	1
18	Capacitor	KCO-3-300-F-3700-II	370 pF	1
19	Capacitor	KCO-3-300-F-2200-II	2200 pF	1
20	Capacitor	KCO-3-300-F-6200-II	6200 pF	1
21	Capacitor	KCO-3-250-B-10000-II	10,000 pF	1
22	Capacitor	KCO-3-300-F-6200-II	6200 pF	1
23	Capacitor	KCO-3-250-II	30,000 pF	1
24	Capacitor	KCO-3-250-II	16,800 pF	1
25	Capacitor	KCO-3-250-B-10,000-II	10,000 pF	1
26	Capacitor	KCO-3-250-B-10,000-II	10,000 pF	1
27	Capacitor	KHEP-3-160-1-II-A	1 $\mu$ F; 160 V	1
28	Coil		450 ohms (copper)	1
29	Resistor	MAT-2-1 kilohms IIS	1 kilohm	1
30	Resistor	BC-0.25-1-310 kilohms II	310 kilohms	1
31	Resistor	BC-0.25-1-62 kilohms II	62 kilohms	1
32	Resistor	BC-0.25-1-100 kilohms	100 kilohms	1
33	Resistor	BC-0.25-1-1.5 kilohms II	1.5 kilohms	1
34	Resistor	BC-0.25-1-310 kilohms II	310 kilohms	1
35	Resistor	BC-0.25-1-310 kilohms II	310 kilohms	1
36	Resistor	BC-0.25-1-62 kilohms II	62 kilohms	1
37	Resistor	BC-0.25-1-100 kilohms II	100 kilohms	1
38	Resistor	BC-0.25-1-1.5 kilohms II	1.5 kilohms	1
39	Resistor	BC-0.25-1-310 kilohms II	310 kilohms	1
40	Resistor	BC-0.25-1-150 kilohms II	150 kilohms	1
41	Resistor	BC-1-1-310 kilohms II	310 kilohms	1
42	Rheostat		500 ohms, aluminum DSX 0.13	1
43	Rheostat		500 ohms, AMX 0.13	1



50X1-HUM

1	2	3	4	5
44	Rheostat		5000 ohms, nichrome BSHX 0.06	1
45	Rheostat		500 ohms, nichrome BSHX 0.13	1
46	Capacitor	KCO-3-250-B-II	30,000 pF	1
47	Coil		4800 ohms (3W), wire dia. 0.07 mm	1
48	Button			1
49	Rheostat		1000 ohms	1
50	Electric meter	AM-0.5		1
51	Plug connector	PM-12		1
52	Plug connector	EP32M28M		1

a Specifications of the transformer (I) are given under Fig. 37.  
 m Specifications of the transformer (II) are given under Fig. 36.

Table 11  
 Brief specifications of fuel gauge eqt. C3TC-608  
 SC2225212  
 (See circuit diagram of fuel gauge automatic equipment Fig. 47)

Ref. No. in Fig. 47	Description	Type or mark	Rating	Quantity
1	Plug connector	EP32M28M		1
2	Plug connector	EP32M28M		1
3	Transformer (III)	"		2
4	Tubular safety fuse	III-45-1	1A	2
5	Rheostat		3 kilohms, nichrome BSHX	2
6	Rheostat		3 kilohms, nichrome BSHX	2
7	Rheostat		3 kilohms, nichrome BSHX	2
8	Rheostat		3 kilohms, nichrome BSHX	2
9	Rheostat		3 kilohms, nichrome BSHX	1
10	Rheostat		3 kilohms, nichrome BSHX	1
11	Rheostat		3 kilohms, nichrome BSHX	1
12	Rheostat		3 kilohms, nichrome BSHX	1
13	Coil			2
14	Coil		mm	2
15	Coil		mm	1
16	Coil			1
17	Coil			1
18	Coil			1
19	Coil			1
20	Coil			1
21	Rectifier, selenium	SC-16-12		2
22	Rectifier, selenium	SC-16-12		2
23	Rectifier, selenium	SC-16-12		2
24	Rectifier, selenium	SC-16-12		1
25	Rectifier, selenium	SC-16-12		2
26	Rectifier, selenium	SC-16-12		1
27	Rectifier, selenium	SC-16-12		1
28	Rectifier, selenium	SC-16-12		1
29	Electromagnetic relay	mm		1
30	Electromagnetic relay			1





50X1-HUM

1	2	3	4	5
31	Electromagnetic relay			2
32	Electromagnetic relay			2
33	Electromagnetic relay			2
34	Electromagnetic relay			1
35	Electromagnetic relay			1
36	Electromagnetic relay			1
37	Relay	PCM-2		1
38	Relay	PO-6		1

\* Specifications of the transformer (III) are given under Fig.59.  
 \*\* Induction coils data: material of the winding - copper of the 0.08 mark, dia. 0.11 mm; resistance 330 to 399 ohms.  
 \*\*\* Relay specifications: winding material - copper of the 0.13 mark, dia. 0.15 mm. Number of turns - 9000; resistance 560 ± 30 ohms; pick up current 3 to 3.5 mA; drop out current 2 to 2.3 mA.

Portable Tester FJA-53-60 for Checking Automatic Equipment of Fuel Gauge Sets C9TC-60A and C9TC-60B

Portable tester FJA-53-60 serves for checking the automatic equipments of the fuel gauges in field as well as on the aircraft. The tester allows checking of the following automatic equipment components for proper operation:  
 (a) the units and amplifiers of fuel consumption control automatic equipment FAT-52-5 and EAC-52-12;  
 (b) the amplifiers and units incorporated in refuelling automatic equipment FAT-52-7 and EAC-52-13;  
 (c) the transmitter signalling units.  
 The tester is enclosed in a metal case. The external view of the tester with the cover removed is illustrated in Fig.60.  
 Installed on the front face of the panel are: simulator knobs, pilot lamps for checking voltage, pilot lamps for checking automatic equipment operation, an indicator, switches H and H<sub>2</sub>.

Tester basic data

1. The tester operates on A.C. of 115-105 V, 400<sup>±</sup> Hz 0.5-0.8.
2. Permissible ambient air temperature variations from -40 to +50°C.
3. During transportation the tester is capable of withstanding the effects of overloads, at acceleration amounting to 4 g within the frequency range of from 0.5 to 3 c.p.s., the number of impact cycles being equal to 10,000.
4. The weight of the tester does not exceed 8 kg.
5. Overall dimensions of the tester - 270x220x130 mm.


Operating principle of tester used for checking bridge in automatic equipment units and amplifiers

The key diagram of tester used for checking the automatic equipment bridge is illustrated in Fig.61. The circuit comprises an A.C. bridge, whose three arms (resistors R<sub>1</sub> and R<sub>2</sub> and permanent inductance L) are arranged in the units or amplifiers under check, the fourth arm being represented by variable inductance L<sub>1</sub> incorporated in the tester proper.  
 Variable inductance L<sub>1</sub> is essentially a series, simulating the function of the transmitter signalling unit and consisting of an induction coil and iron core.  
 The bridge is so adjusted as to allow it to be in the balanced position, when the core is removed from the coil field. As soon as the core is introduced in the coil field, the bridge balance gets disturbed and current appears in the winding of electromagnetic relay P, connected into the bridge diagonal (via the selenium rectifier) and located in the automatic equipment unit or amplifier. The relay picks up, and its contacts switch on the respective pilot lamp mounted on the front panel of the tester.  
 The circuit is energized either by A.C. of 115 V, 400 c.p.s., or D.C. of 27 V.

Operating principle of tester used for checking transmitter signalling units

The key diagram of tester used for checking transmitter signalling units is illustrated in Fig.62. The circuit is represented by an A.C. bridge, whose three arms (two permanent resistors R<sub>1</sub> and R<sub>2</sub> and permanent inductances L<sub>1</sub> and L<sub>2</sub>, connected into the circuit in turn) are arranged in the tester proper, whereas the fourth arm, represented by variable inductance L is incorporated in the signalling unit of the transmitter checked.  
 Connected into one of the bridge diagonals is indicator H.  
 With the transmitter signalling unit in proper condition, its inductance amounts approximately to one of the inductances L<sub>1</sub> or L<sub>2</sub>, arranged in the tester, and the bridge is in the balanced position. The current in the bridge diagonal amounts to zero which makes the pointer of the indicator, connected into the diagonal (via the selenium rectifier, set in the scale zone, marked with 0.00 (HOPKIN)).  
 With the signalling unit out of order, its inductance is not equal to the permanent inductance arranged in the tester, due to which the bridge balance will be disturbed, which will cause current to appear in indicator H. This will result in deflection of the indicator moving section, hence, the instrument pointer will set in the zone marked with 0.00 (HOPKIN).  
 The signalling unit inductance depends on whether the tank that houses the transmitter of the signalling unit checked is full or empty, that is, whether the iron core is placed in or removed from the inductance coil field. To maintain the bridge in the state of balance, with the signalling unit in proper condition and irrespective of the position of the iron core, provision has been made in the circuit for two permanent inductances.

NO FOREIGN DISSEM



50X1-HUM

- with the core drawn into the induction coil L<sub>1</sub>  
 - with the core retracted from the induction coil L<sub>2</sub>  
 Depending on the position of the float of the checked transmitter signalling unit, the appropriate induction coil is connected into the bridge circuit by manipulating switch S<sub>1</sub> (Fig. 63).  
 The circuit is energized from transformer T<sub>p</sub>, whose primary winding is supplied with A.C. of 115 V, 400 c.p.s.

Tester circuit diagram

The circuit diagram of the tester is illustrated in Fig. 63. The circuit is comprised of two independent sections: the section serving for checking the automatic equipment bridges in the amplifiers and units, and the section for checking the transmitter signalling units for proper operation.

Tester circuit for checking automatic equipment bridges

The circuit consists of eight simulating devices (1 - 8), comprising the fourth arm of the automatic equipment bridges checked. The unit or amplifier under check is connected to the tester plug connector, marked with No. 1 and No. 2. If the units or amplifiers are checked outside the aircraft, voltage of 115 V (400 c.p.s.) and 27 V is delivered via three terminals located on the front panel of the tester.

With the units and amplifiers checked on the aircraft, voltage of 115 V and 27 V is fed via the plug connector marked with TRANSMITTERS (LAMPERS), which is connected to the tester plug connector No. 2. To the D.C. minus the tester is connected via terminal 6 of plug connector AUTOMATIC EQUIPMENT (ASTOMATIKA), incorporated in the unit or amplifier checked, the above plug connector being connected to tester plug connector No. 1. As soon as the power supply is switched on, the following pilot lamps light up on the tester panel: two pilot lamps bearing inscription VOLTAGE CHECK, 115 V and 27 V (КОРТОПОЛЕ НАПРЯЖЕНИЕ 115 В и 27 В) and two lamps marked with ON GROUP No. (БЕЛ. No. ГР.) (14) and BOOSTER PUMP, GROUP I (СИ-1 гр.) (9). At the same time, voltage is delivered to the winding of relay PU-2 (23) and PU-3 (24). The relays pick up, thereby connecting the common end to the minus (27 V) of the pilot lamps. The voltage positive is delivered to the pilot lamps from the unit or amplifier checked via plug connector No. 2 of the tester.

When the unit or amplifier of the automatic equipment controlling the refuelling procedure is connected into the circuit, no voltage will be delivered to the windings of relays PU-2 and PU-3 (terminal 6 of plug connector AUTOMATIC EQUIPMENT being not connected to the minus of the voltage delivered). In this case, the positive of the current amounting to 27 V flows to the pilot lamps directly from the aircraft mains, via contacts 1 - 2, 4 - 5, 7 - 8 of relay PU-1, as well as via contacts 1 - 2 and 4 - 5 of relay PU-2. To the power source negative the pilot lamps are connected via the unit or amplifier checked (plug connector No. 1).

The bridges in the automatic equipment amplifiers and units are checked for proper functioning by the indications of the respective pilot lamp, which lights as soon as the bridge is disbalanced. The bridge is brought out of balance by

relaxing the handles of the simulating devices, that is by placing the iron core into the induction coil field.  
 The operating sequence of the pilot lamps, with the automatic equipment bridges, incorporated in the units and amplifiers disbalanced in turn, is given in Table 12.

Table 12

Operating sequence of pilot lamps with automatic equipment bridges disbalanced in turn

Simulator designation	Operating sequence of pilot lamps	Simulator designation	Operating sequence of pilot lamps
1A	Lights up ON, GROUP II	30	Lights up BOOSTER PUMP, GROUP IV ON, GROUP IV
2B	Goes out BOOSTER PUMP, GROUP II	4B	Goes out BOOSTER PUMP, GROUP III BOOSTER PUMP, GROUP III, ADD.
2H	Lights up ON, GROUP III	4H	Lights up "30 min"
3B	Goes out BOOSTER PUMP, GROUP III, ADD. BOOSTER PUMP, GROUP II	Fuel reserve for 30 min. 5 Fuel reserve for 15 min.	Lights up "15 min"

Tester circuit for checking transmitter signalling units

The circuit of the tester for checking the transmitter signalling units for proper operation (See Fig. 63) consists of transformer 25, two manganin resistors 26 and 27 (1500 ohm each), induction coil 31 with an iron core, induction coil 32, having no iron core, selenium rectifier 28, indicator 30, relays PU-2 and PU-3 (23, 24 and 25), and switches 34 and 35. Aircraft main plug connector MAINLINE is connected to the plug connector No. 3 of the tester, thus, the signalling unit of the transmitter checked is connected into the bridge circuit (the signalling unit representing the fourth arm of the bridge).  
 The voltage amounting to 115 V is delivered via terminals 10 and 12 of the plug connector No. 3 to the primary winding of the transformer and to pilot lamp VOLTAGE CHECK, 115 V; the voltage of 27 V is supplied via terminals 11 and 12. The voltage is fed at the same time to pilot lamp VOLTAGE CHECK, 27 V and to the winding of relay PU-2 (23). The relay picks up, thereby causing its contacts 7 - 8 (zero switch S<sub>1</sub> is set in the TANK FILLED position) to connect into the bridge.

S-E-C-R-E-T NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 50 -

circuit the induction coil having no iron core; contacts 5 - 6 of the relay (with switch  $U_1$  set in the TANK EMPTY position) will connect induction coil 31 furnished with an iron core.

With the signalling unit in proper condition, and with switch  $U_1$  set in the TANK FILLED position, the bridge is in the balanced state, and the indicator pointer sets in the scale zone bearing inscription GOOD (ХОРОШО).

With the signalling unit out of order, its inductance will not be equal to the induction arm of the bridge, incorporated in the tester; this will cause the bridge balance to be disturbed, as a result of which current rectified by the selenium rectifier will appear in the bridge diagonal.

With switch  $U_2$  (35) set in turn in each of the eight positions, the signalling unit will be connected into the circuit controlling fuel consumption sequence of the left and right engines, depending on which of the amplifiers is connected to the tester.

The sequence of the transmitter signalling unit checking is given in Table 13.

Table 13

## Sequence of transmitter signalling unit checking.

Positions of switch $U_2$	Left engine		Right engine		Refuelling Tank No.
	Tank No.	Signalling unit designation	Tank No.	Signalling unit designation	
1	2	1B	5	1B	2
1	4	2B	3	2B	4
3	4	2B	3 add.	2B	3
4	7	3B	7	3B	3
5	10	3B	10	3B	
6	12	4B	12	4B	
7	16	30 min.	16	30 min.	
8	6	15 min.	6	15 min.	

When checking the signalling units controlling the refuelling procedure, plug connector TRANSMITTERS of the aircraft refuelling line is connected to the connector No.3 of the tester, whereas switch  $U_2$  is set in the first four positions. Placed into the tester circuit are two resistors 22 and 29, whose function is to reduce the voltage.

## Operation of fuel system automatic equipment

Under normal operating conditions, the aircraft automatic equipment controlling fuel consumption is used as follows:

1. Prior to take-off, the pumps of the fourth and fifth tank groups run at the stand-by duty. The above pumps are started by operating switch STAND-BY PUMPS mounted on the fuel supply panel.

On some of the Tu-16 aircraft, only the pumps of the fourth groups run at the stand-by duty when fuel is being drawn from the first, second, and third tank groups. The pumps of the fifth tank group remain inoperative at that time. As soon as the pumps of the fourth groups start running at the rated duty, the pumps of the fifth tank groups start running at the stand-by duty.

2. Switch MANUAL - AUTOMATIC is set in the AUTOMATIC position. In this case, fuel is first drawn from the first tank groups.

Sequence of automatic equipment operation in the case of manual control of the fuel pumps at engine starting, with some of the fuel tanks empty, is given in the section MANUAL CONTROL OF FUEL CONSUMPTION.

Cases are known when some of the aircraft had their fifth tank groups emptied ahead of the proper time, causing the pilot lamp, indicating 15 min. fuel reserve to light up when fuel was being consumed from the second and third tank groups.

As is known, the pumps of the fourth and fifth tank groups on some of the aircraft run at the stand-by duty during flight. As the outlet pressure from pump SH-7 at the heavy and normal ratings exceeds the outlet pressure at the stand-by rating by 0.4 - 0.6 kg/sq.cm., fuel from the fourth and fifth tank groups should not be drawn, if the fuel is being still consumed from the previous tank groups. However, in flight, pressure fuel consumption from the fifth tank groups takes place on these aircraft.

The cause for the above condition is as follows:

Fuel tanks No.6 (the fifth tank group) are arranged in the fuselage above fuel tank No.3 (See Fig.1). Therefore, fuel level in these tanks is higher than the fuel level in tanks No.7 - 16, and slightly lower than in tanks No.2, No.4, and No.5. As a result, fuel from tanks No.6 will be delivered at a somewhat higher pressure due to a static fuel column resulting in a pressure increase of about 0.13 kg/sq.cm.

Apart from this, fuel from tanks No.6 has to run a shorter distance on its way to the engines, than fuel from the other tanks (See Fig.2). Therefore, hydraulic resistance involved in fuel delivery from tanks No.6 is less in comparison with the case when fuel is supplied from the other tank groups.

Thus, with the fuel consumption automatic equipment functioning properly, some additional supply of fuel from the tanks of the fifth group is expected during the flight, though some fuel is still contained in the previous tank groups.

To preclude additional fuel supply from the fifth tank group, with fuel consumption controlled automatically, some alterations have been made in the circuit controlling starting and stopping of pumps SH-7. These alterations are as follows:

During successive operation of the pumps of the first, second, and third groups at the rated or heavy duty, the fourth tank group runs at the stand-by duty, whereas the fifth tank group is at standstill. As soon as the respective signal causes the pumps of the third group to be switched over to the heavy duty (with about 250 lit. of fuel remaining in each of the third groups), and the pumps of the fourth group from the stand-by to the rated duty, the pumps of the fifth group start running at the stand-by duty. Thus, with the pumps of the first three groups running successively at the operating duties, the fourth tank group pumps run at the stand-by duty; when the pumps of the fourth group run at the rated duty, the pumps of the fifth group operate at the stand-by duty.

50X1-HUM

S-E-C-R-E-T  
NO FOREIGN DISSEM

— 52 —

With the fuel consumption controlled manually, the pumps of the fifth group start running at the stand-by duty when the circuit breaker of the fourth group is switched on (this circuit breaker is switched on as soon as the blue pilot lamp of the fourth tank group lights up on the fuel supply panel).

The circuit of the fifth tank group pumps with the above alterations is illustrated in the cable and wiring diagram of the fuel consumption control units, presented in Fig. 43. By reference to these diagrams, it will be seen that when the signalling unit of the third tank group operates, relay PU-2 picks up (to accomplish switching of the fourth group pumps to the rated duty); in this case negative voltage is supplied from terminal No. 3 of relay PU-2 to the windings of contactors K-30A, causing the latter to start the pumps of the fifth tank group.

It is recommended prior to flight to run the fuel booster pumps (manually) for a few seconds to check their operation and to preclude the possibility of safety fuses blowing out in flight.

Operation of fuel system automatic equipment in emergency.

1. One of the engines fails during flight. To preserve the aircraft balance, open the fuel cross-feed valve, taking care to see that fuel is consumed uniformly. If at the time of engine failure the tanks of the first groups are full, see that fuel is consumed uniformly from these tank groups by watching the readings of the fuel gauges, as the fuel contained in the first tank groups strongly affects the aircraft balance. In case fuel is consumed unevenly, control fuel consumption manually. If the engine failure occurred when the tanks contained not more than 30,000 lit. of fuel, non-uniform fuel consumption will not change the aircraft balance to any considerable degree.

2. Pilot lamp lights up indicating 15-min. fuel reserve. Check amount of fuel in each of the tank groups by the readings of the fuel gauge. Normally, fuel should be contained in the fifth tank group only. If the amount of fuel available is not sufficient for performing the landing, pass to the manual control of fuel consumption and switch on the circuit breakers of all the tank groups, to draw any remaining fuel from the tanks.

3. Both of the amplifiers fail (blue pilot lamps are dead). Pass to the manual control of the fuel system.

When passing from one tank group to another, watch the readings of the fuel gauge (manipulate the switch when the fuel gauge reads 250 lit.). Switch off the circuit breakers of the previous tank groups, as soon as the green lamps go out or start flickering.

The amount of fuel remaining for 15-min. flight is read off the fuel gauge, making allowance for the reading error. For instance, the pilot lamp, indicating 15-min. fuel reserve, lights up when the fifth tank group contains 1600 lit. of fuel. However, the fuel gauge reading error may amount to 5%, which will correspond to 400 lit. of fuel. Thus, the 15-min. fuel reserve as read by the fuel gauge, will amount to 2000 lit.

4. One of the tanks is leaky. It is necessary to pass over to the manual control system and first consume fuel from the faulty tank group. Then proceed with the fuel supply from the other tank groups in proper sequence by means of the manual control system.

5. Blue pilot lamps do not light up in proper sequence. It is necessary to pass over to the manual control system and to check fuel in the tank groups at regular intervals by the readings of the fuel gauge. For instance, if the tank of the left engine fourth group happens to be punctured in combat, when fuel is being drawn from the second tank group, blue pilot lamps of the first, second, and fourth tank groups will light up on the fuel supply panel. Fuel will be consumed from the second and fourth tank groups (green lamps of the second and fourth groups will light up). In this case it is necessary to check fuel level in the respective tank groups and pass over to the manual control. Fuel from the tanks of the right engine fourth group should be supplied to both engines via the cross-feed valve.

6. Green lamp fails to light up whereas blue lamp of the given tank group keeps burning. Check fuel consumption from the tank group in question by the readings of the fuel gauge. If the fuel is being drawn from the tank group (the indicator pointer moves to the left) go on with the automatic control of fuel consumption. In case no fuel is being drawn from the tank group in question, pass over to the manual control, by-passing the group which has failed to supply fuel to the engine.

Note: Fuel from tanks No. 6 can flow to the engines in the last turn by gravity. Not all of the fuel can flow out of tanks Nos 1, 2, 4, 5 and from the third and fourth tank groups by gravity. No fuel can be drawn from tank No. 3 by gravity.

50X1-HUM



CHAPTER III  
ENGINE INSTRUMENTS

Following are the most important factors affecting engine performance both on the ground and during flight:

- temperature conditions and engine lubrication;
- engine rotor speed;
- pressure of fuel delivered to engine fuel nozzles;
- fuel consumption.

The exhaust gases of a jet engine have a high temperature. The gases streaming through the engine exhaust unit are discharged into the atmosphere at a great velocity. The resulting reaction of the gas stream forces is transformed into the engine thrust.

The higher the temperature of the gases the greater the reaction of the gas stream forces. However, an excessively high temperature of the exhaust gases will result in failure of the turbine blades. Therefore, measuring of exhaust gas temperature is regarded as one of the most important checks.

Proper lubrication of the engine depends not only on oil pressure in the main lubricating oil line, but on the temperature of oil as well. At elevated temperatures oil viscosity decreases resulting in better lubricating property. At low temperatures oil viscosity becomes very high which prevents oil from penetrating into small clearances between the rubbing parts; in this case friction losses increase too. Oil temperature values may be also utilized for checking, to some extent, the temperature conditions of the engine. Therefore, measuring of oil temperature and pressure is also very important from the point of view of checking the engine performance.

Proper operation of the engine will prolong its service life and ensure trouble-free performance. Loads imposed on the engine during flight or when operating on the ground depend on the rotor speed. The higher the rotor R.P.M., the greater the thrust developed by the turbo-jet engine. However, if the rotor develops an excessively high speed, its components may be subjected to overloads, which are likely to cause engine failure. On the other hand, it is not economical to run the engine at a maximum speed, as this is associated with excessive fuel consumption. Therefore, measuring of the engine rotor speed is very important for checking engine operation.

The thrust developed by the engine depends on the pressure of the fuel and pressure ratio of the air, delivered into the engine combustion chambers. In turbo-jet engines, fuel pressure delivered to the fuel nozzles at the normal rating is tens of times greater than the fuel pressure at starting. Therefore, fuel pressure

should also be checked since it represents one of the main engine characteristics.

Finally, the amount of fuel contained in the aircraft tanks is one of the most important factors, determining the time of engine operation. The time period within which the aircraft is capable of flying through the air at given flight conditions depends on the amount of fuel held by the aircraft tanks. Therefore, the amount of fuel in the tanks and the fuel consumption should be kept under constant observation during flight.

Thus, the operating conditions of the power plant (aircraft engines) on the given aircraft include the following main characteristics:

- oil pressure in the engine turbo-starter;
- speed of the engine turbo-starter rotor;
- temperature of exhaust gases in the turbo-starter exhaust pipe;
- speed of the engine rotor;
- fuel pressure upstream of the high-pressure pumps;
- fuel pressure in the primary manifold;
- inlet oil pressure delivered to the engine;
- temperature of oil supplied into the engine;
- temperature of gases in the engine exhaust unit;
- amount of fuel in the aircraft tanks and its consumption.

To determine the respective values, which should be known at any moment, with the engines operating on the ground or in the air, the aircraft is equipped with the required measuring instruments.

All the engine instruments employed on the T-16 aircraft may be classified into the following groups:

1. The instruments checking the operation of the turbo-starter in the course of engine starting. These include:
  - pressure signalling unit QA-244 for checking oil pressure in the turbo-starter;
  - thermometer TC-29 for checking turbo-starter exhaust gas temperature;
  - tachometer TD-45 for checking turbo-starter rotor speed.
2. The instruments checking temperature conditions and the condition of engine lubricating oil. These include:
  - thermometer TB-22 for checking temperature of the gases effluent from the engine exhaust unit;
  - pressure gauge in the BM-3P set for checking oil pressure at the engine inlet;
  - thermometer TD-48 in the BM-3P set for checking temperature of inlet oil.
3. The instruments, whose indications may be used for estimation of engine thrust. These include:
  - pressure gauge in the BM-3P set for checking fuel pressure in the primary manifold, downstream of the high-pressure pumps;
  - pressure gauge BM-3 for checking fuel pressure upstream of the high-pressure pumps;
  - tachometer TD-5-2 for checking engine rotor speed.
4. The instruments for checking fuel amount and consumption. These include:

- fuel gauge set C37C-60R or C37C-60M for checking total amount of fuel and amount of fuel contained in the aircraft individual tank groups;
- fuel flow meter PTC-16 for checking total amount of fuel consumed by the engine.

**1. INSTRUMENTS INDICATING TEMPERATURE AND PRESSURE**

Following are the instruments indicating temperature and pressure: three-pointer electric engine-gauge unit SMH-3P, electric remote-reading pressure gauge SMV-3, thermoelectric thermometer TH-11, thermoelectric thermometer TCT-29, and pressure signalling unit CA-24A.

**Three-pointer electric engine-gauge unit SMH-3P**

**Purpose**

Three-pointer electric engine-gauge unit SMH-3P is a combination of three instruments serving to measure:

- fuel pressure downstream of the high-pressure pumps;
- inlet oil pressure supplied to the engine;
- temperature of inlet oil.

The SMH-3P unit set includes: indicator YK3-3, fuel pressure gauge transmitter H-100, oil pressure transmitter H-10, and oil thermometer transmitter H-1.

The indicator accommodates three measuring elements in one common housing:

- the fuel pressure gauge with a measuring range of from 0 to 100 kg/sq.cm.;
- the oil pressure gauge with a measuring range of from 0 to 10 kg/sq.cm.;
- the oil thermometer with a measuring range of from -30 to +130°C.

Each of the elements with its transmitter forms an independent measuring circuit.

The indicator dial consists of three sectors designed for the three pointers.

The aircraft is equipped with two SMH-3P sets. The indicators are mounted on the instrument board of the right-seat pilot.

Transmitters H-100 and H-10 are installed on a special bracket, on top of the engine, transmitter H-1 being accommodated in the oil line pocket. Each of the SMH-3P sets is switched on by means of circuit breakers AX-2, mounted on the circuit breaker panel of the right-seat pilot.

**Main technical data of SMH-3P set**

1. Permissible error in SMH-3P indicator readings, when operating in conjunction with the transmitters, at normal ambient air temperature (+20°C) should not exceed the following values:

For dial	Dial points checked	Permissible error
Fuel pressure gauge	10; 20; 40; 60; 80; and 90	±3 kg/sq.cm.
	0 and 100	±5 kg/sq.cm.
Oil pressure gauge	2; 4; 6; and 8	±0.4 kg/sq.cm.
	0 and 10	±0.6 kg/sq.cm.
Oil thermometer	0 and 100	±5°C

2. Variations in readings:
  - of pressure gauge at all dial points ..... not over 3 kg/sq.cm.;
  - of oil pressure at all dial points ..... not over 0.4 kg/sq.cm.;
  - of oil thermometer at all dial points ..... not over ±4°C.

3. SMH-3P set is supplied with voltage from the aircraft D.C. mains rated for 27 V ±10%.

4. Current consumed by an indicator and its transmitters should not be more than 0.3 A.

5. Similar indicators and transmitters belonging to different sets are interchangeable.

6. Pressure gauge transmitters withstand the following pressures:

- fuel pressure gauge transmitter ..... 120 kg/sq.cm.;
- oil pressure gauge transmitter ..... 15 kg/sq.cm.

7. Indicator is capable of withstanding vibrational stresses amounting to 1.5 g, vibration frequency being equal to 20 - 80 c.p.s. Transmitters can withstand vibrational stresses up to 4 g, with vibration frequency amounting to 10 - 400 c.p.s.

8. Instrument is capable of functioning within the range of ambient air temperatures of from +30 to -60°C.

9. Weight of SMH-3P set ..... not over 2 kg.

**Operating principle of fuel pressure gauge**

The fuel pressure gauge is a diaphragm-type electric remote-reading instrument, consisting of an indicator (measuring element) and a transmitter (Fig. 64).

The fuel gauge indicator comprises a ratiometer of electromagnetic type with a moving magnet employed as a rotor. The magnet carries a pointer with four fixed coils K<sub>1</sub>, K<sub>2</sub>, K<sub>3</sub>, and K<sub>4</sub>, arranged at an angle of 90°. The moving magnet is accommodated inside a copper damper. Fluctuations in the moving system cause pulse currents to appear in the damper, as a result of which the instrument pointer will be stopped.

An additional fixed magnet serves for returning the pointer in the initial position, when the power supply is cut off. Power is supplied to the circuit via the moving contact of potentiometer H, on the one hand, and via the point of ratiometer coils, on the other. Resistors R<sub>1</sub> and R<sub>2</sub> connected in series with coils K<sub>1</sub> and K<sub>2</sub> serve for adjusting the dial range and uniformity. Resistor R<sub>3</sub> serves for limiting the current consumed. Resistance values of the circuit elements at a normal temperature are given in Table 14.

50X1-HUM

Table 14

Resistance values and materials used for components incorporated in fuel pressure gauge circuit

Components	Resistor R <sub>1</sub> , R <sub>2</sub> , R <sub>3</sub>	Coils K <sub>1</sub> and K <sub>2</sub>	Coils K <sub>3</sub> and K <sub>4</sub>	Resistor		
				R <sub>1</sub>	R <sub>2</sub>	R <sub>3</sub>
Resistance, ohms	300	140	110	0-25	80-120	45
Wire material	Constantan HSM, dia. 0.09 mm	Copper HSM, dia. 0.09 mm	Copper HSM, dia. 0.09 mm	Constantan, dia. 0.12 mm		

Fuel pressure gauge transmitter H-100 consists of the following two main assemblies: the sensing assembly and the amplifying transmitter mechanism.

The sensing assembly takes up fuel pressure and actuates the mechanism. The sensing element is represented by a flexible corrugated diaphragm capsule with a box, whose space is connected to the pressure checked.

The last element of the amplifying transmitter mechanism comprises a slide, moving along a linear potentiometer. The potentiometer is divided by three intermediate branches into four sections having identical resistance values. As the external leads of the potentiometer are connected to each other, they act as a circular potentiometer.

The action of the ratiometer with a moving magnet is based on a property of a freely suspended magnet to set along the axis of the magnetic field, created by the coils due to the flow of electric current.

With no pressure in the diaphragm capsule of transmitter H-100, moving contact II of the potentiometer occupies the position exactly in between points 1 and 2. Assuming that the coil resistance values are equal, the currents in coils K<sub>1</sub> and K<sub>2</sub> of the ratiometer will be equal as well, their value being considerably in excess of the currents flowing in coils K<sub>3</sub> and K<sub>4</sub>; coils K<sub>3</sub> and K<sub>4</sub> are connected in series into the larger sections of the potentiometer (sections H-1 and H-2 for coils K<sub>3</sub> and K<sub>4</sub>, sections H-3 and H-4 for coils K<sub>1</sub> and K<sub>2</sub> respectively). The vector of the resultant (total) magnetic field will be directed as shown in Fig. 65, a. The rotor of the indicator will set in the same direction.

Moving contact II is coupled to the sensing element of the transmitter so that as the pressure increases, the contact is displaced from the initial position successively to points 2, 3, and 4; this will cause the current value in the coils and hence the magnetic fields to change in the manner allowing the axis of the resultant magnetic field to turn in unison with the movement of contact II.

With pressure amounting to half of the rated value, moving contact II will be in point 3. This means that in coil K<sub>3</sub> the current will be at its maximum. The corresponding vector diagram will look as shown in Fig. 65, b (right). The moving magnet will turn in the direction of the resultant field, thereby causing the pointer to set against the division in the middle of the scale.

At maximum pressure contact II will be positioned between points 4 and 1. Accordingly, current redistribution will take place in the circuit, which will determine the direction of the resultant magnetic field vector and of the ratiometer moving magnet (see Fig. 65, c).

50X1-HUM

Thus, one intermediate position of the ratiometer moving system will correspond to each of the intermediate positions of the potentiometer slide.

Operating principle of oil pressure gauge

The oil pressure gauge is a differential pressure gauge, measuring the difference between oil and atmospheric pressures. The pressure gauge consists of a measuring element (indicator) and transmitter H-10.

The oil pressure gauge indicator is represented by a ratiometer of an electromagnetic type with a moving magnet and fixed coils K<sub>1</sub> and K<sub>2</sub>, positioned at an angle of 120°.

The construction of the measuring element of the oil pressure gauge is essentially the same as that of the fuel pressure gauge measuring element.

Oil pressure gauge transmitter H-10 differs from fuel pressure gauge transmitter H-100 in that its corrugated membrane is of a different thickness, whereas its potentiometer has no intermediate tapped sections. Besides, the transmitter of the oil pressure gauge is of a differential type; therefore its casing is hermetically sealed and is furnished with a static pressure connection, serving to supply atmospheric pressure to the external side of the membrane.

The circuit of the pressure gauge measuring element (Fig. 66) is essentially a bridge having an additional semi-diagonal (resistors R<sub>1</sub> and R<sub>2</sub>). Variable sections AC and AC' of the potentiometer along with fixed resistors R<sub>1</sub> and R<sub>2</sub> form the bridge arms. Connected into the bridge diagonal are coils K<sub>1</sub> and K<sub>2</sub>. Resistor R<sub>3</sub> connected in series with coil K<sub>2</sub> equalizes the coil resistances (the coils have the same number of turns, their diameters being different). The resistance values as well as the material and diameters of the winding wires are given in Table 15.

Table 15

Resistance values and materials used for components incorporated in oil pressure gauge circuit

Components	Potentiometer AB	Coils		Resistors				
		K <sub>1</sub>	K <sub>2</sub>	R <sub>1</sub>	R <sub>2</sub>	R <sub>3</sub>	R <sub>4</sub>	R <sub>5</sub>
Resistance, ohms	250	280	220	1000-1500	1000-1500	530	2120	60-100
Wire material	Constantan HSM, dia. 0.1 mm	Copper HSM, dia. 0.09 mm	Constantan HSMOK, dia. 0.1-0.12 mm	Copper HSM dia. 0.05 mm	Copper HSMOK, dia. 0.1 mm			

The operating principle of the differential oil pressure gauge is as follows: Oil pressure is taken up by the sensing element - the corrugated diaphragm which deflects under the pressure and displaces moving contact C on potentiometer track AB through the medium of the amplifying transmitter mechanism; this causes a change in the ratio of potentiometer arms AC and BC. The ratio of the potentiometer arms

is measured with the aid of a ratio-meter, which acts as a rotating magnet capable of setting in the direction of the axis of the magnetic field created by energized coils  $K_1$  and  $K_2$ .

Operation of the oil pressure gauge is diagrammed in Fig. 67. The currents flowing in coils  $K_1$  and  $K_2$  may be regarded as:

- (a) are total of currents  $I_1$  flowing in the coils with potentiometer moving contact C in the middle position;
- (b) are total of currents  $I$  induced as a result of moving contact deflection from the middle position.

With the oil pressure amounting to the half of the maximum permissible value, moving contact C is positioned exactly in the middle of potentiometer ACU (Fig. 67, b). In this case the circuit comes to be absolutely symmetrical, as resistors  $R_1$  and  $R_2$  and hence the potentials at points A and B are identical in value.

Current  $I$ , flowing along semi-diagonal  $R_3$  and  $R_4$  branches (from point A common to both of the coils) into two currents equal in value and opposing as to the direction of flow. As the coils have the same number of turns, the resultant field, and consequently the moving system of the ratio-meter will set in the middle of the scale.

As soon as a pressure change takes place, the circuit symmetry becomes disturbed. As a result, a potential difference, directly proportional to the magnitude of the pressure change, will be created between points A and B.

This potential difference may be positive or negative, depending on the direction in which moving contact C travels from the middle position. The potential difference existing between points A and B causes additional current  $i$  to flow in both of the coils in the same direction. Current  $i$  disturbs balance of currents flowing in the ratio-meter coils, as the currents flowing in the coils will amount now to  $I+i$  and  $I-i$  respectively.

The resistance of the circuit has been so selected that when pressure is equal to zero, currents  $I$  and  $i$  become equal in value. Then current in coil  $K_2$  will drop to zero, whereas in coil  $K_1$  it will grow to double its initial value. In this case the moving system of the ratio-meter will be positioned along the axis of coil  $K_1$  and the pointer will set against the zero mark of the scale (Fig. 67, a).

When the pressure checked reaches the maximum value, currents  $I$  and  $i$  will become equal again. Then current in coil  $K_1$  will drop to zero, whereas in coil  $K_2$  it will double its value. The moving system of the ratio-meter will be arranged along the axis of coil  $K_2$ , and the pointer will set against the maximum pressure mark on the scale (Fig. 67, c).

Thus, only one definite position of the ratio-meter moving system will correspond to each of the positions of the potentiometer moving contact.

Operating principle of oil thermometer.

The oil thermometer, type TTB-4B, is a general-purpose resistance thermometer. It consists of a measuring element (indicator) and transmitter D-1. The ratio-meter employed by the indicator is identical to that incorporated in the oil pressure gauge.

Oil thermometer transmitter D-1 is essentially a thermo-sensitive element made of Cu-CO alloy. The resistance values and standards used for the components incorporated in the oil thermometer circuit are presented in Table 16.

Resistance values and standards used for components incorporated in oil thermometer circuit

Table 16

Components	Loops		Resistors							
	I	II	$R_1$	$R_2$	$R_3$	$R_4$	$R_5$	$R_6$	$R_7$	$R_8$
Resistance, ohms	280	220	470	60	440	Up to 52 796 236 ( $R_4 + R_5$ )		100	80	8-153
Fire material	Copper	Copper	Manganin	Copper	Manganin	Copper	Manganin	Copper	Copper	Nickel

The oil thermometer (Fig. 68) makes use of the thermo-sensitive element ability to change its resistance depending on the variations in the oil temperature checked. Each of the temperature values is represented only by one definite resistance value which is being constantly checked with the aid of the ratio-meter.

The resistance of the circuit is so selected that when the oil temperature equals  $-30^{\circ}\text{C}$ , and the transmitter resistance value is equal to 66.3 ohms, the potentials at points A and C are equal, while the potential at point B is higher than that at point A. In loop I current will flow from point B to point A, whereas loop II will be demagnetized. Consequently, intensity  $H$ , created by loop I will increase, thereby causing the vector of resultant field  $H_r$  and the moving magnet of the ratio-meter to occupy the extreme left-hand position, for example, in the direction of axis II - II (Fig. 69); as a result, the instrument pointer will read  $-30^{\circ}\text{C}$ . With an increase of the oil temperature, the resistance of the transmitter will grow, causing an increase in the potential at point A. At an oil temperature of  $+30^{\circ}\text{C}$  the transmitter resistance will amount to 106.8 ohms. In this case the potential difference between points B and A will become equal to the potential difference between points A and C. Current will flow from point B to point A and from point A to point C; the currents in the loops and the intensity of magnetic fields  $H_{r1}$  and  $H_{r2}$  created by these currents will be the same, while resultant field  $H_r$  will be arranged in the direction of axis I - I along which the moving magnet will be positioned; the pointer will read a temperature of  $+30^{\circ}\text{C}$ .

With the oil temperature further increased, the potential at point A will be approximating the potential at point B thereby gradually increasing in comparison with the potential at point C. Current in loop I will be decreasing and in loop II - increasing; as soon as the oil temperature reaches  $+130^{\circ}\text{C}$ , and the transmitter resistance amounts to 153 ohms, current in loop I will drop to zero, whereas current in loop II will reach its maximum value. The moving magnet will set along the vector of the resultant magnetic field, for example along axis III-III, and the instrument pointer will read a temperature of  $+130^{\circ}\text{C}$ .

Remote-Reading Pressure Gauge RMP-3  
 RMP-3

The remote-reading pressure gauge of the RMP-3 type is designed for measuring low pressure of the fuel upstream of the TR-2B-15 equipment. The aircraft is

50X1-HUM



fitted with two sets of the **33W-3** pressure gauges, each set consisting of an indicator and a transmitter. The indicators are arranged on the left-hand instrument board, the transmitters being installed on the engines. Both **33W-3** sets are switched on by means of circuit breakers A30-2 located on the circuit breaker panel of the right-seat pilot (Fig. 70).

The indicator of the **33W-3** set is a magnetic ratiometer, having a moving magnet and two fixed coils  $K_1$  and  $K_2$ , positioned at an angle of  $120^\circ$ ; the moving system of the ratiometer consists of a flat iron-nickel-aluminum magnet, mounted on a cylindrical axle. The same axle carries a pointer and a cross-piece with three balancing weights. The moving system is enclosed inside a copper damper, energized by two coils  $K_1$  and  $K_2$ . Moving system oscillations in the damper induce currents which slow down the magnet thereby causing the oscillations to cease. From the point of view of its construction and operating principle the ratiometer of the **33W-3** set is identical with the ratiometer employed in the measuring circuit of the oil pressure gauge.

The sensing element of the transmitter of the **33W-3** set is represented by a flexible bronze diaphragm capsule, taking up the pressure obtained through a dynamic pressure connection. The static pressure connection serves for supplying static pressure to the inner space of the casing.

The linkage mechanism of the transmitter consists of a rod, rigidly connected to the capsule; the rod works against one of the arms of a rectangular lever-bell crank. This causes the bell crank to turn and to displace the carrier, attached to the brush holder; the latter turns about its axis thereby displacing the moving contact on the potentiometer.

Main technical data of **33W-3** set

- Measuring range ..... from 0 to 3 kg/sq.cm.
- Voltage supplied from aircraft D.C. maine ..... 27 V  $\pm$  10%
- Current consumed ..... 0.1 A
- Permissible overload ..... 4 - 5 kg/sq.cm.
- Main error:
  - on scale marks ..... 0.6; 1.2; 1.8; 2.4 -
  - .....  $\pm$  0.12 kg/sq.cm.
  - on scale marks ..... 0 and 3 -  $\pm$  0.2 kg/sq.cm.
- The electric bridge resistor values are given in Table 17.

Table 17

**33W-3** set electric bridge resistor values

Circuit components	Coils			Resistors				
	$K_1$	$K_2$	AB	$R_1$	$R_2$	$R_3$	$R_4$	$R_5$
Resistor value, ohms	200	220	259	1250	1250	2120	300	50
Wire material	Copper	Copper	Constantan	Constantan	Constantan	Copper	Constantan	Copper

Operating principle

The operating principle of pressure gauge **33W-3** is as follows. An increase in pressure makes the diaphragm capsule expand and cause the amplifying transmitter mechanism to displace contact a, sliding along linear potentiometer ab. As a result, resistance between points a and c will increase; while resistance between points a and b will decrease. The ratio between resistances ac and ab is measured with the aid of a ratiometer. Flowing in the ratiometer coils are currents whose ratio is dependent on the pressure checked.

With the pressure equal to zero ( $p=0$ ), that is when the resistance of section ac exceeds the resistance of section ab, there is no current in coil  $K_1$  while in coil  $K_2$  the current is at its maximum value (Fig. 71, a). In this case the magnetic field is created only by coil  $K_2$ , and the moving magnet will set along the axis of coil  $K_2$ , causing the pointer to read zero pressure.

As the pressure increases, contact a approaches point a, as a result of which current drops in coil  $K_2$  and increases in coil  $K_1$ . Accordingly, the magnetic flux of coil  $K_2$  will decrease, whereas the magnetic flux of coil  $K_1$  will increase. This will cause the axis of the resultant magnetic field to turn. The magnet with the pointer will turn in the same direction thereby reading a pressure increase. As soon as the pressure reaches the mean value ( $p = 0.5 p_{max}$ ), the bridge circuit becomes symmetrical, as the resistance of section ac is equal to the resistance of section ab; in this case currents of the same magnitude will flow in both coils thereby creating similar magnetic fields. The axis of the resultant magnetic field will run symmetrically, at the same angles to the coil axes (Fig. 71, b); the magnet will set along this axis and the pointer will read the mean pressure.

At a maximum pressure, ( $p=p_{max}$ ), when resistance of section ac approximates zero, current in coil  $K_2$  will drop to zero causing the magnet to set along the axis of coil  $K_1$ ; in this case the pointer will indicate the maximum pressure (Fig. 71, c).

With the power supply source disconnected, the ratiometer pointer is returned to the zero mark of the scale with the aid of an additional fixed magnet, operating in conjunction with the main moving magnet.

Thermoelectric Thermometer **TET-11**

Thermometer **TET-11** is of a thermoelectric type serving for measuring mean temperature of engine exhaust gases. The thermometer comprises indicator **TET-1** and four thermocouples **T-1** connected in series.

Indicator **TET-1** is essentially a moving coil millivoltmeter whose moving system is represented by a loop rotating between the poles of a permanent magnet. The measuring range of the scale is from 300 to 900°C. The scale numbering is 3, 4, and 9, each number denoting hundreds of degrees. The division value amounts to 10°C.

The thermocouple of the **T-1** type is made in the form of a hollow rod fabricated in heat-resistant steel; the rod accommodates the ends of the thermoelectrodes, welded together and forming the hot junction of the thermocouple.

50X1-HUM

NO FOREIGN DISSEM

Nickel-cobalt and silver alloys are used for the positive and negative electrodes respectively. Inside the rod, the electrodes are bent at an angle of 90°.

The gas stream, entering the space surrounding the hot junction through the outlet provided at the end of the rod and escaping via the hole 0.6 mm in diameter, has a mean lower velocity, than in the engine exhaust unit. This eliminates the error due to high velocity of gas flow.

The thermocouples are connected to each other and to the indicator by means of copper wire of the MHTC mark, 1.5 sq. mm in cross-section. Series connection of the thermocouples is accomplished in the terminal box.

The aircraft is equipped with two sets of the above thermometers, one for each engine. The indicators are located on the left-hand pilot instrument board, the thermocouples being arranged on the engines, along the exhaust unit circumference. Each of the thermocouples is held in position with the aid of special slots provided on the connections, and pins arranged on the thermocouple heads.

Main technical data of the thermometer TBF-11

Measuring range ..... 300 - 900°C  
 Operating range ..... 440 - 750°C  
 Resistance of thermometer external circuit at the ambient air temperature amounting to +20°C ..... 2.5 ± 0.1 ohms  
 Weight of the set ..... 3900 gr

The indicators and the thermocouples are interchangeable only with the respective components of the same calibration group, which is clearly marked on the indicator scale and on the thermocouple cover.

Thermometer reading error within the temperature range of from 450 to 750°C should not exceed 2°C.

Operating principle

Thermometer TBF-11 employs a thermoelectric principle in its operation (Fig. 72), which can be briefly described as follows. Variations in the temperature of the engine exhaust gases cause thermoelectromotive force to be generated in each of the thermocouples. This force is proportional to the temperature of the given area. The total thermoelectromotive force developed by the four thermocouples is applied to the ends of the wires and is measured by the moving coil millivoltmeter.

When current flows through the millivoltmeter loop, the latter is acted upon by the torque resulting from the interaction of the loop magnetic field produced by the current, with the permanent magnet field. As a result, the loop and the rigidly connected pointer will move until the torque is equalized by the force of the coil springs. The angle of the loop deflection is proportional to the magnitude of the current flowing through the loop. The resistance of the thermometer circuit being constant, the magnitude of the current flowing through the loop and the angle of its deflection are proportional to the thermoelectromotive force of the thermocouples and consequently to the temperature checked.

The magnitude of the thermoelectromotive force depends on the material of the thermoelectrodes starting to develop thermoelectromotive force when the hot junction is heated to a temperature of 300°C, and on the temperature difference between the working end (hot junction), enclosed in the rod casing, and the free ends (cold junctions), brought to the indicator with the aid of wires.

50X1-HUM

Thermoelectric Thermometer TCT-29  
Principle

Thermometer TCT-29 is of a thermoelectric type consisting of indicator TCT-2 and thermocouple T-9 with compensatory leads. The thermometer is designed for measuring the temperature of turbo-starter exhaust gases. The aircraft is furnished with two sets of the above thermometer. The indicators are located on the turbo-starter panel, the thermocouples being arranged in the exhaust pipe of each turbo-starter.

Indicator TCT-2 is essentially a moving coil millivoltmeter, whose scale is calibrated in degrees from 0 to 900°C; the scale numbering is 0; 3; 6; 9; the division value is 20°C.

Thermocouple T-9 is of a tubular type; it is made from heat-resistant steel; the tube encloses the ends of thermoelectrodes welded together and forming the working end of the thermocouple.

The thermoelectrodes are manufactured from chromel (the positive electrode) and from alsteel (the negative one). To reduce deflection of indications to the minimum, the thermocouple tube is provided with two side slots. The multi-core copper-constantan wire of the MHTC mark is used as a compensatory wire.

Main technical data of thermometer TCT-29

Measuring range ..... from 0 to 900°C  
 Operating range of scale ..... from 600 to 900°C  
 Resistance of thermocouple complete with compensatory wire ..... 920.6 ohms  
 Weight of the set ..... 4 kg

The indicators, thermocouples, and compensatory wire sections are interchangeable (respectively).

Thermometer reading error at an ambient air temperature of +20°C should not exceed:  
 within the operating range ..... 2°C  
 beyond the operating range ..... ± 3°C

Operating principle

The operating principle of the thermometer of the TCT-29 type (Fig. 73) is based on the measurement of the thermoelectromotive force generated by the thermocouple due to the difference of temperatures between the hot junction (the operating end of the thermocouple) enclosed in the tube and the cold junction (the free end of the thermocouple) brought to the indicator by means of the compensatory wire. The thermoelectromotive force developed due to the variations in the temperature of gases conveyed through the turbo-starter exhaust pipe is measured by the millivoltmeter. whose operating principle is referred to in the description of thermometer TBF-11.

Pressure signalling unit CA-28A  
Principle

The pressure signalling unit of the CA-28A type (Fig. 74) is designed for closing the electric circuit when pressure in the oil system of the turbo-starter

increases in excess of a specified value, and for opening the circuit when the oil pressure drops below another specified value.

The sensing element of the signalling unit is a flexible corrugated diaphragm whose inner space is connected to the turbo-starter oil line. The circuit is closed by the action of a flat lever spring contacting the diaphragm fixed centre boss. The contact on the lower spring closes with the contact attached to the upper flat spring. The circuit incorporates a pilot lamp.

The aircraft is furnished with one pilot lamp per two engines; it is located on the turbo-starter panel. The pressure signalling units are mounted on the compressor front castings of the engine and are connected to the turbo-starter oil lines through the medium of tubing.

Main technical data of pressure signalling unit CK-244

Signalling unit contact system is opened when pressure drops below ..... 3.5 kg/sq.cm.  
Instrument operating error at a temperature of +20, +30 and -60°C does not exceed ..... 20.3 kg/sq.cm.  
The instrument is designed for switching off a 5 W pilot lamp, with voltage amounting to ..... 27 V ±10%  
with a pressure of 800 mm Hg supplied through static and dynamic connections simultaneously, pressure drop in static chamber within 1 min. should not exceed ..... 6 mm Hg  
No pressure drop should be observed in the dynamic chamber within 5 min., with pressure amounting to 10 kg/sq.cm.  
Weight of the signalling unit ..... not over 400 gr

Operating principle

The operating principle of signalling unit CK-244 is based on the interdependence between varying pressure and deflection of the sensing element (diaphragm).

With the turbo-starter being started, and oil pressure in its system building up, the fixed centre boss of the diaphragm will be forced by the measured pressure to move and work against the contact assembly, thereby closing the pilot lamp circuit. The pilot lamp will light up thereby indicating pressure in the oil line of the turbo-starter.

2. SPEED MEASURING INSTRUMENTS

The speed measuring instruments include: remote-reading electric tachometer T3-5-2 and two-pointer remote-reading electric tachometer T3-45.

Remote-Reading Electric Tachometer T3-5-2

FIGURE 1

The remote-reading electric tachometer T3-5-2 is designed for measuring the speed of the engine rotor. It consists of a three-phases A.C. generator of the A-15 type and a single-pointer indicator.

The aircraft is equipped with two T3-5-2 sets. The generators are mounted on the engine drive frames and are coupled to the engine drives with the aid of flanges. The indicators are arranged on the left-hand instrument board.

Main technical data of tachometer T3-5-2

Measuring range ..... from 0 to 3000 r.p.m.  
Division value ..... 30 r.p.m.  
The generators and indicators are respectively interchangeable. Voltage across the terminals of the generator two phases, with the generator loaded by its indicator and with an engine speed amounting to 4000 r.p.m., should be from 24 to 26 V.  
Indicator weight ..... 790 gr  
Tachometer generator weight ..... 1650 gr  
The reading error of the instrument should not exceed the following values:

Measuring range, r.p.m.	Instrument error in % of rated scale value, r.p.m. at temperatures					
	+20°C		+30°C		-60°C	
	%	r.p.m.	%	r.p.m.	%	r.p.m.
000-3500	±1	±50	±1.6	±60	±2.6	±130
300-4800	±0.5	±25	±0.8	±40	±1.3	±59
800-9000	±1	±50	±1.6	±80	±2.6	±130

Operating principle

Tachometer T3-5-2 operates on the following principle: generator A-15 transforms the engine rotor speed into the electromotive force, the generated current frequency being directly proportional to the r.p.m. (Fig. 75).

The spinning rotor of the generator induces three-phase current in the stator, the current being delivered to the synchronous motor of the indicator.

As a result, a rotating magnetic field is produced in the motor stator windings, which causes rotation of the rotor, consisting of two cruciform permanent magnets and a hysteresis disc mounted on a common shaft.

The permanent magnets serve to provide for starting and steady running torques at low speeds, when the magnitude of the magnetic flux is not great.

The function of the hysteresis disc is to ensure a starting torque at higher speeds, when the magnitude of the magnetic flux is great but the additional permanent magnet is not capable of providing synchronous operation of the indicator motor.

At high speeds the hysteresis disc runs the rotor to an approximately synchronous r.p.m., the additional magnet providing for absolute synchronism.

The additional permanent magnet is freely fitted on the shaft, on a common housing, with the hysteresis disc, to which it is coupled through the medium of a spring, transmitting the torque to the shaft of the synchronous motor.

The tachometer indicator utilizes the induction principle. The indicator synchronous motor rotates the magnet assembly secured at the end of the shaft. The magnetic field produced by the magnets crosses the sensing element (a gap of aluminium-manganese alloy) thereby inducing eddy currents, which act on the magnetic field to produce a torque.

50X1-HUM



50X1-HUM

Due to the torque, the sensing element tends to turn about its axle. The other end of the sensing element axle carries a pointer, indicating the engine rotor speed on the instrument scale.  
A coil spring, attached to the axle of the sensing element represents the counteracting force limiting the motion of the sensing element.  
To make the pointer more stable and to improve instrument readings, provision has been made for magnetic damping of the indicator moving system. The damper, similar to the magnet assembly, consists of six pairs of magnets, whose faces are interposed with an aluminum disc, mounted on the axle of the indicator moving system.

Two-Pointer Remote-Reading Element  
Tachometer TQ-45

Purpose

Tachometer TQ-45 is designed for measuring the speed of the turbo-starter rotor within the range of from 400 to 3500 r.p.m.  
The aircraft is fitted with two TQ-45 sets - one per each turbo-starter. Each of the sets includes a generator installed on the turbo-starter reduction unit drive, and an indicator, mounted on the turbo-starter panel.

Main technical data of tachometer TQ-45

Maximum speed measured	3500 r.p.m.
Scale operating range	from 400 to 3000 r.p.m.
Instrument error at ambient air temperature of	-20°C 2.5 r.p.m. +50°C 2.0 r.p.m. -60°C 2.0 r.p.m.
Gear ratio from turbo-starter to generator	1:10
Indicator weight	625 gr
Generator weight	1150 gr

Operating principle

Tachometer set TQ-45 transforms speed into current of definite frequency. The tachometer generator is a three-phase A.C. machine. The frequency of the current generated is directly proportional to the turbo-starter rotor r.p.m.  
The three-phase current produced by the generator energizes the synchronous motor of the indicator. The motor r.p.m. is directly proportional to the current frequency. The rotary speed of the synchronous motor is measured by the indicator with the aid of an induction motor (Fig. 76).  
From the point of view of its operating principle and construction, tachometer TQ-45 does not differ from tachometer TQ-5-2 (See Fig. 75). The small pointer is fixed on a bushing put on the axle of the sensing element. Fitted on the end of this axle is the big pointer. The rotary motion of the small pointer is effected through the medium of four gears, reducing the angle of turn by 10 times.  
Arrangement of the transmitters and generators on the engine is illustrated in Fig. 77.

Total Fuel Flow Meter PTC-16  
PTC-16

The total fuel flow meter of the PTC-16 type is designed for measuring the amount of fuel consumed by the engine; it also serves to indicate the amount of fuel left in the aircraft tanks, provided the fuel lines are in proper condition and there is no fuel return to the tanks from the lines downstream of the fuel flow transmitter.

Fuel flow meter PTC-16 (Fig. 79) consists of a transmitter, indicator and a thyatron interrupter with a filter.

The aircraft is fitted with two fuel flow meter sets PTC-16. The transmitters are installed in the engine fuel lines, with the arrows on the bodies turned to the direction of fuel flow; the indicators are mounted on the pilots' middle instrument board; the thyatron interrupters are arranged on the navigator-radar operator starboard side.

Fuel flow meters PTC-16 are supplied with D.C. via circuit breakers ABC-2 mounted on the circuit breaker panel of the right-seat pilot. A.C. of 115 V, 400 c.p.s. is delivered to the instruments via glass tube safety fuses CH-2, accommodated in the navigator electric panel.

Main technical data of fuel flow meter PTC-16

Fuel flow meter PTC-16 is capable of operation, with fuel consumed at a rate of from 1200 to 16,000 lit./hr.

The reading error of the fuel flow meter set at normal operating conditions does not exceed 2.5%.

The reading error at a temperature of +50 and -60°C does not exceed 2.5% of the indicator scale rated value.

Pressure differential in the transmitter at maximum fuel consumption of 16,000 lit./hr and with the impeller running does not exceed 0.25 kg/sq.cm.; with the impeller inoperative the pressure differential amounts to not more than 0.4 kg/sq.cm.

The transmitter housing, as well as the pipe connection-to-housing joint are pressure-tight; they can withstand a pressure of 9 kg/sq.cm.

The fuel flow meter is capable of normal operation at vibration overloads of 4g (for the transmitter), 2.5g (for the thyatron interrupter), and 1.5g (for the indicator), with the frequency amounting to 20-80 c.p.s.

D.C. voltage	27 V ±10%
A.C. voltage	115 V ±10%, at 400 c.p.s.
Power consumed	40 W
Thyatron firing lag	100-200 millise.
Transmitter weight	800 gr
Indicator weight	650 gr
Thyatron interrupter weight	1100 gr



50X1-HUM

**Fuel flow meter indicator**

The indicator of fuel flow meter PTC-16 (Fig. 79) is essentially an electro-magnetic counter of pulses delivered by the fuel flow meter transmitter. The scale is calibrated in lit. of fuel. The measuring range is from 0 to 20,000 lit. The division value amounts to 50 lit.

The indicator mechanism consists of an electromagnetic relay, a reduction gear, and a pointer setting gear.

The sensing element of the indicator is represented by the electromagnet. Whenever the contacts of the transmitter relay are closed (that is every 30 revolutions of the impeller), the electromagnet core is attracted thereby turning the ratchet wheel by one tooth. The ratchet wheel motion is imparted through the series of gears to the pointer, which moves in the counter-clockwise direction.

The pointer setting gear (Fig. 80) allows the pointer to be set against any division of the scale, depending on the amount of fuel held by the aircraft tank groups.

After the aircraft has been refuelled, the indicator pointer should be set against the scale division, corresponding to the amount of fuel contained in the aircraft tanks. This is done by manipulating the pointer setting gear accommodated in the indicator and covered with a strip. The strip attachment screw is loosened and the strip is moved aside, then a screw-driver is fitted into the gear pin slot, and the pin is slightly pressed. This makes the gear engage the intermediate gear by rotating the screw-driver in the required direction the indicator pointer is set against the respective division of the scale.

**Thyatron interrupter**

The thyatron interrupter (Fig. 81) is composed of a power transformer, a thyatron, capacitors, resistors, and a voltage divider. All these components are electrically interconnected and mounted on a duralumin panel.

The power transformer serves for energizing the anode circuit (winding 40 V) and the filament circuit of the thyatron (winding 6.3 V).

The blocking capacitor rated for 10  $\mu$ F is designed for diverting the alternating component of the anode current from the indicator relay.

The capacitor rated for 1.0  $\mu$ F and the resistor rated for 126 kilohms are used to tune circuit A C within the grid circuit; the tuned circuit delays thyatron firing when the transmitter contacts are open.

Capacitors rated for 1  $\mu$ F and the resistors rated for 1 kilohm and 500 ohms are the decoupling elements of the filter, serving for elimination of the radio interferences in the wires running from the thyatron interrupter to the transmitter and to the aircraft D.C. main. The blocking capacitors rated for 1.0  $\mu$ F and 0.5  $\mu$ F are designed to suppress radio interferences in the wire running from the thyatron interrupter to the aircraft main rated at 115 V, 400 c.p.s.

The voltage divider is composed of two resistors rated for 400  $\Omega$  and 1000 ohms. It provides grid voltage of 3.4 V required for thyatron control, with the aircraft main voltage amounting to 27 V.

The vitrified resistor rated for 75 ohms is used for reducing the mean value of the anode current to 140 mA.

For connection to the transmitter, indicator and the A.C. power supply source, the thyatron interrupter is furnished with a five-pin plug connector; connection to the D.C. power supply source is accomplished through the use of a single-pin plug connector.

**Fuel flow meter transmitter**

The transmitter of fuel flow meter PTC-16 (Fig. 82) consists of a housing, guide vane assembly, an impeller, a reduction gear, a magnetic coupling, and contact-pulse mechanism.

The central part of the transmitter housing accommodates a guide vane assembly with an impeller and a worm reduction gear. The housing has two connections at the ends, having a clear opening of 42 mm in diameter. The connections are designed for installation of the transmitter in the fuel line of the engine.

The impeller has five blades. The impeller axle runs in ball bearings of stainless steel, accommodated in the guide vane assembly interior chamber. The middle portion of the axle is made in the form of a worm engaging the worm wheel which transmits the rotation of the impeller to the contact-pulse mechanism through the magnetic coupling.

The magnetic coupling consists of two permanent magnets. The driving magnet is rigidly secured at the end of the output shaft of the worm reduction gear, the driven magnet being mounted on the shaft of the contact-pulse mechanism cylindrical interrupter. The magnets are separated by the cover of the worm reduction gear chamber to prevent fuel from finding its way into the contact-pulse mechanism. The cover is fabricated from diamagnetic material.

The contact-pulse mechanism comprises a cylindrical interrupter, and two fixed platinum-iridium brushes.

Fuel entering the inlet connection flows through the guide vane assembly and actuates the impeller blades, set at a definite angle to the fuel flow. The speed of impeller rotation is proportional to the amount of fuel flowing through the transmitter housing. At the maximum rate of fuel consumption amounting to 2,000 lit/hr, the impeller develops a speed of 2400 r.p.m.

The impeller rotates the driving two-pole magnet through the worm drive (Fig. 83) providing for a reduction ratio of 1:30. The driving magnet actuates the driven magnet located above, outside the transmitter housing. Mounted on a common rim with the driven magnet is the cylindrical interrupter, contacting the fixed brushes. While turning through one revolution, the interrupter closes and opens twice the grid circuit of the thyatron, thereby delivering one pulse to the indicator relay. Each litre of fuel, flowing through the transmitter is equivalent to 0.3 pulses. The operating time of the indicator relay (time elapsing from the moment the contacts of the transmitter interrupter are opened to the moment the core of the indicator relay is attracted) amounts to about 150 milliseconds.

For adjustment of the impeller to a predetermined speed, the impeller proper and the enclosure, just are given a conical shape. To change the impeller speed, the impeller should be displaced in the axial direction. This changes the clearance between the blades and the housing. As the velocity of fuel flow is dependent on the passage area of the duct, the impeller will change its speed as well. With the impeller shifted towards the guide vane assembly, the fuel flow velocity will increase resulting in the increase of the impeller speed. If the impeller is moved away from the guide vane assembly, the fuel flow will slow down causing a reduction in the impeller speed.



50X1-HUM

Operating principle

The operating principle of the fuel flow meter (Fig. 84) is as follows. Fuel flowing through the fuel flow meter transmitter at a certain velocity imparts rotary motion to the impeller, whose speed is proportional to the fuel flow velocity and consequently to the amount of fuel conveyed through the transmitter.

The rotating impeller actuates the contact-pulse mechanism through the action of the reduction gear and the magnetic coupling. The contact system of the pulse mechanism will deliver one pulse to the thyatron grid each time the impeller turns 30 revolutions.


The anode circuit of the thyatron, using A.C. of 48 V, 400 c.p.s., supplied from the winding of the power transformer, incorporates the indicator relay. If a zero or positive potential is applied to the thyatron grid, supply voltage of 48 V is sufficient for firing the thyatron and energizing the indicator relay, blocked by the capacitor rated for 10  $\mu$ F.

If a negative potential of about 9 V is applied to the thyatron grid, anode voltage of 48 V will not be sufficient for firing the thyatron. In this case the thyatron will be blocked, as a result of which the anode current will be cut out thereby deenergizing the indicator relay.

The negative potential is delivered to the thyatron grid through the contacts of the pulse mechanism. With the contacts of the pulse mechanism open, the grid potential is equal to zero. This will make the thyatron fire; as a result, the indicator relay connected in the thyatron anode circuit will pick up, which produces a pulse. With the contacts of the pulse mechanism closed, the thyatron grid is supplied with a negative potential causing the thyatron to go out. The indicator relay will drop out thus making for a pause. When the impeller turns 30 revolutions, the interrupter of the pulse mechanism will make one complete revolution and will send one pulse to the indicator relay.

Thus, the number of indicator relay operations is proportional to the number of impeller revolutions, and consequently to the rate of fuel consumption. The indicator relay actuates the indicator pointer through the reduction gear. At any moment the pointer reads the amount of fuel left in the aircraft tanks (for the right and left engines). This amount is found as a difference between the amount delivered into the aircraft tanks and amount conveyed through the transmitter, that is consumed by the engine.

The description of the instrument measuring the amount of fuel is given in Chapter II.



NO FOREIGN DISSEM

— 72 —

## Operating principle

The operating principle of the fuel flow meter (Fig. 84) is as follows. Fuel flowing through the fuel flow meter transmitter at a certain velocity imparts rotary motion to the impeller, whose speed is proportional to the fuel flow velocity and consequently to the amount of fuel conveyed through the transmitter.

The rotating impeller actuates the contact-pulse mechanism through the medium of the reduction gear and the magnetic coupling. The contact system of the pulse mechanism will deliver one pulse to the thyatron grid each time the impeller turns 30 revolutions.


The anode circuit of the thyatron, using A.C. of 48 V, 400 c.p.s., supplied from the winding of the power transformer, incorporates the indicator relay. If a zero or positive potential is applied to the thyatron grid, supply voltage of 48 V is sufficient for firing the thyatron and energizing the indicator relay, blocked by the capacitor rated for 10  $\mu$ F.

If a negative potential of about 5 V is applied to the thyatron grid, anode voltage of 48 V will not be sufficient for firing the thyatron. In this case the thyatron will be blocked, as a result of which the anode current will be cut out thereby deenergizing the indicator relay.

The negative potential is delivered to the thyatron grid through the contacts of the pulse mechanism. With the contacts of the pulse mechanism open, the grid potential is equal to zero. This will make the thyatron fire; as a result, the indicator relay connected in the thyatron anode circuit will pick up, which produces a pulse. With the contacts of the pulse mechanism closed, the thyatron grid is supplied with a negative potential causing the thyatron to go out. The indicator relay will drop out thus making for a pause. When the impeller turns 30 revolutions, the interrupter of the pulse mechanism will make one complete revolution and will send one pulse to the indicator relay.

Thus, the number of indicator relay operations is proportional to the number of impeller revolutions, and consequently to the rate of fuel consumption. The indicator relay actuates the indicator pointer through the reduction gear. At any moment the pointer reads the amount of fuel left in the aircraft tanks (for the right and left engines). This amount is found as a difference between the amount delivered into the aircraft tanks and amount conveyed through the transmitter, that is consumed by the engine.

The description of the instrument measuring the amount of fuel is given in Chapter II.



50X1-HUM

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




Fig. 5. Fuel Jetison System. System for Aircraft Refuelling in Flight  
 1 - panel mounting electric equipment for refuelling control; 2 - compressed air line for fuel jetison control; 3 - fuelling valves of tanks No. 2 and No. 3; 4 - fuel pressure warning unit (C.F.F.); 5 - fuelling valves of tanks No. 4 and No. 5; 6 - control panels of right-seat and left-seat pilots; 7 - fuel jetison control valve; 8 - pneumatic switch; 9 - fuelage valve for fuel jetison line; tanks No. 1 and No. 2; 10 - main fuel system pipeline from pumps of tank No. 2; 11 - main fuel system pipeline from pumps of tank No. 3; 12 - fuelage valve for fuel jetison from tank No. 3; 13 - fuel jetison valve; 14 - fuel jetison valve; 15 - fuel jetison valve (cock); 16 - pipeline for aircraft refuelling in flight; 17 - pipeline terminal branch.




Fig. 6. CFTU-603 Fuel Lounge Set  
 1 - measuring equipment amplifiers 3Y1-2B; 2 - fuel gauge indicators; 3 - fuel gauge selector switches (1 - 2); 4 - transmitter (main); 5 - additional transmitter; 6 - fuel consumption control unit amplifiers 3Y1-2B-3.

50X1-HUM

SECRET  
NO FOREIGN DISSEM



NO FOREIGN DISSEM

50X1-HUM




Fig. 2. Main Fuel System Key Diagram

- 1 - fuel cross-feed valve; 2 - booster pump 3M1; 3 - electric fuel jetison valve; 4 - main fuel jetison valve;
- 5 - main dump valve (for left and right tank groups); 6 - fuel shut-off valve; 7 - low-pressure pumps (booster pumps [I]-[IA]); 8 - transmitters of fuel flow meters PTCG19-CM; 9 - cooler oil cooler (unit 62); 10 - fuel filter; 11 - high-pressure fuel pumps [II]-[25]; 15 (of plunger type); 16 - fuel filter; 17 - fuel filter; 18 - booster pump 3M1; 19 - fuel and water drain cock of tank group.




Fig. 3. Fuel Shut-Off Valve  
 1 - electric mechanism NEK-2; 2 - valve axle; 3 - valve housing; 4 - valve lever; 5 - valve.




Fig. 4. Fuel Cross-Feed Valve  
 1 - electric mechanism NEK-2; 2 - valve axle; 3 - valve housing; 4 - valve lever; 5 - valve.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM




Fig. 7. Accompanying Sketch for Determining Capacitance between Two Flat Plates




Fig. 8. Accompanying Sketch for Determining Capacitance of Cylindrical Capacitor




Fig. 9. Accompanying Sketch for Changing of Capacitance between Flat Plates Immersed into Vessel with Kerosene




Fig. 10. Diagram of Self-Balancing Bridge  
1 - power transformer; 2 - rectifier valve 61YC; 3 and 10 - amplifier valves 61SC; 4 - amplifier valve 61TC; 5 - output transformer; 6 - variable capacitance transducers; 7 and 11 - fixed capacitors; 8 - switch; 9 and 12 - adjusting resistors; 13 - electric motor 230T-0.5; accommodated in indicator; 15 - indicator printer.

S-E-C-R-E-T  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM




Fig. 11. Changing of Currents in Windings of Electric Motor  
 $\mu_{\text{H}} \cdot 0.5$   
 A and B - current curves of respective windings; a, b, c, d, e - time moments.




Fig. 12. Changing of Signal Phase




Fig. 13. Mechanical Diagram of Fuel Gauge Indicator  
 1 - induction motor, 0.12-0.3; 2 - thermostat; 3 - reduction gear train;  
 4 - thermostat slide; 5 - indicator pointer; 6 - contacts; 7 - indicator dial drive; 8 - reduction gear train hand shaft; 9 - plug connector.




Fig. 14. Fuel Gauge Indicator without Housing and with Housing




Fig. 15. Fuel Gauge Measuring Equipment Amplifier (with Housing Removed)  
 1 - mounting frame; 2 - front panel; 3 - thermostats rated for 2 Kilohms;  
 4 - relay 11-B; 5 - power transformer.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM




Fig. 16. Fuel Gauge Measuring Equipment Amplifier (in Housing)  
1 - negative wire; 2 - shock absorber; 3 - rheostat rated for 2 kilohms; 4 - button "Total Average Check-Up" (Полное среднее); 5 - button "Group Check-Up" (Групповая проверка); 6 - three-pin plug connector; 7 - variable plug connector; 8 - safety fuse; 9 - amplifier housing; 10 - bed plate.




Fig. 17. Fuel Gauge Measuring Equipment Amplifier with Bottom Plate Removed  
1 - output transformer; 2 - relay [11-3]; 3 - valve 615C; 4 and 6 - valves 615A; 5 - valve 615C.




Fig. 18. Fuel Gauge Transmitter Tube Connection Diagram



Fig. 19. Sectional View of Fuel Gauge Transmitter  
1 - head; 2 - flange; 3 - profiled tube; 4 - signaling unit coil; 5 - float; 6 - guiding tube; 7 - plug connector; 8 - earthing screw; 9 - gasket.




Fig. 20. Fuel Gauge Transmitter, Disassembled  
1 and 2 - flanges; 3 - profiled tube; 4 - signaling unit coils; 5 - inserts; 6 - flange; 7 - outer tube.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM




Fig. 21. Attachment of Fuel Gauge Transmitter to Fuel Tank  
1 - transmitter; 2 - tank flange; 3 - bolt fastening transmitter to tank flange; 4 - bolt fastening flange to frame.




Fig. 22. Attachment of Fuel Gauge Transmitters to Fuselage Tanks No. 2, No. 4, and No. 5  
1 - transmitter; 2 - sleeve; 3 - spring; 4 - tank flange.




Fig. 23. Rotary Selector Switch ПГ-7  
a - in casing; b - with casing removed.




Fig. 24. Diagram of Rotary Selector Switch ПГ-7 in OFF (Выключено) Position




Fig. 25. Diagram of Rotary Selector Switch ПГ-7 in "Total" (Сумма) Position





Fig. 26. Diagram of Rotary Selector Switch ПГ-7 when Checking Fuel in 1st Group Tanks

SECRET  
NO FOREIGN DISSEM


NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM



SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM




Fig. 27. Cabling and Wiring Diagram of Fuel Gauge C/TIC-68D

1 - switch 2111 250 connecting voltage supply to fuel gauge of left engine tank; 2 - left engine tank fuel gauge rotary selector switch (from C/TIC-68D sect. 3); 3 - left engine tank fuel gauge indicator; 4 - amplifier of left engine tank fuel gauge (on 2nd navigator right rack); 5 - fuel gauge transmitter of left tank No. 6 (group IV); 6 - fuel gauge transmitter of left tank No. 12 (group IV, additional); 7 - fuel gauge transmitter of left tank No. 10 (group III); 8 - fuel gauge transmitter of left tank No. 7 (group VI); 9 - fuel gauge transmitter of tank No. 4 (left engine group IV); 10 - fuel gauge transmitter (group VI); 11 - fuel gauge transmitter (additional) of left engine tank No. 6 (group VI); 12 - fuel gauge transmitter (additional) of left engine tank No. 6 (group VI); 13 - fuel gauge transmitter (additional) of right engine tank No. 6 (group VI); 14 - fuel gauge transmitter (additional) of right engine tank No. 5 (right engine group III); 15 - fuel gauge transmitter (additional) of tank No. 3 (right engine group III); 16 - fuel gauge transmitter of right engine tank (additional) of tank No. 12 (group IV); 17 - fuel gauge transmitter of right engine tank (additional) of tank No. 10 (group III); 18 - fuel gauge transmitter of right engine tank (additional) of tank No. 7 (group VI); 19 - fuel gauge transmitter of right engine tank No. 12 (group IV); 20 - fuel gauge transmitter of right engine tank No. 10 (group III); 21 - fuel gauge transmitter of right engine tank No. 7 (group VI); 22 - right engine tank fuel gauge rotary selector switch (from C/TIC-68D sect. 3); 23 - fuel gauge indicator of right engine tank; 24 - amplifier of right engine tank fuel gauge (on 2nd navigator right rack); 25 - switch 2111 250 connecting voltage supply to right engine tank fuel gauge.

SECRET  
NO FOREIGN DISSEM



50X1-HUM





Fig. 29. Key Diagram of Fuel Gauge C7TC-60J and Fuel Consumption Control Units  
6 - indicator of fuel gauge C7TC-60J; 7 - measuring equipment amplifier ST-58; 8 - zero setting check button KR-6A; 9 - switch ZFI-250 for connection of measuring equipment system; 10 - relay PTI-5; 11 - indicator relay switch IU-7; 12 - switch ZFI-250 for carriage automatic equipment system controlling fuel measuring equipment system; 13 - relay PTI-5; 14 - indicator lamp CB-51 (blue) - 4 pieces; 15 - pilot lamp CRI-51 indicates "Fuel remaining for 30 min." (TDR-2000 No. 30-400-1); 16 - pilot lamp CRI-51 indicating "Fuel remaining for 15 min." (TDR-2000 No. 15-400-1); 17 - switch B-45; 18 - fuel pump control equipment amplifier VAF-52; 19 - pilot lamp CB-51 (blue) - 4 pieces; 20 - fuel pump pilot lamp CRI-51 - 12 pieces; 21 - stand-by pump switch ZF-43; 22 - button "Group manual control circuit breaker"; 23 - blocking relay PTI-5; 24 - fuel pump pilot lamp CRI-51 - 12 pieces; 25 - relay PEG - 8 pieces; 26 - relay PEG - 45; 27 - transmitter - Checklog" = EB-6A; 28 - button "Total Amount Check-Up" - KR-6A; 29 - relay PTI-5; 30 - relay PEG - 8 pieces; 31 - signaling unit of automatic equipment controlling refueling valves; 32 - signaling units of automatic fuel pump control; 33 - fuel transfer pump IH-45T; 34 - pump NH-T-12 pieces; 35 - adjusting resistors 36 - connector V-50J - 12 pieces; 37 - capacitor KEM-31 - 14 pieces; 38 - blocking relay PTI-2 - 10 pieces; 39 - release NO-10-5 - 8 pieces; 40 - signaling unit C7-3TV - 12 pieces; 41 - parametrically operated switch; 42 - blocking relay PTI-2.

S-E-C-R-E-T  
NO FOREIGN DISSEM




50X1-HUM



S-E-C-R-E-T  
NO FOREIGN DISSEM




50X1-HUM



S-E-C-R-E-T  
NO FOREIGN DISSEM

~~SECRET~~  
NO FOREIGN DISSEM



50X1-HUM

Fig. 29. Adjusting Fuel Gauge against Scale Reference Settings




Fig. 30. Tester WHITE-1 with Cover Hinged Off

~~SECRET~~  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM




Fig. 31. View on Right Wall of Tester YNTE-1




Fig. 32. View on Left Wall of Tester YNTE-1




Fig. 33. YNTE-1 Tester Circuit for Checking Fuel Quantity Transmitters  
1 - ferrospenic frequency meter IV; 2 - ferrospenic voltmeter IV; 0.150; 3 - capacitance meter IZ; 53; 4 and 5 - chassis rated for 1.5 kilohms; 6 - resistor IIC-1-1-1000; 7 - resistor IIC-0.5-1-0.2; 8 and 10 - capacitor NMT-1-1-100-2 (20 pF); 9 - resistor MTT-2-1000; 11 - resistor MTT-0.5-100; 12 - resistor IIC-0.5-1-0.2; 13 - capacitor consisting of KLO-5 and KCO-2 (10,000 pF); 14 and 15 - resistors IIC-0.5-1-0.2; 16 and 18 - capacitors KCO-5 (500 pF); 17 - button KIB-64; 19 - resistor IIC-0.25-1-0.31 (510 kilohms); 20 - capacitor base; 21 - capacitor NMT-1-3-250-0.25 (0.25 pF).

SECRET  
NO FOREIGN DISSEM



50X1-HUM




Fig. 34. VITE-1 Tester Circuit for Checking Fuel Quantity Indicators




Fig. 35. VITE-1 Tester Circuit for Checking Signalling Lamps





Fig. 36. Fuel Supply Panel



50X1-HUM




Fig. 37. Key Diagram of Unbalanced Bridge




Fig. 40. Performance Curves of Pump 3111-T  
 $P = f(Q)$  and  $I = f(Q)$




Fig. 38. Attachment of Pump 3111-T to Fuel Tank  
 1 - flange collar; 2 - gasket; 3 - tank connection; 4 - bolt fastening pump to tank flange; 5 - outlet pipe connection; 6 - tank flange; 7 - bolts securing flange to frame; 8 - pump impeller; 9 - slinger; 10 - drain pipe; 11 - electric motor MB-650T.






Fig. 39. Diagram of Electric Motor MB-650T (Commutator End View)  
 H<sub>1</sub>, H<sub>2</sub>, H<sub>3</sub>, and H<sub>4</sub> - winding taps; K<sub>1</sub>, K<sub>2</sub>, K<sub>3</sub>, and K<sub>4</sub> - winding taps; L, M, N, O, P, Q, R, S, T, U, V, W, X, Y, Z - plug connector terminals. The motor is designed for 15 ohm series for factory adjustment of electric motor speed.

NO FOREIGN DISSEM



50X1-HUM




SECRET  
NO FOREIGN DISSEM



~~SECRET~~  
NO FOREIGN DISSEM




50X1-HUM



SECRET  
NO FOREIGN DISSEM


SECRET  
NO FOREIGN DISSEM

50X1-HUM



SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM

Fig. 43. Cable and Wiring Diagram of Fuel Consumption Control Units



SECRET  
NO FOREIGN DISSEM


NO FOREIGN DISSEM

Fig. 43. Cable and Wiring Diagram of Fuel Consumption Control Units

1 - switch ZBI-250 for left amplifier of fuel consumption control unit; 2 - fuel consumption control unit left amplifier VAT-52-5 (frame No. 22); 3 - circuit breaker A3C-5 switch for manual control of fuel consumption; 4 - switch B-45 for fuel consumption control (automatic - manual); 5 - fuel gauge transmitter of left tank No. 16 (group IV); 6 - fuel gauge transmitter of left tank No. 10 (group III); 7 - fuel gauge transmitter of left tank No. 7 (group III); 8 - fuel gauge transmitter of left tank No. 4 (group II); 9 - fuel gauge transmitter of left tank No. 2 (group I); 10 - fuel gauge transmitter (main) of left tank No. 6 (group V); 12 - fuel consumption control relay PI-6 (automatic - manual); 13 - switch ZBI-250 for fuel consumption control unit right amplifier; 14 - fuel gauge transmitter (main) of right tank No. 6 (group V); 15 - fuel gauge transmitter of right tank No. 5 (group II); 16 - fuel gauge transmitter (additions) of left tank No. 3 (group II); 17 - fuel gauge transmitter (main) of right tank No. 3 (group II); 18 - fuel gauge transmitter of right tank No. 7 (group III); 19 - fuel gauge transmitter of right tank No. 10 (group IV); 20 - fuel gauge transmitter of right tank No. 12 (group IV); 21 - fuel gauge transmitter of right tank No. 16 (group IV); 22 - pilot lamps CIII-51 indicating order of fuel consumption from individual tank groups; 23 - double feed bus bar; 24 - left engine distribution panel; 25 - right engine distribution panel; 26 and 27 - pilot lamps CIII-51 indicating that fuel reserve is for 30 min. of flight; 28 and 29 - pilot lamps CIII-51 indicating that fuel reserve is for 15 min. of flight; 30 - fuel consumption control unit right amplifier VAT-52-5 (frame No. 22); 31 - relay K-25A controlling fuel transfer pump of left tank No. 19; 32 - capacitor KBM-31; 33 - fuel pump left distribution box (frame No. 33); 34 - relay K-50L controlling fuel

pump of left tank No. 10; 35 - relay PI-2 controlling augmented duty of fuel pump of left tank No. 10; 36 - resistor KO-10-5 of fuel pump of left tank No. 10; 37 - fuel pump ZBI-T of left tank No. 10 (group III); 38 - relay K-50L of fuel pump of tank No. 2; 39 - relay PI-2 controlling augmented duty of fuel pump of tank No. 2; 40 - resistor KO-10-5 of fuel pump of tank No. 2; 41 - fuel pump ZBI-T of left tank No. 2 (group I); 42 - relay K-50L of fuel pump of tank No. 3; 43 - relay PI-2 controlling augmented duty of fuel pump of tank No. 3; 44 - resistor KO-10-5 of fuel pump of tank No. 3; 45 - fuel pump ZBI-T of right tank No. 3 (group II); 46 - relay K-50L of fuel pump of left tank No. 20 (installed in 5 aircraft of 3rd series); 47 - resistor KO-10-5 of fuel pump of left tank No. 20 (installed in 5 aircraft of 3rd series); 48 - fuel pump distribution box (frame No. 49); 49 - relay K-50L of fuel pump of right tank No. 20 (installed in 5 aircraft of 3rd series); 50 - resistor KO-10-5 of fuel pump of right tank No. 20 (installed in aircraft of 3rd series); 51 - fuel pump right distribution box (frame No. 33); 52 - relay K-50L of fuel pump of tank No. 4; 53 - relay PI-2 controlling augmented duty of fuel pump of tank No. 4; 54 - resistor KO-10-5 of fuel pump of tank No. 4; 55 - fuel pump ZBI-T of left tank No. 4 (group II); 56 - relay K-50L of fuel pump of tank No. 5; 57 - relay PI-2 controlling augmented duty of fuel pump of tank No. 5; 58 - resistor KO-10-5 of fuel pump of tank No. 5; 59 - fuel pump ZBI-T of right tank No. 5 (group II); 60 - relay K-50L of fuel pump of right tank No. 10; 61 - relay PI-2 controlling augmented duty of fuel pump of right tank No. 10; 62 - resistor KO-10-5 of fuel pump of right tank No. 10; 63 - fuel pump ZBI-T of right tank No. 10 (group III); 64 - relay K-25A of fuel transfer pump of right tank No. 19; 65 - right-ear pilot circuit breakers panel; 66 - relay K-50L of fuel pump of left tank No. 16; 67 - relay PI-2 controlling augmented duty of


fuel pump of left tank No. 16; 68 - fuel pump ZBI-T of left tank No. 16 (group IV); 69 - switch ZBI-45 for reading on stand-by pumps; 70 - relay K-50L of fuel pump of right tank No. 16; 71 - relay PI-2 controlling augmented duty of fuel pump of right tank No. 16; 72 - fuel pump ZBI-T of right tank No. 16 (group IV); 73 - relay K-50L of fuel pump of left tank No. 6; 74 - fuel pump ZBI-T of left tank No. 6; 75 - navigator upper electric panel; 76 - relay K-50L of fuel pump of right tank No. 6; 77 - fuel pump ZBI-T of right tank No. 6; 78 - fuel emergency jetison blocking contact (at frame No. 22); 79 - relay PI-2 controlling fuel emergency jetison; 80 - relay K-50L of booster fuel pump of tank No. 2; 81 - relay PI-2 controlling augmented duty of booster fuel pump of tank No. 2; 82 - resistor KO-10-5 of booster fuel pump of tank No. 2; 83 - booster fuel pump ZBI-T of tank No. 2; 84 - relay K-50L of booster fuel pump of tank No. 5; 85 - relay PI-2 controlling augmented duty of booster fuel pump of tank No. 5; 86 - resistor KO-10-5 of booster fuel pump of tank No. 5; 87 - booster fuel pump ZBI-T of right tank No. 5; 88 - crew commander (left 21er) instrument panel; 89 - landing gear and fuel pump relay distribution box (in right landing gear well); 90 - landing gear and fuel pump relay distribution box (in left landing gear well); 91 - fuel gauge distribution box (at frame No. 22); 92 - fuel pump distribution box (at frame No. 49); 93 - distribution box of booster fuel pump of tank No. 5 (beginning from 3rd aircraft of 1st series and ending with 5 aircraft of 3rd series); 94 - plug connector DTZBKH-710.5; 95 - fuel gauge distribution box (frame No. 22); 96 - plug connector DTZBKH-710.5; 97 - distribution box of booster fuel pump of tank No. 5 (beginning from 3rd aircraft of 1st series and ending with 5 aircraft of 3rd series); 98 - pilot upper electric panel; 99 - plug connector DTZBKH-710.2 No. 10; 100 - plug connector DTZBKH-710.1.



50X1-HUM

NO FOREIGN DISSEM

50X1-HUM



SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 46. Cable and Wiring Diagram of Fuel Pump Signaling System

- 1 - pilot lamp CH1-S1 indicating fuel pump operation; 2 - pilot upper electric panel; 3 - signaling unit CA-TTY indicating operation of fuel pump of left tank No. 1; 4 - signaling unit CA-TTY indicating operation of fuel pump of left tank No. 16; 5 - signaling unit CA-TTY indicating operation of fuel pump of left tank No. 2; 6 - signaling unit CA-TTY indicating operation of fuel pump of left tank No. 7; 7 - right pilot circuit breaker panel; 8 - signaling unit CA-TTY indicating operation of fuel pump of left tank No. 4; 9 - signaling unit CA-TTY indicating operation of fuel pump of tank No. 5; 10 - fuel pump left distribution box (see frame No. 33); 11 - signaling unit CA-TTY indicating operation of fuel pump of right tank No. 6; 12 - signaling unit CA-TTY indicating operation of fuel pump of right tank No. 13; 13 - signaling unit CA-TTY indicating operation of fuel pump of right tank No. 16; 14 - loading gear and fuel pump relay distribution box; 15 - signaling unit CA-TTY indicating operation of fuel pump of right tank No. 16; 16 - fuel pump distribution box (see frame No. 43); 17 - signaling unit CA-TTY indicating operation of booster fuel pump of tank No. 2; 18 - signaling unit CA-TTY indicating operation of booster fuel pump of tank No. 3; 19 - right distribution box (see frame No. 12); 20 - fuel pump right distribution box (see frame No. 33); 21 - loading gear and fuel pump relay distribution box (right loading gear - left); 22 - fuel pump No. 12; 23 - plug connector EP301R102 15; 24 - fuel supply header.

Notes: 1. Signal CH1-S1 and CH1-S2 are interlocked signaling units CA-TTY and pilot lamps CH1-S1 and CH1-S2 indicating operation of fuel pumps of tank No. 19 are covered on sketch sheet with tank No. 17, No. 16, and No. 19 in accordance with special instructions.  
2. Wires CH1-S1, CH1-S2 are interlocked. Signaling units CA-TTY and pilot lamps CH1-S1 and CH1-S2 indicating operation of fuel pumps of tank No. 16, as well as pilot lamp CH1-S1.  
3. Figure 46a shows pilot lamps No. 20 in accordance with special instructions.  
4. Figure 46b shows pilot lamps No. 20 in accordance with special instructions.  
5. Pilot lamps indicate direction of fuel pump etc. per instructions.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM





Fig. 44. Cable and Wiring Diagram of Fuel Pump Signalling System  
1 - pilot lamp C11-51 indicating fuel pump operation; 2 - pilot upper electric panel; 3 - signalling unit C12-3TY indicating operation of fuel pump of left tank No. 16; 4 - signalling unit C12-3TY indicating operation of fuel pump of left tank No. 10; 5 - signalling unit C12-3TY indicating operation of fuel pump of left tank No. 4; 6 - signalling unit C12-3TY indicating operation of fuel pump of left tank No. 4; 7 - right pilot circuit breaker panel; 8 - signalling unit C12-3TY indicating operation of fuel pump of right tank No. 6; 9 - signalling unit C12-3TY indicating operation of fuel pump of right tank No. 3; 10 - fuel pump left distribution box (on frame No. 33); 11 - signalling unit C12-3TY indicating operation of fuel pump of right tank No. 16; 12 - signalling unit C12-3TY indicating operation of fuel pump of right tank No. 16; 13 - signalling unit C12-3TY indicating operation of fuel pump of right tank No. 16; 14 - signalling unit C12-3TY indicating operation of fuel pump of right tank No. 16; 15 - loading gear and fuel pump relay distribution box (left); 16 - fuel pump distribution box (on frame No. 49); 17 - signalling unit C12-3TY indicating operation of fuel pump of right tank No. 2; 18 - signalling unit C12-3TY indicating operation of fuel pump of right tank No. 2; 19 - right distribution box (on frame No. 17); 20 - fuel pump right distribution box (on frame No. 33); 21 - loading gear and fuel pump relay distribution box (right); 22 - fuel pump relay distribution box (right); 23 - plug connector EP2810, TM15; 24 - dual supply busbar.

SECRET  
NO FOREIGN DISSEM



NO FOREIGN DISSEM

50X1-HUM



SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 45. Adjusting Fuel Consumption Automatic Control Equipment




Fig. 46. Key Diagram of Fuel Gauge C3TC-60M Automatic Equipment Bridge

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM




Fig. 47. Electric Diagram of Fuel Gauge C3TC-60N Automatic Equipment  
 1 - plug connector (IP22V12(1)); 2 - plug connector (IP22V12(1)); 3 - transformer; 4 - tube fuse (IK-45); 5, 6, 7, 8, 9, 10, 11, and 12 - rheostat  
 13, 14, 15, 16, 17, 18, 19, and 20 - coils; 21, 22, 23, 24, 25, 26, 27, and 28 - selenium rectifiers; 29, 30, 31, 32, 33, 34, 35, and 36 - electromagnetic  
 relays; 37 and 38 - relays.




Fig. 48. Automatic Equipment Unit BAC-52-12. Front View  
 1 - rheostat axles; 2 - safety fuse; 3 - twelve-pin plug connectors; 4 - housing; 5 - mounting plate; 6 - shock absorbers; 7 - bonding strip.





Fig. 49. Automatic Equipment Unit BAC-52-12. Rear View (with Housing Removed)  
 1 - mounting frame; 2 - front panel; 3 - relay PNC-2; 4 - sensitive electromagnetic relays; 5 - coils; 6 - rheostats; 7 - relay PNC-2.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM




Fig. 52. Measur. 1 and 2 - transformers; 3, 4, 5 and 16, 17, 18, 19, 20, 21, 22, 23, 24, rheostats; 46 - capacitor; 47 - c

SECRET NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM




Fig. 50. Automatic Equipment Unit SAC-52-12. Under-view (with Housing Removed). 1 - sensitive electromagnetic relay; 2 - selenium rectifier; 3 - transformer.




Fig. 51. Key Diagram of Self-Balancing Bridge




Fig. 52. Measuring Equipment of Fuel Gauge CSTC-60M. Circuit Diagram  
1 and 2 - transformers; 3, 4, 5 and 6 - valves; 7 and 8 - relays; 9 - coil; 10 and 11 - buttons; 12 and 13, 31 and 32 - plug connectors; 14 - micro fuse; 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27 - capacitors; 28 - coil; 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, and 41 - resistors; 42, 43, 44, and 45 - rheostats; 46 - capacitor; 47 - coils; 48 - button; 49 - chassis; 50 - electric meter.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM





Fig. 53. General View of Amplifier 3T-BRM in Housing  
1 - shock absorber 271c-49-2-6; 2 - bonding wire; 3 - rheostat axes; 4 - mounting plate; 5 - button "Group Check-Up"; 6 - three-pin plug connector; 7 - twelve-pin plug connector; 8 - safety fuse; 9 - amplifier housing; 10 - button "Total Amount Check-Up".




Fig. 54. Amplifier 3T-BRM with Housing Removed (Rear View)  
1 - mounting frame; 2 - front panel; 3, 4, 5 and 6 - valves; 7, 8, 9 and 10 - rheostats; 11 and 12 - capacitors; 13 - valve panels; 14 - resistor.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM





Fig. 55. Amplifier YT-RBN with Housing Removed (Underside View)  
1 - mounting frame; 2 - capacitor panel; 3, 4, 5, 6, 7, 8, 9, 10, 11, and 12 - capacitors; 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, and 24 - resistors; 25 - capacitor.



SYMBOLS  
— see ERM, dir. 6.19 - 6  
I see ERM, dir. 6.19 - 6.9


Note 1. Size 081  
2. Noting soldered wt.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM



Amplifier YT-88M with Housing Removed (Underside View)  
Wiring (1) - 2 - capacitor (see 1); 3, 4, 5, 6, 7, 8, 9, 10, 11, and 12 - resistors; 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, and 24 - resistors; 25 - capacitor.




Fig. 56. Interconnection Diagram of Fuel Gauge CTC-60N  
1. 1/16 in. 1/2 wire shields should not have longitudinal seams.  
2. Having soldered wires to plug connectors of transmitters, fill the latter with ceresote (1 to 7°C).

SECRET  
NO FOREIGN DISSEM



SECRET

NO FOREIGN DISSEM

50X1-HUM





Fig. 57. Diagram of Transformer (I)  
Transformer characteristics:  
Winding I - voltage 115 V; magnet wire ПБВ-2, dia. 0.3 mm; number of turns - 285.  
Winding II - voltage 400 V; magnet wire ПБВ-2, dia. 0.3 mm; number of turns - 1100, with 550 turns tapped.  
Winding III - voltage 22 V; magnet wire ПБВ-2, dia. 0.12 mm; number of turns - 55, with 24, 33, and 38 turns tapped.  
Winding IV - voltage 0.3 V; wire ПБВ-2, dia. 0.15 mm; number of turns - 16.  
Winding V - voltage 0.3 V; wire ПБВ-2, dia. 0.15 mm; number of turns - 16.




Fig. 58. Diagram of Transformer (II)  
Transformer characteristics:  
Winding I - magnet wire ПБВ-2, dia. 0.12 mm; number of turns - 7000.  
Winding II - magnet wire ПБВ-2, dia. 0.15 mm; number of turns - 450.




Fig. 59. Diagram of Transformer (III)  
Transformer characteristics:  
Winding I - magnet wire ПБВ-2, dia. 0.35 mm; number of turns - 380.  
Winding II - magnet wire ПБВ-2, dia. 0.35 mm; number of turns - 120.

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

50X1-HUM




Fig. 60. External View of Tester 311A-53-60 (with Cover Removed).  
 1 - housing; 2 - cover; 3 - simulator knobs serving for changing inductance (8 pieces); 4 - pilot lamps for checking voltage; 5 - pilot lamps for checking automatic equipment operation; 6 - indicator for checking signaling unit for proper functioning; 7 - terminals for connection of power supply.




Fig. 61. Checking Automatic Equipment Bridge.  
 Key Diagram  
 P - relay; 1, 2, 3 - relay contacts; e - pilot lamp;  
 Yp - transformer; L - constant inductance; L<sub>1</sub> - variable inductance; R<sub>1</sub> and R<sub>2</sub> - resistors;  
 K - core.




Fig. 63. Circuit Diagram of Tester 311A-53-60  
 1, 2, 3, 4, 5, 6, 7, and 8 - coils (simulating devices); 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21 - pilot lamps (M-30); 22 - resistor (R-20-60); 23 and 31 - relay (R-1); 24 - relay (R-1); 25 - transformer; 26 and 27 - maximum resistance rated for 1500 ohms; 28 - selenium rectifier (R-18-1); 29 - resistor (R-10-100); 30 - indicator (indicator R-100); 31 - inductance coil with iron core; 32 - inductance coil without iron core; 34 and 35 - switches; 36, 37, and 38 - plug connectors.




Fig. 62. Checking Transmitter Signaling Units.  
 Key Diagram  
 1 and 2 - switch contacts; h<sub>1</sub> and h<sub>2</sub> - constant coils; L<sub>1</sub> and L<sub>2</sub> - constant inductances; L - variable inductance; 11 - indicator; T<sub>p</sub> - transformer.

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 67. Diagram of Oil Pressure Gauge Operation at Various Positions of Potentiometer Moving Contact  
 a - direction of resultant magnetic field vector and indicator rotor with no pressure applied to diaphragm of transmitter; b - direction of resultant magnetic field vector and indicator rotor when pressure applied to diaphragm of transmitter 1/10 amounts to half of maximum pressure; c - direction of resultant magnetic field vector and indicator rotor with maximum pressure applied to diaphragm of transmitter  
 П-10; K<sub>1</sub> and K<sub>2</sub> - fixed coils; R<sub>1</sub>, R<sub>2</sub>, R<sub>3</sub>, R<sub>4</sub>, and R<sub>5</sub> - resistors; AHC - potentiometer; ED - semi-diagonal.




Fig. 68. Key Diagram of Oil Thermometer  
 I and II - loops; R<sub>1</sub>, R<sub>2</sub>, R<sub>3</sub>, R<sub>4</sub>, R<sub>5</sub>, R<sub>6</sub>, and R<sub>7</sub> - resistors.




Fig. 69. Vector Diagram of Oil Thermometer Logometer Magnetic Fluxes




Fig. 70. Key Diagram of Pressure Gauge  
 3.33A - 3

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




Fig. 71. Diagram of 32411-3 Operation at Various Positions of Potentiometer Moving Contact

$\epsilon = 0.1$ ;  $b = 0.5$ ;  $P_{max.} = 1$ ;  $\epsilon - p = P_{max.}$




Fig. 72. Circuit Diagram of Thermometer THF-11



50X1-HUM




Fig. 73. Circuit Diagram of Thermometer TCT-20




Fig. 74. External View of Pressure Warning Mechanism C21-24A

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 75. Key Diagram of Tachometer TD-5-2  
 1 - generator rotor; 2 - generator stator; 3 - hysteresis disc; 4 - permanent magnet; 5 - synchronous motor stator; 6 - sensing element; 7 - magnet assembly; 8 - hair spring; 9 - damper disc; 10 - damper; 11 - pointer; 12 - scale.




Fig. 76. Diagram of Tachometer TD-45 Indicator  
 1 - permanent magnet; 2 - iron screen; 3 - duralumin holder; 4 - thermomagnetic abutment; 5 - sensing element.





Fig. 77. Diagram Showing Arrangement of Transmitters and Generators on Engine  
 1 - transmitter TCT-28; 2 - tachometer generator TD-45; 3 - oil pressure transmitter MM-3P; 4 - fuel pressure transmitter MM-3P; 5 - fuel pressure transmitter MM-3P; 6 - plug connector of tachometer generator TD-45; 7 - tachometer generator TD-5-2; 8 - oil temperature transmitter MM-3P; 9 - thermometer transmitter TBT-11; 10 - engine.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




Fig. 78. External View of Fuel Flow Meter Set PTC-16  
A - transmitter; B - indicator; C - thyatron interrupter.




Fig. 80. Indicator of Fuel Flow Meter PTC-16  
1 - strip; 2 - pointer setting gear.




Fig. 79. Indicator of Fuel Flow Meter PTC-16  
Mechanical Diagram  
1 - electromagnetic relay; 2 - driving pawl; 3 - ratchet wheel; 4 - retaining pawl; 5 - eccentric; 6 - return spring; 7 - reduction gear; 8 - pointer setting gear.





Fig. 81. Thyatron Interrupter  
1 - power transformer; 2 - thyatron TT-1-Q1-1,3; 3, 4, 5, and 7 - capacitors; 9, 10, and 11 - resistors; 6 - duralumin panel; 8 - angle plate; 12 - collar; 13 - five-pin plug connector; 14 - single-pin plug connector.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM




Fig. 82. Transmitter of Fuel Flow Meter PTC-16  
1 - housing; 2 and 3 - pipe connections; 4 - guide vane assembly; 5 - impeller; 6 - guard straps; 7 - contact-pulse mechanism casing.

Fig. 83. Transmitter of Fuel Flow Meter PTC-16 Mechanical Diagram  
1 - worm reduction gear; 2 - driving two-pole magnet; 3 - driven magnet; 4 - cylindrical interrupter; 5 - fixed platinum-iridium brushes; 6 - ferrite ball bearings; 7 - three-pin plug connector.




Fig. 84. Circuit Diagram of Fuel Flow Meter PTC-16  
1 - power transformer; 2 - chymaton; 3, 4, 5, 6, and 7 - capacitors rated for 10, 100, 1.0, and 1.0  $\mu$ F respectively; 8, 9, 10, 11 - resistors rated for 10, 10, 150, and 75 kilohms respectively; 12 - voltage divider.

SECRET  
NO FOREIGN DISSEM

Declassified in Part - Sanitized Copy Approved for Release 2013/02/21 : CIA-RDP80T00246A070800100001-4

**SECRET**  
NO FOREIGN DISSEM

**SECRET**  
NO FOREIGN DISSEM

Declassified in Part - Sanitized Copy Approved for Release 2013/02/21 : CIA-RDP80T00246A070800100001-4



**SECRET**  
NO FOREIGN DISSEM

50X1-HUM



## TU-16 AIRCRAFT

### AIRCRAFT SERVICE MANUAL

#### Book II

Navigation Equipment, Autopilot, Oxygen, Electrical,  
Photo, and Radio Equipment

GROUP 1  
Excluded from automatic  
downgrading and  
declassification

**SECRET**  
NO FOREIGN DISSEM

~~SECRET~~  
NO FOREIGN DISSEM

50X1-HUM

**TY-16 AIRCRAFT  
SERVICE MANUAL**

**Book Two**

~~SECRET~~  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM

**TY-16 AIRCRAFT  
SERVICE MANUAL**

**Book Two**

Navigation Equipment.  
Autopilot, Oxygen, Electrical,  
Photo, and Radio Equipment

**SECRET  
NO FOREIGN DISSEM**

SECRET  
NO FOREIGN DISSEM



50X1-HUM

CONTENTS

	Page
<u>Navigation Equipment and Engine Instruments</u> .....	9
General .....	9
Access .....	12
Pre-Flight Inspection .....	13
Probable Troubles of Navigational Instruments and Their Remedies .....	14
Checking the Pitot-Static System for Tightness .....	18
Post-Flight Operation .....	19
<u>Electrical Instruments of Navigation Equipment</u> .....	19
General .....	22
Maintenance Instructions .....	22
Visual Inspection .....	25
Post-Flight Inspection .....	25
Checking the Instruments for Correspondence to Their Basic Specifications .....	35
Engine Instruments and Gauges .....	35
General .....	38
Maintenance Instructions .....	38
Pre-Flight Inspection .....	38
Checking the Instruments for Correspondence to Their Basic Specifications .....	46
Troubles and Remedies .....	49
Elimination of Compass Deviation on Instruments <u>ANMK-7</u> , <u>APK-5</u> No.1 and No.2 and <u>EA-12</u> .....	57
Autopilot <u>AI-5-2M</u> .....	57
General .....	60
Checking Autopilot for Installation on Aircraft and Operation under Current .....	60
External Inspection .....	63
Checking Operation of Emergised Autopilot .....	67
Faults and Remedies .....	69
<u>Oxygen Equipment</u> .....	69
General Specifications .....	69
Accessibility for Inspection .....	71
Preparation for Flight Inspection .....	71
Charging <u>EM-30</u> Converters with Liquid Oxygen .....	73
Checking Operation of Distant-Reading Liquid Oxygen Level Indicator, Type <u>APK</u> .....	73

The book contains 261 pages.  
Besides, there are seven inserts on seven sheets, and figures on forty three sheets at the end of the book.

SECRET  
NO FOREIGN DISSEM



50X1-HUM

- 4 -	Page	- 5 -	Page
Putting KHM-30 Converters to Operating Condition .....	73	Adjusting and Checking the Operation of HO-4500 Inverter .....	118
Checking Serviceability of KHM-30 Converters before Flight ..	74	Electrically Heated Glass Panels .....	119
Checking Operation of KH-24W Economiser .....	74	Maintenance of Heated Glass Panels .....	119
Possible Faults of Oxygen System and Means of Their Elimination .....	76	Use of Glass Panel Heaters .....	121
Checking System for Leakage .....	76	Tail Empennage De-Icers .....	121
Effects of Temperature Change during Check of System Gas-tightness .....	77	Brief .....	121
Checking Shut-Off Valves .....	78	Checking Tail Empennage De-Icer System on the Ground .....	123
Faults of KHM-30 Converter .....	79	Instructions for Operation of Tail Empennage De-Icer during Flight .....	125
Washing the Vessel KHM-30 Converter .....	79	Warning System .....	125
Causes of KHM-30 Converter .....	81	Light Fitting CH-51 .....	126
Faults of KH-24 Economiser .....	82	Care and Maintenance of Light and Sound Signal Units .....	134
Faults of KH-30H Mask .....	84	Aircraft Interior Lighting .....	134
Faults of Tee-Pieces with Non-Return Valves .....	84	Exterior Lighting .....	142
Faults of KH-23 Parachute Oxygen Breathing Apparatus .....	84	Fire Fighting Equipment and Fire Warning Electric System .....	148
Post-Flight Inspection .....	85	Checking Installation and Operation of Fire Fighting Equipment .....	149
Pressure Release .....	85	Electric System .....	149
Storage of Liquid Oxygen in KHM-30 Converters .....	85	Fuel Shut-Off and Engine Fuel Cross-Feed Cocks .....	151
Storage of Liquid Oxygen in Sealed Vessels of KHM-30 Converters .....	86	Possible Faults of Fire Fighting System and Their Elimination .....	151
Precautionary Measures .....	87	Fuel Pumps Control and Fuel Gauge Electric System .....	152
Instructions for Packing Parachutes with KH-23 Oxygen Breathing Apparatus .....	87	Arrangement of Electric Units Included in the System .....	153
<u>Electrical Equipment</u> .....	89	Checking Operation of Fuelmeter System on Aircraft .....	156
General .....	89	Checking Operation of Fuel Pumps Manual and Automatic Control System and Their Warning System .....	158
Aircraft Electric Mains .....	89	Possible Faults of Fuel Pumps Control Electric System and Their Elimination .....	162
Operating Duties of Electric Mains .....	91	Flap Control Electric System .....	165
Protection of Electric Mains .....	96	Checking Flaps Operation under Voltage .....	168
Wiring .....	97	Tail Skid Control and Landing Gear Warning Electric System .....	169
Laying and Removing the Cables .....	99	Checking Operation of Tail Skid Control and Landing Gear Warning System under Voltage .....	171
Maintenance of Junction Boxes and Electric Control Boards .....	101	Trim Tab Electric Control System .....	172
Specific Features of Aluminium Wire Maintenance .....	101	Voltage Check of Trim Tab Electric Control System .....	173
Regulation and Check-Out of Bonding Arrangement .....	104	Possible Faults of Electrical Parts of Trim Tab Control System and Their Elimination .....	175
Operation Peculiarities of D.C. Power Supply Sources .....	105	Brake System Pump Control Electric System .....	175
Generator Maintenance .....	105	Checking Operation of Hydraulic System Electric Control .....	177
Storage Battery Maintenance .....	107	Cabin Heating Electric System .....	177
Connecting D.C. Ground Supply Source .....	110	Possible Faults of Cabin Heating Electric System and Their Elimination .....	178
Control Over D.C. Power Supply Source and Electric Mains .....	111	Pre-Flight Preparation .....	179
Operation Peculiarities of A.C. Power Supply Sources .....	115	Pre-Flight Preparation Before Energizing Electrical Equipment .....	179
Connection of HO-4500 Inverters and of Ground A.C. Power Supply Source .....	115	Voltage Check of Electrical Equipment .....	182
Inverter Maintenance .....	116	Post-Flight Inspection .....	182
Inverter Probable Troubles Constituting Reason for its Replacement .....	117	Checking Instruments Serviceability .....	183
Control Over A.C. Power Sources and A.C. Mains .....	118	<u>Photographic Equipment</u> .....	185
		General .....	185
		Pre-Flight Preparation .....	189
		Pre-Flight Preparation of Daytime Photography Cameras .....	189
		Pre-Flight Preparation of HAZA Camera .....	193

SECRET  
NO FOREIGN DISSEM



50X1-HUM

	Page
Pre-Flight Preparation of GAPA-1 Camera .....	195
Post-Flight Operations .....	197
General .....	197
<b>Radio Equipment</b> .....	<b>200</b>
Brief Information .....	200
Pre-Flight Check .....	200
Post-Flight Inspection .....	202
Visual Inspection of Radio Equipment .....	202
Checking of Live Radio Equipment .....	204
Interphone System CHV-10 (feeder H7200-26) .....	204
Command Radio Set 1-PCB-70M (feeder H7200-24) .....	207
Radio Set PCB-3M (feeder H7200-25) .....	212
Radio Compass AW-5 Nos 1 and 2 (feeder H7200-23) .....	214
Marker Receiver MFI-48H (feeder H7200-23) .....	217
Radio Altimeter PB-17 (feeder H7200-22) .....	219
Low-altitude Radio Altimeter PB2 (feeder H7200-22) .....	222
Radio Range Finder CJ-1 (feeder H7200-22) .....	225
Localizer Receiver HPI-0 and Glide-Slope Receiver IPI-2 of Instrument Landing System .....	228
Airborne Transponder CPO (feeder H7200-20) .....	232
Radar Bombight FEI-4 .....	234
Post-Flight Inspection and Checking of Equipment .....	252
Troubles and Remedies .....	253
Measurement of Radio Noise Level .....	255
General Instructions .....	255
Operation of Electrical and Radio Facilities .....	261

The Aircraft Service Manual comprises three books:  
**Book One** includes: aircraft ground servicing; care and maintenance of airframe, emergency and rescue equipment, aircraft control system, landing gear, hydraulic systems, power plants, high-altitude equipment; packing and shipment of aircraft.

**Book Two** includes: care and maintenance of navigation equipment, autopilot, oxygen, electrical, photo, and radio equipment.

**Book Three** includes: care and maintenance of bombing equipment.

SECRET  
NO FOREIGN DISSEM



50X1-HUM

NAVIGATION EQUIPMENT AND ENGINE INSTRUMENTS  
GENERAL

1. The navigation equipment includes:
    - (a) the Pitot-static system;
    - (b) the Pitot-static instruments, namely: type KVO-1200 airspeed (I.A.S. and T.A.S.) indicators, type BR-20 altimeters, type RBP-30-3 rate-of-climb indicators, type CCH-3 velocity head warning units, type MC-1 machometers (with warning lights), type EC-46 cabin pressure warning units, type JBHL-15 cabin altimeters;
    - Note:* Apart from the above-listed instruments, the Pitot-static system actuates the T.A.S. transmitter belonging to the HH-505 air position indicator set and the altitude and speed transmitters of the OBE-11p optical bombsight set.
    - (c) the electrical instruments, namely: type DME-7 and type RAK-RE-5 compasses, type HH-505 air position indicator, type AFS-2 gyro horizon, type MK-52 directional gyro, type TFD-48 tachometers, type STH-53 turn indicators;
    - (d) the autonomous instruments, namely: type EM-12 magnetic compass, type AK-53 hand-operated astrocompass, type EAC-51 aircraft sextant, type AM-10 accelerometer, types AXKO and ARP-M clocks.
  2. The engine instruments comprise the electric pressure gauges, thermometers, and tachometers.
- The arrangement of instruments on the instrument panels is shown in Figs 1 to 7 inclusive.

PITOT-STATIC NAVIGATIONAL INSTRUMENTS  
GENERAL

The instruments, types KVO-1200, RBP-30-3, BR-20, MC-1, CCH-3, JBHL-15, and EC-46, are actuated by the Pitot-static pressure system. For installation on and removal of instruments from the instrument panels refer to the Book "Repair of Aircraft".

Altimeters

Altimeters are mounted on the instrument panels of both pilots, navigator, navigator-radar operator, and radio operator, i.e. five altimeters in total. The BR-20 altimeters operate in the temperature range of +50 to -60°C and indicate a relative (barometric) flight altitude within the limits of 0 to 20,000 m. One full revolution of the larger pointer corresponds to 1000 m. One full revolution of the smaller pointer corresponds to 20,000 m.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

NAVIGATION EQUIPMENT AND ENGINE INSTRUMENTS

GENERAL

1. The navigation equipment included:

- (a) the Pitot-static system;
- (b) the Pitot-static instruments, namely: type EFC-1200 airspeed (I.A.S. and T.A.S.) indicators, type BI-20 altimeters, type BAP-30-3 rate-of-climb indicators, type LKH-3 velocity head warning units, type M-1 machmeters (with warning lights), type BC-46 cabin pressure warning units, type YBHR-15 cabin altimeters;

Note: Apart from the above-listed instruments, the Pitot-static system actuates the T.A.S. transmitter belonging to the HI-50E air position indicator set and the altitude and speed transmitters of the OIS-11p optical bombsight set.

- (c) the electrical instruments, namely: type HMK-7 and type RAN-4E-5 compasses, type HI-50E air position indicator, type AFE-2 gyro horizon, type THK-52 directional gyro, type TYS-48 tachometers, type 3VH-53 turn indicators;
- (d) the autonomous instruments, namely: type MI-12 magnetic compass, type AR-53 hand-operated astrocompass, type HAC-51 aircraft sextant, type AM-10 accelerometer, types AHKO and ABP-M clocks.

2. The engine instruments comprise the electric pressure gauges, thermometers, and tachometers.  
The arrangement of instruments on the instrument panels is shown in Figs 1 to 7 inclusive.

PITOT-STATIC NAVIGATIONAL INSTRUMENTS

GENERAL

The instruments, types EFC-1200, BAP-30-3, BI-20, MC-1, CCH-3, YBHR-15, and BC-46, are actuated by the Pitot-static pressure system.  
For installation on and removal of instruments from the instrument panels refer to the Book "Repair of Aircraft".

Altimeters

Altimeters are mounted on the instrument panels of both pilots, navigator, navigator-radar operator, and radio operator, i.e. five altimeters in total.  
The BI-20 altimeter operates in the temperature range of +50 to -50°C and indicates a relative (barometric) flight altitude within the limits of 0 to 20,000 m. One full revolution of the larger pointer corresponds to 1000 m. The full revolution of the smaller pointer corresponds to 20,000 m.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 10 -

Airspeed Indicators

The KVC-1200 airspeed indicators are installed on the instrument panels of both pilots, navigator, navigator-radar operator, and radio operator. The KVC-1200 airspeed indicators function in the temperature range between +50 and -60°C and read I.A.S. from 100 to 1200 km/hr and T.A.S. from 400 to 1200 km/hr at a flight altitude ranging from 0 to 15,000 m. The scale graduation value is 10 km/hr, each 100 km/hr division being numbered.

Rate-of-Climb Indicators

The rate-of-climb indicators are mounted on the instrument panels of both the left-seat pilot and the right-seat pilot. The rate-of-climb indicators operate in the temperature range of +50 to -60°C and give the vertical component of the rate of climb or descent within the range of 0 to 30 m/sec. both towards climb or descent.

Machmeters

The machmeters are installed on the instrument panels of both the left-seat pilot and the right-seat pilot. The machmeters function in the temperature range of +50 to -60°C and read the Mach number within the limits of 0.5 to 1 at a flight altitude ranging from 0 to 18,000 m. At Mach number equal to 0.86 (the instrument is adjusted for this value) the warning lights with red light filters, mounted near the machmeters, go on. Under the warning lights there is a caption "SPEED TOO HIGH". The warning light warns the pilot that the aircraft is approaching the critical Mach number equal to 0.9 for this type of aircraft.

Velocity Head Warning Units

Two warning units are mounted on the aircraft behind the pilot's seats. The warning units operate in the temperature range of -50 to +60°C. By sending electrical signals when the velocity head of  $q=2300 \text{ kg/m}^2$  or Mach 0.86 are reached, the warning units warn the pilot that the aircraft is approaching the maximum allowable flight speed.

Limitations for velocity head  $q$  and Mach number for various flying weights versus flight altitude are given in the graph (See Fig.8).

Cabin Altimeters

Two cabin altimeters, type YBNU-15, are mounted on the instrument panels of the right-seat pilot and the radio operator.

The cabin altimeters operate in the temperature range of +50 to -60°C. They are intended to indicate the "altitude" in a pressurized cabin and the difference between the cabin pressure and the outside air.

Pitot-Static System

Schematic diagrams of Pitot and static pressure systems are shown in Figs 9 and 10.

Table 1 gives the necessary data on the connection of instruments to pressure sources.

- 11 -

Table 1

Connection of Instruments to Pressure Sources

Nos	Name of pressure source	Connected instruments
On Aircraft (See Fig.9)		
1	Pitot tube, front, left-side	Type KVC-1200 airspeed indicator and type MC-1 machmeter on left-seat pilot's instrument panel; type KVC-1200 airspeed indicator on navigator's instrument panel; type CCH-3 velocity head warning unit, left-side
2	Pitot tube, rear, left-side	T.A.S. transmitter of type BH-505 air position indicator set; speed transmitter of type (HB-11p) optical bombight set; type KVC-1200 airspeed indicator on operator's instrument panel
3	(Plumb-type) static vent, upper, left-side	Type KVC-1200 airspeed indicator and type BR-17 altimeter on instrument panels of navigator and operator
4	Static vent, medium, left-side	Type CCH-3 velocity head warning unit, left-side; type KVC-1200 airspeed indicator, type BR-17 altimeter, type BAR-30-3 rate-of-climb indicator, type MC-1 machmeter on left-seat pilot's instrument panel
5	Static vent, lower, left-side	T.A.S. transmitter of type BH-505 air position indicator set; speed and altitude transmitters of type (HB-11p) optical bombight set
6	Pitot tube, right-side	Type KVC-1200 airspeed indicator and type MC-1 machmeter on right-seat pilot's instrument panel; type CCH-3 velocity head warning unit, right-side; type KVC-1200 airspeed indicator on radio operator's instrument panel
7	Static vent, lower, right-side	Type KVC-1200 airspeed indicator, type BR-17 altimeter, type BAR-30-3 rate-of-climb indicator, type YBNU-3 cabin altimeter on right-seat pilot's instrument panel; type CCH-3 velocity head warning unit, right-side; type BR-17 altimeter, type YBNU-3 cabin

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

Nos	Name of pressure source	Connected instrument
8	Static vent, upper, right-side	altimeter, and type ETC-1200 air-speed indicator on radio operator's instrument panel  For type APX-54 automatic cabin-pressure regulator (if type APX-50 automatic cabin-pressure regulator is installed, the static pressure outlet will be blanked off)

Installation of Type E2-75 Speed and Altitude Recorder

1. Type E2-75 recorder is mounted between frames No.9 and No.10 on the right side (Fig.11).

The recorder is connected to the Pitot-static system in the following way: insert tee-piece H7705-3/8 (available in the spare parts set) between the static line and the CCH-3 velocity head warning unit, connect the recorder hose to the tee-piece.

The recorder supply hoses are connected to tee-pieces 1026450-4 out into static line H7702-100-22 and Pitot line H7702-29-6 (the right-seat pilot's main).

**ACCESS**

There are free accesses to Pitot-static instruments mounted on instrument panels. The instrument panels of both pilots and navigator flap back thus giving access to the rear side of the instruments.

Access to the Pitot-static system line is difficult in the following places:

- between frames Nos 5 - 9 on both sides;
- between frames Nos 9 - 12 on both sides. Moisture traps for collecting moisture from the Pitot-static system are located in this section on both sides of the fuselage;
- in the F-3 fuselage section, starboard;
- in the F-4 fuselage section, starboard;
- in the region of frames Nos 49 - 57;
- in the F-6 fuselage section, starboard.

To reach the line between frames Nos 5 - 9, starboard, proceed as follows:

- open the access panels of the right-hand engine instrument board;
- remove the glass heating distribution box.

To reach the line between frames Nos 5 - 9, port, do the following:

- flap back the left-seat pilot's instrument panel;
- remove the access panels of the left-hand engine instrument board.

To reach the line between frames Nos 9 - 12, starboard:

- remove the thyratron interrupters from the starboard rack in the operator's cabin;
- remove the dynamotor of the PC5-70 aircraft radio set from the starboard rack;

To reach the line between frames Nos 9 - 12 port, remove the high-voltage rectifier of the radar beamlight.

In order to reach the line in the F-3 fuselage section, starboard, proceed as follows:

- open the hatch door at the bottom section of frame No.12;
- open the hatches of the containers of fuel tanks No.1 and No.2;
- remove fuel tanks No.1 and No.2;

To get at the line in the F-4 fuselage section in the region of frames Nos 27 - 34, starboard, do the following:

- open the hatch in the F-4 fuselage section between frames Nos 27 - 29;
- remove starting fuel tank H6154-120;
- remove air-cooler H5601-360;
- remove drain pipe H6152-36/1;
- slacken the yoke on pipe H6152-38/3 and turn the branch pipe;
- remove high-altitude equipment pipes H7605-0/23.5.

To reach the line in the F-4 fuselage section in the region of frames Nos 49 - 75, proceed as follows:

- open the hatches of the containers of fuel tanks Nos 4 and 5;
- remove fuel tanks No.4 and No.5;
- lift up the hatches in the containers of fuel tanks.

To gain access to the pipes in the F-6 fuselage section, remove the PCW radio set equipment from the bottom section of frame No.69.

**PRE-FLIGHT INSPECTION**

Prior to each flight:

- Remove protective covers with red warning flags from the Pitot tubes.
- Take the blanking plugs out of the static vents.
- Make visual inspection of the instrument panels (check the instruments for cover glass cracks, luminous paint for intactness, instruments for proper attachment, etc.).
- Drain moisture from moisture traps in rainy weather.
- Check the position of the selector cock for switching the left-seat pilot's instruments to emergency supply and the presence of safety wire with a seal on the cock. (The selector cock is installed on the left-hand engine instrument board).

The cock must be set and sealed in the NORMAL position.

Before each flight, check the efficiency of the Pitot-static system in the following manner:

- Set the hands of two-pointer altimeters to zero and the barometric scales for the pressure check.
- Wind up the clocks and see that they are in good repair.
- Build up a pressure in the Pitot tubes equal to 60 - 75 mm Hg (which corresponds to a speed of 400 to 500 km/hr).
- Connect a vacuum source of 85 - 160 mm Hg (which corresponds to an altitude of 1000 - 2000 m.) to the flush-mounted static vents.

When the Pitot-static system is serviceable the instruments will react to supply as follows:

**Airspeed indicators** - with pressure increase in the Pitot line the hands will rotate clockwise.

**Altimeters and cabin altimeters** - with vacuum increase the hands will rotate clockwise.

**Rate-of-climb indicators** - with vacuum increase the hands will deflect upward, while at constant vacuum of any magnitude the hands will return to zero.

- Check to see that the CCH-3 velocity head warning unit sends a warning signal. To this end:
  - connect in turn a pressure source of the HUV-3 test set type to the

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 14 -

TH-156 Pitot tubes for both the left-hand and right-hand instrument panels of the pilots;

(b) build up a pressure in the Pitot-static system equal to  $159 \pm 4$  mm Hg. At this the CCH-51 warning lamp will light up on a respective panel of the pilot.

6. Check to see that the MC-1 mastermeter sends a warning signal. To this end:

- disconnect the impact pressure lines from the CCH-5 velocity head warning units; blank off the pipe line ends;
- connect in turn a pressure source of the HUV-3 test set type to the TH-156 Pitot tubes for both the left-hand and right-hand instrument panels of the pilots;
- build up a pressure in the Pitot-static system equal to  $473 \pm 19$  mm Hg. At this the warning lamp will light up on the pilot's instrument panel, whereas the MC-1 mastermeter needle will be on the red line.

Note: If atmospheric pressure does not equal to 760 mm Hg, then during the check create a pressure of 760 mm Hg in the static system.

#### PROBABLE TROUBLES OF NAVIGATIONAL INSTRUMENTS AND THEIR REMEDIES

The Pitot-static system troubles include:

- unserviceable condition of Pitot-static instruments;
- leakage or clogging of the Pitot-static system proper.

To draw a conclusion on good or bad repairs of an instrument, if obvious defects are not available, check the instrument as indicated below.

Leakage of the Pitot-static system is eliminated by tightening the nipple joints and replacing the rubberized hoses (in case the latter are worn out). Clogging is eliminated by blowing the system.

#### Checking the Instruments Altimeter

The altimeter check-up includes visual inspection of the instrument, checking its readings for errors and its case for tightness. The altimeter case tightness and the errors in altimeter readings can be checked in situ by means of the HUV-3 test set and master mercury barometer.

To check the altimeter, proceed as follows:

- set the pointers of both the master barometer and the altimeter under test to zero;
- disconnect the altimeter to be checked from the aircraft static pressure line and join it to a tee-piece connected with one end to the master barometer (Fig.12) and with the other end to the HUV-3 test set;
- using the HUV-3 test set, create a rarefaction in the altimeter corresponding to definite altitudes as read off the master barometer. Take into account the altimeter instrumental corrections;
- record the readings of the altimeter under test in the check list and compute the errors. In doing so, take into consideration the corrections of the master mercury barometer;
- compare the obtained corrections of the altimeter under test with the corrections entered into the altimeter correction card.

If these corrections vary, compile a new correction card and use it in flights.

The altimeter admissible errors (total instrumental errors) are given in the altimeter Certificate. If during the altimeter check it is found out that the

- 15 -

altimeter errors exceed the maximum permissible values, the instrument should be replaced by a new one and the defective altimeter should be sent for adjustment to a special workshop.

After the errors and the instrument case tightness have been checked, check the lines for leakage.

#### Airspeed Indicator

- The operating efficiency of the airspeed indicator is determined by visual inspection and check test.
- The static system is checked for leakage at normal temperature by connecting the instrument to a vacuum source. When rarefaction, corresponding to the 1200 km/hr instrument reading, is created, the vacuum source is shut off with a cock. By clamping the hose at the pipe connection of impact pressure line, watch the instrument pointers, the readings of which should not change during one minute.
- Errors in the instrument readings are checked at normal temperature in the following manner (Fig.13):

- connect a pressure source to the instrument pipe connection with index P(A) and a vacuum source to the pipe connection with index B (C);
  - check the error value for each numbered division of the dial by building up a pressure (as read off a pressure gauge) corresponding to the dial readings;
  - take the readings of the values to be checked both clockwise and counter-clockwise at one and the same dial mark.
- Maximum pressure at each dial mark being checked for not less than 1 minute. Maximum pressure, corresponding to the 1200 km/hr dial mark, should be maintained for not less than 15 minutes. Error value will be determined by comparing the readings of the airspeed indicator under test with that of the master pressure gauge;
- maintain vacuum (when checking the instrument at various altitudes), corresponding to the altitude under check as read off the master barometer, taking into account the calibration card given in the Service Manual of the airspeed indicator;
  - compare the data obtained during the check with that entered into the correction card for speed and altitude. Correct the card should any difference occur;
  - replace the airspeed indicator if the corrections obtained exceed the permissible errors given in the instrument Certificate.

The correction cards are furnished with the speed and altitude indicators mounted on the instrument panels of navigator, navigator-radar operator, and both pilots.

The values to be determined by formula

$$V_{indic} = \delta V_{instr} + \delta V_{aer} + \delta V_{comp}$$

will be entered into column  $V_{indic}$ .

- where  $V_{indic}$  is I.A.S. (indicated airspeed);
- $\delta V_{instr}$  are the errors in instrument reading determined as stated above;
  - $\delta V_{aer}$  is an aerodynamic correction. It is a constant value for I.A.S. and equals to 13 km/hr;
  - $\delta V_{comp}$  is a compressibility correction to be taken from tables.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 16 -

The values to be determined by formula

$$\Delta V_{\text{true}} = \delta V_{\text{instr}} + \delta V_{\text{aer}}$$

will be entered into column  $\Delta V_{\text{true}}$ .

where  $V_{\text{true}}$  is T.A.S. (true airspeed),  $\delta V_{\text{aer}}$  at standard atmosphere will be taken from the graph (Fig. 14). The data obtained for  $\delta V_{\text{aer}}$  determined at an altitude of  $H = 8000$  m., will be entered into the third column, whereas the data for  $\delta V_{\text{aer}}$  determined at an altitude of  $H = 12,000$  m., will be entered into the fourth column.

Corrections for type EM-20 altimeter will be entered into column  $\Delta H$ . It is said on the reverse sides of the tables: "Aerodynamical and instrumental corrections and compressibility corrections are accounted for in  $\Delta V_{\text{ind}}$  Aerodynamical and instrumental corrections are taken into account in  $\Delta V_{\text{true}}$ ".

For the table of aerodynamical corrections see the aircraft Service Log.

**Rate-of-Climb Indicator**

The instrument check-up includes visual inspection and airtightness check. The instrument should be so tight that at a rarefaction of 380 mm Hg the rate of pressure drop during one minute would not exceed 2 mm Hg. Vacuum should be created gradually without sharp jerks of the climb indicator's pointer.

**Machmeter**

The instrument check-up comprises visual inspection, check of static pressure line for tightness, and check for errors in readings.

The static system should be so tight at a rarefaction of 380 mm Hg, supplied to both pipe connections, that the rate of pressure drop during one minute would not exceed 8 mm Hg.

The machmeter will be checked as shown in Fig. 15.

The machmeter may be checked in situ. The machmeter is checked by the numbered divisions of the dial, namely 0 km. and at altitudes of 2, 6, 10, 14, and 18 km. To check at these altitudes use the calibration card of the machmeter Certificate. The Mach number readings will be taken both clockwise and counter-clockwise. The error value will be determined by comparing the readings of the machmeter being tested with the reading of the master pressure gauge at an altitude of 0 km. If atmospheric pressure does not correspond to 760 mm Hg, then build up a pressure of 760 mm Hg in the static system when checking the instrument at an altitude of 0 km.

To check the machmeters at an altitude of 0 km., proceed as follows (Fig. 15): close cock 7, open cock 9, and using cock 1 supply the line with pressure which should be read off pressure gauges 2 and 3 and which corresponds to the dial divisions under check. In doing so maintain a pressure of 760 mm Hg as read by the barometer. Simultaneously take the machmeter readings.

To check the machmeter at different altitudes, proceed as follows: close cock 1, open cocks 7 and 9, and using cock 8 create controlled by the barometer a rarefaction, corresponding to the altitude at which the machmeter should be checked. Rarefaction should be read off barometer 4. This done, close cocks 7 and 9, and using cock 1 build up in the line pressure which should be read off pressure gauges 2 and 3, and which corresponds to the main dial divisions (according to the calibration table in the machmeter Certificate). Simultaneously take the machmeter readings.

- 17 -

Upon completion of the machmeter check at a given altitude, close cock 1 at the final reading of the pressure gauge, gradually open cocks 7 and 9 and then through cock 8 create a rarefaction corresponding to the subsequent altitude.

**Velocity Head Warning Unit**

The instrument check comprises visual inspection, checking the pitot-static system for tightness, checking the operation of warning lamp for errors, as well as checking the electric circuit insulation.

1. The static pressure line is checked for tightness at normal temperature by connecting the impact and static pressure pipe connections to a pressure source of 300 mm Hg (Fig. 16). The pressure source will be blanked off with a cock. Pressure differential rate per minute should not exceed 0.5 mm Hg.

The impact pressure system (Fig. 17) is checked by connecting the dynamic pressure pipe connection to the pressure source.

Airtightness should be preserved for 5 minutes at a pressure of 330 mm Hg.

No pressure differential is allowed during this time.

2. Operation of the warning lamp at normal temperature is checked for errors in the following way. The warning unit is connected to the pressure source (Fig. 17). By gradually increasing pressure, watch the moment the circuit is closed (the warning lamp goes on). When taking the reading counter-clockwise, gradually decrease pressure and watch the moment the circuit is open (the warning lamp goes off). The error value is determined by the readings of the master pressure gauge at the moment the warning lamp lights up.

3. Insulation of the current-carrying elements at relative humidity of 30 to 80% is checked by means of a megger, one wire of which is simultaneously connected to three pins of the plug, while the other wire of the megger is connected to the warning unit case. Insulation should not be less than 20 megohms.

**Cabin Altimeter**

The instrument check includes visual inspection and testing the instrument case for tightness. The instrument case is tested for tightness by connecting the case pipe connections to a vacuum source. At a rarefaction corresponding to an altitude of 8 km. as read by the instrument, the vacuum source is blanked off with a cock. Then, by clamping the hose at the pipe connections, watch rarefaction decrease in the instrument case. The rate of pointer drop should not exceed 400 m. per minute.

Airtightness of the instrument diaphragm assembly is checked by connecting the pipe connection with index C to the vacuum source. At a rarefaction corresponding to the instrument reading of 0.6 kg/cm<sup>2</sup>, read off the excessive pressure scale, the vacuum source is blanked off with a cock. Then, by clamping the hose at the pipe connection, watch the pointer, the reading of which should not change during one minute.

The altimeter readings are checked for errors using the method of checking the instrument case for tightness by creating rarefaction in the instrument corresponding to the readings of the dial numbered divisions under check.

Rarefaction should be maintained at each dial mark being checked for not less than 1 minute and at a maximum rarefaction - for not less than 15 minutes.

The differential pressure gauge operation should be checked in the same manner as the diaphragm assembly is checked for tightness.

To determine the instrumental errors, the altimeter readings are compared with the readings of the master mercury barometer, while the readings of the

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM



differential pressure gauge are compared with the readings of the master mercury pressure gauge which are both connected to the test set.

Checking the Pitot-Static System for Tightness

Testing the Static Lines for Tightness

- (a) Disconnect the rate-of-climb indicators from the static lines and blank off the ends.
- (b) Insert in turn the hose, connected to the vacuum source, into the holes of all five static vents and create rarefaction (vacuum) corresponding to 700 km/hr as read off the airspeed indicator.

Note: It is allowed to check the static pressure lines for tightness with the rate-of-climb indicators connected to the line. However, in this case create vacuum, corresponding to an airspeed of 700 km/hr, and equalize it with the atmospheric pressure gradually and for not less than 2 minutes.

- (c) Clamp the hose running from the vacuum source. Note the reading of the airspeed indicator pointer and then determine the rate of airspeed drop per minute.
- (d) Permissible leakage of the static pressure lines corresponds to a value at which the rate of drop in the readings of the airspeed indicators does not exceed 5 km/hr per minute.

Testing the Impact (Dynamic) Pressure Line for Tightness

- (a) Fit a rubber hose, connected with the pressure source, onto the Pitot tubes (see to it that the drain hole is closed). Create a pressure in the line corresponding to an airspeed of 700 km/hr read by the airspeed indicator.
- (b) Clamp the hose running from the pressure source. Take the reading of the airspeed indicator pointer and then determine the rate of airspeed drop per minute.

Permissible leakage of the impact pressure line corresponds to a value at which the rate of drop in the readings of the airspeed indicators does not exceed 2 km/hr per minute.

POST-FLIGHT OPERATIONS

If during the flight the Pitot-static instruments worked without failure, then after the flight do the following:

- (a) put the covers on the Pitot tubes;
- (b) insert the blanking plugs into the static vents;
- (c) make visual inspection of the instruments on the instrument panels (instrument glasses, attachment of instruments, etc.);
- (d) drain moistness from the moisture traps in rainy weather.

Should any malfunctions be detected in the operation of the instruments during the flight, such as, for example, erroneous readings of the instruments, fluctuation of pointers, different readings of identical instruments (for instance type ENO-1200 airspeed indicators), installed on various instrument panels, etc., blow the Pitot-static system, check the system for airtightness and efficiency as indicated above.

50X1-HUM

NAVIGATIONAL INSTRUMENTS OF NAVIGATION

EQUIPMENT

GENERAL

The electrical instruments of navigation equipment include: type ANMK-7 remote-reading gyrocompass, type IAR-RE-5 remote-reading astrocompass, type BK-505 air position indicator, type APF-2 gyro horizon, type NUK-52 directional gyro, and type TPO-48 thermometer.

Type ANMK-7 Remote-Reading Gyrocompass

The ANMK-7 compass is a basic magnetic compass on the aircraft. It is intended to determine the magnetic and true courses of the aircraft.

The ANMK-7 compass complete set (Fig.18) comprises:

- type HME-3 transmitter ..... 1 pc;
- type P-2 gyro unit ..... 1 pc;
- type F-10 amplifier ..... 1 pc;
- type JEM master indicator (navigator's indicator) ..... 1 pc;
- repeater (additional indicator) ..... 3 pcs;
- type BK-53PB erecting outout ..... 1 pc;
- type CK-8 junction box ..... 1 pc;
- type 5k fast slave button ..... 2 pcs;
- type IT-125 inverter ..... 1 pc

Basic Specifications

- 1. Power supply ..... 27 ± 2.7 V D.C., 36 ± 3.6 V, three-phase A.C., 400 ± 40 c.p.s.
- 2. Power consumed from D.C. mains with inverter ..... not over 250 W without inverter ..... not over 25 W
- 3. Power drawn from A.C. mains ..... not over 110 W
- 4. Navigator's indicator error by the scale of compass course ..... not over 4° by the scale of true course (after measurement method error, instrumental error, and compass deviation have been eliminated) ..... not over 1°
- 5. Additional error in compass readings for each minute of turn ..... not over 0.6°
- 6. Error in repeaters' readings ..... not over 3°
- 7. Permissible angle of bank of aircraft, at which the compass readings can be taken without using the fast slave button ..... 65°
- 8. Temperature range (except for master indicator and repeaters) ..... from +50 to -60°

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 20 -

9. Temperature range for master indicator and repeaters ..... from +50 to -35°C  
 10. Altitude limit ..... up to 15,000 m.  
 11. Compass is ready for operation ..... in 3 min. after power supply is on

Under unfavorable combination of flight conditions (bank with angular speed less than 0.2° per second, altitude change, longitudinal acceleration, etc.) the error in compass readings may reach 10°.

All the assemblies, which go to make the HMK-7 compass complete set are interchangeable. In case the HMK-3 transmitter or master indicator are to be replaced, correct an installation error and remove deviation on 24 compass points.

Air Position Indicator\_HH-50E

The HH-50E air position indicator is designed for continuous indication of the aircraft position in rectangular axes, the drift being taken into account.

The HH-50E set (Fig.19) includes:

- (a) T.A.S. transmitter - 1 piece;  
 (b) automatic course device - 1 piece;  
 (c) wind setter - 1 piece;  
 (d) D.R. computer - 1 piece;  
 (e) distribution box - 1 piece;  
 (f) supply-line filter C0-2 - 1 piece;  
 (g) supply-line filter C0-4 - 1 piece;  
 (h) inverter HAP-10 (Fig.20) - 1 piece.

Basic Specifications

- |   |   |
|---|---|
| 1. Power supply .....   | D.C., 27 ± 1 V,<br>A.C., three-phase,<br>36 ± 3.6 V,<br>400 ± 40 c.p.s. |
| 2. Range of operating speeds .....  | 300 to 1200 km/hr   |
| 3. Range of wind speed .....  | 0 to 150 km/hr  |
| 4. Altitude .....   | up to 15,000 m.   |
| 5. Coordinate system .....  | rectangular with any arrangement of the axes                            |
| 6. Maximum error at normal temperature (altitude up to 8000 m., speed from 300 to 1100 km/hr) ..... | 5.5% max.   |
| 7. Course indication error at 24 points (repeated readings of HMK-7 compass main indicator) ....    | 1° max.   |
| 8. Power consumed:<br>direct current .....  | 25 W max.   |
| alternating current in most loaded phase .....  | 35 W max.   |

The units of the HH-50E set are interchangeable. But in case of replacement of any unit except the inverter and filters, it is necessary to determine

- 21 -

the total error of the set and the new correction to the change-over table of the distribution box. After replacement of the distribution box or automatic course device, do not fail to adjust the zero signal anew and to match the readings of the HMK-7 compass main indicator with those of the HH-50E automatic course device.

Gyro Horizon\_AIF-2

The AIF-2 electric gyro horizon with slide indicators are designed to determine the position of the aircraft in the space relative to the true horizon, as well as to determine aircraft sideslip.

The AIF-2 gyro horizon makes it possible to check the following aircraft acrobatics:

- (1) aircraft circle turns with up to 60° banks;  
 (2) diving and climbing at angles up to 60°

The peculiarity of the AIF-2 gyro horizon lies in the fact that the lateral erecting mechanism is cutout at an angular velocity of aircraft turning exceeding 0.2 deg/sec. In this connection, the AIF-2 gyro horizon operates in conjunction with a BR-53-PE erecting cutout.

The gyro horizon and erecting cutout are supplied from the HAP-10 inverter.

Basic Specifications

- |  |   |
|--|---|
| 1. Power supply .....  | alternating three-phase current, 36 ± 3.6 V,<br>400 ± 40 c.p.s. |
| 2. Error in horizon determination .....                                  | 1° max.   |
| 3. Time of initial erection at ambient temperature of:<br>50 ± 5°C ..... | 3 min. max.   |
| 20 ± 5°C .....   | 3 min. max.   |
| -60 ± 5°C .....  | 6 min. max.   |
| 4. Erection time from lateral and longitudinal tilts ...                 | 6 to 12 min.  |
| 5. Time difference in gyro erection from opposite tilts .....            | 3 min. max.   |
| 6. Errors in circle turns and turns lasting not more than 6 min. ....    | 2°  |

The AIF-2 gyro horizon units are interchangeable.

Erecting Cutout\_BR-53-PE

The purpose of the erecting cutout is to cut out the erecting mechanism of the gyro horizon when performing circle turns at an angular velocity exceeding 0.2 deg/sec.

The erecting cutout of the HMK-7 compass cuts out the gyro erecting unit at a turning velocity exceeding 0.3 deg/sec.

On some aircraft the cutout of the erecting unit of the gyro horizon and HMK-7 compass is performed with the help of one common erecting cutout which is adjusted to operate at a turning velocity exceeding 0.2 deg/sec.

SECRET  
NO FOREIGN DISSEM



Basic Specifications

- 1. Power supply ..... alternating three-phase current,  $36 \pm 3.6$  V,  $400 \pm 40$  c.p.s. direct current,  $27 \pm 2.7$  V
- 2. Maximum power consumed in A.C. circuit ..... 0.45 A per phase
- 3. Maximum power consumed in D.C. circuit ..... 3 W
- 4. Sensitivity ..... 0.2 or 0.3 deg/sec.
- 5. Time of erecting outout lag ..... 5 to 15 sec.
- 6. Maximum erecting outout lag time asymmetry ..... 8 sec.

**Note:** The erecting outout should be so mounted on the aircraft that the twin shock-absorbing springs are located on top and index "F" on the erecting outout casing is also on top.

Electric Resistance Thermometer TFB-48

The TFB-48 resistance thermometer is designed to measure the outside air temperature. The instrument includes the following units:

- (a) indicator - 1 piece;
- (b) transmitter - 1 piece.

Basic Specifications

- 1. Power supply .....  $27 \pm 2.7$  V
- 2. Range of measurement .....  $-70$  to  $+150^{\circ}$ C
- 3. Error of instrument does not exceed:
  - at  $20 \pm 5^{\circ}$ C .....  $\pm 5^{\circ}$ C
  - at  $50 \pm 5^{\circ}$ C .....  $\pm 7^{\circ}$ C
  - at  $-60 \pm 5^{\circ}$ C .....  $\pm 8^{\circ}$ C

The thermometer units are interchangeable.

MAINTENANCE INSTRUCTIONS

During service check the instruments of the navigation equipment before and after the flight observing the instructions given below. Check also the instruments in those cases which are specially prescribed for each instrument individually.

Pre-Flight Inspection

The pre-flight inspection comprises visual inspection of the aircraft and a check of their readiness for operation.

Visual Inspection

In inspecting the instruments visually make sure that their outer surfaces are not damaged, that the instruments are reliably secured to the instrument board or to the respective bracket and that the plug connectors or wires are reliably connected to the respective terminal blocks. See also that the safety fuses are in their places, that they are used in conformity with the diagrams and reliably secured in their seats. Check the amplifier valves for proper installation and the wires for good condition, especially in places of attachment to the plug connectors or respective terminal blocks. Make also sure that the

respective knobs and spur racks rotate smoothly, that the dials move properly, that the switches are reliably fixed in their positions, etc.

In performing visual inspection of the navigation equipment observe the following sequence:

- (a) examine, on the instrument board of the left pilot, the gyro horizon, directional gyro indicator, indicator of the ANMK-7 compass, and fast slaving button of the ANMK-7 compass;
- (b) examine, on the instrument board of the right pilot, the gyro horizon, directional gyro indicator, and the RAK-DE-5 compass course indicator;
- (c) examine, on the navigator's instrument board, the RAK-DE-5 compass course indicator, track corrector of the RAK-DE-5 compass, main indicator of the ANMK-7 compass, fast slaving button of the ANMK-7 compass, T.A.S. transmitter, automatic course device, wind setter and D.R. computer of the HH-50B air position indicator;
- (d) inspect the distribution box of the HH-50B air position indicator and the amplifier of the ANMK-7 compass;
- (e) examine the HA1-10, HT-70 and HT-125 inverters through which the gyro horizons, the HIR-52 directional gyro, air position indicator HH-50 and the ANMK-7 compass are energized;
- (f) inspect the computer of the RAK-DE-5 compass;
- (g) examine the transmitters of the RAK-DE-5 compass, and the ANMK-7 compass;
- (h) clean the transparent hood of the RAK-DE-5 compass transmitter of dust and dirt. To avoid scratches wipe the hood with a piece of soft fabric soaked in alcohol;
- (i) check the colour of the silica gel crystals in the dehydrator of the RAK-DE-5 compass transmitter. If the silica gel crystals have turned pink or brown, replace the dehydrator by a spare one.

Remote-Reading Gyromagnetic Compass ANMK-7

- 1. Switch on the ANMK-7 compass circuit breaker on the circuit breaker panel of the navigator.
- 2. Cut in the switch of the ANMK-7 set on the upper electric board of the navigator.
- 3. In 2 - 3 min. after switching on power supply, press the fast slaving button located on the instrument board of the navigator or left-seat pilot and release the button after 10 - 15 sec.
- 4. Check the readings of the main indicator compass course scale with those of the magnetic compasses. The difference in the readings must not exceed  $10^{\circ}$ , the magnetic compass corrections being taken into account.
- 5. Turn the main indicator magnetic variation scale to make sure that the pointers of the auxiliary indicators repeat the readings of the main indicator pointers, the error not exceeding  $3^{\circ}$ .
- 6. Turn the compass transmitter card with the aid of a permanent magnet to check the movement of the main and auxiliary indicator pointers, with the fast slaving button pressed.
- 7. Release the slaving button and take the magnet away from the transmitter.
- 8. Check the follow-up rate of the navigator's indicator pointer with the slaving button not pressed. The follow-up rate should be within  $1 - 4^{\circ}$  per minute.
- 9. Cut off the power supply from ANMK-7 compass.

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 24 -

Air Position Indicator HM-505

1. On the circuit breaker panels of the navigator switch on the circuit breakers of the HM-7 compass and HM-505 air position indicator.
2. On the upper electric board of the navigator put the HM-7 compass switch and two switches of the HM-505 indicator in position ON.
3. In 5 minutes after the line has been energized, turn the magnetic variation spur rack of the HM-7 compass main indicator to make sure that the pointer of the automatic course device follows the readings of the main indicator; then cut out the HM-7 compass power supply switch. When this is done, the pointer of the automatic course device must not shift. This will indicate to the fact, that the zero signal has been adjusted correctly. Should the pointer of the automatic course device shift, use a screw-driver to turn the adjustable resistor screw located in the distribution box to the left (if viewed from the terminal blocks, See Fig.21). The screw must be turned until such a position is found as which movement of the pointer ceases.
4. Set the chart angle on the automatic course device just by 45° less than the reading of the automatic course device pointer. Set the wind speed knob of the wind setter to zero.
5. Use a HM-3 testing device or a special pressure producer which belongs to the HM-50 testing installation to create gradually a pressure in the dynamic system of the T.A.S. transmitter corresponding to a speed of 1150 km/hr. As the speed check changes from 300 to 1150 km/hr check the rotation of the D.R. computer check indexes, the turning rate of the check indexes should change smoothly without sharp jumps or binding.
6. At a speed of 1150 km/hr change gradually the value of the chart angle of the T.A.S transmitter from 0 to 360°.
7. Reduce the pressure in the dynamic system of the T.A.S. transmitter to zero.
8. Shift the wind speed knob on the wind setter gradually from zero to division 150 km/hr. The turning rate of the D.R. computer check indexes should change smoothly.
9. Change gradually the wind direction on the wind setter from 0 to 360°.
10. Switch off A.C. and D.C. supply from the HM-505 air position indicator.

Gyro Horizon HM-2

1. Switch on the power supply of the gyro horizon.
  2. Turn the starting handle located on the front of the gyro horizon to the left. This done, a red bullseye should appear in the cone of the port. Not later than 3 min. after energizing the instrument, the horizon line should assume the horizontal position, the permissible deviation being 1°. Make sure that the akid indicator fluid contains no air bubbles.
- Note:** With the ambient temperature below zero, the gyro erecting time may increase up to 6 min.

Electric Turn Indicator HM-51

1. Switch on the power supply of the turn indicators.
2. Wait 2 - 3 minutes, then press against the edge of the pilot's instrument board to turn it about its vertical axis as far as the check absorbers

- 25 -

perat. When this is being done, the moving index of the turn indicator should deflect from its central position.

3. Make sure that the akid indicator fluid contains no air bubbles.
4. Switch off the power supply from the instrument.

Postflight Inspection

The postflight inspection of the navigation equipment comprises the following operations:

1. Examine visually the units of the navigation equipment in the same way as during preflight inspection.
2. Cover the transparent hood of the HM-5 compass transmitter with a protective casing.
3. Check the colour of the silica gel of the HM-5 compass transmitter. If the silica gel crystals have turned pink or brown, replace the dehydrator with a spare one, since pink or brown silica gel is not capable of absorbing moisture. The silica gel can be reconditioned by drying, for which purpose it must be poured on a metal sheet and dried on a moderate fire until it turns blue again. After the dehydrator is placed on the transmitter, do not fail to open the hole in the dehydrator bottom.

In addition to the visual inspection of the instruments, find out the causes of the defects which have been revealed in the flight. Sometimes the defects and their causes may be found in the course of the check carried out in the sequence adopted for the preflight inspection. Therefore this inspection must be performed immediately after the flight. Sometimes a more careful check is required. The scope and sequence of this check is described below. Besides, trouble-shooting is facilitated by the fault finding chart which contains the most frequent defects of the navigation instruments, their causes and remedies.

Checking the Instruments for Correspondence to Their Basic Specifications

Such a check is to be carried out as soon as you begin to doubt whether the readings of some instruments are correct, and not less than once every three months.

Taking into consideration that special installations for checking some instruments may not always be available under service conditions, the checking method has been so worked out as to reduce the number of the instruments to be removed from the aircraft to the minimum and to carry out the entire check directly on the aircraft.

When special testing equipment is available it is used for checking the instruments in accordance with the Instructions of the respective installation (if available) or in compliance with the given Instructions.

In addition to the method of checking the instruments for correspondence to their Specifications, this Section contains some special instructions on mounting, care and maintenance of the navigation equipment instruments.

Remote-Reading Gyromagnetic Compass HM-7

1. Disconnect the plug connectors from the transmitter and check, using a megger, the insulation between the terminals of the plug connectors and the transmitter body. The insulation must not be below 20 megohms.
2. After having slightly tapped against the cover of the transmitter casing,

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 26 -

- 27 -

note the reading of the transmitter scale, then use a permanent magnet to deflect the transmitter card by 10° to the right and take away the magnet. Take again the readings off the scale of the transmitter. The difference between the last and first readings will be the card lag.

In the same way check the lag of the transmitter card when the latter is deflected to the left. The absolute lag value of the transmitter card must not exceed 2°.

3. Disconnect the double-terminal plug connector from the transmitter.

4. Disconnect the plug connector from the gyro unit and check the insulation between the following pins of the gyro unit plug:

(a) the insulation between pins 3 and K must be from 100 to 150 ohms;

(b) the insulation between pins L and M must be from 400 to 600 ohms;

(c) the insulation between pins A and B, B and B, A and B should be from 355 to 586 ohms;

(d) the insulation between pins 3 and J should be from 450 to 580 ohms.

5. Using a megger check the insulation between the following jacks of the plug located at the end of the wire bundle: A and E, A and M, A and P, as well as between jacks A and the aircraft framework.

The insulation must be not less than 1 megohm.

6. Check the insulation between jacks A and E, E and B, A and B of the gyro unit plug located at the end of the wire bundle. The insulation should be equal (accurate within ±20 ohms) and at least 100 ohms each.

7. Connect the plug connectors to the gyro unit and to the transmitter.

8. Supply power to the MNK-7 compass.

9. Wait 2 and 3 min. and press the fast slaving button. Release the button after 15 - 20 sec. The readings of the compass course scale of the main indicator and the scale readings of the magnetic transmitter should agree within 3°, whereas the readings of the auxiliary indicators should agree with those of the main indicator also accurate within 3°.

10. Using a permanent magnet turn the transmitter card and check, every 30 - 40°, to see that the readings of the compass course scale and those of the repeaters correspond to the readings of the transmitter scale and main indicator pointer respectively.

With the compass operating, oscillation of the main and auxiliary indicator pointers within 20.5° is permissible.

11. Check the follow-up rate of the navigator's main indicator pointer with the slave button not pressed. The follow-up rate must be within 1 - 4° per minute.

**CAUTION:** 1. It is strictly prohibited to use in the junction box a safety fuse other than type NK-0.15 A.

2. Prior to cutting the compass into the electric mains after some units have been replaced or defects in the aircraft diagram have been eliminated, do not fail to check the insulation in conformity with Item 6 of the given Section.

3. Prior to energizing the compass make sure that plug connectors Nos 8 and 11 of the OMS-11p sight computer are not confused to avoid failure of the compass.

Air Position Indicator HH-505

**Checking total error of the set.** Prior to checking the set for total error, make sure that the static and impact pressure lines of the T.A.S.

transmitter are airtight. Check also the zero signal and serviceability of the

1. The set is checked for airtightness as follows:

(a) use a HX-3 test set to create a pressure in the T.A.S. transmitter static system corresponding to a speed of 700 km/hr. Pressure drop in the static system must not exceed 2 km/hr per one minute;

(b) use a HX-3 test set to create a vacuum in the T.A.S. transmitter static system corresponding to a speed of 700 km/hr. With pressure supply cut leakage must not exceed 5 km/hr per min.;

2. The zero signal and the serviceability of the set are checked in accordance with the method adopted for preflight inspection.

3. The total error in the set readings is determined at four different courses selected so that the error may be found by one of the selected courses in the intervals from 0 to 90°, from 90 to 180°, from 180 to 270° and from 270 to 360°.

4. Switch on the A.C. and D.C. power supply of the compass and HH-505 air position indicator.

5. Measure the voltage across terminals 'B' of the distribution box of the HH-505 air position indicator. The voltage is to be measured with a voltmeter having reading corrections within the range of 24 to 30 V. Taking the corrections into consideration, ensure exactness of voltage readings within ±0.1 V.

6. Switch off the power supply from the HH-505 air position indicator and the compass. Change over the internal wiring diagram of the indicator distribution box to a voltage of 27 V.

7. Switch on the power supply of the HH-505 air position indicator and compass.

8. Create a pressure in the T.A.S. transmitter dynamic system corresponding to a speed of 700 km/hr, which is to be checked by the KPC-1200 airspeed indicator having corrections for indication errors.

When applying the pressure, take into consideration the corrections for atmospheric pressure given in Table 2.

Table 2

Speed of 700 km/hr with Corrections for Atmospheric Pressure

Atmospheric pressure, mm of mercury	Airspeed, km/hr
1	2
720	718.7
725	718.85
730	718.25
735	715.0
740	709.8
745	707.6
750	705.4
755	703.2
760	701.05

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 28 -

1	2
760 - 765	698.95
765 - 770	696.8
770 - 775	694.7
775 - 780	692.65
780 - 785	690.6
785 - 790	688.55

9. Place a permanent magnet closely to the compass transmitter and turn the main indicator magnetic variation spur rack to set the course automatic device scale to a course equal to 45° or divisible by 10 deg. within an interval of 0 to 90°.

10. Set the wind setter to a wind speed of 60 km/hr and a direction divisible by 10° or equal to 45°.

11. Set the chart angle on the course automatic device and on the wind setter to zero.

12. Switch off the D.C. supply from the HM-505 air position indicator and set the D.R. computer pointers to zero. Send the pointers to zero position by moving them in a direction opposite to their usual movement (in this case - counter clockwise).

13. Switch on the D.C. supply of the HM-505 air position indicator and start simultaneously a stopwatch.

14. Wait 8 min. and 3/4 sec., then switch off the D.C. power supply of the HM-505 air position indicator and take the readings of north and east pointers of the D.R. computer.

**Notes:** 1. In case the voltage across terminals B of the distribution box is other than  $27 \pm 0.1$  V and if it is impossible to bring it to this value, multiply the testing time (8 min. 3/4 sec.) by coefficient K:

$$K = \frac{27}{V_{ind}}$$

where  $V_{ind}$  - is the voltage measured across terminals B of the indicator distribution box.

2. During the test maintain a pressure in the dynamic system of the course automatic device which corresponds to a speed of 700 km/hr.

15. Using Table 3 determine the rated changes in the D.R. computer pointer readings for a flight in calm weather.

16. Using Table 4 determine the rated changes in the D.R. computer pointer readings depending on the direction of the wind.

17. Determine the rated changes in the readings of the north pointer  $I_N$  and east pointer  $I_E$  for a flight with drift correction introduced.

$$I_N = I'_N + L'_N$$

$$I_E = I'_E + L'_E$$

Values  $I_N$ ,  $I'_N$ ,  $L'_N$  and  $I_E$  should be taken with the signs indicated in Tables 3 and 4.

- 29 -

Table 3  
Rated Changes in Readings of Pointers  $I_N$  and  $I_E$  Depending on Course in Calm Weather

Course	0°	10°	20°	30°	40°	45°	50°	60°	70°	80°
$I_N$ km.	+100	+98.5	+94	+86.6	+76.6	+70.7	+64.3	+50	+34.2	+17.4
$I_E$ km.	0	+17.4	+34.2	+50	+64.3	+70.7	+76.6	+86.6	+94	+98.5
Course	90°	100°	110°	120°	130°	135°	140°	150°	160°	170°
$I_N$ km.	0	-17.4	-34.2	-50	-64.3	-70.7	-76.6	-86.6	-94	-98.5
$I_E$ km.	+100	+98.5	+94	+86.6	+76.6	+70.7	+64.3	+50	+34.2	+17.4
Course	180°	190°	200°	210°	220°	225°	230°	240°	250°	260°
$I_N$ km.	-100	-98.5	-94	-86.6	-76.6	-70.7	-64.3	-50	-34.2	-17.4
$I_E$ km.	0	-17.4	-34.2	-50	-64.3	-70.7	-76.6	-86.6	-94	-98.5
Course	270°	280°	290°	300°	310°	315°	320°	330°	340°	350°
$I_N$ km.	0	+17.4	+34.2	+50	+64.3	+70.7	+76.6	+86.6	+94	+98.5
$I_E$ km.	-100	-98.5	-94	-86.6	-76.6	-70.7	-64.3	-50	-34.2	-17.4

$I_N$  - change in readings of north pointer  
 $I_E$  - change in readings of east pointer

Table 4  
Rated Changes in Readings of Pointers  $I'_N$  and  $I'_E$  Depending on Wind Direction

Course	0°	10°	20°	30°	40°	45°	50°	60°	70°	80°
$I'_N$ km.	+8.6	+8.4	+6	+7.4	+6.6	+6.1	+5.5	+4.3	+2.9	+1.5
$I'_E$ km.	0.0	+1.5	+2.9	+4.3	+5.5	+6.1	+6.6	+7.4	+8	+8.4
Course	90°	100°	110°	120°	130°	135°	140°	150°	160°	170°
$I'_N$ km.	0	-1.5	-2.9	-4.3	-5.5	-6.1	-6.6	-7.4	-8	-8.4
$I'_E$ km.	+8.6	+8.4	+6	+7.4	+6.6	+6.1	+5.5	+4.3	+2.9	+1.5
Course	180°	190°	200°	210°	220°	225°	230°	240°	250°	260°
$I'_N$ km.	-8.6	-8.4	-6	-7.4	-6.6	-6.1	-5.5	-4.3	-2.9	-1.5
$I'_E$ km.	0	-1.5	-2.9	-4.3	-5.5	-6.1	-6.6	-7.4	-8	-8.4
Course	270°	280°	290°	300°	310°	315°	320°	330°	340°	350°
$I'_N$ km.	0	+1.5	+2.9	+4.3	+5.5	+6.1	+6.6	+7.4	+8	+8.4
$I'_E$ km.	-8.6	-8.4	-6	-7.4	-6.6	-6.1	-5.5	-4.3	-2.9	-1.5

$I'_N$  - change in readings of north pointer  
 $I'_E$  - change in readings of east pointer

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



18. By comparing the actually obtained changes in the D.R. computer readings  $L'_N$  and  $L'_E$  with the rated values  $L_N$  and  $L_E$  determine the absolute errors in the readings of the D.R. computer north pointer  $\Delta L'_N$  and east pointer  $\Delta L'_E$ .

$$\Delta L'_N = L'_N - L_N ;$$

$$\Delta L'_E = L'_E - L_E .$$

19. Using the graph presented in Fig.22 determine covered distance  $L$  by the rated indications of the D.R. computer, i.e.  $L_N$  and  $L_E$ .

For example, a change in the readings of the north pointer  $L_N$  is 82 km. and that of the east pointer  $L_E$  is 78 km. Lay off 82 and 78 km. on the axes  $L_N$  and  $L_E$  respectively. From these points erect perpendiculars to the axes until they mutually intersect. Lay off the distance from the intersection point to the beginning of the coordinates on one of the coordinate axes (in this example it is axis  $L_N$ ). This distance will determine in the adopted scale the covered distance  $L$  in km. (in the given example the covered distance is 114 km.).

20. Making use of the graph given in Fig.23 determine the absolute error  $\Delta L$  by the covered distance.

For instance, the absolute error of the north computer  $\Delta L_N$  is 6.15 km. and that of the east computer  $\Delta L_E$  is 4.7 km.

From these points draw lines until they mutually intersect. Lay off the distance from the intersection point to the beginning of the coordinates on one of the axes and determine the absolute error of the set (in this example the absolute error of the computer  $\Delta L$  is 7.75 km.).

21. Determine the total error of the set  $\Delta$  from the formula:

$$\Delta = \frac{\Delta L}{L} \cdot 100\% .$$

22. Following the same routine determine the complete errors of the set at courses within the intervals from 90 to 180°, from 180 to 270° and from 270 to 360°.

The total errors obtained during the tests should be within the limits given in Table 5.

Table 5

Permissible Amounts of Total Errors

Ambient air temperature, °C	Total error of HM-50B set, %						
	altitude 0		altitude above 0 to 8000 m.		altitude from 8000 to 12,000 m.		
	speed 300 km/hr	speed from 300 to 1000 km/hr	speed up to 1100 km/hr	speed up to 1200 km/hr	speed up to 1100 km/hr	speed up to 1200 km/hr	
	1	2	3	4	5	6	7
+20 ± 5	7	5	5.5	7.5	6.5	7.5	
+50 ± 5	9	8	-	-	-	-	
-60 ± 5	9	8	8	9	8	9	

50X1-HUM

Should the total error of the set exceed the permissible value, determine the correction to the inner diagram change-over table of the indicator distribution box.

**Determination and Account of Correction to Inner Diagram Change-Over Table of Indicator Distribution Box**

"Correction" is the value which is to be algebraically added to the value of the air position indicator supply voltage (which is measured across terminals B of the distribution box) in order to determine the corrected voltage value and to change over the distribution box inner diagram correspondingly.

The correction is accounted for by the formula:

$$V_{cor} = V_{supply} \pm \Delta V \text{ (volts)}$$

where:  $V_{cor}$  - is the corrected voltage value, for which the distribution box inner diagram is to be changed over;

$V_{supply}$  - is the supply voltage to the air position coordinator, as measured across the terminals B of the distribution box;

$\Delta V$  - is the correction, volts.

If it is required, depending on the total errors obtained during the check, to increase the change in the readings of the D.R. computer pointers, take the correction with the sign "+", and if it is required to decrease the value, take the correction with the sign "-".

The correction value must be divisible by 0.5 V. A correction value equal to 0.5 V changes the readings of each D.R. computer pointer by 1.85%.

After determining the amount of correction to be introduced is correct, for which purpose correct algebraically the previously obtained values  $L'_N$  and  $L'_E$  (See Item 18), at which the total error proved to be in excess of the permissible value, by the value  $\pm 3.7 \Delta V$  in %, where  $\Delta V$  is the correction (in volts) to be introduced.

Determine by the new corrected values  $L'_N$  and  $L'_E$  the absolute error values of the north pointer  $\Delta L'_N$  and east pointer  $\Delta L'_E$  (See Item 18) and use them to calculate the total error of the set (See Items 20, 21 and 22), which will be obtained after this correction has been introduced.

If the calculated total error meets the requirements, change over the inner diagram of the distribution box in accordance with the selected correction and check the set again.

In case the set total error exceeds the permissible value and cannot be decreased to the value indicated in Table 5 no matter what value  $\Delta V$  is taken, it is required to check each unit of the set separately. The units must be checked on a JHM-50 installation only employing the method described in the Operating Instructions of this installation. On detecting a faulty unit, replace it and check the set again for the total error and correction to the change-over Table of the distribution box inner diagram. In changing over the diagram observe the instructions which are placed on the inner side of the distribution box cover.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 32 -

Checking the HMK-7 and HM-50 Instruments  
for Synchronous Operation

1. Switch on A.C. and D.C. power supply to the HMK-7 compass and HM-50B air position indicator.
2. Wait at least 5 minutes, then adjust the zero signal employing the method described in Section "Preflight Check".
3. Place a permanent magnet closely to the compass transmitter and rotate the magnetic variation spur rack of the main indicator to check the readings of the automatic course device for conformity to those of the compass main indicator at headings 0, 15, 30°, etc., every 15°. The readings of the automatic course device must not differ from those of the main pointer by more than 1°. Otherwise, match the readings by turning the respective deviation screws which are accessible through the holes in the rear wall of the automatic course device (Fig.24).

Gyro Horizon AFE-2

The AFE-2 gyro horizon is checked on type JHP-48 installation ensuring a turn of the gyro horizon with respect to the three mutually perpendicular axes: vertical, longitudinal and lateral.

The horizontal base of the turning table should be checked against a level. In addition to the JHP-48 installation, checking of the AFE-2 gyro horizon requires the employment of an electric panel whose diagram is presented in Fig.25.

The check is performed in the following sequence:

1. Place the gyro horizon on the turning table and connect it to the electric panel.
2. Switch on the power supply to the gyro horizon and start a stopwatch at the same time.
3. The line of the horizon should assume the horizontal position (accurate within  $\pm 1^\circ$ ) not later than three minutes after the power supply has been switched on.
4. In 5 or 6 min. after having energized the gyro horizon measure the voltage between the inverter phases. The voltage should be  $36 \pm 1$  V.  
If the voltage is other than specified, adjust it by changing the voltage of the supply inverter, type HAF-10.
5. Match the miniature airplane with the fixed indices on the front flange of the instrument.
6. Turn the casing of the gyro horizon about the longitudinal and lateral axes to match the horizon line with the miniature airplane.  
With the instrument in this position, tap it slightly to make sure that the slip indicator ball is located between the two central marks made on the slip indicator; see that there are no air bubbles in the slip indicator fluid. Remove air bubbles, if any, by turning the instrument casing clockwise about the longitudinal axis.
7. In 5 minutes after complete erection of the gyro match the vertical mark on the gyro horizon spherical shield with the zero division on the instrument bank scale. The gyro horizon error is characterized by the misalignment between the miniature airplane and the horizon line. This error must not exceed  $\pm 1^\circ$ .
8. Turn gradually the gyro horizon casing with respect to the longitudinal axis until the gyro unit contacts the rest to create a lateral tilt exceeding  $30^\circ$ ; in this case the tilt of the gyro unit will be in the longitudinal direction. Then return the instrument casing to initial position and turn it through  $90^\circ$

- 33 -

with respect to the vertical axis. Thus, the longitudinal tilt of the gyro unit is transferred into a lateral tilt (with respect to the gyro horizon casing). The lateral tilt in this case should be at least  $30^\circ$ . If the tilt is less than  $30^\circ$ , repeat tilting the gyro as indicated above.

9. Turn the gyro horizon casing through  $30^\circ$  with respect to the longitudinal axis (by the scale available on the turning table) in the same direction in which the gyro is tilted.

10. At the moment the horizon line coincides with the miniature airplane start the stopwatch.

The time from the moment the stopwatch is started to the moment the gyro returns to its initial position is considered as the gyro erection time from the lateral tilt.

11. Check the time required for gyro erection from the opposite lateral tilt in the same way.

The gyro erection time from lateral tilts must not exceed 4 - 8 min.

12. Check the gyro for erection time from longitudinal tilt. A longitudinal tilt is established by creating a lateral tilt through  $30^\circ$  and turning subsequently the instrument casing through  $90^\circ$  with respect to the vertical axis.

The time required by the gyro to erect from longitudinal  $30^\circ$  tilts should be within 6 - 11 min. The difference in the erection time when the gyro erects from opposite tilts must not exceed 3 min. When erecting from a longitudinal tilt the gyro must not tilt in the opposite direction by more than  $3^\circ$ , and when erecting from a lateral tilt its pitch must not exceed  $4^\circ$ .

Erecting Cutout, Type SM-53PE

The erecting cutout may be checked on type JHP-48 installation used to check gyro instruments. The check is performed with the aid of an electric panel whose diagram is presented in Fig.26. The erecting cutout is supplied from the HAF-10 inverter, which should be so adjusted as to produce a linear voltage of  $36 \pm 1$  V,  $400 \pm 10$  c.p.s. In 3 - 5 min. after the inverter is energized with D.C.  $27 \pm 1$  V current. The 3 - 5 minute time period is required for placing the gyro under working load (well-rising gyro, warmed up instrument).

The voltage and frequency are regulated by means of a variable resistor located in the inverter benchplate.

The erecting cutout is checked as follows:

1. Place the erecting cutout along with the shock absorbers on the turning table of the JHP-48 installation and connect it to the electric panel.
2. Set up a turning rate for the installation table of 0.2 or 0.3° per sec. depending on the adjustment of the erecting cutout to be checked. This adjustment value is to be found in the cutout Certificate.
3. Turn switch 2 to supply power and start simultaneously a stopwatch. Determine the time during which current in phase 1 will drop to 0.5 A. As this is done, the circuit of button 9 must be open. This time period must not exceed 3 min.
4. In 5 min. after power has been switched on, check the current in phase 1. The current must not exceed 0.45 A.
5. Use selector switch 11 to connect terminals A and 5 of the electric panel to terminals 6 and 7 of the erecting cutout. Make sure, with the aid of an ohmmeter, connected to terminals A and 5, that the latter are disconnected through the inner circuit of the erecting cutout.  
In connecting terminals A and 5 respectively to terminals 8, 9, 10, 11 and 12, 13 of the erecting cutout plug connector, terminals A and 5 should be shorted.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

6. Make the installation table rotate at a rate of 0.2 or 0.3° per sec. starting the stopwatch simultaneously.

The time elapsed from the moment the table was started to the moment terminals A and B close if they are connected to terminals 6 and 7 or open if they are connected to terminals 8 and 9; 10, 11 and 12, 13 of the erecting cut-out plug connector must be within 5 to 15 sec.

7. Not earlier than 30 sec. after checking the erecting cutout for its functioning time as it is rotated in one direction, check its functioning time when the cutout is turned in the other direction.

The difference between the time found under Item 6 and that found under Item 7 must not exceed 8 sec.

Resistance Thermometer, Type T2-48

The thermometer indicator is checked for accuracy of operation by cutting it in a circuit equivalent to the resistance thermometer (Fig. 27) in which the transmitter is replaced by any resistance box, that will permit to cut into the circuit resistance equivalent to the resistance of the transmitter accurate within 0.1 ohm.

The transmitter resistance values for various temperatures are given in Table 6.

Table 6  
Transmitter Resistance versus Measured Temperatures

Temperature, °C	Resistance, ohms	Temperature, °C	Resistance, ohms
-70	68.36	50	108.81
-60	71.06	60	112.78
-50	73.86	70	116.96
-40	76.86	80	121.22
-30	79.96	90	125.56
-20	83.16	100	129.96
-10	86.56	110	134.41
0	90.26	120	138.96
10	94.26	130	143.56
20	98.56	140	148.26
30	103.06	150	153.06
40	107.86	160	158.06

The error of the instrument is determined by the difference between the indicator reading and the actual temperature corresponding to the resistance cut into the circuit.

The indicator error at an ambient temperature of +20 ± 5°C must not exceed 15°C.

ENGINE INSTRUMENTS AND GAUGES  
GENERAL

The set of engine instruments and gauges included: T35-2 and T3-45 tachometers, TBI-11 and TBI-29 thermometers, 3BU-3 pressure gauge and 3WH-3P engine gauge unit. This section contains also information on type THT-13 thermometer of air temperature in the wing de-icing system duct.

Remote-Reading Electric Tachometers  
T35-2 and T3-45

The T35-2 and T3-45 tachometers are designed for continuous measurement of the aircraft engine and turbocharger shaft RPM respectively. Each of the instruments is a set consisting of a generator and single-pointer indicator.

Specifications  
Tachometer T35-2

1. Range of speed ..... from 0 to 5000 r.p.m.
2. Division value ..... 50 r.p.m.
3. Instrument error should not exceed:
  - (a) at +20 ± 5°C
    - 500 - 3500 r.p.m. .... 1% (±50 r.p.m.)
    - 3500 - 4800 r.p.m. (inclusively) ..... 10.5% (±25 r.p.m.)
    - 4800 - 5000 r.p.m. .... 1% (±50 r.p.m.)
  - (b) at +50 ± 5°C
    - 500 - 3500 r.p.m. .... 11.6% (±80 r.p.m.)
    - 3500 - 4800 r.p.m. (inclusively) ..... 10.8% (±40 r.p.m.)
    - 4800 - 5000 r.p.m. .... ± 1.6% (±80 r.p.m.)
  - (c) at -60 ± 5°C
    - 500 - 3500 r.p.m. .... 12.6% (±130 r.p.m.)
    - 3500 - 4800 r.p.m. (inclusively) ..... 11.3% (±65 r.p.m.)
    - 4800 - 5000 r.p.m. .... 12.6% (±130 r.p.m.)

Tachometer T3-45

1. Range of speed ..... from 400 to 3500 r.p.m.
2. Division value ..... 50 r.p.m.
3. Error at ambient temperature of +20 ± 5°C at divisions 600, 1000, 2000, 2600 and 3000 r.p.m. .... ± 3% r.p.m.

Exhaust Gas Thermometer TBI-11

The TBI-11 exhaust gas thermometer is intended to measure the mean temperature of the gases leaving the air-jet engine nozzle. It is a thermal electric set comprising the following units:

- Indicator TBI-11 ..... 1 piece
- transmitter, composed of:
- (a) thermocouples T-1 ..... 4 pieces
  - (b) connecting wires ..... 1 set

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 36 -

Basic Specifications

1. Measurement range ..... 300 - 900°C
2. Range of operating temperatures ..... 450 - 750°C
3. The reading error of the set must not exceed:
  - (a) at +20 ± 5°C
    - 450 - 640°C ..... 215°C
    - 650 - 750°C ..... 212°C
    - on remaining portion of scale ..... 225°C
  - (b) at +50 ± 5°C
    - 450 - 750°C ..... 216°C
    - on remaining portion of scale ..... 236°C
  - (c) at -60 ± 5°C
    - 450 - 750°C ..... 222°C
    - on remaining portion of scale ..... 244°C
4. Resistance of thermometer external circuit at ambient temperature of -20 ± 5°C ..... 2.5 ± 0.1 ohms

The indicators and transmitters are interchangeable within one graduation group. The connecting wires are interchangeable as a single set.

Exhaust Gas Thermometer TCT-29

The TCT-29 exhaust gas thermometer is designed for measuring the temperature of the exhaust gases leaving the air-jet engine turbostarter. The instrument is a thermal electric set comprising the following units:  
 Indicator TCT-2 ..... 1 piece  
 thermocouple T-9 ..... 1 piece  
 connecting wires ..... 1 set

Basic Specifications

1. Range of measurement ..... 0 - 900°C
2. Range of working temperatures ..... 600 - 800°C
3. Reading error of the set must not exceed:
  - (a) at +20 ± 5°C
    - 600 - 800°C ..... 220°C
    - on remaining portion of scale ..... 235°C
  - (b) at +50 ± 5°C
    - 600 - 800°C ..... 230°C
    - on remaining portion of scale ..... 255°C
  - (c) at -60 ± 5°C
    - 600 - 800°C ..... 240°C
    - on remaining portion of scale ..... 275°C
    - Error within 0 - 200°C ..... not checked
4. Resistance of external circuit at +20 ± 5°C ..... 9 ± 0.06 ohms
5. Indicator pointer oscillations with the engine running ..... ±10% max

The indicators, thermocouples and wire set are interchangeable.

- 37 -

Thermoelectric Thermometer THT-13

The THT-13 thermometer is employed for measuring the air temperature in the wing de-icing system duct. The instrument set is composed of the following units:

- thermocouple ..... 1 piece
- indicator ..... 1 piece
- compensating wires ..... 1 set

Basic Specifications

1. Range of measurement ..... from -50 to +350°C
2. Reading error of set must not exceed:
  - (a) at +20 ± 5°C
    - 100 - 260°C ..... 28°C
    - on remaining portion of scale ..... 216°C
  - (b) at +50 ± 5°C
    - 100 - 260°C ..... 213°C
    - on remaining portion of scale ..... 226°C
  - (c) at -60 ± 5°C
    - 100 - 260°C ..... 218°C
    - on remaining portion of scale ..... 236°C
3. Resistance of thermometer external circuit ..... 7.15 ± 0.05 ohms

The indicator and set of compensating wires are interchangeable.

Three-Pointer Electric Fuel Gauge Unit SMF-3P

The SMF-3P engine gauge unit is used for remote check of jet engine operation. The purpose of the SMF-3P gauge unit is to check:

- (a) oil pressure in engine oil line;
- (b) fuel pressure in idling rating manifold;
- (c) oil temperature at engine inlet.

The SMF-3P set (Fig.28) consists of the following units:

- oil pressure pick-up unit ..... 1 piece
- fuel pressure pick-up unit ..... 1 piece
- temperature pick-up unit ..... 1 piece
- electric remote indicator ..... 1 piece

The indicator comprises three metering gauges in one housing, each of which constitutes along with its pick-up unit an independent metering circuit.

Basic Specifications

1. Power supply ..... 27 V ± 10%
2. Range of measurement:
  - oil pressure gauge ..... from 0 to 10 kg/sq.cm.
  - fuel pressure gauge ..... from 0 to 100 kg/sq.cm.
  - oil thermometer ..... from 50 to +115°C
3. Maximum reading errors at ambient air temperature of +20 ± 5°C:
  - (a) oil pressure gauge at divisions 0, 2, 4, 6 and 8 ..... 20.4 kg/sq.cm.
  - at division 10 ..... 20.6 kg/sq.cm.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- (b) fuel pressure gauge at divisions 10, 20, 40, 60, 80 and 90 ..... 23 kg/sq.cm.
  - at divisions 0 and 100 ..... 25 kg/sq.cm.
  - (c) oil thermometer at divisions -40, 50, 0, 100 and 130 ..... 24°C
  - at divisions -50 and +150 ..... 26°C
4. Permissible overload:
- for oil pressure gauge pick-up unit ..... 15 kg/sq.cm.
  - for fuel pressure gauge pick-up unit ..... 120 kg/sq.cm.

The units of the 8MW-3P set are interchangeable.

Remote-Reading Electric Pressure Gauge 8MW-3

The 8MW-3 pressure gauge is used to check the fuel pressure before the high-pressure fuel pumps. It is a set comprising a pressure pick-up unit and a remote-reading electric indicator.

Basic Specifications

- 1. Supply voltage ..... 27 ± 2.7 V
- 2. Range of measurement ..... 0 - 3 kg/sq.cm.
- 3. Working portion ..... 0.6 - 2.4 kg/sq.cm.
- 4. Maximum error on working portion at ambient temperature of +20 ± 5°C ..... ±% from measurement limit
- 5. Permissible overload ..... up to 4.5 kg/sq.cm.

The units of the 8MW-3 set are interchangeable.

MAINTENANCE INSTRUCTIONS

In service the engine instruments and gauges should be checked before flight in compliance with the methods described below, as well as in cases specially specified.

Preflight Inspection

The preflight inspection of the engine instruments and gauges is confined to visual examination of the units belonging to the sets of the instruments and gauges.

During visual examination of the instruments make sure whether they are not damaged on the outside, that they are reliably secured to the instrument board or respective attachment brackets. See also that the plug connectors are well connected and the wires are properly terminated. Check to see that the wires are not broken at places of termination, and that the compensating wires make a reliable connection at their joints, etc.

Checking the Instruments for Correspondence to Their Basic Specifications

This check is to be carried out as soon as doubt arises as to the correctness of operation of some instruments, and at least once every three months. In addition to the description of this check, the section contains a Table dealing with the most frequent faults, their causes and remedies.

Remote-Reading Electric Thermometers T35-2 and T3-45

Check the thermometers in service on a special thermometer installation at least once every 6 months. The check consists in comparing the readings of the thermometer under test with those of a reference thermometer. The reading error of the thermometer must not exceed the values given in the "Basic Specifications" for the T35-2 and T3-45 thermometers.

Thermometer TBF-11

The connecting wires are checked for resistance as follows:

- 1. Disconnect the plug connector from the indicator.
- 2. Using additional wires connect the terminals of the disconnected plug connector to terminals R<sub>1</sub> of the T3B-49 electric bridge or some other bridge ensuring measurement of resistance within the range of 0 to 10 ohms with an accuracy of 20.01 ohm.
- 3. Determine the resistance R<sub>total</sub> of the wires connected to terminals of the bridge.
- 4. Determine the resistance R<sub>add</sub> of the wires by means of which the plug connector terminals have been connected to the terminals R<sub>1</sub> of the bridge.
- 5. Determine the resistance of the thermocouple connecting wires from the

$R_{wire} = R_{total} - R_{add}$

where R<sub>wire</sub> - resistance of thermocouple connecting wires.

The resistance of the TBF-11 thermometer connecting wires at ambient temperature of +20 ± 5°C should be 2.5 ± 0.1 ohms. If this resistance is other than specified, it must be adjusted by changing the value of the series resistor placed inside the socket of the indicator plug connector.

The indicator is checked for reading errors as follows:

Cut the indicator into an electric circuit equivalent to the thermoelectric thermometer and employing a dry cell with a potentiometer as a source of electromotive force (See Fig.29).

The voltage fed to the indicator terminals, is measured with the aid of millivoltmeter of an accuracy class not less than 1.0. When performing this check, it is well to bear in mind that the resistance of the wires connecting the reference millivoltmeter to the indicator under check depends on the ambient temperature as well as on indicator scale division to be checked. This resistance must correspond to the values indicated in Table 7.

Table 7

Wire Resistance as Function of Temperature and Indicator Scale Division to Be Checked

Scale division to be checked	Resistance of external circuits, ohms, at ambient temperatures of		
	+20°C	+50°C	-60°C
1	2	3	4
300	2.6	2.6	2.4

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 40 -

	1	2	3	4
400		2.7	2.7	2.5
500		2.7	2.7	2.5
600		2.8	2.8	2.6
700		2.8	2.8	2.6
800		2.8	2.8	2.6
900		2.9	2.9	2.7

The value of the electromotive force applied to the indicator terminals depends on the scale division under check and on the calibration of the thermocouple. This value is to be found in Table 8.

Table 8

Electromotive Force as Function of Indicator Division under Check and of Thermocouple Calibration

No.	Calibration index	Value of electromotive force in mV for temperatures of							
		300°C	400°C	500°C	600°C	700°C	800°C	900°C	
1	O	-	-	7.16	13.48	20.0	26.64	33.76	
2	P	0.96	4.16	10.24	17.88	25.08	33.04	41.08	
3	T	-	5.46	11.31	17.76	24.26	30.92	37.52	
4	M	-	3.36	8.92	15.32	21.84	28.52	35.2	
5	K	-	3.68	9.32	15.56	22.08	28.56	34.92	
6	H	1.44	6.56	13.68	21.72	30.04	38.04	46.2	
7	A	1.52	6.6	13.76	21.48	29.56	37.68	45.48	
8	E	-	6.48	13.08	20.72	28.92	36.96	44.58	
9	F	-	6.04	13.4	21.08	29.16	37.28	45.44	
10	B	1.4	6.36	13.36	21.08	29.16	37.28	45.48	
11	T	1.32	6.16	12.96	20.68	28.76	36.88	44.8	
12	L	1.68	6.68	13.92	21.72	29.84	37.92	45.96	
13	Z	1.52	6.4	13.64	21.44	29.56	37.64	45.68	
14	S	1.36	6.12	13.36	21.16	29.28	37.36	45.4	
15	K	1.84	6.72	14.12	22.16	30.64	38.92	47.12	
16	N	-	6.12	13.36	21.32	29.56	37.8	45.96	

The value of the reading error is determined as the difference between the indicator reading and the actual temperature value at the given electromotive force. The indicator error must not exceed the values presented in Table 9.

- 41 -

Table 9

Permissible Reading Error of TBI-11 Thermometer

Ambient temperature, °C	Indicator error, °C		
	450 - 640°C	650 - 750°C	Non-working range
+20 ± 5	±10	±7	±18
+50 ± 5	±13	±13	±26
-60 ± 5	±15	±15	±30

CAUTION: The TBI-11 are manufactured with transmitters (thermocouples) of various calibration. Each calibration group has its own thermal electromotive force which differs from that of the other groups.

To distinguish one calibration group from another, each of them is given its own index indicated on the scale, thermocouple cap as well as in the Certificates.

The indicators and transmitters are mutually interchangeable in one and the same calibration group only, except groups E and B and groups A and 2 which are mutually interchangeable.

In performing the check see to it that the indicator is kept for at least 2 hours at the temperature at which the check is to be performed.

Thermometer TBT-29

The resistance of the connecting wires is checked as follows:

1. Disconnect the plug connector from the indicator.
2. Connect, with the aid of additional wires, the terminals of the disconnected plug connector to terminals  $R_2$  of the electric bridge, type JNB-49, used for measuring the resistance or some other bridge ensuring measurements accurate within 0.01 ohm.
3. Determine the resistance  $R_{total}$  of the wires connected to the terminals  $R_2$  of the bridge.
4. Determine the resistance  $R_{wire}$  of the wires by means of which the terminals of the plug connector are connected to the terminals  $R_2$  of the bridge.
5. Determine the resistance of the thermocouple connecting wires from the formula:

$$R_{wire} = R_{total} - R_{add}$$

where  $R_{wire}$  - resistance of thermocouple connecting wires.

The resistance of the connecting wires at ambient temperature of +20 ± 5°C should be 9 ± 0.06 ohm.

The indicator error is checked as follows:

Cut the indicator into an electric circuit equivalent to the thermoelectric thermometer and employing a dry cell with a potentiometer as a source of electromotive force (See Fig.30). The voltage applied to the indicator terminals is measured with a millivoltmeter of an accuracy class not below 1.0. The resistance of the wires connecting the reference millivoltmeter with the indicator under check must be equal to 9 ± 0.6 ohm.

The value of the electromotive force applied to the indicator terminals

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

depends on the indicator scale division to be checked and on the ambient temperature at which the check is performed. This value is to be found in Table 10.  
The error value is determined as the difference between the indicator reading and the actual temperature at the given electrostatic force. The indicator reading error must not exceed  $\pm 12^{\circ}\text{C}$  within a reading range of 500 to 800 $^{\circ}\text{C}$  and  $\pm 2^{\circ}\text{C}$  on the remaining portion of the indicator scale.

**CAUTION:** In performing the check see to it that the indicator is kept for at least 2 hours at the temperature at which the check is to be performed.

Thermoelectric Thermometer THW-13

1. Disconnect the connecting wires is checked as follows:
2. Connect, with the aid of additional wires, the terminals of the disconnected plug connector to the terminals  $R_x$  of the electric bridge, type JMB-49, used for measuring the resistance or any other bridge ensuring a measurement accuracy up to 0.01 ohm.
3. Determine the resistance  $R_{\text{total}}$  of the wires connected to the terminals  $R_x$  of the bridge.
4. Determine the resistance  $R_{\text{add}}$  of the wires, by means of which the plug connector terminals have been connected to the terminals  $R_x$  of the bridge.
5. Determine the resistance of the thermocouple connecting wires from the formula:

$$R_{\text{wire}} = R_{\text{total}} - R_{\text{add}}$$

where  $R_{\text{wire}}$  - resistance of thermocouple connecting wires.

The resistance of these wires at an ambient temperature of  $+20 \pm 5^{\circ}\text{C}$  should be  $7.15 \pm 0.05$  ohms.

The indicator error is checked as follows: cut the indicator into an electric circuit equivalent to the thermoelectric thermometer and employing a dry cell with a potentiometer (Fig. 30) as a source of electrostatic force. The voltage of the potentiometer must be fed to a reference millivoltmeter whose accuracy class is not below 1.0. The indicator to be checked is connected to the terminals of the reference millivoltmeter through wires whose resistance is  $7.15 \pm 0.05$  ohms. The value of the electrostatic force which is determined by the millivoltmeter depends on the scale division to be checked, as well as on the ambient temperature. This value can be found in Table 11.

The error value is determined as the difference between the indicator reading and the actual temperature value at the given electrostatic force. The indicator reading error must not exceed  $\pm 5^{\circ}\text{C}$  within the range of 100 to 250 $^{\circ}\text{C}$  and  $\pm 10^{\circ}\text{C}$  on the remaining portion of the scale.

**CAUTION:** In performing the check see to it that the indicator is kept for at least two hours at the temperature at which the check is to be performed.

Table 10

Electrostatic Force as Function of Indicator Scale Division under Check and of Ambient Temperature

Scale Division to be checked	Electrostatic force in mV at ambient temperatures of									
	15 $^{\circ}\text{C}$	16 $^{\circ}\text{C}$	17 $^{\circ}\text{C}$	18 $^{\circ}\text{C}$	19 $^{\circ}\text{C}$	20 $^{\circ}\text{C}$	21 $^{\circ}\text{C}$	22 $^{\circ}\text{C}$	23 $^{\circ}\text{C}$	25 $^{\circ}\text{C}$
200	7.53	7.49	7.45	7.41	7.37	7.33	7.29	7.25	7.21	7.17
300	11.61	11.57	11.53	11.49	11.45	11.41	11.37	11.33	11.29	11.25
400	15.79	15.75	15.71	15.67	15.63	15.59	15.55	15.51	15.47	15.43
500	20.04	20.00	19.96	19.92	19.88	19.84	19.80	19.76	19.72	19.68
600	24.30	24.26	24.22	24.18	24.14	24.10	24.06	24.02	23.98	23.94
700	28.54	28.50	28.46	28.42	28.38	28.34	28.30	28.26	28.22	28.18
800	32.71	32.67	32.63	32.59	32.55	32.51	32.47	32.43	32.39	32.35
900	36.76	36.72	36.68	36.64	36.60	36.56	36.52	36.48	36.44	36.40

Table 11

Electrostatic Force as Function of Indicator Scale Division and Ambient Temperature

Indicator division to be checked	Electrostatic force in mV at ambient temperatures of									
	15 $^{\circ}\text{C}$	16 $^{\circ}\text{C}$	17 $^{\circ}\text{C}$	18 $^{\circ}\text{C}$	19 $^{\circ}\text{C}$	20 $^{\circ}\text{C}$	21 $^{\circ}\text{C}$	22 $^{\circ}\text{C}$	23 $^{\circ}\text{C}$	25 $^{\circ}\text{C}$
50	2.37	2.30	2.24	2.17	2.11	2.04	1.97	1.91	1.84	1.78
100	5.97	5.90	5.84	5.77	5.71	5.64	5.57	5.51	5.44	5.38
150	9.71	9.64	9.58	9.51	9.45	9.38	9.31	9.25	9.18	9.12
200	13.67	13.60	13.53	13.46	13.40	13.33	13.26	13.20	13.13	13.08
250	17.78	17.71	17.65	17.58	17.52	17.45	17.38	17.32	17.25	17.19
300	21.92	21.85	21.79	21.72	21.66	21.59	21.52	21.46	21.39	21.33
350	26.10	26.03	25.97	25.91	25.84	25.77	25.71	25.64	25.58	25.51

50X1-HUM

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 44 -

Three-Pointer Electric Engine Gauge  
Unit 3M3-3P

The purpose of the check is to:

- (1) find the error of the instrument at an ambient temperature of  $\pm 20 \pm 5^\circ\text{C}$ ;
- (2) find the insulation of the electrical elements of the pick-up units (transmitters) and indicators;
- (3) determine the airtightness of the pressure gauge pick-up unit casing;
- (4) determine how tilts of the indicator affect its readings;
- (5) determine the resistance of the heat-sensitive element of the pick-up unit at  $0^\circ\text{C}$  and at  $+100^\circ\text{C}$ .

The following equipment is required for performing the checks:

1. Wire bundles for interconnecting the units belonging to the 3M3-3P set in accordance with the diagrams given in Figs 31, 32 and 33.
2. Reference pressure gauges up to 15 and up to 150 kg/sq.cm.
3. Resistance box, type RMC, or any other box ensuring selection of resistances accurate within 0.1 ohm.
4. Pressure feed cocks.
5. Wheatstone bridge of JMB type or any other bridge, ensuring measurement of the resistances accurate within 0.2%.
6. Megger with a voltage of 500 V across the feelers.
7. Mercury pressure gauge rated for 1 kg/sq.cm.
8. Source of pressure up to 120 kg/sq.cm.
9. Source of direct current, 27 V.
10. Fittings (2-pieces, pipes, etc.).

Oil Pressure Gauge

The oil pressure gauge is checked as follows:

1. Assemble the 3M3-3P set in accordance with the diagram given in Fig. 34.
2. Making use of the cocks create a pressure in the oil pressure gauge system of 0, 2, 4, 6, 8 and 10 kg/sq.cm. consecutively (the pressure is to be checked by a reference pressure gauge).
3. Keep the system under a maximum pressure of 10 kg/sq.cm. for 15 min.
4. Reduce the pressure in the system consecutively in the reversed order.
5. The reading error is determined as the difference between the readings of the reference gauge and those of the gauge under check.

Before taking the reading tap slightly against the indicator casing and the casing of the respective pressure pick-up unit.

The influence of inclination of indicator 2 on the readings of the set is checked simultaneously with the check for reading errors. With the indicator inclined through  $90^\circ$  to the right or left, the error must not exceed  $20.4 \text{ kg/sq.cm.}$  at divisions 0, 2, 4, 6 and  $8 \text{ kg/sq.cm.}$  and  $20.6 \text{ kg/sq.cm.}$  at division 10 kg/sq.cm.

In order to check the casing of the pressure gauge pick-up unit for airtightness, assemble the set in accordance with the diagram in Fig. 35.

Open the inlet cock and create a pressure of 850 mm of mercury in the pick-up unit casing and in the sensitive element simultaneously. Close the inlet cock and watch the mercury level during one minute. Drop of the mercury level for one minute must not exceed 8 mm.

The insulation of the current-carrying elements of the pick-up units and indicators with respect to their casings should be at least 20 megohms at an ambient temperature of  $\pm 20 \pm 5^\circ\text{C}$  and relative humidity of 30 to 65%.

- 45 -

Fuel Pressure GaugeThe fuel pressure gauge is checked in the same way as the oil pressure gauge. The reading error of the fuel pressure gauge at divisions 10, 20, 40, 60, 80 and 90 kg/sq.cm. must not exceed  $25 \text{ kg/sq.cm.}$ Oil Thermometer

In order to perform the check, cut the temperature indicator into the circuit shown in Fig. 34. Set resistance on the resistance box which would correspond to the indicator scale division to be checked. The resistance values are to be found in the respective table.

The error is determined as the difference between the reading of the temperature indicator and the temperature value for which the resistance has been selected in the resistance box. The error must not exceed  $2.0^\circ\text{C}$  at divisions -40, 0, 20, 100 and  $130^\circ\text{C}$ , and  $1.6^\circ\text{C}$  at divisions -50 and  $+150^\circ\text{C}$ .

The resistance of the heat-sensitive element of the oil thermometer is determined with the aid of an JMB Wheatstone bridge or any other instrument which will ensure a measurement accuracy within 0.2%. Submerge first the temperature pick-up unit into a vessel with thawing ice, measure the resistance of its sensitive element, then submerge it into boiling water and measure the resistance again. The resistance is to be measured not earlier than in 5 min. after the pick-up unit was submerged into the respective medium. During the check the entire thin cylindrical portion of the pick-up unit must be submerged in the medium under check.

The resistance of the pick-up unit sensitive element must correspond to the resistance indicated in the Certificate of the given pick-up unit.

**CAUTION:** 1. Pressure must be supplied to the fuel pressure gauge pick-up unit through a plate damper only. Inobservance of this condition leads to premature failure of the pick-up unit.

2. Prior to installing on the aircraft a damper that was already in use, it must be checked as follows:

- (a) connect it to the compressed air system and apply a pressure of 2-3 atm.;
- (b) if the air passes through the damper, the letter may be installed on the aircraft.

Remote-Reading Electrical Pressure Gauge 3M3-3The 3M3-3 pressure gauge is checked in the same way as the oil pressure gauge of the 3M3-3P set. The wire bundle diagram for checking the 3M3-3 oil pressure gauge is given in Fig. 31. The error of the 3M3-3 set within the measurement range of 0.6 to  $2.4 \text{ kg/sq.cm.}$  must not exceed 1% from the rated value of the scale.

SECRET

NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM



TROUBLE AND REMEDIES

Trouble	Probable cause	Remedy
1	2	3
<u>Thermometers TG-45 and TG5-2</u>		
With the engine running the instrument pointer will not start from zero	(a) Broken wires between generator and indicator (b) Wires from generator to indicator short-circuited	Find faulty place and remedy the wires Find and remedy fault
Indicator readings too low	Faulty indicator	Replace indicator
<u>Thermometer TBP-11</u>		
Indicator pointer stands against zero division when temperature in inner cone differs considerably from instrument reading	(a) Thermocouple or connecting wires open-circuited (b) Connecting wires contact each other (c) Thermocouple ends in junction box are connected in opposition	Find and remedy fault Find and remedy fault
Indicator pointer deflects to left from zero	(d) Faulty indicator Polarity in junction box or indicator plug connector reversed	Rearrange the thermocouple ends in accordance with the diagram given in the description Replace indicator Connect wires in accordance with diagram given in description
Indicator pointer dances	Poor contact in connecting wires	Find and remedy fault
Indicator reading too low as compared with actual temperature in inner cone	(a) Wires of one or several thermocouples closed (b) Polarity of one thermocouple reversed (c) Indicator circuit faulty (d) Poor contact in connecting wires	Find and eliminate fault Connect wires in accordance with diagram Replace indicator Find and eliminate fault Replace indicator
Indicator reading too high as compared with actual temperature in inner cone	Faulty indicator	Replace indicator
<u>Thermometer TCB-29</u>		
Gauge pointer stands against zero division when temperature in inner cone differs	(a) Connecting wires open-circuited (b) Indicator plug connector open-circuited	Find and eliminate fault Find and eliminate fault

50X1-HUM

1	2	3
considerably from instrument readings	(c) Thermocouple open-circuited (d) Faulty indicator (e) Connecting wires short-circuited	Replace thermocouple Replace indicator Find and eliminate fault
Instrument readings too low	(a) Faulty indicator (b) Poor contact in connecting wires	Replace indicator Find and eliminate fault
Instrument readings too high	Faulty indicator	Replace indicator
Instrument readings not stable	Defective contact in places of connecting wire joints	Find and eliminate fault
<u>Thermometer THU-13</u>		
With thermocouple cut in, instrument indicator will not operate	(a) Compensatory wires open-circuited (b) Faulty indicator (c) Connecting wires contact each other	Find and eliminate fault Replace indicator Find and eliminate fault
Instrument readings not stable	(a) Defective contact in places of connecting wire joints	Find and eliminate fault
Instrument readings too low	(b) Faulty indicator (c) Poor contact in places of connecting wire joints	Replace indicator Find and eliminate fault
Instrument readings too high	(b) Faulty indicator Faulty indicator	Replace indicator Replace indicator
<u>Engine Gauge Unit 8MU-3P</u>		
<u>Fuel Pressure Gauge</u>		
When power supply is switched on, pointer remains in position OFF	(a) No power in mains	Check power supply line and remedy if it is broken Remedy plug connectors
	(b) Faulty contact in plug connector terminals	Replace pressure pick-up unit
	(c) Flexible wire in pressure pick-up unit broken	Replace pressure pick-up unit
	(d) Faulty brush contact in pressure pick-up unit	Replace pressure pick-up unit
At no pressure pointer shows 70	Reversed polarity	Reverse polarity

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

1	2	3	1	2	3
At no pressure pointer will not come to stand against zero division	(a) Pick-up unit potentiometer turns shorted (b) Membrane swollen	Replace pressure pick-up unit Replace pressure pick-up unit	move away from it when indicator is shaken	(c) Faulty contact in plug connector terminals B	Find and correct fault
At no pressure pointer will not stand against division 6 kg/sq.cm. When pressure is increased up to 100 kg/sq.cm. pointer stops against division 40 kg/sq.cm. and returns to 6 kg/sq.cm.	Wire running to plug connector terminal A broken Faulty contact in plug connector terminals A	Find and remedy fault	With power supply switched on, pointer is pressed to upper rest	Broken wire or faulty contact in plug connectors	Find and correct fault
At no pressure pointer stops against division 100 kg/sq.cm.	Wire running to plug connector terminal B broken	Find and remedy fault	In checking instrument for error corrections are beyond permissible limits	(a) Wrong adjustment of pressure pick-up unit (b) Amount of indicator adjustment resistances has changed.	Replace pressure pick-up unit Replace indicator
When pressure is increased, pointer goes to division 60 kg/sq.cm. and returns then to 100 kg/sq.cm.	Faulty contact in plug connector terminals B	Find and eliminate fault	When power supply is switched on pointer will not move away from lower rest	Oil Thermometer No power in supply line	Check power supply line and remedy it if it is broken
At no pressure pointer stands below zero division	Wire running to plug connector terminal F broken	Find and eliminate fault	Pointer leaves lower rest when indicator is shaken	Faulty contact in indicator plug connector	Find and correct fault
When pressure is increased pointer moves between divisions 0 and 100 outside the scale	Faulty contact in plug connector terminals F	Find and eliminate fault	With power supply switched on, pointer is pressed to lower rest	Broken wire or faulty contact in plug connector	Find and remedy fault
At no pressure pointer stands at division 30 kg/sq.cm.	Wire running to plug connector terminal A broken	Find and remedy fault	With power supply switched on, pointer is pressed to upper rest	(a) Sensitive element broken (b) Broken wire	Replace temperature pick-up unit Find and remedy fault
When pressure is increased, pointer shifts to 70 kg/sq.cm. and then returns to 30 kg/sq.cm.	Faulty contact in plug connector terminals A	Find and correct fault			
	<u>Oil Pressure Gauge</u>				
When power supply is switched on pointer will not start from low division, but this happens when indicator is shaken	(a) No power in supply line (b) Brush contact in pressure pick-up unit broken	Check power supply line and remedy it if it is broken Replace pressure pick-up unit			
With power supply switched on pointer is pressed to lower rest and will not	(a) Reversed polarity (b) Wire running to plug connector terminal B broken	Reverse polarity Find and correct fault			
			<p><b>ELIMINATION OF COMPASS DEVIATION ON INSTRUMENTS</b> AHK-7, AFK-5, HOG 1 AND 2 AND EH-12</p> <p>Checking AHK-7 compass for Synchronous Operation with EH-505 Air Position Indicator</p> <p>In case faulty compasses are replaced by new one, as well as when wrong readings have been discovered in the flight or in case of compass misalignment, check the compass for operation on the ground and calibrate the compass.</p> <p>Ground swinging is performed also when replacing:</p> <p>(a) engines; (b) AHK-7 compass transmitters; (c) EH navigator's indicators of AHK-7 compass; (d) frames of AFK-5 compass Nos 1 and 2.</p> <p>Compass calibration on the aircraft is performed in order to determine and correct semi-circular deviations and to determine or compensate the residual deviation.</p> <p>The automatic course device of the EH-505 air position indicator is checked for synchronous operation with the navigator's main indicator EH of the AHK-7</p>		

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 50 -

compass in order to determine the mismatching angle. If this angle exceeds 1°, use the deviation adjusting screws to synchronize the pointer readings.

General

1. Before bringing the aircraft to the deviation correcting ground, check the operation of the instruments, which are to be used during elimination of deviations.

2. Operations related to elimination of deviations are to be performed on special ground located at least 500 m. away from steel structures, underground power cables, metal tubes, buildings, H.T. lines, forests and other objects causing a change in the earth magnetic field.

3. The attending personnel who takes part in operations on correcting deviation should not use any tools made of ferromagnetic materials (steel screwdrivers, flat pliers, etc.).

4. Deviations are to be eliminated with the engines stopped.  
5. RH-12 and ANK-7 compasses are to be calibrated simultaneously (both compasses must be checked without fail).

6. Calibrate ANK-5 compass Nos 1 and 2 separately.  
7. Supply the electric mains of the aircraft from a ground source of power through a special plug connector. The mains voltage is 27.5 - 28 V D.C. and 115 ± 0.5 V A.C., 400 c.p.s. (through airborne inverter HO-4500).

8. Before starting to correct deviation do the following:

- (a) switch on the CUV-10 interphone set;
- (b) switch on the SVH-53 turn indicator;
- (c) switch on two AFS-2 gyro horizons (the AFS-2 gyro horizon mounted on the right-hand board and one of the AFS-2 gyro horizons installed on the left-hand board);
- (d) switch on the RHK-52 directional gyro;
- (e) unlock the controls, place the pedals and control wheels in neutral position;
- (f) set the PNI-4 indicator of the navigator in stowed position;
- (g) switch on the AN-5-2M autopilot;
- (h) set up the clock (working);
- (i) place the armament and sight post in stowed position;
- (j) set the OIB-11p sight.

9. In addition to the above-said follow the instructions given in the descriptions of the AFS-5, RH-12, ANK-7 and RH-50B instruments.

Installation of Direction Finder on Aircraft and Position of Aircraft When Turning to Assume Required Readings

1. The aircraft is headed with the aid of a RD direction finder.

**Note:** To head the aircraft it is advisable to use the method of "tail" direction finding at a distance of 150 - 200 m. In this case the direction finder must be placed at the above distance from the rear cabin of the aircraft on a tripod.

2. The sequence of heading an aircraft is given in the description of the deviation direction finder. This description is supplied with the instrument along with the Service Log.

3. When the aircraft is headed the L.H. wheel of the main landing gear

- 51 -

should describe the circumference marked off on the deviation ground, the right leg being inside the circumference.

4. The aircraft is turned by a towing truck with the aid of a drawbar.

**Note:** In case the truck and drawbar influence the readings of the compasses they should be taken away from the aircraft each time the aircraft is turned to a new heading.

Elimination of Deviation of ANK-7 Remote-Reading Gyro-Magnetic Compass

Correction of compass deviation consists of:

- (1) elimination of permanent and semi-circular deviation by means of the deviation instrument of the RHK-3 transmitter (first stage);
- (2) elimination of quarter deviation and remote-reading errors of the RHK-3 transmitter with the aid of a mechanical compensator (profiling device) located in the navigator's indicator (second stage).

Elimination of Permanent and Semi-Circular Deviation

Permanent deviation is corrected as follows:

- (a) switch on power supply to the compass;
- (b) in two-three minutes after switching on power supply to the compass proceed to correction of permanent deviation for which purpose place the aircraft at magnetic courses of 0, 90, 180 and 270° in turn;
- (c) at each of the magnetic courses determine the deviation as the difference in the readings of the magnetic course of the aircraft and the compass course in the readings of the navigator's indicator.

Each time before taking the readings, align the navigator's indicator and the transmitter by pressing the slaving button. Keep the slaving button pressed not less than 15 sec.

The algebraic deviation sum at all four courses divided by four will produce the setting error.

If permanent deviation exceeds 2°, it should be eliminated by turning the RHK-3 transmitter, for which purpose ease off the screw and turn the transmitter casing in the ring with respect to the base through an angle equal to that of the permanent deviation. The casing turning angle is counted by the scale available on the ring.

Semi-circular deviation is corrected by permanent magnets of the deviation instrument at all four magnetic courses (0, 90, 180 and 270°). The semi-circular deviation at the given four magnetic courses is determined in the same way as when correcting permanent deviation. Here we usually encounter two cases:

**First case.** At courses 0 and 90° the initial deviation exceeds 10°. In this case place the aircraft at zero° and turn the extension piece (magnet) E - S to zero the deviation; at magnetic course 180° turn the same extension piece to halve the deviation value; at magnetic course 90° turn the extension piece E - W to zero the deviation; at magnetic course 270° turn the same extension piece to halve the deviation.

**Second case.** At courses 0 and 90° the initial deviation is less than 10°. In this case determine and record the deviation at magnetic courses 0 and 90°. At magnetic course 180° bring the deviation value to  $\frac{C_0 + C_{180}}{2}$ . At magnetic course 270° bring the deviation value to  $\frac{C_{90} + C_{270}}{2}$ .

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

**Elimination of Total Quarter Deviation and Remote-Reading Error**

The total error is corrected as follows:

- (a) place the aircraft at one of the 24 courses (0, 15, 30, 45°, etc.), at which the compass error is the least;
- (b) align the indicator with the transmitter by pressing the slaving button;
- (c) making use of the handle of the navigator's indicator, place the magnetic variation scale to zero, setting index B against zero;
- (d) turn off the adjusting wrench and remove the pad to give access to the 24 adjusting screws;
- (e) eliminate the compass error at the given course by turning that screw at which the pointer of the navigator's indicator indicates. The screw is turned with the aid of the adjusting wrench.

**Example.** The aircraft is placed exactly at 180°, the slaving button is pressed, the indicator pointer shows 181°. Turn the screw at which the pointer indicates to place the pointer exactly against division 180°, and the compass error at the given point will be eliminated.

The compass errors at the other points are eliminated after each turn of aircraft through 15° in the same sequence as indicated above.

After elimination of deviation, the instrument pad must be put in place and the adjusting screw turned into its seat.

Simultaneously with residual error elimination and making charts of the navigator's indicator residual errors, make also charts of the repeaters residual errors.

- Notes:**
1. When eliminating deviation, with the engines stopped, take the indicator reading only after correcting the lag of the magnetic transmitter which is achieved by tapping the instrument on the casing.
  2. The maximum error which can be eliminated with the help of any adjusting screw is 6°.

**Elimination of Deviation of M-12 Magnetic Compass**

Prior to eliminating the deviation of the M-12 magnetic compass, do not fail to switch off the fans and the glass electric heaters. Elimination of deviation of the M-12 compass consists in determining and correcting the setting error, eliminating the semi-circular deviation and in determining and correcting the residual deviation.

**Determination and Elimination of Setting Error**

- (a) Place the aircraft at the four main magnetic courses (0, 90, 180 and 270°) and calculate the setting error as the algebraic sum of the four deviation readings divided by 4.
- (b) Correct the setting error of the navigator and pilots' compasses by turning the brackets through the value of the setting error. Turn the bracket to the left in case of a plus error and to the left in case of a minus error.

**Elimination of Semi-Circular Deviation**

- (a) Place the aircraft at zero magnetic course. Use magnet N - S to make the compass read zero.

- (b) Place the aircraft at magnetic course 180°. Use magnet N - S to halve the deviation:  $\frac{(C_0 + C_{180})}{2}$

- (c) Place the aircraft at magnetic course 90°. Use the E - W magnet to set the compass exactly at 90°.

- (d) Place the aircraft at magnetic course 270° and use the E - W magnet to halve the deviation:  $\frac{(C_{90} + C_{270})}{2}$

**Determination and Elimination of Residual Deviation**

Residual deviation is determined and corrected at eight points: 0, 45, 90, 135, 180, 225, 270 and 315°.

Correct the deviation charts. Residual deviation must not exceed 2.5°.

**Elimination of Radio Deviation of APK-5 Radio Compasses Nos 1 and 2**

**General**

1. The azimuth rings of the APK-5 compass No.1 have black-painted numerals, whereas those of APK-5 compass No.2 are painted red. On some aircraft the numerals on the rings of both compasses are painted black.

2. The frames of APK-5 compasses Nos 1 and 2 should be compensated in accordance with Tables 12 and 13.

**Note:** The difference in the tables is a result of different installation of the frame of APK-5 compass No.2.

Table 12

Standard Correction Compensating Angles at Eliminating Radio Deviation of APK-5 Compasses Nos 1 and 2

Radio station course angle, deg.	Averaged ΔP for compensation, deg.		Radio station course angle, deg.	Averaged ΔP for compensation, deg.	
	APK-5 No.1	APK-5 No.2		APK-5 No.1	APK-5 No.2
0	0	0	180	0	0
15	+12	+6	195	+11	+6
30	+18	+11	210	+16	+12
45	+19	+14	225	+16	+15
60	+16	+14	240	+13	+16
75	+10	+10	255	+7	+10
90	+3	+1	270	0	+1
105	-5	-6	285	-7	-6
120	-9	-10	300	-13	-10
135	-14	-12	315	-16	-11
150	-13	-9	330	-16	-9
165	-10	-6	345	-12	-5

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

Table 13

Standard Correction Compensating Angles  
at Eliminating Radio Deviation of APK-5  
Compasses Nos 1 and 2

Radio station course angle, deg.	Averaged ΔP for compensation, deg.		Radio station course angle, deg.	Averaged ΔP for compensation, deg.	
	APK-5 No.1	APK-5 No.2		APK-5 No.1	APK-5 No.2
0	0	0	180	0	-1
15	+12	+12	195	+11	+11
30	+18	+16	210	+16	+16
45	+19	+16	225	+16	+16
60	+16	+12	240	+14	+12
75	+8	+7	255	+8	+6
90	+3	+0	270	0	0
105	-6	-9	285	-6	-8
120	-9	-13	300	-13	-14
135	-15	-18	315	-16	-17
150	-13	-18	330	-15	-18
165	-10	-13	345	-12	-12

3. In correcting radio deviation, see that the aircraft is placed from MHP or MMAP radio station at a distance of at least three wave lengths. If the power of the radio station exceeds 10 kW, the aircraft should be placed at a distance of at least 100 km. from the station.  
4. Radio deviation must be performed not earlier than 1 hr 30 min. after rise and not later than 1 hr 30 min. before sun set.

Elimination of Radio Deviation of APK-5  
Compass No.1

1. Determine and correct the setting error as follows:  
(a) place the aircraft by the compass at a course which is approximately equal to the magnetic bearing of the radio station which is used for deviation correction;  
(b) using the deviation direction finder place the aircraft exactly at the magnetic course equal to the radio station magnetic bearing;  
(c) tune the APK-5 compass in the radio station frequency, fine and reset the inverse radio bearing. If the latter is not equal to zero, the frame has a setting error;  
(d) to eliminate the setting error, turn off the six bolts and turn the frame base through an angle equal to the setting error: in case of a plus error turn the frame base clockwise, in case of a minus error turn it counter-clockwise.  
2. In order to determine and eliminate radio deviation, do as follows:  
(a) position the aircraft at the magnetic course;  
(b) adjust the radio compass receiver for the selected radio station, allow it to warm up during 5 minutes and correct the deviation at 24 inverse radio bearings: 0, 15, 30, 45°, etc.;  
(c) in case the deviation error exceeds 2.5° remove the frame of the APK-5 compass No.1 and balance it. Then correct the deviation again at 24 inverse radio bearings;

(d) residual radio deviation must not exceed 2.5°, including the frame setting error.  
Notes: At course angles 0 and 180° residual deviation must not exceed 2.1°.

Elimination of Radio Deviation of  
APK-5 Compass No.2

1. Determine, in flight, the setting error with the radio station course angle being equal to zero.  
2. Correct the frame setting error on the ground, for which purpose remove the frame from the bracket, turn out the 6 bolts and turn the frame base through an angle equal to the setting error: in case of a minus error, turn the frame base clockwise, and in case of a plus error turn it counter-clockwise, watching at the same time the readings of the pointer of the APK-5 compass No.2 on the navigator's selwyn indicator.  
3. During the next flight (with the landing gear retracted) check compasses Nos 1 and 2 for correct readings at eight points by the MK-48 directional gyro for a landmark (at any altitude). The difference in the readings of the compasses tuned to one and the same radio station at radio station course angles equal to 0° and 180° must not exceed 2°, and at the remaining course angles this difference must not exceed 2.5°, the radio deviation of APK-5 compass No.1 taken into account.  
Notes: 1. The radio station course angle is to be taken by compass No.1 tuned to a distant radio station (300 - 400 km.) or to an airfield homing station of MAP-3E type (100 - 150 km.).  
2. Take the readings off the navigator's selwyn indicator of compass No.2 with antenna No.1 out in and vice versa.  
4. When approaching for landing (with landing gear extended) check compasses Nos 1 and 2 for differences at radio station course angles equal to 75, 120, 240 and 285°. See that the difference in the readings of the compasses tuned to one and the same radio station does not exceed 1.5° with the deviation error of compass No.2 being taken into account.  
Notes: The radio station course angle is to be taken by compass No.1 tuned to a distant or homing station, and the results are to be entered into the aircraft Log Book.  
5. Check the entries in the aircraft Service Log relating to the readings of APK-5 compass No.2 at radio station course angles equal to 75, 120, 240 and 285° with the landing gear extended.  
6. With the landing gear retracted, the residual radio deviation for APK-5 compass No.2 must not exceed 2.5°; for course angles equal to 0° and 180° the residual deviation must not exceed 2.1°.

Alignment of Automatic Course Device  
Indicator of MK-505 Air Position Indicator  
with Navigator's Course Indicator of MK-7  
Compass

After eliminating deviation of MK-7 compass check the pointer of the MK-7 compass navigator's indicator for synchronous movement with the automatic course device indicator of the MK-505 air position indicator. The courses on both indicators should be aligned, the pointers should move in the same direction. The alignment check is to be performed at courses from 0° to 360° every 15°.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 56 -

Alignment is considered satisfactory, if the difference in the readings of the automatic course device and the compass indicator at courses dividable by 15°, does not exceed 1°, otherwise align the courses with the aid of the adjusting screws of the RH-505 air position indicator automatic course dev. (Fig.28). After adjustment is over, repeat the adjustment check at all points from 0° to 360° every 15°.

AVTOPILOT AH-5-2M

GENERAL

- The AH-5-2M autopilot serves:
- (1) for automatic stabilization of the aircraft with respect to the three axes in a straight flight;
  - (2) for performance of an automatic compensated turn and aircraft additional turns during lateral aiming;
  - (3) for ensuring stabilization of the sight in azimuth.

Complete Set and Arrangement of AH-5-2M Autopilot Units on Aircraft

The directional stabilizer is arranged on a special bracket on frame No.1 in the front pressurized cabin (Fig.36).

The vertical flight gyro is installed on a special bracket in the front pressurized cabin behind the seat of the left pilot (Fig.37).

The procession gyro unit and HAI-16 inverter are positioned at the left wall between frames Nos 19 and 20 (Fig.38).

The servo units of the ailerons are located on frame No.33, those of the rudder and elevator are positioned on a special wing on frame No.66. The elevator servo unit is located to the left and the rudder servo unit is positioned to the right.

The control panel is located on the upper electric board of the pilots (Fig.39).

The pilot director indicator (P.D.I.) is arranged on the instrument board of the left-seat pilot (See Fig.110).

The turn remote control handle is located on the right-hand side of the electric panel of the navigator-radar operator.

The amplifier, HO-45 inverter, distributing box, relay box, resistance box for changing the pitching moment are positioned on the left-hand rack of the navigator-radar operator.

Emergency disengaging buttons are located on the spokes of ailerons control steering wheel of the left and the right pilots.

The formation stick and the control transfer are located on the swivelling bracket on the middle panel of the pilots (See Fig.40).

The directional stabilizer attachment bracket is arranged on frame No.1.

The pitching moment limit switch, type BE2-1418, is positioned on frame No.33 in the mechanism of the bomb bay limit switches.

Specifications of AH-5-2M Autopilot

1. The autopilot employs direct current, 27 ± 2.7 V.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM



- 2. Power consumed by the AH-5-2M autopilot from the aircraft mains at 27 V at rated load of the servo units (110 kg/cm. on the cable drum) does not exceed 500 W.
- 3. Power consumed by heating hoods from the aircraft mains does not exceed 250 W.
- 4. The operating temperature interval of the autopilot set is -45 to +50°.
- 5. The autopilot operates normally within a temperature range from -20 to +45° only when its heating system is switched on.
- 6. Departure of the directional stabilizer from the course at any point during 15 min. of operation of the "yawing base" does not exceed 3.5°.
- 7. Total departure of directional stabilizer from the course at the four end points during 15 min. of operation at each point on the "yawing base" does not exceed 8°.
- 8. Resistance between the contact brush and the aileron pick-up potentiometer centre tap on the directional panel of the directional stabilizer does not exceed 5 ohms; the difference between the resistances of the rudder pick-up potentiometer winding arms does not exceed 5 ohms.
- 9. The contacts of the vertical flight gyro erecting mechanism cutout close when the F.D.I. potentiometer pointer deflects 1 - 1.5° to the left and right from the zero position.
- 10. The total deflection of the vertical flight gyro rotor axis in both directions from the vertical at normal temperature does not exceed 1.4°.
- 11. Maximum deflection of the rotor axis from the vertical of the vertical flight gyro is 1.2°.
- 12. The erecting time of the vertical flight gyro cardan unit from 45° tilts in each of the four quadrants is 2 - 10 min., the difference between the maximum and minimum erecting time from tilts at normal temperature must not exceed 4.5 min.
- 13. Power consumed by servo unit at normal temperature, 27 V and 110 kg/cm. load moment on cable drum does not exceed 80 W.
- 14. The braking effort developed by the servo unit on the cable drum at normal temperature is from 75 to 100 kg.
- 15. Servo unit potentiometer. Tension:
  - (a) potentiometer winding brushes (total) - 25 to 45 gr;
  - (b) slip ring brushes (total) - 20 to 40 gr;
  - (c) limit switch plates - at least 150 gr.
 Resistance of working portion of potentiometer winding is  $1100 \pm 200$ /<sub>150</sub> ohms.
- 16. Power supply of amplifier circuits:
  - (a) valve filament ..... D.C., 27 ± 2.7 V;
  - (b) transformers ..... A.C., 125 ± 15 c.p.s., 17.5 ± 2.5 V;
 (c) voltage in secondary windings of bridge transformers at supply voltage of 17.5 V and frequency of 125 c.p.s. - 27 ± 2 V;  
 (d) throttling voltage:
  - maximum ..... 80 - 20 V
  - minimum ..... 25.5 ± 7.5 V
- 17. Power consumed by amplifier:
  - (a) valve filament ..... 30 W maximum
  - (b) transformers ..... 40 VA maximum
- 18. Control panel resistances:
  - (a) centring potentiometers ..... 200 ± 20 ohms;
  - (b) sensitivity potentiometers ..... 0.35 ± 0.066 megohms;

50X1-HUM

- (c) ratio rheostat ..... 600 ± 60 ohms;
- (d) trimming potentiometers ..... 250 ± 25 ohms;
- (e) compensating potentiometer ..... 2000 ± 200 ohms;
- (f) control transfer potentiometer ..... 2000 ± 200 ohms;
- (g) turn control potentiometer ..... 1000 ± 100 ohms.
- 19. Inverter H0-45:
  - (a) output power ..... 45.5 VA;
  - (b) A.C. voltage ..... 18.3 ± 0.5 V;
  - (c) A.C. frequency ..... 125 ± 5 c.p.s.;
  - (d) duty of operation ..... long-time
- 20. Inverter HAF-10
  - (a) load current ..... 0.32 A;
  - (b) A.C. voltage ..... 36 ± 4 V;
  - (c) A.C. frequency ..... 400 c.p.s.;
  - (d) number of phases ..... 3
- 21. The alternating current in the gyro motor phase of the precession gyro must not exceed 0.35 A.
- 22. Precession gyro sensitivity must meet the following requirement: at an angular velocity not exceeding 0.1°/sec. voltage should appear and be registered by the voltmeter.
- 23. The precession gyro operates within an angular velocity range of ±5°/sec. - 40.5°/sec.
- 24. Time required for formation stick to return to neutral position from any extreme position is from 0.3 to 1.5 sec. both for the "aileron" and "elevator".
- 25. The contacts of the formation central switch close before the signal comes from the aileron potentiometer.
- 26. The button serving to switch off the aircraft control from the autopilot has normally closed contacts. When the button is pressed the contacts open.
- 27. The brush surface contacting the commutator should constitute at least 8% of the brush section.
- 28. The time required for the navigator to additionally turn the aircraft with the autopilot coupling engaged at 4 to 6°, must not exceed 18 sec.
- 29. With the autopilot in operation the control surfaces should deflect:
  - (a) ailerons ..... 14 20.5°;
  - (b) rudder ..... 15 20.5°;
  - (c) elevators ..... 15 20.5°;
- 30. The elevator neutral position corresponds to a deflection of the elevator by 2° downward.
- 31. Elevator deflection when the bomb bays are opened at a speed of 450 km/hr is equal to 20 ± 5 angular minutes.
- 32. The AH-5-2M autopilot set employs the following valves:
  - (a) 6 x 5 ..... 1 piece;
  - (b) 6RBM ..... 3 pieces;
  - (c) 6M ..... 3 pieces.
- 33. The insensitivity zone of the AH-5-2M autopilot with the sensitivity handles shifted to minimum position is as follows:
  - (a) aileron ..... at least 1.5°;
  - (b) rudder ..... at least 0.50°;
  - (c) elevator ..... at least 1.0°.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



34. The insensitivity zone of the AN-5-2M autopilot with the sensitivity handles shifted to maximum position is as follows:
- (a) alleron ..... not in excess of 0.4°;
  - (b) rudder ..... not in excess of 0.25°;
  - (c) elevator ..... not in excess of 0.4°.
35. The temperature inside the electric heating hoods is maintained by a thermal relay within the range of from 10 to 45°C.
36. The minimum length of the brushes at which they should be replaced is given in Table 14.

Table 14

Minimum Length at Which Brushes Should Be Replaced

Name of unit	Mark of brush and index	Length of brush, mm	
		minimum	rated
1	2	3	4
<b>Directional stabilizer:</b>			
gyro	MTU-7	22	28
erecting motor	MTU-7	11 - 12	18.5
<b>Vertical flight gyro:</b>			
gyro	MTU-7	18	24
servo unit	MT-4A-4G	15 - 16	24
<b>Inverter IO-45:</b>			
A.C. commutator	MT-4A-4G	4.5 - 5	10.5
D.C. commutator	MT-4A-4G	6 - 6.5	13.5
<b>Inverter HAN-10:</b>			
D.C. commutator	MC-6	10	14

**CHECKING AUTOPILOT FOR INSTALLATION ON AIRCRAFT AND OPERATION UNDER CURRENT**

**EXTERNAL INSPECTION**

**Directional Stabilizer**

1. Check the bracket for proper attachment and see that the directional gyro is reliably secured to the bracket.
2. Engage and disengage the autopilot and sight couplings several times to make sure that the engagement mechanism functions correctly. When disengaged, the couplings should rotate freely on their drums without binding or dragging the drums along with them.
3. Examine the locking mechanism unit to make sure that the locking mechanism plunger is locked with its nut. Shift the solenoid plunger several times downward to make sure that the return spring returns the entire lever system and the plunger to the initial position. As the plunger goes downward, the lever of the autopilot coupling must be pressed. Remove dirt and foreign particles.
4. Make sure that the locking mechanism does not interfere with the movement of the autopilot coupling lever; see also whether there is a clearance between the "jaws" of the locking mechanism and autopilot coupling.

50X1-HUM

5. Take out the course panel cover and make sure that there is no dirt or dust inside the casing or on the potentiometers.
6. With the sight mounted, check to see that the wire bundles do not interfere with free movement of the sight with respect to the drift angles.
7. Make sure that the handles of the directional stabilizer bracket rotate without binding and allow the stabilizer to be set by a level.
8. Using a dynamometer check the tension of the autopilot, sight and drift gear couplings in accordance with Table 15.

Table 15

Spring Tension on Directional Stabilizer Couplings

Name of coupling	Spring tension by dynamometer, kg	
	minimum	maximum
Autopilot coupling	6	7
Sight coupling	8	9
Drift gear coupling	4	5

**Control Panel**

1. Check the handles for reliability of attachment on the shafts.
2. Check the rotation of all control panel handles within their turning limits. All handles should rotate smoothly and without binding except:
  - (a) TURN COMPENSATOR handle: when the pointer approaches the shaded portion of the scale and the zero position, a resistance to handle rotation should be left.
  - (b) TURN COMPENSATOR control drive handle: when the pointer approaches the position "Pilot", rotation of the handle becomes more difficult.
3. Check the plate of the switches for correct functioning and for proper attachment to the switches.
4. Make sure that all the pointers of the control panel handles are reliably secured and move only when the handles are turned.

- Notes:**
1. After the check handles "RATIO", "TURN COMPENSATOR", "INCREASE BARE", "NO DECREASE SKID" and "UP KLEV" must be placed in position determined in the air.
  2. After the test is over set the drive control handle of the turn compensator into position "Pilot".

**Pilot Director Indicator (P.D.I.)**

1. Check the instrument for reliability of attachment.
2. Check the condition of the glass.
3. Check the pointer and instrument scale for presence of luminous compound.

**Autopilot Switch-Off Button**

1. Check the button for reliability of attachment in the splines of the alleron control wheels.
2. Press the buttons several times to make sure that they return to their initial position without binding.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 62 -

Formation Stick

1. Make sure that the stick after being deflected and released returns to its central position.
2. Check to see that the buttons on the stick do not bind when being pressed and return to the initial position.

Formation Stick Control Transfer

1. Check the stick for reliability of attachment on its shaft.
2. Set the control transfer in all positions and make sure that control transfer is performed without considerable efforts and that the stick is firmly held in the selected position.

Vertical Flight GYRO

1. Check the attachment of the vertical flight gyro and see that there are no cracks on the shock absorbers.
2. Examine the plexiglass cover in the upper part of the vertical flight gyro and make sure that the cover is placed in a position at which the vertical flight gyro is uncaged. The plexiglass cover must not be cracked or have any deep scratches.

Amplifier

Check the amplifier for reliability of attachment, good condition of shock absorbers and bonding.

Inverters

Check the inverters for reliability of attachment.

Distribution Box

1. Check the distribution box in accordance with the requirements presented in Section "Aircraft Electric Mains" (See "Care of Split Boxes and Electric Boards").
2. Check the external condition and correctness of installation of series resistors on terminals E-1 and E-3, as well as on terminals E-6 and E-8 which are equal to 400 ohms.

Relay Box

1. Check the relays for reliability of attachment in their seats.
2. Make sure that there are no metal chips, dust or any foreign objects inside the boxes.
3. Examine tightening of the nuts and attachment shoen of the wires.
4. Check to see that all the wires and their insulation are in good condition.

Precession Gyro Unit

Check to see whether the precession gyro unit is reliably secured and that its surfaces has no dents or scores.

Servo Units

1. Check tightening of the bolts which secure the servo units.
2. Deflect the rudder and elevators into both sides and make sure that the cable is wound around the drum and that it permits shifting of the rudder and elevators into both directions.
3. Press the tension springs of the braking solenoids and make sure that,

- 63 -

after pressure is removed, the rods and levers of the braking solenoids return to their initial position.

4. Make sure that there is no dirt or oil on the potentiometer contact brush and winding. Check the tension of the potentiometer contact brush.
5. Check the potentiometer brushes for reliability of attachment on braking drum.

6. Place the rudder and elevators in neutral position and make sure that the contact brushes of the follow-up system are centered, whereas the slide moving along the potentiometer is in its down position.

Turn Remote-Control Button

1. Check to see that the handle is reliably attached on the potentiometer shaft.
2. Make sure that the handle rotates freely, without binding, except in position "0" and in the shaded portion of the scale where a resistance is felt in turning the handle.

Resistance Box for Changing the Pitching Moment

1. Check the resistance box for reliability of attachment.
2. Check the wires for reliability of attachment to the resistance box.

**Note:** When inspecting the autopilot units, examine the condition of the plug connectors of the units. The plug connectors should be tightened as far as they will go, have no considerable play and be locked with safety wire.

Checking Operation of Energized Autopilot

**CAUTION:** Prior to checking the autopilot for operation, do not fail to unlock the aircraft controls and remove the service ladders, covers and other objects. Stop any operations on the aircraft controls.

1. Switch on the A30-15 autopilot circuit breaker on the circuit breaker board of the left-seat pilot and the A30-2 "Servo" circuit breaker on the circuit breaker panel of the navigator.
2. Actuate the plate on the panel to switch on the master switch and the "Stab." switch; then make sure that:
  - (a) the gyro motors of the directional stabilizer and vertical flight gyro, the precession gyro unit, inverters and servo unit motors are already operating; this is determined by the peculiar noise of the running motors;
  - (b) the erecting roller rotates properly.
3. After cutting in the master switch wait 5 to 8 minutes and then switch on the "Servo - P.D.I." switch on the control panel. This will cause the directional stabilizer erecting motor to operate.
4. Disengage the autopilot coupling and shift it to the left and right to check whether shifting of the P.D.I. potentiometer brush causes the P.D.I. pointer to deflect. When the potentiometer brush is moved to the left, the P.D.I. pointer should gradually deflect to the right and vice versa.
5. Place the P.D.I. potentiometer brush at zero. The P.D.I. pointer should also be at zero. Then engage the autopilot coupling.
6. Shift the aircraft control surfaces (rudder, ailerons, elevators) manually from one extreme position to the other. Repeat this movement several times. Make sure that the controls move freely.
7. In shifting the control surfaces manually check operation of the control panel pilot lamps. When the control surfaces are in the neutral position, the

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 64 -

- 65 -

lamps must not light, when they are in any other position, one of the lamps must burn without blinking. Blinking of the lamps when the control surfaces are not in the neutral position means that the servo unit potentiometers are dirty. In this case clean the potentiometer of the respective servo unit.

**Note:** On some aircraft the slide of the servo unit potentiometer may come off the potentiometer winding when the control surfaces are in the extreme positions. In this case both pilot lamps will not burn.

8. Turn the centering knobs on the control panel to the right or to the left; the position of the control surfaces at which both lamps go out will be changed.

9. Set the knobs "Centering" so that the pointers face upward.

10. Without centering, switch on the following switches on the control panel: "AILERON", "RUDDER", and "ELEVATOR". When some of the mentioned switches are cut in, the respective stabilization pilot lamp must light up and then go out in some time since the control surfaces will be set in the neutral position by the operating servo unit.

11. As the centering knob is slowly turned to the right or to the left as far as it will go, the respective stabilization channel control surface should deflect.

The control surfaces should deflect with interruptions, but evenly, each time the control surface displaces, the respective pilot lamp on the control panel should blink.

Turning the centering knob "AILERON" clockwise should cause the right-hand aileron to go up (the steering wheel rotates clockwise) and vice versa; turning the knob "AILERON" counter-clockwise will cause the left-hand aileron to go up (the steering wheel rotates counter-clockwise).

Turning the centering knob "RUDDER" clockwise will cause the rudder to shift to the right-hand turn position (the right pedal goes forward). Turning of the same knob in the opposite direction should cause the rudder to shift to the left-hand turn position (the left pedal goes forward).

Turning the centering knob "ELEVATOR" clockwise should cause the elevator to move upward (the control column moves backward). When this knob is turned counter-clockwise, the elevator will go down (the control column moves forward). With the knob "ELEVATOR" in the extreme positions, the pilot lamp may not burn.

12. Set the centering knobs to "Pointer Up" position.

**Note:** As the centering knob is turned, not more than two simultaneous blinkings (pulses) of both pilot lamps are allowed on separate sections.

13. Disengage the autopilot coupling on the directional stabilizer and turn the coupling lever into the extreme left-hand position. The steering wheel should turn to the right, the right pedal should go forward and the P.D.I. pointer should deflect to the right.

14. Set the lever of the autopilot coupling in the extreme right-hand position. The steering wheel should turn to the left, the left pedal should move forward, whereas the P.D.I. pointer should displace to the left.

15. Return the autopilot coupling lever into the central position; after the contact brush of the P.D.I. potentiometer assumes its zero position, engage the autopilot coupling.

16. Set the control transfer to position "Pilot" and make sure that the pilot lamp does not burn.

17. Turn the turn control knob on the control panel to the right so that the knob indicator should be at the beginning of the shaded portion of the scale and make sure that the steering wheel has turned to the right and the right pedal has displaced forward. Turn the control knob to the same position, but to the left and make sure that the steering wheel has turned to the left and the left pedal has displaced forward.

Set the knob in position "0", first to the right and then to the left, to be sure that the solenoid of the directional stabilizer locking mechanism is engaged and locks the autopilot coupling lever, whereas the top erecting roller of the vertical flight gyro has ceased rotating.

18. Set the turn control knob in position "Centre", and then to the right-hand and left-hand positions "0". This done, place the knob in position "Centre" again and make sure that the steering wheel and pedals should not move) and make sure that the solenoid of the locking mechanism has disengaged and set the autopilot coupling lever to "0", whereas the top erecting roller of the vertical flight gyro begins to rotate.

19. Set the turn control transfer on the control panel into position "Transfer" to make sure that the transfer position indicating lamp is on. Use the turn reset-control knob to carry out the checks described in items 17 and 18.

20. Place the aircraft controls in neutral position as indicated by the pilot lamps on the control panel.

21. Set the formation stick control switch in position "OFF".

22. Shift the formation stick to the right as far as it will go and make sure that the steering wheel has turned clockwise and that the right pedal has displaced forward. With the formation stick in this position the locking mechanism of the directional stabilizer should be engaged and lock the autopilot coupling lever.

23. Release the formation stick and make certain that it returns to the neutral position. With the formation stick in the neutral position, the solenoid of the directional stabilizer locking mechanism must automatically disengage and unlock the autopilot coupling lever in 3 to 9 sec. after the stick has returned to the neutral position.

24. Shift the stick to the extreme left-hand position and make sure that the steering wheel has turned counter-clockwise and that the left pedal has displaced forward. Release the formation stick. Make sure that the stick, steering wheel and pedals return to the neutral positions. With the formation stick in the neutral position, the solenoid of the directional stabilizer locking mechanism must automatically disengage and unlock the autopilot coupling lever in 3 to 9 sec. after the formation stick has returned to the neutral position.

25. Shift the formation stick backward as far as it will go and make certain that the control column has moved rearward. Release the formation stick and make sure that the stick and column return to the neutral position.

26. Push the formation stick forward as far as it will go to make sure that the control column moves forward. Release the formation stick and see whether the formation stick and control column return to the neutral position.

27. Set the switch in position "Only Elevator ON". Deflect the formation stick forward and rearward to make sure that the control column follows the formation stick. When the formation stick is moved to the right and to the left the pedals and steering wheel must not move.

28. Press the autopilot disengaging button of the left-seat pilot for 2 sec. and displace the steering wheel, control column and pedals to make sure that the autopilot servo units are disconnected and that the aircraft

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



- 66 -	50X1-HUM		
	- 67 -		
	<u>Faults and Remedies</u>		
	Fault	Probable cause	Remedy
	1	2	3
<p>controls move freely. Using the plate cut out the master switch on the control panel and cut it in again. Cut in the switches "AILERON", "RUDDER" and "ELEVATOR". Displace the booster control handle to make sure that the handle actuates the aircraft controls.</p> <p>29. Press the autopilot disengaging button of the right-seat pilot for 1 - 2 sec., with the booster control switch in position "OFF", and shift the steering wheel, control column and pedals to make sure that the autopilot servo units are disengaged and that the aircraft controls move freely. Using the plate cut out the master switch on the control panel and cut it immediately in again. Cut in the switches "AILERON", "RUDDER" and "ELEVATOR" and check to see that the controls are deflected by the turn control knob on the control panel. Make sure that the controls are actuated by the knob.</p> <p><b>Note:</b> If the autopilot disengaging button is released after it was pressed the servo units should not engage the aircraft controls before the master switch on the control panel is switched off and on again with the aid of the plate.</p>	<p>When controlled by autopilot aircraft deviates from given course</p> <p>Periodical jerks in control surface movement</p>	<p>Directional stabilizer gyro unbalanced</p> <p>Improper braking moment of servo unit braking solenoids</p>	<p>Replace directional stabilizer or balance its gyro on a stand</p> <p>Adjust the braking moment of the servo unit braking solenoids by even distribution of the efforts to the left and right sides</p>
<p>30. Check the sensitivity adjusting knobs on the control panel for proper operation of each stabilization channel separately, for which purposes:</p> <p>(a) cut in one of the switches "AILERON", "RUDDER" or "ELEVATOR" on the control panel;</p> <p>(b) set the centering knob of the cut-in stabilization so that its pointer should face upward (both pilot lamps will be out); turn the sensitivity adjusting knob counter-clockwise;</p> <p>(c) turn the sensitivity adjusting knob on the control panel clockwise. The steering wheel, control column and pedals will begin to oscillate, where the pilot lamps on the control panel will begin to blink in turn.</p>	<p>When aircraft is controlled by formation stick, with switch placed in position "ON", the locking mechanism fails to operate or operates twice</p> <p>When the centering knob is actuated, the control surface lags</p>	<p>(a) Unstable operation of time relay</p> <p>(b) Wrong adjustment of locking mechanism jaws on directional stabilizer</p> <p>No contact on servo unit potentiometer</p>	<p>Replace time relay in relay box</p> <p>Adjust the locking mechanism of the directional stabilizer</p>
<p>31. Check operation of the pitching moment counteracting mechanism for its purpose:</p> <p>(a) adjust the neutral position of the steering wheel by the elevator;</p> <p>(b) open the bomb bays. When this is done, the steering wheel should move forward. When the bomb bays are closed, the steering wheel should again assume its neutral position. With the bomb bay open the elevator should be deflected 9 - 10 mm with relation to the inner face of the trailing edge, the blade being not taken into account. The way of measuring the deflections of the aircraft control surfaces is described in Section "Controls" (See Book I).</p>	<p>Locking mechanism solenoid does not keep time (3 to 9 sec.) after the formation stick has been turned</p> <p>Unequal bank when control is exercised through directional stabilizer</p>	<p>Wrong adjustment of time relay</p> <p>Wrong centering of potentiometers on directional panel of directional stabilizer</p>	<p>Clean surface of potentiometer with a brush out of the AN-5-2M autopilot set. The brush should be soaked in clean gasoline</p> <p>Replace time relay in relay box</p>
<p>32. Check operation of the autopilot heaters, for which purpose cut in the A3C-10 circuit breaker of the autopilot heater. The circuit-breaker is located on the circuit-breaker panel of the left-seat pilot. Then switch on the heating system switch on the upper electric panel of the pilots and the A3C-10 circuit breaker of the rudder and elevator servo unit heaters. This done, make sure that the lower covers of the servo units and vertical flight gyro warm up.</p>	<p>Aircraft turns spontaneously</p>	<p>(a) Wrong tension adjustment of directional stabilizer coupling</p> <p>(b) Erecting mechanism of directional stabilizer and vertical flight gyro out of order</p>	<p>Adjust tension of directional stabilizer coupling</p> <p>Eliminate fault of erecting mechanism</p>
<p>33. After the check is over cut out the switches on the autopilot control panel making use of their common plate, cut out the A3C-10 circuit breakers of the rudder and elevator servo unit heaters, as well as the heating switch on the upper electric panel of the pilots.</p>	<p>Aircraft comes out of turn spontaneously</p>	<p>Locking mechanism on directional stabilizer is loose</p>	<p>Adjust tightening of the locking mechanism on the directional stabilizer.</p>
			<p><b>Note:</b> When the autopilot coupling lever is tightly locked, there should</p>

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

1	2	3
<p>When autopilot is engaged the aircraft tends to turn sharply</p> <p>Servo unit braking solenoids will not engage</p>	<p>Gyro of directional stabiliser or vertical flight gyro is out of order</p> <p>Autopilot is disconnected from buttons on aileron control steering wheel</p>	<p>be a clearance of 2 - 3 mm between the bottom and armature of the locking mechanism solenoid</p> <p>Remove directional stabiliser and vertical flight gyro and check their operation on a stand</p> <p>(a) Using the master switch on the autopilot control panel engage completely and disengage the autopilot</p> <p>(b) Check operation of the engaging button serving to engage the autopilot for aircraft control</p>

OXYGEN EQUIPMENT  
GENERAL SPECIFICATIONS

The oxygen equipment ensures normal oxygen supply for the aircrew during high-altitude flights and bailing out by ejecting the seat.

The oxygen system (Fig.41) includes the following elements:

- Two liquid oxygen converters, type H1E-30, designed for storage and justification of liquid oxygen and delivering gaseous oxygen to the line which supplies the aircrew (the arrangement diagram of the H1E-30 liquid oxygen converter is given in Fig.42).
- Six oxygen stations. Each of them includes:
  - stationary oxygen regulator, type H1-24M;
  - pressure gauge, type MK-13M
  - oxygen-flow indicator;
  - excessive pressure gauge, type M-1000;
  - oxygen valve, type KB-5;
  - oxygen hose, type KB-24;
  - oxygen mask, type KM-30M, with the mask-to-face tightness compensator and a lock;
  - yellow warning lamp (only in four stations).
- The aircraft charging system consisting of aircraft charging connection and pipe lines of the AMW-T12x14 material connecting the charging connection to the H1E-30 liquid oxygen converter.
- Six tee-pieces with non-return valves. The tee-pieces ensure oxygen supply to each working station from both H1E-30 converters simultaneously and prevent oxygen from being released from both converters simultaneously in case one of the sections of the oxygen system is damaged.
- Six parachute oxygen apparatus, type H1-23, with hoses.

All these elements are connected to one another by means of pipe lines of the AMW-T6x8 material and aircraft fittings.

The vessel of each converter, type H1E-30, has a capacity of 28 litres. The amount of liquid oxygen filled into both converters is 64 kg. The amount of consumed oxygen is 60 kg.

The minimum operating pressure is 8 ata. gauge, the maximum operating pressure is 10 ata. gauge.

The maximum oxygen consumption from one converter is 6 kg per hour.

The pressure required for the operation of the safety valve is from 11.0 to 11.8 ata. gauge.

The evaporativity of each converter must not exceed 250 gr per hour.

ACCESSIBILITY FOR INSPECTION

Oxygen panels with instruments both in the front and rear pressurized cabins are easily accessible for inspection.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 70 -

To inspect the pipe lines in certain places it is necessary to remove the neighbouring units. Such places are:

(1) Pipe line in the area of frames Nos 4 - 9 on the starboard and port sides.

To obtain access to the pipes, remove from this section: from the starboard side - the shut-off valves control panel, from the port side - the interphone set panel of intercommunication system CHV-10, and the IFF transponder panel. To obtain access to the pipes on frame No. 4, remove the fuse panel and flap back the navigator's instrument board.

(2) Pipe line in the area of frames Nos 9 - 12 on the starboard and port sides. To obtain access to the pipes of this section remove the following from the starboard side:

- (a) converter, type PGE-70, on the operator's panel support;
  - (b) thyatron interrupter on the operator's panel support (starboard).
- from the port side:
- (a) block, type P-6;
  - (b) P-6 block panel.

(3) Pipe line on the bottom of frame No. 12.

To obtain access to the pipes, it is necessary to detach the operator's electric panel (control panel).

(4) Pipe line in the  $\Phi$ -3 cabin on the starboard and port sides.

To obtain access to the pipes, do as follows:

- (a) open the container hatches of fuel tanks Nos 1 and 2;
- (b) remove tank No. 1;
- (c) remove tank No. 2;
- (d) remove hatches in the containers of tanks Nos 1 and 2.

(5) Pipe line in the  $\Phi$ -4 cabin from frame No. 26 up to frame No. 34 on the starboard and port sides.

To obtain access to the pipes, proceed as follows:

- (a) open the hatch in the  $\Phi$ -4 cabin between frames Nos 27 - 29;
- (b) remove the starting fuel tank between frames Nos 27 - 29;
- (c) remove the cooler between frames Nos 30 - 31.

Besides this, to obtain access to the pipes of the starboard side, do as follows:

- (a) remove the drain pipe;
- (b) remove the pipe of the high-altitude equipment;
- (c) loosen the yoke on the drain pipe and turn the branch pipe.

To obtain access to the port side pipes, remove the drain pipe.

To obtain access to the pipes in the area from frame No. 34 up to frame No. 49, it is unnecessary to remove the neighbouring units.

(6) Pipe line in the  $\Phi$ -6 cabin.

To obtain access to the pipes, it is necessary to remove the PCHV-5M radio set from the bottom of frame No. 69.

(7) Aircraft charging pipe line in the area of frames Nos 19 - 22.

To obtain access to the charging pipe union and charging pipe line:

(a) open the aircraft oxygen charging hatch;

(b) open the hatch in the nose wheel well on the starboard side between frames Nos 19 - 22.

(8) The pipes laid in the area of frames Nos 49 - 57 are not accessible.

- 71 -

(9) To obtain access to the liquid oxygen converter, type KHE-30, at frame No. 13 and the pipe line at the converter use the hatch on the bottom of frame No. 12.

#### PREPARATION FOR FLIGHT INSPECTION

The pre-flight inspection consists in thorough examination of all accessible units and pipe lines of the oxygen system. For this, do as follows:

1. Open the entrance hatches in the pressurized cabins (if they are closed).
2. Open the doors of the bomb bay hatches and of the hatch between frames Nos 27 - 29.

3. Remove cases from the oxygen regulator, type KHE-24.

4. Examine the oxygen panels with instruments and make sure that they are not damaged.

5. Check to see that the instruments are securely fastened to the panels.

6. Examine the pipe line in all accessible places; make sure that the pipe lines are securely connected to the oxygen flow indicators, KHE-13M pressure gauges, M-1000 excessive pressure gauges, KHE-24M economizer, KB-5 oxygen valves, BUKOM (B3) and TOP (BEPK) transmitter pipe unions, pipe unions of the KB-5 valves on the KHE-30 converters and check the pipe lines for secure attachment.

7. Examine the KHE-30 converters (Fig. 43); check whether the safety valve case is securely attached and whether the KB-5 valves and the pressure release valves of the KHE-30 converters open easily.

8. Examine the places of connection of the KB-24 hoses to the KHE-24M economizer.

9. Check whether the oxygen adapter in the operator's seat turns easily (Fig. 44).

10. Check the presence of liquid oxygen in the KHE-30 converters. Add liquid oxygen if necessary.

11. Put the KHE-30 converters to the operating condition and check them for serviceability.

12. Check the operation of the KHE-24M set.

#### Charging KHE-30 Converters with Liquid Oxygen

To save liquid oxygen, prior to each flight the KHE-30 converters should be charged with the amount of oxygen necessary for the flight only.

The amount of oxygen required for the flight is to be determined by the formula:

$$G_n = G_n + t q$$

where  $G_n$  is the required amount of liquid oxygen in kg;

$G_n$  is the stock of oxygen not taken into account in kg (6 kg per each converter, type KHE-30);

$q$  is the rated oxygen consumption for all the aircrew in kg per hour (5 kg per hour for all the aircrew);

$t$  is the time of flight in hours.

Calculate the amount of oxygen necessary for the flight and then measure the amount of oxygen on the aircraft turning on the switch, type 2KH-250, with the 10-4500 inverter operating. Add the readings of both indicators and compare the amount obtained with the amount of oxygen required for the flight.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 72 -

If the measured amount is less than the rated value, charge the converters with additional amount of oxygen.

**CAUTION:** Flight with oxygen supply below the rated value is prohibited.

The converters should be charged with liquid oxygen in the following manner:

1. Open the pressure release valves (if they are closed) on the HME-30 converters and equalize the pressure in the converter vessels with the atmospheric pressure (Fig. 45e).

**Note:** To uniformly charge the HME-30 converters with liquid oxygen, open the pressure release valve on the converter at frame No.13 by 0.5 of a turn only, and that on the converter at frame No.22 completely.

2. Close the valves, type EB-5, before the automatic pressure increase units and after the evaporators.

3. Open the cover of the aircraft charging pipe union hatch and unscrew the plug on the pipe union (Fig. 46).

4. Wipe the charging pipe union with a piece of gauze soaked with alcohol.
5. To the charging pipe union connect the pipe line from the "Tank" and the vacuum flask (CA-15).

**Note:** When unscrewing the plug and connecting the pipe line, see that no moisture and dust get into the filler pipe.

6. Switch on the 130-2 circuit breaker on the operator's electric panel in the inverter circuit, set the inverter switch on the generator panel to the OPERATING (РАБОТНИ) position and turn on the oxygen level indicator switch, type 2HM-250, on the pilot oxygen panel.

7. Pressure in the "Tank" reaching 3 or 4 atm. gauge, open the valve on the "Tank" and fill the vessels of the HME-30 converters with liquid oxygen.

8. Fill the converters until liquid appears in the drain holes which indicates that the vessels are charged completely (32 kg in each vessel). Besides this, check filling the vessels with liquid by the pilots' oxygen level indicators. With the vessels charged completely, the indicator pointers must be within the limits of 28 to 32 kg.

9. If the converters are not charged with oxygen to their full capacity, check the amount of oxygen filled by the oxygen level indicators only.

**Note:** When charging the converters with liquid oxygen, see that excessive pressure is equal to 3 or 4 atm. gauge as decreased excessive pressure may cause the non-return valve to get frozen in the HME-30 converter filler neck. In this case stop charging and knock on the valve cover with a wooden stick.

10. If the converter is filled with liquid oxygen from vacuum flasks, prior to connecting the pipe from the vacuum flask to the aircraft charging pipe union do as follows:

- (a) bring the cylinder with gaseous oxygen to the aircraft, connect the oxygen reducer to the cylinder and check the presence of oxygen in the cylinder;
- (b) open the valve on the cylinder and scavenge the reducer with the hose with gaseous oxygen;

- (c) remove the plug from the vacuum flask, fit a rubber packing gasket over the vessel neck, insert the filler pipe and fasten the extension dampers to the handles of the vacuum flask;

- (d) connect the low-pressure hose to the filler pipe;
- (e) connect the adapter pipe to the vacuum flask;

- 73 -

- (f) after the adapter pipe of the vacuum flask has been connected to the aircraft charging pipe union, slowly open the valve on the cylinder with gaseous oxygen, create excessive pressure of not less than 4 atm. gauge and fill the converters.

**Note:** To charge the HME-30 converter to full capacity, it is necessary to have six full vacuum flasks.

11. Make sure that the vessels are charged completely, close the valve on "Tank" or on the cylinder with gaseous oxygen, if charging is done from the vacuum flasks.

12. In two or three minutes after the liquid has been filled disconnect the aircraft charging pipe union the pipe line connecting the vacuum flask to the "Tank" and plug the disconnected pipe line.

13. Screw a plug on the aircraft charging pipe union and close the hatch.

14. Switch off the 2HM-250 oxygen level indicator switch, the inverter circuit and the 130-2 circuit breaker.

15. The charging completed, disconnect the filler pipe from the adaptor pipe. Move the filler pipe from the vacuum flask, plug its upper end and fit a rubber plug on the lower end.

Disconnect the low-pressure hose from the filler pipe and plug its free end; see the vacuum flask with a plug.

#### Checking Operation of Distant-Reading Liquid Oxygen Level Indicator, Type 2HM

Check the operation of the oxygen level indicator, type 2HM, when charging the HME-30 converter with liquid oxygen.

With the vessels filled completely, the indicator pointers must be within 3 to 32 kg. With the pressure increased, the indicator pointers may fluctuate at the indicator readings after pressure rise must differ from those under no pressure by not more than 2 kg. If after pressure rise the indicator pointers move towards increase in readings, this is indicative of leaks in the "Oxygen Level Indicator Top" connections; if they move towards decrease in readings, this is indicative of leaks in the "Oxygen Level Indicator Bottom" connections. If on pressure increase the pointers do not move at all, this shows that the 2HM oxygen level indicator circuit is de-energized. This being the case, ring out the circuit and eliminate the damage.

#### Putting HME-30 Converters to Operating Condition

Put the charged HME-30 converters (See Fig. 45) to the operating condition as follows:

1. Close the pressure release valves (if the converters are put to the operating condition immediately after charging and the pressure release valves are open).

2. Open the EB-5 valves ahead of the automatic pressure increase units.

3. Open the EB-5 valves after the evaporators.

4. Pressure in the converters must first increase rapidly and then stop at 8.3 or 8.5 atm. gauge. If the converter contains not less than 26 or 27 kg. at the time of pressure increase to 8.3 or 8.5 atm. gauge must not exceed 10 minutes (usually this time is equal to 3 to 5 minutes).

The pipes before the automatic unit get frozen and then in 10 or 15 minutes when pressure increase stops, begin to warm up.

Increase pressure not less than 30 minutes before flight.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 74 -

Checking Serviceability of KHK-30 Converters Before Flight (See Fig. 45)

1. When opening the KB-5 valves ahead of the pressure increase automatic units, pressure in the converters must rise up to 8.3 or 8.5 atm. gauge during or 10 minutes, after this pressure increase must stop (the pipes ahead of the automatic units get warmed). If the pipes ahead of the automatic pressure increase valves fail to get warmed during 10 or 15 minutes, this testifies to a loose valve-to-seat fit. In this case, remove pressure and then increase it. If this does not cause the valve to close, it is necessary to close the valve ahead of the defective automatic unit and then open it by 1/8th of a turn after it has warmed up.

**Note:** When no gaseous oxygen is consumed, pressure in the system increases due to evaporation of oxygen in the converter vessel and in some cases reaches 11.5 or 11.8 atm. gauge, that is the safety valve relief pressure. If the automatic units are in good repair, this must take up to less than 45 minutes.

2. Check the gastightness of all the converters connections accessible for inspection. Pay attention to the gastightness of the charging pipe union.

3. Open the oxygen valves, type KB-5, (See schematic diagram 6, Fig. 45) ahead of the economizers, type KH-24M, at all stations.

4. Check oxygen delivery to oxygen stations by the pressure gauges, type KH-13M, which must indicate operating pressure in the supply line from 8.3 to 10 atm. gauge.

5. Check oxygen delivery to the supply line from each vessel of the KHK-30 converter separately. For this close in turn the KB-5 valves after the evaporator of the KHK-30 converters. Check oxygen delivery by the pressure gauges, type KH-13M, installed at oxygen stations. Prior to checking oxygen delivery from a vessel release pressure in the supply line through the emergency cocks of the KH-24M economizers.

Checking Operation of KH-24M Economizer

1. Check the gastightness of the high-pressure system of each oxygen station. For this open the KB-5 valve on the oxygen station and then close it. If the pressure gauge pointer does not show pressure drop during not less than 2 minutes the system is gastight.

2. Check the gastightness of the low-pressure system of the KH-24M economizer (from the economizer valve up to the plug on the KB-24 hose). For this purpose do as follows:

(a) release the remaining oxygen from the system by means of the manual regulator on the KH-24M apparatus;

(b) set the handle of the air dilution switch to the CLOSED ( ЗАКРЫТО ) position;

(c) remove the plug on the KB-24 hose and make an inhalation. If it is impossible to make an inhalation, the system is gastight;

(d) after checking the gastightness, set the handle of the air dilution switch to the OPEN ( ОТКРЫТО ) position.

3. Check oxygen delivery of the mask by the KH-24M economizer without excessive pressure and with excessive pressure setting the economizer cock to 3 MED ( ЧЕРЕЗ ) and PURE ( ЧИСТО ) positions successively.

- 75 -

Checking Operation of KH-24M Economizer without Excessive Pressure

1. Put on the mask, type KH-301, and connect it to the hose, type KB-24.
2. Open the KB-5 valve of the oxygen station.
3. Close the manual regulator on the KH-24M apparatus as far as it will go.
4. Make several inhalations and exhalations setting the manual switch of the air dilution automatic device first to the OPEN ( ОТКРЫТО ) and then to the CLOSED ( ЗАКРЫТО ) positions. If this causes the flow indicator flaps to get together, the KH-24M apparatus functions properly.

Checking Operation of KH-24M Economizer with Excessive Pressure

1. By means of the manual regulator build up excessive pressure equal to 250 mm H.G. on the KH-24M economizer (watch the pressure by the M-1000 excessive pressure gauge).
2. Put on and remove the plug from the KB-24 hose several times. If this causes the flow indicator blinkers to get together and depart, the KH-24M economizer operates normally.

**Note:** When the apparatus operation is checked under excessive pressure on the ground, the flow indicator flaps might fail to operate.

In this case watch the pointer of the excessive pressure gauge. If during the opening and closing of the KB-24 hose plug the pointer of the M-1000 pressure gauge oscillates, the apparatus functions properly.

3. Check emergency oxygen delivery by setting the emergency cock of the KH-24M economizer to the OPEN ( ОТКРЫТО ) position.

**Note:** When checking emergency delivery oxygen, pressure in the system must not drop below 8.3 atm.

Check emergency oxygen delivery by listening, holding the end of the KH-24 hose close to the face and opening the plug in the hose. After the entire oxygen system has been checked and if there is a sufficient supply of liquid oxygen available, the technician reports to the commander on the readiness of the aircraft for flight.

If the flight is cancelled for some reason, do as follows:  
(a) close the KB-5 valves ahead of the pressure increase automatic units and after the evaporator on the KHK-30 converters;

(b) release pressure from the pipe lines through the emergency cocks of the KH-24M economizers. This done, close the valves, type KB-5, on the aircraft oxygen panels.

**CAUTION:** To avoid fire and accidents, it is necessary to observe the following rules:

1. When releasing oxygen from pipe lines all the entrance hatches and ports must be open.
2. The clothes of the personnel handling oxygen equipment must be free from oil and grease.
3. When releasing oxygen, it is prohibited to perform any other work in the aircraft.
4. It is strictly prohibited to smoke.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM

POSSIBLE FAULTS OF OXYGEN SYSTEM AND MEANS OF THEIR ELIMINATION

The oxygen system may have the following defects:

- (a) leakage, clogging of the system;
- (b) faults of the instruments included in the system. Leakage in the system should be eliminated by additional tightening of the union nuts in places of oxygen leakage while clogging of the system should be eliminated by scavenging.

Checking System for Leakage

To check the system for leakage, do as follows:

1. Open the hatch of the aircraft charging pipe union.
2. Unscrew the plug from the end of the aircraft charging pipe union and screw the union nut of the charging hose on the charging pipe union.
3. Connect the pipe line from the stand (a cylinder with nitrogen) to the other end of the hose.
4. Charge the vessels of the KHX-30 converters and the pipe line with nitrogen whose purity and humidity correspond to those of medical oxygen increasing pressure to 10 atm. gauge. Charge the system slowly from forty-litre high-pressure (150 kg/sq.cm.) cylinders. During charging the pressure release valves of the KHX-30 converters must be closed, while the valves after the evaporators must be open.

**Note:** With the pressure increased, take particular care to see that the pipe lines joining the NVE oxygen level indicator and the KHX-30 converter are tightly connected.

5. The charging over, disconnect the pressure source and note the indications of one of the pressure gauges.
6. In no less than 12 hours measure pressure in the system again by means of the same pressure gauge.

The gastightness of the system is considered to be satisfactory if with the KB-5 valves open, the pressure in the system decreases not more than by 6.5 kg/sq.cm. during 12 hours or with the KB-5 valves closed, not more than by 5.2 kg/sq.cm.

- Note:**
1. When checking gastightness, take into consideration the effect of temperature change.
  2. To avoid errors due to possible hysteresis of the mechanism, slightly knock on the instrument case with the finger prior to taking readings.

7. If the system is found leaky, detect the leaky place first of all. For this smear all the places of connection of the pipe line to be replaced with soap-suds. In the event of considerable leakage the leaky place can be detected by the hissing of emerging gas. Examine all the connections and mark the detected leaky places to eliminate the leakage.

8. Slight leakage can be eliminated by careful tightening of the threaded connections without releasing nitrogen from the system. Bear in mind that over-tightening the threaded connections of pipes made of aluminum alloy often causes jamming and stripping of thread.

9. In the event of considerable leakage of nitrogen completely release pressure from the system. This done, start eliminating the leakage. To eliminate jamming of threaded connections and to ensure their gastightness, use special oxygen-proof lubricant.

10. After gastightness has been checked up, scavenge the system. For this expose through the aircraft charging pipe union apply a pressure of 10 atm. gauge to the system from the ground cylinder with pure oxygen. Open the emergency valve at each oxygen station in turn and scavenge each station during 30 or 60 seconds. A strong jet of gas will clean the system from impurities.

When applying pressure, the pressure release valve of the KHX-30 converter must be closed while the valve after the evaporator must be open.

11. When scavenging the entire system with medical oxygen, check the operation of the KHX-30 converter safety valves. For this:
  - (a) close the KB-5 valves after the evaporators on the KHX-30 converters;
  - (b) smoothly build up a pressure of 11.0 to 11.8 atm. gauge in the KHX-30 converters from the cylinder with medical oxygen. Under this pressure the safety valves must open (operate);
  - (c) reduce pressure in the KHX-30 converter vessels to one atm. gauge; opening the pressure release valve on one of the KHX-30 converters make sure by listening that the vessels are gastight; at this pay attention to the gastightness of the NVE oxygen level indicator pipe lines.

12. Release pressure from the KHX-30 vessels and disconnect the hose from the aircraft charging pipe union.

13. Screw the plug on the pipe union and close the hatch.

**CAUTION:** 1. When scavenging the system with oxygen, use of fire (smoking, lighting up matches, etc.) and presence of oil on pipe unions, valves and oxygen system units are absolutely prohibited.

2. To avoid accidents, open the oxygen valves slowly.
3. After the test and the elimination of faults in the system, thoroughly wipe each connection with a piece of clean gauze moistened with rectified alcohol.
4. Scavenging the system with pure oxygen should be done out-of-doors.

Effect of Temperature Change during Check of System Gastightness

When determining the system gastightness, take into consideration pressure change in the system caused by a change of gas temperature in connection with ambient air temperature change.

Gas pressure is directly proportional to the absolute temperature at constant volume, that is on condition of complete gastightness of the system, pressure increases at temperature rise and decreases at temperature drop. This relation is expressed by the formula:

$$\frac{P_1}{P_2} = \frac{T_1}{T_2}$$

$$P_2 = \frac{P_1 T_2}{T_1}$$

where  $T_1$  and  $T_2$  - absolute temperature equal to:

$$T_1 = 273 + t_1^{\circ}\text{C}; T_2 = 273 + t_2^{\circ}\text{C};$$

$P_1$  and  $P_2$  - gas pressure at temperatures  $T_1$  and  $T_2$ .

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 78 -

To take into account the influence of temperature upon pressure in the system, using the above given formula determine pressure to the amount of secondary pressure (in 12 hours after the measuring of initial pressure) and compare it with the original indications of the pressure gauge. If the difference of these pressures with the valves closed exceeds the amount of leakage permitted for this time (5.2 kg/sq.cm. per 12 hours), the gastightness is insufficient.

**Example of Calculation**

**Example 1.** Initial pressure in the system:  $P_1 = 10$  kg/sq.cm.  
Pressure by the reference pressure gauge:  $P_R = 6$  kg per sq.cm.  
Initial temperature:  $t_1 = 20^\circ\text{C}$ .  
Temperature in 12 hours:  $t_2 = 10^\circ\text{C}$ .  
The system is to be tested with the valves closed.  
Pressure in the system with no leakage:  
$$P_2 = \frac{P_1 t_2}{t_1} = \frac{10(273-10)}{(273+20)} = 9.65 \text{ kg/sq.cm.}$$

Pressure difference:

$$\Delta P = 9.65 - 6 = 3.65 \text{ kg/sq.cm.}$$

The difference thus determined is less than the permissible value of leakage (5.2 kg/sq.cm. per 12 hours). The system gastightness is satisfactory.

**Example 2.** Initial pressure:  $P_1 = 10$  kg/sq.cm.

Initial temperature:  $t_1 = 10^\circ\text{C}$ .  
Temperature in 12 hours:  $t_2 = 5^\circ\text{C}$ .  
Pressure as indicated by the reference pressure gauge:  
 $P_R = 3.5$  kg/sq.cm.

The system should be tested for leakage with the valves open.  
Pressure in the system with no leakage:

$$P_2 = P_1 \frac{t_2}{t_1} = \frac{10(273+5)}{(273-10)} = 10.57 \text{ kg/sq.cm.}$$

Pressure difference:

$$\Delta P = P_2 - P_R = 10.57 - 3.5 = 7.07 \text{ kg/sq.cm.}$$

The pressure difference obtained  $\Delta P = 7.07$  kg/sq.cm. exceeds the permissible leakage (5.2 kg/sq.cm. per 12 hours), therefore, the system is insufficiently gastight.

**Checking Shut-Off Valves**

After the leakage test, prior to scavenging the system, check the operation of the shut-off valves.

Check the shut-off valves with nitrogen for shutting off the EHK-30 converters and for equalizing pressure in the converters.

1. To check the converters for pressure equalizing, do as follows: fill the EHK-30 converters with nitrogen under a pressure of 10 atm. gauge. Then slowly release pressure from one converter through the pressure release valve by 0.5 or two atm. gauge; in this case pressure in the second converter must become equal to that in the first one in one or two minutes.

- 79 -

50X1-HUM

Pressure must be released from both vessels in turn.

2. To check the converters for shutting off the vessels, do as follows: fill the EHK-30 converters vessels with nitrogen under a pressure of 10 atm. gauge. Then sharply release pressure from one converter through the release valve to 0 atm. gauge. Pressure in the second converter must not drop more than 0.5 atm. gauge during 5 minutes.

**Note:** Checking the operation of the shut-off valve should be performed with the valves after the evaporators closed.

**Faults of EHK-30 Converters**

1. If the connection is found leaky, tighten it up. In case tightening is of no effect, replace the gasket.  
2. If the safety valve is leaky at 10 atm. or fails to operate at 11.0 - 11.8 atm. gauge, remove and replace it by a new one.  
3. If the automatic pressure increase valve fails (fails to close at 8.5 to 8.5 atm. gauge), replace it by a new one.

Prior to fitting the emergency valve, wash the line up to the automatic unit with liquid oxygen. For this do as follows:

(a) remove the oxygen valve;  
(b) plug the line after the valve running to the receiver;  
(c) by means of the second automatic unit increase pressure in the converter and force out liquid oxygen through the KB-5 valve ahead of the removed automatic unit.

4. If considerable evaporativity of oxygen from the EHK-30 converter is detected, check the converters for evaporativity using the Description of the EHK-30 converters.

5. If oxygen coming out of the converter has an unpleasant smell, the converter must be removed and washed.

6. Prior to the installation of a new converter on the aircraft in the event of replacement of the EHK-30 converter, check the new converter according to the Description of the EHK-30 converter.

**Washing the Vessel of EHK-30 Converter**

On detecting unpleasant smell of oxygen coming out of the EHK-30 converter wash and degrease the converter. For this do as follows:

1. Disconnect the pipe of the line from the KB-5 valve after the evaporator, the pipe of the shut-off valves from the cross-piece, pipes from the pressure release valve, the safety valve and the oxygen level indicator transmitter.

2. Remove the converter from the aircraft having unscrewed the attachment bolts.

3. Disassemble the converter and remove the vessel and the evaporator from the casing.

4. Fill the vessel with 6 litres of tetrachlorated carbon or pure gasoline; tilt the vessel and turning it round its axis during 10 minutes wash the vessel walls.

5. Force out the liquid with nitrogen through each pipe in turn.

6. Fill the evaporator completely with tetrachlorated carbon and then blow out the carbon. Repeat the procedure three times.

7. After the vessel has been washed with tetrachlorated carbon wash it with alcohol as described above. Washing with alcohol should be done not less than two times until the alcohol coming out of the vessel is quite transparent.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM

- 80 -

- 81 -

8. After washing the vessel with alcohol thoroughly scavenge it with dry oxygen or nitrogen (free from oil) till no smell is felt any more. Scavenge storage of oxygen under atmospheric pressure due to warm air coming from the vessel through each pipe in turn plugging the rest.
9. The fittings and pipes should be washed with alcohol and scavenged with oxygen and in four hours weigh it for the first time (during the first four hours evaporativity is increased due to the thermal capacity of the vessel). The hold a piece of white linen cloth against the stream of emerging gas and check the difference of weight in grams divided by the time in hours between the weighings is the evaporativity of the converter. The evaporativity must not exceed 250 gr per hour.
10. During scavenging check whether the washing is done properly. For this purpose weighing of the vessel should be done in 16 or 20 hours after the first weighing.
11. The washing completed, assemble the converter.
12. Apply paste, grade HMO-22, to all threaded connections. Dilute the paste just before the assembly of threaded connections. Paste, grade HMO-22, contains 15 gr of glycerine, 4 gr of dextrene and 32 gr of litharge.
- To prepare the paste, fill a mortar with glycerine, add dextrene and thoroughly grind the mixture. Then add litharge and grind it to obtain uniform compound.
- Cover the pipe union thread (but not the nut thread) with a thin uniform layer of paste. This done, assemble the threaded connection.
- When screwing the threaded connection again, remove the old paste from the face of the thread.
13. The assembled converter should meet the following requirements:
- (a) the evaporator must be arranged concentrically inside the case. The rubber stops must uniformly expand the evaporator relative to the vessel;
  - (b) the vessel must not move crosswise or lengthwise inside the case;
  - (c) the pipes must not come in contact with the nearest parts and each other;
  - (d) after assembly check the converter for leakage by means of dry medium, oxygen or nitrogen under a pressure of 10 atm. gauge. Check the gastightness by means of soap - suds. This done, wipe the connections with a clean piece of cloth moistened with rectified alcohol.
14. Fill the completely assembled converter with liquid oxygen and check the operation of the automatic pressure increase valves.
15. When checking the serviceability of the converter, do as follows:
- (a) plug the non-return valve and the pipe unions OXYGEN LEVEL INDICATOR TOP (YPOBHEMFP BEPK ) and OXYGEN LEVEL INDICATOR BOTTOM ( YPOBHEMFP HBS ); connect a pressure gauge and the pressure release valve to the pressure release pipe communicated with atmosphere;
  - (b) increase pressure in the converter. For this close the pressure release valve and open the valves ahead of the automatic pressure increase valves;
  - (c) watch pressure increase; in the converter filled by not less than 90 per cent, a pressure of up to 8.3 to 8.5 atm. gauge is reached during 3 or 5 minutes (but not in excess of 10 minutes), then pressure stops increasing. In 10 or 15 minutes after pressure increase the pipes ahead of the automatic unit must get warm as at such a pressure the automatic pressure increase valves are closed;
  - (d) note the time up to the moment the safety valve starts bleeding; with the sound automatic pressure increase valves this time must be not less than 45 minutes;
  - (e) in an hour after the beginning of the safety valve bleeding set the amount of consumption to 0.5 kg per hour. At this pressure must drop to 10 atm. gauge and leakage through the valve will stop;
  - (f) set oxygen consumption to 6 kg/sq.cm.; pressure in the converter must not drop below 8 atm. gauge.
16. Check the evaporativity of the converter without pressure. Evaporativity
17. All the operations and test results must be recorded in the Service Log.
- Care of HMK-30 Converter**
- 1. Prior to flight and after flight it is necessary to subject the converters to careful examination for mechanical damage.
  - 2. See that the vessels of the HMK-30 converters contain not less than 2 kg of liquid oxygen at all times.
  - 3. It is not recommended to leave a small amount of liquid oxygen in the vessel because during evaporation in the remaining oxygen there are concentrated in particular substances of unpleasant smell which will be absorbed by newly filled oxygen.
  - 4. Take care to protect the converters from oil and grease.
  - 5. Liquid oxygen always contains lubricating oil which gets into oxygen during the production of the latter. During the service of the converters this oil settles down on the vessel walls therefore the vessels should be washed (degreased) periodically.
- Faults of Instant-Reading Liquid-Oxygen Indicator, Type HMK-30 (Fig. 47)**
- 1. With the power supply switched on and pressure drop changed in the transmitter, the indicator pointer does not move. This may take place if there is no proper contact in plug connectors. To eliminate the fault, check the supply line and repair it if broken.
  - 2. If the instrument reading errors exceed the permissible values, tighten up the union nuts where the pipe lines are connected to the vessel and check the system for leakage or check the bunched conductors lines and eliminate the defect.
- Checking HMK-30 Converters for Evaporativity**
- After the HMK-30 converters have been installed in the aircraft, as well as every three months and on expiration of the guaranteed period of service life, the HMK-30 converters should be tested for evaporativity.
- Check the converters for evaporativity by means of the K-4 testing device as follows:
- 1. Close the EB-5 valves ahead of the automatic pressure units and after the evaporators.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 82 -

2. Open the pressure release valve of both vessels of the KHE-30 converter.
  3. Fill the KHE-30 converters with the amount of liquid oxygen required for the next flight as prescribed in the Section "Filling the KHE-30 Converters with Liquid Oxygen".
  4. After filling, disconnect from the cross-piece the KHE-30 converter pipes connecting the shut-off valves to the KHE-30 converters and plug the cross-piece pipe unions.
  5. From the tee-piece in the pressure release line disconnect the pipe running to the pressure gauge and connect the pipe union of the tee-piece to a union of the KI-4 testing device rheometer.
  6. In four hours after fitting the vessels with liquid oxygen close the pressure release valve and during two hours every 15 minutes measure by the rheometer the amount of gas coming out of the converter (in litres per minutes). Average the results of all measurements.
  7. Convert the average capacity of losses thus obtained (in litres per minute) to units of weight (in grams per hour) using the graph of Fig. 55 taking into account the ambient air temperature. The permissible amount of losses due to evaporativity is not in excess of 250 grams per hour at a temperature of  $15 \pm 5^\circ\text{C}$ , at a temperature of  $30$  to  $50^\circ\text{C}$  the amount of losses increases by  $50$  to  $90$  grams per hour, while at temperature of  $-20$  to  $-30^\circ\text{C}$  it decreases by  $50$  to  $60$  grams per hour.
  8. After checking the converter for evaporativity, open the pressure release valve, connect the pipes joining the shut-off valves with the cross-piece on a KHE-30 converter and connect the pipe running to the pressure gauge with the tee-piece in the pressure release line.
- Note:** On completing the test of the vessels for evaporativity make record in a special log; indicate the number of the aircraft, the number of the KHE-30 converter vessels and the amount of evaporativity.

Faults of KI-24M Economizer

1. If the high and low-pressure cavities are out of repair, replace the apparatus by a new one.
  2. In case leakage is detected in the valve of the economizer, connect the KI-30M mask to the apparatus and make several deep inhalations. If leakage persists, replace the apparatus by a serviceable one.
- Note:** In the event of replacement of the KI-24M economizer prior to installation on the aircraft check the economizer by the Descriptive of the KI-24M apparatus.

Faults of KI-24M Set

Repair of the KI-24M economizer set involving disassembly and adjustment is not permitted in field conditions. In this case the items to be repaired should be replaced by new ones; the removed items must be sent to repair shop.

Leakage in High-Pressure System

If during the high-pressure system leakage test the pressure gauge indications decrease, the system is leaky.

Detect leaky places by means of soap-suds.

As a rule, leakage is detected by tightening up the union nuts. However, leakage in the system is sometimes caused by a leaky economizer valve. This being the case, replace the faulty apparatus by a new one.

- 83 -

Leakage in Low-Pressure System

In case the low-pressure system is leaky, the best way of detecting the leak is to divide the low-pressure system into several sections. Suppose that the leaky low-pressure system is divided into three sections:

- 1st section - from the mask (with the mask-to-face tightness compensator connected to it) to the excessive pressure limiter.
- 2nd section - from the pipe union of the hose running to the KI-23 apparatus and to the elbowed pipe union with a union nut of the KI-24 hose.
- 3rd section - KI-24M economizer.

When checking the 1st section, close the hole in the excessive pressure limiter lock with a hand and make a long but not deep inhalation. If it is impossible to inhale, the 1st section is gastight.

The check over, connect the excessive pressure limiter lock to the pipe union of the hose running from the KI-23 apparatus.

To check the 2nd section, disconnect the KI-24 hose from the KI-24M apparatus, close with a hand the hole in the hose elbowed pipe union and make a long but not deep inhalation. If it is impossible to inhale, the 2nd section is gastight.

After the check-up, connect the KI-24 hose to the KI-24M apparatus. Before doing so, check to see that the apparatus valve is closed, the air dilution switch handle is set to the CLOSED (ЗАКРЫТО) position and the KI-13M pressure gauge pointer is at zero.

When checking the 3rd section, make a long but not deep inhalation. If you cannot do so, the 3rd section is gastight. If it is possible to make an inhalation, the low-pressure cavity of the KI-24M apparatus is leaky. This being the case, replace the defective apparatus by a new one.

Bear in mind that the gastightness of the low-pressure system depends to a great extent on the condition of the rubber gaskets fitted in each joint. Therefore, pay special attention to the joints and replace unserviceable gaskets by new ones in due time.

Faults of KI-30M Mask

1. A faulty exhalation valve. In most cases the leakage of the exhalation valve is caused by dust, sand and other foreign objects getting under the valve. On detecting leakage, wash the valve with a pad moistened with clean water or blow it with oxygen (without dismantling the valve and the mask). This done, reset the valve for leakage. If the valve is still leaky, replace the mask by a new one.
2. Leaky connections of the mask with the mask-to-face tightness compensator and the hose running from the KI-23 apparatus. In such cases replace the gaskets and then reset the connections for leakage.
3. Leakage in the mask body, corrugated hose and mask-to-face tightness compensator. In such cases replace the mask and the mask-to-face tightness compensator by serviceable ones.
4. Leakage in the excessive pressure regulator valve. This being the case, replace the mask by a serviceable one.

Faults of KI-24 Hose

Leakage in the hose (Fig. 49) closed with a plug. This being the case, replace the gasket of the plug. If the leakage is not eliminated, replace the hose by a serviceable one.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 54 -

Faults of MK-12M Flow Indicator of MK-12M Pressure Gauge and H-1000 Pressure Gauge

1. The glass is broken, the body is cracked, the luminous compound has come off.
  2. The indicator blinkers fail to react to inhalations and exhalations.
- In case one of these faults is detected, replace the flow indicator or the pressure gauges by serviceable ones.

Faults of EB-2 Valves

1. Leakage in the valves cavities.
  2. Leakage in the valves flap.
- If at least one of the faults is detected, the valves should be replaced by new ones.

Faults of Tee-Pieces with Non-Return Valves

- Leaky non-return valves. To eliminate leakage, disassemble the unit with non-return valves, wipe the valves and seats with a piece of gauze moistened with pure gasoline (without oil); at this take care to see that all foreign particles (white or brown deposit) are removed from the valves and seats. Next, wash all the parts of the disassembled unit in pure gasoline (without oil), blow them with oxygen and assemble. Check the newly assembled unit for leakage.
- If the unit with non-return valves is still leaky, do as follows:
- (a) replace defective valves and seats in the unit by new ones or
  - (b) replace the entire unit by a serviceable one.

Faults of MK-25 Parachute Oxygen Breathing Apparatus

1. The apparatus is leaky.
  2. The disconnector operation is improper (the box of the MK-24M economizer is disconnected with difficulty).
  3. The non-return valve of the change-over switch is leaky (oxygen leaks out after the disconnector has operated).
- If at least one of these faults is detected, replace the apparatus by a serviceable one.

POST-FLIGHT INSPECTION

1. Open hatches (if they are closed) to obtain access to the oxygen equipment.
2. Check oxygen pressure in the line by the pressure gauges, type MK-12M.
3. In accessible places examine pipe lines and their attachment, oxygen panels and instruments.
4. Check the amount of liquid oxygen remaining in the MK-30 converter by means of the MKK liquid oxygen level indicators. In case of necessity add oxygen.
5. Record pressure in the vessels of the MK-30 converter by the pressure gauges mounted near the MK-30 converter.
6. Check the gastightness of all connections on the MK-30 converters (without releasing pressure).
7. Make sure that the safety valve is serviceable. If pressure in the apparatus amounts to 11 or 11.8 atm. gauge the safety valve must be open. If pressure in the apparatus is below 10 atm. gauge, the valve must be tightly closed.

- 55 -

- The permissible leakage through the safety valve at 10 atm. gauge is not in excess of 200 cu.cm. per minute.
8. Check the MK-24M economizer set. For this:
    - (a) carry out outside examination of the MK-24M economizer mask, mask-to-face tightness compensator and the PR-24 regulator; check to see that the items are free from damage and moisture;
    - (b) check the operation of the automatic pressure increase units and
  9. Close the EB-5 valves ahead of the automatic pressure increase units and after the evaporators on the MK-30 converters.
  10. Release oxygen from the pipe lines and converters by opening the emergency cock of the MK-24M economizer at each oxygen station.
  11. Close the EB-5 valves at oxygen stations.
  12. Wipe the masks with a piece of gauze soaked with alcohol and place it together with the mask-to-face tightness compensator and the corrugated hose into special bags located at the working stations of each member of the air-crew.
  13. Examine the parachute apparatus and send them out for storage at depots or to special workshops.
  14. To save liquid oxygen, do not release pressure from the MK-30 converters.
  15. If it is necessary to add liquid oxygen to the MK-30 converters, release pressure from the apparatus.
  16. If any faults are detected during the flight or inspection, eliminate them in compliance with the Section "Possible Faults".
  17. Put cases on the MK-24M economizers.

PRESSURE RELEASE

- Open the pressure release valves by 1/4th of the knob turn and then slowly (during 3 or 5 minutes) open the valves completely.
- Determine complete pressure release by the pressure gauge.

**Note:** During pressure release intensive evaporation of liquid oxygen in the vessel takes place. The amount of oxygen which has evaporated is directly proportional to the amount of oxygen absorbed by the liquid oxygen. The maximum amount of liquid oxygen which may evaporate during pressure release is equal to 10 kg. This corresponds to pressure release when the apparatus vessel contains 25 or 27 kg of liquid oxygen completely heated to the boiling point at a pressure of the safety valve releasing. If the apparatus vessel contains less liquid oxygen, the amount of evaporating oxygen during pressure release will be proportionally less.

STORAGE OF LIQUID OXYGEN IN MK-30 CONVERTERS

It is permitted to store liquid oxygen in the MK-30 converters in sealed vessels under pressure and without pressure.

Storage of Liquid Oxygen in Sealed Vessels of MK-30 Converters

If the MK-30 converters are filled with liquid oxygen 12 or 16 hours before flight, it is recommended to close the MK-30 converters in an hour after filling. For this close the pressure release valves and the valves after the evaporators (if they are open).

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 86 -

Leave the converters in this condition as at evaporativity of 250 grams per hour no oxygen will be lost during this time because the entire amount of the warmth coming to the vessel from the outside will be spent for warming up liquid oxygen.

Pressure in the vessel will increase gradually. The storage period of liquid oxygen in the KHE-30 converters closed vessels without losses is from 27 to 46 hours.

**Note!** The less liquid oxygen is contained in the apparatus, the less is the time of its storage in closed vessels without losses, because less heat is required for warming up oxygen to the boiling temperature at a pressure of safety valve releasing.

The approximate time required for increasing pressure in a closed vessel to a pressure of safety valve releasing depending on the amount of liquid oxygen in the converters is given in Table 16.

Table 16

Time Required for Safety Valve Releasing Versus  
Amount of Liquid Oxygen and  
Evaporativity

Weight, kg	Amount of warmth Q, cal.	Time required for increasing pressure to 10 atm. gauge at evaporativity, grams per hour		
		150	200	250
25	360	46 hours	35 hours	27 hours
20	280	35 hours	25 hours	21 hours
15	210	26 hours	20 hours	16 hours
10	140	16 hours	13 hours	10 hours

Here Q is the amount of warmth in calories required for heating liquid oxygen to 10 atm. gauge.

Storage of Liquid Oxygen in KHE-30 Converters  
under Pressure

If the KHE-30 converters are in the operating condition, liquid oxygen in the KHE-30 converters vessels can be stored under pressure. For this close the KB-5 valves ahead of the automatic pressure increase unit and after the evaporators. Do not open the pressure release valves as during pressure release losses may amount to 10 kg.

When storing liquid oxygen on the KHE-30 converters under pressure, losses do not exceed 6 kg a day.

Storage of Liquid Oxygen in KHE-30 Converters  
without Pressure

If the vessels of the KHE-30 converters are filled with liquid oxygen two days before flight it is recommended to leave the pressure release valves open for 16 or 20 hours and then close the vessels, that is close the pressure release valves.

- 87 -

50X1-HUM

## PRECAUTIONARY MEASURES

1. Protect all pipe line joints and apparatus elements from oil and grease.
2. When filling liquid oxygen, fence the place where oxygen is drained (from the pressure release valve).
3. The overalls of the personnel engaged in filling the KHE-30 converters with liquid oxygen and in testing the apertes should be clean and free from grease stains. The ground near the aircraft must be cleaned from oil and kerosene.
4. When filling the apparatus with liquid oxygen and testing the system, it is prohibited to smoke, to light matches, etc.
5. Be careful when filling the apparatus with liquid oxygen and see that no liquid oxygen gets onto the skin to avoid frost biting (burns).
6. Prevent moisture from getting into the vessels of the KHE-30 converters and pipe lines as on filling the vessels with liquid oxygen water is turned into ice, which might cause failure of the apparatus.
7. Prior to filling liquid oxygen remove the case of the fuselage compartment (in the 6-3 cabin) in the area of the pressure release drain holes.
8. Take care not to spill liquid oxygen as all organic substances moistened with liquid oxygen are explosive and inflammable until oxygen is completely evaporated.

## Quality of Oxygen

Fill the vessels of the KHE-30 converters only with medical liquid oxygen. Oxygen must have a Certificate indicating whether it meets the requirements specified by Item 2 of State Standards (ГОСТ) 6332-52

INSTRUCTIONS FOR PACKING PARACHUTES WITH  
KH-23 OXYGEN BREATHING APPARATUS

Fig. 50 shows the position of the KH-23 oxygen breathing apparatus in relation to the seats of the aircrew members, which ensures safe and reliable disconnection of the KH-23 apparatus disconnectors during ejection.

To prevent the breathing apparatus hoses from being broken place them into the seats very carefully. In doing so observe the following order:

1. On the navigator's seat lay the short oxygen hose of the KH-23 breathing apparatus through the weight lightening hole in the seat right-hand arm rest as shown in Fig. 51.

**CAUTION.** It is strictly prohibited to pass the oxygen hose through clamp 3 (Fig. 51) as during ejection the snap hook of the KH-23 apparatus locking pins may stick in the clamp. As a result the oxygen disconnector will fail to get disconnected and the supply will fail to change over from the aircraft mains to the KH-23 apparatus.

2. On the pilots' seats when connecting the apparatus hoses to the aircraft hoses pass the short oxygen hoses into the seat arm rests through the cuts in the arm rests to prevent the apparatus hoses from being broken.

3. Prior to placing the parachute on the navigator-operator's seat pass the short hose of the KH-23 breathing apparatus through the hole in the rear part of the seat pan right-hand side. If the hose is passed into the hole of the side after the parachute is placed on the pan, the hose must be sharply beat which causes its rapid wear.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



- 68 -

- 4. On the gunner-radio operator's seat see that the parachute does not swing towards the seat back otherwise the oxygen hose will be crumpled by the hand arm rest.
- 5. The parachute with the KH-23 breathing apparatus is freely arranged on the gunner's seat, and no special instructions on packing are required.

50X1-HUM

ELECTRICAL EQUIPMENT

GENERAL

The electrical equipment of the aircraft, model TV-16, consists of D.C. and A.C. power supply sources, aircraft electric mains and electric power consumers.

The major D.C. power supply sources of the aircraft are four generators, type ICP-18000, of 18-KW power each; the generators operate in parallel and are connected to the aircraft mains to produce a total power of 72 KW, 28 - 28.5 V.

Apart from the generators, the aircraft is provided with a starter-type storage battery, type 12CAM-55; the battery operates in parallel with the generators and serves as a stand-by power supply source.

For A.C. power supply the aircraft is equipped with two HO-4500 inverters which invert direct current into alternating current of 115 V, 400 c.p.s.

The aircraft electric mains consists of wires gauging from 0.35 to 95 sq. mm and incorporates switching equipment, as well as control and protective devices. The mains uses mainly non-shielded and shielded wires, mark EMBL, the airframe being used as the minus wire. In order to lighten the weight of the electrical equipment the D.C. electric power distribution lines are made of aluminum wire, mark EMBR.

Direct and alternating currents are consumed by various instruments and units provided with remote control facilities, as well as by complex automatic systems (the autopilot, cannon system fuel quantity and flow gauging equipment, etc.), signalization means, heating, de-icing, illumination equipment and radio equipment.

The aircraft electric mains is connected to ground power supply sources through two ground-supply plug connectors; one of the plug connectors is used for connecting D.C. ground supply sources, whereas the other - for connecting A.C. ground power supply sources.

AIRCRAFT ELECTRIC MAINS

The entire electric mains system of the aircraft consists of two major sections:

1. The D.C. circuit of 28-28.5 V supplied from the ICP-18000 generators and the storage battery, which is connected for buffer operation with the generators.

2. The single-phase A.C. circuit of 115 V, 400 c.p.s. which is supplied from the operating or stand-by inverter, type HO-4500.

To ensure effective all-condition operation of the aircraft, the D.C. circuit is divided into three subcircuits:

- (a) the normal supply circuit;
- (b) the emergency supply circuit;
- (c) the dual supply circuit.

SECRET  
NO FOREIGN DISSEM



NO FOREIGN DISSEM

50X1-HUM

As a rule, connected to the normal supply circuit are all the four generators and the storage battery (Fig.52). The generators and the storage battery are connected separately and therefore they may be connected to the normal supply circuit in any combination, for example: one generator and the storage battery or two generators and the storage battery, and so on.

Connected to the emergency supply circuit can be only one generator (either generator 2 installed on the left engine, or generator 3 installed on the right engine) and the storage battery.

With the aid of switching contactors, type EI (EI-200I EI-400I), the dual supply circuit is automatically connected either to the normal supply circuit (in case it is energized) or to the emergency supply circuit if the normal supply circuit is de-energized.

The schematic distribution diagram of D.C. supply system (of the aircraft main system) is presented in Fig.53.

The normal, emergency and dual supply mains provide power supply to three groups of distribution busbars:

1. The normal supply busbars which are connected only to the normal supply circuit.
2. The dual supply busbars connected to the dual supply circuit.
3. The triple supply busbar which is usually connected through a special change-over switch to the dual supply circuit and, consequently, is energized from the normal or emergency supply circuit. In case of failure of the normal and emergency supply circuits this busbar is manually reset for direct supply from the storage battery.

The distribution busbars have no direct connection to the emergency supply circuit.

The normal supply busbars feed such power consumers which are necessary for normal operation of the aircraft but which can be done without in emergency conditions. Such power consumers are: the autopilot, de-icers, heaters, ventilators, camera equipment, part of the illumination system, etc.

The dual supply busbars feed such consumers which make it possible to fulfill the mission and to return to the base airfield even in case of the faulty normal supply circuit. Such power consumers are: the bombing system, flight control and navigating instruments, fuel system pumps, landing flap actuator, i.e. warning system, part of illumination system, etc.

The triple supply busbar (the busbar which provides battery supply of the instruments with the mains de-energized) supplies voltage only to such power consumers which are absolutely necessary for accomplishment of a forced landing of the aircraft in case of failure of the normal and emergency power supply circuits. These consumers are: the main gyro horizon, bank-and-turn indicator of the pilot, remote indicating astrocompass, type IAK-15-S, heater of the upper left pitot tube, type TI-156, circuit No.1 of the interphone system and the emergency illumination system (the ultra-violet illumination lamps of the pilot's and navigator's instruments panels, the receptacle of the pilot's extension lamp and the illumination system of the KH-12 compass), automatic brake control unit, drag chute system, engine blow-off hand control system, CO<sub>2</sub> bottle control system, fuel shut-off and stopcock control system and radio station, type PCH-3U.

Three consumers: the feeder of the in-flight engine starting, the feeder of the top emergency bomb dropping system and the radar transponder destructor feed are connected directly to the storage battery and may be used at any moment with additional switching and change-over operations on the power supply sources.

additional switching and change-over operations on the power supply sources.

**Operating Duties of Electric Mains**

In view of the necessity of voltage supply to some power consumers even in conditions when separate sections of the electric supply mains are damaged the D.C. electric power distribution system is designed to allow three operating duties:

- normal;
- emergency;
- de-energized mains duty, when only consumers of vital importance are connected to the storage battery.

**Normal duty.** In the normal operating duty the electric mains, as a rule, connect all the four generators and the storage battery. In this case energized are all the busbars of the normal supply circuit; the busbars of the dual supply circuit and the busbar which supplies the instruments from the battery with the mains de-energized (the triple supply busbar).

To select the normal operating duty, it is necessary that the switches and selectors located on the generator control panel (Fig.55) at the radar operator's station should be placed to the following positions:

1. The switches of all the four generators and the battery-to-normal supply circuit blocking switch should be ON.
2. The storage battery change-over switch should be thrown to NORMAL (НОРМАЛЬНО).
3. The voltmeter change-over switch should be turned to NORMAL SUPPLY CIRCUIT (НОРМАЛЬНАЯ СЕТЬ).
4. The emergency supply circuit switch should be in the OFF position.
5. The change-over switch connecting the generators to the emergency supply system (bearing the inscription FROM GENERATOR ( ОТ ГЕНЕРАТОРА ) should be placed to LEFT No.2 ( ЛЕВЫЙ 2 ).
6. The change-over switch bearing the inscription BATTERY SUPPLY OF EMERGENCY INSTRUMENTS ( БАТАРЕЙНОЕ ПИТАНИЕ ИНСТРУМЕНТОВ НА ПАТЯХ ОТ АККУМУЛЯТОРА ) should be thrown to OFF.
7. The switch with the label GROUND SUPPLY ( АСХОПОННОЕ ПИТАНИЕ ) should be OFF.

**Note:** The storage battery blocking switch is rigidly fixed to the generator-emergency switch connecting bar; this means that when at least one of the generator switches is ON, the storage battery blocking switch is also engaged.

In case of failure of part of the generators, connected to the normal supply circuit may be three, two or even one generator in combination with the storage battery. When connected to the normal supply circuit are three generators plus the storage battery, the number of connected consumers is unlimited, that is, the flight may be continued in the same conditions, as if all the four generators were operating. In case the normal supply circuit connects only two generators plus the storage battery connected simultaneously may be either the cannon system with continuously operating consumers or the tail unit de-icers with continuously operating power consumers. It is forbidden to connect the cannon system and the tail unit de-icer system simultaneously. When it is only the combination of one generator and the storage battery which is connected to the normal supply circuit, the total number of power consumers connected should ensure that the total load does not exceed 600 A.

SECRET NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

**Emergency duty.** In case a shorting appears in the normal supply mains (the trouble will be indicated by beyond-scale movement of the ammeter needles and by decreased-voltage indications of the voltmeter) or in case of another trouble which requires disconnection from the normal supply circuit, the radar operator should quickly select the emergency supply circuit which is de-energized in the normal operating duty serving as a stand-by circuit.

When flying with the supply mains in emergency duty, the circuit in operation connects one of the two generators (generator 2 on the left engine or generator 3 on the right engine) and the storage battery. In this case energized are the emergency supply circuit, the dual supply busbar and the triple supply busbar. The normal supply circuit and its busbars are disconnected and de-energized.

To change from the normal to the emergency operating duty the following action should be done on the generator control panel at the radar operator's station (Fig.54):

1. Operate the generator emergency disconnection lever to disengage all the four generators and the storage battery from the normal supply circuit.
2. Turn the emergency supply circuit switch ON.
3. Place the voltmeter change-over switch to the EMERGENCY SUPPLY CIRCUIT position.

4. As a result (See the Diagram in Fig.54):  
(a) the storage battery will get disconnected from the normal supply circuit;

(b) all the four main differential undercurrent relays, type RMP-600, will disconnect the generators from the normal supply circuit;  
(c) generator No.2 will become connected to the emergency supply circuit through its additional relay, type RMP-600.

When sure (by the ammeter and voltmeter readings) that the emergency supply circuit and generator No.2 operate normally, the storage battery change-over switch should be placed to the EMERGENCY POSITION (АВАРИЙНО); this action will connect the storage battery to the emergency supply circuit for buffer operation with the generator.

- Notes:**
1. In case left generator No.2 or its circuit is faulty, the generator change-over switch should be turned to the RIGHT No.3 (ПРАВЫЙ #3) position. In this position connected to the emergency supply circuit instead of generator No.2 (installed at the left engine) will be generator No.3 located on the right engine.
  2. At the moment of the emergency supply circuit selection it is necessary to disconnect the inverter, type ИД-4500, so as not to overload the generator with large starting currents during its connection to the circuit. Upon engagement of the generator it is necessary to re-engage the inverter.

In the course of emergency-duty flying it is allowed to use only those power consumers which are connected to the dual supply busbars (See Table 17) and to the triple supply busbar (See Table 18). Under these conditions the flying time has no specific limitations.

In case the emergency supply system is faulty it is necessary to select the de-energized mains operating duty.

**De-energized mains operating duty.** Under the headlined duty conditions the normal and emergency supply circuits will be de-energized, and the storage

battery will supply only those consumers which are vitally important for flight continuation (See Table 18). The following operations should be carried out on the generator control panel at the radar operator's station to select the duty in question:

1. Turn on the change-over switch labelled BATTERY SUPPLY OF EMERGENCY INSTRUMENTS (РЕЗЕРВНЫЕ АВАРИЙНЫЕ ПИТАЮЩИЕ НА ПИТАНИЕ ОТ АККУМУЛЯТОРА).
2. Turn the emergency supply circuit switch off.
3. Turn the storage battery switch off.
4. Turn off the switches of the four generators and the blocking switch of the storage battery.
5. Turn the voltmeter change-over switch to STORAGE BATTERY (АККУМУЛЯТОР).

**CAUTION:** The storage battery, type 12-CAM-55, is capable of supplying the instruments listed in Table 18 for not longer than two hours.

Table 17

Consumers Connected to Dual Supply Busbar

No.	Description	Protector of consumer and type of fuse	Marking of feeder
1	2	3	4
1	Fuel flow controller, left	A3C-5	AI
2	Fuel flow controller, right	A3C-5	AI
3	Bomb emergency dropping control	A3C-5	BA
4	Electric bomb release supply (release of bombs armed)	A3C-15	BE
5	ARMED-SAFE system	A3C-10	BB1
6	Armed emergency dropping system	A3C-10	BB2
7	Fuse circuits, left front	CH-5	BBa
8	Fuse circuits, right front	CH-5	BBd
9	Fuse circuits, left rear	CH-5	BBr
10	Fuse circuits, right rear	CH-5	BBr
11	Bomb emergency dropping control relay	A3C-2	BI
12	Bomb emergency dropping control relay	A3C-2	BE
13	Armed bomb release blocking relay	A3C-2	BI
14	Armed bomb release blocking relay	A3C-2	BI
15	Emergency bomb dropping system supply	ИД-50	BH
16	Sight supply	A3C-15	BI
17	Supply of bomb release variant selector box, type KBCB-48	A3C-5	BP
18	Rear adapter disconnecting relay	A3C-2	BD
19	Starting system supply	A3C-25	+3
20	Air cock of left engine	A3C-5	1aA
21	Left engine starting system	A3C-15	1aB
22	Left engine starting system control	A3C-5	1aH
23	Left engine ignition system	A3C-20	1aH
24	Air cock of right engine	A3C-5	2aA
25	Right engine starting system	A3C-15	2aB

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 94 -

- 95 -

1	2	3	4	1	2	3	4
26	Right engine starting system control	A3C-15	2aB	63	IIS equipment	A3C-10	FM
27	Right engine ignition system	A3C-20	2aM	64	Aircraft transponder	A3C-5	PO
28	Inverter, type DD-4500, stand-by	TH-200		65	Radar bomb sight, type PBI-4, (control)	A3C-20	FW
29	Fuel pump of left tank No.19	HH-15	MEa	66	Command radio station, type PCMU-3M	A3C-5	FB
30	Fuel pump of left tank No.16	HH-50	MEG	67	Antenna duplexer of radar altimeters, types FB-2 and FB-17	A3C-2	FW
31	Fuel pump of left tank No.10	HH-75	MEa	68	Left tank group fuel pump warning system	A3C-2	CE
32	Fuel pump of left tank No.2	HH-75	MEb	69	Bombing equipment warning system	A3C-5	CB
33	Fuel pump of right tank No.3	HH-75	MEa	70	Right tank group fuel pump warning system	A3C-2	CA
34	Fuel pump of left tank No.4	HH-75	MEa	71	Hydraulic system warning unit	A3C-2	CT
35	Fuel pump of right tank No.5	HH-75	MEa	72	Cabin sound warning system	A3C-2	CB
36	Fuel pump of left tank No.6	HH-50	MEa	73	Mach limit warning system	A3C-2	CM
37	Fuel pump of right tank No.6	HH-50	MEa	74	Differential pressure warning unit of front cabin	A3C-2	CO
38	Fuel pump of right tank No.10	HH-75	MEa	75	Fire warning unit of left tank group	A3C-15	CH
39	Fuel pump of right tank No.16	HH-50	MEa	76	Fire warning unit of right tank group	A3C-15	CV
40	Fuel pump of right tank No.19	HH-15	MEa	77	Follow-the-leader bombing procedure leaps	A3C-15	CO
41	Fuel stopcock of left engine	A3C-5	MEF	78	Colour flare bomb normal release system	A3C-20	CI
42	Fuel stopcock of right engine	A3C-5	MEa	79	Colour flare bomb bay doors warning system and release control interlock	A3C-2	CI
43	Fuel shut-off cock	A3C-5	MEa	80	Colour flare bomb emergency dropping system	HH-30	CI
44	Air position indicator (dead reckon- ing computer system, type HH-50B	A3C-5	IX	81	Colour flare bomb station status indicator	A3C-2	Cu31
45	Flap actuator, electric motor No.1	HH-150	IX	82	L.O. warning system	A3C-2	CM
46	Flap actuator, electric motor No.2	HH-150	IX	83	Colour flare bomb emergency dropping control	A3C-2	CM
47	Ultra-violet illumination of pilot's instrument panel and overhead electric control board	A3C-2	IV	84	Heaters of Pitot tube of co-pilot, radar operator, radio operator, HH-50B air position indicator and OHS-11p sight	A3C-10	TH
48	Directional gyro of pilot	A3C-5	IX	85	Control of stand-by pumps of tanks No.16	A3C-2	JFA
49	Gyro horizon set of pilot	A3C-5	IX	86	Control of stand-by pumps of tank No.6	A3C-2	JFb
50	Gyro horizon set and directional gyro of co-pilot	A3C-5	IX	87	Remote-indicating compass	A3C-2	JX
51	Three-pointer indicator, type 3M-3P, of right engine	A3C-2	IX	88	CO <sub>2</sub> bottle control	A3C-10	JF
52	Fuel quantity gauge of left engine tanks	A3C-2	IX	89	Emergency fuel jettison valve system	A3C-2	JX
53	Fuel quantity gauge of right engine tanks	A3C-2	IX	90	Control of stand-by inverter, type HO-4500	A3C-2	JH21
54	Fuel flow gauge of left engine tanks	A3C-2	IX	91	Bomb bay doors control (normal)	A3C-5	JX
55	Fuel flow gauge of right engine tanks	A3C-2	IX	92	Bomb bay doors control (emergency)	A3C-5	JH
56	Fuel pressure gauge	A3C-2	IX	93	Flap control, electric motor No.2	A3C-5	JF
57	Three-pointer indicator, type 3M-3P, of left engine	A3C-2	IX	94	Fuel flow control	A3C-2	JX
58	Bank-and-turn indicator of co-pilot	A3C-2	IV				
59	Flap position and free air tempera- ture indicator	A3C-2	IX				
60	Range-finder, type CR-1	A3C-2	IX				
61	Radio compass, type AFX-5, No.1	A3C-2	IX				
62	Radio compass, type AFX-5, No.2	A3C-2	IX				

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 96 -

- 97 -

1	2	3	4
95	Flap control, electric motor No.1	A3C-5	7H
96	Control of first fuel pump group of left engine	A3C-5	7a1
97	Control of first fuel pump group of right engine	A3C-5	7a2
98	Control of second group fuel pumps	A3C-5	7a3
99	Control of third group fuel pumps	A3C-5	7a4
100	Control of fourth group fuel pumps	A3C-5	7a5

Table 18

Consumers Connected to Triple Supply Busbar for Storage Battery Supply of Instruments in Case of De-Energized Mains

No.	Description	Protector of consumer and type of fuse	Marking of feeder
1	Emergency ultra-violet illumination of front cabin and illumination of RH-12 compasses	A3C-5	GA
2	Gyro horizon set, master	A3C-5	HE
3	Bank-and-turn indicator of pilot	A3C-2	HH
4	Interphone system channel No.1	A3C-5	FA1
5	Interphone sets CHV-10	A3C-2	FA-20
6	Hesters of TH-156 Pitot tube of pilot, navigator and velocity head warning unit CCS-3	A3C-5	TH
7	Automatic brake control unit	A3C-10	AF
8	Engine blow-off band control system		
9	CO <sub>2</sub> bottle control system	A3C-10	FE
10	Drag chute control system	A3C-5	JC
11	Fuel shut-off and stopcocks control system	A3C-5	MG
12	Radio station, type PWH-3M	A3C-5	P7
13	Radio transponder destructor	No protection	2A31
14	De-energized mains bomb release	No protection	2C
15	In-flight engine starting system	No protection	3H

Protection of Electric Mains

The electric mains of the aircraft is built up of separate feeders. Term "feeder" is a single consumer or a group of power consumers supplied through a separate protective device (a circuit breaker or fusible cutout). The following protective devices are used for protection of the aircraft mains and power consumers:

- (1) Automatic circuit breakers of A3C family.

- (2) Glass fuses of CH family.
- (3) Delayed-action fuses of HH family.
- (4) High-beat fuses of TH family.

Automatic circuit breakers of A3C type (Fig.56) are employed for automatic disconnection of electric power consumers, as well as for protection of electric wires against dangerous over-loads and short circuits in electric circuits. The circuit breakers can be used for manual on-off switching operations on electric circuits, in which case they function as ordinary single-pole switches. However, the largest part of the circuit breakers installed in the aircraft act as fuses, and therefore they should be always turned on before each flight and held in this position throughout the entire flight. The automatic circuit breaker is engaged manually by its operating handle. In overload and short-circuit conditions the circuit breaker is out out automatically; under normal loading conditions the circuit breaker is disengaged manually.

The circuit breakers are mounted in D.C. circuits with nominal voltage of 28 V, as a rule, in locations where they are easily accessible in flight. The following range of automatic circuit breakers is used on the aircraft: A3C-2, A3C-5, A3C-10, A3C-15, A3C-20, A3C-25, A3C-30, A3C-40 and A3C-50 (the hyphenated figure indicates the nominal voltage the circuit breaker is rated for).

Fuses, types CH, HH and TH (Fig.57), are designed for protecting electric units from short-circuit currents and continuous, although small over-loads. Delayed-action fuses ensure normal protection and at the same time withstand instantaneous current surges (300% and even 600% of rated currents) which are characteristic for the operation of some electric units.

Fuses, type CH, are installed in A.C. circuits, in permanent-load D.C. circuits, and at places difficult for in-flight access.

Fuses, types HH and TH, are installed in electric actuator supply circuits and are also used for group protection of the electric power distribution system and for the generators protection (See Figs 55 and 56).

Fuses of all the usable types are mounted on the aircraft in various-type boxes. The following ranges of fuses are used on the aircraft: CH-1a, CH-2a, CH-5, CH-10, HH-5, HH-10, HH-15, HH-30, HH-35-2, HH-75, HH-100, HH-150, HH-200, HH-250, TH-600 and TH-900 (the hyphenated figure denotes the nominal voltage the fuse is rated for).

Note: Fuses, type HH, which have polarity marking should be installed in compliance with the polarity identification, i.e. attaching the fuse to the supply busbar with its hook lug which corresponds to the plus sign marked on the fuse cap. This is a must, as the operating characteristic of these fuses depend on the polarity of the current applied to them.

For the arrangement and layout of the protective devices on the panels and boards see Figs 58, 59, 60, 61, 62 and 63. The general layout diagram of the aircraft protective devices is presented in Fig.64.

Wiring

The electric mains of the aircraft consists of wires, marks ETRH and ETRB, coated with coloured insulation, and of aluminum wire, mark ETRBA, with white insulation.

All the wires belonging to the armament system are of red colour, those

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 98 -

of the radio equipment system - of light blue colour, the A.C. mains wires coloured yellow, and all the other wires are of white colour.

To ensure radio interference suppression, part of copper wires used are shielded (wire, mark SHBES). For the same reason, part of copper wires are encased in common anti-interference braidings.

The wires are fitted in the terminal lugs, individual connectors are connections by means of upsetting, while their connection to plug connector terminals, to warning light fittings, miniature relays and other instruments effected by soldering, use being made of HOC-40 or HOC-50 solders and so on. For the types of wire fittings and terminations used on the aircraft see Fig. 65.

The wires of the aircraft electric mains are coded in letters and figures. Each wire should be coded over its entire length every 400 - 500 mm, and a bear at least six code markings every 50 mm by the wire end. Wires, mark are coded only at their ends: three code markings every 50 mm. Apart from that put on the end of each wire prior to its fitting are vinyl pipes carrying wire identification markings.

Wires and vinyl pipes are marked in RH-52 paint with the aid of stamp, the marking procedure being as follows:

1. Prior to marking an electric wire or vinyl pipe, clean the wire or surface from moisture and dust using a clean cloth for this purpose.
2. Stir up the RH-52 paint and pour it on to a felt pad (State Standard TSC 288-53) contained in a metal case.
3. Inspect the stamp and in case it is fouled wash it in rectified oil.
4. Coat the stamp with the paint covering the pad and mark the wire or vinyl pipe.
5. The wire or the vinyl pipe marked, dry it during 20 to 30 minutes at a temperature of 15 to 20°C.

The plotted markings should be well discernible. The marking may be effected with use of special devices or with the aid of an automatic wire marker, if available.

**Note:** It is allowed not to mark the following wires:

- (a) in bonding jumpers;
- (b) in internal wiring jumpers of control boards, boxes, instrument panels and other units if the wire does not run out of its respective unit and if the wire length does not exceed 100 mm;
- (c) all wires whose length does not exceed 200 mm;
- (d) wires connecting electric units to the airframe if it is not possible to trace them over their entire lengths from the unit to the structural member they lead to.

In conditions noted in Points (b) and (c) it will be the vinyl pipes at the end of each wire which are to be marked.

Separate wires of the aircraft electric system are ganged in bunches ("bunched conductors") with the aid of thread bandages. The bunched conductors are marked with numerical or compound numerical and letter markings which are placed on rings fitted around the bunched conductors.

Metal tags are provided at points where the bunched conductors are put out of the electric units and over the entire length of the bunched conductors at points most accessible for inspection. No tags are attached to bunched conductors of smaller-than-10-mm diameter.

Used as connecting links between separate wires and bunched conductors.

- 99 -

cables. The term "cable" is used for a single wire or a group of wires which interconnect any two electric units. Cables have letter and numerical markings; identification letters stand for:

- I - cables of the front pressurized cabin;
- II - cables of the centre plane and the non-pressurized section of the fuselage;
- III - cables of the left outer wing panel;
- IV - cables of the right outer wing panel;
- C - cables of the rear pressurized cabin;
- EM - cables of the left engine;
- ER - cables of the right engine;
- X - cables of the tail unit.

The figure which follows the identifying letter denotes the ordinal number of the cable for the given electric unit of the aircraft.

The above-mentioned cable designations are indicated in all the feeder and schematic wiring diagrams available, but as a matter of fact these designations are present on the aircraft only in case of a single-cable conductor; the conductor tag in this case reads the cable designation. In all other cases, when bunched conductors consist of several cables, the identification tags carry only numerical data to indicate the line number of the given bunched conductor on the aircraft.

#### Laying and Removing the Cables

When laying or removing cables, keep it in mind that the electric system is built up as a single-wire circuit, the airframe being used as the minus wire. The single-wire circuit sets forth the following requirements:

1. The plus wire should be insulated with utmost thoroughness. Any contact of an energized current-carrying element (wire lugs, plug connector terminals and the like) with the airframe results in short-circuiting.
2. The minus wire of the electric equipment should be reliably connected to the airframe. The connection should ensure minimum contact resistance (not in excess of 100 microhms) which is accomplished by cleaning the contact points from dielectric coatings and by secure attachment of the minus wire lug to the airframe.
3. The insulator maximum resistance of the aircraft mains relative to the airframe is the requirement to be fulfilled. For each feeder the insulator resistance of the plus wire (at the relative air humidity of 70%) should not be smaller than:
  - (a) 10 megohms if the feeder supplies up to three consumers;
  - (b) 8 megohms if the feeder supplies more than three consumers;
  - (c) the insulator resistance of the electric power distribution system wires should not be smaller than 1 megohm.

**CAUTION.** NEVER lay or remove wires when the electric system is energized.

Wires with damaged insulation are subject to replacement. To replace a wire:

1. Disconnect the damaged wire from the equipment.
2. Slacken the bunched conductor attachment yokes and loosen all the thread bandages on the section of the wire to be replaced.
3. Withdraw the damaged wire and lay the new one. The gauge, colour and the marking of the newly laid wire should be identical to those of the replaced wire.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

4. Re-bandage the conductor with Mackay threads and fasten up all the slackened yokes of the bunched conductor.

In case of rupture or partial replacement of wires gauging from 0.35 to 6.8 sq.mm it is allowed to joint the wire ends by means of fixed connections shown in Fig.66. It is not recommended to butt-joint wires gauging over 6.8. As an exceptional measure, it is allowed to couple the wires by way of fitting the wire ends in terminal lugs with successive jointing of the lugs with the aid of a bolt and a nut; the jointing over, the connection should be thoroughly insulated with a vinyl pipe and vinyl tape.

In case all the wires of a bunched conductors are damaged, and the damaged portion of a separate wire constitutes not less than 100 mm, the defective bunched conductor should be removed and replaced. The new bunched conductor should be made according to the respective Drawing or to the model of the bunched conductor to be replaced. To make a new bunched conductor:

- (a) prepare and mark the required quantity of wires of corresponding gauge and colour;
- (b) collect together and bind the wires in a bunch according to the model of the damaged bunched conductor;
- (c) put vinyl pipes with respective marking on the wire ends;
- (d) carry out termination of the wire ends.

The wire or the bunched conductor replaced, identify it with the aid of a testing lamp or a voltmeter; then, referring to the feeder diagrams, check the insulation resistance of each feeder comprising the repaired bunched conductor. For examples on circuits for testing separate sections of the electric system see Figs 67 and 68.

**Note:** When checking by the diagram presented in Fig.68 the method of connecting the megohmmeter is the same as when testing with equipment of the circuit presented in Fig.67.

The capacitors the puncture voltage rating of which is smaller than the voltage developed by the megohmmeter should be disconnected and tested separately.

When testing the continuity of the electric circuit of any electric unit, it is necessary to insulate the circuit from all the other electric circuits. Before connecting the minus wires to the airframe, the contact place on the structural member should be thoroughly cleaned from its protective coating; this done, the lugs of the minus wires should be tightly bolted to the airframe and painted red.

Electric Wire Maintenance

After every two or three flights all the electric wires must be inspected and all the faults detected should be corrected.

- 1. Wipe dry the wires covered with oil or hydraulic mixture. Fasten up the loose attachment fittings of shielded bunched conductors to prevent radio interference which is likely to appear due to insufficient tightness of attachment.
- 2. Check plug connectors for secure coupling and lock their union nuts.
- 3. Check the through bolts in power leads, pressurized cabin bottoms and contact blocks for secure fastening.
- 4. Check all the minus wire-to-airframe contact points. If the red locking paint is deteriorated, it is required to tighten up the attachment screws,

to check the contact resistance value which should not exceed 100 microhms, and re-apply red paint to the contact point.

**Note:** When wires gauging 5.15 sq.mm and heavier are attached to the airframe, the wire lug surface contacting the airframe structural member should be coated with a layer of anti-corrosion paste used in aluminum wire fittings; this done, it is necessary to reliably secure the lug, to wipe the place dry all around, to check the contact resistance value and to apply red locking paint.

5. When replacing a separate aircraft unit, make sure that the contact resistance of the newly installed unit does not exceed the value specified in Fig.69.

Maintenance of Junction Boxes and Electric Control Boards

Electric power is distributed within the aircraft electric system through different distribution arrangements (electric control boards, panels and junction boxes) which are provided with various-kind switching, control and protection equipment. The layout of electric control boards and panels, as well as of junction boxes, is presented in Fig.70, (a) and (b).

After a prolonged period of operation or parking of the aircraft it is necessary to check all the junction boxes, as well as electric control boards and fuse panels, the check-out procedure running as follows:

- 1. Check the cover locks for intactness and reliability.
- 2. Check the condition of wires' insulation at points where they are inserted into their boxes and electric control boards; inspect for adequate wire termination.
- 3. Check the contacts for reliable coupling. Use a nut wrench to tighten up the nuts on contact bolts of plus and minus connections.
- 4. Check and, if such a necessity arises, tighten up the contact connections on the on-off and change-over switches, circuit breakers, etc.
- 5. Check the switching arrangements (on-off switches, change-over switches, starters, relays, buttons, contactors and the like) for secure attachment and sound operation.
- 6. Remove dust, dirt or moisture from the junction box or the electric control board and wipe it with a dry cloth.
- 7. Use a dry cloth to clean those portions of the supply busbars which bear traces of oxidation or dust.
- 8. Check all the fuses indicated in the attached diagram for availability, their integrity and for meeting the current intensity rating requirements, as well as for secure fitting of the CU-type fuses in their holders. If it is revealed that some fuses are missing or faulty, mount or replace the fuses.
- 9. Inspection over, close the cover of the box, panel or electric control board and lock the cover, if it was not locked before the inspection.

**CAUTION:** Never repair or check units mounted in junction boxes, electric control boards and panels when the aircraft electric system is energized.

Specific Features of Aluminum Wire Maintenance

With the view to lightening up the aircraft weight, the electric power distribution system is wired principally with aluminum wire, mark HUBNA, gauging from 35.0 to 95.0 sq.mm. The current-carrying core of these wires is

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 102 -

- 103 -

made of the material, grade AT, and consists of separate (twisted together) wires the gauge of which (1.08 to 1.4 sq.mm) is much heavier than that of copper wires.

In clean and dry air it is characteristic of aluminum wires to get coated with a thin non-conductive oxide film which prevents the metal from further oxidation. However, moisture and gas contaminated air may become a favourable medium for intensive electro-chemical corrosion of aluminum. Apart from this, when in contact with some metals or alloys (copper, for example), aluminum makes up a couple prone to intensive corrosion.

Oxide film on the aluminum surface adversely affects the contact between the wire conductors and between the wire and the lug which may result in voltage drop and excessive overheating at the wire termination point.

In order to preclude the probability of oxide film formation and corrosion the ends of aluminum wires are sealed by upsetting wire ends in special copper lugs which are hot-soldered (to obtain a heavier coating) and are filled with special anti-corrosion paste (a mixture of petrolatum with zinc powder).

**CAUTION:** NEVER use electrolytically treated copper lugs with holes for aluminum wire termination.

Upon upsetting the terminal lug and checking the contact resistance, the bare portion of the wire is to be wrapped with sealing tape, mark Y20A.

Next to their terminal lugs the aluminum wires are provided with identification markings: a red ring on a vinyl pipe or a red vinyl pipe fitted on the wire.

If it occurs that in the course of operation the terminal lug of an aluminum wire breaks or the lug gets out of contact with the wire, the repeated wire should be carried out as follows:

1. Remove the wire from the aircraft.

**Notes:** It is allowed to terminate (fit) aluminum wires directly on the aircraft only in top urgency cases, for example, when removal of the wire from the aircraft calls for large-scale deaunting operations on other equipment.

2. Cut off the broken conductors of the wire or the defective lug, and remove the insulation from the wire end, having previously shifted the vinyl pipe with the label along the wire. The insulation should be removed from the wire only with the aid of an electrothermal tool since no cuts and other mechanical damage are tolerated on the wire conductors.

3. Having stripped the wire end, coat it from outside with a thin layer of anti-corrosion paste and then clean it with a special metal brush to remove oxide film from the wire conductors.

4. Self-fill the lug sleeve with anti-corrosion paste (to expell air from it) and fit the lug onto the wire.

5. Using a special device for fitting aluminum wires of the given gauge upset the lug on the wire.

6. Check the degree of lug upsetting; the dimensions of the pressed lug (Fig.71) should be within the limits specified in Table 19 below.

Table 19

Key to Values Indicated in Fig.71

Wire gauge, sq. mm	Dimension, mm		
	A	B	C
35	12	5.2 - 5.6	13 - 15
50	12	6.8 - 7.2	15 - 17
70	16	7.2 - 7.6	16 - 18
95	16	8.2 - 8.6	17 - 20

7. Measure the contact resistance between the upset lug and the wire using an ammeter and millivoltmeter according to the circuit diagram presented in Fig.71. To measure:

(a) connect the wire under check to a D.C. power supply source with rated voltage of 28 to 28.5 V and power not exceeding 7.5 W;

(b) using an excitation rheostat, determine the intensity of current through reference to the ammeter) flowing in the wire. The intensity should not exceed 140, 180, 200 and 225 A for wires gauging 35, 50, 70 and 95 sq. mm, respectively;

(c) place one of the probes of the millivoltmeter in the middle of the upset portion of the lug and connect the other probe to the yoke fitted around the bare section of the wire;

(d) calculate the contact resistance according to the formula:  $R = V/I$ , where I is the current passing in the wire at the moment the measurement is being taken (as read by the ammeter), and V is the voltage drop in the wire termination point (as indicated by the millivoltmeter). The contact resistance shall not exceed the limits specified in Table 20. If the contact resistance will surpasses the indicated limits, the lug should be cut off, the wire should be terminated anew, and contact resistance should be checked once more.

Table 20

Tolerated Contact Resistance Values for Aluminum Wire Lug Terminations and Tolerated Bend Radii of These Wires

Wire gauge, sq. mm	Contact resistance (in microhms) at temperature of 20 to 22°C	Tolerated bend radius of wire, mm	
		1	2
35	up to 20	50	30
50	up to 15	60	40
70	up to 12	100	60
95	up to 10	150	100

8. Use a clean piece of cloth or gauze to remove superfluous anti-corrosion paste from the portion to be taped. Tightly wrap tape, mark 20 A, around the bare portion of the wire until completely covered, and then use a 10-mm wide tape to wrap around the lug and the insulation so that the tape would wrap them 2 to 3 mm. Cover to tape surface with talc and fit the vinyl pipe with the tag over the lug.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

**Note:** Due to the fact that aluminum is an easily corroded material, all the operations covering the lug-to-wire fitting and sealing of the termination should be completed during not longer than one hour.

9. Record the work done in the aircraft Service Log, with indication of contact resistance of the fitted lug.

10. Mount the wire on the aircraft. In view of the fact that aluminum wire is much less flexible than copper wires, no sharp bends should be involved in their mounting.

Small-radius bends of aluminum wires result in displacement of conduction of the wire at the fitting point and in increased contact resistance at the fitting point. Therefore the bend radii of aluminum wires should be not smaller than those specified in column 1 of Table 20.

If it proves impossible to maintain the specified radii during mounting operations (at the inlets into boxes, control panels and the like), resort may be made to the radius values specified in column 2 of Table 20. In the latter case the lug should be put onto the wire bent to the radius indicated in Table 20, and the wire should not be bent after the fitting operation.

**Regulation and Check-Out of Bonding Arrangements**

Due to the fact that the airframes is used in the function of the minus wire all the units and items of aircraft equipment are reliably bonded to ensure normal operation of electric power consumers, to reduce to the minimum radio interference, as well as to eliminate the probability of local overheating and electric corrosion of separate units and joints.

The following bonding methods are used:

1. Connection of all the aircraft structural members and equipment into an integral system by means of rivets and bolts.

2. Provision of special bonding jumpers which interconnect separate structural members of the airframe and connect the aircraft equipment to separate aircraft structural members.

The maximum allowable values of contact resistance between separate aircraft structural members are indicated in Fig. 59. The maximum allowable contact resistance for all the other structural members and equipment units of the aircraft is divided into the following major groups:

- (a) 50 microohms - at installation points of ballast resistors, type EM-1
- (b) 100 microohms - for points of direct coupling of all the ignition systems and for points at which the manifold pipes are connected to the engine body;
- (c) 200 microohms - at installation points of decoupling capacitors and filters;
- (d) 600 microohms - at points of direct coupling of parts and units;

**Note:** Tolerated in some cases for directly coupling parts is contact resistance as high as 2000 microohms (for covers, access panels, doors, etc.).

(e) 2000 microohms - for bonding jumper connections of parts and units.

However, in some cases it proves possible to obtain smaller contact resistance values which considerably improves the aircraft bonding characteristics. Contact resistance is checked with the aid of low-resistance meters, type RMC-3, or with special microhmeters of high accuracy class, with division value not more than 100 microohms.

It should be always remembered that poor bonding in any aircraft system creates even heavier radio interference (due to appearance of additional variable contacts) than a completely unbonded system. Therefore, unlike other types of aircraft mountings, the bonding system requires constant care. This especially refers to the engine bonding systems which should be paid the greatest attention since the engines carry large masses of metal and mount a great number of units which are sources of radio interference.

In the course of operation some bonding jumpers may get broken, or the bonding jumper-to-airframe contact may become loose. The other problem is absented neglect of providing bonding arrangements for all the newly installed off-board items. There are other problems, too.

In view of all this, the aircraft bonding system should be systematically and thoroughly checked and maintained throughout the entire service life of the aircraft. The maintenance procedure consists in the following:

- 1. Checking all the electric cables of the engine group for secure attachment and reliable contact with the engine body.
- 2. Checking the integrity of all the bonding jumpers installed on the aircraft; special attention should be paid to the bonding jumpers installed on the aircraft engines.
- 3. Tightening up loose jumpers and check-out of static dischargers for cleanliness.
- 4. Replacement of all unusable or broken bonding jumpers with due anti-corrosion provisions.

When installing a bonding jumper:

- (a) use an end cutter or emery paper No.00 to clean bright the contact surfaces of the bonding jumper lugs and of the bodies to be bonded;
- (b) mount the bonding jumper seeing to it that its resistance value and length are same as those of the replaced bonding jumper; make sure that the bolts attaching the bonding jumper to the airframe element are tight;
- (c) measure the contact resistance;
- (d) apply red paint, mark A-67, to the cleaned portion of the structural member, to the jumper lug and the bolt head in the same manner as it was done with the replaced bonding jumper.

5. For effective inspection, it is necessary to take regular selective measurements of contact resistance with the aid of low-resistance meters, type RMC-3. If it is revealed in the course of inspection that the actual contact resistance values considerably differ from the rated ones, actions should be taken to normalize the bonding system.

**OPERATION PECULIARITIES OF D.C. POWER SUPPLY SOURCES**

**Generator Maintenance**

Aircraft generators, type TGP-18000, operate in heavy vibration conditions and therefore need systematic and thorough care and inspection.

The generator maintenance procedure consists in the following:

- 1. Checking the bolts of the generator lead-out wires and all the threaded connections for tight fastening.
- 2. Checking the pipeline for secure attachment to the generator air delivery branch pipe.
- 3. Checking the cap for proper attachment to the commutator and shield of the generator; tightening up the nut attaching the cap with the branch pipe to the commutator end shield in case of necessity.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM

4. Checking the commutator end shield for play-free attachment. The shield is likely to play in case of loose attachment of the air pipe to the generator air delivery branch pipe or due to excessive length of the free portion of lead-out wires.

5. Checking the commutator and brushes for condition. To inspect the commutator and those brushes which are accessible, it is necessary to remove the cover band. When re-mounting the cover band, see that the body-mounted pin by all means coincides with the reference hole in the band.

If it has been revealed in the course of inspection that the commutator is severely burned and the brushes have been worn out down to a length of 1/8 inch, the generator should be removed from the aircraft and thoroughly inspected. The commutator should be cleaned with sandpaper, the faulty brushes should be replaced, and the generator - tested on a laboratory stand.

Note: The length of brushes should be measured from the side of the commutator surface of the brush.

Maintenance of Voltage Regulator and of Equipment Operating in Set with Voltage Generator

In the course of operation of voltage regulators, type PVT-82, the level adjustment and distribution of loads among the regulators operating in parallel are effected by means of external resistors, type BC-20. It is forbidden to employ any other method for adjusting the regulator.

Due to wear of the carbon pile and possible sagging of the springs the pressure applied to the regulator carbon pile is likely to become weakened in incorrect operating conditions the wear of the carbon pile of the PVT-82 voltage regulator may be so severe that the regulator will be maladjusted to the point when the regulator begins to pop. It is forbidden to operate the regulator in popping conditions since this leads to burning out and disintegration of the carbon pile.

To prevent popping operating conditions of the voltage regulator, the regulator should be subjected to regular inspection (approximately after every 50 hours of operation) on board the aircraft. The regulator adjustment and inspection should be carried out at high generator speed, and therefore it is advisable to carry out generator check with the engine maximum r.p.m. testing.

When the generator is operated with the storage battery disconnected, the out-in and out-out taps place, the load variation being not less than 50% of the nominal generator rating. If the regulator, due to maladjustment, opens in popping conditions, this operational instability will be detected by oscillations of the voltmeter needle.

The voltmeter check of the regulator allows to determine popping operating conditions of the regulator. However, checking by this method fails to reveal popping conditions since in this case popping is present only under transient operating conditions and disappears quite rapidly. Therefore, conditions allowing, it is best advisable to carry out the check by listening to the arcing of the carbon pile through high-resistance earpieces. For operation the earpieces should be connected to the wires running from the first and second pins of the PVT-82 regulator plug connector (in a place easiest for access to effect several load on-off cycles. If the regulator functions normally, the load out-out is accompanied by a single click and changed tone in the earpiece. If the regulator load out-out is characterized by wheeze, this testifies to

maladjusted regulator. The faulty voltage regulator should be removed from the aircraft and sent over for adjustment to the repair workshop.

CAUTION: NEVER try to adjust the PVT-82 voltage regulator on board the aircraft by changing the air gap of the electromagnet or by varying the carbon pile pressure.

Apart from voltage regulator adjustment checks, attention should be paid to the course of the aircraft service life to the integrity (condition) of the wires running from the second socket of the regulator plug connector to the external resistor, type BC-20, and from the resistor to terminal X of the stability transformer, type SO-8; terminal III of the stability transformer should be checked for proper grounding. Any breakage in the above-mentioned circuit results in a sharp generator voltage increase, in disturbances in the parallel operating system, and in burn-out of the generator field winding. Stable operation of the voltage regulator is ensured by the stability transformer, type SO-8.

CAUTION: It is forbidden to operate the voltage regulator, type PVT-82, without the stability transformer, type SO-8.

The differential undercurrent relay, type AMP-600, the stability transformer, type SO-8, the external resistor, type BC-20, and the capacitor, type KSM-51, do not require special maintenance. In operation, they will be checked only for contact tightness of their connected wires and for secure attachment.

CAUTION: NEVER clean the contacts of the AMP-600 relay or adjust the relay in operating conditions.

Storage Battery Maintenance

When installing the capacity-charged storage battery on the aircraft, it is necessary to inspect it for condition of the sealing compound, terminals, group and plugs. There should be no cracks in the sealing compound and group bars. Terminal bolts should have intact thread, and the output busbar lugs as well as the surfaces of the terminals contacting the busbars should be cleaned from oxides.

External inspection over, the plugs (free from fouling) are screwed into the battery, and the functioning of the valves is checked. Never install plugs which do not open when the battery returns to the normal operating position after being tilted through 180 and 190°.

Battery Discharge Level Test

The level to which the storage battery has been discharged can be roughly estimated by the voltage produced by the battery under load or by the density of the electrolyte, the second method being the most correct one.

The battery voltage is measured with the battery connecting (generators and power consumers OFF) one of the aircraft power consumers rated for a current close to 22 A. The electrolyte density is gauged with a densimeter.

For the battery voltage and electrolyte density as functions of the battery discharge level see Table 21 below.

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

50X1-HUM

- 108 -

Table 21

Battery Voltage and Electrolyte Density as Functions of Battery Discharge Level

Battery discharge level relative to nominal capacity	Battery voltage (in volts) at 20 A load	Electrolyte density in cells, reduced to 25°C	Note
Charged battery	25 to 24	1.260 ± 0.005	Battery ensures 6 engine startings
Battery discharged by 25%	25 to 24	1.200 - 1.210	Battery ensures 3 to 4 engine startings
Battery discharged by 50%	24 to 23	1.170 - 1.160	Battery may fail to start engine
Battery discharged by 75%	23 to 22	1.120 - 1.110	Engine starting failure to be expected
Battery fully discharged	22 to 21	1.080 - 1.010	No engine starting

After each flight it is necessary to check the battery discharge level. If the battery has been discharged completely or partially (by over 25%), it is necessary to send it for charging to the charging station no longer than an eight-hour period. After each flying day (night) it is necessary to check the battery discharge level by the electrolyte density. All the charging cycles of the number of engine startings effected by the battery should be recorded in a Service Log of the storage battery.

Inoperative storage batteries should be additionally charged with a current of 3.5 A at least once in a month.

Once in every three months all the storage batteries (both operating and inoperative batteries) should be subjected to a procedure charge-discharge cycle as a measure against sulphating. The results of the operation should be entered in the Service Log of the storage battery.

In the course of operation it is necessary to regularly check the level of density of the electrolyte and add distilled water to the cells. It is forbidden to add electrolyte or acid in the cells unless it is known for sure that the level decrease is due to electrolyte spilling. In the latter case it is necessary to add battery sulphuric acid solution of the same density as the density of the electrolyte contained in the cells.

Never expose storage batteries to direct sun rays or place them one onto another.

If cracks are detected in the sealing compound, eliminate them by the soldering method. Hot-treat the sealing compound only with the battery discharged and plugs removed, making use of a soldering torch, hydrogen flame or other means.

**Storing the Battery**

Storage batteries which are in active service and which have been in operation for not longer than half the guaranteed service life period, as well as storage batteries which have passed the manufacturer's electrical tests (marked with a red strip on the group bar) should be stored with electrolyte in the charged state.

- 109 -

**CAUTION: IT IS ABSOLUTELY FORBIDDEN TO STORE ELECTROLYTE-FREE 12-CAM-55 STORAGE BATTERIES WHICH HAVE BEEN IN OPERATION OR HAVE PASSED ELECTRICAL TESTS.**

Storage batteries should be placed for storage as follows:  
 1. Charge the storage battery to capacity.  
 2. Check and carry out necessary operations to obtain the normal density level of electrolyte.

3. Install the vent plugs in all the battery cells and wipe the battery surfaces with rags soaked in a solution of soda or ammonia hydroxide.

4. Wash the battery surface with water and wipe the whole battery dry with clean rags.

5. Clean the clamps and intercell connections of the battery and coat them with a thin layer of petrolatum or grease. This done, the battery may be considered ready for storage.

6. Every month it is necessary to give the battery an additional charge with a current of 3.5 A till there are indications that the battery is charged to capacity. At least once in every three months the battery should be subjected to a procedure operating cycle.

Prior to beginning the operation of a storage battery just removed from storage, it is necessary to give it an additional charge with a current of 3.5 A to obtain constant electrolyte density and voltage.

The storage battery can be stored with electrolyte charged for not longer than six months.

When there is no possibility of storing the battery with charged electrolyte, the storage batteries, type 12-CAM-55, which have been in operation for some time and are not intended to be used during long period of time may be stored discharged, without electrolyte. Before the storage battery is placed for storage, it is subjected to one procedure operating cycle, and then it is discharged with a current of 11 A till the voltage in one of the battery cells drops to 1.7 V.

The discharged batteries are turned with their plug holes down and are left in this position during three hours. For complete removal of electrolyte from the battery it is necessary to slightly tilt the battery and give it light shake-ups. It is forbidden to wash the battery out with water before placing it for storage.

Batteries are placed for long-time storage with their blank plugs tightly inserted in and with their surfaces thoroughly wiped dry with clean rags. To prevent bulging of the sealing compound during its storage, the cells should be dried with blank plugs at a temperature of 30 to 45°C inside the battery, for which purpose the battery should be either placed in the corresponding ambient temperature conditions, or warmed up with hot water from the outside.

**CAUTION:** One-time used storage batteries, type 12-CAM-55, can be stored without electrolyte for not longer than three months.

**Main Storage Battery Troubles**

All the troubles which are probable to develop in the storage battery can be divided into three categories:

1. Troubles of electrochemical character which can be eliminated by electrochemical methods (by using specially selected charging-discharging conditions).

2. Mechanical troubles which can be eliminated on the spot, by available means.

3. Troubles related to defective plates and group bars; these faults are corrected in special workshops.

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 110 -

Troubles in the storage battery can be detected either by external inspection or by pertinent measurements during electrochemical tests.

Detected by visual (external) inspection are: cracks in the vessels and bars, leakage of electrolyte, cracks or softened spots in the sealing compound, fouling of the external surfaces, breakage of the output pins and intercell connections, poor contact between the output pins and intercell connections, a seal of the covers, as well as breakage or fouling of the plugs. The majority of these troubles is eliminated right in the using unit.

The troubles mentioned under Items 1 and 3 above can be detected by the battery voltage and voltages of separate cells in the course of the charge-discharge cycle, by the density and temperature of electrolyte and by gas evolve during the charging half-cycles. These troubles can be eliminated only at special repair workshops or at a charging station.

Following should be the characteristics of a sound battery by the end of its charging:

- (1) voltage at each cell - 2.45 to 2.6 V (when alive);
- (2) specific weight of electrolyte -  $1.260 \pm 0.005$ ;
- (3) electrolyte temperature - not over  $45^{\circ}\text{C}$ ;
- (4) almost simultaneous "boiling" and gas formation in all battery cells;
- (5) neutral-colour, transparent electrolyte, free from any sediment.

When test-discharged, a sound storage battery should manifest a capacity which is not smaller than 75% of normal capacity.

#### Particularities of Storage Battery Operation in Subzero Temperature

In those cases when the storage half-battery cells are left in their containers with the aircraft parked at temperatures down to minus  $40^{\circ}\text{C}$ , prior to flight it is necessary to engage the electrical heater system of the containers.

The electrical heater system of the containers can be energized only from a ground supply source (See the diagram in Fig.54) which is connected to the ground supply plug connector of the aircraft.

When already in flight, i.e. when the storage battery is connected for buffer operation with the RP-18000 generators, there is no need in electric heating of the containers even when the ambient air temperature is below zero and down to minus  $60^{\circ}\text{C}$ . This is explained by the fact that while in flight the temperature of the electrolyte in the storage battery cells remains above zero due to operation of the storage battery. The effect of the ambient air temperature is considerably reduced due to the use of heat-insulator which lines the interior of each container.

To engage the container heater system, proceed as follows:

1. Connect a D.C. ground power supply source to the aircraft mains.
2. Slightly close the covers of both storage battery containers.
3. Turn on the heater switch located above the left storage battery container.

The heater system is disconnected automatically by means of thermal switches type 777b, which are connected to the minus circuit of the heaters of each container. The switches operate as soon as the temperature at the surface of the heating plates reaches  $80 \pm 10^{\circ}\text{C}$ .

#### Connecting D.C. Ground Supply Source

To energize the aircraft electric mains at parking and for engine start

- 111 -

purpose, the aircraft is equipped with a ground supply plug connector the plug of which is secured in the nosewheel leg well, port side, at frame No.15.

The plug and the mating detachable receptacle of the ground supply plug connector have three pins and three sockets. Two thicker pins are power pins, and they are longer than the third (thinner) pin which is used as a guide element. Such a construction ensures that the power contacts are energized only after the full contact is obtained, which precludes burning of the power contacts when connecting the receptacle.

To connect the ground supply source to the aircraft electric mains, act as follows:

1. Couple the ground supply receptacle (with the ground supply source connected to it) with the ground supply plug.
2. Place the voltmeter change-over switch on the generator control panel at the radar operator's station to GROUND SUPPLY RECEPTACLE (PAI).
3. When sure (through reference to the voltmeter) that the voltage across the terminals of the ground supply plug connector is normal, select the NORMAL SWITCH CIRCUIT (НОРМАЛЬНАЯ ЦЕПЬ) position of the voltmeter change-over switch.
4. Turn on the ground supply switch.
5. As soon as the voltmeter begins to indicate that the aircraft mains is energized, it is allowed to begin connecting power consumers, checking their operation by the ammeter and voltmeter.

Ground supply sources are connected to the aircraft electric mains through a connector, type E-400J (See Ref.No.32 in the diagram of Fig.54) which operates only with the ground supply switch cut in (See Ref.No.31 in the same figure).

To disconnect the ground supply source:

1. De-energise all the power consumers.
2. Turn off the ground supply switch on the generator control panel at the radar operator's station.
3. Disconnect the ground supply receptacle.

**CAUTION.** When the aircraft mains is energized from a ground supply source, it is not advisable to impose a simultaneous load which would exceed 500 A.

In case the aircraft mains requires a current larger than 500 A, it is necessary to withdraw the fuses from the storage battery ammeter and ground supply circuits which are installed in the storage battery junction box. In overload conditions use should be made of a special ground ammeter with a scale range exceeding 500 A.

#### Control over D.C. Power Supply Sources and Electric Mains


Control over the operation of the power supply sources and over the continuity of the electric circuits is effected by means of five ammeters. Four ammeters, type A-3, with scales reading to 100 - 0 - 1000 A are installed in the generator circuits, while the fifth ammeter, type A-2, with its scale reading to 50 - 0 - 500 A is provided in the aircraft storage battery and ground supply circuit.

The ammeters are provided with extension shunts which are located on the distribution panels of the engine compartments and in the storage battery junction box (Fig.72).

The operation of the power supply sources and functioning of the electric

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

circuit are checked by a voltmeter, type B-1, rated for 30 V. By means of a selector switch, type H-46, the voltmeter can be connected to each of the generators to the normal supply circuit, to the emergency supply circuit, to ground supply plug connector and to the storage battery.

In flight, under normal electric power supply conditions the voltmeter should be connected to the normal supply circuit, and in emergency power supply conditions it should be connected to the emergency supply circuit; in de-energized mains conditions the voltmeter should be connected directly to the storage battery.

All the above mentioned instruments, as well as the selector switch, type H-46, of the voltmeter are mounted on the generator control panel installed at the radar operator's station (See Fig. 55). In addition, the radio operator instrument panel mounts a voltmeter, type B-1, which measures the normal supply circuit voltage in the rear pressurized cabin.

Basic Technical Characteristics of Ammeters, Types A-1, A-2, A-3 and of Voltmeter, Type B-1

Description	Type of Instrument	Measuring range	Graduation value	Scale graduation marking
Ammeter	A-1	40 - 0 - 400 A, with shunt rated for 300 V	20 A	0, 1, 2, 3 and 4
Ammeter	A-2	50 - 0 - 500 A, with H-2 shunt rated for 500 A	25 A	0, 1, 2, 4 and 5
Ammeter	A-3	100 - 0 - 1000 A, with H-3 shunt rated for 1000 A	50 A	0, 2, 4, 8 and 10
Voltmeter	B-1	0 - 30 V	1 V	0, 1, 2 m

1. The main error of the ammeter without shunt under normal conditions at nominal resistance of the connecting wires does not exceed  $\pm 2\%$  of the sum total of the nominal scale values.

2. The shunt is accurate within  $\pm 0.5\%$  of the shunt nominal current ratio.

3. The main error of the B-1 voltmeter under normal operating conditions should not exceed  $\pm 2\%$  of the nominal scale value.

4. The additional error for every  $10^\circ\text{C}$  ambient air temperature variation within plus 50 to minus  $60^\circ\text{C}$  should not exceed  $\pm 0.5\%$  of the sum total of the nominal scale values for the ammeter, and of the nominal scale value for the voltmeter.

Maintenance of Ammeters and Voltmeters

When the power supply sources are disconnected, the needles of the instruments should indicate zero.

If the instrument needle does not respond to the connection of a power supply source, it is necessary to check the wires for condition and to check whether the contacts at the wire-to-instrument (or to shunts in case of ammeter) connections are reliable.

In short-circuit conditions the ammeter needles swing to the extreme right position (beyond the scale range) and the voltmeter needle indicates reduced voltage. If, at the moment of connecting a power supply source, the instrument

needle moves in the reverse direction, it is necessary to change the places of the wire ends leading to the indicating instrument.

In case troubles develop inside the indicating instrument, it should be replaced. There is no need in removing the ammeter shunt (if it is intact) since all the ammeter shunts are interchangeable.

If in the course of operation there appears a necessity to replace the connecting wires in a certain section between the indicator and the ammeter shunt, the length and the gauge of the newly selected wires should be identical to those of the replaced wires. Changes in the length and gauge of the wires result in changed resistance of the connecting wires, and other-than-nominal resistance leads to additional instrument errors.

Adjustment of D.C. Power Supply Sources

The generator system adjusting procedure should be started from individual voltage adjustments on each generator with the view to obtaining a voltage of 28.5 V with the aid of the external resistors, type EC-20, and the B-1 voltmeter mounted on the generator control panel at the radar operator's station (See Fig. 55).

**CAUTION.** It is allowed to connect the generator to the aircraft mains only after it has been adjusted for the voltage of 28.5 V.

Generator Voltage Adjustment in Ground Conditions

In ground conditions the generator voltage will be adjusted with the engines running; in the course of the adjusting procedure, the power consumers of the engine accessories group should be energized from a ground power supply source.

To adjust the generator voltage:

1. Place the voltmeter change-over switch to the position corresponding to the generator subject to adjustments.
2. Obtain the engine speed of 3750 r.p.m.
3. Obtain the voltage of 28.5 V by rotating the knob of the EC-20 external resistor of the generator to be adjusted.
4. For a short period of time advance the engine speed to 4100 r.p.m. As a result, the generator voltage should not vary by more than 0.5 V.

The voltage adjusting procedure for all the other generators is absolutely identical to that described above.

Connecting Generators to Aircraft Mains

To connect the generators to the aircraft mains act as follows:

1. Disconnect the power consumers leaving the minimum number of connected consumers which ensure normal operation of the engines.
2. Disconnect the ground supply source and quickly connect all the four generators, one after another.
3. Cut in all necessary power consumers.

**CAUTION.** Before connecting the generators, see to it that the 12-CAM-55 storage battery is installed in its container.

Adjusting Parallel Operation of Generators

The parallel operation of the generators will be adjusted in flight, in 30 to 40 minutes after the take-off, i.e. as soon as the voltage regulators and the generators are warmed up sufficiently.

The adjusting procedure runs as follows:

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 114 -

1. Connect all the de-icer and heater devices. The current load in this case will total:

permanently connected consumers .....	430 A (approx.)
electric heaters of cabins .....	340 A
glass panel heaters .....	190 A
tail unit de-icers .....	470 A (approx.)
amplifiers and dynamotor of cannon aiming system .....	250 A (approx.)
Total .....	1680 A (approx.)

Hence, the average load per one generator amounts to approximately 420 A. To avoid dangerous overloading of any one generator, all the large loads (de-icers and heaters) should be applied in turn.

Upon connection of a power consumer it is necessary to check, through reference to the generator ammeters, whether the current is equally distributed among all the generators. In case the generator current is unbalanced by more than 120 A, it is necessary to level off the generator loading with the aid of the RP-20 external resistors; the voltage of the generators bearing the smaller load should be increased, and the voltage of the heavier-loaded generators should be reduced.

2. Place the B-46 selector switch of the voltmeter to the NORMAL SUPPLY CIRCUIT (НОРМАЛЬНАЯ ЦЕПЬ) position and check the aircraft mains voltage; the voltmeter should read within 28 to 29.5 V. In case of other readings, the voltage level of all the generators should be either raised or lowered by the required magnitude. This is effected by rotating the RP-20 resistor control knobs through one and the same angle.

3. Disconnect the power consumers which are not required for normal flight procedure and check the generator loading by the ammeters. Unbalanced loadings of the generators in small-load conditions is no problem to bother about; however, all the generators should supply current to the aircraft mains. In conditions of very small loading some generators can be disconnected by their respective relay type RP-600. This presents no trouble, since, as the load increases, the RP-600 relay will reconnect the generator to the mains.

**Note:** It is necessary to adjust the parallel operation of the generators in each flight. The adjustment should be repeated only if the generator current is unbalanced by more than 150 A at a load amounting to 25 - 50% of the nominal loading, and 120 A at loads exceeding half the nominal rating of each separate generator.

In flight, all the generators should be connected. A generator may be disconnected in flight only in case a trouble has developed in it. In this case the radar operator should report his actions to the aircraft commander.

If fire breaks out on the engine or in the engine nacelle, the fire-fighting system of the aircraft is engaged into operation automatically. In synchronism with the fire-fighting system actuation the engine cowl vent pipe is automatically shut off which stops the generator blowing. Therefore all the generators installed on the engine located in the fire area should be quickly disconnected from the aircraft electric mains. Having disconnected two of the generators, make sure that the total load applied to the operating generators is not in excess of their performance. In case of excessive loading, part of the power consumers should be disconnected.

- 115 -

**CAUTION:** In conditions when two generators are disconnected from the aircraft mains, it is forbidden to effect simultaneous connection of the cannon system and the tail unit de-icer system.

#### Disconnecting Generators from Aircraft Mains

To disconnect the generators from the aircraft mains prior to stopping the engines, act as follows:

1. Disconnect three generators from the aircraft mains.
2. Disconnect all the power consumers from the aircraft electric mains but the channel No.1 of the intercom set, the stand-by pumps and the engine control instruments.
3. Disconnect the storage battery from the aircraft mains.
4. Stop the engines.
5. Disconnect all the consumers which were left connected.
6. Disconnect the fourth generator from the electric mains.

#### OPERATION REGULARITIES OF A.C. POWER SUPPLY SOURCES Connection of NO-4500 Inverters and of Ground A.C. Power Supply Source

Connection of NO-4500 Inverters is effected from the generator control panel at the radar operator's station (See Fig.55) by means of a change-over switch, type 3MHH-45, which precludes simultaneous connection of both inverters.

The operating inverter is supplied with direct current through the storage battery junction box from the normal supply busbar, and the stand-by inverter is energized through the dual supply circuit junction box (mounted at frame No.17) from the dual supply busbar.

For the key circuit diagrams of A.C. power supply sources refer to Fig.75. When connecting the inverter for operation from a ground D.C. power supply source, see to it that at the inverter starting moment the voltage across its terminals is not lower than 20 volts.

**CAUTION:** NEVER start the NO-4500 inverter for operation from a ground D.C. power supply source which reduces the voltage across the inverter terminals to below 20 V at the inverter starting moment.

The inverter connecting circuit (See Fig.75) makes it impossible for the inverter to be engaged with its voltage regulator, type P-25B, disconnected. If (in ground operating conditions) the inverter fails to get disconnected when the 3MHH-45 change-over switch is turned off and the respective ASC-2 circuit breaker is opened, and goes on operating, it is required to de-energize the D.C. circuit, i.e. to disconnect the ground supply source.

**CAUTION:** It is FORBIDDEN to uncouple the plug connectors until the NO-4500 inverter is de-energized.

With the inverter disengaged, it is necessary to check the external supply circuits; if they are faulty, remove the inverter from the aircraft and send it over to the repair workshop.

For A.C. supply of the aircraft electric mains on the airfield, provided in the nosewheel well, starboard, at frame No.16, is a ground A.C. supply circuit junction box with a two-pin plug connector of WP2822H7 type. The ground supply source is connected by means of a switch, type B-45, located on the

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



- 116 -

generator control panel at the radar operator's station. The design of the ground supply circuit (See Fig. 73) makes it impossible to connect the ground supply after one of the aircraft inverters, type HO-4500, has been engaged.

Inverter Maintenance

To ensure reliable operation of the inverter, type HO-4500, it is required to carry out its inspections after every 100 operating hours; the inspection procedure will include condition checks of the commutator, slip rings, brushes, brush holders and scavenging with compressed air to remove dust from the brushes.

In case traces of burning are detected on the slip rings or commutator, the elements should be cleaned with sandpaper No. 00. During this step of the maintenance operations it is necessary to differentiate uniform dark-colour deposit from real burning; the deposit in question has no adverse effect on the inverter operation and therefore it is not subject to removal.

Should the length of the commutator brushes be worn out down to 16 mm, and the slip ring brushes - down to 14 mm, the brushes are to be replaced. The new brushes should be lapped to the commutator and slip rings with the aid of sandpaper No. 00 or ground in at idle running of the inverter during 5 to 6 hours.

The inspection of the inverter over, it is necessary to push the centrifugal switch return button as far as it will go, and to make sure that the inverter is ready for starting.

In case of failure of the voltage stabilizer (which is indicated by higher-than-nominal output voltage and absence of glow in the voltage stabilizer) the faulty stabilizer should be replaced.

The voltage stabilizer replacement procedure is as follows:

1. Open the access hole in the top part of the box having previously unsealed the access panel fastening screw and turned it by 90°.
2. Carefully lift the voltage stabilizer. To replace the voltage stabilizer with your left hand pull back the cap which holds down the voltage stabilizer. Starting pressure with the index finger of the right hand, move the voltage stabilizer aside, holding it up while doing this. Then, operating with the left hand, install the new stabilizer and fit the cap on.

When replacing the voltage stabilizer, see to it that the coil springs which secure the voltage stabilizer are not expanded excessively and that they are positioned correctly. The axis of the springs should run normal to the horizontal plane; the position of the springs is adjusted by turning the cap on the voltage stabilizer to one or another direction.

3. Close the access hole panel of the box and seal.
4. Enter the reason for the replacement and the number of pre-installation operating hours of the new inverter in the Service Log of the inverter.

If after the replacement it proves impossible to obtain the nominal output voltage value (115 V) with the aid of the voltage level adjusting rheostat, the inverter should be replaced and subjected to thorough inspection at the repair workshop.

**CAUTION.** NEVER adjust HO-4500 inverters on the aircraft.

50X1-HUM

- 117 -

Inverter Probable Troubles Constituting Reason for Its Replacement

Trouble	Indication
<u>In frequency control circuit</u>	
Electric connection of magnetization winding of HO-25-170 choke with neutralizing winding	Sudden r.p.m. drop. Somewhat reduced voltage
Breakage of one A.C. winding of choke	Somewhat increased frequency at idle running (approximately 435 c.p.s.) Frequency increases to 500 c.p.s.
Breakage of magnetization winding of HO-26-170 choke	Frequency drops to 300 c.p.s.
Breakage of neutralizing winding of HO-26-170 choke	Increased frequency
Shorted turns of HO-11 mesh choke	High frequency, large current of electric motor, heavy starting
Confused ends of control winding	High frequency, large current intensity of electric motor
No A.C. voltage in the circuit	
<u>In voltage control circuit</u>	
Electric connection of magnetization winding of HO-12-25 choke with neutralizing winding	Voltage drops to 70 V
Shorted (punctured) capacitor rated for 200.5 μF	Voltage stabilizer fails to fire, low voltage level
Breakage in magnetization winding circuit of HO-12-25 choke	Voltage increased to 150 V at idle running and to 130 V under load
Loose contact in voltage stabilizer panel	Voltage increases to 135 V under load and to 165 V at idle running
Breakage in neutralizing winding circuit of HO-12-25 choke	Voltage drops to 57 V both at idle running and under load
Wrong connection of A.C. coils of HO-12-25 choke	Inverter voltage is 70 V
Confused interconnections of magnetization and neutralizing windings	Low voltage (55 V), high frequency
Confused connections of HO-11 stability transformer	Voltage elevated to 160 V, negative drop up to 10 V
Mixed polarity in connections of magnetization and neutralizing windings of HO-12-25 choke	High voltage - up to 130 V
Confused polarity in connections of neutralizing winding of HO-12-25 choke	Low voltage (55 to 60 V), high speed
Confused polarity in connections of magnetization winding of HO-12-25 choke	Low voltage (60 to 65 V), high speed

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 118 -

**Control over A.C. Power Supply Sources and A.C. Mains**

For control over A.C. voltage of 115 V the radar operator's generator control panel (See Fig. 55) is provided with a ferrodynamic voltmeter, type B4-150.

**Specifications of Voltmeter, Type B4-150**

1. Measuring range	0 to 150
2. Main error	±2.5%
3. Additional error for every 10° temperature variation from normal (+20°)	±0.25%
4. Additional error for a ±50 c.p.s. frequency variation from mean frequency of 400 c.p.s.	±1.25%
5. Power consumption	2.5 W
6. Operating temperature range	from -60° to +50°
7. Weight of instrument	400 gr

**Note:** Voltmeter errors are given in per cent of full scale.

**Maintenance of Voltmeter, Type B4-150**

To ensure correct operation of the instrument, the pre-flight preparation procedure should include a check-up of the voltmeter needle for correct zero position. The check should be carried out before energizing the instrument. The voltmeter needle should be zeroed by means of the corrector screw located on the face panel of the instrument; in the course of zeroing the instrument must be energized.

**CAUTION.** The B4-150 voltmeter should be checked for its needle position before each flight.

If the voltmeter needle fails to respond to the connection of the HO-4500 inverter, it is necessary to check the condition of the connecting wires, as well as the integrity and reliability of contact connections. Should other troubles be detected in the course of the voltmeter operation, the faulty instrument should be removed and replaced.

**Adjusting and Checking the Operation of HO-4500 Inverter**

It is allowed to connect the inverters for operation with the aircraft A.C. mains only when the aircraft D.C. mains is energized from a ground power supply source or from aircraft generators, type ICP-18000.

The inverter adjusting and checking procedure is as follows:

1. With the ABC-2 circuit breakers of the operating and stand-by inverters open, place the generator selector switch on the generator control panel to OPERATING (PARSONS). This action should engage the operating (starboard) inverter.
2. At least 5 minutes after, check the inverter voltage by the aircraft A.C. voltmeter. If the gauged voltage differs from the nominal voltage of 115 V by less than 0.5 V, operate the respective inverter voltage rheostat to obtain the value of  $115 \pm 0.5$  V.
3. Connect the permanently engaged A.C. power consumers (the radar bomb aim sights).
4. Check the voltage of the operating inverter, and correct it if the voltage is other than  $115 \pm 0.5$  V.

- 119 -

5. Disconnect the A.C. power consumers.

6. Throw the generator selector switch to the STAND-BY (PERSEPHONE) position; check and adjust the voltage of the stand-by inverter repeating steps (2), (3), (4) and (5) above.

**Note:** For uniform expenditure of the service lives of the inverters it is advisable to connect them to the aircraft mains during ground adjustments and to engage them in flight in turn.

**ELECTRICALLY HEATED GLASS PANELS**

Electrical heating of glass panels prevents their external icing and internal fogging thus providing adequate visibility conditions under any flight conditions encountered.

Electrically heated are the two forward glass panels, type H-13, (right and left) of the pilots and the lower glass panel, type H-13, of the navigator. Each glass panel is an assembly of two hardened allicate glasses butt-jointed between which is a heater element consisting of thin constantan wires.

The power requirement of the heaters depends on the heated area and constitutes 0.5 to 0.64 W per one square cm. of the heated glass surface. This specific power (0.5 to 0.64 W/sq.cm.) is so large that should there be no sufficient heat dissipation, the operating heater would raise the glass temperature to such a degree which might result in deterioration of the glass. To meet these conditions, provisions are made for temperature regulation. This is done by thermostats press-fitted in the glass panels and by an automatic temperature controller, type AOC-31M. The AOC-31M controller is installed at the starboard side of the front pressurized cabin in the area of frame No. 5. The electric heaters of the glass panels of both the pilot and co-pilot are engaged by means of two B-45 switches located on the overhead electric control board of the pilots (See Fig. 59), while the heater of the navigator's glass panel is cut in by the B-45 switch mounted on the navigator's overhead electric control board (See Fig. 62). The current energizing the pilot's glass panel heaters is applied through two H-50H contactors (See the diagram in Fig. 74), while the navigator's glass panel heater is energized through a K-100H contactor. The power supply lines are protected by delayed action fuses of HII type (two fuses rated for 75 A each and one fuse - for 100 A).

The fuses and contactors are housed in the glass panel heater junction box (Fig. 75) which is installed at frame No. 6, starboard.

**Maintenance of Heated Glass Panels**

When replacing equipment items of the electrically heated glass panel sets, make sure that the equipment is mounted and wired correctly. Special attention should be paid to correct connection of glass panels which have additional leads (the navigator's glass panel, type H-13). The continuity check will be carried out in compliance with the existing rules, using the methods of identification and measuring the insulation resistance value.

The connections of the thermostat circuits are of no lesser importance. Thermostat No. 1 of each glass panel is its operating thermostat. Thermostat No. 2 is a stand-by instrument and it is engaged only in case of failure of thermostat No. 1.

**Note:** Thermostat No. 1 corresponds to lead 1 on the terminal block, and the operating lead for thermostat No. 2 is lead 3. Lead 2 is common for both.

SECRET

NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 120 -

If the terminal lead-outs are not numbered, the left lead should be considered as the lead of thermistor No.1, and the right lead (as viewed from the down-oriented block side) should be taken as corresponding to thermistor No.2.

#### Adjusting the Glass Panel Heating Degree

When through with the circuit continuity check, it is necessary to adjust (regulate) the degree of glass panel heating; this procedure consists in testing the channels for correct connection and in adjusting the automatic temperature controller, type AOC-SLM. The AOC-SLM controller has three independent channels, each of which controls its connected glass panel.

The adjustment procedure runs as follows:

1. Disconnect the wires from the terminal block of the navigator's glass panel.
2. Connect a test lamp between the plus wire and the airframe.
3. Engage the NAVIGATOR'S GLASS PANEL HEATER ( OQOPPEB CTERMA HETEMARA ) circuit breaker, type AOC-2 , on the navigator's circuit breaker control panel.
4. Engage the NAVIGATOR'S GLASS PANEL HEATER ( OQOPPEB CTERMA HETEMARA ) switch, type B-45, on the overhead electric control board of the navigator. As a result, the test lamp connected to the plus wire of the glass panel heater should flash.
5. Close (through a resistor of 1000 to 2000 ohms) the wires disconnected from the thermistor of the navigator's glass panel heater. This action should result in going out of the lamp connected to the plus wire.

**Note:** Used in the function of the resistor may be a calibrating resistance rheostat (Fig.76).

6. With the navigator's glass panel heater switch disengaged, connect the thermistor wires and the plus wire to the terminal block without disconnecting the test lamp.

7. Place the slide of the navigator's glass panel heater channel rheostat the AOC-SLM controller to the extreme left position and turn on the switch of the respective glass panel heater.

8. Moving the rheostat slide to either side, check to see if the test lamp flashes up when the rheostat slide is turned to the right and goes out as soon as the slide is moved to the left from the centre.

9. By turning the rheostat slide to the left, and then slowly returning it to the right and farther on, determine the position in which the lamp flashes. At this moment the R-100M contactor will be engaged and the heater will start its operation. After a certain lapse of time the AOC-SLM controller will disconnect the navigator's glass panel heater. As soon as the glass cools down to the pre-established degree, the AOC-SLM controller will re-engage the heater.

All the time during the check it is necessary to watch the temperature of the outer surface of the glass panel referring to the thermometer, type POC 204-43 . The thermometer ball should be applied to the hottest spot on the glass (See Fig.74), holding it tight against the glass by means of a piece of cotton wool or felt.

10. After two or three operating cycles of the contactor, the glass surface temperature can be considered to be stable. If the temperature is other than  $32 \pm 2^{\circ}$ , it is necessary to carry out additional adjustments which is done by turning the slide of the respective rheostat on the AOC-SLM controller.

11. Adjustments of the AOC-SLM controller over, determine the value of the resistance the AOC-SLM controller is adjusted for, and make the corresponding

50X1-HUM

- 121 -

entry in the controller Certificate with the indication of the system resistance and of the glass surface temperature. To do this:

(a) disconnect the wires from the terminal block, and connect a test lamp to the glass panel electric supply cable and the calibrating resistance rheostat to the other two wires;

(b) set a resistance value of 9000 ohms on the rheostat, and then gradually decrease the resistance until the test lamp goes out. The resistance at which the lamp goes out will be the resistance for which the AOC-SLM controller is adjusted; the value of this resistance should be within 1500 to 8000 ohms. In case the obtained resistance value is other than 1500 to 8000 ohms, it is necessary to regulate the glass surface temperature by means of the stand-by thermistor, since the conditions indicate failure of thermistor No.1.

12. The heater channels of the AOC-SLM controller for the glass panels of the pilot and co-pilot will be adjusted with the same methods as those described above.

13. Once all the three controller channels are completely adjusted, seal the covers closing the rheostats of the AOC-SLM controller.

**CAUTION:** 1. During the check, NEVER short-circuit the wires running to the thermistor and NEVER set a resistance smaller than 1000 ohms on the rheostat, since this will result in failure of the automatic temperature controller, type AOC-SLM.

2. IT IS ABSOLUTELY FORBIDDEN to engage the glass panel heaters if the thermistor is disconnected or the AOC-SLM controller is maladjusted; same is true when thermistors have internal breakdowns.

3. The automatic temperature controller, type AOC-SLM, should be adjusted with employment of a thermometer at ambient air temperatures of minus 10 to plus 25°C as at lower temperatures it may occur that glass surface temperature measurements will be erroneous, while at higher-than-specified temperatures the glass cools down very slowly after its heater has been automatically disconnected.

#### Use of Glass Panel Heaters

In flight the glass panel heaters will be engaged if icing or fogging conditions are about to be encountered (before cloud-breaking, in haze and mist). On flying in adverse weather conditions, it is advisable to keep the heaters engaged throughout the entire flight.

At parking sites and when taxiing to the take-off position, the glass panel heaters should be engaged only in icing or fogging conditions.

Before going down for landing, as well as prior to taxiing to the take-off position it is recommended to switch off the glass panel heaters for when the heaters are engaged, the additional strains (deformations) resulting from humpiness (vibration) of the aircraft may render the electrically heated glass panels unserviceable.

**CAUTION:** Never engage the glass panel heaters with thermistor disconnected or AOC-SLM automatic temperature controller maladjusted.

#### TAIL EMPENNAGE DE-ICERS

##### Brief

The fin and stabiliser leading edge sections are provided with electrically operated de-icers. Each de-icer consists of sections, parts and heaters.

SECRET

NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM



50X1-HUM

The stabilizer de-icer is divided into two sections:  
(a) inner section heating the basic (butt) parts of the left and right stabilizer leading edge sections;  
(b) outer section heating the end parts of the stabilizer leading edge sections.

The fin de-icer has one section consisting of one part. The inner and outer sections of the stabilizer consist each of two parts located on the left- and right-hand surfaces of the stabilizer. In each section the parts of the stabilizer left- and right-hand surfaces are connected to each other in parallel (see diagram in Fig. 93). Each part consists of several heaters connected to each other in series.

Each part of the de-icer sections is provided with bimetal thermostats, type 777 B, which cut out the de-icer section when at least one of the parts is heated to a temperature of  $80 \pm 10^\circ\text{C}$  in the place where this thermostat is mounted.

The de-icer sections are energized during 40 seconds and de-energized during 30 seconds. The cycle is ensured by the distributing electrical mechanism, type MK-3A, switching on the de-icer sections in turn through the K-600K contactor.

The beginning of switching on the de-icer sections varies in time and depends on the position of the MK-3A contact device at the moment the MK-3A electrical mechanism stops; the order of switching on the sections is always the same. The switching on of the inner section of the stabilizer de-icer is always followed by that of the stabilizer de-icer outer section, then by that of the fin de-icer, then again by that of the stabilizer de-icer inner section, etc.

The MK-3A mechanism is mounted on the port side of the fuselage tail unsealed section at frame No. 63. The power contactors, type K-600K, and fuses, type H-600, of the de-icer sections power circuits are located in the junction box of the tail spenage de-icers (Fig. 78) which is also mounted on the port side of the fuselage tail unsealed part between frames Nos 63 and 63a.

The de-icers are switched on by means of the B-45 switch on the pilots' upper electric board. The de-icer operation is checked by a white lamp, type GM-51, which every 80 sec. flashes up for 40 sec. thus warning of the operation of the stabilizer outer section de-icer. The lamp is mounted on the right-seat pilot's instrument panel.

Main Specifications of MK-3A  
Electric Mechanism

1. Nominal voltage .....	27 V
2. Operating voltage range .....	27 $\pm$ 2.7 V
3. Nominal current at the moment the contactor contacts open .....	5 A (of inductive load)
4. Nominal current consumed by the mechanism motor .....	0.8 A
5. Duty of mechanism operation .....	continuous
6. The electric mechanism must operate normally under the following conditions:	
(a) at relative humidity of ambient air .....	up to 98 per cent
(b) at change in ambient air temperature .....	from +50 to -60°C
(c) at vibration and shaking with acceleration .....	4 g
(d) at sea level altitude .....	up to 15,000 m.
7. Mechanism service life .....	300 hours of continuous operation

tion in the course of two years from the moment the mechanism is installed on the aircraft

- 5. Weight of the electric mechanism ..... not in excess of 2.4 kg
- 6. Comutator ensures switching on the contactor windings under voltage according to the following cycles:
  - (a) two 60  $\pm$  9-sec. switchings with an interval between them ..... not in excess of 4 sec.
  - (b) three 40  $\pm$  6-sec. switchings with an interval between them ..... same
  - (c) six 20 - 3-sec. switchings with intervals between them ..... same

- Notes:
1. The connection diagram of the MK-3A electric mechanism ensures the latter operation only according to the cycle indicated in item "6".
  2. The intervals between the switchings is included in the time during which the contactor contacts are closed. Two contacts of one cycle cannot be closed simultaneously.

Care of MK-3A Electrical Mechanism

During service the MK-3A electrical mechanism does not require adjustment, maintenance or special care. The attending personnel must only periodically check the quality and reliability of the electrical mechanism attachment, as well as the locking of the plug connector and attachment bolts. On detecting a fault in the MK-3A electrical mechanism replace it by a new one.

Checking Tail Spenage De-Icer System on the Ground

The ground check of the tail spenage de-icers should be carried out only with the aircraft mains supplied from the ground D.C. power source connected through the ground supply plug connector.

CAUTION. To avoid overheating of the skin and damage to the protective coating, it is not permitted to switch on the electric de-icer with the aircraft mains supplied from the TGP-18000 generators and with the engines running on the ground.

- The de-icer ground test makes it possible to check:
1. The condition of the circuit and the serviceability of the de-icers.
  2. The sequence of switching on the de-icer sections.
  3. The duration of the de-icer sections switching cycles.
  4. Current consumed by the de-icer separate sections at a voltage of 26 V across the heater terminals, that is, provided the de-icers are supplied from the aircraft generators.

Check to see that the surface of the de-icer boots is heated and the de-icer sections are switched on in correct sequence by hand feel. Besides this, the surface of the de-icer boots can be checked for warming up by means of a special instrument which is a thermocouple mounted on a tubular rod adjustable in length. Inside the rod a wire running to the temperature indicator is laid.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 124 -

When checking temperature by means of the special instrument (thermocouple) in temperature on the surface at any point of any de-icer boot section must exceed ambient air temperature approximately by 30 to 50°C during one cycle of the de-icer section operation.

Check the duration of the switching cycles by means of a stopwatch, with the NI-600 fuses in the power circuits of the de-icer sections removed. Consumed current is checked by means of the 2 aircraft ammeter connected to the storage battery and ground power supply source.

Complete check up of the tail empennage de-icer system on the ground shall be performed in the following manner:

1. Remove the NI-600 fuses from the power circuits of all the three sections in the junction box of the tail empennage de-icers.
2. With the de-icer A30-5 circuit breaker (on the right-seat pilot's circuit breaker panel) switched on, turn on the tail empennage de-icer switch on the pilot's upper electric board. In this case the MKA-3A electrical mechanism must be brought into operation which is indicated by the warning lamp on the right-seat pilot's instrument panel flashing up periodically.
3. Check the operation of the R-600J contactors by means of pilot lamps connected to the wiring terminals of all the three contactors. The lamps must periodically flash up.
4. Check the duration of the switching cycles by the pilot lamps.
5. Turn off the de-icer switch at the moment the warning lamp on the right-seat pilot's instrument panel goes out.
6. Install the NI-600 fuse in the power circuits of all the three de-icer sections.
7. Connect a voltmeter between the aircraft body and the plus terminal (power bolt on the terminal block) of the fin leading edge heater.
8. Turn on the de-icer switch and measure the current consumed by the section of the fin leading edge heater and voltage at this section.
9. As soon as the fin leading edge heater is out, turn off the de-icer switch.
10. In a similar way measure current and voltage on the inside and outside sections of the stabilizer de-icer.
11. When checking according to Items 8, 9 and 10, simultaneously check by hand feel the serviceability and sequence of switching on the de-icer sections. Make sure that the inside or outside sections of the stabilizer leading edge heaters start operating simultaneously. Asymmetric operation of the de-icers is not permitted.

**CAUTION.** It is prohibited to switch on the tail empennage de-icers on the ground for a longer period than one operation cycle of the MKA-3A electrical mechanism.

12. Determine the current consumed by each section of the de-icers at a voltage of 26 V across the heater terminals. The current is to be determined by the formula:

$$I_{26} = \frac{I_{\text{measured}} \cdot 26}{V_{\text{measured}}}$$

where  $I_{26}$  is the current consumed by the de-icer section at 26 V across the heater terminals;

$I_{\text{measured}}$  is the current measured during the test of the given section;

$V_{\text{measured}}$  is the voltage measured during the test of the given section.

- 125 -

For the fin de-icer the value  $I_{26}$  must be within  $480 \pm 10$  per cent, for the inside section of the stabilizer de-icer - within  $450 \pm 10$  per cent and for the outside section - within  $490 \pm 10$  per cent.

If for any section of the tail empennage de-icers the value  $I_{26}$  exceeds the permitted limits, make sure that the taken measurements and calculations are correct and only after that replace the defective leading edge sections by new ones.

It is not permitted to eliminate the defects caused by short circuit and the open circuit of the heaters during service.

#### Instructions for Operation of Tail Empennage De-Icers during Flight

The tail empennage de-icers should be switched on during flight prior to entering the zone of probable icing. The de-icers must be switched off if the surface of the tail empennage leading edge sections is quite free from ice.

**Note:** When checking the serviceability of the tail empennage de-icers during flight in case no ice formation takes place, it is permitted to switch them on for not more than 5 minutes.

This being the case, the de-icer operation is checked by the warning lamp and consumed current (as measured by the generator ammeters).

#### WARNING SYSTEM

The aircraft is provided with light and sound warning system. The light warning system consists of warning lamps, type CJH-51, of various colour mounted on desks, boards and instrument panels.

The light warning devices are designed for signalling:

1. preparation of the engines for starting;
2. oil pressure in the turbostarter;
3. operation of fuel pumps and determination of the order of fuel consumption;
4. fire and opening the fuel shut-off cocks;
5. release of the brake parachute;
6. pressure drop in the hydraulic system and operation of the brake automatic unit;
7. landing gear and tail support position;
8. trim tab neutral position;
9. SPEED TOO HIGH (СКОРОСТЬ БЕРИМА);
10. switching on the ATE-2 gyro horizon;
11. armament position prior to aircraft landing;
12. camera tilting mount and camera hatch position;
13. operation of the tail empennage de-icers;
14. charging cocks open position and FUEL DELIVERED (ТОЛКНО ПОЯВИЛОСЬ) warning unit;
15. pressure drop in the pressurized cabins;
16. outside signalling by signal flare launcher.

The types of warning lamps, their arrangement on the aircraft and nature of operation are indicated in Table 22.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



50X1-HUM

Light Fitting GH-51

The light device, type GH-51, (Fig.79) is designed for signalling inside the aircraft or for use as a light indicator of the aircraft separate units as mechanics operation. The light device ensures the possibility of operation under day- and night-time conditions. The reduction of signal brightness by turning the device cover to the right as far as it will go during the night makes it possible to preserve the adaptation of the aircrew member's eyes to the low brightness background. The position at which all the four holes in the end face walls of the device head and cover are open (the cover with the light filter is turned to the left as far as it will go) corresponds to the day conditions. Besides the two extreme positions, the cover with the light filter can be set to any intermediate position which corresponds to partial opening of the three triangular holes in the end face walls of the device head and cover.

The aircraft is provided with devices of five colours: red, green, yellow, blue and white.

The GH-51 fitting is intended for use with a special aircraft lamp (rate for 28 V and 0.17 A), type GK-50, with a single-contact base 1c-9-1.

The sound signalling is performed by continuous and intermittent bussing of aircraft horn, type G-1 (Fig.80). The aircraft has two G-1 horns; the arrangement, use and nature of operation of the horns are given in Table 25.

The transmitters of intermittent sound signals are cabin pressure warning units, type EK-46.

The transmitters of continuous sound signals are:

(a) in the event of aircraft take off with the flaps retracted or extended by an angle below the rated value - mechanism, type ME-2, mounted on the flap transmission shaft (at frame No.33) and limit switches, type BE2-1A2 (front), mounted on the right-seat pilot engine control panel;

(b) in the event of throttle control retraction (aircraft landing) with landing gear extended - blocking contacts, type BE2-1A2 (rear), mounted on the right-seat pilot engine control panel and the landing gear extended position limit switches.

Specifications of G-1 Horns

Table with 2 columns: Specification and Value. Includes Voltage range (20 to 30 V), Nominal voltage (26 V), Nominal duty of operation (intermittent), Maximum current consumed at 26 V (0.85 A), Sound intensity at 26 V (not less than 80 db), Frequency of contact opening at 26 V (200 to 310 c.p.s.), Horn weight (not in excess of 1.81).

The cabin pressure warning unit is designed for closing the electric circuit of the sound and light signal system warning the aircrew of the necessity of using oxygen apparatus.

The warning unit, type EK-46, is a unit of four aneroid boxes connected to the electric circuit moving contact. If pressure drops below the rated value, the boxes unit closes the circuit contacts and sends electric signals to the PE-12 busser relay. The warning unit is adjusted for signal transmitting at altitudes from 1000 to 5000 m.

Specifications of EK-46 Cabin Pressure Warning Unit

- 1. The cabin pressure warning unit must continuously send out light and sound signals from the moment pressure decreases in the cabin to a value corresponding to the altitude set at the dial.
2. Range of adjusting the unit for the beginning of the signal transmission according to pressure in the pressurized cabin corresponding to altitude in compliance with the international standard atmosphere from 1000 to 5000 m.
3. Instrument temperature range from +50 to -60°C
4. Instrument error during signal sending out at normal temperature at scale marks: 2; 3; 4; 5; 6; 7; 8; 9; 10; 11; 12; 13; 14; 15; 16; 17; 18; 19; 20; 21; 22; 23; 24; 25; 26; 27; 28; 29; 30; 31; 32; 33; 34; 35; 36; 37; 38; 39; 40; 41; 42; 43; 44; 45; 46; 47; 48; 49; 50; 51; 52; 53; 54; 55; 56; 57; 58; 59; 60; 61; 62; 63; 64; 65; 66; 67; 68; 69; 70; 71; 72; 73; 74; 75; 76; 77; 78; 79; 80; 81; 82; 83; 84; 85; 86; 87; 88; 89; 90; 91; 92; 93; 94; 95; 96; 97; 98; 99; 100; 101; 102; 103; 104; 105; 106; 107; 108; 109; 110; 111; 112; 113; 114; 115; 116; 117; 118; 119; 120; 121; 122; 123; 124; 125; 126; 127; 128; 129; 130; 131; 132; 133; 134; 135; 136; 137; 138; 139; 140; 141; 142; 143; 144; 145; 146; 147; 148; 149; 150; 151; 152; 153; 154; 155; 156; 157; 158; 159; 160; 161; 162; 163; 164; 165; 166; 167; 168; 169; 170; 171; 172; 173; 174; 175; 176; 177; 178; 179; 180; 181; 182; 183; 184; 185; 186; 187; 188; 189; 190; 191; 192; 193; 194; 195; 196; 197; 198; 199; 200; 201; 202; 203; 204; 205; 206; 207; 208; 209; 210; 211; 212; 213; 214; 215; 216; 217; 218; 219; 220; 221; 222; 223; 224; 225; 226; 227; 228; 229; 230; 231; 232; 233; 234; 235; 236; 237; 238; 239; 240; 241; 242; 243; 244; 245; 246; 247; 248; 249; 250; 251; 252; 253; 254; 255; 256; 257; 258; 259; 260; 261; 262; 263; 264; 265; 266; 267; 268; 269; 270; 271; 272; 273; 274; 275; 276; 277; 278; 279; 280; 281; 282; 283; 284; 285; 286; 287; 288; 289; 290; 291; 292; 293; 294; 295; 296; 297; 298; 299; 300; 301; 302; 303; 304; 305; 306; 307; 308; 309; 310; 311; 312; 313; 314; 315; 316; 317; 318; 319; 320; 321; 322; 323; 324; 325; 326; 327; 328; 329; 330; 331; 332; 333; 334; 335; 336; 337; 338; 339; 340; 341; 342; 343; 344; 345; 346; 347; 348; 349; 350; 351; 352; 353; 354; 355; 356; 357; 358; 359; 360; 361; 362; 363; 364; 365; 366; 367; 368; 369; 370; 371; 372; 373; 374; 375; 376; 377; 378; 379; 380; 381; 382; 383; 384; 385; 386; 387; 388; 389; 390; 391; 392; 393; 394; 395; 396; 397; 398; 399; 400; 401; 402; 403; 404; 405; 406; 407; 408; 409; 410; 411; 412; 413; 414; 415; 416; 417; 418; 419; 420; 421; 422; 423; 424; 425; 426; 427; 428; 429; 430; 431; 432; 433; 434; 435; 436; 437; 438; 439; 440; 441; 442; 443; 444; 445; 446; 447; 448; 449; 450; 451; 452; 453; 454; 455; 456; 457; 458; 459; 460; 461; 462; 463; 464; 465; 466; 467; 468; 469; 470; 471; 472; 473; 474; 475; 476; 477; 478; 479; 480; 481; 482; 483; 484; 485; 486; 487; 488; 489; 490; 491; 492; 493; 494; 495; 496; 497; 498; 499; 500; 501; 502; 503; 504; 505; 506; 507; 508; 509; 510; 511; 512; 513; 514; 515; 516; 517; 518; 519; 520; 521; 522; 523; 524; 525; 526; 527; 528; 529; 530; 531; 532; 533; 534; 535; 536; 537; 538; 539; 540; 541; 542; 543; 544; 545; 546; 547; 548; 549; 550; 551; 552; 553; 554; 555; 556; 557; 558; 559; 560; 561; 562; 563; 564; 565; 566; 567; 568; 569; 570; 571; 572; 573; 574; 575; 576; 577; 578; 579; 580; 581; 582; 583; 584; 585; 586; 587; 588; 589; 590; 591; 592; 593; 594; 595; 596; 597; 598; 599; 600; 601; 602; 603; 604; 605; 606; 607; 608; 609; 610; 611; 612; 613; 614; 615; 616; 617; 618; 619; 620; 621; 622; 623; 624; 625; 626; 627; 628; 629; 630; 631; 632; 633; 634; 635; 636; 637; 638; 639; 640; 641; 642; 643; 644; 645; 646; 647; 648; 649; 650; 651; 652; 653; 654; 655; 656; 657; 658; 659; 660; 661; 662; 663; 664; 665; 666; 667; 668; 669; 670; 671; 672; 673; 674; 675; 676; 677; 678; 679; 680; 681; 682; 683; 684; 685; 686; 687; 688; 689; 690; 691; 692; 693; 694; 695; 696; 697; 698; 699; 700; 701; 702; 703; 704; 705; 706; 707; 708; 709; 710; 711; 712; 713; 714; 715; 716; 717; 718; 719; 720; 721; 722; 723; 724; 725; 726; 727; 728; 729; 730; 731; 732; 733; 734; 735; 736; 737; 738; 739; 740; 741; 742; 743; 744; 745; 746; 747; 748; 749; 750; 751; 752; 753; 754; 755; 756; 757; 758; 759; 760; 761; 762; 763; 764; 765; 766; 767; 768; 769; 770; 771; 772; 773; 774; 775; 776; 777; 778; 779; 780; 781; 782; 783; 784; 785; 786; 787; 788; 789; 790; 791; 792; 793; 794; 795; 796; 797; 798; 799; 800; 801; 802; 803; 804; 805; 806; 807; 808; 809; 810; 811; 812; 813; 814; 815; 816; 817; 818; 819; 820; 821; 822; 823; 824; 825; 826; 827; 828; 829; 830; 831; 832; 833; 834; 835; 836; 837; 838; 839; 840; 841; 842; 843; 844; 845; 846; 847; 848; 849; 850; 851; 852; 853; 854; 855; 856; 857; 858; 859; 860; 861; 862; 863; 864; 865; 866; 867; 868; 869; 870; 871; 872; 873; 874; 875; 876; 877; 878; 879; 880; 881; 882; 883; 884; 885; 886; 887; 888; 889; 890; 891; 892; 893; 894; 895; 896; 897; 898; 899; 900; 901; 902; 903; 904; 905; 906; 907; 908; 909; 910; 911; 912; 913; 914; 915; 916; 917; 918; 919; 920; 921; 922; 923; 924; 925; 926; 927; 928; 929; 930; 931; 932; 933; 934; 935; 936; 937; 938; 939; 940; 941; 942; 943; 944; 945; 946; 947; 948; 949; 950; 951; 952; 953; 954; 955; 956; 957; 958; 959; 960; 961; 962; 963; 964; 965; 966; 967; 968; 969; 970; 971; 972; 973; 974; 975; 976; 977; 978; 979; 980; 981; 982; 983; 984; 985; 986; 987; 988; 989; 990; 991; 992; 993; 994; 995; 996; 997; 998; 999; 1000.

Cabin pressure warning units are mounted in the front cabin at frame No.5 (starboard side) and in the rear cabin at frame No.75 (starboard side).

To obtain intermittent light and sound signals, connected to the circuit of each cabin pressure warning unit is a busser relay, type PE-12, with two capacitors, type EB-1A-50, C=50 - V. The relay and capacitors are installed in the boxes of the sound signal relays (Figs 81 and 82). The relay boxes are mounted in the front pressurized cabin on the navigator-radar operator left-hand rack and in the rear pressurized cabin on the starboard side at frame No. 73.

The relay is switched on by the operation of the cabin pressure warning unit contacts and ensures intermittent duty of operation.

Specifications of PE-12 Relay

- 1. Nominal voltage 26.5 V
2. Frequency of relay operation at nominal voltage 3 to 5 switchings per second
3. The relay operates normally under the following conditions:
(a) ambient air temperature from +50 to -60°C
(b) ambient air relative humidity up to 98 per cent
(c) sea-level altitude up to 15000 m.
(d) aircraft vibration
4. Operating voltage when operating under load (continuous operation) not in excess of 14 V
5. Amature attraction voltage not in excess of 12 V
6. Amature drop-out voltage 2 to 5 V
7. Relay weight not in excess of 195 gr

SECRET

NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM

Table 22

Mechanical Signalling

No	Purpose	Number of lamps	Type of device	Signal devices		Location of device	Note
				Conditions under which the device operates	Nature of operation		
1	Signalling of the engine readiness for starting	2	CH-51, green	With the turbocharger exhaust gas shutters open of the lamps	Constant glow	On the engine starting panel on the left-seat pilot's engine control console	
2	Signalling of oil pressure in the turbocharger	1	CH-51, green	At oil pressure in the turbocharger exceeding 3.5 atm.	Constant burning of the lamps	On the turbocharger control panel	
3	Signalling of fuel consumption sequence	4	CH-51, blue	1st group lamp flashes up when the fuel consumption control switch is set to the AUTOMATIC (АВТОМАТИКА) position and the sapifiers switches turned on. The rest of the lamps flash up in sequence after 200 lit. of fuel is left in the previous tank group	Constant glow of the lamps	On the fuel supply panel	
4	Signalling of fuel available for 30- or 15-minute flight	2	CH-51, red	Two lamps flash up with fuel available for a 30-minute flight, the other two lamps flash up with fuel available for a 15-minute flight	Constant glow of the lamps on the left-seat pilot instrument panel	On the fuel supply board	
5	Signalling of fuel pump operation	12	CH-51, green	With the pump operating and pressure in the system reaching 0.3 or 0.35 kg per sq.cm.	Constant glow of the lamps	On the fuel supply board	
6	Signalling of engine shut-off cocks open position	2	CH-51, green	With the engine shut-off cocks open from the beginning of engine starting to its stopping	Constant glow of the lamps	On the fuel supply board	
7	Fire signalling	6	Red	With the fire-fighting system switched on, when temperature in the area of the fire-sensitive units reaches 140 to 170°C or on pressing the button	Constant glow of the lamps	On the fuel supply board	
8	Signalling of the brake parachute release	2	CH-51, green	With the brake parachute released	Constant glow of the lamps	On the instrument panels of the right- and left-seat pilots	

SECRET

NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM

1	2	3	4	5	6	7	8
9	Signalling of pressure trap in emergency hydraulic system	CHI-51, red	At pressure in the normal hydraulic system less than 100 kg per sq.cm and in the emergency hydraulic system less than 130 kg per sq.cm.	Constant glow of the lamp	On the pilot's central electric board		
10	Signalling of the brake automatic unit operation	CHI-51, blue	With abrupt braking of the wheels, with the brake automatic unit switch turned on	Blinking of the lamp	On the pilot's central electric board		
11	Signalling of the armament position during landing	CHI-51, blue	With the armament barrels of the lower and rear sighting stations in the lowered position	Constant glow of the lamp	On the left-seat pilot's instrument panel		
12	Signalling of the tail support and landing gear position	CHI-51, five green and three red lamps	The three green lamps indicate the landing gear lever under position; the three red lamps - the landing gear legs retracted position	Constant glow of the lamps	On the pilots' central electric board, on the gunner - radio operator's and gunner's electric board		
13	Signalling of the rudder and aileron trim tabs position	CHI-51, white	With the rudder and aileron trim tabs in the neutral position	Constant glow of the lamps	On the left-seat pilot's instrument panel, in the aileron trim tab indicator panel		

1	2	3	4	5	6	7	8
14	ALERT TWO HIGH (CHOPOTIS BEMEM) signalling	CHI-51, red	With pressure head amounting to 2300 kg per sq.cm. at low altitudes; at 60.05 at high altitudes	Constant glow of the lamp	On the pilot's instrument panels		
15	Signalling of the standby gyro horizon switching	CHI-51, red	With the standby gyro horizon switched on by the left-seat pilot or navigator-rudder operator	Constant glow of the lamp	On the left-seat pilot's instrument panel		
16	Signalling of the camera flash in the open position, camera tilting mount position during air survey and checking	CHI-51, green, white, yellow	(a) The green lamp is on with the flash open (b) The white lamp flashes, when the camera tilting mount passes the zero position, in SURVEY MODE OF OPERATION (PAREMMA) (c) The yellow lamp is on with the camera tilting mount operating in CHECK mode (KORPOBE) at tilt angles of 0, 10, 15, 20 and 25°	Constant glow of the lamp Blinking of the lamp	On the navigator's right-hand console		
17	Signalling of the tail expensage de-icers operation	CHI-51, white	On switching on the de-icer outer sections	Blinking of the lamp (90-sec. glow followed by 80-sec. interval)	On the right-seat pilot instrument panel		

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



- 132 -

1	2	3	4	5	6	7	8
18	Signalling of the fuel supply cocks open position and FUEL DELIVERED (VOICE) signal	4	CH-51, four green lamps are on when the fuel supply cocks are switched on for opening	(a) The green lamps are on when the fuel supply cocks are switched on for opening (b) The yellow lamp is on when the FUEL DELIVERED (VOICE) warning unit is switched on	Constant glow of the four lamps  Constant glow of the lamp	On the fuelling control board	
19	Signalling of pressure drop in the cabin	5	CH-51, yellow lamp	When pressure drop corresponds to the altitude set at the dial within 1000 to 5000 ft.	Flinking of the lamp	On the navigator's oxygen panel, on the left-seat pilot instrument panel, the navigator-radar operator's oxygen panel, the gunner's radio operator's instrument panel, the gunner's electric board	

- 133 -

50X1-HUM

Table 23  
Sound Signalling

Row	Purpose	Number of devices	Type of device	Signal devices Conditions under which they operate	Nature of operation	Location of devices	Note
1	Signalling of flap position during take off	1	Horn, Type C-1, of the front pressurized cabin	With the flaps not extended to the take off angle, that is $19 \pm 1^\circ$ to $23 \pm 1^\circ$ and with both throttle controls set to the position corresponding to the aircraft take off	Constant buzzing of the horn	On the port side at frame No. 9 of the front pressurized cabin	
2	Signalling of pressure drop in the cabin	1	Horn, Type C-1, of the front pressurized cabin	When at least one landing gear leg is not extended and at least one throttle control is set to low throttle (during landing)	Constant buzzing of the horn	On the port side at frame No. 9 of the front pressurized cabin	
3	Signalling of pressure drop in the cabin	2	Horn, Type C-1, of the front pressurized cabin Horn, Type C-1, of the rear pressurized cabin	When air pressure in the pressurized cabin is below the value set at the dial of the cabin pressure warning unit, Type EC-46	Intermittent buzzing of the horn	On the port side at frame No. 9 of the front pressurized cabin On the starboard side at frame No. 71 of the rear pressurized cabin	

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 134 -

Care and Maintenance of Light and Sound Signal Units

The light, type GM-51, horn, type C-1, cabin pressure warning units, type EC-45, and the buzzer relay, type PA-12, do not require special care and maintenance. During service take care to see that these units are securely attached, and the contacts of the connected wires are in good condition and properly tightened.

Maintenance of the light signal fittings in the main consists in replacing burnt out lamps. To replace a lamp in the GM-51 fitting, it is necessary to unscrew the head with the light filter, fit a new lamp into the holder and screw up the head again. When soldering the wires to the fitting, observe polarity (the plus wire must be soldered to the fitting central contact). If polarity is incorrect, short circuit may take place during the replacement of the lamp under voltage.

In case the C-1 horn is being replaced or the supply conductors are being connected to the horn during installation of the horn cap, when the attachment screw is being tightened, ensure not only proper attachment of the cap but also normal sounding of the horn. The horn is adjusted by the Manufacturer. During service the horn does not require any additional adjustment.

As the signal fittings under voltage are checked only in conjunction with the operation check of the mechanisms included in the systems provided with the signal fittings, the data concerning the methods of adjusting the limit switches are given in the sections of the Instruction dealing with the operation of corresponding mechanisms, units and devices.

As a rule, various types of light signal devices are cut in when the corresponding units and mechanisms are switched on by means of cutout and change over switches located on the instrument panels and electric boards.

Sound signal devices are switched on by means of switches, type B-45, mounted on the rheostat panel (Fig.83) of the right-seat pilot engine control panel and on the gunner-radio-operator's electric board (Fig.84).

AIRCRAFT INTERIOR LIGHTING

- For aircraft interior lighting the following fittings are used:
- (a) dome lights, type HC-45 and HCM-51;
  - (b) light fitting, type KMPCK-45;
  - (c) ultra-violet scale illumination lights, type APYQCH-45

In addition to this fitting extension lamps, type LM-10-36, are used to illuminate dark places on the aircraft.

Dome Lights, Types HC-45 and HCM-51

The dome light, type HC-45 (Fig.85) without a special lens but with reflector and a single-contact holder for the GM-25 lamp of 28 V and 20 W is intended for illumination of the pressurized cabins and unpressurized fuselage compartments. The bulb of the GM-25 lamp has a bowl of plate glass to protect the aircrew from the blinding effect of the lamp rays. Therefore, it is not recommended to use luminaires with other lamps (with open bulbs).

The inner surface of the dome light body which serves as a reflector is covered with white enamel or aluminum paint dispersing light. To ensure the proper operation of the luminaire, it is recommended to wipe the inner surface of the reflector with a clean moist piece of cloth or cotton wool.

- 135 -

In addition to the dome lights, type HC-45, for general illumination of landing gear compartments the aircraft is provided with small dome lights, type KM-51, which are used by the aircrew or attending personnel during repair or maintenance operations in the landing gear compartments. The HCM-51 dome lights differ from the HC-45 dome lights in that they are not provided with protection from the blinding effect of direct lamp rays as these dome lights are within the sight of the aircrew for a short time.

The main parts of the smaller HCM-51 dome light (Fig.86) are: body, protective transparent glass and reflector whose neck mounts a single-contact socket for the GM-24 lamp of 28 V and 20 W. The second pole for the HCM-51 dome light as well as for the HC-45 dome light is the dome light body and aircraft frame.

To replace the lamp in the HCM-51 dome light or the entire luminaire, first of all remove the protective glass. When mounting the protective glass, take care to see that the spring retaining the glass and the reflector is mounted correctly. The spring must pass between two lugs on the glass bowl. To retain the glass in position, bend the spring when it is weakened in the central part to ensure reliable attachment of the cap. For maximum glow keep the protective glass clean by wiping it regularly with a clean piece of cloth.

When using the HC-45 and HCM-51 dome lights, check to see that the union nut of the nipple on the dome light inlet pipe union is tightened up at all times, as loosening of the nut may result in poor contact and flickering or dying out of the lamp.

The location of the dome lights, types HC-45 and HCM-51, as well as the location of the switches designed for switching these dome lights on and off is indicated in Table 24.

Light Fitting, Type KMPCK-45

For illumination of panels, boards, dark places and instruments the aircraft is provided with fittings, type KMPCK-45, with a rheostat and a button, which are GM-30 lamps of 28 V and nominal current of 0.17 A.

The aircraft has ten cabin lamps altogether (two of them are mounted at the navigator's seat, three lamps - at the pilot's seats, two - at the navigator-radio operator's seat, two - at the gunner-radio-operator's seat and one - at the gunner's seat).

Cabin lamps, type KMPCK-45, are mounted on special hinged brackets (Fig.87) which make it possible to use these lamps for directed illumination of several places. On some of the hinged brackets the cabin lamps are mounted together with ultra-violet illumination fittings. If necessary the KMPCK-45 fitting can be removed from the hinged bracket or from its base and used as an extension lighting device for temporary illumination of some section in the cabin within the length of the cord.

The rheostat for adjusting the lamp light and the button by means of which the rheostat can be short circuited temporarily and the lamp caused to flash at full glow are located on the fitting case. By changing the distance between the lens and the lamp which is ensured by moving the cylindrical nozzle on the fitting it is possible to obtain more dissipated and more directed lighting.

The cabin lamp, type KMPCK-45, is switched on and off and its filament is adjusted by means of the rheostat handle made of colour plastic and mounted on the fitting body. Replace lamps in the KMPCK-45 fitting in the following manner:

- (1) turn out the stop screw fastening the cylindrical nozzle;
- (2) replace the lamp;
- (3) remove the cylindrical nozzle;
- (4) mount the cylindrical nozzle and turn in the stop screw. When fitting the stop screw, see that a metal washer is placed under the screw head.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




Table 24  
Location of NC-45 and NC-46 Dome Lights and Their Switches on Aircraft

No.	Type of dome light	Place of dome light installation	Place of switch installation	Note
1	NC-45	On the ceiling of the front pressurized cabin between frames Nos 4 and 5	On the dome light mounting panel	For the navigator
2	NC-45	On the ceiling of the front pressurized cabin at frame No. 9	On the dome light mounting panel	For the pilots
3	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 14	On the navigator-radar operator's electric panel	For lighting the hydraulic panel
4	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 20	On the starboard side on the bracket of the NC-4500 Inverter support	
5	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 24	On the navigator-radar operator's electric board	For lighting the bomb bay
6	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 28	On the navigator-radar operator's electric board	For lighting the bomb bay
7	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 42	On the navigator-radar operator's electric board	For lighting the bomb bay
8	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 46	On the navigator-radar operator's electric board	For lighting the bomb bay
9	NC-45	On the ceiling of the fuselage unpressurized portion at frame No. 49	On the navigator-radar operator's electric board	For lighting the bomb bay

11	NC-45	On the starboard side of the fuselage unpressurized portion at frame No. 62	On the starboard side at frame No. 62	
12	NC-45	On the ceiling of the rear pressurized cabin at frame No. 71	On gunner-radio-operator's electric board	For the gunner-radio-operator
13	NC-45	On the ceiling of the rear pressurized cabin at frame No. 71	On the gunner's electric board	For the gunner
14	NC-45	In the landing-gear port leg wall		
15	NC-45	In the landing gear starboard leg wall		
16	NC-45	In the nose leg wall on the starboard side at frame No. 20	On the navigator-radar operator's electric board	
17	NC-45	In the landing gear nose leg wall on the port side at frame No. 20		

50X1-HUM

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM



Extension Lamps, Type III-10-36

For additional lighting of dark places on the aircraft the latter is provided with extension lamps, type III-10-36, (Fig. 88). The III-10-36 extension lamp has a 10-a. cord and a filament lamp, type CM-15, of 26 V and 10 W. The extension lamps, type III-10-36, are switched on and off by means of the switch mounted on the handle of the lamp carbollite body.

The aircraft has three extension lamps altogether kept in special bags located in the following places: on the rear wall of the pilots' central console; on the wall of frame No.9 (starboard side) and in the rear pressurized cabin on the port side at frame No.75.

Extension lamps, type III-10-36, are connected to the aircraft mains by means of two-pin plugs. Receptacles, type 47K, for these lamps are mounted in various places of the aircraft. The aircraft has 13 receptacles, type 47K, altogether; four receptacles are mounted in the front pressurized cabin, four receptacles - in the fuselage unpressurized portion, two receptacles - in the engine nacelle compartments, two receptacles - in the landing gear main legs wells and a receptacle - in the rear pressurized cabin. The location of receptacles, type 47K, described in Table 25.

Table 25

Location of Plug Connector Receptacles 47K for III-10-36 Portable Lamps

No.	Place of receptacle installation	Note
1	On the navigator's right-hand console	For illuminator of the sight; it is switched on through a special rheostat from the set of this sight. The rheostat is mounted on the left-seat pilot's instrument panel.
2	On the pilot's central console	
3	On the port side at frame No.5	
4	On the wall of the upper part of frame No.9	For illumination of the aircraft sextant
5	On the bracket of the HO-4500 inverter tank (starboard side)	
6	On the fuel pump starboard junction box at frame No.35	
7	On the junction box of the extension lamp mounted on the distribution board of the port engine nacelle	
8	On the junction box of the extension lamp mounted on the distribution board of the starboard engine nacelle	

50X1-HUM

1	2	3
9	On the junction box of the extension lamp mounted on the port side at frame No.5 of the landing gear starboard leg well	
10	On the junction box of the extension lamp mounted on the starboard side at frame No.5 of the landing gear port leg well	
11	On the fuel pump junction box at frame No.49 (starboard side)	
12	On the starboard side at frame No.62	
13	On the port side of the rear pressurized cabin at frame No.72	

EM-12 Compass Illumination

For illumination of two compasses, type EM-12, mounted at the navigator's seat in the upper part of frame No.1 and at the pilots' seats on the cabin empty frame, special lamps are provided. The lamps are mounted right into the body of these compasses. Each compass illumination lamp is switched on by means of the switch, type B-45. The navigator's compass illumination switch is mounted on the navigator's upper electric board, while the pilots' compass illumination switch is on the pilots' central electric board. Both lamps are supplied by the triple-duty supply busbar through the automatic circuit breaker, type A3C-5, mounted on the right-seat pilot circuit breaker panel, that is the EM-12 compass illumination is ensured when the aircraft mains operates in all duties.

The triple-duty supply busbar supplies through the same A3C-5 circuit breaker one of the receptacles, type 47K, mounted on the pilots' central panel. The rest of the circuits of the light fitting are supplied from the normal supply busbars and are protected by the automatic circuit breaker mounted on panels and boards of the front and rear pressurized cabins. The extension lamps receptacles mounted outside the pressurized cabins and some lamps are protected by glass fuses.

Luminaire, Type APFOE-45

The cabin luminaire, type APFOE-45, is designed for ultra-violet illumination of the instruments and the control units (electric boards and instrument panels) to cause luminescence of the luminous compounds as well as for lighting purposes. Ultra-violet illumination is performed by means of special aircraft fluorescent mercury lamps of low pressure with rated power of 4 W, type J90-4A.

The luminaire, type APFOE-45, is used in conjunction with the PFO-45 rheostat designed to switch on the ultra-violet illumination lamp and to control its light intensity. The APFOE-45 fitting is provided with special twin-conductor in a common copper braiding which serves as a third conductor. One of the ends of the twin-conductor has white insulation, the other end has white insulation with a black thread. The conductor having white insulation with a black thread is excluded from the lamp connection circuit and is insulated. The braiding of the fitting cord is connected to the aircraft framework either directly or through the aircraft conductor, type EMB, connected to this braiding.

The lamp plastic body has a cylindrical nose with two light filters of black violet and a hinged base for the luminaire. The upper light filter may turn

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



together with the nozzle ring within 90°. By rotating the nozzle ring it is possible to:

- (a) match the slots of the both light filters; in this case white light of the lamp passes through these slots;
- (b) overlap the slots; in this case only ultra-violet rays pass through the violet light filters. The ultra-violet rays cause luminescence of luminous compounds.

Most of the luminaires, type AP790E-45, are mounted on special hinged brackets (See Fig. 87) which make it possible to use this lamp for directed illumination of several places. On some of the hinged brackets the luminaires are mounted together with the KUCPK-45 fitting. If necessary, the fitting may be removed from the hinged bracket or from its base used as an extension luminaire for temporary lighting of some area in the cabin as far as the cord permits.

The aircraft is provided with AP790E-45 fittings with rheostats, type P790-45. Three AP790E-45 fittings are mounted in the rear pressurized cabin, the rest of them are installed in the front pressurized cabin. The arrangement of the ultra-violet illumination devices and P790-45 rheostats is shown in Table 26.

Table 26  
Arrangement of AP790E-45 Luminaires and P790-45 Rheostats

No.	Place of luminaire installation	Place of rheostat installation	Note
1	2	3	4
1	On the starboard side of the front pressurized cabin on frame No. 2	On the navigator's upper electric board	For lighting the sight, the instrument panel and the navigator's right-hand console
2	On the ceiling of the front cabin on frame No. 3	Same	
3	On the ceiling of the front cabin at frame No. 4	Same	
4	On the right-seat pilot's steering wheel	On the right-seat pilot's engine control panel	For lighting the pilots' instrument panel
5	Same	Same	
6	On the left-seat pilot's steering wheel	On the left-seat pilot's engine control panel	Together with the KUCPK-45 fitting it serves to light the pilot's instrument panel
7	Same	Same	
8	On the port side at frame No. 8	Same	

50X1-HUM

1	2	3	4
9	On the ceiling of the front cabin on frame No. 8	On the left-seat pilot's engine control panel	Together with the KUCPK-45 fitting it serves to light the pilots' upper electric board and the fuel supply panel
10	On the starboard side at frame No. 8	On the right-seat pilot's engine control panel	Together with the KUCPK-45 fitting it serves to light the right-seat pilot's panel
11	On the fuel supply panel	On the right-seat pilot's engine control panel	To light the pilot's central panel
12	On the left-hand side of the upper blister	On the navigator-radar operator's instrument panel	Together with the KUCPK-45 fitting it serves to light the instrument panel and the navigator-radar operator central panel
13	On the right-hand side of the navigator-radar operator's central panel	Same	Same
14	On the port side of the rear pressurized cabin at frame No. 74	On the gunner's electric board	For lighting the instrument panel, board and the gunner's panel
15	On the starboard side of the rear cabin at frame No. 70	On the gunner-radio-operator's electric board	Same
16	On the rear cabin circuit breaker panel on the port side at frame No. 71	Same	Same

Basic Specifications of the P790 Set

1. Total resistance of the P790-45 ..... 35 ohms
2. Rheostat resistance in the cutoff position ..... 22 ohms
3. Normal current of lamp operating duty ..... 0.35 A
4. Lamp resistance with the rheostat cut off ..... 0.5 to 0.6 A
5. Luminous compound brightness adjustment range of the P790-45 rheostat ..... from 150 to 30%

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

6. F90-4A lamp flashes up .....

7. Lamps which were on for not less than 10 min. at nominal current of 0.35 A flash up again on switching .....

Switching On F90 Lamp:

The F90 lamp is switched on by means of the rheostat, type FV90-45. In the idle position the rheostat handle must be set to the OFF (BKKADPEHO) position at all times. The F90-4A lamp is switched on automatically in no more than 12 sec. after the rheostat is set to the ON (BKKADPEHO) position; it is necessary to set the FV90-45 rheostat handle to the right as far as it will go. On switching on the lamp, adjust as required the brightness of the scale and stencil covered by luminous compound or the degree of illumination during operation with the light filter open. The rheostat handle being turned to the left, the brightness decreases, the handle being turned to the right, the brightness increases.

Replacement of Lamp in APV90E-45 Fitting

1. Remove the cylindrical nozzle with the light filters. To detach the cylinder from the body, press with the finger the lower part of a special pin riveted to the cylinder. This done, turn the fitting cylinder counter-clockwise and remove it from the body.
2. Replace the lamp. When fitting a new lamp, type F90-4A, bear in mind that the lamp has a bayonet base with pins (type 2C-15A-1); the base pins are located at various height due to which the lamp can be inserted into the socket only in one definite position ensuring correct polarity of switching.
3. Fit the cylindrical nozzle with the light filters. When fitting it on the body turn the cylinder clockwise until the elastic pin clicks in the hole.

EXTERIOR LIGHTING

The aircraft exterior lighting consists of the following light fittings:

- (a) taxiing lights, type 9P-100;
- (b) landing lights, type H9CB-45;
- (c) formation lights, type HCCO-45;
- (d) navigation lights, type HAHO-45, and IC-39.

100% is assumed to be the brightness of luminous compound illuminated by a lamp operating under nominal conditions (at 0.35 A in no more than 12 seconds after switching).

In no less than 2 minutes from the moment of switching.

Taxiing Lights, Type 9P-100

The aircraft taxiing lights, type 9P-100, are designed for illumination of the ground during taxiing in the night time. For the landing gear nose leg the landing light is mounted right on the landing gear strut while for the landing gear main legs the landing lights are mounted on the struts.

The taxiing light, type 9P-100, (Fig. 89) consists of a base with a reflector and a single-contact socket for the CM-21 lamp of 27 V and 2.7 A. The landing lamp protective glass which is a colourless transparent disperser ensures angle of dispersion in the horizontal plane equal to 30°. The maximum luminous intensity of the taxiing light is 9000 candles.

With the aid of the adjustable bracket each taxiing light can be set to the position which ensures illumination of part of the landing strip at a distance of 15 or 20 m. from the pilots' cabin in the direction of flight. The taxiing light is fixed in the required position by means of a nut and a lock nut.

All the three taxiing lights are switched on simultaneously with one switch, type B-45, mounted on the pilots' upper electric board (Fig. 90).

Landing Lights, Type H9CB-45

To illuminate the place of aircraft landing in the night time, the aircraft is provided with two retractable landing lights, type H9CB-45, installed in the lower part of the nose unpressurized section of the fuselage at frame No. 13. The retractable part of the landing light consists of a casing and a special reflector lamp, type CM-2M, of 28 V and 600 W. The CM-2M lamp consists of a filament lamp proper, a reflector and a protective glass.

The landing light control electric mechanism, type MHQ-2 consists of a reversible electric motor of series excitation, a reducer and a cutting off contact device.

The landing light is supplied from a single-line mains; the second pole for the light and for the electric drive is the landing light body and the aircraft frame. The light is switched on automatically when the landing light is extended. Switching off is performed automatically too when the landing light is retracted.

The landing lights are controlled by means of a switch, type ZHM-45, from the pilots' upper electric board (Fig. 91).

Specifications of Landing Light, Type H9CB-45

1. Maximum luminous intensity ..... not less than 350,000 candles
2. Landing light angle of dispersing:
  - in the horizontal plane ..... not less than 12°
  - in the vertical plane ..... not less than 8°
3. Landing light extension angle ..... 86°30' ± 30'
4. Time required for extension or retraction of the landing light ..... not in excess of 12 sec.
5. Permissible continuous glow of the landing light ..... not in excess of 5 min.
6. CM-2M lamp service life guaranteed by the manufacturer ..... 5 hours of burning
7. Operating voltage range for the MHQ-2 electric mechanism ..... 24 to 30 V

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



- 144 -

8. Current consumed by the electric mechanism ..... 2.8 A  
 9. Maximum moment ..... 220 kg-cm  
 10. Duty of the electric mechanism operation ..... intermittent  
 11. Weight of the landing light with the electric mechanism ... 3.5 kg

The landing lamps, type EPCB-45, installed on the aircraft in the extended position ensure illumination of part of the landing strip at a distance of 40 to 60 m. from the pilots' cabin in the direction of flight.

Maintenance of Landing Lights, Type EPCB-45

To check the operation of the landing lamps on the ground, it is permitted to switch them on for not more than 5 minutes. The landing light may be switched on again only after they have been cooled during not less than 5 minutes.

Avoid shaking and knocking to prevent crack formation and failure of the landing lights.

When checking the landing light in a workshop the supply voltage must not exceed the nominal value of 28 V, otherwise the lamps may burn out.

To prevent decrease in the landing light luminous intensity, clean the part of the lamp surface which serves as a protective glass.

Replacement of CHP-2M Lamp

The CHP-2M lamp is a changeable element of the landing light and is replaced by the unit technician in the event of failure. To replace the lamp in the EPCB-45 landing light, do as follows:

1. By means of the ZHM-45 switch extend the landing light with the burnt out lamp; at this the circuit breakers, types ASC-5 and ASC-30, mounted on the left-seat pilot circuit breaker panel for the serviceable landing light must be switched off.
2. Switch off the supply circuit breaker, type ASC-30, of the unserviceable landing light on the left-seat pilot circuit breaker panel.
3. Unscrew four screws 3 (Fig. 91).
4. Remove retaining ring 4 and draw the lamp out of the streamlined case.
5. Disconnect the supply conductors from the lamp terminals and remove the lamp.
6. Installation of a new lamp is performed in the reverse order.

When replacing the lamp, see that the rubber chock absorbers supporting the lamp bowl in the case are intact.

Re-adjustment of Turning Units of the M13-2 Electric Mechanism Sector

The M13-2 electric mechanism is adjusted for a turning angle of the sector (landing light) equaling  $76^{\circ} \pm 30'$ . For the aircraft, model TP-16, the landing light extension angle of  $86^{\circ}30' \pm 30'$  is necessary. Therefore, when replacing the EPCB-45 landing light during service, bear in mind that it is impossible to mount a new light on the aircraft without preliminary re-adjustment of the sector turning angle of the M13-2 electric mechanism.

Re-adjustment of the electric mechanism is performed in the following manner:

1. Remove the seal and the check wire, turn out the screws fastening the cover to body 2 and turn the cover aside according to Fig. 92.
2. Loosen screw 3 and by moving limit switch 4 together with plate 5 along guide grooves see that the contacts of limit switch 4 are opened by stop 6 at an angle of the sector (landing light) turning equal to  $86^{\circ}30' \pm 30'$ .

- 145 -

3. Tighten up screw 3 again.

4. Check the operation of the electric mechanism.

5. Place cover 1 in position, turn in the screws fastening the cover to the body and seal the electric mechanism again.

6. Make corresponding entries in the Certificate of the M13-2 electric mechanism.

The re-adjustment of the electric mechanism should be made by trained personnel, no damage to the inner connecting conductors, limit switches and other elements of the electric mechanism is permitted.

Installation of EPCB-45 Landing Light on Aircraft

Install the landing light on the aircraft so that the body of the landing light electric mechanism is pointed in the direction of flight while the dimmer located inside the lamp and designed for screening the direct rays looks with its prominent portion towards the aircraft centre line.

The landing light is fastened in position with 15 screws 4 mm in diameter passing through the holes in the landing light flange.

Formation Lights, Type BCCO-45

Formation lights, type BCCO-45, are used during group flights in the night time or under conditions of poor visibility to allow the aircraft flying in the rear to form up and to keep their proper places in formation.

When forming up above the leading aircraft, the upper formation lights are used; when forming up below the leading aircraft, the lower formation lights are used. The upper and the lower formation lights are installed over the axis along the fuselage and over the wing span on the landing gear fairings so that during the flight the illuminated aircraft resembles the letter F. The formation light attachment is made flush with the skin by means of bolts and self-locking anchor nuts. The upper and lower formation lights are switched on by means of corresponding switches, type B-45, mounted on the pilots' upper electric board (See Fig. 91).

The BCCO-45 formation light (Fig. 92) consists of the following main parts: aluminum body, the inner electrically polished surface of which serves as a reflector of the socket holder with a single-contact socket mounted in it for the CH-30 lamp of 28 V and 0.17 A, and a prismatic light refractor of blue polystyrene serving as a light filter at the same time.

Specifications of BCCO-45 Formation Lights:

1. Maximum luminous intensity ..... not less than 5.5 colour candles, with the formation light in the horizontal position; it is directed backward at an angle of  $45^{\circ}$  to  $50^{\circ}$  up from the direction opposite to the direction of flight
2. Lights visibility range in the direction of maximum luminous intensity in the night time in clear weather ..... about 3 km.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

3. Angular width of luminous beam ..... about 20°

This arrangement of formation lights enables the aircraft flying behind somewhat higher to keep its place in the formation taking bearing on the lightest of the leading aircraft.

**Maintenance of Aircraft Formation Lights, Type HCCO-45**

To avoid decrease in the formation lights luminous intensity, clean the reflector and light refractor from dirt with a clean piece of soft cloth or cotton wool. It is prohibited to wipe the aluminum reflector or plastic refractor with coarse material.

**CAUTION:** The HCCO-45 formation lights are designed for operation only during flights. To prevent the plastic light refractor from overheating and damage, switching on the lights for a long time during parking is not permitted.

Polystyrene of which the light refractor is manufactured swells and cracks almost in all solvents - acetone, ethyl-acetate, ether, chloroform, benzol, benzoin (containing benzol), toluene.

The vapours of these solvents also produce a harmful effect on plastic: the solvents are absorbed by polystyrene and then slowly evaporate causing the appearance of irregular dimming in the light filter and the formation of small cracks near the surface.

If such a light filter is held up against the light, some silvery brilliancy may be noticed in the plastic.

These phenomena considerably reduce the coefficient of the light filter total passing capacity, its transparency and, therefore, change the light distribution of the HCCO-45 formation lights. Therefore, to avoid harmful influence of solvent vapours upon the plastics and dry the bomb bay doors of the light refractors of the HCCO-45 formation lights mounted on them. If the formation lights are already mounted, prior to painting remove the light refractors and tightly close the reflectors with some plug. To protect polystyrene refractors, take care to see that they are not splashed with solvents.

**Replacement of HCCO-45 Fitting and Replacement of Lamp in the Fitting**

To remove the HCCO-45 fitting, turn out the fitting attachment screws and disconnect the plus conductor.

When mounting a new formation light, see that the installation is precise: the glass passing through the lamp axis perpendicularly to the refractor prism must be parallel to the aircraft longitudinal axis and the socket holder must face forward (upward for the lower lights) and forward with flight. The formation lights are fastened in position with five screws 3 mm in diameter (passing simultaneously through the holes and anchor nuts in the aircraft frame) in the body of dome lamp 1 (See Fig. 93), rubber gasket 3, light refractor 4 and retaining ring 5 holding the refractor in place. Thus, the formation light is assembled simultaneously with its installation on the aircraft. The asymmetrical location of attachment holes in the formation light excludes incorrect position of the blue light refractor in relation to the reflector, nevertheless, see that the refractor prism look inside the formation light. If the locating diameter of the HCCO-45 formation light dome lamp does not correspond to the out in the aircraft frame recess, it is permitted to fit washers ensuring

light under the dome lamp attachment bolts and the recess bottom. In this case the dome lamp may project in relation to the skin outer surface by up to 1 mm. The dome lamp installed, fill the clearance between ring 5 and the aircraft skin with packing sealing thiokol putty.

To replace the lamp in the HCCO-45 fitting, do as follows:

1. Turn out the attachment screws of the formation light fitting, remove the retaining ring and the light refractor.
2. Replace the lamp.
3. Mount the light refractor and the retaining ring in place, screw in and tighten up the attachment screws.

**Navigation Lights, Type EARO-45**

The navigation lights, type EARO-45, are designed to be shown by aircraft in the air during flight and on the ground during taxiing.

The fairing of each wing mount front and rear navigation lights. Two red lights, type EARO-45, are located on the port wing-tip fairing, two green lights are located on the starboard wing-tip fairing. The navigation lights are installed in recesses closed with plexiglass and are fastened in position with three bolts, 3 mm in diameter. The fitting is provided with lamps, type CM-22, of 28 V, 24 W with luminous intensity of 21 candles.

The navigation light, type EARO-45, has asymmetrical light distribution. The maximum luminous intensity in the direction of flight is not less than 33 colour candles which ensures the visibility range in the night time of about 5 km under normal conditions. In the horizontal plane light is emitted within 110° outside from the direction of flight; in the vertical plane - within 50° up and down from the horizon.

**Replacement of Lamp in EARO-45 Fitting**

1. Turn out the plexiglass fairing attachment screws and remove the fairing.
2. Turn out screw 7 fastening the light filter (Fig. 94) and remove the glass.
3. Unscrew the lamp and replace it.

When replacing the lamp, take into consideration that the pins of the lamp base are located at various heights; this makes it possible to insert the lamp into the socket only in the definite positions: the amalgamated surface of the bulb must face screw 7.

4. Mount the glass light filter and fasten it in position with screw 7.
- When mounting the light filter, it is recommended that the glass end face should be slightly covered with sealing thiokol putty to prevent moisture from getting inside the device. During the assembly take care to see that packing gasket 2 is fitted under the glass and lead washer 6 is fitted under the head of attachment screw 7, otherwise the glass might break when the screw is being tightened. After the light filter has been installed, it is recommended to cover the head of screw 7 with putty or paint.
5. Mount the plexiglass fairing and fix it with screws.

**Removal of EARO-45 Fitting**

1. Remove the plexiglass fairing.
  2. Turn out the light filter attachment screw and remove the glass.
  3. Turn out the three fitting attachment screws.
  4. Unscrew socket union nut 4 and disconnect the supply conductor.
  5. Remove the EARO-45 fitting.
- Installation of the navigation light is performed in the reverse order.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM

- 148 -

Tail Light, Type XE-29

In the fuselage tail section the rear fairing lower part mounts a tail navigation light, type XE-29, with the CM-15 lamp of 26 V, 10 W. The tail light is switched on by means of the same switch, type B-45, which is designed for switching on wing-tip navigation lights, type BHO-45. The switch is mounted on the pilots' upper electric board (See Fig. 90).

Replacement of Lamp in the XE-29 Fitting

1. Unscrew the attachment screws of the wire lattice and remove the lattice.
2. Loosen the glass shade attachment screws 7 (Fig. 95) and remove the shade.
3. Replace the lamp.
4. Mount the glass shade in position and tighten up the screws.
5. Fit the wire lattice.

Removal of XE-29 Fitting

1. Remove the wire lattice.
2. Remove tail light fitting attachment screws 7 and remove the fitting in the recess in the fairing bracket.
3. Disconnect the supply conductors.

Installation of the tail light fitting is performed in the reverse order.

FIRE FIGHTING EQUIPMENT AND FIRE WARNING ELECTRIC SYSTEM

With the aid of the electric system:

- (1) CO<sub>2</sub> is delivered to the area where fire occurs in the aircraft;
- (2) fuel delivery to the engines is cut off;
- (3) the fuel system is being filled with neutral gas.

The aircraft electric system includes the following units:

- fire-sensitive unit TN - 28 pieces;
- electromagnetic shut-off cocks unit (unit 635900) - 2 pieces;
- push-button type lamp with a red light filter - 6 pieces;
- electromagnetic air valve 2512800 - 2 pieces;
- relay, type PU-2 - 1 piece;
- warning lamp with a green light filter - 2 pieces;
- fuel cross-feed cock with the MKK-2 electric mechanism - 1 piece;
- firing mechanism - 10 pieces (four of them are intended for CO<sub>2</sub> cylinders and six - for neutral gas cylinders);
- CO<sub>2</sub> cylinder switch button SK - 1 piece;
- fuel shut-off cock with the MKK-2 electric mechanism - 2 pieces.

The units of the system are located in the following places:

1. Fire-sensitive units on special brackets:
  - (a) in the area of the fuselage nose section fuel tanks: two fire-sensitive units are located on frame No. 17, one unit is located on frame No. 22, one unit is located on frame No. 25 and four units are located on frame No. 33;
  - (b) in the area of the fuselage tail section fuel tanks: two units are located on frame No. 50 and two - on frame No. 56;
  - (c) on the engines under the collapsible cowls: four fire-sensitive units are located on each engine;
  - (d) in the area of fuel tanks between ribs Nos 3 - 4, 6 - 7, 8 - 9 and 12 - 13 along the rear wall of the wing second longeron - four fire-sensitive units are located in between each pair of the ribs.

- 149 -

2. The electromagnetic fuel shut-off cocks units are located on the ceiling of the bomb bay between frames Nos 37 and 38.

3. CO<sub>2</sub> cylinders switching and warning push-button type lamps (Fig. 112) are mounted on the pilots' upper electric board.

4. The electromagnetic air valve 2512800 is mounted on the engine.

5. The relay, type PU-2, and the warning lamps with green light filters are located on the pilots' upper electric board.

6. The fuel cross-feed cock with the MKK-2 electric mechanism is located on frame No. 33.

7. The firing mechanism designed for opening the CO<sub>2</sub> cylinders is installed on frame No. 22, that designed for opening the neutral gas cylinders is mounted on frame No. 15.

8. The SK button for switching on the CO<sub>2</sub> cylinders is located on the pilots' upper electric board.

9. The starboard and port engines fuel shut-off fire cocks are installed on the engines behind the fire wall.

Specifications of Electric Units Included in System

1. Fire-sensitive unit TN (Fig. 113):	
operation range .....	140 to 170°
insulation .....	not less than 2 megohms
2. Fuel shut-off cocks unit:	
operating pressure .....	up to 100 kg/cm <sup>2</sup>
nominal voltage .....	27 V
current on switching .....	not in excess of 7 A
current with cocks open .....	0.5 A
time unit is energized .....	not in excess of 20 min.
minimum pulling effort at the beginning of travel with 6.5 mm clearance, at nominal voltage and time unit is energized not exceeding 15 sec. .... 9 kg	

The Specifications of the MKK-2 mechanism are given in the Section "Fuel Pumps Control and Fuel Quantity Measuring Electric System".

Checking Installation and Operation of Fire-Fighting Equipment Electric System

Carry out the outside inspection with the aircraft mains de-energized. During the inspection make sure that:

1. The fire-sensitive units attachment is in proper condition, the diaphragms are free from dents and are not deformed, there are no foreign matter and no moisture between the body and the fire-sensitive unit diaphragm.
2. The glass of the push-button type lamp is not broken and is securely fixed in position.
3. The CO<sub>2</sub> cylinder button, type SK, operates without jamming and is in good repair.
4. The firing mechanisms on the discharge bonnets of the CO<sub>2</sub> and neutral gas cylinders are screwed up and locked with the III-3 explosive charges inserted (Fig. 98).

SECRET

NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM

- 150 -

**CAUTION:** During service it is prohibited to touch the fire-sensitive coil contact screw with the nut, to re-adjust the contact screw and press the diaphragm.

5. The plug connectors of the fuel shut-off cocks units must be connected in compliance with the marking (the plug connector bodies and the fuel shut-off cocks units are marked) and locked with wire.

Checking Operation of Energized System

**CAUTION:** The neutral gas switch, type B-45, is turned on only when neutral gas is delivered to the system.

Neutral Gas HT

The system is checked by connecting an extension pilot lamp to the firing mechanisms. For this:

1. Unscrew all the six firing mechanisms from the neutral gas cylinder discharge bonnets and remove the explosive charges.
2. Switch on the neutral gas circuit breaker on the right-seat pilot circuit breaker panel and turn on the B-45 switch on the pilots' upper electric panel; in this case the extension pilot lamp whose one conductor is connected to the hot and the other conductor is connected to the mid contact of the firing mechanism must be on.
3. The check up over, turn off the neutral gas switch, type B-45, on the pilots' upper electric board.
4. Charge the firing mechanisms with explosive charges, screw them to the neutral gas cylinder discharge bonnets and lock the firing mechanism nuts with wire.

Fire-Fighting System

1. On the right-seat pilot circuit breaker panel switch on two starboard and port engine tanks fire warning circuit breakers, type ASC-15.

**CAUTION:** The CO<sub>2</sub> cylinder opening circuit breaker, type ASC-10, must be in the OFF ( ЗАКРЫТО ) position.

2. On the pilots' upper electric board turn on the fire-fighting system switch; the lamp must be dead.
3. Press in turn all the push-button type lamps mounted on the pilots' upper electric board. Each push-button type lamp must flash up and the cock of the fuel shut-off cocks unit corresponding to this lamp must operate. Simultaneously the CO<sub>2</sub> cylinder opening relay, type PH-2, must operate. Prior to each pressing of the push-button type lamp, turn off the fire-fighting system switch and in 2 seconds turn it on again; the push-button type lamps must go out. On pressing the push-button type lamp of the starboard and port engine besides flashing of the push-button type lamp and operation of the PH-2 relay, the electromagnetic air valve of the shutter in the system designed for scavenging the space under the engine cowd with air must operate.
4. On the left-seat pilot circuit breaker panel switch on the air control circuit breaker and press one of the push-button type lamps. On throttling down one of the engines the blow-off hand must operate for closing and the shutter of the undercowd reverse air scavenging system must get closed.

- 151 -

Fuel Shut-Off and Engine Fuel Cross-Feed Cocks

1. On the right-seat pilot circuit breaker panel switch on two fuel shut-off cock circuit breakers, type ASC-5, two fuel pump operation warning system circuit breakers, type ASC-2, and the fuel cross-feed cock circuit breaker, type ASC-5.

2. On the pilots' upper electric board set the fire shut-off cock switches and the fuel cross-feed control switch to the OPEN ( ОТКРЫТО ) position; in this case the fuel shut-off cocks green warning lamps (OPEN) on the pilots' upper electric panel must flash up. With the cock switches in the CLOSED ( ЗАКРЫТО ) position the warning lamps must go out.


The system operation should be checked during the engine operation by the aircraft technician or mechanic, who opens the fuel shut-off cocks prior to engine starting and closes them after switching them off.

Possible Faults of Fire-Fighting System and Their Elimination

Fault	Cause	Remedy
1	2	3
One of the push-button type lamps is on when there is no fire	(a) Closing of contacts in the fire-sensitive unit	Check the entire group of the push-button type lamp fire-sensitive unit. On detecting a fault inside the fire-sensitive unit replace the latter
The push-button type lamp continues glowing after pressing the lamp when turning the fire-fighting system switch on and off	(b) Closing of contacts inside the push-button type lamp  The change-over system in the fuel shut-off cocks unit is out of repair	Replace the push-button type lamp  Replace the fuel shut-off cocks units. <b>Note:</b> The defects eliminated, check the firing mechanisms and if they have operated, replace the explosive charges
The warning lamp is dead with the fuel shut-off cocks open	(a) The lamp is burnt out  (b) The adjustment of the limit switches in the HSK-2 electric mechanism is disturbed  (c) The pump operation warning system circuit breaker, type ASC-2, is not switched on on the right-seat pilot circuit breaker panel	Replace the burnt out lamp  Replace the fuel shut-off cock  Switch on the circuit breaker. <b>Note:</b> To determine the fault of the fuel shut-off cocks warning system,

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



1	2	3
<p>The fuel shut-off cocks or the cross-feed cock fall to open or to close</p>	<p>(a) The fuel shut-off cocks circuit breaker, type ASC-5, or the cross-feed cock circuit breaker, type ASC-5, on the right-seat pilot circuit breaker panel is OFF</p> <p>(b) The connecting wires are broken, or there is no contact in the plug connector</p> <p>(c) The electric mechanism, type MK-2, is out of repair</p>	<p>disconnect the plug connector from the MK-2 electric mechanism and connect terminal 4 to the aircraft frame by means of a conductor; if the warning lamp is serviceable and the wiring is in good repair, the warning lamp must be on</p> <p>Switch on the circuit breaker</p>
<p>The fuel shut-off cocks or the cross-feed cock let the fuel through in the closed position</p>	<p>The adjustment of the limit switches of the MK-2 electric mechanism is disturbed</p>	<p>Detect the places of damaged wiring by ringing out the wires and checking the damage. This done, check the operation</p> <p>Replace the MK-2 electric mechanism with the cock</p> <p>Replace the MK-2 electric mechanism with the cock</p>

FUEL PUMPS CONTROL AND FUEL GAUGE ELECTRIC SYSTEM

- The system is designed for:
- (a) checking the total quantity of fuel in five tank groups;
  - (b) checking the quantity of fuel in each group of tanks separately;
  - (c) automatic control of the fuel consumption sequence so as to preserve the aircraft centering within permissible limits during flight and landing;
  - (d) manual control of the fuel pumps when the automatic control of fuel consumption fails;
  - (e) warning of fuel available for 30-minute and 15-minute flight;
  - (f) aircraft fuel filling control;
  - (g) measuring the amount of fuel consumed by each engine;
  - (h) signalling of the fuel pump operation of each group of tanks separately.

The system includes the following instruments and units:

1. Capacitive fuel level gauge, type C37C-60M.
- The fuel level gauge set includes:
- indicators ..... 2 pieces
  - measuring device amplifiers, type FI-6EM ..... 2 pieces
  - automatic units, type RAC-52-12 ..... 2 pieces
  - switches, type IT-7 ..... 2 pieces
  - main transmitters (with signalling) ..... 10 pieces
  - additional transmitters (with signalling) ..... 5 pieces
  - additional transmitters (without signalling) .. 2 pieces
2. Warning fuelmeter, type PFO-16 (two sets). The fuelmeter set includes:
    - transmitter ..... 1 piece
    - indicator ..... 1 piece
    - thyatron interrupter, type IT-51T ..... 1 piece
  3. Fuel pump, type SHR-T, with the MB-650A electric motor ..... 12 pieces
  4. Contactor, type K-30 ..... 12 pieces
  5. Relay, type PI-2 ..... 10 pieces
  6. Relay, type PI-6 ..... 1 piece
  7. Warning lamps, type CHH-51:
    - with a red light filter ..... 4 pieces
    - with a blue light filter ..... 4 pieces
    - with a green light filter ..... 12 pieces
  8. Fuel-pressure warning unit, type CA-3 TF ..... 12 pieces
  9. Resistor, type HO-10-5 ..... 8 pieces

Arrangement of Electric Units Included in the System

1. The fuel pump operation warning lamps and control switches are located on the fuel supply electric board (Fig. 99).
2. The arrangement of fuel pumps, fuses, switching contactors, HO-10-5 resistors and PI-3 relay designed for changing the fuel pumps over to the forced conditions is indicated in Table 27.
3. The fuel gauge amplifiers (Fig. 100) are located on the navigator-radar operator's rack on the starboard side.
4. The automatic units (Fig. 101) are mounted in the landing gear nose log on frame No. 22.
5. The 30- and 15-minute flight fuel remain warning lamps are located on the left-seat pilot instrument panel and on the fuel supply panel.
6. The location of the fuel level gauge transmitters is shown in Table 28.
7. The fuel-level gauge switches and indicators are installed on the right-seat pilot instrument panel (Fig. 102).
8. The fuel gauge A.C. supply fuses, type CH-1, are mounted on the navigator's upper electric board.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

Table 27

Arrangement of Fuel Pumps and Units and Their Switching by Groups

Name of tank group	Place of installation					
	1	2	3	4	5	6
1st group	No. 2 - 2 pieces	No. 2 - 2 pieces	HI-75 fuse in the additional pump junction box of tank No. 2 (on frame No. 35)	Pump switching contactor	HO-10-5 resistor	Pump HI-2 function relay
1st group	left	left	HI-75 fuse in the fuel pumps left junction box (on frame No. 33)	K-50H contactor in the additional pump junction box of tank No. 2	In the additional pump junction box of tank No. 2	In the additional pump junction box of tank No. 2
1st group	right	right	Two HI-75 fuses in the fuel pumps right junction box (on frame No. 49)	K-50H contactor in the fuel pumps left junction box Two K-50H contactors in the fuel pumps junction box	In the fuel pumps left junction box Two resistors in the fuel pumps junction box	In the fuel pumps left junction box Two resistors in the fuel pumps junction box
2nd group	left	left	HI-75 fuse in the fuel pumps junction box (on frame No. 49)	K-50H contactor in the fuel pumps junction box	In the fuel pumps junction box	In the fuel pumps junction box
2nd group	right	right	HI-75 fuse in the fuel pumps starboard junction box (on frame No. 33)	K-50H contactor in the fuel pumps right junction box	In the fuel pumps right junction box	In the fuel pumps right junction box
3rd group	No. 10 - 1 piece	No. 10 - 1 piece	HI-50 fuse in the distribution panel of the port and starboard engines	One K-50H contactor in the landing gear junction box and one contactor in the fuel pumps junction box (in the port and starboard landing gear wells)	In the landing gear junction box and the fuel pumps relay	In the landing gear junction box and the fuel pumps relay
4th group	No. 16 - 1 piece	No. 16 - 1 piece	HI-50 fuse in the distribution panel of the left and starboard engines	One K-50H contactor in the landing gear junction box and one contactor in the fuel pumps relay junction box (in the port and starboard landing gear wells)	In the landing gear junction box and the fuel pumps relay	In the landing gear junction box and the fuel pumps relay
5th group	No. 6 - 1 piece	No. 6 - 1 piece	HI-50 fuse in the fuel pumps left junction box (on frame No. 33)	K-50H contactor in the fuel pumps left junction box	In the fuel pumps left junction box	In the fuel pumps left junction box
5th group	right	right	HI-50 fuse in the fuel pumps right junction box (on frame No. 33)	K-50H contactor in the fuel pumps right junction box	In the fuel pumps right junction box	In the fuel pumps right junction box

50X1-HUM

- 155 -

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 156 -

Table 28  
Arrangement of Fuel Level Gauge Transmitters

Name of tank group		Transmitters	
		main transmitters in tank No.	additional transmitters in tank No.
1st group	left	2	-
	right	5	-
2nd group	left	4	-
	right	3	3
3rd group		10	7
4th group		16	12
5th group		6	6

9. The fuel level gauge D.C. supply circuit breaker, type ASC-2, is located on the right-seat pilot circuit breaker panel.
10. The automatic unit A.C. supply fuses, type CH-1, are mounted on the navigator's upper electric board.
11. The automatic unit D.C. supply circuit breaker, type ASC-5, is located on the right-seat pilot circuit breaker panel.
12. Right- and left-hand circuit breakers, type ASC-2, of the 4th and 5th fuel pump groups are located on the right-seat pilot circuit breaker panel.
13. The fuel consumption control switch AUTOMAT-MANUAL (ABTOMAT-PPYBOM) relay is in the fuel-level gauge junction box on frame No. 22.
14. The fuel-pressure warning units, type CA-317, cutting in warning lights, are located near each fuel pump; they are connected to the fuel line.
15. The FPC-16 fuel-level gauge indicators are mounted on the pilots' central instrument panel.
16. The FPC-16 fuel-level gauge transmitters are mounted in the fuel lines of the engine lower part.
17. The thyristor interrupters, type BT-51, are located on the navigator-radar operator right-hand rack (Fig. 103).

Checking Operation of Fuelmeter System on Aircraft

Prior to checking the fuel pumps automatic control and fuelmeter system make certain that on the navigator's upper electric board CH-1 fuses are mounted in the fuel-level gauge A.C. supply circuits.

1. The aircraft mains must be supplied with 28 or 28.5 V D.C. from the ground power supply and with 115 V A.C. from the aircraft operating or standby inverter, type HO-4500.
2. Switch on two FUEL-LEVEL GAUGES (TOLEBOMEPH) circuit breakers, type ASC-2, on the right-seat pilot circuit breaker panel.

- 157 -

3. Cut in two port and starboard engine fuel-level gauges supply switches, type ZH-250, on the right-seat pilot's instrument panel.

4. Set the handle of the port fuel-level gauge switch to the 1 position. In two or three minutes the pointer of the port fuel-level gauge indicator must indicate the amount of fuel filled in the 1st tank group with permissible error of 2320 lit. by the lower scale marks. Press the button on the indicator case; the indicator pointer must stop at the zero scale mark, the permissible error being 2160 lit.; then release the button; in this case the pointer must indicate the amount of fuel filled in the 1st tank group.

After the fuel-level gauge has been checked with the switch in the 1 position, perform checking with the switch in the 2, 3, 4 and 5 positions. The instrument pointer must be in the same position as with the switch in the 1 position.

5. Set the handle of the port fuel-level gauge switch to the TOTAL (CPYMA) position; the instrument pointer must indicate the total amount of fuel filled in all the five tank groups with permissible error of 2960 lit. by the upper scale marks.

Press the button on the indicator case; the indicator pointer must stop at the scale zero mark; then release the button; the pointer must read the total amount of fuel in all the five tank groups.

6. Set the handle of the port fuel-level gauge switch to the 1 position and press the GROUP CHECKING (HPOBEPMA TPYB) button on the port group fuel-level gauge amplifier. The pointer of the fuel-level gauge left indicator must indicate the amount of fuel in the group (6000 lit.) with permissible error of 200 lit. After the fuel-level gauge has been checked with the switch in the 1 position, perform checking with the switch in the 2, 3, 4 and 5 positions; the instrument pointer must be in the same position as with the switch in the 1 position.

7. Set the port fuel level gauge switch to the TOTAL (CPYMA) position and press the TOTAL CHECK (HPOBEPMA CPYMA) button on the port group fuel-level gauge amplifier. The pointer of the fuel-level gauge port indicator must indicate 16,000 lit. with permissible deviation of 2520 lit.

- Notes:
1. The starboard group fuel-level gauges are to be checked in the same manner as the port group fuel-level gauges.
  2. After the fuel-level gauges have been checked for proper operation, turn off the switches of the fuel-level gauges starboard and port groups on the right-seat pilot's instrument panel and the HO-4500 inverter.

Checking Operation of Fuelmeter. Type FPC-16

1. Prior to checking, set the indicating instrument pointer precisely to the amount of fuel filled in the fuel tanks starboard and port groups.
2. Prior to checking, make sure that the FPC-16 fuelmeter A.C. supply fuses, type CH-1A, are mounted on the navigator-radar operator's electric board.
3. Make certain that the FPC-16 fuelmeter D.C. supply circuit breakers, type ASC-2, on the right-seat pilot's circuit breaker panel are on.
4. Check the operation of the system with the engines switched on. The accuracy of operation is determined by the fuel consumption per hour.
5. After the FPC-16 fuelmeter has been checked for proper operation, switch off the ASC-2 circuit breaker on the right-seat pilot's circuit breaker panel.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 158 -

Checking Operation of Fuel Pump Manual and Automatic Control System and Their Warning System

1. Switch on the fuel pump warning system circuit breaker, type A30-2, on the right-seat pilot's circuit breaker panel; the green and blue warning lamps must be dead.
2. Set the fuel flow control switch to the MANUAL ( РРВНОЕ ) position and the pilots' upper electric board turn on the switch of the 1st front tank group fuel flow manual control A30-5 circuit breaker. The green lamps of the 1st front tank group on the pilots' upper electric board must flash on.
3. Switch off the 1st front tank group fuel flow manual control A30-5 circuit breaker (operating as a switch); the warning lamps must go out.
4. Switch on the 1st rear tank group A30-5 circuit breaker; the lamps of the 1st rear tank group must flash on. Then turn off the 1st rear tank group A30-5 circuit breaker switch; the warning lamps must go out.
5. Turn on the 1st rear and front tank group A30-5 circuit breakers; the warning lamps must glow constantly without flickering.
6. Switch on the 2nd group A30-5 circuit breaker; the warning lamp of the 2nd group on the upper electric board must flash on, while the 1st group pumps must change over from the nominal to the heavy duty.
7. Switch off the 1st front and rear tank group A30-5 circuit breaker; in this case the 1st group warning lamps must go out.
8. Switch on the 3rd group A30-5 circuit breaker; the 3rd group warning lamps must flash on, while the 2nd group pumps must change over from the nominal to the heavy duty.
9. Switch on the A30-2 circuit breaker of the 4th and 5th group fuel pump supply on the right-seat pilot's circuit breaker panel.
10. Turn off the switch of the 2nd group A30-5 circuit breaker; the 2nd group pumps and warning lamps must get switched off.
11. Turn on the stand-by pump switch, type 2B-45, on the pilots' upper electric board; the 4th group pump warning lamps must flash on.
12. Turn on the 5th group switch, type 2B-45; the 5th group warning lamps must flash on, the 3rd group pumps must change over from the nominal to the heavy duty and the 4th group pumps must change over from the stand-by to the nominal condition.
13. When checking the operation of the fuel pumps, pay attention to the amount of current consumed by them which must be within the data given in the Certificate of the fuel pump.
14. Set the fuel flow control switch on the pilots' upper electric board to the AUTOMATIC ( АВТОМАТ ) position and the fuel flow manual control A30-5 circuit breaker switch to the OFF ( ВЫКЛЮЧЕНО ) position.
15. Switch on the fuel automatic line A30-2 circuit breaker on the right-seat pilot circuit breaker panel.
16. On the pilots' upper electric board turn on the supply switch, type 2M-250, of the starboard and port engines automatic control line amplifiers; make sure that the fuel pumps automatic control operates correctly with the given amount of fuel in the aircraft tanks. The flashing of the blue and green warning lamps and the switching on of the fuel pumps depend on the amount of fuel in each group separately. The operation of the automatic control versus the amount of fuel filled is described in the Section "Operation of PA-M Engines", Book one, "Operating Instructions of IV-16 Aircraft".
17. The fuel flow automatic control is performed through two channels independent of each other. The left tank group fuel flow automatic control is

- 159 -

applied by the right tank group automatic control and vice versa. Therefore, when checking the operation of the automatic control, check the operation of each group separately, that is by switching the 2M-250 automatic control amplifiers on and off in turn. The flashing of the warning lamps on the pilots' upper electric board when the amplifiers are switched on and off in turn certifies to serviceability of the amplifiers.

- Notes:
1. After the operation of the automatic control has been checked up, switch off the H0-4500 inverter, if other units operating from the A.C. power supply are inoperative.
  2. Set all the switches of the automatic control system on the pilots' upper electric board to the OFF ( ВЫКЛЮЧЕНО ) position.
  3. In case faults of the automatic control are detected during the check up, it is necessary to check the system by means of the JMA-53-60 installation as prescribed by special instructions appended to the installation.

Specifications of Fuel Pump Control and Fuel Gauge Electric SystemFuel-Level Gauge

1. The fuel-level gauge set operates:
  - (a) within ambient air temperature range of  $-60$  to  $+50^{\circ}\text{C}$ ;
  - (b) at A.C. voltage of  $115 \pm 11.5$  V, 400 - 28 c.p.s. and D.C. voltage of  $27 \pm 2.7$  V;
  - (c) with outside pressure changed from 760 to 90 mm of mercury, that is at altitudes from 0 to 15,000 m;
  - (d) in conditions of relative humidity from 30 to 98 per cent.
2. The error of the fuel-level gauge reading when bench tested under normal conditions (at temperature of  $20 \pm 5^{\circ}\text{C}$ , pressure of 760 mm of mercury, relative humidity of 30 to 98 per cent and voltage of 115 V, 400 c.p.s.) does not exceed  $\pm 2$  per cent at the zero mark and  $\pm 4$  per cent of the scale nominal value at the other scale marks.
3. The error of the fuel-level gauge reading at  $-60^{\circ}\text{C}$  does not exceed  $\pm 6$  per cent at the zero mark and  $\pm 8$  per cent at the other scale marks; at temperature of  $+50^{\circ}\text{C}$  the error does not exceed  $\pm 5.5$  per cent at the zero mark and  $\pm 5.5$  per cent at the scale nominal value at the other scale marks.
4. The error of the signal unit operation checked by means of the bench does not exceed 10 mm of the float travel in the transmitter.
5. The additional error of the fuel level gauge reading at voltage change of  $\pm 10$  per cent does not exceed  $\pm 1$  per cent; at frequency change of  $\pm 5$  per cent it does not exceed  $\pm 1$  per cent of the scale nominal value.
6. The insulation of transmitters and switches, type II-7, at normal temperature and relative humidity of 30 to 80 per cent is not less than 100 megohms and at relative humidity of 95 to 98 per cent - not less than 20 megohms.
7. The insulation of the indicating instrument is not less than 20 megohms at normal temperature and relative humidity of 30 to 80 per cent and not less than 2 megohms at humidity from 95 to 98 per cent.
8. The similar elements of the set within one group are interchangeable.
9. The additional error is  $\pm 1$  per cent of the fuel-level gauge scale nominal value (taking into consideration possible difference in the capacity of the tanks included in the groups).

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

10. The first warning signal 30-MINUTE FLIGHT-FUEL REMAINDER (ОЦЕНКА ТИПОВ НА 30 МИН. ПОЛЕТА) is sent when the fuel left in one of the 4th tank groups is equal to  $600 \pm 200$  lit.
11. The second warning signal 15-MINUTE FLIGHT-FUEL REMAINDER (ОЦЕНКА ТИПОВ НА 15 МИН. ПОЛЕТА) is sent when the fuel left in one of the 5th tank groups is equal to  $1600 \pm 100$  lit.
12. The electrical capacity of "dry" transmitters is given in Table 29.

Table 29  
Capacity of Dry Transmitters (Initial Capacity)

No.	No. of tank and transmitter	Capacity of transmitters, pF	No.	No. of tank and transmitter	Capacity of transmitters, pF
1	2	3300	7	6A	1000
2	3	2300	8	7	1000
3	3a	1000	9	10	2300
4	4	3300	10	12	1000
5	5	3300	11	16	2300
6	6	2300			

FPC-16 Fuelmeter of Fuel Consumed by Each Engine

1. The summing fuelmeter, type FPC-16, operates within a range of 1200 to 16,000 lit. per hour.
2. The error of the fuelmeter set under normal conditions does not exceed  $\pm 2.5$  per cent.
3. The fuelmeter set at temperatures of  $+50$  and  $-60^\circ\text{C}$  does not exceed  $\pm 4.5$  per cent of the indicating instrument scale nominal value.
4. Pressure drop by the transmitter at fuel viscosity of  $15 + 1$  c.s.u. (corresponding to fuel temperature of  $-40^\circ\text{C}$ ) and maximum fuel flow of 16,000 lit. per hour does not exceed 0.25 kg per sq.cm. with the impeller operating and 0.4 kg per sq.cm. with the impeller inoperative.
5. The inner chamber of the transmitter body, as well as the connections of the branch pipe with the transmitter body, are gastight and withstand a testing pressure of fluid (kerosene) of 9 kg per sq.cm.
6. Power consumed by the set is 40 W.
7. The thyatron fires with delay of 100 or 200 milliseconds.

Fuel Pump Automatic and Manual Control

1. The pump-switched-on signals of the subsequent groups - the transmitter lower warning unit operate when  $350 \pm 150$  lit. remain in one of the tank groups of the same name.
2. The pump-switched-off signals of the previous groups - the transmitter upper warning unit - must operate when the following amount of fuel remains in one of the tank groups of the same name:
 

2nd left group, tank No. 4	$2450 \pm 250$ lit.
2nd right group, tank No. 3	$2250 \pm 250$ lit.
3rd group	$5000 \pm 250$ lit.
4th group	$2300 \pm 250$ lit.

3. The fuel pump, type SHH-T, with the MB-650A electric motor:
  - (a) Electric motor power supply .....  $27 \pm 2.7$  V D.C.
  - (b) Current consumed by the electric motor:
    - main duty ..... not in excess of 31 A
    - light duty ..... not in excess of 19 A
  - (c) Fluid pressure drop produced by the unit at the output of 14,000 lit. per hour and voltage of 27 V across the electric motor terminals on the ground:
    - main duty ..... 0.8 to 0.9 kg per sq.cm.
    - light duty ..... 0.25 to 0.45 kg per sq.cm.
  - (d) Pressure produced by the pump at light duty with the cock closed and voltage of 27 V across the electric motor terminals ..... not on excess of 0.8 kg per sq.cm.

Note: Check these parameters at ambient air and pressure fluid temperature of  $15$  to  $35^\circ\text{C}$ .

- (e) Period of continuous operation ..... prolonged
- (f) Permissible temperature of ambient air during the operation of the unit ..... from  $+50$  to  $-60^\circ\text{C}$
- (g) Minimum permissible length of the electric motor brushes ..... 18 mm

Note: The pump heavy duty continuous operation during 60 minutes (15 minutes of them at zero output) is performed by connecting a 5-ohm resistor to the main duty winding circuit.

CAUTION: Change-over to heavy duty can be performed only from the main duty. It is not permitted to start the pump at heavy duty.

4. The fuel pressure warning unit:
  - (a) At pressure change from  $0.35 \pm 0.05$  to 2 kg per sq.cm. the warning lamp flashes on.
  - (b) The device operates within the range of  $+50$  to  $-60^\circ\text{C}$ .
  - (c) The device warning lamp power is 3 W, its supply voltage is  $27 \pm 2.7$  V.
  - (d) Errors of the warning unit operation:
    - at normal temperature .....  $\pm 0.05$  kg per sq.cm.
    - at temperature of  $+50$  and .....  $-5^\circ\text{C}$   $\pm 0.075$  kg per sq.cm.
  - (e) The gastightness of the device must meet the following requirements:
    - (1) at air pressure of 5 kg per sq.cm. no pressure drop as indicated by the reference pressure gauge must take place in the warning unit sensing element;
    - (2) the gastightness of the device body ensures that on delivering air under a pressure of 300 mm of mercury simultaneously to the static and dynamic systems pressure drop does not exceed 8 mm of mercury during one minute.
  - (f) The device can withstand pressure overload of 5 kg per sq.cm. during 5 minutes.
  - (g) The device insulation at normal temperature and relative humidity of 30 to 80 per cent is not less than 20 megohms.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



Possible Faults of Fuel Pumps Control Electric System and Their Elimination			50X1-HUM		
Fault	Cause	Remedy	1	2	3
The indicator pointer is pressed to the left-hand limiter	(a) The transmitter circuit is open	Detect the faulty transmitter by switching on the transmitters in group of transmitters and check its connection in the plug connector. Eliminate the fault.			insulation. If the insulation exceeds 100 megohms, mount the transmitter in place. In case the insulation is less than 10 megohms replace the transmitter.
	(b) The outer connecting wires of the transmitter circuit are broken	Check the connecting wires and eliminate the fault.	Then switched over to the NORMAL (COWMA) position, the indicator pointer overshoots the scale maximum.		Replace the amplifier.
The indicator pointer is beyond the scale maximum	(c) Break inside the amplifier circuit running to the transmitters	Replace the amplifier.			Switch on the A3C-2 circuit breaker on the right-seat pilot's circuit breaker panel or eliminate the break of the outside connection circuit wires.
	(d) There is no contact on the PH-3 relay located in the amplifier	Replace the amplifier.			Replace the amplifier.
	(e) Short circuit of the 6H-9 lamp grid wire to frame in the amplifier	Replace the amplifier.			Check the CH-1 fuse on the navigator's upper panel.
	(f) Shorting to frame of the circuit connecting pin 11 of the switch plug connector to pin 9 of the amplifier plug connector to earth	Check the connecting line and eliminate the circuit.			Replace the lamps and check the serviceability of the set by pressing the CHECK UP (HPOBEP2A) buttons on the amplifier front panel. These buttons pressed, the indicating instrument pointer must move towards the scale maximum. The button released, the pointer must return to the initial position.
	(g) There is no contact between the transmitter plates and the plug connector pins	Check the contact and replace the transmitter.			Replace the lamps and check the serviceability of the set by pressing the CHECK UP (HPOBEP2A) buttons on the amplifier front panel. These buttons pressed, the indicating instrument pointer must move towards the scale maximum. The button released, the pointer must return to the initial position.
	(a) Shorting between the transmitter plates	Detect the faulty transmitter or the group of transmitters by switching them on in turn. Remove the faulty transmitter from the tank. Check the insulation between the plates and between the plate and frame. If the insulation is less than 100 megohms, wash the faulty transmitter with clean fuel and dry it. Then re-check the			Replace the lamps and check the serviceability of the set by pressing the CHECK UP (HPOBEP2A) buttons on the amplifier front panel. These buttons pressed, the indicating instrument pointer must move towards the scale maximum. The button released, the pointer must return to the initial position.
				Poor sensitivity of the indicating instrument	

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



- 164 -			50X1-HUM		
1	2	3	1	2	3
<p>With the tanks empty, the indicating instrument pointer shows the presence of fuel in the tanks</p> <p>The warning lamp fails to flash on</p> <p>The indicating instrument fails to operate with fuel being consumed and the transmitter operating</p>	<p>(b) Loss of emission of 6H-9 and 6H-8 lamps</p> <p>(c) The turns of the output transformer primary winding are shorted</p> <p>The insulation of the line or transmitters is too low</p> <p>(a) The warning lamp burnt out</p> <p>(b) The D.C. supply line is damaged</p> <p>(c) The A.C. supply line is damaged</p> <p>(d) The relay, type PH-6, is out of repair</p> <p>(e) The special sensitive relay is out of repair</p> <p><u>Expulsor, Type FXN-16</u></p> <p>(a) CH-1 fuses are not fitted on the navigator-radar operator electric board</p> <p>(b) The A3C-2 circuit breaker on the right-seat pilot circuit breaker panel is not switched on</p> <p>(c) Open circuit.</p> <p>(d) Jamming of the mechanism in the indicating instrument</p>	<p>Insulation is still low, replace the transmitter. Check the fuel for presence of moisture</p> <p>Replace the lamps</p> <p>Replace the amplifier</p> <p>The means of elimination of the fault is the same as in the event of poor sensitivity of the indicating instrument, Item 4</p> <p>Replace the lamp</p> <p>Repair the line</p> <p>Repair the line</p> <p>Check the transmitter coil by means of a tester</p> <p>Replace the transmitter</p> <p>Replace the automatic unit</p> <p>Check the presence of the CH-1 fuse on the navigator-radar operator electric board</p> <p>Switch on the A3C-2 circuit breaker on the right-seat pilot circuit breaker panel</p> <p>Using a tester check the connecting wires and eliminate the fault</p> <p>Replace the indicating instrument</p>	<p>The transmitter fails to operate with fuel being consumed</p> <p>The indicating instrument pointer fails to rotate when the setting dial is rotating</p> <p>Great positive error of the set (that is the indicated amount of remaining fuel is greater than the actual amount)</p> <p>Great negative error of the set (that is the indicated amount of fuel remaining is smaller than the actual amount)</p> <p>The transmitter and the indicating instrument are in good repair but the set fails to operate with fuel being consumed</p>	<p>(e) The thyatron in the HT-51A thyatron interrupter fails to operate</p> <p>(a) Clogging of the transmitter bearings in the guide mechanism - the impeller fails to rotate</p> <p>(b) Clogging of the contact mechanism - the interrupter fails to rotate when the impeller is rotating</p> <p>The stop spring is damaged or deformed, the stop ball drops out</p> <p>(a) Clogging of the transmitter</p> <p>(b) Clogging in the indicating instrument mechanism</p> <p>(a) Poor contact in the connecting wires (most often at the plug connectors and leads)</p> <p>(b) The indicating instrument kinematic coupling is disturbed, when the driving pawl engages two teeth during one cycle of the relay operation</p> <p>Failure of the thyatron interrupter elements</p>	<p>Replace the thyatron</p> <p>Replace the transmitter</p> <p>Replace the transmitter</p> <p>Replace the transmitter</p> <p>Replace the transmitter</p> <p>Replace the transmitter</p> <p>Replace the indicating instrument</p> <p>Thoroughly check the wiring and ensure reliable contact</p> <p>Replace the indicating instrument</p> <p>Replace the thyatron and, if after this the set does not operate, replace the thyatron interrupter</p>
			FLAP CONTROL ELECTRIC SYSTEM		
			<p>The flap control electric system is designed for extending and retracting the flaps, indicating the angle of their deflection and transmitting the horn</p>		

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM

signals in the front pressurized cabin when the engine throttle control is set to the take-off rating while the flaps are not in the take-off position.

The system includes the following electric units:

- electric mechanism, type MIB-3M;
- distant-reading electric flap position indicator, type FSI-47; the instrument set includes one FSI-47 indicator transmitter and two FSI-47 indicators;
- limit switches mechanism, type MIB-11;
- limit switches mechanism, type MIB-2;
- relay, type PH-2;
- two contactors, type K-250;
- switch, type ZMB-20;
- switch, type MIB-45;
- fuses and circuit breakers.

The electrical units are located in the following places:

1. The flap control electric mechanism, type MIB-3M, is mounted on the centre plane between frames Nos 32 and 33.
2. The flap position indicators, type FSI-47, are located on the right- and left-seat pilots' instrument panels.
3. The transmitter of the FSI-47 position indicators is installed on the MIB-2 mechanism.
4. The limit switch mechanism, type MIB-2, for switching on the warning horn is located on the flap transmission shaft.
5. The limit switch mechanism, type MIB-11, for switching off the electric motors of the MIB-3M mechanism with the flaps in the extreme positions is on the flap driving shaft.
6. The contactor, type K-250, for switching on and off the supply of electric motors Nos 1 and 2 of the MIB-3M mechanism and landing flaps junction box is in the bomb bay ceiling at frames Nos 34 and 35.
7. The fuse, type MIB-150, for electric motor No.1 of the MIB-3M mechanism is in the double supply left-hand junction box and for electric motor No.2 in the right-hand junction box.
8. The flap control switches, type MIB-45, of the left-seat pilot, and type ZMB-20 of the right-seat pilot are mounted on the engine control panels of the left-seat and right-seat pilots respectively.
9. The relay, type PH-2, for interlocking which prevents switching the flaps by one pilot for extension and by the other pilot for retraction is installed on the left-seat pilot's engine control panel.
10. The limit switches for switching on sound signalling are mounted on the engine throttle controls on the right-seat pilot's console (Fig.104).

Specifications of Electric Units

1. Electric mechanism, type MIB-3M:	
(a) mains nominal voltage .....	27 V
(b) range of mains operating voltage .....	24.3 to 29.7
(c) loading moment:	
nominal .....	10 kg-m
maximum .....	15 kg-m
(d) current with the mechanism operating with two electric motors:	
at nominal moment .....	not in excess of 190 A

at maximum moment .....	250 A
current with the mechanism operating with one electric motor:	
at nominal moment .....	100 A
at maximum moment .....	125 A
(i) speed of rotation of the mechanism output shaft at nominal voltage and nominal loading moment with the mechanism operating with two electric motors .....	not less than 240 r.p.m.
with the mechanism operating with one electric motor .....	120 r.p.m.
(ii) speed of rotation of the output shaft in both directions of rotation at nominal voltage, simultaneous operation of two electric motors and a moment of 2 kg-m on the output shaft .....	not in excess of 420 r.p.m.
(iii) friction clutch slipping torque reduced to the mechanism output shaft .....	18 to 25 kg-m
(iv) when determining the direction of rotation of the mechanism output shaft from the side of the angle transmission larger diameter the rotation to the left corresponds to the flap extension and the rotation to the right corresponds to the flap retraction	
(v) mechanism operation duty .....	intermittent
with two electric motors operating after the extension or retraction of the flaps .....	5-minute interval; complete cooling of the engines is necessary after 5 cycles
with one electric motor operating after the extension or retraction of the flaps .....	10-minute interval; complete cooling of the engines is necessary after 2 cycles
(vi) the electric mechanism operates normally at ambient air humidity of up to 98 per cent at temperature change from +50 to -60°C and at above-sea-level altitudes of up to 5000 m.	
2. Flap position indicator, type FSI-47:	
(a) mains voltage .....	27 ± 2.7 V
(b) the indicator operates at temperatures .....	from +50 to -60°C
(c) power consumed by the set .....	not in excess of 5 W

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



- 169 -

(d) current consumed by the transmitter .....	not in excess of 100 mA
(e) set indications error .....	not in excess of 2%

3. Limit switch mechanics, type MB-2:

(a) nominal voltage .....	24 V
(b) maximum current at ohmic load .....	15 A
(c) maximum load at inductive load .....	8 A

4. Limit switch mechanics, type MB-11:

(a) operating voltage range .....	23.4 to 30 V
(b) maximum current at ohmic load .....	15 A
(c) maximum current at inductive load .....	8 A

5. Full angle of flap extension .....

6. The sound signalling is switched off with the engine throttle control in the take-off rating position when by the JSH-47 flap position indicator the flaps are extended by an angle .....

7. Flap extension time with both electric motors operating simultaneously and at current not in excess of 155 A and voltage of 26 V .....

8. Flap retraction time with both electric motors operating simultaneously and at current not in excess of 160 A and voltage of 26 V .....

9. Flap extension time with one engine operating at current not in excess of 80 A and voltage of 26 V .....

10. Flap retraction time with one engine operating at current not in excess of 85 A and voltage of 26 V .....

Checking Flaps Operation under Voltage

1. On the left-seat pilot's circuit breaker panel switch on two LANDING FLAPS (DOGAPOHBE HbTKE ) circuit breakers, type ASC-5 , and LANDING FLAPS AIR TEMPERATURE INDICATORS (PKAPATZEHO DOGAPOHBE BHTPOB Hb TESHKAPATZEHO BOBETWA ) circuit breaker, type ASC-2 ; on the right-seat pilot's circuit breaker panel switch on the HORN ( CHEPBA ) circuit breaker, type ASC-2.

**CAUTION:** 1. Prior to switching on the circuit breakers on the right and left pilots' console, check the position of the flap-control switches which must be in the neutral position.

2. Prior to extending or retracting the flaps make sure that the flaps and the flap driving gear are clear of personnel and that the ladders and the cases are removed.

2. With the flaps in the retracted position, set the left-seat pilot switch to the EXTENDED (JEPABO ) position. This done, by short pulses set the right-seat pilot switch to the REVERSE (BHWICE ) position; the flaps must not extend.

- 169 -

3. By means of the left-seat pilot switch extend and retract the flaps completely (Fig.105). When extending the flaps by operating the left-seat pilot switch, set the right-seat pilot switch to the EXTENDED (JEPABO ) position by short pulses. The flaps must continue extending.

4. The flap control operation is checked from the left-seat control switch and from the right-seat control switch by means of both electric motors and by each electric motor separately. Check the flap control operation from the right-seat pilot console after the flaps have been checked for complete extension and retraction from the left-seat pilot console.

When checking the flap control from the right-seat pilot console, do not extend and retract the flaps completely (Fig.106).

5. When extending the flaps completely (Fig.106), set the engine throttle control to the take-off rating; the horn must boot all the while. When the flaps are deflected from 19 to 23° during extension and from 23 to 19° during retraction the horn must not boot.

6. When checking the flap control operation check the operation of the flap position indicators. During the extension and retraction of the flaps the pointer of the JSH-47 indicators must move without noticeable jerks and jamming. The difference in the flap position indicators reading of the right-seat (Fig.107) and left-seat pilots must not exceed 2°.

TAIL SKID CONTROL AND LANDING GEAR WARNING ELECTRIC SYSTEM

The tail skid control and landing gear warning electric system is designed for:

- (a) sending out signals of the landing gear legs extended and retracted positions separately;
- (b) control of the tail skid extension and retraction;
- (c) sending out sound signals in case the throttle control is in the off position and the landing gear is not extended.

The system includes the following units:

- MI-250 electric mechanism;
- EM-51 warning lamp - 6 pieces (5 green lamps and 3 red lamps);
- EM-44 limit switch - 6 pieces;
- EM-2-140B limit switch - 1 piece;
- EM-2-141F limit switch - 2 pieces.

The electric units are located as follows:

1. The tail skid electric mechanism, type MI-250 , is mounted on frame No.65.
2. The landing gear extended and retracted positions warning lamps, type EM-51 , are located on the pilots' central instrument panel.
3. The tail skid retracted position warning lamps, type EM-51 , are installed in the rear cabin on the gunner-radio-operator's and rear gunner's electric boards.
4. The blocking limit switches, type EM-2-142F , designed for switching on sound signalling in case the throttle control is in the off position with the landing gear retracted are mounted on the right-seat pilot engine control panel.
5. The EM-44 limit switches (Fig.108) designed for switching on the landing gear main legs extended position warning lamps are located on the landing gear starboard and port legs struts.

50X1-HUM

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

- 170 -

The EK-44 limit switches designed for switching on the main and nose legs retracted position warning lamp are mounted on the landing gear legs up-locks. The EK-2-1403 nose leg extended position limit switch is mounted on the nose leg down-lock.

6. The EK-44 limit switch serving to switch the tail skid for retraction and extension is located on the nose leg up-lock.

7. The NH-5 fuse in the NH-250 electric mechanism supply circuit is in the double supply left-hand junction box on frame No.17.

## Specifications of Electric Unit

## 1. Tail skid control electric mechanism, type NH-250:

(a) supply voltage	27 ± 2.7 V
(b) rod load	
nominal	250 kg
maximum	375 kg
(c) current	
at nominal load	not in excess of 3.4 A
at maximum load	not in excess of 3.8 A
(d) rod travel	180 ± 1 mm
(e) rate of rod travel at voltage of 27 V and nominal load opposite to the rod travel	6.2 ± 0.62 mm/sec.
(f) duty of operation at nominal data	intermittent, consisting of 5 cycles followed by an interval of one hour at least
(g) brushes A-12 measuring	435/7
(h) altitude	15,000 m.
2. Limit switch, type EK-44:	
(a) rod travel downward before the contacts are changed over	5 ± 1.8 mm
(b) rod reserve travel downward after the contacts are changed over	not less than 1.5 mm
(c) travel of the additional device downward after changing over	4 ± 1.5 mm
(d) full travel of the rod and the additional device button	from 10.5 to 15 mm
(e) reverse travel of the rod upward after the contacts are changed over	not in excess of 4.5 mm
(f) reserve travel of the rod upward after the contacts are changed over	not less than 1.5 mm
(g) force applied to the rod to change over the contacts	4 to 6 kg

50X1-HUM.

- 171 -

(h) force applied to the rod at the beginning of compression of the additional device spring	5 to 7 kg
(i) difference between the forces	not less than 1 kg
(j) force applied to the rod at the end of compression of the additional device spring	11 to 15 kg
(k) operating voltage	27 ± 2.7 V current flowing through the contacts 10 A
(l) the switch operates within the ambient air temperature range	from -60 to +50°C
(m) operating altitude	from 0 to 15,000 m.
(n) range of the rod total length adjustment	7.7 mm

## Checking Operation of Tail Skid Control and Landing Gear Warning System under Voltage

Checking the Operation of the Warning System without the Landing Gear Kinematic Adjustment

1. Switch on the L.G. legs position warning system circuit breaker, type EK-2, on the left-seat pilot's circuit breaker panel and the sound signalling circuit breaker, type A3C-2, on the right-seat pilot's circuit breaker panel. The three green warning lamps mounted on the pilots' instrument panel must flash on.
2. Press the limit switches, type EK-44, on the L.G. main legs up-locks and the left-hand limit switch, type EK-44, on the L.G. nose leg up-lock. The three green warning lamps on the pilots' central electric board must flash on.

## Checking the Operation of the Tail Skid Control and Warning System with the Landing Gear Kinematic Adjustment

1. Switch on the L.G. legs position warning system circuit breaker, type EK-2, on the left-seat pilot's circuit breaker panel and the sound signalling circuit breaker, type A3C-2, on the right-seat circuit breaker panel; if the landing gear is extended the green warning lamps must flash on.
  2. As soon as the landing gear legs start rising, the three L.G. extended position green warning lamps must go out. The legs reaching the extreme retracted position, the three L.G. retracted position red warning lamps on the pilots' central electric board must flash on. The L.G. nose leg reaching the extreme retracted position, the tail skid control mechanism must get automatically on for retraction.
- With the tail skid completely retracted, the electric mechanism must get automatically switched off; simultaneously the two green warning lamps of the tail skid retracted position must flash on; one of the lamps is mounted on the

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 172 -

rear gunner's electric board; the other lamp - on the gunner-radio operator's electric board.

3. Pull up in turn both throttle controls on the right-seat pilot's control panel as far as they will go. In this case the horn in the front pressurized cabin must hoot. Switch off the horn by pressing the button on the right-seat pilot throttle controls designed for mechanical disconnection of the horn.

4. As soon as the L.G. legs start extending all the three L.G. retracted position red warning lamps must go out and the tail skid electric mechanism must get switched on for extension; after the tail skid has been completely extended the electric mechanism gets switched off and the two green lamps of the tail skid retracted position go out.

5. Pull up both throttle controls as far as they will go. The horn must be silent.

During the landing gear check make sure that the adjustment of the limit switches is not disturbed. The adjustment of the landing gear limit switches is described in the Section "Landing Gear", Book one, "Service Manual of the Aircraft, Model IV-16".

#### TRIM TAB ELECTRIC CONTROL SYSTEM

The trim tab electric control system of the aircraft is used for remote control of the aileron, elevator and rudder trim tabs, and at the same time as a system providing light indication of the neutral position of the aileron and rudder trim tabs.

The system comprises the following units:

- two electric actuators, type MH-100A-60;
- one electric actuator, type MH-100A-36;
- one electric actuator, type JT-11;
- aileron synchronization console;
- limit switches, change-over switches and circuit breakers;
- three tail-tale (warning) lights with white screens.

The electric units are located as follows:

1. The electric actuators, type MH-100A-60, of the aileron trim tabs - between ribs 18 and 19 of the right and left wings; the actuators are accessible through the underwing access holes.
2. The electric actuator, type MH-100A-36, of the rudder trim tab - between ribs 2 and 3 of the fin; the actuator can be reached upon removal of the adjacent skin portion of the fin.
3. The electric actuator, type JT-11, of the elevator trim tab and its EH-1A1B limit switches of the up and down positions - at fuselage frame No. 59; the units are accessible upon removal of the stabilizer access hole panels.
4. The aileron trim tab control change-over switch, type ZHH-20, and the rudder trim tab control change-over switch, type HH-45M, - on the trim tab control panels (stations) of the pilot and co-pilot.
5. The elevator trim tab control change-over switch, type HH-45M, - on the control wheel spokes of the pilot and co-pilot (Fig.109).
6. The B-45 switch used for emergency disconnection of the elevator trim tab electric control system - under the red cap on the overhead electric control board of the pilots.
7. The white GH-51 tail-tale lights indicating neutral position of the aileron and rudder trim tabs - on the pilot's instrument panel (Fig.110).
8. The aileron trim tab synchronization console (Fig.111) carrying the trim

50X1-HUM

- 173 -

tab control change-over switch, type HH-45, white GH-51 light indicating the left aileron neutral position and auxiliary (blocking) contact, type K3-6, - between frames Nos 9 and 10, port side.

#### Technical Characteristics of Electric Actuators

##### Electric Actuator, Type MH-100A

1. Voltage requirement .....  $27 \pm 2.7$  V
2. Current requirement:
  - at nominal rod load of 100 kg ..... not over 1.35 A
  - at maximum rod load of 150 kg ..... not over 1.4 A
3. Rod speed at 27 V voltage and nominal rod load ..... 1.65 mm/sec.
4. Tail-tale light glow duration with rod midposition travel restricted by limit switch within  $\pm 1$  mm ..... 0.5 to 2 mm of travel length intermittent, consisting of 6 cycles followed by obligatory complete cool-down of the actuator
5. Operating duty in nominal conditions ..... intermittent, consisting of 6 cycles followed by obligatory complete cool-down of the actuator
6. Brakes, mark A-12, sizing .....  $425 \times 7$  mm
7. Motor speed .....  $4100 \pm 410$  r.p.m.
8. Operating altitude ..... up to 15,000 m.
9. Working travel length of MH-100A-36 actuator rod ..... 36 mm
10. Working travel length of MH-100A-60 actuator rod ..... 60 mm

##### Electric Actuator, Type JT-11

1. Operating voltage range ..... 23.4 to 28.6 V
2. Current requirement:
  - at nominal load of 180 kg/cm ..... not over 2.8 A
  - at maximum load of 260 kg/cm ..... not over 3.3 A
3. Output shaft speed ..... 7 r.p.m.  $\pm 0.7\%$

#### Voltage Check of Trim Tab Electric Control System

1. Turn on the ABC-5 aileron, elevator and rudder trim tab control circuit breakers on the pilot's circuit breaker control board.
2. Prior to beginning the trim tab operation check, make sure that the aileron and elevator covers are removed, and there are no obstacles under the aircraft to hinder the trim tab movement.
3. Engage the B-45 elevator trim tab electric control emergency disconnecting switch on the pilot's overhead electric control panel.
4. Release the lock on the pilot's control wheel which secures the HH-45M elevator trim tab change-over switch.
5. Operating the switch in pulses and engaging it for continuous operation, move the elevator trim tabs from one extreme position to the other. With the trim tabs in motion, the elevator trim tab control handwheel will be rotating.
6. Operate the HH-45M elevator trim tab change-over switch on the scale of the elevator trim tab control handwheel to set the trim tab neutral.
7. By operating the trim tab switch, type HH-45M, on the left-seat pilot's steering wheel switch on the JT-11 mechanism, then switch off the B-45 trim tab

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 174 -

emergency output. This done, the trim tab electric mechanism stops operating; it begins to operate after the output is switched on.

7. Close the stop on the elevator trim tab switch, with a slight movement pull and push the switch; the electric mechanism must not operate.

8. By means of the rudder trim tab switch, type III-45M, and the aileron trim tab switch, type 2III-20, on the left-seat pilot trim tab control panel (Fig. 112) shift the trim tabs in both directions till they are completely deflected, then set the trim tabs to the neutral position. The trim tab neutral position warning lamps must flash on.

9. Open the aileron synchronization panel cover. With the aileron trim tab in the neutral position, the neutral position warning lamp on the panel must flash on. On pressing on the blocking contact, type KB-6, the warning lamp must go out.

10. Shift the III-45M switch on the trim tab synchronization panel to the right or to the left. This causes the L.H. wing aileron electric mechanism to operate, the R.H. wing aileron mechanism being inoperative.

11. The aileron trim tabs must be synchronized. For this turn on by pulses to aileron tabs control switch on one of the pilots' consoles till the aileron trim tab neutral position lamp flashes on the left-seat pilot instrument panel, and the left aileron trim tab control switch on the synchronization panel till the lamp on the synchronization panel flashes on. Synchronization is ensured if both lamps on the left-seat pilot's instrument panel and on the synchronization panel glow simultaneously.

12. After the operation of the trim tab control from the left-seat pilot's console has been checked, check the operation of the trim tabs control from the right-seat pilot's console as prescribed in items 4, 5, 6, 7 and 8.

13. When checking the trim tabs operation, make sure that:

- (a) the trim tab switches on the left- and right-seat pilots' console have guards and that the stencilled markings are intact and not dirty (Fig. 113);
- (b) the elevator trim tabs are deflected upward when the elevator trim tab control switch is pushed forward and that they are deflected downward when the elevator trim tabs control switch is pulled backward;
- (c) the rudder trim tab is deflected to the left when the rudder trim tab control switch is shifted to the right and the trim tab is deflected to the right when the control switch is shifted to the left;
- (d) the right aileron trim tab is deflected downward and the left one upward when the aileron trim tab control switch is shifted to the right; the right aileron trim tab is deflected upward and the left one downward when the aileron trim tab control switch is shifted to the left.

**CAUTION:** It is prohibited to turn on the trim tab switches simultaneously on the consoles and steering wheels of the right- and left-seat pilots.

14. The operation checked, set the trim tabs to the neutral position, fix in position the trim tab switches on the steering wheels and close the synchronization panel with the cover.

- 175 -

## Possible Faults of Electrical Part of Trim Tab Control System and Their Elimination

Fault	Cause	Remedy
The trim tab deflects in one direction and fails to deflect in the other direction	(a) Jamming of the mechanism (b) Failure of the electric motor	Replace electric mechanism
The neutral position lamp is flickering	(a) Poor contact in the plug connector for switching on the mechanism (b) Poor contact in the mechanism warning lamp switching on system	Eliminate the defect in the plug connector Replace the electric mechanism

## BRAKE SYSTEM PUMP CONTROL ELECTRIC SYSTEM

The electric units mounted in the system regulate the pump operation thus maintaining pressure in the brake hydraulic system within certain limits and transmit signals at minimum permissible pressure.

The electric system includes the following main units:

- hydraulic pump 465 K with the electric motor, type K-4500K;
- pressure drop warning unit, type GM-130;
- pressure switch, type HNS-150;
- contactor, type K-400K;
- relay, type PH-2;
- fuse, type HU-250;
- warning lamp, type GM-51, with red light filter (2 pieces).

The electric units are located as follows:

1. The hydraulic pump 465 K, the GM-130 pressure drop warning unit and the HNS-150 pressure switch are located in the hydraulic panel at frame No. 15.
2. The contactor, type K-400K, designed for switching on the hydraulic pump electric motor, the intermediate relay, type PH-2, for switching on the hydraulic pump and the fuse, type HU-250, are connected in the hydraulic pump electric motor supply circuit and are mounted in the hydraulic panel junction box at frame No. 15.
3. The pressure drop warning lamps, type GM-51, of the normal and emergency hydraulic systems are mounted on the pilots' central electric board.

## Checking Operation of Hydraulic System Electric Control

1. On the left-seat pilot's circuit breaker panel switch off the two hydraulic system control and warning circuit breakers, type AUC-2, and release to zero hydraulic pressure from the main and emergency hydraulic accumulators of the brake hydraulic system. From the main hydraulic accumulator pressure is released by the operation of the main brake system valves (by pressing the pedals) or through the shut-off valve in the hydraulic panel on frame No. 15; from the emergency hydraulic accumulator pressure is released by the operation of the emergency brake valve on the pilot's central panel.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM

2. Switch on the two hydraulic system control and warning circuit breakers, type ABC-2. The two red lamps warning of pressure drop in the normal and emergency systems on the pilots' central electric board must flash on.

3. Turn on the hydraulic pump control switch on the pilots' central panel. The hydraulic pump must start operating and increase pressure in the hydraulic system.

With the hydraulic system pressure not exceeding 35 kg per sq.cm., release the switch handle; the hydraulic pump must continue operating. At a pressure of  $100 \pm 5$  kg per sq.cm. the normal system pressure drop warning lamp must go out; pressure reaching  $130 \pm 5$  kg per sq.cm., the emergency system pressure drop warning lamp goes out. At a pressure of  $150 \pm 5$  kg per sq.cm. the hydraulic pump gets automatically out off.

4. By means of the main brake valve, release pressure in the normal hydraulic system. With pressure dropping to  $120 \pm 5$  kg per sq.cm., the hydraulic pump starts operating; at a pressure of  $150 \pm 5$  kg per sq.cm. the pump gets out off.

5. By means of the emergency brake valve release pressure from the emergency system. Pressure reaching  $130 \pm 5$  kg per sq.cm., the emergency hydraulic system pressure drop red warning lamp must flash on.

- Note:** 1. The operation of the brake hydraulic system pressure control electric system should be checked by the aircraft technician together with an electrician.  
 2. When checking the operation of the hydraulic system, see that proper operation duty of the hydraulic pump is maintained.  
 3. During the operation of the hydraulic pump make sure that the current consumed by the pump electric motor is within the rated limits.

Specifications of System Electric Units

Electric Pump 465 K and Electric Motor A-4500E

1. Direction of rotation .....	left
2. Nominal voltage .....	27 V
3. Voltage operating range .....	24 to 30 V
4. Consumed current:	
at operating pressure of 150 kg per sq.cm. ....	not in excess of 180 A
at maximum pressure of 180 kg per sq.cm. ....	not in excess of 260 A
5. Permissible peaks .....	not in excess of 300 A, up to 2 sec.
6. Operation temperature range .....	from +70 to -60°
7. Electric motor operating altitude .....	12,000 m.
8. Brush minimum length .....	14 mm
9. Operation duty on the ground .....	60-min. operation followed by complete cooling (not less than 1 hour)
at altitudes .....	30-min. operation followed by complete cooling

Pressure Drop Warning Unit, Type CHM-150

1. Operation pressure .....	130 kg per sq.cm. not in excess of
2. Error of the contact operation at normal temperature ...	$\pm 5$ kg per sq.cm.
3. The instrument operates at 0.5 A and $27 \pm 2.7$ V	
4. Maximum vibration overload .....	not in excess of 2.5 g, with error not exceeding $\pm 0.6$ kg per sq.cm.

Pressure Switch, Type HZV3-150

1. Pressure operating range .....	from 0 to 150 kg per sq.cm.
2. Error of contact operation at normal temperature:	
at points 30 and 100 kg per sq.cm. $\pm 5$ kg per sq.cm.	
at points 120 and 150 kg per sq.cm. $\pm 5$ kg per sq.cm.	
3. Maximum vibration overload .....	not in excess of 1.5 g
error of operations:	
at points 120 and 150 kg per sq.cm. ....	$\pm 5$ kg per sq.cm.
at points 30 and 100 kg per sq.cm. ....	26 kg per sq.cm.
4. The instrument operates at $27 \pm 2.7$ V and 0.5 A.	

CABIN HEATING ELECTRIC SYSTEM

The cabin heating electric system is designed to prevent the glass pane from freezing, as well as for additional heating of the cabin by means of electric heaters "Unit 107". In the front cabin the heater is installed at the starboard side near frame No.5; the switches are mounted on the pilots' upper electric boards. In the rear cabin the heater is installed on the port side near frame No.73 (Fig.118), the switches being mounted on the radio operator's electric board (Fig.115).

The fuses, type HZ-150, of the electric heater circuits are located as follows for the front cabin on the starboard side at frame No.6 in the glass pane heating system junction box, for the rear cabin on the port side at frame No.74 in the rear cabin junction box.

Specifications of the Heater "Unit 107"

1. Voltage .....	D.C. $27 \pm 2.7$ V
2. Current in the heating element circuit at V = 27 V (with 3 heating elements cut in) .....	not in excess of 135 A
3. Current in the ventilator motor circuit at V = 27 V ...	not in excess of 30 A
4. Heating values:	
(a) at altitudes from 0 to 7000 m. ....	3000-120 Kcal -510 per hour

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

(b) at altitudes from 7000 to 15,000 m. ....	2000 <sup>±50</sup> -340 kcal per hour
5. Brushes, type M/C-7 ; minimum length .....	10 mm
6. Operating altitude .....	up to 15,000 m.

Checking Operation of Cabin Heating Electric System

1. Switch on the heater control circuit breaker, type 480-30, on the pilot's circuit breaker panel.
2. Turn on the HEATER-VENTILATOR (OBOIPESATEPEL-BEHTLEHTOP ) switch on the pilots' upper electric board. The heater ventilator must force air through a switching on the 1st section warm air must start coming out of the heater in some time; when the 2nd section is switched on in addition to the 1st section still warmer air comes out of the heater. Make sure that air from the slot of the pipe line nozzles of the navigator's, pilots' and blisters glass panels are at constant pressure.

Check the operation of the heater in the rear cabin in a similar manner as the operation of the heater in the front cabin.  
When checking the operation of the heater "Unit 107", measure the current consumed; normal current consumption testifies to the proper operation of the heater.

- Notes:
1. In case the electric motor, type A-400A , fails, it is prohibited to switch on the heater.
  2. Prior to switching on the power supply, make sure that there are no foreign objects at the ventilator window and on the body of "Unit 107". Remove foreign objects, if any.
  3. Switch off the heater after its operation has been checked.

Possible Faults of Cabin Heating Electric System and Their Elimination

Fault	Cause	Remedy
The heater body is overheated during operation	(a) The ventilator window is closed by foreign objects (b) The non-return valve operates with jamming	Remove the foreign objects Check the operation of the non-return valve in the tube connecting the heater with the pipe line. If jamming is detected, eliminate it
	(c) The thermostat fails to operate	Remove "Unit 107" from the aircraft. Check the operation of the thermostat switch. In the event of its improper operation, replace the thermostat

1	2	3
	(d) The altitude relay fails to operate	Remove "Unit 107" from the aircraft and check the operation of the altitude relay. In case the latter fails to operate properly, replace it.

PREFLIGHT PREPARATION

Systematic maintenance operations on the aircraft electrical equipment are absolutely necessary to ensure normal operation of the equipment; the main elements of the maintenance procedure are the preflight preparation, postflight inspection and scheduled maintenance operations.

The scope of the preflight preparation depends on the scope and results of the previous postflight inspections and the thoroughness with which the troubles detected in flight and during the ground check have been eliminated.

The preflight preparation and postflight inspection of the aircraft electrical equipment consist in inspecting the electric wiring and units for condition and in voltage testing of the units.

It is advisable to adhere to the following ground check inspection procedure (walk-around) during the preflight preparation and postflight inspections of the electrical equipment:

- (1) front cabin and fuselage between frames Nos 12-14;
- (2) L.G. nosewheel well;
- (3) L.G. left strut nacelle;
- (4) navigation lights of left outer wing panel;
- (5) stern cabin and tail skid;
- (6) accessories compartment between frames Nos 56-69, fuselage belly section and bomb bays;
- (7) L.G. right strut nacelle;
- (8) navigation lights of right outer wing panel;
- (9) top sections of fuselage and wings;
- (10) nacelles of right and left engines.

Preflight Preparation before Energizing Electrical Equipment

Front Cabin and Fuselage between Frames Nos 12-14

1. Make sure that the storage battery switch on the radar operator's electric control board is OFF.
2. Carry out the following checks at the radar operator's station:
  - (a) check the ON-OFF and change-over switches, circuit breakers, rheostats and operating knobs of the cabin light and ultra-violet illumination system for proper functioning; the check is done by manually engaging and disengaging the above-mentioned items; check for proper attachment;
  - (b) make sure that the glasses of the ammeters, voltmeters and lights are intact and that the instruments are securely attached in their mounting positions;
  - (c) see to it that the voltmeter and ammeter needles are zeroed and that the fuel system boosters are reliably fastened to their mounting platforms.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

50X1-HUM

- 180 -

3. The following checks should be carried out at the stations of the pilot and navigator:
  - (a) check (by engaging and disengaging with the hand) the ON-OFF and change-over switches, as well as the circuit breakers, operating knobs and rheostats for sound operation;
  - (b) check the signalization and illumination equipment for condition and secure attachment;
  - (c) make sure that the cabin heater (Unit 107) and the ACC-SIM automatic glass panel temperature controller are reliably attached and that their shock absorbers function properly.

4. When through with the checks, place all the ON-OFF and change-over switches and the circuit breakers (which serve as switches) to OFF ( *ВЫКЛЮЧЕНО* ) or NEUTRAL ( *НЕЙТРАЛЬНО* ).
5. Make sure that spare bulbs and fuses are available in the flight maintenance kit.
6. See to it that the hydraulic control panel connections from the units of the hydraulic system automatic control equipment are intact.
7. Inspect and make sure that the union nuts on plug connectors and five extinguisher discharge bonnets at frame No.12 are properly tightened up and lockwired.

L.G. Nosewheel Well

1. Check to see that the glasses of the landing, taxiing and well illumination lamps are intact and that the lamps are attached securely.
2. Check to see if the limit switches on the lock and brace strut of the L.G. nosewheel are intact and reliably attached; inspect for secure wire connections.
3. Check the fuel system boosters and NO-4500 inverters for secure attachment and see that the firing (discharge) mechanisms on the discharge bonnets of the CO<sub>2</sub> and inert gas bottles are properly locked.

Right and Left L.G. Strut Macelles

1. Check the limit switches on the locks and shock absorbers of the main L.G. legs for secure attachment and sound operation.
2. Check the wires for proper attachment and connection to the limit switches, taxiing lamp and automatic brake control units, type VA-16
3. Check the bottom formation light and illumination equipment for sound operation.

Navigation Lights of Left and Right Outer Wing Panels

1. Inspect the attachment fittings of the navigation light equipment and make sure that the cover glasses of the lights are intact.
2. Make sure that there is no water, ice or dirt under the light covers glass.

Stern Cabin and Tail Skid

1. Operating the switches, control knobs, circuit breakers and rheostats manually, make sure that they function properly.
2. Make sure that the cabin heater and the warning (signalization) equipment are attached reliably.
3. Place all the switches and rheostats OFF.

- 181 -

4. Check the voltmeter for condition and make sure that the instrument and its cover glass are securely held in place.
5. Inspect the tail navigation light system and make sure that the glass covers and the attachment fittings are intact.
6. Check the tail skid actuator and its electric wires for condition and attachment.

Accessories Compartment between Frames Nos 56 and 60, Fuselage Belly Section and Bomb Bays

1. Check to see if the MEA-1A actuator, the de-icer junction box and the circuit breaker of the autopilot servo-unit heater system are attached securely.
2. Check electric wires for condition and secure attachment.
3. Inspect the bottom formation light system.
4. In the bomb bays: check the electric wires for condition, and the section boxes and landing flap actuator, type MHS-3W, for reliable attachment.
5. Check the FO-18000 ballast resistor for secure attachment and proper wiring.

Top Section of Fuselage and Wings

Check the top formation light system for condition and reliable attachment.

Right and Left Engine Macelles

Check the electric equipment of the engines for proper attachment and the electric wires for condition; check to see if the NUP-18000 generators, EPT-82 wing regulators, TG-8 stability transformers and the overheat warning units are attached securely.

During external inspections of the equipment in all the aircraft sections make sure that the fuses on the control panels and in boxes meet the Specifications indicated on the respective nameplates and are reliably attached, that the covers of the connector boxes are tight at their edges, and that the locks are lockwired and reliably retain the covers against vibration and falling out in flight.

Autopilot, Type AU-5-2M

1. Carry out condition and voltage checks of the autopilot units. Inspect externally to check whether the autopilot units are free from moisture, dust and breakdowns in connections to aircraft structural members. Remove the covers from the formation stick and directional stabilizer.
2. The autopilot preflight preparation procedure is obligatory before each flight. If several flights take place during one day, it is sufficient to carry out the preflight preparation before the first flight.
3. If the ambient air temperature is below minus 20°C, the autopilot heaters should be engaged for one hour before the flight.
4. Turn on the A30-15 circuit breaker of the torque motor assembly on the navigator's circuit breaker control panel, the A30-5 circuit breaker on the pilot's circuit breaker control panel, and the master switch on the autopilot control panel, and check the autopilot operation under voltage.

Check the clutch tension by hand, employing the following procedure:

- (a) engage the bomb sight and autopilot clutches;
- (b) turn the bomb sight so that the autopilot clutch lever would reach its stop. In this position the autopilot clutch begins to slip on its drum; during the further rotation the clutch should not slip!

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 182 -

(e) turn the switches on the autopilot control panel off.

Voltage Test of Electrical Equipment

1. Carry out external inspection of the storage half-batteries, type 12-GAM-55. If the batteries are operative, install them on the aircraft, face in place and close the container covers.
2. Place the storage battery change-over switch to the NORMAL (NORMALIZED) position, and check for loads by the ammeter on the radar operator's electric control board. Engage the gyro horizon sets of the pilot and co-pilot and the interphone set which will correspond to a 10 to 12 A load on the battery, and check the battery voltage. The indicated voltage should not be smaller than 24. Disconnect the gyro horizon sets and the interphone system, and set the storage battery change-over switch to the neutral position.
3. Connect the storage battery in turn to the normal supply circuit and to the triple supply busbar. To make certain that the storage battery energizes these circuits, engage the gyro horizon sets of the pilot. When the storage battery is connected to the normal supply circuit, both gyro horizons should operate. When the battery is connected to the triple supply busbar, it is only the stand-by gyro horizon which should operate. The operation of the gyro horizons will be indicated by the noise of the inverter.
4. Disconnect the gyro horizon sets and the storage battery.
5. Connect the aircraft electric mains to a ground supply source.
6. Operating collectively with the aircraft technician or mechanic, check the following:
  - (a) operation of the control system of flaps, elevator and rudder trim tab and of ailerons. Synchronize the operation of the aileron trim tabs;
  - (b) operation of the tail unit de-icers;
  - (c) glass panel electric heating system;
  - (d) L.G. warning system: hand pressure upon the limit switches corresponding to the L.G. retracted position should result in flashing up of the red warning lights; at the same time the green L.G. position warning lights should go on burning;
  - (e) operation of the main and stand-by inverters, type HO-4500, with reference to the aircraft A.C. voltmeter;
  - (f) operation of the fuel automatic control system and of the fuel flow gauges;
  - (g) operation of the cabin ventilators and heaters.
7. Check the operation of the unit of fire-fighting system electromagnetic valves; while checking, do not engage the 130-10 circuit breaker which opens the CO<sub>2</sub> bottles and the inert gas system switch, type B-45, on the overhead electric control panel of the pilots since otherwise the discharge bombs (firing mechanisms) will be actuated.
8. When testing the operation of the engines, check the operation of the generators; if necessary, adjust the generator voltage and check the generator-to-emergency supply circuit voltage supply.

PREFLIGHT INSPECTION

Gain information on the in-flight operation of the electrical equipment from the crew members.

De-energize the aircraft electric mains and disconnect the storage battery. This done, proceed to inspecting the system. The sequence of inspections is the same as that authorized for the preflight preparation.

50X1-HUM

- 183 -

Subject to inspection will be: the electrical equipment, the warning (signalization) system, the illumination equipment, the electric actuators, the bunched conductors and junction boxes. When inspecting, make sure that:

1. All the equipment fittings, rheostats, switches, relays, bulbs, receptacles, circuit breakers and other equipment items are securely attached to their mounting panels and boards.
2. All the nameplates and instruction plates which concern the function or operation of separate units and switches are in good condition (are neither erased nor fouled).
3. The clearance between the bunched conductors and moving parts is at least 10 mm.
4. The union nuts of the plug connectors are adequately tightened up and locked.
5. The mounting areas of the plug connectors and special wire adapters have no damaged portions of cabin-sealing cement.
6. The gaps between the power contacts and the airframe members gauge at least 5 mm. Special attention should be paid to insulating the wires from the case ("airframe") as any contact of a bare plus wire with the airframe results in short-circuiting.
7. Reliable contact is ensured at the connections of power contacts.
8. In case of dirt, dust, oil or moisture on the electric wires or equipment items, wipe them with a clean cloth.
9. Carry out external inspection of the storage half-batteries and make sure that:
  - (a) the half-batteries are clean from the outside;
  - (b) there are no cracks and breakdowns in the electric contacts and intercell connections;
  - (c) the monoblock, cover and vent plugs are free from fouling and damage; clean fouled spots, if any.

Note: If the storage battery is damaged, send it over for detailed inspection or correction of faults.

10. Check the condition of the storage battery containers:
  - (a) see to it that the felt is not moistened with electrolyte;
  - (b) check to see if the wires in the container are intact;
  - (c) see to it that the container cover locks are intact;
  - (d) make sure that the storage battery connectors connecting it to the aircraft electric mains are sound.

The inspection over and the detected troubles eliminated, turn off all the switches but for the interlock switch operating with the generator switch connecting bar; place the storage battery change-over switch neutral, connect the ground supply source and carry out the voltage check of the electrical equipment.

Correct all the troubles detected during the voltage check. Troubles should be eliminated with the aircraft electric mains de-energized.

The inspection and trouble eliminating procedure over, report the electric equipment readiness for operation and termination of the operations to the aircraft technician and the special equipment technician.

Checking Instruments for Serviceability

1. Turn on the 130-2 circuit breaker and the cabin air temperature regulator on the circuit breaker control panel of the co-pilot.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



2. Place the CABIN AIR SUPPLY TEMPERATURE (TEMPERATYPA HALOVYA KLYMA) selector switch mounted on the co-pilot's instrument panel to the HOT (TAV) position. In this position the MPT-1 actuator of the turbine-driven cooler should close the cooler and open the cabin air temperature regulator.
3. With the selector switch thrown to COLD (KOL), the electric actuator should operate in the reverse direction.
4. Set the change-over switch to the AUTOMATION (ASTOMAT) position.
5. Set the cabin air temperature regulator thermostat scale of the first cabin to read 3 to 5°C lower than the ambient air temperature. In this position the MPT-1 electric actuator should cut out the cabin air supply temperature regulator and engage the turbine-driven cooler.
6. Set the thermostat scale to read 3 to 5° above the ambient air temperature. In this position the MPT-1 actuator should engage the cabin air supply temperature regulator and cut off the turbine-driven cooler.
7. The thermostat of the rear cabin will be checked with employment of the same procedure.
8. If the ambient air temperature does not permit to set the thermostat scale at a temperature higher or lower than the original one, it is necessary first to heat up or cool down the thermostat to a temperature of 19 - 23°, and then to carry out the check according to steps 4 - 7 above.

Due to the fact that the regulator check for meeting the Specifications requires bulky fixtures which are not in quantity production, it proves impossible to carry out the checks directly in the using unit. Therefore adequate operation of the temperature regulator will be judged upon by its satisfactory functioning to maintain the pre-assigned cabin air temperature in the course of the flight.

**Automatic Cabin Air Temperature Regulator, Type PERK-45**

The regulator, type PERK-45, is designed for automatically maintaining the pre-assigned air temperature in the pressurized aircraft cabin.

- The regulator set includes:
- one thermostat, type TPERK-24;
  - one electric actuator, type MPT-1.

**Basic Characteristics**

1. Nominal voltage requirement .....	27.5 V
2. Temperature control range .....	16.5 to 26.5°C
3. Accuracy (no-response zone) .....	±1°C
4. Degree of feedback irregularity .....	4%
5. Current requirement by MPT-1 actuator .....	not over 1 A
6. Nominal shaft load of MPT-1 actuator .....	120 kg/cm.
7. Rotation angle of MPT-1 actuator output shaft .....	135° ± 3°
8. Time required for MPT-1 actuator output shaft to turn through 135° ± 3° .....	not longer than 45 sec.
9. Operating duty of MPT-1 actuator .....	intermittent
10. Resistance of MPT-1 actuator potentiometer .....	400 ± 20 ohms

All the units of PERK-45 are interchangeable.

50X1-HUM

**PHOTOGRAPHIC EQUIPMENT**

**GENERAL**

- The photographic equipment carried by the aircraft includes:
- set of cameras A9A-33/50M, A9A-33/75M and A9A-33/100M intended for daytime photography of the ground targets;
  - set of cameras HA9A-30/50 or HA9A-6/50 for night time photography of the ground targets;
  - camera GAPI-1 for photographing the screen of the cathode-ray tube of radar bomb sight PBU-4;
  - automatic tilting mount ARAW-156H for all daytime cameras;
  - camera mount (frame HA9A) for night time cameras;
  - camera hatch;
  - camera hatch and tilting mount control panel.

Arrangement of the photographic equipment on the aircraft is shown in Fig. 116.

The aircraft may carry only one of the aforementioned cameras (besides camera GAPI-1 which is never removed) and one camera mount.

The camera mounts (tilting mount ARAW and the frame) are installed on spring-loaded shock absorbers selected according to the camera weight. Furnished with the aircraft are shock absorbers coming in three variants to fit cameras HA-33/100M, A9A-33/75M and HA9A-33/50M; HA9A-30/50 and HA9A-6/50.

The automatic tilting camera mount ARAW-156H ensures two-strip vertical and oblique photography. In the case of two strip photography (AERIAL RECONNAISSANCE mode of operation), the camera mount departs from the vertical plane through 6°30' to both sides when carrying camera A9A-33/100M and through 8°30' when carrying camera A9A-33/75M.

Note: Camera A9A-33/50M is not employed on aircraft T7-16 with the AERIAL RECONNAISSANCE mode of operation because only part of the light rays of the camera vision field (34°) pass through the camera hatch hole.

During the oblique photography (BOMBING CONTROL mode of operation), the automatic tilting camera mount ARAW-156H deflects against the flight through the angles of 0, 10, 15, 20 and 25°.

Aerial cameras for daytime photography can be operated at various altitudes depending on the scale of aerial survey.

Minimum survey altitude depends on the flight speed and is calculated by the formula:

$$H_{\min.} = \frac{1}{360} \text{ KPV,}$$

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

- 186 -		- 187 -	
<p>where: <math>H_{min}</math> - minimum altitude of flight in km.;  <math>t</math> - exposure time in seconds;  <math>F</math> - focal length of aerial camera in km.;  <math>V</math> - speed of flight in km/hr.</p> <p><u>Specifications</u>  <b>Daytime Photography Camera A9A-33/100H</b></p> <ol style="list-style-type: none"> <li>Picture size ..... 30x30 cm.</li> <li>Number of pictures ..... 190 to 195 per</li> <li>Size of film to be threaded up ..... 32x5000 cm.</li> <li>Photography cycle time:  at 15 to 25°C temperatures ..... not exceeding 2 s.  at -60°C temperature ..... not exceeding 2.5 s.</li> <li>Power consumed  at 15 to 25°C temperatures ..... up to 13.5 A  at -60°C temperature ..... up to 16 A</li> <li>Focal length:  camera A9A-33/100H ..... 100 cm.  camera A9A-33/75M ..... 75 cm.  camera A9A-33/50M ..... 50 cm.</li> <li>Interframe space ..... 10 to 25 mm</li> <li>Camera controller intervals ..... 2 to 60 sec.</li> <li>Thermoregulator:  engagement temperature ..... 3 to 13°C  disengagement temperature ..... 20 to 30°C</li> <li>Camera controller ensures functioning of the camera upon keeping electric bomb release button BCRP pressed for 0.2 - 0.3 seconds</li> <li>Exposure time (expressed in fractions of second):  cameras A9A-33/50M and A9A-33/75M ..... 1/75;  1/150;  1/300  camera A9A-33/100H ..... 1/75; 1/125; 1/200</li> </ol> <p><b>Camera A9A-30/50</b></p> <ol style="list-style-type: none"> <li>Focal length ..... 50 cm.</li> <li>Picture size ..... 18x24 cm.</li> <li>Number of pictures ..... approx. 190 per</li> <li>Shutter ..... louvre type</li> <li>Exposure time (expressed in fractions of second) .. 1/25; 1/50; 1/100</li> <li>Power consumed:  at 10 to 30°C temperatures ..... 12 A  at -60°C temperature ..... 13.5 A</li> <li>Photography cycle time ..... not exceeding 3 s.</li> <li>Shutter operation optical exposure ..... 2 to 15 luxes of photocell</li> </ol>		<p><b>Camera HA9A-6/50</b></p> <ol style="list-style-type: none"> <li>Focal length ..... 50 cm.</li> <li>Picture size ..... 18x24 cm.</li> <li>Shutter ..... louvre type</li> <li>Exposure time in fractions of second ..... 1/25; 1/50; 1/100</li> <li>Power consumed:  at 10 to 30°C temperatures ..... 12 A  at -60°C temperature ..... not exceeding 15 A</li> <li>Photography cycle time ..... not exceeding 3 sec.</li> <li>Camera operation temperature range ..... +50°C to -60°C</li> <li>Shutter operation optical exposure ..... 1 to 15 luxes of photocell</li> </ol> <p><b>Camera #APA-1</b></p> <ol style="list-style-type: none"> <li>Focal length ..... 100 mm</li> <li>Picture size ..... 13 cm. in dia. (13x18 cm. frame)</li> <li>Film, perforated  width ..... 19 mm.  length ..... 28.5 m.</li> <li>Number of pictures taken without loading the film magazine ..... approx. 200</li> <li>Cycle of camera operation ..... alternative, depending on the antenna revolutions or sector scanning angle</li> <li>Power consumed:  with heater off ..... 5.3 A  with heater on ..... 15.6 A</li> <li>Camera operation temperature range ..... +50°C to -60°C</li> </ol> <p><u>Technical and Adjustment Data of Automatic Tilting Mount ARAW-15GH</u></p> <ol style="list-style-type: none"> <li>Original position of the automatic tilting mount ARAW is the vertical zero position of the aerial camera A9A set within +0°30' to -1° tolerance.</li> <li>The tolerance for the tilting angle should stay within: +0°30' to -1° for 6°30' and 8°30' tilting angles in the AERIAL RECONNAISSANCE mode of operation;  +0°30' for 0; 10; 15; 20; 25° tilting angles in the BOEMING CONTROL mode of operation.</li> <li>In the zero position, the play of the automatic tilting mount should be within ±0°30' (without taking into account the play in the reduction unit of the electric mechanism MYO-2).</li> <li>Time of changing the automatic tilting mount from one extreme position to the other:  in the AERIAL RECONNAISSANCE mode of operation - 0.9 to 1.5 sec.</li> </ol>	

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 188 -

in the BOMBING CONTROL mode of operation when tilting  
from 0 to 25° and from 25 to 0° - 1.9 to 3.5 sec.

5. Minimum permissible interval between exposures in the AERIAL RECONNAISSANCE mode of operation - 3 sec.
6. Current pulse sent by the contact-pulse mechanism of camera 40A should not last longer than 0.3 sec.
7. The automatic tilting mount AKAV must reliably operate at temperature from +50°C to -40°C and relative humidity up to 96%, withstanding vibrations of 10 to 20 cycles.
8. Service life of the automatic tilting mount AKAV guaranteed covers 2 years including 21,000 cycles of operation (20,000 cycles in the AERIAL RECONNAISSANCE mode of operation and 1000 cycles in the BOMBING CONTROL mode of operation).
9. Current in the circuit of electric mechanism MPA-2 in the AERIAL RECONNAISSANCE and BOMBING CONTROL modes of operation with camera 40A installed in the automatic tilting mount AKAV should not exceed 10 A when the voltage applied is within  $27 \pm 2.7$  V.
10. During the BOMBING CONTROL mode of operation, reverse movement limit switch must function at the moment when the frame moving from the lower position pass the zero by 1 to 1.5°.
11. The limit switch labelled STARTING FROM EXTREME POSITIONS (ПУЛКЕ И КРАЙНЕМ ПОЛОЖЕНИИ) must function in the zero position of the AERIAL RECONNAISSANCE mode of operation, keeping OFF all the time the frame remains in the extreme positions.
12. Accuracy of operation of the limit switches of all fixed positions for the tilting angles - 20°/30°.

#### Technical and Adjustment Data of Mount (Frame HA9A) for Night Time Photography Cameras

1. The mount may accommodate either camera HA9A-Jo/50 or camera HA9A-6A.
2. The mount (frame HA9A) is intended to change the camera tilting angle from 0 to 25° against the flight every 2°/30°.
3. The camera is set at the required tilting angle on the ground.
4. Frame HA9A is fixed in the lower attachment sleeves of camera mount AKAV-156H. The shock absorbers should be free of vertical play.
5. The inner frame of the camera mount (frame HA9A) must be fixed without play at all tilting angles of the camera.
6. The camera cables should not be in the way of the camera (frame HA9A) tilting irrespective of the angle.

#### Main Technical and Adjustment Data of Camera Hatch

1. The camera hatch doors are opened inside the fuselage with the aid of the remote-controlled mechanism JP-7M.
2. Strain of band pulls - 8 to 12 kg.
3. Door opening and closing time - 40 sec.
4. The current consumed by mechanism JP-7M should not exceed 8 A under the rated voltage.
5. Coat all friction parts of the camera hatch actuator with lubricant of State Standard ГОСТ 3276-54. There is no need to apply lubricant to the rails surface on which the doors and rod bearings move.

- 189 -

#### PREFLIGHT PREPARATION

Preflight preparation of the daytime photography cameras includes:

- (1) checking of the camera hatch;
- (2) installation of the automatic camera tilting mount AKAV;
- (3) mounting of the camera and its preliminary checking;
- (4) checking of the tilting mount operation;
- (5) preparation of the cameras for surveying.

Preflight preparation of the night time photography cameras includes:

- (1) installation of frame HA9A;
  - (2) installation of the night time photography cameras and their preliminary checking;
  - (3) preparation of the cameras for surveying.
- Preflight preparation of camera 9AP-1 includes:
- (1) installation of camera 9AP-1;
  - (2) checking of the camera mechanism functioning;
  - (3) preparation of the camera for flight.

#### Preflight Preparation of Daytime Photography Cameras. Checking of Camera Hatch

Check the camera hatch doors for proper closing and opening (Fig.117) by turning the switch mounted on the control panel (Fig.118) 2 - 3 times on and off. Bring and be sure the camera hatch functions properly, proceed to installing the automatic camera tilting mount AKAV or frame HA9A.

#### Installation of the Tilting Mount AKAV-156H

When doing survey jobs with the aid of camera 40A-33/100M, install the tilting mount (Fig.119) with the shock absorbers, having on the cover marking A-1000, on the upper row of the sleeves; in the case of camera 40A-33/75M or 40A-33/50M, install the tilting mount with the shock absorbers, having on the cover marking P-750, on the lower row of sleeves. The tilting mount being been installed, tighten the shock absorber sleeves as far as they will go with the aid of union nuts 1.

- Notes: 1. For installing the automatic tilting mount, remove the partition separating the case leg wall from the camera bay.
2. Install the tilting mount horizontal accurate within 40°/30° to -1° with the aircraft in the line-of-flight position.

Set the crank of the mount tilting mechanism with the aid of locking screw 11 at 6°/30° when camera 40A-33/100M is to be installed and at 8°/30° when camera 40A-33/75M is to be installed. Mount the bonding strips.

#### Camera Installation

To install the camera:

1. Release hinged clamps 7 (See Fig.119).
2. Bring the camera trunnions in the seats of the tilting mount AKAV and fix them with the aid of clamps.

Note: The chamber portion must be brought to the position shown by the arrow marked on the film magazine (with the cartan shaft of the driving unit set right of the aircraft fore-and-aft axis).

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

3. Arrange the driving and delivery unit on plate 6 and connect it to the reducing gear on the chamber portion with the aid of cardan shaft 3. The shaft bands in this event should not exceed 25° at the hinge joints.
4. Use flexible hose 4 to connect the air blower valve chamber to the chamber portion pipe connection.
5. Adjust screws 2 to zero the automatic tilting mount ARAGV accurately within ±0°30' to ±1°.
6. Connect all the units with electric cables.
7. Mount camera controller KUV-2 on the navigator's panel and join plug connectors to it.

Checking of Cameras A9A-33/100M, A9A-33/75M and A9A-33/50M. Focusing.

1. Take the levers all the way out of the chamber portion and remove the protective cover from the latter.
2. Set 5 - 7 sec. interval on the camera controller dial (Fig.120).
3. Press the green button START (DVCK).

As the chamber portion of the driving and delivery unit operates, check the air delivery to the chamber portion, functioning of the shutter and the objective protective covers, and the illumination of the recording instruments at the moment of the shutter operation.

4. Arrange the film magazine loaded with the exposed waste film on the chamber portion and take the cover off the film magazine.

Press button START (DVCK) on camera controller KUV-2. As camera film operates, check the film for proper rewinding watching the indicating lamp labelled REWINDING (HEFENOTHA), the pressure plate for proper rising and lowering and the camera controller meter for proper operation. This done, disengage the camera controller by pressing the STOP (OCTAROB.) button.

5. Disconnect the cardan shaft from the chamber portion reducing gear and the reducing gear driving unit.
6. Connect the hand drive to the input shaft of the chamber portion rotary gear.

7. Slowly rotate the hand drive handle clockwise to check the functioning of the shutter (accompanied by a click).

8. Beginning with the moment the shutter starts functioning count the number of the hand drive handle revolutions up to the closing and opening moments of the protective covers.

9. Check the air pressure in the chamber seeing that it is at least 1X of water.

The aerial camera is considered ready for employment on the aircraft if the check-up has proved positive.

Checking of Operation of Automatic Tilting Mount ARAGV-156H.

During the BOMBING CONTROL (KONTPOB BOMBOHSTANHH) mode of operation:

1. Set the continuous operation switch on camera controller KUV-2 at OFF (BUDAPRHO), the BOMBING CONTROL (KONTPOB BOMBOHSTANHH) switch at INTERVAL (HTEPEBAI) and turn the setting dial at 5 - 7 second inter-exposure interval.
2. Set the mode-of-operation selector on the control board (See Fig.118) located on the navigator's panel at the BOMBING CONTROL (KONTPOB BOMBOHSTANHH).

3. Press the START (DVCK) button with the camera hatch closed and make sure the red indicating lamp labelled CURRENT ON (TUK BLEDNEN) goes on but the camera does not operate. The REWINDING (HEFENOTHA) lamp must be either ON or OFF depending on the position of the rewinding indicating contacts. Press the STOP (OCTAROB.) button.

4. Open the camera hatch. To this end, set the switch on the control panel to the CAMERA HATCH OPENED (SOTUMER OTKRYT) position and make certain that green indicating lamp 4 on the control panel glows when the camera hatch is fully opened.

5. Press the START (DVCK) button again and make certain the camera operates at preset intervals every 5 to 7 seconds and the green indicating lamp marked REWINDING (HEFENOTHA) flickers. After making 4 to 6 exposures, disengage the camera controller by pressing the STOP (OCTAROB.) button.

Note: If the ambient air temperature is below 15°C, cut in the heater switch on camera controller KUV-2 at least 15 minutes before proceeding to the check-up.

6. Check the functioning of the camera tilting mount ARAGV during the BOMBING CONTROL (KONTPOB BOMBOHSTANHH) mode of operation as set at 0°, 10°, 15°, 20°, 25° tilting angles. For this purpose: bring angle-of-tilt selector 2 (See Fig.118) on the control panel to every angle setting, successively; then press button 6 and let go of it. Make sure the electric mechanism has operated, inner frame 10 (Fig.119) has turned around semi-axle 5 together with intermediate frame 8 to set the camera at the desired tilting angle, and yellow indicating lamp 5 on the control panel (See Fig.118) is on.

To return the automatic camera tilting mount ARAGV to the original (zero) position, set angle-of-tilt selector 2 at 0° and press button 6. After a while, yellow indicating lamp 5 goes on to show the tilting mount has assumed its zero position.

7. If it is necessary to set the mount at a greater tilting angle (e.g. changing it from 15° to 20°), first return tilting mount ARAGV to the zero position, wait till the yellow indicating lamp has gone on and only then bring the mount to the tilting angle required. There is no need to return the automatic tilting mount to the zero position should it become necessary to set it at a smaller tilting angle (e.g. changing it from 20° to 15°).

Checking of Tilting Mount ARAGV-156H in BOMBING CONTROL Mode of Operation (Accounted by Electric Bomb Release)

Prior to checking, make certain the bombing equipment circuit is absolutely faultless. Then:

1. Set the electric bomb release to drop single bombs.
2. Cut in the bomb release circuit breaker and the bomb release main switch; make sure all other switches, selectors and bombing equipment circuit breakers are OFF.
3. Bring the yellow index of the setting dial on the camera controller opposite 4-km. altitude. Tilt the mount through the required angle.
4. Press the START (DVCK) button on camera controller KUV-2. After that, the green indicating lamp labelled READY FOR BOMBING CONTROL (TOBOK BOMBOHSTANHH) and the red indicating lamp labelled CURRENT ON (TUK BLEDNEN) must go on.
5. Press button KCF-49. After that, electric bomb release button

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 192 -

BCFP-49 must operate, and the green indicating lamp on the camera controller goes off. In 20 seconds (i.e. 10 seconds before the "burst" of the bomb) this lamp should go on again to flicker in the course of 25 ± 2 seconds (the camera performs continuous survey).

The aforementioned period lapsed, the lamp should go off and then light up again (mechanism of camera controller KIV-2 has come to the original position).

**Note:** If continuous photography is imperative, set switch 12 (See Fig.120) to CONTINUOUS PHOTOGRAPHY ( НЕПРЕРЫВНАЯ ПЯСМА ), selector 13 to INTERVAL ( ИНТЕРВАЛ ), and adjust setting dial 7 to bring infinity symbol ( ∞ ) marked on the camera controller dial opposite the white triangular index. In that instance, the camera will function continuously until the STOP ( ОСТАНОВ. ) button on camera controller KIV-2 is pressed. During 25-sec. period of continuous survey done in the BOMBING CONTROL ( КОМПЛЕКС БОМБОУСТАНОВКИ ) mode of operation, the camera taken 11 - 13 pictures in all (5 - 6 pictures before the "bomb burst" and 6 - 7 pictures after it). The aerial camera cycle is repeated during the next "bomb run".

6. The surveying operations having been completed, return the automatic camera tilting mount ARAGV to the zero position.

**Checkins of Automatic Tilting Mount ARAGV-156H in AERIAL RECONNAISSANCE Mode of Operation (Two-Strip Photography)**

1. Set the mode-of-operation selector on the control panel at AERIAL RECONNAISSANCE ( ПЯСМЕНА ) and make sure the camera mount has tilted through 6°30' or 8°30' outward off the zero(original) position depending on the position of the locking bolt on the crank mechanism.

2. Set 5 - 7 sec. interval between the exposures on the camera controller dial, turn the continuous photography switch at OFF ( ВЫКЛЮЧЕНО ), and the BOMBING CONTROL ( КОМПЛЕКС БОМБОУСТАНОВКИ ) switch, at INTERVAL ( ИНТЕРВАЛ ).

**Note:** When the automatic tilting mount ARAGV is engaged in the AERIAL RECONNAISSANCE ( ПЯСМЕНА ) mode of operation, 2-sec. inter-exposure interval and CONTINUOUS SURVEY ( НЕПРЕРЫВНО ) mode of operation are not allowed.

3. Press the START ( ВКЛ ) button on camera controller KIV-2. The camera starts functioning at preset intervals and the contact-pulse mechanism sends pulse of current to relay PIV-2. Make sure electric mechanism KIV-2 intended to govern the camera operation has functioned to change the tilting mount to the opposite position. Watch the indicating lamp on the control panel to make certain the automatic tilting mount functions properly.

The normal operation of aerial camera A91 is shown by flickering of the green indicating lamp labelled ВЕРДИНДО ( ВЕРДИНТО ) on the camera controller and by proper functioning of the exposure counter.

4. At the chosen mode of operation of the tilting mount, make a 8 to 10-exposure series and then disengage the camera controller.

5. During the AERIAL RECONNAISSANCE mode of operation, the tilting mount is checked without the camera controller and camera A9A. The check-up is performed by pressing and releasing button 9 (See Fig.119) labelled CHECK UP OF TILTING

- 193 -

50X1-HUM.

**WIRE OPERATION ( ПРОВОДКА ПЯСМЫ МАШАКИ )** and arranged on the inner frame. As button is pressed to move the frame from one extreme position to the other where it stops. Upon pressing the button for the second time, the tilting mount comes back to its original position. As the tilting mount passes the zero position, respective can close the supply circuit of the indicating lamp on the control panel. The lamp flickers to indicate normal functioning of the automatic camera tilting mount during the AERIAL RECONNAISSANCE mode of operation.

**Preparation of Aerial Camera for Flight**

1. Take the protective covers off the objective.
2. Wipe the objective using a special piece of cloth.
3. Install an appropriate light filter and set the required exposure.
4. Zero the exposure counters of the chamber portion and camera controller.
5. Mark on the film magazine panel the navigator's name, data and the aircraft number painted on its tail using a lead pencil, wind the aerial camera clock and synchronize it with the aircraft clock.
6. Load the film magazine with the film required for the survey mission. Perform the loading job in a special case (furnished with the aircraft) or in a special room. If the aerial film spool has a leader, the film may be loaded directly on the aircraft in daylight. Prior to loading, carefully examine the film magazine, select a set of film spools to fit, mark the camera number on the spool flanges and load the magazine with these spools only.
7. Arrange the film-loaded magazine in its place, lock the latches and open the film magazine gate all the way out until four red marks are aligned.

**Preflight Preparation of Camera HA9A**

Prior to mounting frame HA9A on the aircraft, check the operation of the camera hatch.

**Installation of Frame HA9A**

1. Remove the partition separating the nose leg well from the camera bay.
2. Set frame HA9A on the lower row of sleeves (Fig.121).
3. Bring frame HA9A horizontal accurate within 215' using washers 234450-1-8-16 placed between the shock absorbing roller and the shock absorber (with the aircraft in the line-of-flight position).
4. Coat all flexible joints with lubricant ЖЕМ State Standard ГОСТ 3276-54.
5. Set the bonding strips.

**Mounting of Camera HA9A**

1. Unscrew the bolt wing nuts from the camera brackets.
2. Bring the bolts into the slots of the sliding frame and screw the wing nuts on.
3. Mount the camera controller, converter 1 and automatic release 28 (the two latter for camera HA9A-30/50 only) on the dome-tails.
4. Connect all members of the camera for night photography with electric cables.

**Checking Camera HA9A for Proper Operation**

1. Open the camera hatch and check the interlocking microswitch for faults closing.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 194 -

2. Pull out the locking latches as far as they will go and remove the protective cover from the camera attachment frame.
3. Cut in the camera controller common switch (Fig. 122) and press the CHECK UP (HPOBEFPA) button 1 - 2 minutes later.
4. As the camera functions, check the operation of the shutter and exposure counter.
5. Discontinue the power supply and fit the magazine loaded with exposed waste film in the camera.
6. Remove the film magazine cover and open the gate.
7. Energize the camera, press the CHECK-UP (HPOBEFPA) button and as camera HA9A functions check the film rewinding, lowering and raising the pressure plate, going on and out of the REWINDING (HPRHOZKA) indicating lamp in the camera controller, glowing of the CHECKER ON (TKH BEIYKH) and ILLUMINATION (HOBEBEYKA) lamps at the instant the button is pressed.

Checking Units of Camera HA9A for Timely Functioning  
During Operation Cycle

1. Press the button labeled CHECK-UP (HPOBEFPA) to check the shutter operation aurally.
  2. Perform 8 - 10 successive cycles of the camera to check the film rewinding mechanism performance. The film rewinding should start after the pressure plate has gone up and before the pressure plate has lowered all the way down. Pay more than ordinary attention that the camera does not operate spontaneously without pressing the button.
  3. Press the button marked CHECK-UP (HPOBEFPA) and keep it pressed to make sure the camera does not operate after the shutter has functioned. The camera must perform one operation cycle upon releasing the button.
  4. Disconnect the connector plug from the camera.
  5. Unscrew the threaded plug and connect the camera crank to the input shaft and count the revolutions up to the moment the pressure plate starts moving upward (the number of the camera crank revolutions should keep within 42 to 10).
  7. Engage the common switch, press the CHECK-UP (HPOBEFPA) button to perform 2 - 3 cycles and keep it pressed while turning-off the common switch; this done, release the button.
- When the common switch is turned off, the camera must function to bring the pressure plate all the way upward.
8. Close the gate and disconnect the connector plug from the camera. The above operations performed, camera HA9A is considered ready for film survey.

Preparation of Camera HA9A

1. Take the protective cover off the camera blind.
2. Wipe the objective lens with a piece of flannel.
3. Set the exposure time required.
4. Tilt the camera through the required angle.
5. Connect the camera to the aircraft mains.
6. Fill the magazine with the film.
7. Press the locking hooks and take the locking latches all the way out.
8. Mount the film magazine on the chamber portion and secure it with the aid of locking latches.

- 195 -

9. Open the gate all the way out.
10. Try the camera operation by snapping 2 - 3 shots. Check the film for being properly rewound (by flickering of the indicating lamp on the camera controller) and the shutter for proper functioning (by watching the shutter from the objective side, or aurally by a click).
11. Check the heater of the camera controller for proper operation. For this purpose, cut in the heater switch and make sure the heater is operative.
12. Remove the cover of the automatic release AC and wipe the protective glass of the photocell (for camera HA9A-3c/50).

Pre-flight Preparation of Camera 9AP-1

Mounting of Camera 9AP-1

- Camera 9AP-1 (Fig. 123) are furnished with sets and mounted on the plane by the aircraft works.
- The installation instructions for this camera are set forth should the necessity arise to substitute the camera or install it after maintenance.
- To mount camera 9AP-1:
1. Take middle-portion jacket 3 from the camera.
  2. Take lower focusing ring 5 of the taper portion.
  3. Carefully unscrew guiding pins 10 attached to the housing where the objective is secured.
  4. Take out the upper focusing ring.
  5. Take the nut and locknut from the bottom part of the chamber portion.
  6. Install the chamber and taper portions of the camera on the camera mount and lock it with nuts.
  7. Mount the focusing rings, guiding pins and middle-portion jacket in the reverse order.
  8. Install the assembled camera mount on the aircraft between the radio operator's stand and the main control panel and secure it by means of quick-release locking studs 6.
  9. Connect cathode-ray tube 1 to the camera middle portion jacket. Fit clamp 11 onto the shock-absorbing lugs of the cathode-ray tube instead of the shock absorbers with a view to attaching the tube to the frame posts. See that the indicator is set without misalignment and securely tightened by the jacket clamp. Pay attention that the jacket lugs closely adhere to the glass or to the light filter.
  10. Set the bonding strip.
  11. Set the spring braces and adjust the springs so that they are uniformly tightened.
  12. Connect the electric cable parts.
  13. Connect one of the branches of cable PA to the 27 ± 2.7 V D.C. source so that one pole of the branch should be periodically closed by hand thereby sending pulses to the can relay.
  14. Connect the fuse link of MAINS (CTB) cable to the camera controller.
  15. Set the camera controller common switch to the lower position marked OFF (VIMYEDO).
  16. Zero the camera controller counter.
  17. Set the sector scanning and circular scanning indicator switches to the position the branch of cable PA is connected to at the present moment.
  18. Connect the supply plug to the 27 ± 2.7 V D.C. source.
  19. Proceed to checking the serial camera.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 196 -

20. Connect the aerial camera and the camera controller by means of electric cables.

#### Checking the Camera Operation

1. Press the latch and shift it to make sure the drive loading axle sinks all the way down and then comes back to the original position.
2. Set the antenna multiple frequency control at interval 5.
3. Change the gang switch to ON (BREMERS) and make sure the red lamp on the camera controller and the digital drum illumination lamp are glowing.
4. Send pulses to the cam relay regularly closing the circuit. Make certain that after application of the first pulse the yellow lamp goes on to indicate that the shutter is opened, the second pulse showing that the film has been rewound.
5. Set the selector at 0 (OPERATION) and check the camera by pressing the single exposures button.
6. Discontinue the power supply and install the magazine loaded with exposed waste film on the chamber.
7. Take off the film magazine cover.
8. Check the mechanics functioning by turning the camera crank and watch the film rewinding process.
9. Cut in the gang switches and occasionally send pulses to the cam relay.

While the camera is operating, watch the camera controller for glowing of the green indicating lamp (film rewinding), of the yellow lamp (shutter opening) and for the raising and lowering of the pressure plate crosspiece. This check-up requires that the end of the lever keeping the pressure plate in the upper position should be pressed.

#### Checking Units of Camera GAF-1 for Timely Functioning during Operation Cycle

1. Open the side cover of the camera and take out electric motor MA-40A.
2. Insert the driving crank.
3. Remove the film magazine and the cover from the change speed gear box.
4. Slowly rotate the handle of the hand drive clockwise until the contacts of the recording instruments illumination system have closed, count the number of the revolutions up to the starting moment of the pressure plate rising.
5. Mount the film magazine loaded with exposed waste film on the chamber.
6. Take the cover off the film magazine. Turn the driving crank to actuate the mechanics. Be sure to manually disconnect the lever keeping the pressure plate in the upward position.

Starting from the moment the contacts of the recording instruments illumination system are closed, count the number of the driving crank revolutions up to (a) raising of the pressure plate, (b) termination of the film rewinding process, (c) initial point of the table lowering. The revolutions counted must correspond to the table coming under "Adjustment and Technical Data" of the Manual furnished with the camera.

#### Preparation of Camera GAF-1 for Flight

1. Open the side holes made in the jacket for cleaning the cathode-ray tube open the shutter and fix the shutter opening lever in position with the aid of the pawl.

2) Single exposures setting

- 197 -

2. Bring the ground object images yielded by the screen of the cathode-ray tube to their sharpest definition, place a diffusing glass on the flattening glass, focus the camera and bring the image to sharp focus adjusting the objective with the aid of the focusing rings.

**Note:** Place the diffusing glass on the flattening glass with the frosted surface facing downward.

3. After focusing, be sure to check if the rings are locked and unclasp the shutter opening lever.
4. Load the magazine with the film.
5. Let go of the latch, draw the catch out and take the protective cover off the camera.
6. Install the film magazine and lock it with the catch.
7. Turn the actuator handle to make one or two operation cycles.
8. Set the antenna multiple frequency per exposure in accordance with the air survey mission.
9. Set the sector scanning and circular scanning selector to the required position.
10. Zero the counter drums.
11. Check the camera for proper functioning by taking 2 - 3 shots, make sure the film is being rewound watching the indicating lamp and the film rewinding mechanical indicator arranged on the film magazine. Follow the shutter opening by watching the indicating lamp.
12. Set the sensitivity potentiometer knob to fit the type of film loaded in the magazine.
13. Make sure the silica gel cells are available in the chamber.
14. Wind and set the clock.
15. Try the camera operation by taking two-three pictures.

#### POSTFLIGHT OPERATIONS


##### General

After taxiing the aircraft to the parking site, the photographic equipment technician must:

- (1) Try the camera operation in the presence of the navigator by taking one or two pictures with the camera hatch opened. If the whole of the film has been exposed during the flight, the camera operation will be checked aurally.
- (2) Ask the navigator about the operation of the photographic equipment in the air and fill in the standard form.
- (3) Close the camera hatch and the gate, and take out the film magazine. It is **PROHIBITED** to close the gate with the film magazine pressure plate in the downward position.
  - (a) Put the protective cover on the camera.
  - (b) Protect the blind and the automatic release window (for HA9A-3c/50 camera) with the covers.
  - (c) Place the film magazine in its container, remove the automatic release of camera HA9A-3c/50 to be kept in dry premises.
  - (d) Unload the magazine and send the exposed film to be processed.
  - (e) Carry out thorough outer inspection and clean the photographic equipment of dust and fouling. While doing this, the technician should check:
    - condition of the camera units and parts accessible without disassembly of the mechanisms;

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

attachment of the camera mounts to the aircraft members, and that of the cameras to the camera mounts; attachment of the camera controller and indicating lamps; attachment and condition of the camera hatch doors and camera hatch door actuating mechanism; condition and attachment of the electric cables to the camera, camera controller, etc.

**Note:** After high altitude flights, special attention should be paid to the aircraft optics.

(9) After examination of the camera, eliminate all the defects revealed during the flight and during the inspection.

(10) Load the film magazine with the film and install the former in the camera.

(11) Disconnect the camera (with the exception of camera OIPI-1) from the aircraft main, loosen the shutter spring, set the maximum exposure value, set the camera objective with the cover and close the camera hatch doors.

**Unloading Film Magazines of Day and Night  
Photography Camera and Camera OIPI-1**

Unload the film magazine in the dark room or in a special cover. To this end:

1. Place the film magazine on a clean table so that the actuating head stands to the right.
2. Turn off the light in the dark room.
3. Take off the film magazine cover and disengage the metering roller.
4. Press the film magazine locking mechanism lever and remove the spools from the container.
5. Rotating the idle gear, wind over two-three frames of the unexposed film and then cut the film off the take-up spool.
6. Take out the take-up spool.
7. Mark the date of aerial survey and the navigator's name on the end portion of the exposed film using a frame free from pictures.
8. Wrap the film-loaded spool in black paper and put it into the film can.
9. Mark on the can containing the exposed film the size, grade and sensitivity of the film, the date of unloading, return card number and the name of person responsible for unloading the film magazine.

**Loading Film Magazines of Day and Night  
Photography Camera**

Load the film magazine in the dark room or in a special cover designed for the purpose.

In case the film is loaded in the dark room, it should be handled on a clean and dry table free of foreign objects.

**Loading Procedure**

1. Take the film magazine from the film magazine holder and place it on the table.
2. Prior to loading, open the film magazine cover. Load the film either in non-actinic light, or in complete darkness. If the film is provided with a leader, the loading may be done in diffused light, too.
3. Remove the film spool from the film can and fix it to the semi-axes of

cut the film should come toward the operator with the emulsion layer outside. Run the scrabble semi-axle all the way in.

4. Make sure the spool freely rotates on the semi-axes playing, but slightly.

5. Raise the film magazine mechanism and pass the film around the guiding roller so that it is arranged between the fillets. Then bring the film under the pressure plate and between the metering rollers having previously disconnected the latter by applying pressure to the draw-out clamp. Pass about 20 to 25 cm. length of film between the metering rollers.

6. Loop the film over the take-up spool fixed in place, pass it around the spool and insert the film end into the slot so that the film is arranged symmetrically relative to the spool flanges.

7. Rotating the idle gear counter-clockwise, transport approximately two frames seeing that the film is properly arranged relative to the flanges and bring it against warping. Stop rotation as soon as the pressure plate has come to the upward position.

8. Replace the cover to the film magazine.

**Loading the Film Magazine of OIPI-1 Camera**

Load the film magazine with the film on the dry and clean table. Place the magazine so that its base rests on the table with the film rewinding mechanical initiator to the right. If the film spool is provided with a paper leader, the film magazine may be loaded in diffused light, too. In case no leader is available, the loading should be done in complete darkness.

**Loading Procedure**

1. Take the cover off the film magazine and then hand-press the centre of the pressure plate.
2. Turn the safety latches and draw the semi-axes out.
3. Insert the film-free take-up spool in the film magazine.
4. Insert the film-loaded supply spool.
5. If the leader of the film is not ready for threading, cut it with scissors at 45°. The leader should clear the spool and pass in the direction to the operator. Take up from the spool 30-40 cm. of the film and pass the threading end into the slot between the guiding roller and the edge of the light trap. Turn the film magazine over and place it between the metering roller and the light trap.
6. Again put the film magazine on the base, fix the leader to the take-up spool, make sure that the film is properly aligned and the metering roller perforation teeth have entered the film perforation holes.
7. Holding the supply spool, give the take-up spool two-three turns in. The taut film must closely adhere to the take-up spool.
8. Replace the cover to the film magazine according to the marks made on the film magazine housing. After that, securely lock the cover by means of the screw.
9. Place the film magazine in its jacket.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 201 -

**RADIO EQUIPMENT**  
**BRIEF INFORMATION**

The aircraft radio equipment includes radio communication, radio navigation and radar facilities.

The radio communication facilities include:

- (a) aircraft interphone system CNU-10;
- (b) communication radio set I-PCB-70 with receiver VC-9;
- (c) command radio set I-PCB-70M with receiver VC-9M;
- (d) command ultra-short wave radio set PCW-JW with two receivers.

Arrangement of elements of the radio communication facilities is shown in Fig. 1A.

The radio navigation facilities include:

- (a) radio compasses APK-5 Nos 1 and 2;
- (b) radio altimeters PB-17 and PB-2;
- (c) course radio receiver KFU-4;
- (d) glide-slope receiver KFU-2;
- (e) marker receiver MP1-68H;
- (f) radio range finder C3-1.

The radar facilities include:

- (a) airborne transponder CPO;
- (b) radar bomb sight PEO-4;
- (c) radar gun sight HPO-1.

**PREFLIGHT CHECK**

**CAUTION.** 1. Before making a check take measures against shocks by H.V. current, prevent the equipment from being switched on by its own accord. Make so that men and foreign objects may not touch the radio set antennas.

2. Inspect the units, cables, antennas with the equipment deenergized. The aircraft and airfield power supplies must be switched on only upon permission of an electrician.

3. Before flight the aircraft crew members must make such checks of the radio equipment which do not require use of special ground simulators.

4. If the equipment is installed on the aircraft immediately before flight, it must be fully checked and adjusted by technical personnel before the crew members make a preflight check.

**Radio Communication Equipment**

1. Check the fastening and soundness of the antenna insulator and antennas of the command and communication radio sets on the fuselage.

2. Check the antenna fairleads and bonding jumpers for fastening and reliable connection; check the fastening, shock absorption and outward soundness of the radio sets and cables.

The equipment check technique is outlined in Section "Check of Live Radio Equipment".

3. Check the operation of selector switches, switches and control knobs of the radio communication equipment in the following scope:

(a) CNU-10 - for two-way communication between all members of the crew in position NETWORK No.1 (CSTs # 1) and NETWORK No.2 (CSTs # 2) and for possibility of the output connection to the radio sets attached.

(b) The transmitters of the command and communication radio sets - by the indications of the check meters and for monitoring their own operation.

(c) The receivers of the communication and command radio sets - by listening through the operation of the radio sets over the working bands.

(d) The ultra-short wave radio set - for two-way communication with the airfield station or with the radio set of another aircraft on the working channels and monitoring its own operation on the other channels.

After the check made, place all the switches and other controls in the original position and switch off the equipment.

**Radio Navigation Equipment**

1. Check the fastening and soundness of the radio altimeters antennas, range scale and dome of the marker receiver antenna.

2. Check the fastening and connection of the antenna leads of the glide-slope receiver and radio compasses, external view and fastening of the pointer and light indicators.

3. Check the operation of the controls and the overall performance of the radio navigation equipment in the work positions of the crew members in the following scope:

(a) The radio range finder - for two-way communication with the airfield transponder on the working channel.

(b) Course and glide-slope receivers - for reception of signals from the respective ground radio beacons on the working channel.

(c) The marker receiver - for reception of signals from the simulator.

(d) Radio compasses - for reception of signals and indication of course bearings of the precision approach radars and broadcast stations.

(e) Low altitude meters - for deviation of altimeter HPO-46 pointer after standing on and over the bands.

(f) High altitude meters - by the pulses on the indicator screen and operation of the controls.

(g) Receiver-indicator unit - by the signals of the radio stations or simulator. After the check made, set all the switches and other controls to the initial position and switch off the equipment.

**Radar Equipment**

1. Check the fastening and soundness of the transponder antennas and the dome of the radar sight antenna.

2. Check the locking of the protective cover of button ARMED (B3WB), condition of the inertia switch, external view and fastening of the light and pointer indicators.

3. Check the units and waveguides for hermetic sealing and then the functioning of:

(a) the radar sight - by operation of the controls and by appearance of echo scale on the tube screens;

(b) the radar sighting station - by the control system and joint operation with the installation;

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 202 -

(c) the transponder - by operation of the controls.  
Before flight insert the plug of the ARMSD circuit into the fuse socket and withdraw it after the flight.  
The check made, set all the switches and controls to the initial position and switch off the equipment.

POSTFLIGHT INSPECTIONVisual Inspection of Radio Equipment

The radio equipment should be inspected visually after the flight to determine whether the equipment is ready for operation in flight conditions and to locate possible troubles in separate units, bunched conductors, fastenings and shock absorbers. The visual inspection of the radio equipment should be made in a definite order so that all the elements are subjected to inspection.

In doing this proceed as follows:

1. Set the equipment controls to the initial positions.
  2. Check for evidence of the required seals and locking.
  3. Make sure that all the connectors, cables, antennas and individual wires are connected and fastened properly.
  4. Check for evidence of spare fuses.
  5. Check whether the switches and controls are fastened properly.
  6. Check for evidence of damage to units and cables.
  7. Check the condition of the antennas, antenna leads and earthing wires as well as the soundness and cleanliness of the antenna insulators.
  8. Clean the radio equipment of dust and dirt.
  9. If some units are discovered to be spilled by oil, ice-covered or snow-bound, they should be removed from the aircraft and sent to the repair shop for checking.
- CAUTION.** If some elements of the radio equipment are repaired or replaced on the aircraft it is necessary to carefully check the quality of the mounting of the newly installed elements.

Access to Elements of Radio Equipment

The majority of elements of the radio equipment have open access for their inspection, removal or installation on the aircraft.

To reach the assemblies of the radio equipment, access to which requires removal of separate elements of the aircraft or near-by cables, pipes or separate units of the equipment, do as indicated in the respective sections.

Radio Communication Equipment

1. Check the fastening and soundness of the antennas and antenna insulators of the command and communication radio set.
2. Check the external view and fastening of the radio station units, interphone system and fairleads; completeness of valves, correct installation of fuses inserted during flight; performance of the equipment and operation of the switches and knobs on the working places if the equipment was not used in flight or there are remarks on its functioning.
3. Check the operation of the controls and the performance of:
  - (a) The transmitters of the command and communication radio sets - by the indications of the check meters, monitoring their own transmission and by switches on the transmitters on the working places.

- 203 -

(b) The receivers of the command and communication radio sets - for reception of signals of radio stations over all bands and for monitoring the receiver operation on the working places.

(c) The ultra-short wave radio set - for establishment of two-way communication on all the channels with the airfield radio station and those of other aircraft from working place No.2 and for monitoring its own operation on other working places.

(d) Aircraft interphone system - for establishment of communication between the working places, establishment of communication from the pilots seats with other working places by means of interphone system buttons and for monitoring their operation on each working place when the interphone system is switched by buttons or foot-operated switches.

Place all the switches and control knobs in the initial position and switch off the equipment.

Radio Navigation Equipment

1. Check the fastening and soundness of the antennas of the radio altimeters, radio range finder, the dials of the marker receiver antennas, radio compass loops.
2. Check the external view and fastening of the units of the radio altimeters, radio range finder, radio range finder supply box, marker course and glide-slope receivers, radio compasses, their leads and points of connection to the antennas, light and pointer indicators.
3. Check the performance of the navigation equipment and operation of the switches and control knobs of:
  - (a) The radio range finder - by the simulator on all the channels.
  - (b) The marker receiver - by the simulator.
4. Radio compasses - for reception of signals from precision approach radars and broadcast stations as well as by checking their course bearings over all the bands. Monitor the operation of the radio compasses from the working places.
5. Check the low altitude meter for deflection of the indicator pointer after it has been energized and when changing the bands.
6. Check the high altitude meter by the pulses on the indicator screen and the operation of the control knobs.

Radar Equipment

1. Make sure that the plug of the ARMSD circuit is out of the fuse socket.
  2. Check the soundness and fastening of the interrogator and transponder antennas and radar domes.
  3. Check the external view and fastening of the radar units, light and pointer indicators; locking of the fuses of the ARMSD button cover; completeness of spare fuses and valves; installation of the fuses inserted in flight.
  4. Check the operation and soundness of the switches and control knobs of the radar equipment (make a check if the equipment was not used in flight and there are remarks on its operation) and performance of:
    - (a) The radar sight - by the operation of the control knobs and by the presentation of the echo signals on the indicator screen.
    - (b) The radar sighting station - by the control system and by the joint operation with the installation.
    - (c) The transponder - for operation of the controls and correctness of signals of the sound and light signalling systems.
- The check made, set all the controls to the initial position and switch off the equipment.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

CHECKING OF LIVE RADIO EQUIPMENT

**CAUTION.** Before attempting to check the live equipment eliminate all the troubles in the equipment and wiring revealed in flight. When checking the live equipment pay special attention to the functioning of the equipment that has failed in flight.

The check of the live radio equipment shall be made after the visual inspection in the scope and order prescribed by the respective sections of the present instructions.

Prior to checking the live radio equipment proceed as follows:

1. Make sure that the power supplies required are switched on.
2. Make sure that the supply voltage of the aircraft mains is within the limits of 28.5 - 28 V for D.C. and 115±0.5 V, 400 c.p.s. for A.C.
3. Make sure that all the troubles revealed during previous inspections are remedied.

**CAUTION.** If radio range finder CR-1, course receiver RPU-3, glide-slope receiver RPU-2 and marker receiver RPU-48H are checked on the airfield with the use of special truck carrying instruments RHD-1, RHD-3, RHP-4, RHP-2 and RHD-48, this truck should be placed in front of the aircraft 2 to 5 m. away from it so that the left side of the truck faces the aircraft antennas of the radio equipment to be checked. In this case, there must be no obstructions (ladders, run, part of the aircraft body, etc.) between the truck and antennas. When checking the marker receiver, place the truck in any spot, but external antenna RHD-48 (from the truck spare set) should be placed 0.5 to 2 m. from inboard antenna RPU-48H.

The radio equipment is checked by the instruments installed on the truck in essentially the same way as by individual instruments described below.

If suspicious results are obtained in the course of checking of any piece of radio equipment, it is necessary to take the required simulator from the truck and use it to check the performance of the equipment concerned.

Checking of Pumping System of Hermetically Sealed Units of Radar Station RPU-4

To check the unit pumping system proceed as follows:

1. Disconnect tubes from the cross-piece near frame No.38, plug the end of the tube previously at unit PL2 and build up an air pressure of 3 kg/sq.cm. in the pipeline.
2. Keep the system under the pressure for 30 min., air release being objectionable. The test made, assemble the system and seal the joints.

Interphone System CUW-10  
(feeder BY200-26)

1. Energize transmitters 1-FCB-70, 1-FCB-70M and FCBW-3M, adjust them for telephony and set at RECEPTION (RA SPEAKERS).
- Energize receivers JU-9EM, JU-9, FCBW-3M No.1 or No.2, APR-5 Nos 1 and 2, tune them to well heard radio stations and set at maximum volume of reception. Note: The order of energizing and tuning of stations 1-FCB-70M, JU-9EM, FCBW-3M, APR-5 is outlined below.
2. Energize simultaneously the amplifiers of interphones Nos 1 and 2 by tumbling

position of circuit breaker A30-5:

Interphone No. 1 (CUW No. 1) and INTERPHONE SETS (ADDITIONAL AIRMANS) on the circuit-breaker panel of the right pilot, INTERPHONE No. 2 on the circuit-breaker panel of the navigator, and switches INTERPHONE No. 1 and INTERPHONE No. 2 on the upper board.

Set the switches of the interphone sets (Fig.125) to positions NETWORK No. 1. Turn the volume control fully clockwise (maximum volume) and check the operation of the interphone system adjusted for intercommunication through conversations from all the interphone sets. The speech transmitted must be loud, clear, without noticeable distortions.

Use meter EB-4 to measure the voltage of the useful signal at the output of amplifier No. 1 when it is loaded by six pairs of telephones TA-4 and two pairs of throat microphones MA-5. The mean speech voltage should not be less than 40 V at the maximum gain (the gain control on the amplifier is turned fully clockwise) and no less than 20 V at the normal gain (the amplifier gain control stands against the scale notch) (Fig.126).

Check the operation of the interphone system adjusted for conference call from all the interphone sets. For this purpose press button CONFERENCE CALL (KUPK. KUP) on the interphone set being checked. In this case, the voice of the caller on the set being checked must be heard in the remaining sets, whatever may be the position of the function switch, and the volume of the radio station receiver's operation must decrease materially.

Listen through the operation of receivers JU-9, JU-9EM, FCBW-3M, APR-5 No.1 and No.2 from all the interphone sets setting the function switch on the set being checked successively in positions COM, RADIO SET (OB3/PC), COMMAND RADIO (KUP/PC), USE RADIO SET (VUB/PC), ADD. BOARD-APR/1 (KUP/ST-APR/1) and ADD. BOARD-APR/2 (KUP/ST-APR/2).

When monitoring any of these receivers it is allowed to slightly listen through operation of the other receivers to which the position of the function switch being checked does not correspond. For instance, when monitoring receiver JU-9 (the main switch in position COM, RADIO SET) the operation of receivers APR-5, FCBW-3M, JU-9EM may be heard weakly. The noise voltage being not more than 0.1 V measured with the dead receiver to which the function switch position being checked does correspond.

Check the starting and modulation of the transmitters of the communication (FCB-70), command (FCB-70M) and ultra-short wave (FCB-3M) radio sets from all the interphone sets by depressing the interphone buttons and switches which serve to switch on the transmitters and throat microphone of the radio set (button RADIOS on the pilots' control wheels). In this case check the operation of all the buttons and switches of the interphones.

When the interphone button is not depressed the operation of the receiver (FCB-70), command (FCB-70M) and ultra-short wave (FCB-3M) radio sets must be heard in the telephones connected to the interphone set being checked.

When depressing the interphone button (on control wheel RADIOS) the receiver should cease, but instead in telephones must be heard the operation of the transmitter (monitoring) of the radio set to which corresponds the position of the function switch on the interphone set being checked. When checking transmitters FCB-70 and 1-FCB-70M the pointer of the antenna current indicator on the front panel of the transmitter must deflect and swing in step with sounds transmitted through the throat microphones.

**CAUTION.** The transmitters of the radio sets must be started, modulated and monitored from the interphone sets: 1-FCB-70 - from all the interphone sets, except those of the radio operator and gunner.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

- 1-PCB-70M - from all the interphone sets except that of the gunner.  
 PCB-3M - from all the interphone sets.  
 The operation of all the receivers must be monitored from interphone set  
 JG-9M - from all the interphone sets except those of the radio operator  
 and gunner.  
 JG-9 - from all the interphone sets except those of the gunner.  
 PCB-3M - from all the interphone sets.  
 AFK - 5 No. 1 and No.2 from the interphone sets of the pilots and navigator.
8. Check for possibility to change from external communication to internal  
 from the interphone sets of the pilots. For this purpose set the switch of the  
 interphone set at any position (except INTERPHONE) for instance at COMMAND RADIO  
 SET and depress button INTERPHONE on the pilot's control wheel. In this case, the  
 audio of the aircraft radio set receiver to which corresponds the selected position  
 of the function switch must cease, the transmitter should not be modulated. The  
 interphone set must change to intercommunication and operate in accordance with  
 Point 3 of the present Section.
9. Set network switches on the interphone sets in position NETWORK No. 2 and  
 check the operation of network No. 2 adjusted for intercommunication according to  
 Point 3 of the present Section.
10. Switch off the receivers and transmitters of the radio sets.

Interphone System Trouble Chart

Trouble	Probable cause	Remedy
1	2	3
No audio through one of networks in interphone wires (conductors 3 and sets in position INTERPHONE.	(a) Faulty connecting of networks in interphone wires (conductors 3 and 4 of connector ) of amplifier in bunched wires (b) Poor contact in valve sockets (c) Faulty one of amplifier valves (d) Short in input or output circuits of amplifier (e) Discontinuity of input or output circuits of amplifier in connector or cable	Remedy the fault  By inserting valves alternately find faulty contact and remedy it by bending socket jacks  Check and replace faulty valve 6H8C  By isolating separate sections of network and interphone set in successive find trouble and remedy it  Check cable conductors of right connector of amplifier, locate discontinuity and eliminate it  Remedy fault
When depressing conference call button of one of interphone sets, conference call is not heard in other interphone sets	Conference call relay cannot be energized - faulty connecting wires (conductors 5 and 10 of 14-terminal connector)	Remedy fault

1	2	3
When depressing conference call button of one of remaining sets no call is heard	Relay of interphone set being called cannot be fed with 27 V (conductors 5 and 12 of 14-terminal connector)	Remedy fault
No audio is heard in one of interphone sets in all positions if function switch on interphone set	Discontinuity in telephone circuits in headgear or connecting cable running from set to headgear	Eliminate discontinuity of wires, replace faulty headgear

Command Radio Set 1-PCB-70M  
(feeder H7200-24)

- Switch on transmitter 1-PCB-70M and receiver JG-9M, for which purpose:
    - Set circuit breaker A3C-5 JC-9 on the circuit-breaker panel of the navigator to position ON (BROWNSHED).
    - Set the function switch on the front panel of the radio set first to position TFM (TSM) and in 30 sec. to position TGRH ( TTR ).
    - Set switch APO-OFF-MPO ( AP4-BRHS-PP4) located on the remote control panel of the receiver to position MFC (Fig.127).
  - Set the function switch of the interphone set of the right pilot to position COMMAND RADIO SET, turn knob LOUDER (TPOWER) fully clockwise.
    - Connect a pair of earphones TA-4 and throat microphones HA-5 to the interphone set.
    - Check the operation of receiver JG-9M following procedure below:
      - Match the tuning scale of the remote control panel with the receiver tuning, for which purpose turn knob TUNING on the remote control panel smoothly first counter-clockwise and then clockwise so that the tuning scale of the panel comes into one extreme position to the other.
      - Place switch EPUS-20PH (TSM-TTR) in position TFM, turn the volume control fully clockwise and tune the receiver to the well-heard radio station on each wave band.
- CAUTION:** Knobs B, J and K of transmitter 1-PCB-70M when tuning the receiver to the station whose frequency does not correspond to those fixed on the APC channel of 1-PCB-70M, should be placed in the position of the frequency of the transmitting radio station. In this case, the APC channel switch of radio set 1-PCB-70M must be shifted to the normal control position.
- Check the operation of the volume control; rotating knob VOLUME (TPOWER) counter-clockwise must reduce the volume of the picked up signals. Volume should change continuously without crackling.
  - Check the operation of buttons ANTENNA ADJUSTMENT (DORCTOPKA ANTENNY). When depressing one of the buttons for a long time the volume of the picked up signals must vary periodically from maximum to minimum. When changing from one button to the other the nature of volume must alter, i.e., if volume increases in intervals between maximum and minimum upon depressing the first button, then it must decrease upon depressing the other, and vice versa.
  - Check the receiver operation on telegraphy. For this purpose shift switch TSM-TTR to position TGRH; in this case, BEAT NOTE must be superimposed on the signals of the transmitting station.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

When one of buttons BEAT NOTE (TOK BESHG) on the remote control panel of receiver JC-9M is kept depressed for a long period, the beat frequency must change periodically. If when pressing the first button the beat frequency increases, then it must decrease when the second button is depressed, and vice versa.

(f) Check the operation of the crystal filter. For this purpose set switch CRYSTAL (KRAMU) to position ON (VESHGHO). In this case, the volume of the signal being picked up and the noise level must decrease, the signal must be heard more distinctly, the turn angle of the tuning scale at which the picked up signals are heard must increase appreciably.

(g) Check the operation of switch APC - OFF - MPC. When changing over from position APC to position MPC the signal intensity of powerful radio station must be reduced appreciably. The intensity of poorly audible signals should not decrease noticeably (at the same position of the volume control).

(h) Check the operation of the scale illumination rheostat on the control panel. When rotating knob ILLUMINATION (OCHRESHE) the brilliance of the scale lamp must change steplessly.

(i) Tune receiver JC-9M to frequencies according to the table of radio set tuning.

4. Check the operation of transmitter 1-PCB-70M of the command radio set following the procedure set below:

(a) Tune the transmitter on extreme frequencies for each section of the stub antenna following the "Operating Instructions for Transmitter Radio Set" that comes with every transmitter. Intermediate frequencies should be checked when the necessity arises. Location of the transmitter control knobs is shown in Fig.128.

**CAUTION.** 1. Take precautions to prevent the antenna of radio set 1-PCB-70M from being touched by the crew members and various objects (ladders, covers, etc.).

2. The continuous operation of the transmitter into the antenna should not last more than 5 min. after which a 10-min. interval is necessary.

3. In case of precise tuning of the transmitter the pointer of the antenna current indicator is allowed to overshoot slightly on certain frequencies of the band, provided the indicator readings do not exceed  $\pm 6$  divisions in position TUNING (NACHPOUSKA).

4. Knob B is allowed to depart from the position indicated in the table of tuning of "Operating Instructions for Radio Set 1-PCB-70M", if the antenna current indicator pointer when set against the tabular data deflects from zero.

5. Knob F is allowed to depart from the position indicated in the table of tuning under the very same conditions, but by not more than 1 division.

(b) Check the operation of the automatic control system by changing over the channels from the transmitter remote control panel, having shifted switch LOCAL-REMOTE (MESH-NEVT.) on the front panel of the transmitter to position REMOTE (remote control of transmitter, Fig.129). Upon completion of the operating cycle of the automatic control system knobs A, B, E, F, H on the front panel of the transmitter must automatically settle to the positions in which they were locked during tuning of the transmitter on the given channel.

**CAUTION.** Continuous operation of the automatic control system should not last more than 20 min. Every 20 min. of operation should be followed by 20-min interval.

(c) Check for evidence of modulation and monitoring on low frequency on any of the fixed channel. When depressing button RADIOS on the pilot's control wheel or the button on the remote control panel the transmitting station signals being picked up should not be audible at the output of receiver JC-9M, but instead the

operation of the own transmitter must be heard in the earphones; the pointer of the antenna current indicator on the transmitter front panel should oscillate in step with sounds transmitted through throat microphones.

(d) Check the keying relay of the transmitter (in TPIH, TQPH and TNGPH) for proper operation during transmission of dashes and dots. In this case, it is necessary to see whether the transmission influences the operation of the receiver (disturbance of the receiver, simultaneous audibility of the transmitting station and operation of the own transmitter, etc.).

(e) Check whether the transmitter of the command radio set can be operated by the telegraph key of the radio operator. For this purpose set the key switch to the respective position and press the key. In this case, a signal must be heard in the earphone which vanishes when the key is released.

Check the operation of the radio set with the switch on the key cover (Fig.117) in position RECEIVING, COMPLEX (MPL. GUMH.). The transmitter in this case must be disconnected (rotary converter is switched off). Receiver JC-9 must operate without wig off upon depressing of the interphone buttons and telegraph key. The stub antenna of the radio set must be connected to its full length, since the relays switching over the stub sections must be dennergized.

5. Energize transmitter 1-PCB-70 and receiver JC-9 of the communication radio set, for which purpose proceed as follows:

(a) Close circuit breaker AJC-50 PCB-70 on the circuit-breaker panel of the second cabin.

(b) Set switch SIMPLEX-HALF-DUPLEX (GUMH-MESH) on the telegraph key panel to position HALF-DUPLEX.

(c) Set the function switch on the front panel of the transmitter to position TTS and in 30 sec. to GPH.

(d) Set switch APC-OFF-MPC on the front panel of receiver JC-9 to position MPC.

6. Check the operation of receiver JC-9 against Items 2, 3, c, d, e, f, g, h of the present Section using the interphone set of the radio operator and the appropriate controls on the front panel of receiver JC-9 (Fig.131).

7. Check the operation of transmitter 1-PCB-70 in accordance with the Operating Instructions of transmitter 1-PCB-70 by using the controls located on the front panel of the transmitter.

8. Check the operation of the monitoring switch. In position ON (low-frequency monitoring) and with the button of the interphone set depressed the signals of the transmitting station should not be audible, but instead operation of the own transmitter must be heard in the earphones. In position OFF (high-frequency monitoring) with the interphone set button in the press-down condition operation of the own transmitter must be monitored only during the precise tuning of the receiver to the frequency of the transmitting station; if the receiver is slightly detuned from the transmitter frequency, the transmitter operation should not be heard.

Command Radio Set Trouble Chart

Trouble	Possible cause	Remedy
1	2	3
Transmitter on, pilot lamp fails to come on	Blown fuse 20 A (or disconnected circuit breaker AJC-10) in transmitter supply circuit	Replace fuse, cut in circuit breaker

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 210 -			- 211 -		
1	2	3	1	2	3
Transmitter on, dynamotor fails to start	(a) Blown fuse 40 A (or cut off circuit-breaker 430-30) (b) Open contact of starting relay interlock under transmitter cover (c) Fumbler on telegraph key panel in position RECEIVER-SIMPLEX	Replace fuse, cut in circuit breaker  Close interlock of upper cover  Set telegraph key to position HALF-DUPLEX TRANSM. PWR-RECEIVER	Transmitter cannot be tuned in one of bands: 4.8 to 9 Mc/s 9 to 13 Mc/s 1.3 to 18 Mc/s	Faulty relay PC shorting respective stub sections: 3-metre 1.5 -metre 0.75-metre	Replace faulty relay. When in flight switch transmitter to reserve wave in good band
No grid current	(a) Blown fuse for 0.5A in 400-V circuit (b) Faulty anster oscillator valve (F-837) or one of multiplier valves	Replace fuse  Replace valves in succession	No grid current on 7-12 band, but there is current on 1-6 bands  No high-frequency oscillations	Faulty valve F-1625 of 2nd multiplier (R103)  Faulty anster oscillator valve FV-837(R101)	Replace valve F-1625 (R103)  Replace valve
Fuse in 400-V circuit burns out	Fracture of conductor insulation in cable running from dynamotor to transmitter	Remedy cable fault	Large anode and grid currents	(a) Excessive mains voltage (b) Faulty power amplifier valve FV-13	Check and adjust voltage of aircraft mains  Replace valve
Fuse in 1150-V circuit burns out	Fracture of conductor No.10 in cable running from dynamotor to transmitter	Remedy cable fault	Transmitter cannot be tuned, no antenna current	(a) Vacuum relay fails to operate (b) Faulty power amplifier valve FV-13 (c) Discontinued antenna circuit and lead	Replace vacuum relay  Replace faulty valve
Transmitter on, pilot lamp fails to burn	(a) Wrongly set switch LOCAL-RESEVER on front panel of transmitter (b) Pilot lamp burned out	Set switch LOCAL-RESEVER to respective position  Replace lamp	No grid current, no beat note is heard at crystal points	Faulty valve F-837 (R101)	Replace valve F-837 (R101)
Transmitter is on, dynamotor operates, meter does not indicate modulation	(a) Microphone switch not set at GARDEN (W101R21) (b) Defective valves 6H9C, 12C8B, F-811	Set microphone switch to GARDEN  Replace valves 6H9C, 12C8B, F-811 in succession	No grid current, but beat note is heard	Faulty valve F-1625 of 1st multiplier (R102)	Replace valve F-1625 (R102)
When radio set is operated on telegraphy, no note is heard in earphones	(a) Low-frequency monitoring is off (b) Monitoring control is off (c) Faulty valve 6H9C of tone generator	Set monitoring switch to M  Turn speech amplifier control fully clockwise Replace valve 6H9C	No modulation, monitoring is normal  Monitoring is weak or absent at all  No tone modulation in positions W116 and W118, there is voice modulation, 1000 c.p.s. note is not heard at monitoring output	One of valves F-811 (R105 or R106) is faulty Faulty valve 12C8 (R202) or 6H9C (R203) Faulty valve 6H9C (R303)	Replace valve F-811 in succession  Replace faulty valves  Replace faulty valve 6H9C
No anode current with transmitter on	(a) Blown fuse for 0.5 A in 750-V circuit (b) Faulty valve FV-13	Replace fuse  Replace valve	No beat note of "crystal points" is heard during calibration	(a) Faulty valve 6H9C (R301) or 6A7 (R302) (b) Faulty crystal	Replace valves 6H9C, 6A7 in succession Replace crystal
Dynamotor runs with transmitter operated on telephony	Closed circuit of telegraph key or interphone button	Check condition of key and button circuits and remedy fault			

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 212 -

Radio Set FCWV-3M

(feeder H7200-25)

1. Energize radio set FCWV-3M for which purpose cut in circuit breaker A30-5 of the radio set on the circuit-breaker panel of the navigator and common switch 210-250 on the motor-panel of the left pilot.
  2. Place the function switches of the pilots' interphone sets in position USW RADIO SET, turn the volume controls of the interphone sets fully clockwise.
  3. Place switches 1-2 on the radio set control panels in position 2 (Fig. 134).
  4. Give the operational check on the first receiver for which purpose:
    - (a) Turn the volume control on the panel of the first receiver fully clockwise (position F-LOUVER) whilst on the panel of the second receiver fully counter-clockwise.
    - (b) Check the correct operation of the automatic control mechanism by pressing in succession communication channel buttons 1, 2, 3 and 4 on the control panel of the transmitter and the first receiver of radio set FCWV-3M.
    - (c) Listen to the receiver operation on all the channels through interphone sets. With button RADIOS depressed, the receiver noise and atmospheric interference must be heard in the earphones.
    - (d) Check the operation of the volume control of the control panel. Rotating the volume control counter-clockwise reduces the noise volume in the earphones.
  5. Check for evidence of modulation and monitoring of the transmitter on all the channels. In doing this proceed as follows:
    - (a) Press button RADIOS on the pilot's control wheel. In this case, atmospheric noise should not be heard in the earphones.
    - (b) Say a few words abruptly through throat microphones which must be heard in the earphones with the button depressed, and disappear with the button released. The speech transmission must be loud without noticeable distortions.
  6. Give the operational check on the second receiver for which purpose:
    - (a) Turn the volume control on the control panel of the second receiver fully clockwise (position F-LOUVER) and on the panel of the first receiver fully counter-clockwise.
    - (b) Check the operation of the second receiver according to Points 4 b, c, d of the present Section.
  7. Check the operation of radio set FCWV-3M on all the channels for two-way communication with two airfield (or aircraft) radio stations simultaneously operating on various channels. In doing this proceed as follows:
    - (a) Listen to the operation of the airfield transmitters on the corresponding receivers of the aircraft radio set being tested having set switches 1-2 on the control panels to position 2, and volume controls fully clockwise (maximum volume). In this case, operation of both transmitters must be heard in the earphones. Rotating the volume control on the panel of one of the receivers will cause a change (noticeably by ear) the volume of the other receiver, operation. The transmission of ground transmitters must be heard well without noticeable distortions.
    - (b) Simultaneously check the operation of the transmitter of the station under test by monitoring its operation on the receiver of the airfield station. The transmission must be loud, without noticeable distortions; speech intelligibility must be not less than 100 per cent.
- ATTENTION!** 1. When setting switches 1-2 on the radio set control panel to position 1 operation of the first receiver must be heard in the earphones.  
2. Check (if necessary) the operation of the sensitivity control and noise limiter of the receiver. Rotating the sensitivity control clockwise will increase the volume of signal (noise) at the receiver output.

- 213 -

When setting the noise limiter to the ON position, and the sensitivity control for maximum volume (fully clockwise) the noise at the receiver output should disappear.

3. Check the tuning of the transmitter and receivers of the radio set against test instrument H (Fig. 133) or KCP-1 (Fig. 134), the radio set operation for two-way communication with the airfield radio station on all four channels when the engines are running. Tune the radio set, if necessary. Location of the controls of radio set FCWV-3M is shown in Fig. 135 and 136.

4. Switch on the radio set intermittently: 2 min. for transmission; 2 min. for reception. The radio set is allowed to continuously operate on transmission not more than 15 min.

Radio Set Trouble Chart

Trouble	Possible cause	Remedy
1	2	3
All receiver and transmitter valves are not heated	Broken wires in heater circuits of valves	Identify cable wires from rectifier to receiver. Remedy wire fault
No modulation and monitoring of own operation	Faulty throat microphones. Throat microphones are not supplied because of broken leads	Replace faulty throat microphones. Remedy faulty leads
1st knob of transmitter cannot be tuned by unit H	Channel is not selected, faulty crystal. Faulty one of valves: H 101, H 02, H 54, H 55, H 03	Press button of corresponding channel. Replace faulty crystal and valves
Power amplifier cannot be tuned by unit H	Broken high-voltage circuit. Faulty output valve HV-32	Correct wire fault. Replace defective valve
No tuning indications on unit H in position ANTENNA (ANTENNA)	Defective valve 6X3B	Replace defective valve
Pointer of unit H overshoots in position ANTENNA	Discontinued antenna circuit	Eliminate discontinuity
Automatic control devices cannot be operated from buttons on unit H	Wrong connected plugs 6-106 and 6-206	Connect plugs according to markings
On pressing button on unit H automatic devices operate continuously	Automatic devices reset button on panel is not depressed	Depress reset button on panel

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

**Radio Set PCNV-3M**  
(feeder H7200-25)

1. Energize radio set PCNV-3M for which purpose cut in circuit breaker A30-5 of the radio set on the circuit-breaker panel of the navigator and common switch 2HM-250 on the motor-panel of the left pilot.
  2. Place the function switches of the pilots' interphone sets in position USW RADIO SET, turn the volume controls of the interphone sets fully clockwise.
  3. Place switches 1-2 on the radio set control panels in position 2 (Fig. 134).
  4. Give the operational check on the first receiver for which purpose:
    - (a) Turn the volume control on the panel of the first receiver fully clockwise (position F-LOUDER) whilst on the panel of the second receiver fully counter-clockwise.
    - (b) Check the correct operation of the automatic control mechanism by pressing in succession communication channel buttons 1, 2, 3 and 4 on the control panel of the transmitter and the first receiver of radio set PCNV-3M.
    - (c) Listen to the receiver operation on all the channels through interphone sets. With button RADIOS depressed, the receiver noise and atmospheric interference must be heard in the earphones.
    - (d) Check the operation of the volume control of the control panel. Rotating the volume control counter-clockwise reduces the noise volume in the earphones.
  5. Check for evidence of modulation and monitoring of the transmitter on all the channels. In doing this proceed as follows:
    - (a) Press button RADIOS on the pilot's control wheel. In this case, atmospheric noise should not be heard in the earphones.
    - (b) Say a few words abruptly through throat microphones which must be heard in the earphones with the button depressed, and disappear with the button released. The speech transmission must be loud without noticeable distortions.
  6. Give the operational check on the second receiver for which purpose:
    - (a) Turn the volume control on the control panel of the second receiver fully clockwise (position F-LOUDER) and on the panel of the first receiver fully counter-clockwise.
    - (b) Check the operation of the second receiver according to Points a, b, c, d of the present Section.
  7. Check the operation of radio set PCNV-3M on all the channels for two-way communication with two airfield (or aircraft) radio stations simultaneously operating on various channels. In doing this proceed as follows:
    - (a) Listen to the operation of the airfield transmitters on the corresponding receivers of the aircraft radio set being tested having set switches 1-2 on the control panels to position 2, and volume controls fully clockwise (maximum volume). In this case, operation of both transmitters must be heard in the earphones. Rotating the volume control on the panel of one of the receivers will somewhat change (noticeably by ear) the volume of the other receiver operation. The transmission of ground transmitters must be heard well without noticeable distortions.
    - (b) Simultaneously check the operation of the transmitter of the station under test by monitoring its operation on the receiver of the airfield station. The transmission must be loud, without noticeable distortions; speech intelligibility must be not less than 100 per cent.
- ATTENTION!** 1. When setting switches 1-2 on the radio set control panel to position 1 operation of the first receiver must be heard in the earphones.  
2. Check (if necessary) the operation of the sensitivity control and noise limiter of the receiver. Rotating the sensitivity control clockwise will increase the volume of signal (noise) at the receiver output.

- When setting the noise limiter to the ON position, and the sensitivity control for maximum volume (fully clockwise) the noise at the receiver output should disappear.
3. Check the tuning of the transmitter and receivers of the radio set against test instrument H (Fig. 133) or KOP-1 (Fig. 134), the radio set operation for two-way communication with the airfield radio station on all four channels when the engines are running. Tune the radio set, if necessary. Location of the controls of radio set PCNV-3M is shown in Fig. 135 and 136.
  4. Switch on the radio set intermittently: 2 min. for transmission, 2 min. for reception. The radio set is allowed to continuously operate on transmission not more than 15 min.

Radio Set Trouble Chart

Trouble	Possible cause	Remedy
1	2	3
All receiver and transmitter valves are not heated	Broken wires in heater circuits of valves	Identify cable wires from rectifier to receiver. Remedy wire fault
No modulation and monitoring of own operation	Faulty throat microphones. Throat microphones are not supplied because of broken leads	Replace faulty throat microphones. Remedy faulty leads
1st knob of transmitter cannot be tuned by unit H	Channel is not selected, faulty crystal. Faulty one of valves: H 101, M02, M54, H155, M103	Press button of corresponding channel. Replace faulty crystal and valves
Power amplifier cannot be tuned by unit H	Broken high-voltage circuit. Faulty output valve 1V-32	Correct wire fault. Replace defective valve
No tuning indications on unit H in position AMERENA (AMERENA)	Defective valve 6X01	Replace defective valve
Pointer of unit H overshoots in position AMERENA	Discontinued antenna circuit	Eliminate discontinuity
Automatic control devices cannot be operated from buttons on unit H	Wrong connected plugs G-106 and G-206	Connect plugs according to markings
On pressing button on unit H automatic devices operate continuously	Automatic devices reset button on panel is not depressed	Depress reset button on panel

50X1-HUM

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 214 -

1	2	3
1st knob of receiver cannot be tuned by unit M	Defective crystal. Defective crystal oscillator or multiplier valve	Replace defective crystal or valve
2nd knob of receiver cannot be tuned by unit M	Defective indicating lamp 6X06	Replace defective lamp
Receiver sensitivity below rated	Defective one of I-F amplifier valves. Sensitivity control is not set at maximum	Set sensitivity control at maximum. Replace defective valves
No signal applied	Defective valve 6I2. Break in telephone circuit	Replace defective valve. Eliminate break
Receiver valves are not heated	Broken conductors in cables (2 or 3)	Eliminate trouble
Crockling in earphones in one of receivers operating on reception or periodical fading of picked up signals during flight. Operates normally on ground	Hidden loose contact in circuit of antenna feeder. Disturbed soldered joint in high-frequency connector	Restore contacts in connectors. Eliminate breaks in feeder.

Radio Compasses AFK-5 Nos 1 and 2  
(feeder H7200-23)

1. Close the circuit breaker of radio compass No. 1 on the navigator's left-hand circuit-breaker panel.
2. Set the control knobs of the interphone set and additional interphone panel of the navigator to position "LOUDER ADD. PANEL" (AFK No. 1). Connect telephones T-4 to the set.
3. Energize radio compass AFK-5, for which purpose turn control VOLUME (TPOGREN) on the control panel of radio compass AFK-5 No. 1 of the navigator fully clockwise and set the function switch to position COMPASS (KOHM.). In this case a green lamp must light up on the control panel, a characteristic noise of the receiver must be heard in the earphones, the tuning indicator pointer must deflect from the extreme right to the extreme left position (scale zero). The course indicator pointers must start moving. With no reception of signals from radio stations check the position of the tuning indicator pointer. If the latter rests on the left stop of the scale use a screwdriver to set the sensitivity control of the indicator on the control panel to such a position at which the pointer will leave the stop and settle against the first division of the scale. Location of the controls on the remote control panel is shown in Fig. 137.

**CAUTION:** If the green lamp on the control panel fails to light up upon energizing the radio compass, press and release button CONTROL (VYPABIBRENE).

4. Operate knob TUNING to tune to a few radio stations in each of the three bands. With fine tuning to a well heard radio station the tuning indicator pointer must deflect to the right, and pointers of course indicators (pointer No. 1 on VIB-1) must occupy a definite position, i.e. indicate the course bearing of the transmitting station. The course indicators are shown in Figs 138 and 139.

- 215 -

When rotating knob VOLUME the volume of the signals being picked up should not change. The tuning indicator pointer should remain in place oscillating about the main position in step with the signals of the transmitting station.

Check the operation of switch TPNH-TGPH in position TGPH, in the presence of a signal of the transmitting station (carrier frequency) note of about 800 c.p.s. a signal of the transmitting station (carrier frequency) note of about 800 c.p.s. frequency must be heard in the earphones.

5. Repeat the operation indicated in Point 4 when setting the function switch on the control panel to positions ANTENNA and LOOP (PANKA). In this case the course indicators should not respond to the signals of the transmitting stations being received. The volume of signals in the earphones and position of the tuning indicator pointer must change in step with rotation of knob VOLUME.

6. Set the function switch to position LOOP, press knob LOOP towards the face of the panel and move it to the right (position H). In this case, the pointers of the course indicators must rotate clockwise. Move knob LOOP to position I - the pointers of the course indicators must rotate counter-clockwise. The speed of the pointer rotation in both directions - 20 to 45° per second. If knob LOOP is moved to the right or left without being pressed, the pointers of the course indicators must rotate slowly at a speed of 1 to 6° per second; the pointer rotation must be smooth and jumpless.

Make sure that there is no seizing of the course indicator and tuning indicator pointers.

7. Check the operation of the illumination rheostat. Rotating knob ILLUMINATION (DORZEN) clockwise will increase illumination of the tuning scale and scale of the tuning indicator.

8. Do operation indicated in Points 2, 3, 4, 5, 6, 7 using the control panel of the first radio compass and the interphone set of the left pilot. When changing over the control press and release button CONTROL on the control panel AFK-5 No. 1 of the left pilot. Check the operation of course indicator BOW-1 on the instrument panel of the left pilot.

**CAUTION:** 1. To check the second radio compass set the switch on the additional interphone panel to position AFK-2. The second radio compass should be checked according to Points 2, 3, 4, 5, 6, 7 of the present section. Check the output of the radio compass (AFK-5 No. 2) by pointer No. 2 of course indicator VIB-1 of the navigator and by the pointer of indicator BOW-1 on the instrument panel of the right pilot.

2. On some aircraft when radar station FEH-4 is energized the supply blocking relay PH-2 of the second radio compass must disconnect 115 V, 400 c.p.s. from the radio compass.

3. Checking the first and second radio compasses on the aircraft positioned close to large metal structures, buildings or inside the hangar may result in unstable operation of the radio compass (fading of the transmission being picked up, large difference in readings of AFK-5 No. 1 and No. 2 when tuned to the same radio station, oscillation of pointers, etc.)

9. Adjust sensitivity of both radio compasses (No. 1 and No. 2). In doing this proceed as follows:

(a) Tune the radio compass to a frequency close to 50 c.p.s. free from the station noise.

(b) Disconnect the antenna from the receiver and bridge terminals ANTENNA and BOW (ZEMIN).

(c) Turn the volume control on the control panel of the radio compass fully clockwise.

(d) Set the gain control marked RECEIVER GAIN (JOML, HEM) on the front panel of the radio compass so that the set noise voltage at the output of the radio compass is 20 V. Disconnect terminals ANTENNA and BOW. Connect the antenna in place. The front panel of the radio compass receiver is shown in Fig. 140.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 216 -

Radio Compass Trouble Chart

Trouble	Probable cause	Remedy
1	2	3
No switching of operation modes and frequency band	Discontinued 27.5-V supply circuit; blown 27.5-V supply fuse	Restore connection, replace fuse
Upon energizing radio compass pilot lamp fails to light up and receiver valves are not heated	Discontinued 115-V supply circuit; blown fuse in 115-V supply circuit	Replace fuse, restore connection of wires. Check change over contacts in relay box.
After tuning indicator has been cut in its pointer does not deflect	(a) Open- or short-circuited wires running to tuning indicator (b) One of valves 6B8C, 5Y4G is defective	Restore connection or remove short circuit Replace defective valve
There is no noise in earphones on any band after switching on	(a) Open- or short-circuited wires of earphones (b) One of receiver valves is defective	Restore connection or eliminate short circuit Replace defective valve
There is noise, but no reception of radio station in earphones	(a) Open- or short-circuited antenna circuit  (b) Defective valve in H.F. or I.F. amplifier stages	Restore connection or remove short circuit Replace defective valve
No tone modulation in TONE condition	Broken wire running to tumbler switch TFRH-TGRH	Restore connection
Continuous rotation of band switching motor when set at 2nd band	Short circuit-to-earth fault of one of wires running to band switch	Eliminate short circuit
Inoperative manual control of loop rotation	Fault in loop rotation reversal circuits	Restore connection
Loop rotates, pointers of course indicators are motionless or move only within one sector of scale	Break in one of wires connecting fixed windings of solenoids; wrong connection of solenoid windings	Restore connection of wires according to feeder diagram
In position LOOP there is noise in earphones, but no reception or signal in any position of loop	(a) Defective feeder of loop (b) Defective valve 6K7(1) or 6H7 (H3)	Remedy feeder fault Replace defective valve
In position COMPASS (HOMING) course indicator pointers rotate rapidly in one direction	One of valves (6H3C) is defective	Replace defective valve

- 217 -

1	2	3
In position COMPASS low-frequency tone of local modulation is not heard in earphones. Loop cannot be set in bearing position	(a) Defective valve 6H7 (H2), 6K7 (H1) or 6H7 (H3) (b) Broken wires in loop feeder	Replace defective valve Restore connection
Weak up signals are heard in earphones, loop cannot be set in bearing position, local modulation tone is heard. Loop rotates slowly in one direction	Defective valve 6B8C (H10) of compass output amplifier	Replace defective valve
Same, but loop is motionless	Defective valve 6H3C (H3)	Replace defective valve
<b>Marker Receiver MPH-48</b> (feeder B7200-33)		
<p>1. Close circuit breaker ASO-2 of the first radio compass on the left circuit-breaker panel of the navigator.</p> <p>2. Cut in radio compass ATR-5 No.1 and make sure that it is in operable condition by superheterodyne noise in the earphones and by the deflection of the tuning indicator.</p> <p>3. Connect the antenna to the simulator of marker beacon MMH-48 (Fig.141); install MM-48 near the aircraft 0.5 to 2 m. away from the antenna of the marker receiver so that the simulator antenna is in parallel with the aircraft axis.</p> <p>4. Check whether the cover of the inboard antenna of the marker receiver (MPH-48) is dirty. If it is, wipe the cover with a clean dry cloth or cloth moistened in alcohol.</p> <p><b>CAUTION.</b> Never wipe the cover with oil-moistened rags.</p> <p>5. Energize simulator MPH-48 by operating tumbler ON; approximately in 1 min. the pointer of the simulator meter must deflect from its zero position.</p> <p>6. Set the control knob of simulator MMH-48 in the following positions:</p> <p>(a) Switch MODULATION FREQUENCY ( ЧАСТОТА МОДУЛИРОВАНИЯ) in position 3000 c.p.s.</p> <p>(b) Switch CRYSTAL-BAND (КРИСТАЛЛОПОЯС) in position BAND.</p> <p>(c) Switch DOYS-CONTINUOUS (ТУН-НЕПР) in position CONTINUOUS.</p> <p>7. Tune simulator MMH-48 to 75 Mc/s frequency by means of knob MARKER-FREQUENCY SETTING (МАРКЕР-ЧАСТОТА НАСТРОЙКИ) against the diagram available on the front panel of the simulator.</p> <p>Upon coincidence of the tuning frequency of the simulator and marker receiver, pilot lamps MARKER located on the instrument panels of the left and right pilots must come on and the marker receiver bell installed on the port side must ring at a time.</p> <p><b>CAUTION.</b> 1. With the receiver energized see that the MARKER lamp circuit is not shorted, for this will result in the burning out of the current carrying jumper between the contact and the armature of the relay inside the receiver.</p> <p>2. If the frequency of the marker receiver is not equal to that of the simulator (lamps are dark), tune the simulator to the receiver frequency using knob MARKER - FREQUENCY SETTING.</p>		

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

8. Set switch DOT-CONTINUOUS on the simulator to position DOT. As a result pilot lamps MARKER on the instrument panels of the pilots should start flickering and the bell of the marker receiver should ring intermittently in step with signals of the simulator.

**CAUTION.** If the lamps burn and the bell rings continuously, the simulator is allowed to be carried away from the aircraft to such a distance at which the bell will ring intermittently in step with the signals from the simulator.

9. Do as instructed under Point 7 when setting switch MODULATION FREQUENCY to position 400 and 1300 c.p.s.

10. Check the frequency of the marker receiver by the crystal, for which purpose:

(a) Set switch CRYSTAL - BAND to position CRYSTAL.

(b) Connect the simulator antenna to radio-frequency connector entitled GROUND ANTENNA (ANTENNA KBRALIA).

If the receiver frequency equals the crystal frequency of the simulator, the lamps MARKER must burn and the bell ring.

**CAUTION.** 1. If the receiver frequency differs from the crystal frequency, the receiver for which purpose:

(a) Plug a milliammeter (from the simulator spares or the like) into socket CHECK (NORTHPOINT) on the front panel of the receiver.

(b) Use a screwdriver to rotate controls CIRCUIT I (KORIT 1) and CIRCUIT II on the front panel of the marker receiver until the maximum deflection of the milliammeter pointer is obtained (Fig. 142).

2. If the receiver tuning does not yield positive results adjust the inboard antenna for which purpose:

(a) Remove the protective cap from the antenna tuning control (Fig. 137).

(b) Unlock the antenna tuning control and set it by a screwdriver to such a position at which the deflection of the milliammeter pointer is at maximum.

(c) Lock the antenna tuning control and make sure that the antenna tuning is as it should be by the milliammeter readings.

(d) Put the cap of the control in place.

11. Deenergize the first radio compass and circuit breaker A30-2.

12. Check the operation of the marker receiver against Point 7 of the present Section when it is fed from the second radio compass for which purpose energize radio compass AFK-5 No.2 and make sure that it is in operable condition against Point 2 of the present Section.

13. Deenergize the second radio compass AFK-5.

14. Deenergize simulator MRM-48.

Marker Receiver Trouble Chart

Trouble	Probable cause	Remedy
1	2	3
On operation of receiver relay lamp MARKER fails to burn	Break in filament circuit of pilot lamp; break of flexible jumper of relay; no contact in lamp holder	Check supply circuit of lamp; eliminate trouble
No reception of signals from simulator or marker beacon	(a) Break in antenna circuit (b) Poor contact in connectors of radio-frequency cable (dirty, loose point in connector)	Check antenna circuit and correct trouble Check cable and correct trouble

Trouble	Probable cause	Remedy
1	2	3
Variable sensitivity of receiver; pressing front panel changes relay current	(c) Detuned tuning circuits (CIRCUIT I or CIRCUIT II)  Poor contact between front panel and cabinet of receiver  Poorly adjusted relay	Tune circuits as instructed under Section "Marker Receiver MRM-48"  Tighten up screws on front panel of receiver, check rivets  Adjust relay
Pick-up currents of relay do not comply with standards (0.4 and 0.6 ma)	Anode voltage (220 V) is not supplied to valves from radio compass AFK-5	Check 220-V supply circuits of receiver (connector No.2) in receiver connector. Eliminate trouble

**Radio Altimeter PB-17**  
(feeder H7200-22)

**CAUTION.** The radio altimeter must be checked with radio altimeter PB-2 deenergized.

1. Energize radio altimeter PB-17 for which purpose turn on tumbler A30-2. MARKER ANTENNA SWITCH (RISPOKHIVAYEMUB ANTENNA PAKHOBOCHOTOMERPOB) on the circuit-breaker panel of the left pilot and tumbler ON-OFF (BKU-BKLU) on indicator PB-17. As a result, a red pilot lamp must light up on the indicator and, after the station has been warmed-up, the indicator screen should display the sweep ring. Indicator PB-17 is shown in Fig. 144.

2. Check and adjust the sweep display on the indicator screen. In doing this proceed as follows:

(a) Set the range-scale selector on the indicator to position SCALE x10 (KURILIO).

(b) Rotate knob RING SIZE (PAPMEP OKPPEHOCTM) to match the sweep ring with the black ring of the scale on the indicator screen so that the sweep ring projects over its outer edge. The trace of the sweep ring must be bright, clear, with no interruptions and spots and have the correct form concentric to that of the scale. If the brightness, centering and focusing of the sweep is insufficient, adjust the same by rotating controls BRIGHTNESS (APPOCTE), FOCUS (FOKUS), HORIZONTAL CENTERING (GEPPOBHAJIMAH HENTPOPKA) and VERTICAL CENTERING (BEPPEJAHAH HENTPOPKA) located at the lower side of the indicator with the help of an insulated screwdriver. The indicator should be removed when making adjustment on it.

(c) Set knob GAIN (FOKUSHE) on the indicator to such a position at which the initial pulse will be presented in the indicator near the zero mark of the scale. In this case the screen may display the grass (the clear sweep trace is blurred, its ends are fluttering).

**Note:** When varying gain from minimum to maximum the sweep form should not change in radius by more than ± 2 mm.

(d) Use knob DIRECT PULSE AMPLITUDE CONTROL (PEPUB. AMPL. OPEM. KMM.) to adjust the pulse height equal to 6 mm and set it to the scale zero.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

(e) Rotate knob ZERO ADJUSTMENT X10 ( ПЕРВЫЙ КРУГ X10 ) to check whether the direct pulse can be moved along the scale. The pulse must move to the right of the scale zero at least 400 m., in this case the diameter of the sweep ring should not change by more than  $\pm 2$  mm.

(f) Check the value of change of the sweep ring form having placed range-scale selector in position SCALE X1 (МАСШ. X1 ). The radius of the ring form should change by more than  $\pm 2$  mm.

If the ring changes by more than  $\pm 2$  mm, use control SCALE X1 (КОМПЕНСИРУЮЩАЯ МАСШ. X1) on the upper panel of the indicator to adjust the sweep ring to normal sizes.

(g) Set the range-scale selector on the indicator to position SCALE X1 and check the quality of sweep in accordance with Points 2 b, c, d, e, f. In this case, rotating control ZERO ADJUSTMENT X1 will move the pulse to the right side of the scale zero at least 40 m. The diameter of the sweep ring should not change by more than  $\pm 2$  mm.

Recheck the change of quality and form of the sweep ring when switching over range scales.

3. Check the antenna radiation for which purposes:  
(a) Set the range-scale selector to position SCALE X1.  
(b) Install power indicator M-1 on the transmitting antenna; the pilot lamp on indicator M-1 must burn;  
(c) Disconnect the cable of the transmitting antenna from the transmitter and instead, connect the cable of the receiving antenna. Install indicator M-1 on the receiving antenna; the indicator pilot lamp must burn.  
(d) Connect the cables in position.

4. Check the overall sensitivity of radio altimeter PB-17 for which purposes:  
(a) Connect the radio altimeter to tester T-1 (Fig. 145) for a delay equaling to 100-m. height according to the diagram in Fig. 146. Energize the radio altimeter and allow the valves to warm up (for 3 - 5 min.).  
(b) Set the draw-out part of the attenuator to such a position at which the total attenuation of the tester (attenuator reading + attenuation of coils) may be 100 to 106 db.  
(c) Set the range-scale selector to position SCALE X1.  
(d) Set knob GAIN on the indicator to such a position at which noise appears on the outer edge of the sweep ring;  
(e) Set knob DIRECT PULSE CONTROL (ПЕРВОНАЧАЛЬНЫЙ ПУЛЬС) to a position corresponding to fading of the direct pulse on the indicator screen, and set knob GAIN as instructed under Point 4.  
(f) Set the attenuator slider to such a position at which the pulse delay is 6 mm high (size of big mark) and determine the altimeter sensitivity which is the sum of the readings of the attenuator and attenuation of the tester coil. The sensitivity of radio altimeter PB-17 must be at least 106 db (allowing for attenuation inserted by antenna selector AB-1).  
(g) Repeat the operations indicated in Points 4, e, f when measuring sensitivity on range-scale SCALE X10.

5. Measure the radiation power of transmitter PB-17, doing this proceed as follows:  
(a) Connect the radio altimeter to tester T-4 as shown in Fig. 147.  
(b) Energize the radio altimeter and allow the valves to warm-up.  
(c) Set the switch of tester T-4 (Fig. 148) to position + A and adjust (if necessary) the aircraft mains voltage so that the anode voltage as measured by the tester meter is 305.5 V.

(d) Set the switch of tester T-4 at position POWER - FREQUENCY ( МОЩНОСТЬ - ЧАСТОТА ).  
(e) Set output control A of the radio altimeter transmitter (Fig. 149) to a position at which deflection of tester T-4 meter pointer is a maximum, not below the red line of the scale when the radio altimeter operates at SCALE X1 and not below the blue line at SCALE X10.  
6. Demergize the radio altimeter by switch ON - OFF on indicator PB-17 and switch APC-2 R. ALTIMETER APERTURE SWITCH on the circuit-breaker panel of the left pilot.

Radio Altimeter Trouble Chart

Trouble	Probable cause	Remedy
1	2	3
Radio altimeter is not energized, pilot lamp fails to burn	(a) 115 V, 400 c.p.s. are not supplied to radio altimeter	Check 115 V, 400 c.p.s. wiring (conductors 11 and 12 in indicator connector). Remedy trouble
Fuse blows	(b) Blown fuse (a) Shorted 115 V A.C. circuit	Replace fuse Check A.C. circuits (conductors 12 and 11 in indicator connector) Remedy trouble
Indicator does not present sweep on both range scales	(b) Defective valve 5U9G (c) Shorted D.C. circuit (conductor 7 in junction cable)	Replace valve Remedy trouble
Short sweep radius	Defective valve: 6U3 or 6U8, type 6U11, or 6E2, type 5U9G	Check valves; replace faulty ones
Sweep is off centre	Low gain of valves 6U3 and 6U8, type 6U11	Check valves and replace defective ones
Unsatisfactory brightness and focusing of presentation on indicator	Maladjusted potentiometers K-222 and K-225 (centring)	Adjust potentiometers
Sweep distortion	(a) Maladjusted potentiometers R-57 and R-60 (b) Defective cathode-ray tube	Adjust potentiometers R-57 and R-60 Replace tube
No presentation of pulse on indicator screen	(a) Poor pin-socket contacts of C.R.T. (b) Defective C.R.T.	Make closer contact between C.R.T. pins and panel sockets Replace tube
	(a) Defective valve: 6U4, type 6U11 or 6U5, type 6U11 (b) Broken wires No. 4 in junction cable	Check valves. Replace defective ones Restore connection

SECRET  
NO FOREIGN DISSEM

- 222 -

1	2	3
Echo pulse decreases when direct pulse is suppressed by knob DIRECT PULSE CONTROL	Shield is not earthed in one of connectors of junction cable	Connect shield reliably with connector body
Insufficient suppression of direct pulse	Defective valve 4L7, type 6H15	Replace valve

Radio Altimeter PB-2 (Low-Altitude)  
(feeder H7200-22)

1. Move foreign objects (ladders, trucks, etc.) capable of causing reading error away from the aircraft antennas PB-2.
2. Energize radio altimeter PB-2 for which purpose:
  - (a) Close circuit breaker 430-5 of the radio altimeter and 430-2 R. ALTIMETER ANTENNA SWITCH on the circuit-breaker panel of the left pilot.
  - (b) Turn knob ON on indicator HFB-46 fully clockwise (Fig.150).
3. Check the performance of the radio altimeter on the first and second bands for which purpose set knob BAND (RIMANAZHON) successively to positions 0-120 and 0-1200 m. of the scale of indicator HFB-46. 2 - 3 min. after the radio altimeter has been energized the indicator pointer must come to stand against the scale zero mark. The pointer setting accuracy:  $\pm 2$  m. on the first band; on the second band the pointer deflection from the scale zero may reach 300 m.
4. Check the antenna and antenna feeders PB-2 for radiation. For this purpose mount indicator M-1 on the transmitting antenna; in this case the indicator lamp must burn.  
Disconnect the feeder of the transmitting antenna from the transmitter-receiver and instead connect the receiving antenna feeder. Check the receiving antenna and feeder for radiation in the same way as the transmitting antenna. Connect the receiving and transmitting antennas to their sockets.
5. Deenergize the radio altimeter following Point 2 in the reverse order.

Checking Overall Sensitivity of Radio

Altimeter PB-2

1. Connect the radio altimeter and tester T-1 as shown in Fig.151.
2. Set switch BAND on indicator HFB-46 to position 0-120.
3. Energize the radio altimeter and allow the valves to warm up for 5 to 6 min.
4. Draw out slowly the movable part of the attenuator until the indicator (HFB-46) pointer deflects downwards by 7 m. from the initial reading. The attenuator reading must be at least 52 units (when using the tester coils with 28 db attenuation).  
Note: If, according to the tester Certificate, attenuation of the coils is 28 n db, then the attenuator should read not less than 52 - n db.
5. Deenergize the radio altimeter

Calibration of Radio Altimeter PB-2

Within the range of low altitudes

1. Energize the radio altimeter.
2. Connect the radio altimeter with tester T-1 as shown in Fig.151. Set the attenuator at maximum coupling and lock it. Check the readings of the radio altimeter

- 223 -

at the end of the scale of indicator HFB-46 on the first band, for which purpose place the band switch located on the indicator in position 0-120. In 5 - 6 min. the indicator pointer settles in the position corresponding to the equivalent altitude of tester T-1 (100 m.). (See Service Log of tester T-1) minus the aircraft altitude (12.5 m.); the reading accuracy of the radio altimeter must be at least  $\pm 2$  m., i.e. the indicator pointer must show the altitude

$$100 - 12.5 \pm 2 = 85.5 - 89.5 \text{ m.}$$

3. If the readings of indicator HFB-46 do not correspond to the data in Point 2, open cover CALIBRATION - HIGH - LOW ALTITUDES (KALIBROVKA - BOL'NIE - NIZNIE BUKVA) and use a screwdriver to adjust control CALIBRATION - LOW ALTITUDES so that the indicator pointer shows the altitude according to Point 2 (average reading 87.5 m.).
4. Connect the radio altimeter to tester T-1 as shown in Fig. 152 and check the radio altimeter readings at the beginning of the indicator scale on the first band. In this case the indicator pointer must settle at the beginning of the scale in the position corresponding to the equivalent altitude of tester T-1 (20 m.) for the connection shown in Fig.152 (See Service Log of tester T-1) minus the residual altitude of the aircraft; the reading accuracy must be at least  $\pm 2$  m., i.e.

$$20 - 12.5 \pm 2 = 5.5 - 9.5 \text{ m.}$$

5. If the readings of indicator HFB-46 do not correspond to the data in Point 4, open cover ZERO ADJUSTMENT (YUTANOROKA NYVNI) on the transmitter-receiver PB-2 and use a screwdriver to set control ZERO ADJUSTMENT - LOW ALTITUDES (YUTANOROKA NYVNI - NIZNIE BUKVA) so that the indicator pointer shows the altitude according to Point 4 (average reading 7.5 m.).
6. Repeat operations indicated in Points 2, 3, 4 and 5 until the indicator pointer settles in both positions to within  $\pm 2$  m.

- Note: 1. Altitude equivalent (time delay) when connections are made as shown in Fig.151 corresponds to 100 m., and as in Fig. 152 to 20 m.  
2. The residual altitude for mounting the radio altimeter on the aircraft equals 12.5 m.

Within the range of high altitudes

7. Connect the radio altimeter to tester T-1 as shown in Fig.151. Set the band switch on indicator HFB-46 to position 0-1200 and check the readings of the radio altimeter at the beginning of the scale on the second band. In this case, the indicator pointer must settle in position corresponding to the tester equivalent altitude (100 m.) (See Service Log of tester T-1) minus the residual altitude of the aircraft; the reading accuracy must be at least  $\pm 20$  m., i.e.

$$100 - 12.5 \pm 20 = 67.5 - 107.5 \text{ m.}$$

8. If the readings of indicator HFB-46 do not correspond to those in Point 7, use control ZERO ADJUSTMENT - HIGH ALTITUDES to set the pointer to a position corresponding to the altitude in Point 7 (average reading 90 m.).

9. Connect the radio altimeter to tester T-2 as shown in Fig.153 and check the accuracy of the radio altimeter readings at the end of the indicator scale on the second band. In this case, the indicator pointer must settle in a position corresponding to the tester equivalent altitude (500 m.) (See Service Log of tester T-2) minus the residual altitude of the aircraft; the reading accuracy must be at least  $\pm 20$  m., i.e.

$$500 - 12.5 \pm 20 = 467.5 - 507.5 \text{ m.}$$

SECRET  
NO FOREIGN DISSEM

- 224 -

10. If the readings of indicator HPR-46 do not correspond to those in Point 9, use control CALIBRATION - HIGH ALTITUDES to set the pointer to a position corresponding to the altitude indicated in Point 9 (average reading 490 m.).

11. Repeat operations indicated in Points 7 - 10 until the indicator readings at the beginning and the end of the scale will correspond to the required altitude within  $\pm 20$  m.

12. Deenergize radio altimeter PB-2.

Notes: 1. Equivalent altitude of tester T-2 equals 500 m.

2. Location of controls ZERO ADJUSTMENT and CALIBRATION on transmitter-receiver PB-2 is shown in Fig. 154.

Radio Altimeter Trouble Chart

Trouble	Possible cause	Remedy
1	2	3
On energizing radio altimeter, dynamotor fails to operate (armature does not rotate)	(a) Blown fuse in supply circuit of radio altimeter (b) Break in supply circuits dynamotor relay (pin No. 1 in cable dynamotor - transmitter-receiver) (c) Break in L.V. supply circuit of dynamotor (conductors 2 - 4 of dynamotor cable) (d) No contact between brushes and commutator of dynamotor	Replace fuse Remedy cable fault Remedy cable fault Clean contacts or replace brushes (if necessary)
On energizing radio altimeter, pointer does not deflect from left limit	(a) Break in cable of H.V. circuit (conductors of dynamotor cable 3 - positive, 2 - negative) (b) Blown fuse	Remedy cable fault Replace fuse
When changing over to 2nd band indicator pointer remains motionless	Break of conductors 4 and 5 in indicator cable	Remedy cable fault
Dancing of indicator pointer - unstable readings	Dirty H.V. commutator in dynamotor	Clean commutator, make closer contact between commutator and brushes
Radio altimeter fails to ensure required sensitivity margin in altitude during flight	(a) Defective antenna feeders, not matching (b) Cracked steatite insulators of antenna	Replace defective feeders and antenna. Check power of tester T-1 by indicator Replace antenna

- 225 -

50X1-HUM

Radio Range Finder CR-1

(feeder H7200-22)

CAUTION: During checking the supply voltage of the radio range finder must be within: 27.5 - 28 V D.C., 115  $\pm$  0.5 V, 400 c.p.s. A.C.

Checking Performance of Radio Range Finder

Set knobs MODE OF OPERATION (FOR PAROT) and BAND on range indicator HPR-50 located on the instrument panel of the left pilot to position RM (range measurement) and 0-150 (second band).

Energize the range finder, for which purpose close circuit-breaker A30-2 RANGE FINDER (RANGHOMEP) on the circuit-breaker panel of the navigator and set RADIO RANGE FINDER on remote control panel CR-1-3 of the left pilot to position 1 (first communication channel). In this case, pilot lamp CR on control panel CR-1-3 must light up. Approximately 2 min. after energizing the indicator pointer must start smoothly to the end of the scale and swing smoothly within the range of the right portion of the scale (with no reception of reply signals from the transponder). Lamp CALL SIGNAL (POZABHOP CHYHAN) on control panel CR-1-3 must burn continuously with slight variation of light intensity. The time of one complete swing of the indicator pointer (search time) during range measurements and orbiting must be within 1 and 1.8 sec.

Checking Performance of Fine Selector

(calibration of range finder CR-1)

- At least in 10 min. after range finder CR-1 has been energized, press knob ZERO ADJUSTMENT on control panel CR-1-3; the pointer of indicator HPR-50 must come slowly to the scale zero. If the pointer fails to settle against zero turn knob ZERO ADJUSTMENT to adjust the pointer exactly to the scale zero mark.
- Press knob ADJUSTMENT 30 - 150 km. on the control panel; the indicator pointer must come slowly to mark "30" on the first band or to mark "150" on the second band. If the indicator pointer fails to settle against the required mark of the scale, turn the knob to adjust the pointer exactly to mark "30" or "150". Repeat operations under Points 1 and 2 until the indicator pointer settles exactly against the extreme marks of the scale "0" and "30" (or "150").
- Set knob MODE OF OPERATION of the range indicator to position ORBITING (ORBITM). Press knob ORBIT SETTING (POZABHOKA OPGET) on the control panel and rotate it so as to place it in such a position at which the indicator pointer comes to stand against the middle of the triangular mark of the scale. Location of the range finder controls on control panel CR-1-3, and indicator HPR-50 are shown in Figs 155 and 156.
- CAUTION: When doing operations indicated in Points 1, 2, 3 (adjustment of indicator pointer to marks "0", "30" and "150") there must be control margin left, i.e. the control knobs should not reach their extreme positions.
- Check the antenna of transmitter CR-1-2 for radiation of radio-frequency energy on the first, second and third channels. For this purpose bring a power-level indicator (from the complement of tester HMMU -1 and keep it in parallel alignment with the antenna (Fig.157) near the aircraft skin 15 cm. from the transmitting antenna. In case of radiation the indicator neon lamp must glow.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM

Checking Radio Range Finder CR-1 by Testers

KMU-1 and KMU-3

1. Check the supply voltage of the range finder. For this purpose install tester KMU-1 (Figs 158 and 159) on the aircraft and connect it to transmitter CR-1-2 by aid of a cable with T-joint (from the tester complement) as shown in Fig.160.  
Connect converter MA-100 to 27.4-28 V supply taking into account its polarity.  
**CAUTION:** Wrong connection of the converter to the supply source will result in a short circuit in the aircraft D.C. mains.  
Energize the tester using the ON - OFF switch on the front panel of the tester.  
Energize the range finder for which purpose set switch RANGE FINDER located on control panel CR-1-3 to position "I" (first communication channel).  
Measure the D.C. supply voltage of the range finder. To do this, set switch SUPPLY VOLTAGE (НАПРЯЖЕНИЕ ПИТАНИЯ) of the tester to position "27 V" (27a). If the readings of the tester voltmeter come beyond 27.5 - 28 V, adjust the voltage of the aircraft mains (airfield supply) to the specified values.  
Measure the A.C. voltages for which purpose set switch SUPPLY VOLTAGE to position "115 V, 400 c.p.s." (115a, 400Hz). If the voltmeter reads the value other than 115 V, adjust the voltage to 115 ± 0.5 V.  
Measure the voltage in 250-V circuits. When doing this set switch SUPPLY VOLTAGE to position "250 V" (250a) and press button 250 V CHECK (КОМПОНД 250в); the test voltmeter must read 250±5 V.
2. Check the operation of the decoding circuit. For this purpose install the tester and converter MA-100 that feeds it on the right or left of the aircraft so the distance from the receiving and transmitting antennas of the range finder to the tester is not less than 5 m., and the line of the tester antennas is in parallel to the aircraft axis. Energize the range finder and tester. Set knob BAND on indicator HPR-50 to position "0-30 km". Set knob RANGE BAND (РАДИАЦИОННАЯ РАДИОСЕТЬ) on tester KMU-1 to position "I". Set knob RANGE AND CHECK (РАДИАЦИОННАЯ РАДИОСЕТЬ) of the tester to position "10 km" on the first band scale.  
1 - 2 min. after the range finder has been energized the pointer of indicator HPR-50 on the instrument panel of the left pilot must settle against scale mark 10 allowing for error. Simultaneously left-hand lamp CALL SIGNAL on control panel CR-1-3 must go out.  
Depressing button CODE (КОД) on the tester must cause lamp CALL SIGNAL to light up simultaneously with the depressing of the button.  
Make a check on the first and second bands, and in the orbiting mode.
3. Check the operation of the tuning out circuit. For this purpose set knob of indicator HPR-50 to the second band (0 - 150 km.) and press button RETURNING (ВЕРНУТЬСЯ) on control panel CR-1-3; pressing the button will stop the locking, the pointer of indicator HPR will have to search and come back immediately to read the previous range; lamp CALL SIGNAL must light up when the pointer starts searching and go out when it comes back.
4. Check the operation of the communication channel selector. For this purpose set the tester knobs RANGE BAND to position I (first band), and knob RANGE, IN (РАДИАЦИОННАЯ РАДИОСЕТЬ) to mark 15 km. Operate knobs COMMUNICATION CHANNELS (КАНАЛЫ СВЯЗИ) on control panel CR-1-3 and MODE OF OPERATION on the tester to set by turn similar channels. In this case the pointer of indicator HPR-50 should read 15 km.  
Set these knobs to different position; the indicator pointer must stop reading range and start searching. Lamp CALL SIGNAL should burn.

5. Check the reading errors of the range finder on the first band. For this purpose set knob BAND and MODE OF OPERATION of range indicator HPR-50 to position "0 - 30 km". Set knob RANGE BAND of tester KMU-1 to position "I", knob RANGE AND CHECK to such a position at which the indicator pointer settles exactly against scale mark "5 km". In this case, the reading error read on the tester scale RANGE AND CHECK should not come beyond the limits given in Table 30 and calculated by formula

$$\Delta P_1 = \pm 0.6 + 0.02 P_1$$

where  $\Delta P_1$  = the maximum permissible error for the range measured in km. on the first band  
 $P_1$  = reading of range indicator HPR-50 in km.

Check similarly the reading errors on the following marks of the indicator scale: "10", "15", "20", "25" and "30" km. using Table 30.

Table 30

Errors of Indicator Readings at Check Points of First Band

Points of range measurement (km.) on first band	5	10	15	20	25	30
Permissible reading errors, km.	±0.7	±0.8	±0.9	±1.0	±1.1	±1.2

6. Check the range reading error of the range finder on the second band (0 - 150 km.). For this purpose set knob BAND of the range indicator to position "0 - 150 km.", knob RANGE BAND of the tester to position II (second band). Determine the reading error of the indicator on the scale marks: "25", "50", "75", "100", "125" and "150" when knob RANGE AND CHECK is set according to Point 5.  
The reading error should not come beyond the limits of values given in Table 31 and calculated by formula

$$\Delta P_2 = 3.0 + 0.02 P_2$$

where  $\Delta P_2$  = the maximum permissible error for the range measured in km. on the second band.  
 $P_2$  = reading of indicator HPR-50 in km.

Table 31

Errors of Indicator Readings at Check Points on Second Band

Points of range measurement (km.) on second band	25	50	75	100	125	150
Permissible reading errors, km.	±3.5	±4.0	±4.5	±5.0	±5.5	±6.0

7. Check the range reading error of range indicator HPR-50 in the orbiting mode. For this purpose, set knob MODE OF OPERATION of the indicator to position

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 228 -

ORBIT, knob RANGE BAND on tester KHMU-1 to position ORBIT. Operate knob RANGE AND ORBIT on the tester to set 9 km. range (9th orbit). Set knob ORBIT on control panel CR-1-3 to position "9" (9th orbit). In this case the indicator pointer should approach the middle of the scale smoothly and stop within the limits of the triangular mark.

Check similarly the indicator reading errors on orbits 11, 13, 15, 17 and 19. If the indicator pointer fails to settle within the limits of the triangular mark, operate knob RANGE AND ORBIT on tester KHMU-1 to bring the pointer to the nearest extremity of the triangular mark and find on scale RANGE AND ORBIT of the tester the reading error which should not exceed 20.25 km. of all No. of orbits.

**Note:** The sector of the indicator pointer swinging in the search mode during orbiting is displaced on the scale from left to right with orbit number increasing in numerical succession. On orbits "9" and "11" the indicator pointer can reach the left stop of the scale.

8. Check the frequency of transmitter generator CR-1-2. For this purpose insert tester KHMU-3 and converter MA-100 near the transmitting antenna. Connect a rod antenna to R.F. receptacle TO RECEIVER ( K ПРИБОРУ ПОЛУЧАТЕЛЯ ) on instrument KHMU-3 using a cable from the spare set of KHMU-3. Set the function switch on instrument KHMU-3 to position FREQUENCY OF TRANSMITTER CR-1 ( ЧАСТОТА ПЕРДАВАТЕЛЯ CR-1 ). Energize the instrument.

Bring the antenna of instrument KHMU-3 to transmitting antenna CR-1-2 and keep it vertically 0.5 - 0.7 m. away from the aircraft body on the line between the transmitting and receiving antennas of the range finder. Find the generator frequency, rotating the vernier tuning knob on the instrument until maximum deflection of meter "KB" pointer on instrument KHMU-3 is obtained. Read the generator frequency (in Mc/s) on the limb scale marked FREQUENCY Mc/s ( ЧАСТОТА В МГц ). The frequency of the transmitter generator must be within  $845 \pm 1$  Mc/s.

9. Check the frequency of the receiver local oscillator. To do this, bring the antenna of instrument KHMU-3 close to receiving antenna CR-1-1 and keep it near the aircraft body so that the antennas are in parallel alignment with each other. Set the function switch of instrument KHMU-3 to position RECEIVER FREQUENCY ( ЧАСТОТА ПРИБОРА ПОЛУЧАТЕЛЯ ).

Determine the local oscillator frequency in accordance with Point 8. The oscillator frequency must be within  $855 \pm 1$  Mc/s.

**CAUTION:** Operations indicated in Points 8 and 9 should be done in case of unstable operation of the range finder.

10. Deenergize the range finder and testers KHMU-1 and KHMU-3.

#### Localizer Receiver KHM-8 and Glide-Slope Receiver

##### FPB-2 of Instrument Landing System (Feeder H7200-22)

1. Check mechanical "crosses" of instrument KHM-8.
2. Energize receivers KHM-8 and FPB-2, for which purpose turn on tumbler ABC-10 of the ILS of the circuit-breaker panel of the left pilot and the tumblers on the ILS control panel.
3. Install simulators KHM-8 and FPB-2 5 - 15 m. in front of the aircraft and energize them.
4. Check the performance of the localizer receiver for which purpose: Set switches of simulator KHM-8 (Fig. 161) to positions: COURSE ( КУРС ), OPERATION ( РАБОТА ), MODULATION ( МОДУЛЯЦИЯ ), PILED WAVE No.1 ( ШИРОКОПОЛОСНАЯ ВОЛНА No.1 ); set the channel selector on the ILS control panel to position "1"

- 229 -

50X1-HUM

(first channel). This will cause operation of the drop indicator of the COURSE channel emergency signalling system (the black bulleye drops) and right- or left-side deflection of the vertical pointer of indicator KHM-8 depending upon the position occupied by the phase shifter limb on simulator KHM-8. The indicator pointer must overshoot when the limb is turned by 90°.

Check the operation of the localizer receiver on the other channels setting the wave switches on simulator KHM-8 and control panel simultaneously in positions "2", "3", "4", "5" and "6".

Control panel M-50 and indicator KHM-8 are shown in Figs 162 and 163. Make sure that the pointer does not deflect and the drop indicator does not operate when the simulator and receiver operate on different fixed waves. For this purpose switch over the receiver channels alternately (from the first to the sixth) for each position of selector PILED WAVE ( ШИРОКОПОЛОСНАЯ ВОЛНА ) on simulator KHM-8. The pointer of indicator KHM-8 is allowed to deflect within the black circle in the absence of signals from simulator KHM-8.

5. Check the electrical zero (balancing) of the localizer receiver. For this purpose press button ZERO CHECK ( КОМПЕНСИРУЙТЕ НУЛЬ ) on the front panel of the receiver; the vertical pointers of indicators KHM-8 should come to stand against zero (boundary between the blue and yellow sectors of the indicator scale). Check in the like manner the electrical zero by pressing button CHECK on control panel M-50.

If the indicator pointers fail to settle against zero, open the cover labelled ADJUSTMENT on the front panel of the receiver (Fig. 164), loosen the locking nut of control knob BALANCE ( БАЛАНС ), turning by means of a screwdriver control knob BALANCE adjust the indicator pointers exactly to the scale zero and then lock the control knob.

6. Check the localizer receiver sensitivity. In doing this turn the limb of the simulator phase shifter through such an angle that the meter pointer on the simulator may stop at the end of the yellow-blue sector of the scale. In this case, the vertical pointers of indicators KHM-8 should also deflect to the right and stop at the end of the yellow sector. Turn the phase shifter limb counter-clockwise until the pointer of the simulator meter comes to stand at the end of the yellow-blue sector. As a result the indicator pointer must deflect to the left.

**CAUTION:** 1. The pointer is allowed to deflect asymmetrically to either side by 20 per cent.

2. The difference of pointer deflection of both indicators is allowed to be 20 per cent towards one side.

7. At larger or smaller deflection of the indicator pointers with respect to the end of the blue or yellow sector of the scale, adjust the receiver sensitivity by control SENSITIVITY ( ЧУВСТВИТЕЛЬНОСТЬ ) located on the front panel of the receiver so that the indicator pointer stops at the end of the yellow or blue sector of the scale.

Lock the sensitivity control and shut cover ADJUSTMENT of the localizer receiver.

8. Check the performance of glide-slope receiver FPB-2. In doing this proceed as follows:

- (a) Set switch H.F. LEVEL - L.F. LEVEL ( ПЕРЕКЛ. В.Ч. - ПЕРЕКЛ. Н.Ч. ) on simulator FPB-2 (Fig. 165) to position L.F. LEVEL switch MODE OF OPERATION to position 90 c.p.s. LEVEL ( ПЕРЕКЛ. 90 П/с ) and rotate knob 90 c.p.s. LEVEL to adjust the meter pointer of simulator FPB-2 to mark LEVEL.
- (b) Set the function switch to position 150 c.p.s. LEVEL and rotate knob 150 c.p.s. LEVEL to adjust the meter pointer to mark LEVEL.
- (c) Reset switch as indicated in Point 8 a, b, and make sure that the meter pointer settles exactly against mark LEVEL after every operation.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

(d) Set the fixed-wave switch on the simulator to position "1". Set switch H.F. LEVEL - L.F. LEVEL to position H.F. LEVEL and operate knob H.F. LEVEL to adjust the simulator meter pointer to mark LEVEL. Set the channel selector on the control panel of receivers FPM-2 and FPM-4 successively to positions "1", "2", "3", "4", "5" and "6". In this case the horizontal pointer (glide-slope indicator) must deflect, and the drop indicator of the emergency signalling system must operate only when the channel selector on the receiver control panel is set at positions "1" and "2".

Depending upon the setting of switch MODE OF OPERATION on simulator FPM-2 to positions marked with signs showing the direction of the pointer deflection the horizontal pointer of indicator HCH-48 must deflect up or down respectively.

(e) Repeat as instructed under Point 8, d for the remaining positions of the wave switches, taking into account that positions of the switch on the control panel of the receivers correspond to those of the fixed-wave switch of simulator FPM-2 in the following order:

Positions of switch on simulator	1	2	3
Positions of switch on control panel	1 and 2	3 and 4	5 and 6

9. Check the electrical zero (balancing) of glide-slope receiver FPM-2, for which purpose set the function switch on simulator FPM-2 to position CHECK; in this case, the horizontal pointers of indicators HCH-48 must settle against zero, along the horizontal dotted line on the scale.

If the balancing is upset, open the cover labelled ADJUSTMENT on the glide-slope receiver (Fig.166), slacken locking nut of control BALANCE and operate the control with a screwdriver to set it so that the horizontal pointers of the indicators settle against zero. Lock control BALANCE.

Note: The electrical zero is allowed to be checked directly through the low-frequency channel of the receiver. For this purpose connect socket RECEIVER on simulator FPM-2 through a special cable from the complement of the simulator to socket TESTER (TESTER) on the localiser receiver and do operations indicated under Point 9.

10. Check the glide-slope receiver sensitivity. For this purpose set switch MODE OF OPERATION on the simulator alternately to the positions showing the direction of the pointer deflection (Positions 4 and 5). In this case, the horizontal pointers of indicators HCH-48 must settle respectively between the first and third dots of the upper or lower vertical line of dots on the indicator scale, and the drop indicators of the emergency signalling system must operate. If the pointers fail to settle within the given limits, unlock control SENSITIVITY on the glide-slope receiver and turn it with a screwdriver so that the indicator pointers will stand against the second dot (from the centre) in the vertical row.

Lock the SENSITIVITY control and shut cover ADJUSTMENT on the glide-slope receiver.

CAUTION: 1. The pointers are allowed to deflect asymmetrically up and down by 20 per cent as well as to differ in deflection by up to 20 per cent towards one side on both indicators.

2. The sensitivity is allowed to be checked with the receiver directly connected to simulator FPM-2 through radio-frequency cable RFE-32 taken from the simulator complement. In this case, disconnect the antennas of the receiver and simulator and check the sensitivity as instructed under Point 10.

Receivers Trouble Chart

Trouble	Probable cause	Remedy
1	2	3
Localiser receiver FPM-2		
On energizing receiver, pointer fails to operate	Blown fuse in supply circuit. No contact in tumbler ON on control panel. Poor contact in terminal block connecting dynamotor with receiver. Break in wires of supply circuit. Defective dynamotor	Replace fuse. Check and make tighter contacts in supply connectors. Replace dynamotor
Dynamotor operates, but pointer fails to deflect on rotating control	Defective valve M10 (GISM)	Replace defective valve
Indicator pointer deflects and overshoots to one side only	Maladjusted control BALANCE	Adjust control BALANCE
With simulator KHPM-2 operating the indicator pointer fails to deflect in both sides. SENSITIVITY control has no effect on pointer deflection, but drop indicator operates normally	Shorted contact ZERO CHECK or relay P7. Control SENSITIVITY is at minimum	Eliminate short circuit. Adjust sensitivity
Receiver fails to operate, no negative voltage across pins 1-5 of valve M13	Defective valve M13 (12FL)	Replace valve
Receiver fails to operate on one of channels	Defective crystal. Poor contact in switch on control panel	Replace crystal. Restore switch contact
Relay of one or two of channels fails to operate	Break of relay supply circuit. Punctured winding of channel relay in receiver FPM-2	Eliminate break or poor contact in supply circuit of relay winding. Replace defective receiver FPM-2
Drop indicator of emergency signalling system fails to operate	Poor contact, break or short in drop indicator supply circuit	Check supply circuit, eliminate trouble
With simulator operating, pointer of indicator HCH-48 deflects little	Inter-electrode short in one of valves	Check valves, replace defective one

SECRET  
NO FOREIGN DISSEM



NO FOREIGN DISSEM



1	2	3
	<u>Slide-slope receiver FPM-2</u>	
On energizing receiver dynamotor fails to operate	Blown fuse of receiver in distribution box Poor contact in supply connectors on receiver or control panel. Poor contact in dynamotor terminal block. Broken supply wires	Identify supply circuits. Make tighter contacts in connectors. Restore wire connections
Pointer of indicator HCB-48 fails to deflect when simulator FPM-2 operates. Drop indicator does not operate	One of valves is defective. Poor contact in terminal block of dynamotor	Replace defective valve. Make tighter contact in terminal block
Receiver fails to operate on one of channels	Poor contact in channel selector. Defective crystal. Break in supply wire of relay winding	Make contact tighter. Replace crystal. Restore wire connection
Pointer of indicator HCB-48 does not deflect. Drop indicator operates	Poor contact in indicator connector. Defective indicator	Make contact tighter. Replace indicator HCB-48
Low sensitivity of receiver	Low voltage of aircraft mains. Loss of emission by one or several valves	Adjust aircraft mains voltage to 27.5 - 28 V. Check valves, replace defective ones
During joint operation of both receivers receiver KPM-4 does not operate on one of waves	Winding of one of relays of receiver FPM-2 shorts relay winding of receiver KPM-4	Send receiver FPM-2 to repair shop to have defective relay replaced

**CAUTION:** With the receiver energized do not remove the valves from their sockets as it may result in good valves being damaged due to overheating.

Airborne Transponder CPO  
(feeder H7200-20)

**CAUTION:** Do not insert the fuse plug into ARMED socket on the transponder transmitter-receiver (do it only before flight).

1. Check the ARMED circuit of the station, for which purpose (if there is a battery in 8-2):

- (a) Connect a 28-V lamp to the pins of the fuse plug.
- (b) Press button EMERGENCY ARMED - TRANSPONDER (ABAPPHHHE B3PHB - PAHMOOTHTHTHT) on the instrument panel of the left pilot; in this case the lamps on the ARMED button and that indicating connection to the fuse plug light up.

50X1-HUM

- (c) Disconnect one pole of the lamp from the fuse plug and connect it to the aircraft body; the lamp should not burn. Check similarly the second pin of the fuse plug.
- 2. Check the inertia switch. In doing this proceed as follows:
  - (a) Turn out the upper transparent cover of the contactor.
  - (b) Connect the pilot lamp to the contactor plug.
  - (c) Move the pendulum lever until a sharp click is heard. In this case, the lamps on the ARMED button body and pilot lamp on the contactor plug must come on.
  - (d) Cock the inertia contactor again. For this purpose turn out the transparent cover on the right side, insert a screwdriver in the screw slot and turn the screw fully counter-clockwise. The pendulum lever must settle and fix itself in the vertical position. The lamps on the button and contactor plug must go out.
  - (e) Seal the contactor covers.

Checking Airborne Transponder on the Ground

1. Energize the transponder by tumbler A30-5 TRANSPONDER located on the circuit breaker panel of the right pilot and by the TRANSPONDER switch on the control panel of the left pilot. In this case, a code illumination lamp must light up on the code panel of the left pilot.
  2. Have the ground interrogator positioned at the control post energized. This is done by challenging over the radio from the aircraft being checked.
  3. Set tumbler READY - RESPONSE ( POTOBHOCYB-OTBET ) to position RESPONSE.
  4. Check the code system for proper operation by placing the code selector on the code panel successively from the first to the fourth position. In this case Morse code signals corresponding to preset code must be heard in the earphones connected to the TQPH sockets on the code panel. At the same time the code lamps on the code panel must flash in step with the signals. During transmission of a short signal (dot) one lamp must light up, during transmission of a long signal (dash) - two lamps.
- The sequence of short and long signals during transmission of codes is tabulated below.

T a b l e 32

Transponder Codes (Pulse Sequence)

Codes	Letters	Cycle				
		1	2	3	4	5
1	X	Narrow	Narrow	Narrow	Narrow	Interval
2	O	Narrow	Narrow	Narrow	Interval	Interval
3	B	Narrow	Narrow	Wide	Wide	Interval
4	Y	Narrow	Narrow	Wide	Interval	Interval

5. Switch on tumbler DISTRESS SIGNAL (BEMOTBHE) on the code panel. This will cause transmission of distress signals instead of intervals alongside with code signals. Both code lamps must light up simultaneously with distress signals.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 234 -

Radar Bombight FEB-1

The preflight preparation of the sight comprises:

- (1) Visual inspection.
- (2) Checking air-tightness of the waveguide system and units P2 and P12.
- (3) Checking and adjustment of the live equipment of the navigator-operator.
- (4) Checking the pulse length for automatically switching on optical sight ONE-1p.
- (5) Checking and adjustment of the live equipment of the navigator.

Visual Inspection

When inspecting the sight visually proceed as follows:

- (1) Check the presence of all the units and inspect their surface for evidence of mechanical damage.
- (2) Check that the units are secured reliably on shock-mounted frames.
- (3) Check the connection of cables and feeders to all the units according to their numbers; make sure that the cable and feeder connectors are closely tightened with nuts.
- (4) Check for presence and good condition of all the fuses (working and spare) in connection box P-15 (See Table 33).
- (5) Check for complete set of spare equipment and radio valves.

Fuses Table 33

No.	Fuse No.	Unit	Current, A	Voltage, V
1	2	3	4	5
1	15-1	P3	2	115
2	15-2	P4	2	115
3	15-3	P5/1	2	115
4	15-4	P11	10	115
5	15-5	P10	2	115
6	15-6	P14(P5/2, P7, P8)	5	115
7	15-7	P2 and P12	10	115
8	15-8	P1	5	115
9	15-6	Control (P3 and P6)	15	27
10	15-10	P14(P7, P8, P9, P11, P5/2)	5	27
11	15-11	P2 and P12	10	27
12	15-12	P1 and P5/1	10	27
13	15-13	Asimuth 1	2	27
14	15-14	Asimuth 2	2	27

Checking Air-Tightness of Waveguide System and Units P2 and P12

The waveguide system and units P2 (Fig.168) and P12 is checked for airtightness by means of device 137-m that comes with the equipment.

**ATTENTION:** When making a check do not shut the pipe connection of the intake valve on unit P12.

- 235 -

50X1-HUM

Connect the nipple of the rubberized hose of device 137-m to the outlet nipple of unit P2 through reducer RM-950. Build up an excessive air pressure of 0.8 atm. in the airtight system. Switch on the continuous rotation of the antenna for 30 min. and then sector swinging for 30 min. changing the antenna tilt periodically. After an hour check the pressure in the airtight system by the low-pressure gauge of device 137-m. The gauge reading should not differ from the initial value by more than 0.03 atm.

Checking and Adjustment of Live Equipment of Navigator-Operator

- CAUTION:** 1. Voltages dangerous to human life exist in the operation of the equipment; removal of the cases and disconnection of the cables with power on should be allowed on no circumstances.
2. The bombight is allowed to be energized on the ground if at least 5-kw airfield power supply is available.
  3. Prior to changing over converters NO-4500 it is necessary to switch off circular scanning and sector scanning to prevent unphasing of the bombight indicators.
  4. Make various adjustments except those in 27-V circuit only after the equipment has warmed-up for 15 min.
  5. Switch on the transmitter only 2-3 min. after power has been turned on.
  6. In case of elevated ambient air temperature do not switch on the equipment for a long period. At +50°C the continuous operation of the equipment should not be longer than 50 min. The equipment is allowed to be energized 1 hour after it has been demagnetized.
  7. At ambient temperatures below -10°C the transmitter may be energized after the equipment has been warmed-up for 15 min.
  8. To avoid cooking of the covers and damage to the case collar, turn in and out the bolts and nuts during installation and removal of the covers of units P2 and P12 gradually in the sequence shown in Fig.169.
  9. When tightening the covers set all the bolts previously into the cover holes and centre the cover in reference to all eight bolts.
  10. When working on the ground with the transmitter energized tilt the antenna by -25° if there is no need to obtain presentation.
1. Set the equipment controls in the positions indicated in Table 34.
  2. Make sure that 27.5 V D.C. are applied. If necessary, give instructions to the electrician to adjust the ground supply voltage to 27.5 V.
  3. Set the converter switch to position OPERATING (РАБОТЯЩ) (in special cases, to position STAND-BY (РЕЗЕРВНО)).
  4. Close the circuit breaker of converter NO-4500 on the circuit-breaker panel of the navigator-operator.
  5. Consult the 115 V A.C. airborn check voltmeter to make sure that A.C. voltage is applied and to measure its magnitude. If the voltage is outside the 113 - 117-V range bring it to normal (115 V) by means of the converter adjusting screw located on the electric panel of the navigator-operator.
  6. Close circuit-breaker AJC-20 RADAR SIGHT (РАБОТЯЩ) on the circuit-breaker of the navigator-operator.
  7. Use the interphone system to warn the technician who is now at the aircraft navigator's position about the bombight to be energized and get an answer as to its being ready for energizing.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



8. Press button SUPPLY ON (DVTANGH BKL.) on unit P6 (Figs 170 and 171). Green pilot lamps must light up on the panel of the navigator-operator (P6) and bomb aimer's panel P9. Consult voltmeter SUPPLY on unit P6 to make sure that it reads 115 V, 400 c.p.s.  
 Make sure that voltmeter CHECK (KONTROL) on unit P6 reads +300 V D.C. If necessary operate potentiometer +300-V ADJUSTMENT (VOTAH. HAIP. +300s) on unit P11 to adjust the voltage to +300 V.  
 Set switch CHECK on unit P6 to position "+300 V" (-300 s). Make sure that this voltage is within ±290 to 320 V (the pointer overshoots not more than 2 ms). This done, set the switch to position MAIN CRYSTAL CURRENT ( TOK KPHCT.OCH.).

Table 34

INITIAL POSITIONS OF CONTROLS ON UNITS

P6L-4 and OHE-11p

Unit	Controls	Position	
		1	3
Navigator-operator's panel P6	Switch CHECK		+ 300 V
	Switch APC-BEACON		APC - OFF
	Switch RANGE, KM		"10 - 70"
	Switch SWEEP DELAY, KM (ZADENPKA PABREPTKH KM)		0
	Switch ROTATION (SPABEGHE)		OFF
	Switch COURSE LINE (BEBEH KYPKA)		OFF
	Switch SECTOR SCANNING (CENTOPHAI OBOGOP)		OFF
	Switch FREQUENCY		"1"
	Knob ALTITUDE DELAY (ZADENPKA HA ENOOTY)		Extreme counter-clockwise position. Middle position
	Knob RECEIVER TUNING		Extreme counter-clockwise position
	Knob "10-70"		Middle position
	Knob POSITION CONTROL ( PEP. DOROK.)		Extreme counter-clockwise position
	Knob RANGE MARKER BRIGHTNESS (PHOCTH METOK HAJIM.)		Extreme counter-clockwise position
	Switch MARKERS (METOK)		Middle position
Operator's and photoattachment indicator P5/1, P5/2	Azimuth scale rotation knob		Scale zero is matched with zero index
	Light filter rotation knob		Central vertical line on light filter is matched with zero index
	Knob SCALE ILLUMINATION (DOROKH BKAM)		Extreme counter-clockwise position
	Knob BRIGHTNESS		Extreme counter-clockwise position
Bomb aimer's panel P9 (Figs 172 and 173)	Switch CALIBRATION (KALIBROVKA)		OPERATION
	Knob SCALE ILLUMINATION		Extreme counter-clockwise position

50X1-HUM

	1	2	3
Bomb aimer's indicator P8 (Figs 174 and 175)		Scale SLANT RANGE CORRECTION (DORPKA HAKOBEHO HAHPOCTH)	"0"
		Switch SEARCH - HOLDING (DOROK - HAHBEHEHE)	SEARCH
		Switch SPEED GENERATOR (PHEBATOP CHPOCTH)	OFF
		Knob POSITION (DOROKHEHE)	Extreme counter-clockwise position
		Knob TRACK SPEED (DVTBAH CHPOCTH)	200
		Knob BRIGHTNESS	Extreme counter-clockwise position
		Knob SCALE ILLUMINATION	Extreme counter-clockwise position
		Switch AZIMUTH (AZIMPT)	ON
		Light filter	To be turned until the lock operates
		Azimuth scale	Scale zero is matched with central vertical line on light filter
Range unit P3 (Fig.176)		Switch CALIBRATION - OPERATION (KALIBROVKA - PABOTA)	OPERATION
		Knob LOW LEVEL (HBEHE YPOBEH)	1/4 of turn from extreme counter-clockwise position
Navigator-operator lock unit P8 (Fig.177)		Knob HIGH LEVEL (HBOOKEH YPOBEH)	1/4 of turn from extreme clockwise position
		Knob RECEIVER GAIN	Extreme counter-clockwise position
Optical sight OHE-11p		Index of sighting angle scale	"0"
		Scale ALTITUDE (BHOCTA)	"14 KM"
		Index of drift angle scale	"0"
		Lock of vertical gyro switch CORRECTION (KOP-PEKHEH)	LOCKED (ZAAPETPOBADO)
		ON-OFF switch on altitude scale	OFF
		Handle LAG (OTCTAHHE)	"0"
		Handle SERIES (CEPH)	"0"
		Other controls	According to operating instructions for optical sight OHE-11p

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 236 -

9. Gauge PRESSURE IN TRANSMITTER ( ДАВЛЕНИЕ В ПРЕДАТЧИКЕ ) on unit P6 should read normal pressure of  $1 \pm 0.2$  atm. After the equipment is warmed up the pressure may rise to  $1.4$  atm.

10. Make sure (by ear) that the fan motors in units P2 and P12 are started.

11. Turn knob SCALE ILLUMINATION on indicators P5/1 and P5/2 until the scale is properly illuminated.

12. Turn knob BRIGHTNESS on indicators P5/1 and P5/2 clockwise until appearance of the sweep trace. Turn switch RANGE KM on unit P6 to positions "10", "20", "10-70", "100" and "200" and then return it to position "10-70". Do in the like manner when setting switch APO-BEACON to position BEACON, the sweep should not vanish from the indicator screens at all positions of switches RANGE KM and APO-BEACON on unit P6.

The sweep brightness is controlled by knobs BRIGHTNESS on units P5/1 and P5/2.

13. Use knob FOCUS on the indicators to focus the sweep trace so that it may be as thin and contrast as possible. To avoid the interference of the screen after-glow displace the sweep trace by momentarily pressing switch SEARCH on unit P6.

Note: Focusing on indicators P5/1 and P5/2 is obtained noticeably better than that on indicator P6.

14. Set switch SWEEP DELAY KM in all positions from "0" to "400"; the sweep should not vanish from the indicator screens. Reset the switch to the zero position.

15. Set switch ANTENNA TILT (НАКЛОН АНТЕННЫ) first to position UP (ВВЕРХ) and then to position DOWN (ВНИЗ). Make sure by the tilt indicator on unit P6, that the antenna is tilted up by  $5 \pm 1^\circ$  and down by  $25 \pm 2^\circ$  from the horizontal position. Establish a tilt angle of  $0 \pm 2^\circ$  as read by the tilt indicator.

16. Set switch SEARCH on unit P6 to position RIGHT (ПРАВО) and allow the antenna to make 2 - 3 revolutions, then to position LEFT (ЛЕВО); the sweep trace must rotate jerkless in the direction corresponding to the switch position at a speed of 9.5 to 14.5 r.p.m. Release the switch.

17. Turn on switch ROTATION located on unit P6. In this case, the sweep trace must rotate smoothly clockwise at a speed of 16 - 24 r.p.m.

The start of the sweep should be matched with the light filter cross-hairs. On displacing the sweep it is necessary to match the start of the sweep with the center of the indicator filter by means of knobs HORIZONTAL CENTERING (Горизонтальное центрирование) on units P5/1 and P5/2.

Note: Make centering on indicator P5 so that the outer end of the sweep may be concentric in relation to the inner circle of the azimuth scale with the antenna rotating.

There may be a discrepancy between the start of the sweep and center of the light filter at which the start of the sweep describes a circle of not more than 3 mm in diameter with the eccentricity not exceeding 0.5 mm.

18. Turn on switch COURSE LINE and make sure that there is a course line on the indicator screen. The course line must coincide with the vertical index line of the light filter and azimuth scale zero accurate to  $\pm 1.5^\circ$ .

Note: Course line is not traced on the screen of indicator P6.

Turn off switches ROTATION and COURSE LINE.

19. Turn on switch SECTOR SCANNING. As a result, the sweep trace on the indicator screen must swing within a sector of  $85 \pm 10^\circ$  with a frequency of 40 - 60 oscillations per minute.

Rotate knob POSITION CONTROL fully clockwise and then fully counter-clockwise; make sure that the sector is displaced in azimuth in the front some limited by angles  $305 - 55^\circ$  - on the azimuth scale of the indicator.

Turn off switch SECTOR SCANNING.

20. Turn potentiometer RANGE MARKER BRIGHTNESS on unit P6 clockwise until range markers appear on the indicator screens. Check the presence of range markers on the

- 239 -

50X1-HUM

screens in all positions of switch RANGE KM on unit P6. Range markers should appear every 2-km. intervals with switch RANGE KM in position "10", with 10-km. intervals with 2-km. intervals with switch RANGE KM in position "10", with 10-km. intervals in positions "100" and "200" km.

Note: The marker brightness should be so inserted as to avoid backward journey of the markers on the sweep trace; potentiometer RANGE MARKER BRIGHTNESS should not be placed in the extreme clockwise position.

21. Check the sweep range scale when setting switch RANGE KM to position "10", "20", "100" and "200". If the markers are not in the respective number in one of the switch positions, adjust the amplitude and range of the sweep on the screen of the navigator-operator's indicator following the procedure below:

(a) Set switch RANGE KM in position 20.

(b) Turn knob SWEEP AMPLITUDE (АМПУЛИТУДА ПЕРИОДИЧЕСКОГО) on unit P4 fully counter-clockwise.

(c) Adjust potentiometer RANGE CONTROL (ПЕРИОДИЧЕСКОЕ РАДИОСЧЕТ) on unit P4 so that two range markers are visible on the sweep trace and the sweep trace does not come beyond the second range marker.

(d) Adjust the sweep by potentiometer SWEEP AMPLITUDE so that the second 10-km. marker is coincident with the inner circle of the indicator azimuth scale.

(e) Set switch RANGE KM on unit P6 successively to position "10" and "20" and make sure that 2 and 5 markers respectively have appeared on the sweep trace (counting the markers just after the start of the sweep).

(f) Set switch RANGE KM on unit P6 successively to position "100" and "200" and make sure that 5 and 10 range markers respectively have appeared on the sweep trace.

(g) If the operation (Points e and f) does not cause the required number of markers to appear, readjust potentiometer RANGE CONTROL on unit P4.

(h) If the sweep amplitudes on indicators P5/2 and P6 differ from that on the navigator-operator's indicator, remove the cover of unit P4 case and make an additional adjustment of the sweep amplitude of the indicators by potentiometers P4-15 and P4-16 located at the rear wall in unit P4.

(i) Set all the control knobs to the initial positions.

22. Set switch RANGE KM to position "10-70", turn knob "10-70" fully counter-clockwise. In this case only one marker is allowed to appear on the indicator screen

at the very end of the sweep trace. Turn knob "10-70" fully clockwise; this will cause

7-10 ten-km. markers to appear on the indicator screen.

23. Set switch CALIBRATION - OPERATION on unit P3 to position CHECK 5-1, switch

RANGE KM on unit P6 to position "10-70". In this case four 2-km. range markers with adjustable brightness must locate on the indicator screen between all bright 10-km. markers. If the division is not in line with 5:1 ratio, rotate potentiometer

FREQUENCY DIVISIONS 5:1 (РАДИОСЧЕТ ЧАСТОТЫ 5:1) on the front panel of unit P3 to obtain

correct and clear division.

Then setting frequency division 5:1 proceed as follows:

(a) Set 40 - 50 km. range by turning knob "10-70" on unit P6.

(b) Turn potentiometer FREQUENCY DIVISION 5:1 clockwise until division 5:1 is

out of alignment; note this position.

(c) Turn potentiometer FREQUENCY DIVISION 5:1 counter-clockwise until division

5:1 is out of alignment; note this position as well.

(d) Set the potentiometer mid-way between the marked positions.

24. Set switch CALIBRATION - OPERATION on unit P3 to position CHECK 6:1, switch

RANGE KM on unit P6 to position "200". In this case five 20-km. range markers must

locate between two 6:1 division marks. If the frequency division is not in line with

6:1, obtain the correct division by rotating potentiometer FREQUENCY DIVISION 6:1

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

- 240 -

on the front panel of unit P3. Frequency division 611 is set in the same way as division 511.

Note: When setting frequency division 611 potentiometer RANGE CONTROL on unit P3 is allowed to rotate until stable markers are obtained on indicator screens.

After the frequency division (611) has been checked make a check on the sweep range as instructed in Point 20.

25. Set switch CALIBRATION - OPERATION on unit P3 at OPERATION, switch RANGE KM on unit P6 to position "10-70", knob "10-70" to the maximum clockwise position, knob POSITION on unit P9 to the mid position, tumbler MARKERS on unit P6 to position CALCULATION (RUBKOL.). Set a shorter range on the RANGE scale on unit P6 than the range corresponding to the indicator sweep.

Under normal operation in the SEARCH mode indicators P5/1, P5/2, and P6 will display a range marker being off the centre at a distance corresponding to the range indicated on scale RANGE.

26. To check the operation of the step delay set switch CALIBRATION - OPERATION on unit P3 to position FREQUENCY DIVISION 611, switch RANGE KM on unit P6 to position "200". When setting switch SWEEP DELAY KM to position "0" and "20", four 20-km. markers should appear on the sweep forward of the first bright marker. If they do not, use potentiometer ZERO to adjust the step delay. Rotating switch SWEEP DELAY KM on unit P6 clockwise must cause the bright mark of frequency division 611 to move towards the centre of the indicator screen. The mark moves by 20-km. steps upon every switching, except the first one (from 0 to 20).

If in any position of the switch, 611 frequency division mark fails to cover 20 km. with respect to the previous position, adjust step delay by potentiometer ZERO and RANGE SCALE on unit P3. If you experienced in doing this operation make an adjustment without using an oscillograph. Otherwise adjust the delay of the sweep start by steps up to 400 km. following the procedure below:

- (a) Connect the oscillograph input to grid 1 of coincidence valve J3-9 in unit P3.
- (b) Set oscillograph knobs in the following positions:
  - switch SYNCHRONIZING (CHLIPORERALEN) - in position INTERNAL (BETZPZEBROG),
  - switch SWEEP - in position "250 - 500 microseconds."

Set switch CALIBRATION - OPERATION on unit P3 to position OPERATION, switch RANGE KM on unit P6 to position "200", switch APC - BEACON to position BEACON - ON.

Turn switch SWEEP DELAY KM and watch the marker on the pedestal of the oscillograph screen. If the marker is moved off the middle of the pedestal, move it back by rotating step delay potentiometer ZERO and RANGE SCALE. Rotate potentiometer ZERO with switch SWEEP DELAY KM in positions from 0 to 100 km. At greater delays, rotate step delay potentiometer RANGE SCALE. Make adjustments until the marker is at the middle of the pedestal (not no farther than 1/4 width of the pedestal from the middle) in all positions of switch SWEEP DELAY KM.

Connect the oscillograph input to cathode 3 of coincidence valve J3-9 in unit P3. Turn switch SWEEP DELAY KM successively from one position to another to make sure that every switch-over, except the first one (from 0 to 20) causes the marker to cover one interval; otherwise repeat adjustments.

27. Set switches located on unit P6:
  - CHECK to position MAGNETRON CURRENT (ZOK MAFL.)
  - APC - BEACON to position APC - OFF.

Press button TRANSMITTER ON (BEPRAVNIK BGL.). As a result a red pilot lamp must light up on unit P6.

Set switch RANGE KM to positions "10", "20", "10-70", "100", and "200". Note the readings of meter CHECK on unit P6.

Set switch FREQUENCY to position II and note the readings of meter CHECK again in all positions of switch RANGE KM. For all the ranges the magnetron current should be

50X1-HUM

- 241 -

within 9.5 to 15 mA.

Set switch APC-BEACON to position BEACON-ON. Note the readings of meter CHECK located on unit P6 in all positions of switch RANGE KM and in both positions of switch FREQUENCY on unit P6.

- Note: 1. Rare (non-systematic) self-disconnections of the transmitter do not indicate that the equipment is defective. Such a self-disconnection has occurred, press button TRANSMITTER ON again and proceed operating.
2. If high voltage is not applied upon pressing button TRANSMITTER ON, check the condition of fuses HPL5-7 and HPL5-11 in distribution box P15.
  28. Set switch APC - BEACON to position APC - OFF, switch CHECK to position MAIN CRYSTAL CURRENT and rotate knob RECEIVER TUNING in both directions until the meter reads the maximum value. The crystal current must be within 0.4 to 1 mA with the transmitter energized.

Set switch FREQUENCY on unit P6 to position II and check crystal currents on the second channel.

Note: 1. When energizing the transmitter the currents of the main and APC crystals are allowed to vary by 0.2 mA.

2. At low temperatures the crystal current may rise to 1.3 mA.
3. At the tuning point the currents of the main and APC crystals must be not less than 80 per cent of the maximum currents of the crystals.
29. Set switch APC - BEACON on unit P6 to position APC - OFF. Turn knob RECEIVER TUNING from one extreme position to the other. In this case the crystal current must reach the maximum value with the knob in the middle position. In the extreme positions of the knob the crystal current may differ from zero. Operate potentiometer APC VOLTAGE (HAUPPEKREGE AINU) to obtain the maximum crystal current with knob RECEIVER TUNING in the mid-position.

30. Set switch CHECK on unit P6 to position APC VOLTAGE with the crystal current at maximum; in this case the meter reading must be 160-200 V.

31. Set switch APC - BEACON on unit P6 to position APC - OFF. Rotate knob RECEIVER TUNING from one extreme position to the other. This should cause the APC voltage to vary within 30 to 40 V.

32. Turn knob RECEIVER GAIN located on unit P6 fully clockwise and make sure that there is clutter on the sweep trace of the indicator after which turn the knob back to the initial position, i.e. fully counter-clockwise.

33. Set switch APC - BEACON to position APC - OFF. Aim the antenna at the known object or with the antenna rotating tune the equipment to an echo signal from any unit P6. BRIGHTNESS on the indicators. To obtain better display choose optimum positions of switches RANGE KM and ANTENNA TILT. As a result clean echo signals reflected from the objects must appear at certain distances.

34. Set switch APC - BEACON on unit P6 to position APC - ON. The presentation of the echo signals on the indicator must be the same as during optimum manual tuning when the switch is set at APC - OFF.

Place switch CHECK on unit P6 to position MAIN CRYSTAL CURRENT. Rotate knob RECEIVER TUNING all the way in both directions; in this case the pointer of the CHECK meter must be motionless and read the crystal current within 0.4 to 1 mA, and the presentation on the indicator screen should not fade. Check this with switch FREQUENCY in both positions and antenna rotating.

Note: If, during APC operation after different kinds of change-over (changing over frequency, range, step delay), the APC voltage appears to be lower than the normal rated value, turn knob RECEIVER TUNING clockwise to bring this value to normal (in this case the voltage is varied by jumps). This operation done, set knob RECEIVER TUNING to the mid-position.

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 242 -

35. To check and adjust the range delay, place switch CALIBRATION - OPERATION on unit P3 in position RANGE CALIBRATION (KALIBROVKA RAZMEROV), switch RANGE EM on unit P6 in position "10-70", turn knob "10-70" on unit P6 until 30-40 km. sweep range is obtained.

Turn knob RANGE on unit P6 and watch matching of the range marker with the appropriate calibration markers (on ranges divisible by 2). A divergence of  $\pm 100$  m. is allowable. If this is not so, adjust the range delay following the procedure below:

- Rotate scale RANGE located on unit P6 in the direction from 2 to 30 km., count how many times the range marker is matched with calibration markers on the indicator screen.
  - Adjust potentiometer RANGE-SCALE on unit P3 to match the lower edge of the range marker with that of the 14th calibration marker on the indicator screen with the RANGE scale set at 28 km.
  - Set scale RANGE on unit P6 to position "2 km." and match the lower edge of the range marker with that of the first calibration marker on the indicator by adjusting potentiometer RANGE-ZERO on unit P3.
  - Set scale RANGE on unit P6 to position "28 km." and obtain precise adjustment of the range scale.
  - Repeat operations indicated in Points b and c a few times to obtain precise adjustment.
  - Set scale RANGE successively to positions 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28 km. and make sure that the range markers are matched with the appropriate calibration markers accurate to  $\pm 100$  m.
36. Press button TRANSMITTER OFF; in this case the transmitter is not fed with power, the magnetron current is absent, the red pilot lamp on unit P6 goes out.
37. Make sure that there is a sweep trace and range markers on the screen of indicator P8 in the SEARCH mode.

Checking Pulse Duration for Automatic Connection  
of Optical Sight OOB-11p

Apply 220 V, 50 c.p.s. to instrument UB-52 via relay contact K7-7 as shown in Fig. 179.

Connect one end of the relay winding to terminal 1448 in unit P14, the other - to the body.

Set switches located on unit P9: CALIBRATION to position OPERATION and SPEED GENERATOR to position ON.

Determine the pulse duration by a stopwatch at the moment when lamp SIGHTING BUTTON ON (KHOVKA BEKHOBAHNI ENL.) lights up on unit P9. The pulse duration must be within 0.25 to 0.8 microsec.

Checking and Adjustment of Energized  
Navigator's Equipment

- Set all the control knobs to the initial positions as shown in Table 34; prior to checking and adjusting the navigator's equipment see that division 61, step delay zero and altitude zero of the search part of the equipment are set properly.
- See that a green pilot lamp labeled SUPPLY ON lights up on unit P9 upon energizing the equipment and adjust the brightness of the pilot lamp by means of a shutter.

- 243 -

3. Adjust the required illumination of the indicator scale by smoothly rotating knob SCALE ILLUMINATION on unit P8. Adjust the required illumination of scales START RANGE CORRECTION M and TRACK SPEED KM/HR located on knob above a panel P9.

4. Set switch ANTENNA TILT on unit P9 first to position UP, then to position DOWN.

Make sure by means of the antenna tilt indicator on unit P6 that the antenna tilts up by  $5\frac{1}{2}^\circ$  and down by  $25\frac{1}{2}^\circ$ . Set switch ANTENNA TILT to the mid-position when the tilt indicator reads  $0^\circ$  or  $-2^\circ$ .

5. Rotate knob BRIGHTNESS smoothly clockwise (located on unit P6), adjust the brightness of PPT display to the required level.

6. Set switch SEARCH - HOMING (HOREK-HAZERENIE) located on unit P9 to position SEARCH; make sure that the sweep brightness is approximately the same as that in the SEARCH mode.

NOTE: If there is no sweep trace in the HOMING mode, check in what direction (in azimuth) the antenna is installed and, if need be, adjust the sweep to  $0^\circ$  of the azimuth scale of indicator P5/1.

7. Rotate knob FOCUS on unit P8 to focus the sweep trace so that it may be as thin and contrast as possible.

8. Set switch SEARCH - HOMING located on unit P9 to position SEARCH and make sure that the sweep trace starts from the centre of the light filter. If this is not so, operate knobs HORIZONTAL CENTERING and VERTICAL CENTERING PPT on unit P8 to match the start of the sweep with the centre of the indicator light filter.

9. Rotate knob POSITION on unit P9 clockwise; in this case the sighting pip on the screen of indicator P8 must move from the side of the sweep towards the centre of the screen.

10. Make a horizontal centering of the sweep trace on the screen of indicator P8 in the homing mode following the procedure below:

- Set switch SEARCH - HOMING on unit P9 to position HOMING.
- Adjust the antenna exactly to  $0^\circ$  of the azimuth scale of indicator P5/1.
- Make sure that the sweep trace in the SEARCH mode is exactly coincident with  $0^\circ$  of the azimuth scale and central vertical line on the light filter of indicator P8.
- Make sure that the drift angle index of the optical bombsight is exactly coincident with  $0^\circ$  of the drift angle scale on the course stabilizer; if necessary, bring them in precise alignment.
- Make sure that the vertical gyro of the optical bombsight is locked, whilst switch AZIMUTH on unit P8 is set at OFF.
- Make sure that  $0^\circ$  of the indicator azimuth scale - the central vertical line on the light filter - is matched precisely with the white index on the front of indicator P8; if necessary bring them in line.
- Operate knob HORIZONTAL CENTERING to precisely match the sweep trace with the central longitudinal line on the light filter. Matching done, tighten the union nut of the knob.

11. Make a vertical centering of the sweep trace following the procedure below:

- Make sure that switch CALIBRATION on unit P9 is set at OPERATION, switch SEARCH - HOMING on unit P9 at HOMING, and switch RANGE EM on unit P6 is set at "10-70".
- Set switch AZIMUTH on unit P8 at ON.
- Switch on sector scanning; in this case knob POSITION CONTROL on unit P6 must be set at the mid-position.
- Match the upper edge of the sighting line with the transverse line of the light filter by smoothly rotating knob VERTICAL CENTERING. Care should be taken to bring the sighting line upwards. Tighten the nut of knob VERTICAL CENTERING on unit P8.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 244 -

12. When checking the drift angle compensation circuit proceed as follows:
- Set the sweep trace at the course line, place switch COURSE LINE located on unit P6 in position OFF. Bring the scale zero on the screen of indicator P5/1 in line with the sweep trace.
  - Make sure that the EPI display on the screen of indicator P8 is adjusted to 0°. Turn on and off switch AZIMUTH on unit P8 several times watching simultaneously the homing sweep trace on the indicator screen. The sweep trace must be motionless in relation to the longitudinal axis of the light filter. If it is not, make the B display motionless by changing over switch SEARCH. Make a check with the optical sight (ONE-11p) adjusted.
  - Check the horizontal centring.
  - Turn on switch AZIMUTH located on unit P8.
  - Turn the antenna through 20° to the right.
  - Turn the sight toward the antenna until the vertical sweep is coincident with the central longitudinal line of the light filter on indicator P8.
  - Read off the drift angle from the drift angle scale located on the course stabilizer. The reading must be equal to the antenna turn angle with a tolerance not exceeding ±2°.
  - Make a similar check when turning the antenna through 20° to the left.
  - If the value read off the drift angle scale comes beyond the limits of ±2°, check the adjustment of the drift correction potentiometer following the procedure below:
    - disconnect cable No. 16 from the altitude unit of sight ONE-11p;
    - set switch AZIMUTH to position ON and make a horizontal centring of the homing sweep on unit P8. Set the sight at zero on the scale of the course stabilizer, lock the gyro;
    - connect cable No. 16 to the altitude unit of sight ONE-11p. The B display on the screen of indicator P8 should be motionless or is allowed to move within ±0.5°. The sweep displacement in excess of ±0.5° testifies to faulty operation of sight ONE-11p;
    - remove the dose;
    - turn the antenna through 20° to the right as measured by the scale mounted on a crown gear, turn the sight (ONE-11p) in the same direction through a drift angle equal to the antenna turn angle and operate potentiometer DRIFT CORRECTION on unit P8 to match the vertical sweep trace with the longitudinal central line on the light filter;
    - turn the antenna through 20° to the left and do the same operations as during turning of the antenna through 20° to the right;
    - make a check when the drift angles are ±10°;
    - the accuracy when matching the sweep with the longitudinal line on the indicator light filter must be at least ±1°;
    - tighten the locking nut of the drift correction potentiometer shaft on unit P8.
  - Check and adjust the bomb side deviation system and bank compensation following the procedure below:
    - Make sure that the vertical gyro of sight ONE-11p is locked.
    - Set all the controls on sight ONE-11p to positions indicated in Table 35.

- 245 -

Positions of Controls on ONE-11p Sight with Corresponding  
Antenna Turn Angle by Scale Mounted on Crown Gear of Antenna

Table 35

No.	Antenna turn angle (drift angle + $\varphi_{side}$ )	Leg, %	Sighting angle, degrees	$\varphi_{side}$	Drift angle, degrees
1	+22°30'	51	45	7°30'	+15
2	-22°30'	51	45	7°30'	-15
3	+25°	25.5	45	5°	+20
4	-25°	25.5	45	5°	-20

- Turn the antenna through drift angle +  $\varphi_{side}$  (degrees) to the right (or left).
- The antenna turn angle is taken from column DA +  $\varphi_{side}$  in Table 35.
- Turn the sight to follow the antenna until the sweep trace is matched with the central longitudinal line of the light filter of indicator P8 and at the moment of matching note the reading of the drift angle index of sight ONE-11p on the drift angle scale. The drift angle value should correspond to that specified in Table 35 with a tolerance not exceeding ±2°.
- Make a similar check of all the drift angles given in Table 35.
- If the drift angle value does not correspond to that given in Table 35 (with a tolerance of ±2°), adjust the transverse stabilization as follows:
  - turn the antenna through angle DA +  $\varphi_{side}$  as measured by the scale mounted on a crown gear of the antenna as indicated in Table 35;
  - turn the optical sight to follow the antenna through a drift angle (Table 35) corresponding to the antenna turn angle DA +  $\varphi_{side}$ ;
  - rotate potentiometer TRANSVERSE STABILIZATION (BOHRPBYH. OTAB.) on unit P8 to match the sweep trace with the central longitudinal line of the light filter;
  - make a check of all drift angles indicated in Table 35. Accuracy in matching the sweep with the longitudinal line on the light filter should be at least ±1.5°;
  - tighten the locking nut of the shaft of potentiometer TRANSVERSE STABILIZATION on unit P8;
  - place the antenna dome in position.
- To adjust zero and range scales proceed as follows:
  - Set the controls to the positions indicated in Table 36.
  - Engage the transmitter.
  - Turn the slant range correction scale clockwise if the sighting marker is above the calibration marker and counter-clockwise if the sighting marker falls to reach the calibration marker. See that the lower edge of the sighting marker is coincident with that of the calibration marker. The reading of the slant range correction scale must be within 0.15 m. If the scale readings exceed the tolerance make an adjustment by means of knob RANGE ZERO ADJUSTMENT on unit P3. This should be done as carefully as possible while matching the lower edge of the sighting marker with the lower edge of the calibration marker. In this case the readings of the slant range correction scale approximate zero despite the existing tolerance.
  - Shift switch CALIBRATION on unit P9 to position RANGE, adjust the slant range correction scale to 0.
  - Set switch SEARCH - HOMING to position SEARCH and make sure that the sighting marker is close to the fourteenth 2-km. calibration marker or matched with it.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 246 -

(f) Shift switch SEARCH - HOMING back to position HOMING, turn the slant range correction scale and make sure that the sighting marker is matched with the calibration marker on the screen of indicator P6 when the slant range correction scale reads within 0 to 100 m. If this is not so, operate potentiometer RANGE SCALE on unit P9 to make adjustment until the sighting marker is properly matched with the calibration marker. If the sighting marker falls to reach the 14th calibration marker, turn the potentiometer knob clockwise. If the sighting marker overpasses the 14th calibration marker, rotate the potentiometer knob counter-clockwise.

Table 35

Initial Positions of Controls on Units of Bombight PBU-4 and OHS-11p when Adjusting Zero and Range Scale

Unit	Controls	Position
Bomb aimer's panel P9	Switch CALIBRATION	RANGE ZERO
	Switch SEARCH - HOMING	HOMING
	Switch SPEED GENERATOR	OFF
	Slant range correction scale	0
Optical sight OHS-11p	Scale ALTITUDE on computer	14 km.
	Scale SIGHTING ANGLE	60°
	ON-OFF switch on altitude unit	OFF
Navigator-operator's panel P6	Switch RANGE EM	10-70
	Knob "10-70"	Turn knob until 30-km. range is obtained
Range unit P3	Switch CALIBRATION - OPERATION	Range CALIBRATION
Lock unit P4	Knob RECEIVER GAIN	Extreme counter-clockwise position

(g) Set switch CALIBRATION on unit P9 back to position RANGE ZERO and operate knob RANGE ZERO ADJUSTMENT to match the sighting marker with the calibration marker. The above adjustment should be made until the sighting marker is fully coincident with the calibration marker.

Note: During calibration when matching the calibration marker with sighting marker at 28th kilometre, keep them at a distance equal to half the maximum error.

15. To check the accuracy of slant range injection proceed as follows:  
(a) Set the controls in positions indicated in Table 37.

- 247 -

50X1-HUM

Table 37

Initial Positions of Controls on Units of Bombights PBU-4 and OHS-11p when Checking Accuracy of Slant Range Injection

Unit	Controls	Position
Bomb aimer's panel P9	Switch CALIBRATION	RANGE
	Switch SEARCH - HOMING	HOMING
	Switch SPEED GENERATOR	OFF
	Slant range correction scale	0
Navigator-operator's panel P6	Switch RANGE EM	10-70
	Switch CALIBRATION-OPERATION	Range calibration
Range unit P3	Knob RECEIVER GAIN	Extreme counter-clockwise position
Optical sight OHS-11p	ON - OFF switch on altitude unit	OFF

(b) Set scales ALTITUDE and SIGHTING ANGLE on optical sight OHS-11p alternately at the values indicated in Table 38.

Table 38

Position of Controls on Bombight OHS-11p when Checking Accuracy of Slant Range Injection

No.	Altitude H, m.	Sighting angle, degrees	Slant range, km.
1	2000	0	2
2	4000	0	4
3	6000	0	6
4	8000	0	8
5	10,000	0	10
6	12,000	0	12
7	14,000	0	14
8	16,000	0	16
9	9948	10	10
10	9397	20	12
11	10,392	30	14
12	10,725	40	16
13	10,284	50	22
14	11,000	60	24
15	12,000	60	28
16	14,000	60	32
17	16,000	60	32

Note: 1. During range calibration the altitude should be set by means of knob ALTITUDE on the computer. When the flight altitude exceeds 14,000 m.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

- 248 -

make calibration setting the altitude by the altitude potentiometer located on the altitude unit having placed the ON - OFF switch on the altitude unit in position ON.

2. Rotate scale SIGHTING ANGLE in the direction from larger to smaller angles.
3. Rotate the slant range correction scale counter-clockwise until the lower edge of the sighting marker is matched with that of 2-km. calibration marker on the screen of indicator P8.

The readings on the slant range correction scale for all the points given in Table 38 should not differ by more than  $\pm 100$  m.

Note: If the bomb dropping height is known, the data for check on range calibration may be taken from Table 39.

Table 39

Bomb Dropping Slant Range

Flight altitude H, m.	Altitude set on sight OHS-11p	Sighting angle, degrees	Bomb dropping range, m.
6000	6087	41	8000
	6018	53	10,000
	6000	60	12,000
8000	7988	37	10,000
	8029	48	12,000
	8030	55	14,000
10,000	8000	60	16,000
	9948	34	12,000
	10,070	44	14,000
	10,068	51	15,000
	10,062	56	18,000
12,000	10,000	60	20,000
	12,000	31	14,000
	12,075	41	16,000
	12,043	48	16,000
	12,036	53	20,000
	11,976	57	22,000
	12,000	60	24,000
14,000	13,933	29	16,000
	13,907	39	18,000
	13,894	46	20,000
	14,137	50	22,000
	14,107	54	24,000
	14,159	57	26,000
	14,000	60	28,000

16. To adjust the speed zero proceed as follows:  
(a) Set the controls to the positions indicated in Table 40.

50X1-HUM

- 249 -

Table 40

Initial Positions of Controls when Adjusting Speed Zero

Unit	Controls	Position
Bomb aimer's panel P9	Switch CALIBRATION	SPEED ZERO (H/2/3 CROCKET)
	Switch SEARCH - AIMING	AIMING
	Switch SPEED GENERATOR	OFF
	Slant range correction scale	0
	Scale TRACK SPEED	Any
Navigator-operator's panel P6	Knob POSITION	Extreme counter-clockwise position
	Switch RANGE EM	10-70
Knob unit P4	Knob RECEIVER GAIN	Extreme counter-clockwise position

(b) Shift switch SPEED GENERATOR to position ON.  
(c) Rotate knob POSITION clockwise, bring the calibration marker to the horizontal line on the indicator light filter. Note position of the calibration marker one minute after it has been matched with horizontal line on the light filter. The marker is allowed to displace by not more than the length of its diameter. If the displacement of the calibration marker is in excess of its diameter, make an adjustment of the speed zero.  
(d) Turn knob SPEED ZERO ADJUSTMENT located on unit P9 counter-clockwise, if the calibration marker crawls up the horizontal line on the light filter. Turn the knob clockwise, if the calibration marker crawls down the horizontal line on the light filter.

Make a check again to make sure that the marker's crawl does not exceed the length of its diameter for one minute.

17. To adjust the speed scale proceed as follows:  
(a) Set the controls to the positions indicated in Table 41.

Table 41

Initial Positions of Controls when Adjusting Speed Scale

Unit	Controls	Position
Bomb aimer's panel P9	Switch CALIBRATION	SPEED (CROCKET)
	Switch SEARCH - AIMING	AIMING
	Switch SPEED GENERATOR	OFF
	Knob POSITION	Extreme counter-clockwise position
Navigator-operator's panel P6	Scale TRACK SPEED	1200
	Switch RANGE EM	10-70
Knob unit P4	Knob RECEIVER GAIN	Extreme counter-clockwise position

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

- 250 -

- (b) Turn on switch SPEED GENERATOR not less than 30 sec. after setting of the controls. Watch the movement of the calibration markers on the screen of indicator P8. Pass first 5 calibration markers, start the stopwatch at the moment of passage of the 5th calibration marker and stop it at the moment when the 10th marker passes the preset sighting marker.
- (c) Adjust potentiometer SPEED SCALES so that the passage time of the five 2-km. calibration markers may be within 30±6 sec.
- (d) Check the time taken by the five 2-km. calibration markers to pass the preset sighting marker for the following speeds: 1200, 900, 600, 300 km/hr.  
The passage time of the five 2-km. calibration markers for the above-mentioned speeds should correspond to the time indicated in Table 42.

Table 42  
Passage Time of 2-km. Calibration Markers  
for Various Speeds

Speed, km/hr	300	600	900	1200
Time, sec.	120±2.4	60±1.2	40±0.8	30±0.6

18. To check the change to the operating conditions from optical sight OHS-11p, proceed as follows:  
(a) Set the controls to the positions indicated in Table 43.

Table 43  
Initial Positions for Controls when Checking  
Change to Operation from Optical Sight OHS-11p

Unit	Controls	Position
Bomb aimer's panel P9	Switch CALIBRATION Switch SEARCH - HOMING Switch SPEED GENERATOR Knob POSITION	OPERATION SEARCH OFF Extreme counter-clockwise position
Navigator-operator's panel P6	Switch RANGE EM Knob 10-70 Knob RANGE MARKER BRIGHTNESS	10-70 Extreme clockwise position Turn clockwise until markers appear
Range unit P3	Switch CALIBRATION - OPERATOR	OPERATION
Optical sight OHS-11p	Scale SIGHTING ANGLE Scale ALTITUDE Knob RECEIVER GAIN	60° 14 km. Extreme counter-clockwise position

- 251 -

50X1-HUM

- (b) Turn on switch SPEED GENERATOR located on unit P9. Rotate knob POSITION clockwise to make sure of the change to operation from optical sight OHS-11p by the lighting up of the red lamp on unit P9 and green lamp on unit P8. See that the change to the main synchronizing takes place at a distance of 28 km.
19. To check the bomb drop warning signal follow the procedure below:  
(a) Set the controls to the positions indicated in Table 44.

Table 44  
Positions of Controls when Checking Bomb  
Drop Warning Signal

Unit	Controls	Position
Bomb aimer's panel P9	Switch CALIBRATION Knob POSITION Switch SPEED GENERATOR	OPERATION Extreme clockwise position ON
Optical bombsight OHS-11p	Sighting angle index Aiming angle index Scale ALTITUDE ON COMPUTER (BPOOZA HA PERAMOM HPHOPE) ON - OFF switch on altitude unit Knob AUTOMATIC DROP (ABTOOPEOO)	70° 40° 14 km. OFF Cocked

- (b) Energize the optical bombsight.  
(c) Rotate the sighting knob located on the optical bombsight to make sure that the red lamp lights up on unit P8.  
CAUTION: Prior to making a check, cut out the circuit-breakers of the bomb doors. The check should be made on permission of the aircraft armament specialist.  
20. When checking the quality of presentation in the HOMING mode proceed as follows:  
(a) Set the controls to the positions indicated in Table 45.

Table 45  
Initial Positions of Controls when Checking Quality  
of Presentation in HOMING mode

Unit	Controls	Position
Navigator-operator's panel P6	Switch RANGE EM	10-70
Bomb aimer's panel P9	Switch SEARCH - HOMING Switch CALIBRATION	ON OPERATION
Optical bombsight	Sighting angle index	0°

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM

- 252 -

- (b) Obtain the target presentation on the indicator screens as instructed in Points 3) and 3\* of Section "Checking and Adjustment of Live Equipment of Navigator-Operator".
- (c) Operate knob ALTRUSS on the optical bombight to bring the sighting marker under the target visible on the screen of indicator P8.
- (d) Change to AIMING mode and make sure that the objects are visible on the screen of indicator P8.
21. To deenergize the equipment proceed as follows:
- Set the controls to the initial positions indicated in Table 3\*.
  - Switch on the transmitter and the supply of radar bombight RUS-4.
  - Open circuit-breaker A30-20 "Radio Sight" located on the circuit-breaker panel of the operator's cabin.

Postflight Inspection and Checking of Equipment

The postflight inspection and checking of the equipment are the main preventive maintenance jobs the aim of which is to ensure normal operation of the equipment. When making a postflight inspection and check, proceed as follows:

- Obtain information as to operation of the equipment in flight from the navigator-operator and aircraft navigator.
- Inspect the equipment visually, check the tightness of the plug connectors, fastening of the cables to the aircraft sides, fastening of the units; check bonding of the units. Give special attention to the condition of the bunched cables and their dressing.
- Check reliability of operation of all the switches, interlocking contact in distribution box P15 with the radar bombight supply off. Check for presence of spare fuses, spare valve complement and tools, replenish the complement with missing fuses and valves.
- Make an entry into the Log as to all troubles revealed by inspection. Do not eliminate troubles until the inspection is finished.
- Eliminate all the troubles located in flight and during inspection. The troubles eliminated, check the live equipment following the above technique.
- Make an entry into the radar bombight Service Log as to replacement of components.

Elimination of Possible Troubles

Troubles in the equipment are most frequently caused by the burning out of fuses, poor tightening of plug connectors, breaks or shorts in junction cables or wires. Sometimes wrong setting of the control knobs is misleading. Therefore, when finding the cause of trouble in the equipment it is necessary first of all to carefully inspect the units and junction cables, tighten the nuts of the connectors, if necessary, check the condition of fuses and position of the controls. The defective units should be replaced in succession by good ones; if the cause of trouble is not revealed, find which unit is defective.

If, for any reason, the defective unit should be replaced in the given station, make complete adjustment and calibration of the equipment.

- 253 -

Troubles and Remedies

Trouble	Probable cause	Remedy
1	2	3
At 115 V A.C. are applied (illumination lamps do not glow, check instrument does not read 115 V, 400 c.p.s., valves are not heated)	Blown fuse CB-15A in fuse distribution box of navigator-operator. No contact in interlock button of unit P15	Replace fuse CB-15A in fuse distribution box of navigator-operator. Press interlock button with hand
Voltages -300 V, +300 V, +400 V cannot be applied	Blown fuse Rp15-4 in unit P15	Replace fuse Rp15-4
Voltages +300 V and +400 V are absent (very bright and wide spot arising on indicators, brightness and focus are not adjustable)	Defective valves M1-1, M1-2 and M1-3 in unit P11	Replace defective valves in unit P11
No voltage of - 300 V	Defective valves M1-5 M1-13, M1-14 in unit P11	Replace defective valves in unit P11
Voltage of +300 V is unadjustable or unstable	Defective valve M1-4 in unit P11	Replace defective valve in unit P11
Voltage of +400 V is too high or low	Defective valve M1-1, M1-2, M1-3 in unit P11	Replace defective valves in unit P11
In motors fail to operate in units P2 and P12	Break of supply wires running to motors or defective motors	Eliminate trouble in supply wires of motors. 27 V D.C. must be across terminal 1304 in unit P13
Indicator P5/1 scale is not illuminated, valves of unit P6 are not heated	Blown fuse Rp15-2 in unit P15	Replace fuse in unit P15
Indicator P5/1 scale is not illuminated	Burned out scale illumination valves or short circuit in sockets	Replace blown out valves
Scale of indicators P5/2, P6 is not lighted, valves of unit P7 are not heated	Blown fuse Rp15-6 in unit P15	Replace fuse in unit P15
No sweep and electronic spot on all indicators	(a) Blown fuse Rp15-5 in unit P15 (b) Defective valve M10-1 in unit P10	Replace fuse Replace defective valve
No sweep on one indicator	Burned out filament in cathode-ray tube	Replace cathode-ray tube

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM

- 254 -

1	2	3
Too bright and too wide spot (sweep trace), brightness is uncontrollable by knob BRIGHTNESS	+300 V are not applied to indicator (no contact in ball-type connector, break of wire in +300 V circuit)	Restore contact, eliminate trouble in +300 - V circuit
No sweep existing on indicators P5/2 and P8	Blown fuse Hpl5-6 in unit P15	Replace fuse
No sweep existing on indicator P5/2	Defective valve H-26 in unit P4	Replace valve H-26
No sweep existing on indicator P8 in SEARCH	Defective valve H-27 in unit P4	Replace defective valve
No sweep on all range bands, but there is sharply focused spot in centre of indicator screen	(a) Blown fuse Hpl5-1 or Hpl5-2 in unit P15 (b) Defective valve H3-4 in unit P3 (c) Defective valves H-20, H-21 and H-22 in unit P4 (d) Defective valve H-19 in unit P4 (e) Wrong repetition frequency	Replace fuse Hpl5-1 or Hpl5-2 Replace defective valve Replace defective valves
Sweep trace and blurred range markers on all indicators are generated	(a) Defective valve H-19 in unit P4 (b) Wrong repetition frequency	Replace defective valve Check frequency division 5l and 6l, adjust with potentiometers CHECK OF FREQUENCY 5l and CHECK OF FREQUENCY 6l in unit P3
Antenna fails to rotate when switch ROTATION on unit P6 is set at ON	Blown fuse Hpl5-12 in unit P15	Replace fuse in unit P15
Antenna rotates continuously when switch SECTOR SCANNING is set at ON	Blown fuses Hpl5-13 and Hpl5-14 in unit P15	Replace fuses in unit P15
Antenna is motionless when switch SECTOR SCANNING is turned on	Blown fuse Hpl5-12 in unit P15	Replace fuse in unit P15
No range markers and clutter on indicators	One of valves H-9, H-10, H-11, H-12 is defective in unit P4	Replace defective valve
There are range markers, but no clutter on indicators	One of I.F. amp. valves H-1, H-2, H-3, H-4, H-5, H-6, H-7, H-8 in unit P4 is defective	Replace defective valve
There are no range markers on indicators	Defective valve H3-3 in unit P3	Replace defective valve
There is no range marker on indicators	One of valves H3-10, H3-11, H3-12 in unit P3 is defective	Replace defective valve
No crystal current when switch APC - SEARCH on unit P6 is set at APC-ON	No voltage of -300 V (defective valve H11-15)	Replace defective valve H11-15 in unit P11

- 255 -

50X1-HUM

1	2	3
Pointer of meter CHECK on unit P6 is motionless, while it should swing	Defective valve H-17 in APC circuit in unit P4	Replace defective valve
Transmitter-receiver P2 cannot be energized	(a) Apparatus had not time to warm up (b) Blown fuse Hpl5-7 or Hpl5-11 in unit P15	Allow apparatus to warm up Replace defective fuse
Weak or no target presentation when knob APC - SEARCH is set at APC - ON	Defective valves H-13, H-14, H-15, H-16 in APC circuit of unit P4	Replace defective valves in unit P4. Rotate potentiometer APC VOLTAGE on unit P4 until target presentation is bright and knob RECEIVER TUNING until lamp burns bright
There is no sweep on screen of indicator P8 in SEARCH and HOMING modes	Blown fuse Hpl5-6 of connection box P15 in unit P15. Therefore 115 V are not fed to unit P4	Replace fuse Hpl5-6 in unit P15
There is no sweep on screen of indicator P8 in HOMING mode	Defective valve H7-1 of square-pulse generator in unit P7	Replace defective valve
Scan B display on screen of indicator P8	Defective valve H7-9 or H7-10 in sweep amplifier of unit P7	Replace defective valve
Scale of indicator P8 is not lighted	Blown fuse Hpl5-10 in unit P15	Replace defective fuse P15
Pilot lamp SUPPLY ON located on unit P9 fails to burn	Blown fuse Hpl5-10 in unit P15	Replace defective fuse P15
There is no target presentation on screen of indicator P8 both in SEARCH and HOMING modes with target presentation on screens of indicators P5/1 and P5/2	Defective video amplifier valve H7-21, H7-22, or H7-23 in unit P7	Replace defective valve

MEASUREMENTS OF RADIO NOISE LEVEL  
General Instructions

- Prior to measuring the radio noise level make sure that:
  - The performance of the radio equipment and noise sources on board the aircraft is checked and complies with Specifications.
  - Bonding of the aircraft, especially of radio facilities and noise sources, is checked and complies with Specifications.
  - All temporary wiring systems and check instruments (oscillographs, recorders, etc.) are disconnected.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



(d) Sensitivity of the receivers is measured.  
2. When measuring radio noise observe the following conditions:  
(a) Have the aircraft positioned outside the zone of manmade interference.  
(b) Measure radio noise when the level of atmospheric and industrial noise does not exceed the permissible level for the given receiver in line with its sensitivity.  
(c) The aircraft mains should be powered from a storage battery of at least 500 a.h. capacity.  
(d) The supply voltage of the aircraft mains should be 27.5 to 28 V D.C. and 112 to 116 V, 400 c.p.s. A.C.  
Note: The supply voltage of the aircraft mains should be checked by the meters on the operator's panel.  
**CAUTION:** 1. The aircraft mains may be fed by an airfield generator, provided the generator noise level does not exceed the permissible value for the given receiver.  
2. The permissible level is allowed to rise on account of atmospheric and industrial noise at one or two points over the band to be measured, provided the main clutter is clear against the background of atmospheric clutter (upon switching on the noise source the output voltage of the receive rises).  
3. Depending upon the receiver sensitivity the rise of the measured noise level above the permissible value for the given receiver is determined by formulas:

$$U_{rec.perm.} = \frac{U_{rec.}}{K_{rec.}}$$

which  $U_{rec.perm.}$  = the permissible noise level at the receiver output, V;  
 $U_{rec.}$  = the permissible noise level at the receiver output for sensitivity  $E_{rec.} = 1$  microvolt. For receivers JC-9 and AFK-5  $U_{rec.} = 18.5$  V, for PCHV-3M  $U_{rec.} = 37$  V;  
 $K_{rec.}$  = the receiver sensitivity at a frequency of interference to be measured, microvolts.

4. To facilitate determination of the noise level allowable at the output of receivers JC-9, AFK-5 and PCHV-3M use is made of the diagram of Fig.180 and Table 46 made up according to the above formula.

Table 46

Permissible Noise Levels at Output of Receivers JC-9, AFK-5 and PCHV-3M Depending upon Receiver Sensitivity

Receiver sensitivity, microvolts	Permissible noise level (V) at outputs of receivers	
	JC-9, AFK-5	PCHV-3M
1	2	3
1.0	18.5	37
1.1	16.8	33.6
1.2	15.4	30.8

50X1-HUM

1	2	3
1.3	14.2	28.4
1.4	13.2	26.4
1.6	11.6	23.2
1.8	10.3	20.6
2.0	9.3	18.6
2.2	8.4	16.8
2.5	7.4	14.8
2.7	6.9	13.8
3.0	6.2	12.4
3.2	5.8	11.6
3.5	5.3	10.6
3.7	5.0	10.0
4.0	4.6	9.2
4.5	4.1	8.2
5.0	3.7	7.4
5.6	3.3	6.6
6.0	3.1	6.2
7.0	2.7	5.4
8.0	2.3	4.6
10.0	1.85	3.7

5. The possible sources of noise on the aircraft are listed in Table 47.

Table 47

Possible Sources of Noise and Receivers at Output of which Noise is Heard

Source of noise	Operating duty of noise source during measurements	Receivers acted on by noise	Nature and amount of noise (in case of defective screening, bonding and filtering)	Remedy
1	2	3	4	5
PEB-4	Transmission on range 10-70	JC-9/M	Hum of about 1300 c.p.s. frequency is most loudly heard at tuning frequency 4.5 - 6.0 Mc/s of the receiver JC-9/M The permissible level is exceeded 2 - 4 times	Bring to normal the screening of the units and cables of noise sources and receiver Replace defective filters
MC-1	When switching on high voltage	JC-9	Same	Same

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

1	2	3	4	5
AP-52M	When changing over control wheels	JC-9 and JC-9EM	Periodical crackling most loudly heard at frequencies 3.0 - 5.0 Mc/s. The permissible level is exceeded 2 - 2.5 times.	Same
EB-3, EB-650, set "107", Y-600	Normal operation	JC-9	Crackling over a frequency band of 3 - 9 Mc/s. The permissible level is exceeded 3 - 4 times at separate points of the band	Bring screening and bonding to normal. Clean the motor commutators
PCW-3M	Transmission on crystals A76, A172 and others	KPL-8	Deflection of indicator HPL-8 pointer by 1 - 2 mm when the aircraft flies on route and pointer swing toward zero mark when the aircraft is off the course line	Do not operate set PCW-3M in the TRANSMISSION mode in presence of interference from PCW-3M during landing by localizer receiver
FB-2	During operation on the second band	OR-1	Locking by signals from radio altimeter FB-2, change of readings of indicator HPL-50, stopping of locking, unstable operation	Bring to normal the bonding and screening of the units and cables of radio altimeter FB-2 and range finder OR-1, replace filters BPL-2
FB-17		OR-1	Same	Same

Measurement of Noise at Output of Receiver  
JC-9 and JC-9EM

**CAUTION:** 1. Noise at the output of receiver JC-9EM should be measured through the interphone set of the right pilot, whilst at the output of receiver JC-9 through the set of the radio operator. In this case turn knob LOUDER (ГРОМКО) on the interphone sets should be turned to a maximum (fully clockwise). Connect a pair of high-resistance earphones PA-4 and output meter, type EB-4, (Fig.161) to the output plug connector of the interphone set.

2. During noise measurements the switches of the other interphone sets should not be placed in the same positions as the switches on those sets through which the noise is measured.

50X1-HUM

3. Tune and fix on the APC channels of transmitter 1-PCB-70M the following frequencies:

No. of channel	7	8	9	10	11
Frequency, Mc/s	3.0	5.6	9.0	12.8	17.2

1. Before attempting to measure noise set the receiver knobs to positions KFC, KCH, CRYSTAL OFF, and the volume control - at maximum.
2. Tune transmitter 1-PCB-70M to a frequency of 3.0 Mc/s (the 7th channel).
3. Tune receiver JC-9 (or JC-9EM) to a frequency of 3.0 Mc/s by the maximum deflection of the pointer of meter EB-4 and maximum volume of atmospheric noise in the earphones.
4. Measure the atmospheric noise voltage at the output of receiver JC-9 (or JC-9 EM). Set the antenna adjustment knob at maximum sensitivity of the receiver by the maximum volume of atmospheric noise in the earphones.
5. Set the noise sources to be checked (PHS-4 and HPC-1, AP-52M and others) for normal operating conditions separately or simultaneously (if it is found necessary), measure the level of noise generated by them.
6. Repeat the operations indicated in Points 2, 3, 4 and 5 on tuning frequencies of JC-9 and PCB-70M: 5.6, 9.0, 12.8 and 17.2 Mc/s.
7. If there is noise due to operating radio stations on the frequencies fixed by automatic tuning of station 1-PCB-70M and it is necessary to determine the frequency of the maximum noise the receiver and transmitter should be tuned as follows:
  - (a) Tune receiver JC-9 (JC-9EM) to a frequency as close as possible to the frequencies indicated in Points 3 and 6, but free from the radio station noise (or any other frequency, for instance, to a frequency of the loudest noise), adjust the receiver antenna according to Point 3.
  - (b) Change over the automatic tuning of station 1-PCB-70M to position MANUAL (РУЧНОЙ НАСТРОЙКА). Set knobs A, B, F and K to positions corresponding to tuning frequency of receiver JC-9: course - against the table of tuning of station 1-PCB-70M (the table is supplied with every transmitter), fine - by the maximum deflection of the output meter pointer and maximum volume of noise in the earphones.
  - (c) Measure the noise level according to Point 5.

Measurement of Noise at Output of Radio  
Compass APK-5

**CAUTION:** 1. Noise at the output of radio compass receiver APK-5 Nos 1 and 2 should be measured through the interphone set of the navigator. In this case set the knob marked LOUDER (located on the interphone set) for maximum volume, and the function switch to position ADD. BOARD (ДОП. ДИШ.). Set the switch of the additional board to position APK-1 or APK-2. Connect a pair of earphones, type PA-4, and output meter EB-4 to the output of the interphone set.

2. During measurements of noise at the output of the radio compass make sure that other interphone sets are not in position ADD. BOARD.

1. Set the function switch on the radio compass panel to position АПВКВН, short knob VOLINE at maximum. Tune the radio compass to a frequency of 500 Kc/s, short terminal АПВКВН - ВАРНН (АВТЕННА - ЗЕМЛЯ). Operate control RECEIVER GAIN on the front panel of the radio compass to set the noise level at the output at 20 V. Short terminals АПВКВН - ВАРНН of the radio compass receiver.

SECRET  
NO FOREIGN DISSEM

NO FOREIGN DISSEM



2. Tune the radio compass to 250 Kc/s frequency short terminals ANTENNA - EARTH of the radio compass receiver, operate the volume control located on the radio compass panel to set the noise level at the output at 2 V. Unshort terminals ANTENNA - EARTH of the receiver and measure the level of atmospheric noise at the output of the radio compass.
3. Energize the noise sources to be checked (FEB-3, GP) and others) separately or simultaneously (if this proves to be necessary) and measure the level of noise generated by them.
4. Repeat the operations indicated in Points 2 and 3 on medium frequencies of the second and third bands of the radio compass - 500 and 1000 Kc/s, or on any other frequencies on which the noise level should be measured (for instance, on the frequency of the loudest noise).
5. Check against course indicator VME-1 the effect of noise on the operation of the compass portion of radio compass APX-5 during reception of weak signals (from remote radio stations).

Measurement of Noise at Output of Receiver of Radio Set PCW-3M

**CAUTION:** Noise at the output of receiver PCW-3M should be measured through the interphone set of the pilot. In this case set knob LOUDER on the interphone set for maximum volume, and the function switch to position USW RADIO SET (VKB/PC).

1. Set the volume control located on the panel of receiver No. 1 at maximum (to position P), switches 1 and 2 to position "1". Set the sensitivity control on the front panel of the receiver at maximum sensitivity, switch off the noise limiter.
2. Measure the level of atmospheric noise on each channel of the receiver (No.1).
3. Energize the noise sources to be checked in normal operating conditions simultaneously or separately (if necessary) and measure the level of noise generated by them on each channel of the receiver.
4. Press the throat microphone button and measure the noise of the radio set operation at the monitoring output on each channel (400 c.p.s. hum).

Measurement of Noise at Output of Aircraft Interphone System CNV-10

**CAUTION:** Noise at the output of the interphone system is measured through the interphone set of the operator by output meter W-4.

1. Place the gain controls of the amplifiers in the position marked with a white line.
  2. Energize receivers VC -9, VC-9M, APX-5 Nos 1 and 2, PCW-3M, tune them to well-heard radio stations, operate the volume controls of the receivers to set the output voltage of the signal from the radio stations to be received at 30 V.
  3. Place the switches of all the interphone sets in positions NETWORK No. 1 and INTERPHONE, turn the volume control fully clockwise, connect a pair of earphones TA-4 to each set.
  4. Measure the noise level during simultaneous operation of all the receivers. The noise level at the output of the interphone system should not exceed 0.4 V.
- When monitoring any of the receivers it is allowed that the operation of the interphone system and other receivers not connected to the output of the interphone set being checked is slightly heard. The monitoring voltage should not exceed 0.4 V

50X1-HUM

When the receiver deenergized, which corresponds to the given position of the function switch of the interphone set being checked).

**Effect:** In order to detect electrical units - sources of high noise level-if the noise level exceeds the permissible one, monitor and measure the voltage of noise from each unit separately in all positions of the function switches on the interphone sets.

5. Repeat the operation indicated in Point 4 for position NETWORK No. 2.
6. Measure the hum voltage with the interphone button pressed and released during operation of the electrical unit permanently acting in the aircraft. The hum voltage should not exceed 0.4 V.

Operation of Electrical and Radio Facilities

When measuring the noise generated by the electrical units, the unit must be under normal operating conditions.

When measuring the noise generated by the radio facilities, these facilities should be operated at the main operating frequencies and ranges most commonly used during simultaneous operation with the receivers which are acted upon by the given noise sources. Switching on and tuning of the radio facilities is done according to Manufacturers instructions.

When measuring the noise generated by the electrical equipment of the tail and other installations, it is necessary to release the action switch, set the sight at the predetermined angle within the working control zone of the respective installation (the installation when matched with the sight does not get on the limit stop) and having pressed the action switch, make a change-over toward the other side (initially matched with the sight make another change-over toward the other side (in all planes at a time). In this case note the noise level on the output meter (No.4) connected to the output of receiver VC-9 ignoring separate short-time peaks of pointer kicks).

The given angle of the sight should be set and the action switch pressed at the command of a person making noise measurements.

Do not measure the noise when the installations are operated in continuous operating conditions (swinging of the sights within greater limits (more than 10 degrees) at a frequency of 2 - 3 oscillations per second as not complying with normal operating conditions).

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




FIG. 1. Left-Seat Pilot Instrument Board

- 1 - Indicator of DZMK-7 remote-reading gyroscopic compass; 2 - Indicator of ГПК-52 directional gyro; 3 - ПЦТ-48 ILS indicator; 4 - MC-1 machmeter (with warning light); 5 - KVC-1200 airspeed indicator; 6 - BAP-30-3 rate-of-climb indicator; 7 - АГБ-2 gyro horizon; 8 - BCMT-1 indicator of APK-5 radio compass No. 1; 9 - ЗВТ-53 turn indicator; 10 - AM-10 altimeter; 11 - PFI-1 range finder indicator; 12 - PB-2 low-altitude radio altimeter indicator; 13 - BA-20 altimeter; 14 - Indicator of left-hand engine tachometer, type TD-2; 15 - Indicator of right-hand engine tachometer, type TD-2; 16 - Y31-47 flap position indicator; 17 - pilot director indicator (PDI); 18 - TEH-11 exhaust gas temperature indicator of left-hand engine; 19 - TEH-11 exhaust gas temperature indicator of right-hand engine; 20 - АГБ-2 standby gyro horizon; 21 - ЗВТ-53 fuel pressure gauge; 22 - ЗВТ-53 fuel pressure gauge.




FIG. 2. Right-Seat Pilot Instrument Board

- 1 - MC-1 machmeter; 2 - Indicator of ГПК-52 directional gyro; 3 - Indicator of DZMK-7 remote-reading gyroscopic compass; 4 - ЗВТ-53 flap position indicator; 5 - KVC-1200 airspeed indicator; 6 - BAP-30-3 rate-of-climb indicator; 7 - АГБ-2 gyro horizon; 8 - BCMT-1 indicator of APK-5 radio compass No. 2; 9 - ПЦТ-48 ILS indicator; 10 - АГВ-10 altimeter; 11 - Y31-47 flap position indicator; 12 - PB-2 low-altitude radio altimeter indicator; 13 - Indicator of BAK-AB-5 set; 14 - Indicator of PBV-48V air flowmeter; 15 - Y31-15 cabin altimeter; 16 and 17 - ЗВТ-53 gauge unit indicators; 18 - fuel content gauge indicator of CSTC-60H set; 19 and 20 - fuel gauge selector switches П-7 of CSTC-60H set; 21 - fuel content gauge indicator of CSTC-60H set; 22 - air thermometer indicator ТПТ-13 of left-hand wing heater; 23 - cabin pressurization air thermometer indicator TV3-48.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM



50X1-HUM




Fig. 3. Navigator's Instrument Board  
 1 - course indicator of JAWC/JB-1 set 2 - D.R. compass of JRF-90B set 3 - wind setter of JRF-90B set 4 - magnetic compass set of JRF-90B set 5 - magnetic compass indicator of JRF-90B set 6 - magnetic compass of JRF-90B set 7 - indicator of JRF-90B set 8 - indicator of JRF-90B set 9 - indicator of JRF-90B set 10 - indicator of JRF-90B set  
 JAWC-1 compass 8 - indicator JRF-90B 9 - clock JAWC 10 - stopped indicator JAWC-1000.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




Fig. 4. Operator's Instrument Board  
 1 - rheostat of PY90-46 (directional light); 2 - elapsed indicator KVC-1200; 3 - indicator TP3-48 of external  
 meter BU-20; 4 - clock AYXO; 5 - interphone button; 6 - warning lamp; 7 - ready for takeoff release; 8 - stop  
 watch BU-20; 9 - course indicator of AYMK-7 and 9 - release button KCB-46.




Fig. 5. Radio-Operator's Instrument Board  
 1 - air flowmeter TP3-46; 2 - cabin altimeter YBUL-15; 3 - altimeter BU-20; 4 - elapsed indicator KVC-1200; 5 - inter-  
 phone meter BU-20; 6 - altimeter BU-1; 7 - clock ABP-1; 8 - cabin air flowmeter TP-46.

50X1-HUM

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 6. Starter Instrument Board

- 1 - CMI-51 indicating lamp "01" pressure warning;
- 2 - TCT-29 tachometer indicator; 3 - T3-45 tachometer indicator.





Fig. 7. Pilot's Control Board

- 1 - switch B-45 of 104-12 compass; 2 - pressure gauge UN-2001 of main tank; 3 - pressure gauge MT-2501 of landing gear - main tank; 4 - warning lamp of pressure drop in main tank; 5 - pressure gauge UN-2001 of fuel tank; 6 - warning lamp of fuel tank; 7 - altimeter indicator; 8 - altimeter indicator; 9 - altimeter indicator; 10 - altimeter indicator.



- 1 - maximum speeds by speedograph at normal engine rating;
- 2 - maximum speeds by speedograph at maximum engine rating;
- 3 - maximum speeds under standard conditions at normal engine rating;
- 4 - maximum speeds under standard conditions at maximum engine rating;
- 5 - Mach number at normal engine rating;
- 6 - Mach number at maximum engine rating.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 11. Suspension of Recorder K2-75  
 1 - dynamic pressure line; 2 - static pressure line; 3 - duct hose;  
 4 - suspension hook; 5 - shock-absorbing cord; 6 - recorder;  
 7 - removable ring.




Fig. 12. Altimeter Checking Diagram  
 1 - altimeter to be checked; 2 - shut-off valve; 3 - pipe line; 4 - T-piece; 5 - barometer.




Fig. 13. Airspeed Indicator Checking Diagram  
 1, 7, 8 and 9 - shut-off cocks; 2 - water pressure gauge;  
 3 - mercury pressure gauge; 4 - mercury barometer; 5 - instrument to be checked; 6 - pipelines.




Fig. 14. Aerodynamic Correction Chart




Fig. 15. Mochmeter Checking Diagram  
 1, 7, 8 and 9 - shut-off cocks; 2 - water pressure gauge;  
 3 - mercury pressure gauge; 4 - mercury barometer; 5 - venting lamp; 6 - instrument to be checked.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




Fig. 16. Checking Diagram of CCH-3 Velocity Head Warning Unit of Static Pressure Line  
1 - instrument to be checked; 2 - pressure gauge; 3 - shut-off valve; 4 - T-piece.




Fig. 17. Checking Diagram of CCH-3 Velocity Head Warning Unit of Pitot Pressure Line  
1 - instrument to be checked; 2 - warning lamp; 3 - pressure gauge; 4 - shut-off valve; 5 - T-piece.




Fig. 18. Set of DTMK-7 Compass  
1 - junction box; 2 - transmitter; 3 - ground; 4 - amplifier; 5 - main indicator; 6 - inverter; 7 - correction cut-out; 8 - auxiliary indicators; 9 - quick-staving button.




Fig. 19. Set of HI-50B Air Position Indicator  
1 - line filter CP-4; 2 - line filter CP-2; 3 - wind setter; 4 - automatic course device; 5 - D.R. computer; 6 - distribution box; 7 - T.A.S. transmitter.




Fig. 20. Position of Adjustable Resistor Slide when Adjusting Inverter for Operation with Two Instruments




Fig. 21. Adjustment of Zero Signal  
1 - distribution box; 2 - adjusting resistor.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




Fig. 22. Graph Used for Determining Covered Distance by Readings of D.R. Computer Pointers




Fig. 23. Graph Used for Determining Absolute Error




Fig. 24. Matching of Readings of Automatic Course Device with Those of Compass Main Indicator




Fig. 25. Electric Panel Diagram for Checking АГБ-2 Gyro Horizon

1 - plug connector of ПАГ-1Ф inverter; 2 - supply terminals; 3 - plug connector of АГБ-2 gyro horizon; 4 - terminals for measuring currents and voltages in D.C. circuit; 5 - terminals for measuring currents and voltages in A.C. circuit; 6 - plug connector of correction circuit.





Fig. 26. Electric Panel Diagram for Checking Correction Circuit

1 - plug connectors of ПАГ-1Ф inverter; 2 - switch B-45; 3 - terminals; 4 - D.C. voltmeter, up to 30 - 40 V; 5 - A.C. ammeter, up to 1 A; 6 - A.C. voltmeter, up to 40 - 50 V; 7 - selector switch III-45; 8 - plug connectors III of correction circuit; 9 - button (normally closed); 10 - terminals for ohmmeter; 11 - selector switches.

SECRET  
NO FOREIGN DISSEM

**SECRET**  
NO FOREIGN DISSEM



50X1-HUM




Fig. 27. Diagram for Checking TY3-48 Resistor Thermometer Indicators

1 - plug connector of TY3-48 Indicator; 2 - supply terminals; 3 - resistance box




Fig. 31. Diagram of Wire Bundle for Checking Oil Pressure Gauge of 3MH-3P Set

1 - plug connectors of all pressure indicators; 2 - power supply terminals; 3 - pressure pick-up unit П-10.



Fig. 32. Diagram of Wire Bundle for Checking Fuel Pressure Gauge of 3MH-3P Set

1 - plug connectors of fuel pressure indicators; 2 - power supply terminals; 3 - pressure pick-up unit П-100.



Fig. 28. Set of 9MH-3P Gauge Unit

1 - indicator; 2 - fuel pressure pick-up unit П-100; 3 - oil pressure pick-up unit П-10; 4 - temperature pick-up unit.




Fig. 33. Electric Diagram for Checking Temperature Indicator of 3MH-3P Set

1 - plug connectors of all temperature indicators; 2 - power supply terminals; 3 - resistance box.




Fig. 29. Diagram for Checking Indicators of TBF-11 Thermometers

1 - source of electromotive force, 1 - 1.5 V; 2 - switch B-45; 3 - potentiometer; 4 - reference millivoltmeter; 5 - resistance box; 6 - indicator plug connector.




Fig. 30. Diagram for Checking Indicators of TCT-29 and THT-13 Thermometers

1 - source of electromotive force, 1 - 1.5 V; 2 - switch B-45; 3 - potentiometer; 4 - reference millivoltmeter; 5 - series resistor; 6 - indicator plug connector.





Fig. 34. Diagram for Checking 3MH-3P Set

1 - plug resistance box; 2 - indicator; 3 - pressure pick-up П-100; 4 - pressure pick-up unit П-10; 5 - bottle with pressed gas; 6 - cock for feeding pressure into oil pressure gauge system; 7 - reference pressure gauge, up to 150 kg/cm<sup>2</sup>; 8 - cock for feeding pressure into oil pressure gauge system; 9 - reference pressure gauge, up to 10 kg/cm<sup>2</sup>.


**SECRET**  
NO FOREIGN DISSEM

**SECRET**  
NO FOREIGN DISSEM

50X1-HUM




**Fig. 35. Diagram for Checking Airtightness of Pressure Pick-Up Unit Casing**  
1 - pressure pick-up unit; 2 - mercury pressure gauge; 3 - pressure feed cock; 4 - pressure release cock; 5 - bottle with compressed air.



**Fig. 36. Installation of AP-5-2M Autopilot Directional Stabilizer**

1 - locking mechanism; 2 - turn control knob; 3 - autopilot clutch engaging knob; 4 - bracket with shock absorber; 5 - bombight clutch; 6 - bombight ODE-11P; 7 - directional panel; 8 - drift gear clutch disengaging knob.




**Fig. 37. Vertical Flight Gyro of AP-5-2M Autopilot**




**Fig. 38. Attachment Wing of Angular Rate Control Unit of AP-5-2M Autopilot**

1 - angular rate control gyro;  
2 - ПАП-1Ф Inverte.



**Fig. 39. Autopilot Control Panel**



**Fig. 40. Swivelling Bracket for Autopilot Booster Control Knob and Selector Switch**

1 - booster control knob; 2 - selector switch.

**SECRET**  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 41. Key Diagram of Oxygen Equipment  
 1 - liquid oxygen converter, type KOK-30; 2 - stenoxygen oxygen economizer, type KST-25N; 3 - oxygen indicator, type IBC-24;  
 4 - oxygen regulator, type KOK-24; 5 - oxygen hose, type KOK-24; 6 - mask, type KOK-24, with mask-face gaskets  
 and mask; 7 - oxygen mask; 8 - oxygen mask; 9 - oxygen mask; 10 - oxygen mask; 11 - parachute oxygen breathing apparatus, type KOK-24; 12 - flow indicator.




Fig. 42. Arrangement Diagram of the Liquid Oxygen Installation  
 1 - oxygen converter, type KOK-30; 2 - oxygen level indicator transducer, type KOK-24; 3 - emergency oxygen level  
 indicator, type KOK-24; 4 - pressure receiver; 5 - oxygen charging pipe union; 6 - pressure gauge; 7 - check valve.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




Fig. 43. K11A-30 Converter and Oxygen Level Indicator installation at Frame No. 22

- 1 - oxygen converter, type K11A-30; 2 - automatic pressure increase valve; 3 - valve, type KB-5, ahead of pressure increase automatic units; 4 - bypass valve; 5 - non-return valve; 6 - safety valve; 7 - valve, type KB-5, after evaporator; 8 - pipe; 9 - pressure release pipe; 10 - pipe for filling vessel with liquid; 11 - pipe from safety valve; 12, 13 - brackets securing converter to frame No. 22; 14 - pressure release valve; 15 - pressure gauge; 16 - liquid oxygen level indicator transmitter, type ДУЖК-Д.




Fig. 44. Oxygen Adapter

- 1 - cover; 2 - hose, type K11-10; 3 - packing rings; 4 - holder; 5 - pipe; 6 - adapter; 7 - hose, type K11-24; 8 - current-collecting device; 9 - nut; 10 - limiter; 11 - ring.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 45. Schematic Diagram of KTR-30 Oxygen Converter

- 1 - pipe; 2 - valve, type KB-6; 3 - safety valve; 4 - pressure gauge; 5 - pressure release valve; 6 - filter; 7 - safety valve; 8 - safety valve; 9 - safety valve; 10 - safety valve; 11 - safety valve; 12 - safety valve; 13 - safety valve; 14 - safety valve; 15 - safety valve; 16 - safety valve; 17 - safety valve; 18 - safety valve; 19 - safety valve; 20 - safety valve; 21 - safety valve; 22 - safety valve; 23 - safety valve; 24 - safety valve; 25 - safety valve; 26 - safety valve.




Fig. 46. Aircraft Charging Pipe Union  
1 - hatch cover; 2 - packing gasket; 3, 6 - chains; 4 - aircraft charging pipe union attachment bracket; 5 - plug; 7 - bolt; 8 - aircraft charging pipe union; 9, 11 - nuts; 10 - washer; 12 - plate.




Fig. 47. Kinematic Diagram of DVKK Liquid Oxygen Indicator  
1 - diaphragm; 2 - moving centre; 3 - rod; 4 - fork; 5 - sector axle; 6 - hairspring; 7 - sector; 8 - pipe; 9 - rotor axle; 10 - meter rotor; 11 - pointer; 12 - dial; 13 - transmitter rotor.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 48. Graph for Determining Losses Caused by Evaporativity by Measured Volumetric Amount of Oxygen in lit. per min. versus Ambient Air Temperature




Fig. 49. Oxygen Hose, Type KII-24  
1 - pipe union; 2 - bracket; 3 - strip; 4 - axle; 5 - valve; 6 - rubber gasket.




Fig. 50. Diagram of Arrangement of KII-23 Oxygen Breathing Apparatus on Aircraft Seats  
1 - apparatus short hose for connection with aircraft oxygen hose; 2 - apparatus long hose for connection with mask.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 51. Placing Oxygen Hoses on Navigator's Seat  
1 - aircraft oxygen hose; 2 - short hose of KI-23 oxygen breathing apparatus; 3 - clamp; 4 - long hose of KI-23 oxygen breathing apparatus (to the mask); 5 - parachute; 6 - locking pin snap hook; 7 - cord; 8 - seat right-hand arm rest.





Fig. 52. Key Distribution Diagram of D.C. Supply System  
1 - normal supply circuit; 2 - emergency supply circuit; 3 - generator, type GCP-18600; 4 - emergency differential under-current relay, type ZMP-600; 5 - normal differential under-current relay, type ZMP-600; 6 - storage battery, type 12CAW-55; 7 - actuator, type K-300A, for connecting storage battery to emergency supply circuit; 8 - contactor, type K-300A, for connecting storage battery to normal supply circuit; 9 - selecting contactor, type KI; 10 - dual supply circuit; 11 - change-over switch, type KI-45; 12 - normal supply distribution busbars; 13 - dual supply distribution busbars; 14 - triple supply distribution busbar



— NORMAL SUPPLY CIRCUIT AND ITS BUSBARS  
- - - EMERGENCY SUPPLY CIRCUIT AND ITS BUSBARS  
- · - · - DUAL SUPPLY CIRCUIT AND ITS BUSBARS  
- - - - - BATTERY SUPPLY WIRES AND BUSBARS  
- · - · - · - TRIPLE SUPPLY CIRCUIT WIRE AND BUSBAR

supply head circuit breaker control panel of navigator; 41 - JCI-53 box; 42 - round capacitor; 43 - blister station control panel; 44 - lower gun mount supply box; 45 - power junction box; 46 - circuit breaker box e; autopilot heater system; 47 - distribution panel, right; 48 - storage battery junction box; 49 - power load-in of emergency supply circuit; 50 - generator control panel; 51 - fueling control board; 52 - glass panel heater system junction box; 53 - fuel supply control board;

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 53. Schematic Connection Diagram of D.C. Circuit Distribution System

7 - circuit breaker control panel of radar operator's station; 8 - circuit breaker control panel of radar operator's station; 9 - circuit breaker control panel of radar operator's station; 10 - power lead-in to gun mount; 11 - power lead-in to gun mount; 12 - power lead-in to gun mount; 13 - power lead-in to gun mount; 14 - power lead-in to gun mount; 15 - power lead-in to gun mount; 16 - power lead-in to gun mount; 17 - power lead-in to gun mount; 18 - power lead-in to gun mount; 19 - power lead-in to gun mount; 20 - power lead-in to gun mount; 21 - power lead-in to gun mount; 22 - power lead-in to gun mount; 23 - power lead-in to gun mount; 24 - power lead-in to gun mount; 25 - power lead-in to gun mount; 26 - power lead-in to gun mount; 27 - power lead-in to gun mount; 28 - power lead-in to gun mount; 29 - power lead-in to gun mount; 30 - power lead-in to gun mount; 31 - power lead-in to gun mount; 32 - power lead-in to gun mount; 33 - power lead-in to gun mount; 34 - power lead-in to gun mount; 35 - power lead-in to gun mount; 36 - power lead-in to gun mount; 37 - power lead-in to gun mount; 38 - power lead-in to gun mount; 39 - power lead-in to gun mount; 40 - power lead-in to gun mount; 41 - power lead-in to gun mount; 42 - power lead-in to gun mount; 43 - power lead-in to gun mount; 44 - power lead-in to gun mount; 45 - power lead-in to gun mount; 46 - power lead-in to gun mount; 47 - power lead-in to gun mount; 48 - power lead-in to gun mount; 49 - power lead-in to gun mount; 50 - power lead-in to gun mount; 51 - power lead-in to gun mount; 52 - power lead-in to gun mount; 53 - power lead-in to gun mount.

control panel; 16 - circuit breaker control panel of radar operator's station; 17 - dual supply circuit junction box of frame No. 4; 18 - selecting connector, type K-200U; 19 - fuel pump junction box, rear; 20 - colour flare bomb emergency dropping circuit junction box; 21 - power junction box of normal supply circuit; 22 - power junction box of emergency supply circuit; 23 - dual supply circuit junction box, right; 24 - dual supply circuit junction box, left; 25 - fuel pump system junction box, right; 26 - fuel pump system junction box, left; 27 - power junction box; 28 - top gun mount supply box; 29 - camera equipment junction box; 30 - ground supply plug connector; 31 - connector, type K-400U, for connecting ground power supply source; 32 - connector, type K-300U, for connecting storage battery to normal supply circuit; 33 - storage battery, type 12-CAV-53; 34 - connector, type K-300U, for connecting storage battery to emergency supply circuit; 35 - hydraulic pump system junction box; 36 - pilot's instrument panel; 37 - pilot's circuit-breaker control panel; 38 - copilot's circuit breaker control panel; 39 - left-hand circuit breaker control panel; 40 - right-hand circuit breaker control panel of navigator; 41 - JCI-53 box; 42 - rounds counter; 43 - battery station control panel; 44 - lower gun mount supply box; 45 - power junction box; 46 - circuit breaker box of autopilot heater system; 47 - distribution panel, right; 48 - storage battery junction box; 49 - power lead-in of emergency supply circuit; 50 - generator control panel; 51 - fueling control board; 52 - glass panel heater system junction box; 53 - fuel supply control board.

ply box; 29 - camera equipment junction box; 30 - ground supply plug connector; 31 - connector, type K-400U, for connecting ground power supply source; 32 - connector, type K-300U, for connecting storage battery to normal supply circuit; 33 - storage battery, type 12-CAV-53; 34 - connector, type K-300U, for connecting storage battery to emergency supply circuit; 35 - hydraulic pump system junction box; 36 - pilot's instrument panel; 37 - pilot's circuit-breaker control panel; 38 - copilot's circuit breaker control panel; 39 - left-hand circuit breaker control panel; 40 - right-hand circuit breaker control panel of navigator; 41 - JCI-53 box; 42 - rounds counter; 43 - battery station control panel; 44 - lower gun mount supply box; 45 - power junction box; 46 - circuit breaker box of autopilot heater system; 47 - distribution panel, right; 48 - storage battery junction box; 49 - power lead-in of emergency supply circuit; 50 - generator control panel; 51 - fueling control board; 52 - glass panel heater system junction box; 53 - fuel supply control board.

hand circuit breaker control panel of navigator; 41 - JCI-53 box; 42 - rounds counter; 43 - battery station control panel; 44 - lower gun mount supply box; 45 - power junction box; 46 - circuit breaker box of autopilot heater system; 47 - distribution panel, right; 48 - storage battery junction box; 49 - power lead-in of emergency supply circuit; 50 - generator control panel; 51 - fueling control board; 52 - glass panel heater system junction box; 53 - fuel supply control board.

SECRET

NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

50X1-HUM




Fig. 53. Schematic Connection Diagram of D.C. Circuit Distribution System

1 - tail section control panel; 2 - rear cabin power junction box; 3 - circuit breaker control panel of rear cabin; 4 - power lead-in of normal supply circuit; 5 - supply junction box of tail gun mount; 6 - decoder junction box of tail unit; 7 - power junction box; 8 - generator, type GCP-18000; 9 - ballast reactor, type BC-18000; 10 - differential undercurrent relay, type DMR-600; 11 - distribution panel, left; 12 - selecting contractor, type K1-400; 13 - dual supply junction box of frame No. 17; 14 - power lead-in of emergency supply circuit; 15 - top section

control panel; 16 - circuit breaker control panel of rear operator's station; 17 - dual supply circuit junction box at frame No. 6; 18 - selecting contractor, type K1-200; 19 - fuel pump junction box, rear; 20 - colour flare bomb emergency dragging circuit junction box; 21 - power junction box of normal supply circuit; 22 - power junction box of emergency supply circuit; 23 - dual supply circuit junction box, right; 24 - dual supply circuit junction box, left; 25 - fuel pump system junction box, right; 26 - fuel pump system junction box, left; 27 - power junction box; 28 - top gun mount sup-

ply box; 29 - camera equipment junction box; 30 - ground plug connector; 31 - contactor, type K-400, for connecting power supply source; 32 - contactor, type K-300, for connecting storage battery to normal supply circuit; 33 - storage battery; 34 - contactor, type K-300, for connecting storage battery to emergency supply circuit; 35 - hydraulic pump's junction box; 36 - pilot's instrument panel; 37 - pilot's circuit breaker control panel; 38 - co-pilot's circuit breaker control panel; 39 - left-hand circuit breaker control panel of navigator; 40 -

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 53. Schematic Connection Diagram of D.C. Circuit Distribution System

- 1 - tail station control panel; 2 - rear cabin power junction box;
- 3 - circuit breaker control panel of rear cabin; 4 - power load-in of normal supply circuit; 5 - supply junction box of tail gun mount;
- 6 - d-c-c-r junction box of tail unit; 7 - power junction box;
- 8 - generator, type GCP-18000; 9 - ballast resistor, type BC-18000; 10 - differential undercurrent relay, type DMP-600;
- 11 - distribution panel, left; 12 - selecting connector, type KD-400A; 13 - dual supply junction box at frame No. 17;
- 14 - power load-in of emergency supply circuit; 15 - tail station

- control panel; 16 - circuit breaker control panel at radar operator's station; 17 - dual supply circuit junction box at frame No. 6;
- 18 - selecting connector, type KD-200A; 19 - fuel pump junction box, rear; 20 - colour flare bomb emergency dropping circuit junction box; 21 - power junction box of normal supply circuit; 22 - power junction box of emergency supply circuit; 23 - dual supply circuit junction box, right; 24 - dual supply circuit junction box, left;
- 25 - fuel pump system junction box, right; 26 - fuel pump system junction box, left; 27 - power junction box; 28 - rear gun mount


- ply box; 29 - camera equipment junction box; 30 - ground plug connector; 31 - connector, type K-400A, for connecting power supply source; 32 - connector, type K-300A, for connecting battery to normal supply circuit; 33 - storage battery, 12-CAV-55; 34 - connector, type K-300A, for connecting battery to emergency supply circuit; 35 - hydraulic pump of junction box; 36 - pilot's instrument panel; 37 - pilot's circuit breaker control panel; 38 - co-pilot's circuit breaker control panel; 39 - left-hand circuit breaker control panel of navigator; 40

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM




- 1 - ballast resistor, type BC-18000; 2 - generator, type TCP-18000, No. 1; 3 - capacitor, type K3S-31; 4 - shunt of ammeter, type A-3; 5 - differential undercurrent relay, type AMP-500 for connecting generator No. 1 to normal supply circuit; 6 - contactor, type PFI-5B; 8 - fusing resistor; 9 - contactor, type PFI-5B; 10 - parallel relay, type PFI-2A; 11 - switch, type ZB-45 of generator No. 1; 12 - carbon regulator, type PFI-62; 13 - parallel operation winding; 14 - automatic connection winding; 15 - temperature compensation winding; 16 - working winding; 17 - stabilizing resistor; 18 - adjusting resistor; 19 - temperature compensation resistor; 20 - carbon pile; 21 - relay, type AMP-500, for connecting generator No. 2 to emergency supply circuit; 22 - relay, type AMP-500, for connecting generator No. 2 to normal supply circuit; 23 - switch, type ZB-45, of generator No. 2; 24 - change-over switch, type PFI-45, of voltmeter; 25 - switch, type PFI-45, labelled EMERGENCY SUPPLY CIRCUIT (ABAPPHIAH CEB); 26 - change-over switch, type PFI-45, labelled FROM GENERATOR (OT TEPATOPAI); 27 - contactor, type K-3001, for connecting storage battery to emergency supply circuit; 28 - contactor, type K-3001, for connecting storage battery to normal supply circuit; 29 - shunt of ammeter, type A-1; 30 - ammeter, type A-1; 31 - ground supply switch, type B-45; 32 - contactor, type K-4001, for connecting ground supply source to normal supply circuit; 33 - storage battery; 34 - change-over switch, type PFI-45; 35 - change-over switches, type PFI-45 and ZFI-45, of triple supply busbar; 36 - ammeter, type B-45, of standard; 37 - voltmeter, type BC-20; 38 - voltmeter, type B-1; 39 - blocking relay, type PFI-2; 40 - parallel relay, type PFI-A; 41 - switch, type B-45, of storage battery container heater circuit; 42 - switch, type B-45, for storage battery-to-normal supply circuit blocking; 43 - stability transformer, type TC-8; 44 - generator No. 2; 45 - generator No. 3; 46 - generator No. 4; 47 - storage battery; 48 - ground supply plug connector; 49 - thermal switch, type 777B, of storage battery container heater circuit; 50 - heater element of storage battery container; 51 - schematic connection diagram of generator, type TCP-18000; 52 - main pole; 53 - generator No. 2; 54 - blocking relay, type PFI-6, of generator No. 2; 55 - blocking relay, type PFI-6, of generator No. 3.

D.C. Supply Sources

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM



- 1 - ballast resistor, type BC-18000; 2 - generator, type TCF-18000, No. 1; 3 - contactor, type KEM-31; 4 - shunt of ammeter, type A-3; 5 - differential undercurrent relay, type ANP-600 for connecting generator No. 1 to normal supply circuit; 6 - contactor, type K-400L, for connecting generator No. 1 to emergency supply circuit; 7 - auxiliary relay, type PTL-5B; 8 - limiting resistor; 9 - common relay; 10 - polarized relay, type PTP-2A; 11 - switch, type 2B-45 of generator No. 1; 12 - carbon regulator, type PPT-82; 13 - parallel operation winding; 14 - automatic correction winding; 15 - temperature compensation winding; 16 - working winding; 17 - stabilizing resistor; 18 - adjusting resistor; 19 - temperature compensation resistor; 20 - carbon pile; 21 - relay, type ANP-600, for connecting generator No. 2 to emergency supply circuit; 22 - relay, type ANP-600, for connecting generator No. 2 to normal supply circuit; 23 - switch, type 2B-45, of generator No. 2; 24 - change-over switch, type B-45 of voltmeter; 25 - switch, type 2B-45, labelled EMERGENCY SUPPLY CIRCUIT (ABAPUJIAN CETY); 26 - change-over switch, type 2B-45, labelled FROM GENERATOR (OT PELEPATOPA); 27 - contactor, type K-400L, for connecting storage battery to emergency supply circuit; 28 - contactor, type K-400L, for connecting storage battery to normal supply circuit; 29 - shunt of ammeter, type A-1; 30 - ammeter, type A-1; 31 - ground supply switch, type B-45; 32 - contactor, type K-400L, for connecting ground supply source to normal supply circuit; 33 - storage battery; 34 - change-over switches, types B-45 and 2B-45, of triple supply busbar; 35 - switches, type B-45, of stand-by type busbar; 36 - ammeter, type A-3; 37 - external resistor, type BC-20; 38 - voltmeter, type B-1; 39 - blocking relay, type PTL-2; 40 - polarized relay, type PTL-A; 41 - switch, type B-45, of storage battery controller heater circuit; 42 - switch, type B-45, for storage battery-to-normal supply circuit blocking; 43 - stability transformer, type TC-8; 44 - generator No. 2; 45 - generator No. 3; 46 - generator No. 4; 47 - storage battery, type B-45; 48 - ground supply plug connector; 49 - thermal switch, type 7770, of storage battery controller heater circuit; 50 - heater element of storage battery controller; 51 - schematic connection diagram of generator, type TCF-18000; 52 - main pole; 53 - commutating pole; 54 - blocking relay, type PTL-6, of generator No. 1.

3.C. Supply Sources

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM





Fig. 54. Key Circuit Diagram of D.C. Supply Sources

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




- 1 - ballast resistor, type BC-18000; 2 - generator, type GCP-18000, No. 1; 3 - capacitor, type KB3-51; 4 - shunt of ammeter, type A-3; 5 - differential undarcurent relay, type DMP-600 for connecting generator No. 1 to normal supply circuit; 6 - contactor; 7 - auxiliary relay, type PJI-5B; 8 - limiting resistor; 9 - common relay; 10 - polarized relay, type PTE-2A; 11 - switch, type 2B-45 of generator No. 1; 12 - carbon regulator, type PVI-82; 13 - parallel operation winding; 14 - automatic connection winding; 15 - temperature compensation winding; 16 - working winding; 17 - stabilizing resistor; 18 - adjusting resistor; 19 - temperature compensation resistor; 20 - carbon pile; 21 - relay, type DMP-600, for connecting generator No. 2 to emergency supply circuit; 22 - relay, type DMP-600, for connecting generator No. 2 to normal supply circuit; 23 - switch, type 2B-45, of generator No. 2; 24 - changeover switch, type P-46, of voltmeter; 25 - switch, type 2B-45, labelled EMERGENCY SUPPLY CIRCUIT (ABAPUHAH ЦЕПЬ); 26 - changeover switch, type 2B-45, labelled FROM GENERATOR (OT ГЕНЕРАТОРА); 27 - contactor, type K-3001, for connecting storage battery to emergency supply circuit; 28 - contactor, type K-3001, for connecting storage battery to normal supply circuit; 29 - shunt of ammeter, type A-1; 30 - ammeter, type A-1; 31 - ground supply switch, type B-45; 32 - contactor, type K-4001, for connecting ground supply source to normal supply circuit; 33 - storage battery changeover switch, type PTE-45; 34 - change-over switches, types PTE-45 and 2PT-45, of triple supply busbar; 35 - switches, type B-45, of stand-by gyro horizon set; 36 - ammeter, type A-3; 37 - external resistor, type BC-20; 38 - voltmeter, type B-1; 39 - blocking relay, type PTE-1; 40 - polarized relay, type PTE-A; 41 - switch, type B-45, of storage battery container heater circuit; 42 - switch, type B-45, for storage battery-to-normal supply circuit blocking; 43 - stability transformer, type TO-B; 44 - generator No. 2; 45 - generator No. 2; 46 - generator No. 2; 47 - storage battery; 48 - ground supply plug connector; 49 - thermal switch, type 777B, of storage battery container heater circuit; 50 - heater element of storage battery container; 51 - schematic connection diagram of generator, type GCP-18000; 52 - main pole; 53 - contactor pole; 54 - blocking relay, type PTE-6, of generator No. 2; 55 - blocking relay, type PTE-6, of generator No. 2.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM



SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM





Fig. 55. Generator Control Panel

1 - main disconnecting bar of generator switch; 2 - circuit switch, type RC-20; 3 - panel attachment screw; 4 - meter, type 2014-R; 5 - meter, type 2014-R; 6 - meter, type 2014-R; 7 - meter, type 2014-R; 8 - chopper switch, type 2014-45; 9 - fuse, type B-45; 10 - chopper switch, type 2014-45; 11 - voltmeter, type B5-150; 12 - switch, type B-45; 13 - adjusting potentiometer, type B-45; 14 - voltmeter chopper switch, type B-45; 15 - voltmeter, type B-45; 16 - switch, type B-45; 17 - generator switch, type B-45, for storage battery blocking from normal supply circuit.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




Fig. 56. Automatic Circuit Breaker, Type A3C





Fig. 57. Fuses  
(a) glass fuse, type CI; (b) - delayed-action fuse, type VII;  
(c) - high heat fuse, type XII



SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM

50X1-HUM




Fig. 58. Circuit Breaker Control Panels of Pilot and Co-Pilot

1 - automatic circuit breaker; 2 - safety screen.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM



50X1-HUM




Fig. 59. Left-Hand Circuit Breaker Control Panel of Navigator  
1 - circuit breaker, type ACC.




Fig. 60. Right-Hand Circuit Breaker Control Panel of Navigator  
1 - circuit breaker, type ACC.

SECRET  
NO FOREIGN DISSEM






Fig. 64. Layout of Protective Equipment

- 1 - left-hand circuit breaker control panel of awing; 2 - right-hand circuit breaker control panel of awing; 3 - pilot's circuit breaker control panel; 4 - copilot's circuit breaker control panel; 5 - de-ice system junction box; 6 - overhead electric control board of pilats; 7 - radar operator's fuse box, 115 V A.C.; 8 - circuit breaker control panel of radar operator; 9 - power lead-in on frame No. 12, starboard; 10 - hydraulic pump junction box; 11 - junction box of operating inverter; 12 - storage battery junction box; 13 - top mount supply system junction box; 14 - camera equipment junction box; 15 - fuel pump system junction box, right; 16 - right junction box of L.G. well extension lamp; 17 - right junction box of engine compartment extension lamp; 18 - distribution panel, right; 19 - dual supply system junction box, right; 20 - fuel pump system junction box on frame No. 49; 21 - bottom mount supply system junction box; 22 - power junction box of rear cabin; 23 - circuit breaker control panel of rear cabin; 24 - left power lead-in on frame No. 69; 25 - roll gun mount supply system junction box; 26 - roll unit de-ice system junction box; 27 - outboard heater circuit breaker box; 28 - left junction box of L.G. well extension lamp; 29 - distribution panel, left; 30 - left junction box of engine compartment extension lamp; 31 - junction box of flare bomb emergency dropping system; 32 - dual supply system junction box, left; 33 - combat release system junction box; 34 - fuel pump system junction box, left; 35 - stand-by inverter junction box; 36 - dual supply system junction box; 37 - emergency circuit lead-in on frame No. 12, port side; 38 - power lead-in on frame No. 12; 39 - dual supply system junction box; 40 - in-flight fuel panel of pilats; 41 - awing's fuse panel, 115 V A.C.; 42 - flare bomb control board.

SECRET

NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




Fig. 64. Layout of Protective Equipment

- 1 - left-hand circuit breaker control panel of engine; 2 - right-hand circuit breaker control panel of engine; 3 - pilot's circuit breaker control panel; 4 - copilot's circuit breaker control panel; 5 - deceler system junction box; 6 - overhead electric control panel of pilot; 7 - radar operator's fuse box, 115 V A.C.; 8 - circuit breaker control panel of radar operator; 9 - power lead-in on frame No. 12, starboard; 10 - hydraulic pump junction box; 11 - junction box of operating inverter; 12 - storage battery junction box; 13 - top mount supply system junction box; 14 - camera equipment junction box; 15 - fuel pump system junction box, right; 16 - right junction box of L.G. well extension lamp; 17 - right junction box of engine compartment extension lamp; 18 - distribution panel, right; 19 - fuel supply system junction box, right; 20 - fuel pump system junction box; 21 - bottom mount supply system junction box; 22 - power junction box of rear cabin; 23 - circuit breaker control panel of rear cabin; 24 - left power lead-in on frame No. 69; 25 - fuel gas mount supply system junction box; 26 - fuel unit deceler system junction box; 27 - outlet heater circuit breaker box; 28 - left junction box of L.G. well extension lamp; 29 - distribution panel, left; 30 - left junction box of engine compartment extension lamp; 31 - junction box of fire bomb emergency dropping system; 32 - dual supply system junction box, left; 33 - combat release system junction box; 34 - fuel pump system junction box, left; 35 - standby inverter junction box; 36 - dual supply system junction box; 37 - emergency circuit lead-in on frame No. 12, port side; 38 - power lead-in on frame No. 12; 39 - dual supply system junction box; 40 - instrument panel of pilot; 41 - navigator's fuse panel, 115 V A.C.; 42 - fire bomb control board.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 64. Layout of Protective Equipment

- 1 - control panel of navigator; 2 - right panel of navigator; 3 - pilot's circuit breaker's circuit breaker control panel; 4 - bag 6 - overhead electric control center's base box, 115 V. A.C.; 5 - control panel of radar operator; 6 - power boards; 7 - hydraulic pump junction box; 8 - control panel of navigator; 9 - pilot's circuit breaker's circuit breaker control panel; 10 - storage battery junction box; 11 - top mount supply system junction box; 12 - camera equipment junction box; 13 - fuel pump system junction box, right; 14 - right junction box of L.G. well extension lamp; 15 - right junction box of engine compartment extension lamp; 16 - fuel supply system junction box, right; 17 - fuel pump system junction box at frame No. 49; 18 - bottom mount supply system junction box; 19 - power junction box of rear cabin; 20 - circuit breaker control panel of rear cabin; 21 - left power feed-in on frame No. 69; 22 - left gun mount supply system junction box; 23 - left unit heater junction box; 24 - left junction box of L.G. well extension lamp; 25 - distribution panel, left; 26 - left junction box of engine compartment extension lamp; 27 - junction box of flare bomb emergency dropping system; 28 - dual supply system junction box, left; 29 - combat release system junction box; 30 - fuel pump system junction box, left; 31 - standby inverter junction box; 32 - dual supply system junction box; 33 - emergency circuit feed-in on frame No. 12, port side; 34 - power feed-in on frame No. 12, starboard; 35 - dual supply system junction box; 36 - instrument panel of pilot; 37 - navigator's face panel, 115 V. A.C.; 38 - flare bomb control board; 39 - power junction box of rear cabin; 40 - circuit breaker control panel of rear cabin; 41 - left power feed-in on frame No. 69; 42 - left gun mount supply system junction box; 43 - left unit heater junction box; 44 - left junction box of L.G. well extension lamp; 45 - distribution panel, left; 46 - left junction box of engine compartment extension lamp; 47 - junction box of flare bomb emergency dropping system; 48 - dual supply system junction box, left; 49 - combat release system junction box; 50 - fuel pump system junction box, left; 51 - standby inverter junction box; 52 - dual supply system junction box; 53 - emergency circuit feed-in on frame No. 12, port side; 54 - power feed-in on frame No. 12, starboard; 55 - dual supply system junction box; 56 - instrument panel of pilot; 57 - navigator's face panel, 115 V. A.C.; 58 - flare bomb control board.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




Fig. 65. Typical Wire Fittings  
 1 - soldered wire termination; 2 - loop termination; 3 - wire-to-capacitor attachment; 4 - lug termination of wire; (a) - for wires, gauging 0.15 to 0.5 sq.mm; (b) - for wires gauging 1 to 0.5 sq.mm; 5 - termination of plug connector wires; (a) - fitting the wires in plug connector pins and sockets; (b) - fitting the wires in plug connector pins and sockets with cutting off part of wire conductors; (c) - fitting the bunched conductor in plug connector; 6 - tagging the bunched conductors; 7 - fitting bunched conductors consisting of six or more shielded wires in plug connectors; 8 - fitting the wires in lug; 9 - fitting the wires in plug connectors with screw clamps; 10 - fitting the wires in plug connectors.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 66. Typical Wire Connections  
1 - plug connector; 2 - individual connector; 3 - fixed connector; 4 - sealed lead; 5 - terminal block;  
6 - bolt connector; 7 - power lead.




Fig. 67. Circuit Continuity Test without Commutating Relay  
1 - fuse; 2 - change-over switch; 3 - capacitor; 4 - megohmmeter; 5 - mechanism; 6 - plug connector; 7 - terminals in junction boxes; 8 - plug busbar.




Fig. 68. Circuit Continuity Test with Commutating Connector  
1 - mechanism; 2 - plug connector; 3 - connector winding; 4 - change-over switch; 5 - fuse; 6 - plug busbar.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM





Fig. 60. Maximum Allowed Values of Contact Resistances (in microohms) between Separate Aircraft Structure Members




- 1 - bomb bay door control board; 2 - navigator's intercom control panel; 3 - dual junction box; 4 - trim tab control panel; 5 - trim tab control panel; 6 - trim tab control panel; 7 - trim tab control panel; 8 - overhead electrical control board; 9 - fueling control board at cockpit; 10 - synchronization control panel; 11 - stand-by inverter; 12 - junction box; 13 - relay box of stand-by inverter; 14 - release electric control board; 15 - auxiliary fuel pump junction box; 16 - emergency supply system junction box; 17 - dual supply system junction box; 18 - power junction box; 19 - fuel pump system junction box; 20 - power junction box; 21 - power junction box; 22 - power junction box; 23 - power junction box; 24 - power junction box; 25 - power junction box; 26 - power junction box; 27 - rear cabin sound signalization system junction box; 28 - gun operator's electric control board; 29 - missile mount fuse system junction box; 30 - switch and receptacle box of extension lamp; 31 - power junction box; 32 - roll unit detector junction box; 33 - multiple heater system circuit breaker box; 34 - roll gun mount fuse box; 35 - circuit breaker board of rear cabin; 36 - radio operator's electric control board; 37 - junction box of rear pressurized cabin; 38 - engine nacelle; 39 - L.G. fairing; 40 - auxiliary fuel pump junction box; 41 - emergency supply system junction box; 42 - dual supply system junction box; 43 - power junction box; 44 - fuel pump system junction box; 45 - power junction box; 46 - power junction box; 47 - power junction box; 48 - power junction box; 49 - power junction box; 50 - power junction box; 51 - power junction box; 52 - power junction box; 53 - power junction box; 54 - power junction box; 55 - power junction box; 56 - power junction box; 57 - rear cabin sound signalization system junction box; 58 - gun operator's electric control board; 59 - missile mount fuse system junction box; 60 - switch and receptacle box of extension lamp; 61 - power junction box; 62 - roll unit detector junction box; 63 - multiple heater system circuit breaker box; 64 - roll gun mount fuse box; 65 - circuit breaker board of rear cabin; 66 - radio operator's electric control board; 67 - junction box of rear pressurized cabin; 68 - engine nacelle; 69 - L.G. fairing.

SECRET  
NO FOREIGN DISSEM



SECRET  
NO FOREIGN DISSEM

50X1-HUM



1 - bomb bay door control board and camera mount control board of navigator; 2 - navigator's interphone control board; 3 - circuit breaker control panel of copilot; 4 - glass panel de-icer system junction box; 5 - trim tab control panel of copilot; 6 - ultraviolet illumination rheostat control panel of copilot; 7 - fuel supply control board; 8 - overhead electric control panel of pilots; 9 - heating control board of copilot's station; 10 - trim tab synchronization control panel; 11 - relay box of operating inverter, type PO-4500; 12 - junction box, right; 13 - generator control panel of radar operator's station; 14 - junction box, left; 15 - relay box of stand-by inverter, type PO-4500; 16 - bomb release electric control board; 17 - lower bomb release electric

control board on navigator's left-hand console; 18 - upper electric control board of navigator; 19 - left-hand circuit breaker control panel of navigator; 20 - circuit breaker control panel of copilot; 21 - dual supply system junction box of front cabin; 22 - trim tab control panel of pilot; 23 - electric control board of pilot; 24 - de-energized main bomb dropping control station; 25 - front cabin sound signalization system junction box; 26 - right junction box of L.G. and fuel pump relay systems; 27 - left junction box of L.G. and fuel pump relay systems; 28 - hydraulic pump junction box; 29 - ground supply system junction box; 30 - storage battery junction box; 31 - top gun mount fuse system junction box; 32 - power junction box;

33 - camera equipment junction box; 34 - fuel quantity gauge junction box; 35 - distribution panels, left and right; 36 - junction box of operating and stand-by inverters; 37 - dual supply system junction box; 38 - fuel pump system junction box; 39 - emergency bomb dropping system junction box; 40 - power junction box; 41 - landing flap system junction box; 42 - bomb release system junction box; 43 - fuse system junction box; 44 - emergency supply system junction box; 45 - dual supply system junction box; 46 - bomb bay doors interlock limit switch mechanism; 47 - bomb bay doors limit switch mechanism; 48 - fuel pump system junction box; 49 - de-energized main bomb emergency dropping system junction box;

50 - auxiliary fuel pump junction box; 51 - emergency supply system junction box; 52 - dual supply system junction box; 53 - power junction box; 54 - fuel pump system junction box, rear; 55 - range-finder supply system junction box; 56 - power junction box; 57 - rear cabin sound signalization system junction box; 58 - gun operator's electric control board; 59 - Misto of extension lamp; 61 - power junction box; 62 - tail unit de-icer junction box; 63 - autopilot heater system circuit breaker box; 64 - tail gun mount fuse box; 65 - circuit breaker board of rear cabin; 66 - radio operator's electric control board; 67 - junction box of rear pressurized cabin; 68 - engine nacelle; 69 - L.G. fitting.

SECRET  
NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM



50X1-HUM




Fig. 71. Fitting the Aluminium Wire in Lug and Circuit Diagram for Measuring Contact Resistance At Aluminium Wire Fitting Point

- 1 - lug; 2 - millivoltmeter rated for up to 60 millivolts, class 0.5;
- 3 - contact yoke; 4 - wire, mark БГВМА; 5 - adjusting rheostat;
- 6 - generator; 7 - ammeter, class 0.5; 8 - shunt of ammeter rated for up to 300 A




Fig. 72. Storage Battery Junction Box

- 1 - polarized relay, type ППТ-А; 2 - terminal block; 3 - location of fuse, type ТП-400, for protection of operating inverter, type ПП-4500; 4 - blocking relay, type ПП-2; 5 - locations of fuses, type ПП-35-2, for protection of instrument supply circuit in de-energized mains conditions; 6 - contactor, type К-300А, for connecting storage battery to emergency supply circuit;
- 7 - contactor, type К-300А, for connecting storage battery to normal supply circuit; 8 - location of fuse, type ПП-10, for protection of storage battery heater circuit; 9 - contactor, type К-400А, for connecting ground power supply source; 10 - shunt of ammeter, type А-1.

SECRET

NO FOREIGN DISSEM

SECRET

NO FOREIGN DISSEM



50X1-HUM




Fig. 73. Key Circuit Diagram of A.C. Power Supply Sources

- 1 - operating inverter, type PD-4500; 2 - contactor, type K-500;
- 3 - voltmeter, type DV-150; 4 - change-over switch, type 3723 of inverters; 5 - ground supply switch, type B-45; 6 - blocking relay, type PT-2; 7 - stand-by inverter, type PD-4500;
- 8 - adjusting resistor (trimmer), type PC-4M; 9 - carbon voltage regulator, type FS-25B; 10 - plug connector of A.C. ground supply circuit; IC - starting resistor; CO - series winding of motor; II - winding of motor commutating poles; YO - motor control winding; DO-25-170 - magnetic amplifier of A.C. frequency stabilization; DO-12-25 - magnetic amplifier of A.C. voltage stabilization; D - damping winding; Π - magnetization winding; ΠΠ - A.C. winding; OC - negative feedback winding; Π - magnetization winding; KK - resonant circuit; CH - voltage stabilizer; OCB - generator field winding; POP - generator working winding; TC-11 - stability transformer; III - centrifugal switch.

SECRET


NO FOREIGN DISSEM



**SECRET**  
NO FOREIGN DISSEM




50X1-HUM




**Fig. 75. Cabin and Glass Panel Heater System Junction Box**

- 1 - contactor, type K50A, of co-pilot's glass panel heater;
- 2 - contactor, type K-100A, of navigator's glass panel heater;
- 3 - location of IPT-100 fuse of navigator's glass panel heater;
- 4 - location of IPT-150 fuse of front pressurized cabin heater;
- 5 - locations of IPT-75 fuses of glass panel heaters of pilot and co-pilot;
- 6 - locations of IPT-50 group protection fuses;
- 7 - location of IPT-10 group protection fuse;
- 8 - terminal block;
- 9 - contactor, type K-50A, of pilot's glass panel heater.



**Fig. 76. Calibrating Resistance Rheostat**



**Fig. 77. Key Diagram of Tail Emergency De-icers**  
1 - stabilizer de-icer outside sections; 2 - electric motor; 3 - electric motor; 4 - four-stage planetary reducer; 5 - contact device; 6 - rheostat; 7 - warning lamp; 8 - switch, type B-45; 9 - terminal block; 10 - fin de-icer section; 11 - stabilizer de-icer inner sections.

**SECRET**  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM




Fig. 78. Tail Empennage De-Icers Junction Box  
1 - stabilizer outer section contactor, type K-600/L; 2 - fin section contactor, type K-600/L; 3 - attachment bolts of fuses, type TT-600; 4 - stabilizer inner section conductor, type K-600/L.




Fig. 79. Aircraft Coloured Warning Light, Type CJII-51  
1 - body; 2 - cap with nozzle; 3 - light filter; 4 - contact busbars.




Fig. 80. Horn, Type C-1  
1 - cap attachment bolt; 2 - inlet pipe union for conductors with a union nut; 3 - holes for attachment of the horn.



50X1-HUM




Fig. 81. Box of Front Pressurized Cabin Sound Signal Relay  
1 - capacitor, type K1-1A-50 50 ohms - V; 2 - alarm signal relay, type 121-2; 3 - intermittent signal cutoff relay, type 121-2; 4 - terminal block; 5 - cabin pressure drop intermittent signal buzzer relay, type 121-12.




Fig. 82. Box of Rear Pressurized Cabin Sound Signal Relay  
1 - capacitor, type K1-1A-50 50 ohms - V; 2 - cabin pressure, drop intermittent signal buzzer relay, type 121-12.

SECRET  
NO FOREIGN DISSEM



Fig. 83. Right-Seat Pilot's Rheostat Panel  
 1 - rheostats, type PY90-45; 2 - cutouts, type B-45.




Fig. 84. Gunner-Radio Operator's Electric Board  
 1 - switch, type B-45; 2 - change-over switch, type III-45;  
 3 - warning lamp, type CIII-51, with green light filter; 4 - rheostat, type PY90-45; 5 - change-over switch, type II-45; 6 - change-over switch, type IZIII-45.




Fig. 85. Dome light, Type IIC-45  
 1 - reflector; 2 - lamp; 3 - inlet pipe union for the conductor with union nut




Fig. 86. Dome light, Type IICM-51  
 1 - protective glass; 2 - glass and reflector attachment spring; 3 - dome light body; 4 - reflector; 5 - bush; 6 - contact pin; 7 - union nut; 8 - holes for the attachment of the dome light.




Fig. 87. Lamp Hinged Bracket  
 1 - hinged bracket; 2 - ultra-violet illumination lamp, type APV90111-45; 3 - cabin lamp, type KICPK-45.




Fig. 88. Extension Lamp, Type III-10-36  
 1 - reflector; 2 - switch; 3 - handle body; 4 - cord; 5 - plug.

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 89. Taxiing light, Type QP-100  
1 - taxiing light attachment hinge bracket; 2 - protective glass  
3 - reflector; 4 - lamp; 5 - casing; 6 - cord




Fig. 91. Landing Light, Type J10CB-45  
1 - landing lamp body; 2 - landing lamp retractable part;  
3 - attachment screws; 4 - attachment ring; 5 - landing lamp control electric mechanism, type M1K-2; 6 - plug connector.




Fig. 90. Pilots' Upper Electric Board  
1 - A11-5-2M automatic pilot control panel; 2 - extension plate; 3 - switch, type B-45; 4 - change-over switch, type 2H1-6; 5 - change-over switch type III-45M.




Fig. 92. M10-2 Electric Mechanism Drive Box with Cover Open  
1 - cover; 2 - body; 3 - screw; 4 - limit switch; 5 - plate; 6 - stop.




Fig. 93. P100-45 Formation Lights Dome Lamp  
1 - dome lamp body; 2 - socket holder with a union nut for the conductor; 3 - rubber gasket; 4 - polystyrene light refractor; 5 - retaining ring.

SECRET  
NO FOREIGN DISSEM



SECRET

NO FOREIGN DISSEM



50X1-HUM




Fig. 94. Navigation Light, Type SAHO-45  
1 - glass light filter; 2 - pecking gasket; 4 - base with socket;  
4 - union nut; 5 - firing attachment hole; 6 - lead washer;  
7 - light filter attachment screw.




Fig. 96. Push-Button Type Lamp  
1 - lamp, type CM-30; 2 - body; 3 - button.




Fig. 95. Tall Navigation Light, Type XC-39  
1 - body; 2 - mounting; 3 - gasket; 4 - lamp; 5 - glass shade;  
6 - glass shade attachment screws; 7 - fitting attachment screw;  
8 - supply conductors attachment screw.




Fig. 97. Fire Sensitive Unit  
1 - diaphragm; 2, 3 - fire-sensitive unit pins.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM



Fig. 98. CO<sub>2</sub> and Neutral Gas Cylinders Discharge Bonnet

1 - discharge bonnet; 2 - firing gun.





Fig. 99. Pilot's Upper Electric Board

1 - fuel automatic control line switch; 2 - stand-by pumps switch; 3 - manual and automatic control switch; 4 - fuel pumps manual control circuit breakers; 5 - blue warning lamps; 6 - green warning lamps; 7 - fire warning and cylinder discharge bonnet switching push-button type lamp.

SECRET  
NO FOREIGN DISSEM


**SECRET**  
**NO FOREIGN DISSEM**




**Fig.100. Fuel Gauge Amplifiers**  
1 - port group fuel gauge amplifier;  
2 - starboard group fuel gauge amplifier.



**Fig.101. Fuel System Automatic Units**  
1 - port group automatic unit; 2 - starboard group automatic unit.




**Fig.102. Right-Seat Pilot's Instrument Panel**  
1 - fuel-level gauge switches; 2 - port group fuel-level gauge indicator; 3 - port group fuel-level gauge change-over switch; 4 - starboard group fuel-level gauge change-over switch; 5 - starboard group fuel-level gauge indicator.



**Fig.103. Thyratron Interrupters of the PTC-16 Fuelmeter**  
1 - port engine fuelmeter interrupter; 2 - starboard engine fuelmeter interrupter.

50X1-HUM



**Fig.104. Throttle Control on the Right-Seat Pilot's Console**  
1 - flap sound signal limit switch; 2 - throttle control; 3 - horn cutoff button; 4 - landing-gear sound signal limit switch.

**SECRET**  
**NO FOREIGN DISSEM**

**SECRET**  
**NO FOREIGN DISSEM**




Fig. 105. Left-Seat Pilot's Console  
1 - flap change-over switch.




Fig. 106. Right-Seat Console  
1 - landing-gear sound signal cutoff button; 2 - flap change-over switch.




Fig. 107. Right-Seat Pilot's Instrument Panel  
1 - flap position indicator.




Fig. 108. Limit Switch of Landing Gear Main Legs Extended Position Warning System  
1 - limit switch; 2 - stop and adjusting screw of the limit switch.




Fig. 109. Right-Seat Pilot's Steering Wheel  
1 - elevator trim tab switch; 2 - switch neutral position stop; 3 - automatic pilot emergency cutoff button.




Fig. 110. Left-Seat Pilot's Instrument Panel  
1 - rudder trim tab neutral position warning lamp; 2 - aileron trim tab neutral position warning lamp; 3 - course indicator, type AT-5-2M 1001.



Fig. 111. Aileron Trim Tab Synchronization Panel  
1 - synchronization panel; 2 - warning lamp; 3 - control switch; 4 - limit switch of the trim tab neutral position warning lamp with the panel cover closed.

**SECRET**  
**NO FOREIGN DISSEM**

SECRET  
NO FOREIGN DISSEM



50X1-HUM




Fig. 112. Left-Seat Pilot's Trim Tab Control Panel  
1 - rudder trim tab control switch; 2 - aileron trim tab control switch.




Fig. 114. Rear Cabin Electric Heater (Unit 107)  
1 - K-200 contactor box; 2 - unit 107; 3 - hatch for access to unit 107.




Fig. 113. Right-Seat Pilot's Trim Tab Control Panel  
1 - rudder trim tab switch; 2 - aileron trim tab switch;  
3 - guard.




Fig. 115. Gunner-Radio-Operator's Electric Board  
1 - heater switches.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 116. Photographic Equipment Arrangement Diagram  
 1 - camera 04P21-1; 2 - 04P21-1 camera controller; 3 - camera ASA-32/4; 4 - mount of camera H30A-32/50; 5 - IIA0A camera controller; 6 - camera controller KITV-2; 7 - fitting mount control panel.




Fig. 117. Camera Hatch  
 1 - electric mechanism YP-7N1; 2 - driving shaft; 3 - bracket; 4 - camera; 5 - IIA0A camera interlocking limit switch; 6 - CAMERA HATCH CLOSED limit switch; 7 - IIA0A camera interlocking limit switch; 8 - IIA0A camera interlocking limit switch; 9 - IIA0A camera interlocking limit switch; 10 - IIA0A camera interlocking limit switch; 11 - IIA0A camera interlocking limit switch; 12 - pulley; 13 - belt; 14 - pulley; 15 - driven shaft; 16 - guide; 17 - camera hatch door.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 118. Control Panel

1 - camera hatch door control switch; 2 - tilting angle change-over switch employed during the BOMBING CONTROL mode of operation; 3 - mode-of-operation selector; 4 - CAMERA HATCH OPENED (ВКЛ. ОТКРЫТ) green indicating lamp; 5 - tilt angle setting indicating lamp during BOMBING CONTROL mode of operation; 6 - АВА camera tilt control button for BOMBING CONTROL mode of operation; 7 - camera tilting mount control indicating lamp for AERIAL RECONNAISSANCE mode of operation.

*callout 7*





Fig. 119. Camera Automatic Tilting Mount AKAOY-156H

1 - valve nut; 2 - setting screw; 3 - lockable base; 4 - lockable base; 5 - lockable base; 6 - plate for arranging the drive-and-pressure screws; 7 - ball; 8 - ball; 9 - ball; 10 - lower frame; 11 - locking screw.

*callout 3*


SECRET

NO FOREIGN DISSEM



**Fig. 120. Camera Controller KIV-2**  
 1 - АККУ mount operation switch; 2 - camera controller heater switch; 3 - fusible cutout cover; 4 - time interval setting scale (white color); 5 - АККУ mount operation indicating lamp; 6 - CURRENT ON (ТОК ВКЛЮЧЕН) indicating lamp; 7 - setting dial; 8 - bombing altitude scale (yellow color); 9 - REWINDING (ПЕРЕМОТКА) or READY TO BOMBING CONTROL (ГОТОВ К КОНТРОЛЮ БОМБОМЕТАВ) indicating lamp; 10 - exposure counter sealing disc; 11 - exposure counter; 12 - continuous functioning switch; 13 - BOMBING CONTROL (КОНТРОЛЬ БОМБОМЕТАВ) - INTERVAL (ИНТЕРВАЛ) setting switch; 14 - camera controller cable connector; 15 - camera controller stopping button; 16 - starting button; 17 - two-pin plug; 18 - single exposure button.


*Callout 6*



**Fig. 122. HAFA-30/30 Camera Controller**  
 1 - common switch; 2 - REWINDING (ПЕРЕМОТКА) indicating lamp; 3 - CURRENT ON (ТОК ВКЛЮЧЕН) indicating lamp; 4 - ILLUMINATION (ПОКРЕЩЕНА) indicating lamp; 5 - CHECK-UP (ПРОВЕРКА) button; 6 - heater switch; 7 - housing; 8 - connector plug.


*Callout 5*

50X1-HUM



**Fig. 121. HAFA Camera Mount**  
 1 - converter; 2 - camera chamber portion; 3 - film magazine; 4 - plate; 5 - arrow indicating the flight direction; 6 - gate; 7 - sector; 8 - locking pin; 9 - movable frame; 10 - sensor; 11 - shock absorber; 12 - outer (fixed) frame; 13 - sensor; 14 - bracket; 15 - exposure setting knob; 16 - blind; 17 - camera taper portion; 18 - automatic release; 19 - photocell; 20 - suspension bracket.

*Callout 4*



**Fig. 123. APR-1 Camera Mount**  
 1 - cellulose tube; 2 - attachment ring; 3 - intermediate lock; 4 - spring; 5 - focusing ring; 6 - locking stud; 7 - camera cover; 8 - film magazine; 9 - camera crank; 10 - guiding pin; 11 - clamp.

*Callout 1*



**SECRET**  
NO FOREIGN DISSEM

50X1-HUM




Fig. 124. Arrangement of Radio Communication Facilities  
 1 - remote control panel of command set I-PCB-70M; 2 - control panel of command set receiver VC-9; 3 - receiver VC-9; 4 - antenna; 5 - Y-500 of transmitter I-PCB-70M; 6 - transmitter I-PCB-70M of command set; 7 - control panel of command set PCBV-3M; 8 - loop antenna of command set I-PCB-70M; 9 - receiver VC-9 of communication radio set; 10 - telegraph key panel of communication radio set; 11 - radio operator's electric board with monitoring switches and telegraph key; 12 - dynamometer Y-500 of communication radio set; 13 - transmitter VC-9 of communication radio set; 14 - transmitter of communication radio set I-PCB-70; 15 - transmitter VC-9 of communication radio set; 16 - transmitter VC-9 of communication radio set; 17 - transmitter of radio set I-PCB-3M; 18 - receiver No. 1 of command radio set PCBV-3M.



Fig. 125. Interphone Set PCBV-10  
 1 - volume control (knob LOUDER); 2 - network switch; 3 - conference coil button; 4 - function switch.




Fig. 126. Interphone System Amplifier  
 1 - white notch on gain control scale; 2 - gain control.




Fig. 127. Remote Control Panel of Receiver VC-9 JM  
 1 - switch CRYSTAL; 2 - tuning scale window; 3 - scale illumination control; 4 - tuning knob; 5 - control BEAT NOTE; 6 - buttons ANTENNA ADJUSTMENT; 7 - volume control; 8 - bend selector; 9 - switch AFC - off - MFC; 10 - voltage (115 V) indicator lamp; 11 - switch TGPH - TPHN.

**SECRET**  
NO FOREIGN DISSEM

**SECRET**  
**NO FOREIGN DISSEM**



50X1-HUM




Fig. 128. Transmitter 1-PCG-70M  
1 - key CHECK; 2 - switch LOCAL - REMOTE; 3 - antenna current indicator; 4 - anode current indicator switch; 5 - anode current indicator; 6 - power selector switch; 7 - transmitter function switch; 8 - table to record results of transmitter tuning; 9 - terminal TRANSMITTER ANTENNA (АНТЕННА ПЕРЕДАТЧИКА); 10 - terminal RECEIVER ANTENNA (АНТЕННА ПРИЕМНИКА); 11 - channel selector; 12 - telegraph key socket; 13 - knob Д; 14 - jacks TELEPHONES no. 1 and No. 2; 16 - jack MICROPHONE; 17 - knob Г; 18, 20 - knobs А; 19 - knob А revolution counter; 21 - knob А corrector.



Fig. 129. Remote Control Panel of Transmitter of Command Radio Set 1-PCN-70M  
1 - button-telegraph key; 2 - red pilot lamp - station on-indicator




Fig. 132. Control Panel of Radio Set PCII Y-3M  
1 - channel reset button; 2 - channel on-signalling windows (the third channel is on); 3 - receiver telephone output switch (protective clamp is removed); 4 - volum control limiter; 5 - volum control; 6 - channel selection buttons.



Fig. 130. Telegraph Key




Fig. 131. Receiver YC-9




Fig. 133. Taster (unit 1)

**SECRET**  
**NO FOREIGN DISSEM**

SECRET  
NO FOREIGN DISSEM



50X1-HUM




Fig. 134. Tester KCP-1




Fig. 136. Receiver PCMV-3M (unit B)  
1 - channel reset button; 2 - tuning knob of local oscillator and U.H.F.; 3 - tuning knob of tripler and second mixer; 4 - crystal; 5 - noise limiter switch; 6 - sensitivity control.




Fig. 135. Transmitter PCMV-3M (unit A)  
1 - channel reset button; 2 - tuning knob of master oscillator and first amplifier; 3 - tuning knob of second amplifier; 4 - tuning knob of power amplifier; 5 - crystals.




Fig. 137. Control Panel of Radio Compass MPK-5  
1 - band switch and tuning scale APK-5; 2 - scale illumination control; 3 - tuning indicator; 4 - loop antenna manual rotation switch; 5 - sensitivity control of tuning indicator; 6 - button to change over control from one panel, APK-5 to the other; 7 - function switch; 8 - volume control; 9 - green lamp indicates that panel is energized; 10 - flex-shaft pipe connector; 11 - fuse for 28 V D.C. circuits; 12 - switch TGPH-TPHN; 13 - fuse for 115 V, 400 c.p.s. circuit.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



Fig. 138. Radio Compass Course Indicator BCMT-1



Fig. 139. Course Indicator УДДС-1





Fig. 140. Receiver of Radio-Compass APK-5  
1 - sensitivity control APK-5; 2 - terminal ANTENNA;  
3 - terminal EARTH; 4 - flexible shaft pipe connection.



50X1-HUM

Fig. 141. Marker Beacon Simulator МВМ-48  
1 - frequency setting limb MARKER; 2 - indicator; 3 - modulation switch; 4 - function switch; 5 - simulator tuning chart;  
6 - antenna; 7 - socket BAND ANTENNA (АНТЕННА ДИАПАЗОНА); 8 - socket ANTENNA-CRYSTAL; 9 - supply switch;  
10 - R.F. oscillation being switch.




Fig. 142. Marker Receiver МРМ-48П  
1 - circuit I tuner; 2 - circuit II tuner; 3 - jack for plug of check instrument for measuring relay current.

SECRET  
NO FOREIGN DISSEM

**SECRET**  
NO FOREIGN DISSEM



50X1-HUM




Fig. 143. Inboard Antenna of Marker Receiver MPPI-4HH  
1 - cap of antenna tuning screw.




Fig. 144. Indicator PB-17  
1 - screen; 2 - control knob ZERO CONTROL  $\times 10$ ; 3 - range scale switch; 4 - control knob ZERO CONTROL  $\times 1$ ; 5 - control knob DIRECT PULSE CONTROL-GAIN; 6 - control knob CIRCLE SIZE (PASM. OKPVA.); 7 - on-pilot lamp; 8 - supply switch.




Fig. 145. Tester T-1  
1 - bridging feeder  $\Phi$ -3; 2 - socket H-1; 3 - feeder  $\Phi$ -2; 4 - B-1; 5 - two feeders  $\Phi$ -1; 6 - antenna radiation indicator; 7 - attenuator; 8 - socket H-2; 9 - socket B-2.




Fig. 146. Diagram Showing Connections of Radio Altimeter PB-17 to Tester T-1 for Measurement of Overall Sensitivity

1 - tester T-1; 2 - receptacle RECEIVING ANTENNA; 3 - transmitter-receiver PB-17; 4 - cable connecting transmitter-receiver PB-17 to indicator; 5 - indicator of radio altimeter; 6 - receptacle TRANSMITTING ANTENNA;  $\Phi 1, \Phi 2, \Phi 3$  - radio-frequency feeders; H-1, H-2, B-1 and B-2 - radio-frequency sockets of tester T-1.




Fig. 147. Diagram Showing Connection of Radio Altimeter PB-17 to Tester T-1 for Measurement of Radiation Power of Transmitter PH-17

1 - tester T-1; 2 - switch POWER-FREQUENCY; 3 - receptacle TO INDICATOR (KINIRININININ); 4 - cable connecting tester T-1 to indicator PB-17; 5 - indicator PB-17; 6 - cable connecting tester T-1 to transmitter-receiver PB-17; 7 - transmitter-receiver PB-17; 8 - receptacle RECEIVING ANTENNA; 9 - control  $\Phi$ ; 10 - receptacle TRANSMITTING ANTENNA; 11 - radio-frequency cable connecting receptacle TRANSMITTING ANTENNA on transmitter-receiver PB-17 to receptacle POWER on tester T-1; 12 - receptacle FREQUENCY; 13 - receptacle POWER.

**SECRET**  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




Fig. 148. Tester T-4

1 - instructions for tester; 2 - function switch; 3 - connector for cutting in indicator PB-17; 4 - power-level indicator; 5 - cable for connection to transmitter-receiver PB-17; 6 - T-joint; 7 - socket POWER; 9 - socket FREQUENCY.




Fig. 149. Transmitter-Receiver 1M-17

1 - control A for tuning transmitting antenna.




Fig. 150. Indicator PPB-46 of Radio Altimeter PB-3




Fig. 151. Diagram Showing Connection of Radio Altimeter PB-2 to Tester T-1 for Checking Overall Sensitivity of PH-2 and Calibration of Readings at the End of Indicator Scale on 1st Band

1 - transmitter-receiver PB-2; 2 - receptacle RECEIVING ANTENNA; 3 - receptacle TRANSMITTING ANTENNA; 4 - control ZERO ADJUSTMENT - HIGH ALTITUDES; 5 - control ZERO ADJUSTMENT - LOW ALTITUDES; 6 - tester T-1; 7 - control CALIBRATION - HIGH ALTITUDES; 8 - control CALIBRATION - LOW ALTITUDES; 9 - supply cables PB-2; 10 - altimeter indicator;  $\Phi-1, \Phi-2, \Phi-3$  - radio-frequency cables;  $\bar{U}-1, \bar{H}-2, \bar{H}-1, \bar{H}-2$  - sockets of tester T-1.




Fig. 152. Diagram Showing Connection of Radio Altimeter PB-2 to Tester T-1 for Calibration of Radio Altimeter Readings at the Beginning of Indicator Scale on 1st Band

1 - receptacle RECEIVING ANTENNA; 2 - receptacle TRANSMITTING ANTENNA; 3 - transmitter-receiver PB-2; 4 - control ZERO ADJUSTMENT - HIGH ALTITUDES; 5 - control ZERO ADJUSTMENT - LOW ALTITUDES; 6 - tester T-1; 7 - control CALIBRATION - LOW ALTITUDES; 8 - control CALIBRATION - HIGH ALTITUDES; 9 - supply cable; 10 - altimeter indicator;  $\Phi-1, \Phi-2$  - radio-frequency cables;  $\bar{H}-1, \bar{H}-2, \bar{B}-1, \bar{B}-2$  - sockets of tester T-1.




Fig. 153. Diagram Showing Connection of Radio Altimeter PB-2 to Tester T-2 for Calibration of Radio Altimeter Readings at the End of Scale on 2nd Band

1 - tester T-2; 2 - tester receptacle; 3 - radio-frequency cable to connect tester T-2 receptacle TRANSMITTING ANTENNA PB-2; 4 - cable connecting tester T-2 to receptacle RECEIVING ANTENNA PB-2; 5 - receptacle RECEIVING ANTENNA; 6 - red mark on adapter; 7 - adapter for connection of receptacle TRANSMITTING ANTENNA to tester T-1 and dummy antenna; 8 - transmitter-receiver PB-2; 9 - receptacle; 10 - receptacle TO INDICATOR; 11 - indicator of radio altimeter; 12 - supply cable; 13 - dummy antenna; 14 - radio-frequency cable.

SECRET  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM



50X1-HUM




Fig. 154. Transmitter-Receiver of Radio Altimeter PB-2




Fig. 155. Control Panel of Radio Range Finder CD-1



Fig. 156. Indicator ПРД-50 of Radio Range Finder CD-1



Fig. 157. Checking Radiation Power of Radio Range Finder  
1 - transmitting antenna CD-1; 2 - power-level indicator; 3 - receiving antenna; 4 - aircraft skin.




Fig. 158. Range Finder Test Instrument КИПД-1  
1 - receptacle for connection to transmitter; 2 - voltmeter; 3 - voltmeter switch; 4 - communication channel selector (MODE OF OPERATION); 5 - scale RANGE-ORBIT; 6 - socket for connection to transmitter antenna (input); 7 - supply switch; 8 - switch RANGE BAND; 9 - cable with T-joint for connection of instrument КИПД-1 to transmitter CD-1; 10 - socket for connection of instrument КИПД-1 to receiver antenna; 11 - radiation indicator; 12 - button CHECK 250 V.




Fig. 159. Test Instrument КИПД-3  
1 - tuning scale FREQUENCY Mc/s; 2 - tuning knob; 3 - socket for connection to receiver antenna; 4 - socket for connection to transmitter antenna; 5 - function switch; 6 - filament voltage control; 7 - supply switch; 8 - indicator; 9 - zero adjustment knob.




Fig. 160. Diagram Showing Connections for Measurement of Range Finder Supply Voltage  
1 - supply receptacle of range finder; 2 - cable with T-joint for connection of instrument КИПД-1 to transmitter CD-1-2; 3 - supply cable CD-1; 4 - converter MA-100.

SECRET  
NO FOREIGN DISSEM

**SECRET**  
**NO FOREIGN DISSEM**




Fig. 161. Course Beacon Simulator KHPM-Φ  
1 - antenna; 2 - channel selector; 3 - indicator; 4 - function switch; 5 - limb for setting phase of modulation voltage; 6 - switch ZERO CHECK - OPERATION; 7 - switch COURSE - AZIMUTH; 8 - supply switch.




Fig. 164. Localizer Receiver KP11-Φ  
1 - button CHECK; 2 - sensitivity control; 3 - control BALANCE.




Fig. 165. Glide-Slope Beacon Simulator ГПРМ-2  
1 - signal level indicator; 2 - R.F. signal level control knob; 3 - antenna; 4 - channel selector; 5 - control knob 150 c.p.s. LEVEL; 6 - socket for connection of simulator to glide-slope receiver; 7 - switch H.F. LEVEL - L.F. LEVEL; 8 - function switch; 9 - control knob 90 c.p.s. LEVEL; 10 - supply switch.



Fig. 162. Control Panel M-50




Fig. 163. Instrument Landing Indicator ПЦП-48  
1 - course pointer corrector; 2 - "black ring"; 3 - glide-slope signalling indicator; 4 - yellow scale sector; 5 - course signalling indicator; 6 - blue sector of course scale; 7 - glide-slope pointer; 8 - glide-slope pointer corrector; 9 - course pointer.




Fig. 166. Glide-Slope Receiver ПР11-2  
- socket for connection of simulator ПР11-2; 2 - cover plate of controls BALANCE and SENSITIVITY.




Fig. 167. Transponder Panel  
1 - light control; 2 - switch READY-RESPONSE; 3 - code switch; 4 - switch DISTRESS SIGNAL; 5 - jacks PHONE; 6 - pilot lamps.



50X1-HUM

**SECRET**  
**NO FOREIGN DISSEM**



**SECRET**  
NO FOREIGN DISSEM

50X1-HUM




Fig. 168. Transmitter-Receiver P2, Inside View.

- 1 - potentiometer R2-4 for adjusting AFC voltage on 1st channel;
- 2 - potentiometer R2-5 for adjusting AFC voltage on 2nd channel;
- 3 - screw for adjusting spark gap P2I on 1st channel; 4 - screw for adjusting spark gap P2II on 2nd channel; 5 - screw for adjusting crystal current on 1st channel; 6 - screw for adjusting crystal current on 2nd channel; 7 - screw for adjusting frequency of 1st channel klystron; 8 - screw for adjusting frequency of 2nd channel klystron.




Fig. 169. Sequence for Screwing In and Out Bolts and Nuts on Units P2 and P12




Fig. 170. Front of Operator's Panel P6

- 1 - button SUPPLY ON; 2 - button SUPPLY OFF; 3 - green pilot lamp to indicate that power is on; 4 - yellow lamp PRESSURE DROP SIGNALLING; 5 - red pilot lamp to indicate that transmitter is on; 6 - button TRANSMITTER ON; 7 - button TRANSMITTER OFF; 8 - switch FREQUENCY I-II; 9 - meter CHECK; 10 - meter SUPPLY; 11 - meter PRESSURE IN TRANSMITTER (ДАВЛЕНИЕ В ПЕРЕДАТЧИКЕ); 12 - meter ANTENNA TILT; 13 - switch AFC - BEACON; 14 - switch CHECK; 15 - switch RANGE KM; 16 - switch SWEEP DELAY KM; 17 - switch COURSE LINE; 18 - switch SECTOR SCANNING; 19 - knob potentiometer POSITION CONTROL R6-7; 20 - knob of potentiometer RECEIVER TUNING R6-8; 21 - knob of potentiometer RANGE MARKER BRIGHTNESS R6-5; 22 - knob of potentiometer "10-70" R6-3; 23 - knob of potentiometer ALTITUDE DELAY (ЗАПЕРКА НА ВЫСОТУ) R6-8; 24 - switch MARKERS; 25 - switch ROTATION; 26 - switch SEARCH; 27 - switch TILT; 28 - scale of potentiometer RANGE; 29 - adjusting screw of potentiometer ADJUSTMENT - 115 V R6-8.




Fig. 171. Navigator-Operator's Panel as Viewed from Wiring Side

- 1 - potentiometer R6-65; 2 - potentiometer R6-57

**SECRET**  
NO FOREIGN DISSEM

**SECRET**  
NO FOREIGN DISSEM



50X1-HUM




Fig. 172. Front of Bomb Aimer's Panel P9  
1 - switch CALIBRATION; 2 - green lamp SUPPLY ON; 3 - red lamp SIGHTING BUTTON ON; 4 - knob of potentiometer SCALE ILLUMINATION R9-22; 5 - scale SLANT RANGE CORRECTION M; 6 - knob of potentiometer SLANT RANGE CORRECTION R9-12; 7 - knob of potentiometer RANGE SCALE R9-2; 8 - knob of potentiometer SPEED SCALE R9-2; 9 - potentiometer for adjusting slant range correction R9-13; 10 - switch SEARCH - AIMING; 11 - knob of potentiometer SPEED ZERO ADJUSTMENT R9-6; 12 - knob of potentiometer SPEED ZERO ADJUSTMENT R9-6; 13 - switch SPEED GENERATOR; 14 - switch ANTENNA TILT; 15 - scale TRACKING SPEED KM/HR; 16 - knob of potentiometer TRACKING SPEED R9-20; 17 - knob of potentiometer POSITION R9-23




Fig. 174. Bomb Aimer's Indicator P8, Right Side View

1 - knob of potentiometer FOCUS R8-6; 2 - knob of potentiometer HORIZONTAL CENTRE R8-4; 3 - adjusting screw of potentiometer DRIFT CORRECTION R8-1; 4 - adjusting screw of potentiometer TRANSVERSE STABILIZATION R8-2.




Fig. 175. Bomb Aimer's Indicator P8, Left Side View




Fig. 173. Bomb Aimer's Panel P9 as Viewed from Wiring Side  
1 - potentiometer R9-31; 2 - potentiometer R9-21; 3 - potentiometer R9-24; 4 - potentiometer R9-17.




Fig. 176. Front Panel of Range Unit P3

1 - adjusting screw of range potentiometer SCALE R3-92; 2 - adjusting screw of step delay potentiometer SCALE R3-53; 3 - adjusting screw of altitude potentiometer SCALE R3-31; 4 - adjusting screw of range potentiometer ZERO R3-94; 5 - adjusting screw of step delay potentiometer ZERO R3-51; 6 - adjusting screw of altitude potentiometer ZERO R3-30; 7 - adjusting screw of frequency division potentiometer "5," R3-8; 8 - switch CALIBRATION - OPERATION; 9 - adjusting screw of frequency division potentiometer "6," R3-22.

**SECRET**  
NO FOREIGN DISSEM

SECRET  
NO FOREIGN DISSEM

50X1-HUM




Fig. 177. Front Panel of Operator's Lock Unit P4  
1 - adjusting screw of potentiometer AFC VOLTAGE R4-107; 2 - adjusting screw of potentiometer RANGE CONTROL R4-42; 3 - adjusting screw of potentiometer SWEEP AMPLITUDE R4-66; 4 - knob of potentiometer RECEIVER GAIN R4-106; 5 - knob of potentiometer LOW LEVEL R4-94; 6 - knob of potentiometer HIGH LEVEL R4-85.




Fig. 178. Inside View of Bomb Aimer's Lock Unit P7  
1 - potentiometer R7-130; 2 - potentiometer R7-40; 3 - potentiometer R7-138; 4 - potentiometer R7-139; 5 - delay line.




Fig. 179. Diagram Showing Connection of Device IB-52 when Determining Duration of Pulse for Automatic Switching of Optical Sight OIB-11P




Fig. 180. Permissible Noise Level at Receiver Output as Plotted against Receiver Sensitivity



Fig. 181. Output Meter MB-4

SECRET  
NO FOREIGN DISSEM

Declassified in Part - Sanitized Copy Approved for Release 2013/02/21 : CIA-RDP80T00246A070800100001-4

**SECRET**  
NO FOREIGN DISSEM

**SECRET**  
NO FOREIGN DISSEM

Declassified in Part - Sanitized Copy Approved for Release 2013/02/21 : CIA-RDP80T00246A070800100001-4