

ALBUM № A-1
АНК-5В autopilot
operating instruction.
/2-nd edition/

secret
Copy No. _____

AIM-5B AUTOPILOT OPERATING INSTRUCTIONS
(2-53 edition)

secret
Copy No. _____

AUG-5B AUTOPILOT OPERATING INSTRUCTIONS

(2-nd edition)

	Page
9. Calibrating the ANA-5B autopilot output signals.....	53
SECTION III. ANA-5B AUTOPILOT STORAGE	58
10. Requirements to the ANA-5B autopilot storage.....	58
11. Periodic checks of the ANA-5B autopilot in storage.....	61
12. Checking the ANA-5B autopilot operation in storage without removing it from the K-1M missile	64
13. Checking the ANA-5B autopilot operation in storage with some units removed from the missile..	71
14. Checking the ANA-5B autopilot when storing it packed in tare..	74
15. Procedure of replacing the ANA-5B autopilot individual units and components.....	72
SECTION IV. ANA-5B AUTOPILOT PRE-FLIGHT TEST..	81
16. Separate checkout of the ANA-5B autopilot	81
17. Combined checkout of the ANA-5B autopilot and K-1M station.....	86
SECTION V. ANA-5B AUTOPILOT TEST BEFORE A FAIL-OFF	89
18. Testing the ANA-5B autopilot by using the carrier-aircraft equipment	89

	Page
9. Calibrating the AIM-5B autopilot output signals.....	53
SECTION III. AIM-5B AUTOPILOT STORAGE	58
10. Requirements to the AIM-5B autopilot storage.....	58
11. Periodic checks of the AIM-5B autopilot in storage.....	61
12. Checking the AIM-5B autopilot operation in storage without removing it from the "K" missile	64
13. Checking the AIM-5B autopilot operation in storage with some units removed from the missile..	71
14. Checking the AIM-5B autopilot when storing it packed in tare..	75
15. Procedure of replacing the AIM-5B autopilot individual units and components.....	72
SECTION IV. AIM-5B AUTOPILOT PRE-FLIGHT TEST..	81
16. Separate checkout of the AIM-5B autopilot	81
17. Combined checkout of the AIM-5B autopilot and E-1M station.....	86
SECTION V. AIM-5B AUTOPILOT TEST BEFORE A TAK-OFF	89
18. Testing the AIM-5B autopilot by using the carrier-aircraft equipment	89

	Page
9. Calibrating the AIM-5B autopilot output signals.....	59
SECTION III. AIM-5B AUTOPILOT STORAGE	58
10. Requirements to the AIM-5B autopilot storage.....	58
11. Periodic checks of the AIM-5B autopilot in storage.....	61
12. Checking the AIM-5B autopilot operation in storage without removing it from the "K" missile	64
13. Checking the AIM-5B autopilot operation in storage with some units removed from the missile..	71
14. Checking the AIM-5B autopilot when storing it packed in tare..	74
15. Procedure of replacing the AIM-5B autopilot individual units and components.....	74
SECTION IV. AIM-5B AUTOPILOT PRE-FLIGHT TEST..	81
16. Separate checkout of the AIM-5B autopilot	84
17. Combined checkout of the AIM-5B autopilot and K-41 station.....	86
SECTION V. AIM-5B AUTOPILOT TEST BEFORE A TAKE-OFF	89
18. Testing the AIM-5B autopilot by using the carrier-aircraft equipment	89

	4
	Page
SECTION VI. A1H-5B AUTOPILOT PERIODIC MAINTENANCE OPERATIONS	93
19. A1H-5B autopilot periodic maintenance operations procedures.....	93
20. Periodic maintenance operations record	94
SECTION VII. A1H-5B AUTOPILOT TEST EQUIPMENT.....	102
21. A1H-5B autopilot set test equipment.....	102
22. A1H-5B autopilot units test equipment	112
APPENDIX	115

P R E F A C E

The "AIR-5B Autopilot Operating Instructions" are intended for the plants, manufacturing "KC" winged missiles, and mechanical personnel of the using organizations.

The "AIR-5B Autopilot Operating Instructions" are the manual for storage, shipment, installation, checks and maintenance of the AIR-5B autopilot within the guaranteed service life.

The main form of storing the AIR-5B autopilot is keeping it in the "KC" winged missile being preserved in accordance with the present instructions KC-05-MK, edition III for preservation and extended storage of the "KC" missile in the depots for one year since the date of arrival to the point of destination.

The complete autopilot equipment may be installed in the "KC" missile or the H-2 gyro unit may be removed from it; in this case this unit is stored in a special metal tare.

The AIR-5B autopilot is permitted to be stored in the "KC" missile in a hangar for 3 months within the entire guaranteed service life.

The AIR-5B autopilot and its individual units which are not installed in the "KC" missile can be stored in the depots packed in special metal tare for one year since the date of arrival to the point of destination.

The AIR-5B autopilot and its individual units can be transported in tare or installed in the "KC" missile.

The requirements for the AUK-5B autopilot shipment are outlined in these instructions. The autopilot installed in the "KC" missile is shipped in accordance with the "KC" Winged Missile Maintenance and Operating Instructions", Book I.

The autopilot must be installed in and removed from the "KC" missile according to the "KC" Winged Missile Maintenance and Operating Instructions" Book I.

The amount and methods of the AUK-5B autopilot checkouts at the "KC" missile manufacturing plant, during an extended storage and also during the pre-flight test and test before a take-off are given in these instructions.

SECTION I


PACKING AND SHIPMENT OF THE ANK-5B AUTOPILOT

I. INSTRUCTIONS FOR PACKING THE ANK-5B AUTOPILOT UNITS IN TARE

1. The tare for the ANK-5B autopilot consists of 2 welded metals cases. Packed in one of the cases are II-1 and II-2 units and in the other - II-4 and II-18MO units and HAP-10A inverters. The cases are made according to drawings No.399.00.00.000 (for II-1 and II-2 units) and No.400.00.00.000 (for II-4, II-18MO units and HAP-10A inverters).

The external view of one of the cases is given in Fig.1. Furnished with the metal case made according to dwg.No.399.00.00.000 is the box (dwg.399.01.00.000) with the plug connectors.

2. The rooms in which the ANK-5B autopilots are packed should meet the requirements indicated in para.10.



Back the II-1 control panel and II-2 gyro unit in order as follows:

Install the II-1 control panel on the shock mounts of the mounting (1, Fig. 2) and secure it by 4 screws with nuts. Then the cables plug connectors with two sheets of oil paper (ГОСТ 1760-51) and herringbone tape and bind the tape with linen threads.

Insert the plug connectors in the holders (3). Secure the cables by the tape with the button (4). Fasten the control panel filter in the clamp (6).

Install the II-2 gyro unit on the shock mounts (2) of the mounting (1, Fig. 3) and secure by 3 bolts. Attach the II-2 gyro unit plug connectors No. 31, 39, 42 (manufactured specially for the II-2 gyro units) 43, 45 and 47 to the flanges (3) using their coupling nuts. Fasten plug connector No. 35 to the flange (4) by a coupling nut.

Cover the bent portions of cables No. 39, 42 and 43 with a split chlorvinyl tubes (7, dia. 34) and secure them by the tape with the button to the mounting. (8)

Secure cables No. 31, 35 and 44 by the tape with the button (9), cover them with the split chlorvinyl tube (10) and fasten them to plug connector No. 35 by the tape with the button (11). Cover cables No. 45 and 47 with the split chlorvinyl tube (12) and fasten them to plug connector No. 45 by the tape with the button (10, Fig. 3).

Secure the II-2 gyro unit filter to the mounting with the II-1 control panel by means of a clamp and plug connector No. 44 by means of its coupling nut - to the flange located on the same mounting.

Move the mountings with the H-I and U-2 units installed along the guide rails into the case placed on the floor; see that the mountings are in the vertical position. The mountings must move along the rails without shaking and sticking. If necessary, bend the guide rails.

Secure cables No.45 and 47 to cable No.44 by the tape with the button (1) and place them in the box (2, Fig.4) manufactured according to dwg. No.399.01.00.000, with the plug connector mating parts furnished with the autopilot set.

NOTE: The chlorvinyl tubes may be substituted by chlorvinyl tape.




Fig.2. H-I Control Panel-to-Mounting
Attachment




Fig.3. H-2 Gyro Unit-to-Mounting Attachment




Fig.4. H-1 and H-2 Units in Tare

Prior to installation, place in each mounting a bag (5, Fig.2 and 3) with "KOH" silica gel dehydrator, 500 gr. (FOCI 3956-47) and in the H-2 gyro unit mounting a bag (6, Fig.3) with blue silica gel indicator, 15-20 gr.

Place the silica gel bags so that they cannot shift during shipment. It is recommended to tie the bags to the cables or mounting with the H-2 gyro unit by woven threads or fasten them by tapes with buttons.

- NOTES:
1. When placing the bags in the cases silica gel dehydrator humidity must not exceed 2%.
 2. The silica gel dehydrator type "KOH" can be substituted by silica gel type "KOH" (FOCI 3956-47).
 3. If a cartridge with silica gel - indicator is placed in the case, the bag (5) with silica gel indicator should not be put in the case.
 4. When packing the H-2 gyro unit (manufactured with plug No.42) which is incorporated in the autopilot set installed in the H-2 missile, place in the case the cap for the above mentioned plug; attach the plug to the clamp (6, Fig.2).

On accomplishing the packing, furnish the case with a packing list of a given standard, close the case with the cover, fasten the latter with 14 bolts, secure the case with two seals 1052A55 at two corners located obliquely and mark with an indelible black paint the number of the autopilot set on the right upper corner of the cover and top wall of the case.

Tighten the HAF-10A inverters (2 ea) to the mounting (1, Fig.7) by the screws with nuts, wrap the end caps and plug connectors of the inverters with two sheets of oil paper (Fig.7) and tie the oil paper with linen threads.

Move the mountings with the H-4 servo units and H-18M0 timer and mounting with the HAF-10A inverters into the case using the guide rails (Fig.8).

The mounting should move along the guide rails without shaking and sticking.

If necessary, bond the rails. The mountings must be moved into the case placed on the floor in the vertical position.



Fig. 8. H-4 Servo Units and H-18M0 Timer to Mounting Attachment



Fig.7. HAI-IGA Inverter-to-Mounting Attachment




Fig.8. R-1 Servo Units, H-18MO Timer and HAI-IGA Inverters Installed in Rack.

Before installing the mountings, place on the mounting with H-4 servo units and H-18MO timer two bags (5) with "KCM" silica gel dehydrator, 200 gm. each and the bag (6) with a blue silica gel - indicator, 15-20 gm. The bags must be placed so that they are not moved during transportation. It is permitted to tie the bags to the cables with linen threads or secure them by tapes with buttons (Fig.6).

- NOTES:
1. When placing the silica gel dehydrator bags in the tare, silica gel humidity must not exceed 2%.
 2. The silica gel type "KCM" may be substituted by silica gel type "MCM", "HCT" and "LCT".
 3. If a special cartridge with silica gel-indicator is installed in the case, the bag (6) with silica gel-indicator must not be placed in the case.

On accomplishing the packing, furnish the case with the packing list of a given standard, close the case with the cover, attach the case cover with 14 bolts, secure the case with two seals 1053A55 at two corners located obliquely (Fig.1) and mark with an indelible black paint the number of the autopilot set in the right upper corner of the cover and upper wall of the case.

Test the case welded seams tightness and tight fitness of the cover in the same way as for the case with H-1 and H-2 units (see step 3).

NOTE: When packing the autopilot in the using organization it is permitted, as an exception, not to put the silica gel bags in the case and to test the case for airtightness.

2. INSTRUCTIONS FOR PACKING THE AIM-53 AUTOPILOT UNITS
IN SHIPPING BOXES

1. To transport the AIM-53 autopilot set or its individual units, the metal cases are additionally placed in the wooden shipping boxes manufactured according to dwg. No.464.00.00.000.

2. When packing the autopilot set in the shipping boxes, proceed as follows:

Open the upper cover of the shipping box. Carefully, without jerks and shocks, place the metal ^{case} in the shipping box so that the case position would correspond to the inscriptions made on the case.

Placed between the walls of the shipping box and metal case are plywood and felt spacers to prevent the metal case from shifting inside the wooden box (Fig.9).

Close the upper cover, secure the box with four iron strips and two seals 1053A55.

On accomplishing the packing, mark with an indelible black paint the number of the autopilot set in the right upper corner of the cover.

NOTE: When packing the H-2 gyro unit incorporated in the autopilot set installed in the "KC" missile, additionally mark on the case cover the number of the "KC" missile in which the H-2 gyro unit is to be installed.




Fig.9. Packing Case in a Shipping Box

3. AH-1B AUTOPILOT UNPACKING INSTRUCTIONS

1. When unpacking the shipping boxes, proceed as follows:

Check for presence of seals on the box. Remove the iron strips and upper cover of the shipping box.

Take out the plywood and felt spacers placed between the wooden box and metal case. Carefully remove the metal case from the wooden box so that the metal case position would correspond to the inscriptions made on the case.

2. Unpack the packing cases with the H-1 and H-2 units as follows:

Check the case for freedom from damages and for presence of seals.

Break the seals and unscrew 14 bolts attaching the ^{wall}~~side~~.
 Make sure that the packing list is furnished. Check for presence of units and their numbers according to the packing and completing lists.

Inspect the silica gel-indicator. If the silica gel-indicator has become pink, replace the silica gel-indicator and silica gel dehydrator before a repeated packing.

NOTE: The autopilot units stored in the cases with pink silica gel-indicator should not be subjected to special checks; the units serviceability is determined during the next periodic check.

Remove the tape with the button securing cables No.45 and 47 to cable No.44.

Simultaneously take the mountings with the H-1 and H-2 units out of the case so that the units would be in the horizontal position.

Disconnect the H-2 gyro unit plug connector No.44 from the flange located on the mounting with the H-1 unit and release the H-2 gyro unit filter from the clamp located on the same mounting.

Remove the tapes with the buttons, securing the cables and unscrew the remaining plug connectors of the H-2 gyro unit from the mounting flanges.

Remove the silica gel bags.

Unscrew 3 bolts and remove the H-2 gyro unit from the shock-mounts of the mounting. Move the mounting in the case along the guide rails. Unscrew the screw of the clamp, release the H-1 control panel filter and take out the H-1

control panel plug connectors from the holders. Remove the tapes with buttons securing the cables.

Remove the herringbone tape and oil paper from the plug connectors.

Unscrew four screws and remove the H-1 control panel from the mounting shock-mounts. Move the mounting in the case along the guide rails.

Attach the side wall by 2 bolts and place the remaining 12 bolts inside the case.

3. Unpack the cases with the H-4 servo units, H-18MC timer and HAP-12A inverters as follows:

Check the case for freedom from damages and for presence of seals.

Break the seals and unscrew 14 bolts attaching the side wall. Make sure, that the packing list is furnished. Check the units and their numbers according to the packing and completing lists. Inspect the silica gel indicator. If the silica gel has become pink, replace the silica gel-indicator and silica gel-dehydrator before a repeated packing.

NOTE: The autopilot units, stored in the cases with a pink silica gel, should not be subjected to special checks; the units serviceability is determined during the next periodic check.

Remove the mounting with the H-4 servo unit and H-18MC timer so that the units would be in the horizontal position. Remove the silica gel bags.

Unscrew the screws of the clamps, release the H-4 servo unit filters and take out the H-4 servo unit plug connectors from the holders.

Remove the tapes with buttons which secure the cables. Cut the threads, remove the herringbone tape and oil paper from the plug connectors.

Unscrew four screws and remove the П-18M0 timer from the shock-mounts. Unscrew 4 bolts and remove the П-4 servo units from the mounting. Move the mounting into the case along the guide rails.

Take the mounting with the ИАП-10А inverters out of the case. Cut the threads and remove oil paper from the end caps and plug connectors of the inverters. Unscrew 4 screws and remove the inverters from the mounting. Move the mounting into the case along the rails.

Attach the side wall by 2 bolts and place the remaining 12 bolts inside the case.

4. АИК-5В AUTOPILOT SHIPMENT

1. The АИК-5В autopilot and its individual units which are not installed in the "KC" winged missile must be shipped in a box according to the requirements indicated in par. 1 and 2, these Instructions.

2. When carrying, loading and shipping the boxes see that the position of the boxes corresponds to the inscriptions made on them. The boxes must be carefully carried and loaded without jerks and shocks.

When shipping, install and attach the boxes so as to protect them from falls, displacement and impacts against each other. Do not transport the autopilot and its individual units

7. The attachment parts must ensure secure attachment of the autopilot units in the missile through out the entire service life. The autopilot units attachment parts and plug connectors must be securely locked.

8. Install and remove the autopilot units only with the electrical system de-energized.

9. The requirements for the autopilot unit installation and removal from the missile are given in the "AG-100" Missile Maintenance and Operating Instructions, Part 1.

6. CHECKING THE AIR-100 SIMULATOR BEFORE THE TEST

1. Inspect the working area. Check the condition of seals and insulation. Proceed in accordance with the instructions given in par. 3. Visually inspect all the units. Check the external surfaces of the units and cables for freedom from damage and traces of corrosion.

When checking the AIR-100 servo units, proceed as follows:

2. Return the AIR-100 servo units to the AIR-100 simulator to its place each -4 unit only. Place it on the simulator base and secure it by the lock.

3. Set the "POWER" switch to the "ON" position in the "OFF" position.

4. Connect a supply of 24V DC to the control panel.

5. Connect the plug connector of the AIR-100 servo units to the control panel by the plug connector.

Set the "PANEL" selector switch in the "II-4" position, "WINDINGS SELECTOR SWITCH" - in the "0" position and "SIGNAL" selector switch-in the "60mA" position. Set the "SIGNAL" knob in the "0" position.

4. Switch on the "FEEDBACK" and "POWER" switches. The II-4 servo unit outlet shaft should move to the zero position. Attach the RHA-3 simulator pointer to the outlet shaft, aligning the pointer with the scale zero division. Set the "POWER" switch in the "OFF" position.

Manually turn the servo unit outlet shaft in any direction to the stop. Switch on the "POWER" switch, in this case the II-4 servo unit outlet shaft must move to the zero position to within $\pm 0.25^\circ$; self-oscillations should not appear. Repeat the check with the servo unit outlet shaft turned in the opposite direction.

5. Set the "FEEDBACK" switch in the "OFF" position, the "WINDING SELECTOR SWITCH" - in the "I" position and the "SIGNAL" selector switch-in the "3mA" position (for the KH-I control panels, whose "SIGNAL" milliammeter has the scales of "3-0.3mA", "60-0-70mA"). Smoothly turn the "SIGNAL" knob to the right, increase the control signal till the servo unit outlet shaft starts steadily rotating and moves to the limit switch (turning through an angle of $10-11^\circ$ from the zero position).

The control signal value (in mA) is the unit sensitivity.

When using the KH-I control panel whose "SIGNAL" milliammeter has the scales of "1-0-1mA", "1.5-0-1.5 mA", "2.5-0-2.5mA" and "60-0-60mA", check as described above except for the position of the "SIGNAL" selector switch which must be set before the check in the "1mA" position. If, when turning the "SIGNAL" knob, the

Set the "PANEL" selector switch in the "1" position, "WINDINGS SELECTOR SWITCH" - in the "0" position and "SIGNAL" selector switch - in the "COMA" position. Set the "SIGNAL" knob in the "0" position.

4. Switch on the "SERVO" and "POWER" switches.

The H-4 servo unit outlet shaft should come to the zero position. Attach the H-4 simulator pointer to the outlet shaft, aligning the pointer with the scale zero division. Set the "POWER" switch in the "OFF" position.

Manually turn the servo unit outlet shaft through one cycle to the stop. Switch on the "POWER" switch. The servo unit outlet shaft must move to the zero position within $\pm 0.25^\circ$ self-oscillation. Repeat the check with the servo unit outlet shaft turned in the opposite direction.

5. Set the "SIGNAL" selector switch in the "1mA" position. The "POWER" and "SERVO" switches must be in the "ON" position. The "SIGNAL" selector switch is on the control panel, whose "SIGNAL" knob is on the scale "3-0.3mA", "60-0-70mA". When turning the knob to the right, increase the control signal. The outlet shaft starts steadily rotating at a rate of 100 rpm (turning through an angle of 180° from the zero position).

The control signal value in mA is well controlled.

When using the H-4 control panel whose "SIGNAL" knob has the scales of "3-0.3mA", "60-0-70mA", "20-0-20mA" and "60-0-60mA", check as described here except for the position of the "SIGNAL" selector switch which must be set before the check in the "1mA" position. If, when turning the "SIGNAL" knob, the

Set the "PANEL" selector switch in the "OFF" position, "WINDINGS SELECTOR SWITCH" - in the "0" position and "SIGNAL" selector switch - in the "000A" position. Set the "SIGNAL" knob in the "0" position.

4. Switch on the "SERVO" and "MOTOR" switches. The H-4 servo unit outlet shaft should move to the zero position. Attach the H-4 camulator pointer to the outlet shaft, aligning the pointer with the scale zero direction, set the "POWER" switch in the "OFF" position.

Manually turn the servo unit outlet shaft in any direction to the stop. Switch on the "SERVO" switch. The servo unit H-4 servo unit outlet shaft must move to the zero position to within $\pm 0.2^\circ$; self-oscillations should not occur. Repeat the check with the servo unit outlet shaft moving in the opposite direction.

5. Set the "PANEL" selector switch in the "OFF" position, the "WINDINGS SELECTOR SWITCH" - in the "0" position, and the "SIGNAL" selector switch in the "OFF" position. On the control panels, whose "SIGNAL" dial is set to the position of "3-0.3mA", "60-0-70mA", proceed as follows: Turn the knob to the right, increase the control signal until the outlet shaft starts steadily rotating in the "ON" direction (turning through an angle of 90° to 180°).

The control signal should be increased until the outlet shaft has the speed of 60 ± 5 rpm. When using the "SERVO" switch, the control signal should be set to "60-0-60mA". When using the "MOTOR" switch, the control signal should be set to "60-0-60mA". The control signal should be set to "60-0-60mA" in the "OFF" position.

Set the "TRAINING" selector switch in the "0" position, the "TRAINING SWITCH" in the "0" position and "SIGNAL" selector switch in the "0" position. The "SIGNAL" knob in the "0" position.

4. Switch on the "POWER" and "SIGNAL" switches. The H-4 servo unit outlet shaft starts to move in the "0" position. Attach the H-4 indicator pointer to the outlet shaft, aligning the pointer with the scale zero division. Set the "POWER" switch in the "OFF" position.

Manually turn the servo unit outlet shaft to the stop. Switch on the "POWER" switch, and allow the H-4 servo unit outlet shaft to move to the zero position to within $\pm 1.0^\circ$; self-oscillations are not allowed. Repeat the check with the servo unit outlet shaft turned in the opposite direction.

5. Set the "TRAINING" selector in the "0" position, the "TRAINING SWITCH" in the "0" position, and the "SIGNAL" selector switch in the "0" position. On the control panels, whose "SIGNAL" indicator has the scales of "0-0.5mA", "0-0-70mA". Control signal is sent to the right, increase the control signal until the servo unit outlet shaft starts steadily rotating and moves to the "1" position (turning through an angle of $10-11^\circ$ from the zero position).

The control signal value (in mA) is the self-oscillation. Then using the H-4 control panel whose "SIGNAL" indicator has the scales of "0-1mA", "0-0-10mA", "0-0-100mA" and "60-0-60mA", check as described above except for the position of the "SIGNAL" selector switch which must be set before the check in the "1" position. If, when turning the "SIGNAL" knob, the

control signal value, at which the shaft starts rotating, exceeds 1mA, it is necessary to set the "SIGNAL" selector switch in the "1.5mA" position and if these values are exceeded, set the selector switch in the "2.5mA" position.

Repeat checking with the "SIGNAL" knob turned to the left.

The servo unit outlet shaft should move to the opposite limit switch.

When setting, in turn, the U-1 SERVO UNIT in the positions "1", "2" and "3" check the servo unit sensitivity with the other switches, with the "LIMIT SWITCH" in the "1", "2" and "3" positions. The servo unit sensitivity must be 0.95-1.05 mA. per 1 degree - 0.95-1.05 mA.

6. Switch on the "LIMIT" switch, with the selector switch in the "1" position, and the "LIMIT SWITCH" in the "1" position.

Gradually increase the control signal to bring down the "SIGNAL" knob to the stop. The outlet shaft should move smoothly without jerks.

Repeat the check when setting the signal to the sensitivity. Set the "LIMIT" switch in the "2" position, disconnect the U-1 servo unit plug, connector from the control panel.

7. Check the other two U-1 SERVO UNITS in the same manner as in the similar way.

Check the U-1 SERVO UNIT in the same manner as above.

8. Set the "LIMIT" and "U-1 SERVO UNIT" switches of the control panel in the "OFF" position and the "LIMIT SWITCH" in the "0" position.



Connect supply of 26 V D.C. to the control panel.

Connect the control panel cable to the plug connector of one of the HAI-1BA inverters.

9. Switch on the "POWER" and "LOAD" switches.

The gyro motors installed in the control panel must start rotating. After 3 min. check by the control panel D.C. ammeter the current drawn by the inverter which under normal conditions must not exceed 3.5 A.

When checking the autopilot at a temperature different from the normal temperature within a range of -35°C to $+50^{\circ}\text{C}$, increase the above mentioned tolerance by 0.06A for each 10°C of the temperature change either side from normal.

10. Set the "PHASE SELECTOR SWITCH" in the "1" position. Check A.C. voltage generated by the inverter using the control panel A.C. voltmeter and the alternating current generated by the inverter using the control panel A.C. ammeter. Under normal conditions voltage should be equal to 36 ± 4 V and current should not exceed 0.5 A.

When checking at a temperature different from the normal temperature within a range of -35° to $+50^{\circ}\text{C}$, increase the 4 V tolerance of the voltmeter readings by 0.2 V for every 10°C of the temperature change either side from normal.

In the temperature range indicated below and other similar conditions the tolerance for the ammeter, must be increased:


at $T = +20$ to -35°C by 0.051 A

at $T = +20$ to $+50^{\circ}\text{C}$ by 0.012 A.

Set the "PHASE SELECTOR SWITCH" in the "2" and "3" positions and check voltage and current in two other phases of the inverter.

and No 12 to A001-55 output lot specifications

A-1000 timer cable




∴ Plug connectors are arbitrarily designated.
E (example)

— plug connector No. 35.

secret

ent No. 12 to ANK-5B outopilot specifications




NOTE: Plug connectors are arbitrarily designated.
 Symbol (example)  - plug connector No. 35.

Fig. 10. Block Diagram of AHG-5B autopilot Uni.s Connection with Test Set.

Attach the KHA-3 simulator pointers to the E-4 servo unit outlet shafts and set the pointers at zero points on the simulator scales.

NOTES: a) Before energizing the autopilot, check the "CENTERING" potentiometer wipers position on the E-1 control panel; in this case the slot on the potentiometer shaft must be against the index on the panel cover.

b) After illumination of the "ELEVATOR" warning lights but not earlier than 3 min. after power is applied, set the selector switch on the E-1 panel in the "RIGHT" position. Set the "ELEVATOR" knob of the E-1 panel in the "UP" position, the millimeter pointer on the E-1 panel must deflect "UP", approx. one division. Press the "CENTERING" button on the KHA-1 control panel, the "ELEVATOR" warning light must go out and the "UNDESIRABLE" warning light must come on, the elevator simulator pointer must deflect 1°42' to the left. Turn the "ELEVATOR" knob of the E-1 panel in turn to the left and to the right. The pointers of the elevator simulator and millimeter on the E-1 panel must be motionless. Set the "ELEVATOR" knob on the E-1 panel in the zero position and change the selector switch from the "RIGHT" position to the middle position.

cut off power supply on the 10-11 control panel and after 5-10 sec. reenergize the autopilot again. Wait, until the "BANK LIGHT" warning light comes on.

- c) After the "BANK LIGHT" warning light is illuminated, repeat the check according to step 1 with the pre-set unit knob on the 10-11 panel set in one of 1°, 4°, 7° and 10° position. In this case the vertical surface simulator must be set at within ±50% of the values indicated by the pre-set unit of the 10-11 panel.

Repeat the check for each of the pre-set unit knob set down in the 1°, 4°, 7°, 10° and 13° positions, in each case the bank indicator on the 10-11 panel must have shown the vertical surface simulator must def. down to the right (as viewed from the servo unit side).

NOTE:

1. When turning the 10-11 panel pre-set unit knob to the left or to the right in the range of 0° to 2°, the "BANK LIGHT" warning light may remain illuminated.
2. When switching over to the 10-11

the air power supply on the 30-1 control panel and after 5-10 sec. energize the autopilot again. Wait, with the "BASES" warning light comes on.

- e) After the "BASES" warning light is illuminated, repeat the check according to step "d" with the pre-set unit knob on the 11-2 panel set in one of the 1°, 4°, 5° and 6° position. In this case the control surface simulator must deflect to within $\pm 3\%$ of the value indicated by the pre-set unit of the 11-2 panel.

Repeat the check with the 11-2 panel pre-set unit knob set down in the 1°, 2°, 3°, 4°, 5° and 6° positions, in which case the trim indicator on the 11-2 panel must move down and the control surface simulator must deflect to the right (as viewed from the servo unit side) and).

- 11-3. 1. When turning the 11-2 panel pre-set unit knob to the left or to the right in the range of 0° to 2°, the "BASES" warning light may remain illuminated.

2. When switching over to the 11-17M

simulator, the direction indicator on the BOARD panel is inoperative.

15. After the "WARNING" warning lights come on (but not earlier than 3 min. after power is supplied) set the "BOARD WARNING" indicator on the control panel in the "BOARD ON" position and select on the "CHECK" switch.

The "BOARD ON" and "CHECK" warning lights must come on. Sharply deflect the H-3 gyro unit in direction; at the instant of turning the H-3 gyro unit, the H-4 rudder servo unit outlet shaft must turn. Repeat the check when turning the H-3 unit in the opposite direction.

Perform similar checks when turning the H-2 gyro unit in each and every direction.

The direction of the H-3 servo unit starts rotation must correspond to Table No. 1. The pointers of the control panel position indicators, when the H-2 gyro unit is turned in the directions indicated in Table No. 1, must move to the left.

Table No. 1.

Channel	Direction of H-3 gyro unit turn	Direction of outlet shafts rotation		
		H-3 rudder servo unit	H-4 elevator servo unit	H-4 aileron servo unit
Direction	to the right	counter-clockwise	-	-
Pitch	up	-	clockwise	-
Roll	to the right	-	-	clockwise

NOTE: After the H-3 gyro unit is stopped, the H-4 servo unit outlet shafts must return to the zero position to within $\pm 0.25^\circ$.

15. Fully turn the "PITCHER" knob on the control panel to the "RIGHT". The H-4 rudder servo unit outlet shaft must smoothly, without jerks, turn clockwise and the H-4 aileron servo unit outlet shaft - counterclockwise. Fully turn the "PITCHER" knob to the "LEFT". The H-4 rudder servo unit outlet shaft must smoothly, without jerks, turn counterclockwise and the H-4 aileron servo unit outlet shaft - clockwise. Set the "PITCHER" knob in the zero position.

Fully turn the "ELEVATOR" knob on the control panel to the "UP" position.

The H-4 elevator servo unit outlet shaft must smoothly, without jerks, turn counterclockwise. Fully turn the "ELEVATOR" knob to the "DOWN" position. The H-4 elevator servo unit shaft must smoothly, without jerks, turn clockwise. Set the "ELEVATOR" knob in the zero position and the "CHECK" switch in the "UP" position. Wait until the H-4 servo units outlet shafts move to the zero position and "HAZARD ZERO" warning lights come on.

17. Set the "PITCHER SELECTOR SWITCH" in the "REC-17M SIMULATOR" position. The "REC-17M SIMULATOR" warning light must become illuminated. Press the "UNCOUPLING" button on the control panel and simultaneously start the stop-watch; in this case the "CASSETT" warning light must go out and "UNCOUPL" warning light must come on. 2-3 sec. after the "UNCOUPLING" button is pressed, the H-4 elevator servo unit outlet shaft must turn counterclockwise through an angle of $9-9.5^{\circ}$ and 40-42 sec. after the button is pressed, the outlet shaft must return to the zero position to within $\pm 0.55^{\circ}$. Perform the check twice. When uncoupling for the first time, check the H-4 servo

power of 28.6 V D.C. to the control panel. Set the "PANEL" selector switch in the "H-4" position, the "WINDING SELECTOR SWITCH" - in the "0" position and the "SIGNAL" selector switch - in the "COM" position. Set the "SIGNAL" knob in the "0" position.

3. Switch on the "POWER" and "FEEDBACK" switches, in this case the H-4 aileron servo unit shaft must turn to the zero position.

Check the ailerons position. If the ailerons are deflected from the neutral position (i.e. the ailerons neutral position does not correspond to the zero position of the H-4 servo unit) set the ailerons in the neutral position by changing the rod length using the adjustment elements.

4. Set the "FEEDBACK" switch in the "OFF" position and "WINDING SELECTOR SWITCH" - in the "I" position. Slowly rotating the "SIGNAL" potentiometer knob, first in one and then in ^{the} other side of zero position, determine the ailerons maximum angle of deflection (till the H-4 servo unit limit switches are actuated) which must be within ± 9.5 to 11.5° from the neutral position.

5. Set the "SIGNAL" knob in the "0" position, switch on the "FEEDBACK" switch and check that the ailerons are set in the neutral position again; in this case permissible angle of the ailerons deflection from the neutral position is up to 0.25° .

6. Set the "POWER" switch in the "OFF" position and manually deflect the ailerons in either side to the stop; then switch on the "POWER" switch, in this case the ailerons

must move to the neutral position and self-oscillation must not occur.

Repeat the check with the ailerons deflected to the opposite side. Set the "POWER" switch in the "OFF" position and disconnect the II-4 aileron servo unit plug connector from the control panel.

7. Check the II-4 rudder and elevator servo units for proper installation (steps 2-6).

NOTE: The elevator neutral position is the deflection through $2.5-3^{\circ}$ up from the geometric neutral position. Further, this position of the elevator is called "ZERO" position.

8. TESTING THE ANK-5B AUTOPILOT AFTER INSTALLATION IN THE "KC" MISSILE

1. To check the ANK-5B autopilot after installing it in the "KC" missile, remove the II-2 gyro unit from the missile irrespective of the preservation to which the given "KC" missile will be subjected after it is accepted by the Customer.

2. Install the II-2 gyro unit on the KIA-5 turn table according to the instructions given in step 12, par.6.

NOTE: It is permitted to install the II-2 gyro unit on the KIA-5 turn table without removing the gyro unit from the mounting.

3. Place the II-2 gyro unit secured to the turn table at a distance of 1-2.5 m. from the access door in the fuselage bottom section between frames 14 and 18.

NOTE: When installing the turn table see that it does not slide on the base.

4. Connect the H-2 gyro unit plug connectors observing the numbers on the plug connectors and the autopilot wiring diagram (Fig.11), in this case:

a) connect the H-2 gyro unit receptacles No.31, 35,39,43 and 47 to the mating plugs of the missile wiring system through the connecting cables;

b) connect the H-2 gyro unit receptacle No.44 to the mating plug of the HIA-1 control panel through the connecting cable; the HIA-1 control panel plug connector No.43 through the connecting cable - to the plug connector No.36 used for checking the autopilot installed in the missile and the H-2 gyro unit plug connector No.45 - to the HIA-1 and H-2 control panels through the connecting cable according to the block diagram given in Fig.10.

NOTES:

1. Do not connect plug connectors when the system is energized.
2. Connect the autopilot to the missile and energize the electrical system to check it only after the autopilot wiring system is approved by the Missile Inspection Department and by the Center for checking the autopilot operation, proceed as follows:

Supply power of 28 ± 0.5 V d.c. to the missile electrical system switch on the "POWER" switch on the control console. In this case the HIA-1 indicator lights and the "CHECK" warning lights and (no later than 10 seconds) the "CHECK" warning light come on. Do not touch the autopilot wiring system.

The rudder and ailerons must be set in the neutral positions to within $\pm 0.5^\circ$ and the elevator must be set $2.5-3^\circ$ up from the geometric neutral position (further, this position of the elevator is called a "ZERO" position). The control surfaces position indicators pointers must be in the middle positions.

a) After the "BASES ZERO" warning lights become illuminated, but not earlier than 3 min. after power is supplied, set the "B" selector switch on the III-A control panel in the "TO THE RIGHT" position. Set the pre-set unit knob on the III-A control panel in the position 4 divisions down. The pointer of the milliammeter on the III-A panel must deflect down approx. 4 divisions. The "BASES ZERO" warning light on the KOLA-1 control panel must go out. Press the "UNCAGING" button; the elevator must move through an angle of $4^\circ \pm 1^\circ 24'$ down from the initial position.


Turn the pre-set unit knob on the III-A control panel "UP", "DOWN" and then set it in the zero position.

The elevator must be motionless. Set the selector switch on the III-A control panel in the middle position.

De-energize the autopilot. Repeat the check with the pre-set unit knob set in the 3° and 6° positions.


b) Repeat the check as specified in step "a" with the pre-set unit knob set 4° "UP". In this case the elevator must move through an angle of $4^\circ \pm 1^\circ 24'$ up.

289



- to TKC System
see dwg. KC-7406-10
- 2) Test plug connector WIP48NK249W2
- 3) П-4 servo unit (ailerons)
- 4) П-4 servo unit (rudder)
- 5) П-4 servo unit (elevator)
- 6) Filter
- 7) П-18M0 timer
- 8) П-2 gyro unit
- 9) Cable No. 9
- 10) Cable No. 1
- 11) K-1-13M unit
- 12) Cable No. 3
- 13) ПAГ-1ΦA inverter
- 14) Cable No. 2
- 15) П-1 control panel
- 16) ПП-2 relay
- 17) K-20A contactor
- 18) Junction box (see dwg. 7201-00)

Fig. 11. KC-738 Autopilot Wiring Diagram



- 1) Cable N. 11/4
to TKC System
see dwg. KC-7406-10
- 2) Test plug connector W/P48NK249W2
- 3) 11-4 servo unit (ailerons)
- 4) 11-4 servo unit (rudder)
- 5) 11-4 servo unit (elevator)
- 6) Filter
- 7) 11-18M0 timer
- 8) 11-2 gyro unit
- 9) Cable No. 9
- 10) Cable No. 1
- 11) K-1-13M unit
- 12) Cable No. 3
- 13) 11A1-10A inverter
- 14) Cable No. 2
- 15) 11-1 control panel
- 16) 11-2 relay
- 17) K-20A contactor
- 18) Junction box (see dwg. 7201-00)

Fig. 16. 11-10 Autopilot Wiring Diagram

4. If two stop-watches are available check the programmed operation at a single switching-on of the H-18M0 timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-2 gyro unit through an angle of $\pm 45^\circ$ in yaw, $\pm 25^\circ$ in pitch and $\pm 40^\circ$ in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of 10° in the direction opposite to that checked. Then, one minute after the auto-pilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-2 unit in pitch within $\pm 25^\circ$.

Table No.4

Channel	Direction of free gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

4. If two stop-watches are available check the programmed operation at a single switching-on of the H-18MO timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-2 gyro unit through an angle of $\pm 45^\circ$ in yaw, $\pm 25^\circ$ in pitch and $\pm 40^\circ$ in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of 10° in the direction opposite to that checked. Then, one minute after the auto-pilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-2 unit in pitch within $\pm 25^\circ$.

Table No.4

Channel	Direction of free gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

4. If two stop-watches are available check the programmed operation at a single switching-on of the H-18M0 timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-2 gyro unit through an angle of $\pm 45^\circ$ in yaw, $\pm 25^\circ$ in pitch and $\pm 40^\circ$ in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of 10° in the direction opposite to that checked. Then, one minute after the autopilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-2 unit in pitch within $\pm 25^\circ$.

Table No.4

Channel	Direction of gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

4. If two stop-watches are available check the programmed operation at a single switching-on of the H-18MO timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-2 gyro unit through an angle of $\pm 45^\circ$ in yaw, $\pm 25^\circ$ in pitch and $\pm 40^\circ$ in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of 10° in the direction opposite to that checked. Then, one minute after the auto-pilot is unengaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-2 unit in pitch within $\pm 25^\circ$.

Table No.4

Channel	Direction of free gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

4. If two stop-watches are available check the programmed operation at a single switching-on of the H-18MO timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-2 gyro unit through an angle of $\pm 45^\circ$ in yaw, $\pm 25^\circ$ in pitch and $\pm 40^\circ$ in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of 10° in the direction opposite to that checked. Then, one minute after the auto-pilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-2 unit in pitch within $\pm 25^\circ$.

Table No.4

Channel	Direction of gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

4. If two stop-watches are available check the programmed operation at a single switching-on of the H-18MO timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-2 gyro unit through an angle of $\pm 45^\circ$ in yaw, $\pm 25^\circ$ in pitch and $\pm 40^\circ$ in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of 10° in the direction opposite to that checked. Then, one minute after the auto-pilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-2 unit in pitch within $\pm 25^\circ$.

Table No.4

Channel	Direction of gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

8. If two stop-watches are available check the programmed operation at a single switching-on of the H-18MO timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-2 gyro unit through an angle of $\pm 45^\circ$ in yaw, $\pm 25^\circ$ in pitch and $\pm 40^\circ$ in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of 10° in the direction opposite to that checked. Then, one minute after the autopilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-2 unit in pitch within $\pm 25^\circ$.

Table No.4

Channel	Direction of H-2 gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

4. If two stop-watches are available check the programmed operation at a single switching-on of the II-18MO timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the II-2 gyro unit through an angle of $\pm 45^\circ$ in yaw, $\pm 25^\circ$ in pitch and $\pm 40^\circ$ in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the II-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of 10° in the direction opposite to that checked. Then, one minute after the autopilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the II-2 unit in pitch within $\pm 25^\circ$.

Table No.4

Channel	Direction of gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

10. Set the "CHECK COMMANDS POSITION" in the "2-14 SIMULATOR" position. The "2-14 SIMULATOR" warning light must come on. Switch on the "COMMAND No.1" switch on the control panel. The "COMMAND No.1" warning light must become illuminated. When command No.1 is sent, the control surfaces may deflect from the position, occupied by them before the command is sent, through the angles within $\pm 1.6^\circ$ (elevator and ailerons) and $\pm 0.3^\circ$ (rudder).

Fully turn the "RUDDER" knob on the control panel to the "RIGHT". The rudder must smoothly, without jerks, deflect to the right and the right aileron - up. Set the "RUDDER" knob in the zero position; in this case the rudder and ailerons must move to the neutral position.

Repeat the check with the "RUDDER" knob turned to the "LEFT".

Fully turn the "ELEVATOR" knob on the control panel to the "UP". The elevator must smoothly, without jerks, deflect upwards. Set the "ELEVATOR" knob in the zero position; in this case the elevator must move to the zero position. Repeat the check with the "ELEVATOR" knob turned to the "DOWN" position.

NOTE: The time, required for sending a signal of one polarity, should not exceed 15 sec.

11. Switch on the "COMMAND No.2" switch on the control panel. The "COMMAND No.2" warning light must become illuminated. Check how the control surfaces are controlled by the "RUDDER" and "ELEVATOR" pre-set units on the control panel in the same manner as when sending command No.1; in this case, when setting the "RUDDER" and "ELEVATOR" knobs in the zero positions, the control surfaces must get move to the neutral position.

12. Set the "COMMAND No.1" and "COMMAND No.2" switches in the "OFF" position and the "POWER SELECTOR SWITCH" on the control panel - in the "FREE PRESSION" position. Set the "POWER" switch of the gyro control unit in the "OFF" position and if the autopilot has operated for more than 60 min. make an interval for not less than 30 min. to cool the gyro unit.

13. Switch on the gyro control unit "POWER" switch. After the "BASIC ZERO" warning light comes on (but not earlier than 3 min. after power is supplied) press the "UNWAGING" button on the control panel.

The "BASIC" warning light must go out and the "UNWAGING" warning light must come on.

After 5 min., check the autopilot free gyro precession. The gyro rigidity should be so, that the control surfaces deflection from the neutral position for 5 min. would not exceed:

rudder $\pm 1.25^\circ$
 elevator $\pm 2.5^\circ$
 ailerons $\pm 1.25^\circ$.

When checking the gyro rigidity, the gyro unit must be in the horizontal position.

NOTE: The ailerons deflection depends also on the yaw free gyro precession (due to a signal picked up from the coordination potentiometer): therefore before determining the value of the roll free gyro precession, set the rudder in the neutral position by turning the gyro unit in yaw. In this case the ailerons deflection from the neutral position corresponds to the roll gyro precession.

14. Set the "POWER" switch on the H-I control panel in the "OFF" position. Disconnect the H-2 gyro unit plug connectors and remove the unit from the turn table.

15. Make entries about the autopilot checks performed in the "KC" missile Log-Book.

16. Install the H-2 unit in the missile and check the autopilot operation as follows (steps 17-24).

17. Connect plug connector No.36 of the ground test panel to the autopilot board check plug connector No.36 via the connecting cable, control panel plug connector No.12 through the connecting cable to plug connector No.12 of the missile wiring system having disconnected this plug connector from the H1-13M unit and connect plug connector No.45 through the control panel connecting cable to plug connector No.45 of the H-2 gyro unit having disconnected it from the missile electrical system.

Switch off all the switches on the control panel, supply power of 28 ± 0.5 V d.c. to the missile electrical system and 26 volts to the "+" terminal of the control panel.

18. Switch on the "POWER" switch on the H-I control unit. The HAI-10A inverters must start operating. The "CAGED" and "BASES ZERO" warning lights on the control panel must become illuminated.

The control surfaces should be set in the neutral position. The indicator pointers on the control panel must be in the middle positions.

19. Switch on the "POWER" and "CHECK" switches on the control panel. Turn the "TRIP" knob on the control panel.

14. Set the "POWER" switch on the [I-] control panel in the "OFF" position. Disconnect the H-2 gyro unit plug connectors and remove the unit from the turn table.

15. Make entries about the autopilot checks performed in the "KC" missile Log-Book.

16. Install the H-2 unit in the missile and check the autopilot operation as follows (steps 17-24).

17. Connect plug connector No.36 of the ground test panel to the autopilot board check plug connector No.36 via the connecting cable, control panel plug connector No.12 through the connecting cable to plug connector No.12 of the missile wiring system having disconnected this plug connector from the K1-13M unit and connect plug connector No.45 through the control panel connecting cable to plug connector No.45 of the H-2 gyro unit having disconnected it from the missile electrical system.

Switch off all the switches on the control panel, supply power of 28 ± 0.5 V d.c. to the missile electrical system and +26 volts to the "+" terminal of the control panel.

18. Switch on the "POWER" switch on the [I-] control unit. The HAP-10A inverters must start operating. The "CAGED" and "BASES ZERO" warning lights on the control panel must become illuminated.

The control surfaces should be set in the neutral position.

The indicator pointers on the control panel must be in the middle positions.

19. Switch on the "POWER" and "CHECK" switches on the control panel. Turn the "RUDDER" knob on the control panel.

14. Set the "POWER" switch on the [J-1] control panel in the "OFF" position. Disconnect the [J-1] gyro unit plug, connectors and remove the unit from the turn table.

15. Make entries about the autopilot checks performed in the "KC" missile Log-Book.

16. Install the [J-1] unit in the missile and check the autopilot operation as follows (steps 17-24).

17. Connect plug connector No.36 of the ground test panel to the autopilot board check plug connector No.36 via the connecting cable, control panel plug connector No.12 through the connecting cable to plug connector No.12 of the missile wiring system having disconnected this plug connector from the K1-13M unit and connect plug connector No.49 through the control panel connecting cable to plug connector No.49 of the [J-1] gyro unit having disconnected it from the missile electrical system.

Switch off all the switches on the control panel, supply power of 28 ± 0.5 V d.c. to the missile electrical system and +26 volts to the "+" terminal of the control panel.

18. Switch on the "POWER" switch on the [J-1] control unit. The [J-1] inverters must start operating. The "CAGE" and "BASES ZERO" warning lights on the control panel must become illuminated.

The control surfaces should be set in the neutral position.

The indicator pointers on the control panel must be in the middle positions.

19. Switch on the "POWER" and "CHECK" switches on the control panel. Turn the "RUDDER" knob on the control panel.

The rudder and ailerons must deflect. Turn the "RUDDER" knob in the opposite direction. The rudder and ailerons must move in the opposite direction. Set the "RUDDER" knob in the zero position. Turn the "ELEVATOR" knob on the control panel. The elevator must deflect. Turn the "ELEVATOR" knob in the opposite direction. The elevator must deflect in the opposite direction. Set the "ELEVATOR" knob in the zero position.

Set the "CHECK" switch in the "OFF" position. Wait, till the control surfaces move to the neutral position and the "RAISES ELEV" warning light comes on.

20. Press the "ELEVATOR" button on the control panel. The "CHECK" warning light must go out and the "ELEVATOR" warning light must come on. Press the "ELEVATOR" button and keep it pressed for 20 seconds; in this case, the elevator must deflect upwards, and the elevator returns to the initial position.

21. Switch on the "CHECK" switch on the control panel. The "CHECK" warning light must come on. Turn the "RUDDER" knob on the control panel.

The rudder and ailerons must deflect.

Set the "RUDDER" knob in the zero position; in this case the rudder and ailerons must move to the neutral position. Repeat the check when turning the "RUDDER" knob in the opposite direction.

Turn the "ELEVATOR" knob on the control panel. The rudder must deflect. Set the "ELEVATOR" knob in the zero position; in this case the elevator must move to the neutral position. Repeat the check with the "ELEVATOR" knob turned in the opposite direction.

NOTE: It is permitted to check how the autopilot responds to control signals by means of No.1 and No.2 (steps 17-23) when sending the signals directly from the F-105 station. In this case do not disconnect plug connector No.12 from the A-1-131 unit and use the autopilot control panel instead of the ground test control panel.

9. CALIBRATING THE A-1-131 AUTOPILOT OUTPUT SIGNALS

The A-1-131 autopilot output signals are calibrated when adjusting the altimeter equipment of the "M" missile, 3rd version, at the Mirin plant.

Given below are the instructions for calibrating the signals.

1. Install the test gyro unit on the special test table and connect the gyro unit plug connectors at outlets 1 or 2 (steps 3 and 4). Connect the test gyro unit plug connector No.42 to the "A" plug connector of the autopilot control panel through the connecting cable.

Adjust the direction channel as follows:

2. At the "NO. 21" POSITION SWITCH of the control panel in the "OFF" position and "A" position, switch on the "NO. 21" switch of the autopilot control panel.

Connect the "A" terminal of the test connector (voltage - 10 V, division value - not more than 0.02 V, inner resistance - not less than 2 kOhms, degree of precision - 0.05%) to the "A" terminal of the control panel and the "B" terminal to the "NO. 21" terminal on the control panel.

After the "POWER SUPPLY" warning lights come on (but not earlier than 3 min. after power is supplied) press the "UNFACING" button.

3. Setting the "ALIGN" switch (with the "OFF" of the control panel) in the "FORWARD" and "REVERSE" positions in turn, measure supply voltage, output signal from the free gyro and μ -2 gyro unit feedback output signal by the voltmeter connected.

4. Measure as specified in step 3 with the μ -2 gyro unit turned about the vertical axis in the following succession:

to the right through the angles of: $1^\circ, 2^\circ, 6^\circ, 9^\circ, 11^\circ$;
reverse travel: $8^\circ, 5^\circ, 2^\circ, 0^\circ$;

to the left through the angles of: $1^\circ, 2^\circ, 6^\circ, 9^\circ, 11^\circ$;
reverse travel: $8^\circ, 5^\circ, 2^\circ, 0^\circ$.

Before measuring with the μ -2 gyro unit turned to the left, cut off power supply for a short time using the "OFF" switch of the "ALIGN" control panel and then send the "UNFACING" command.

NOTE: See also as specified in steps 3 and 4 for not more than 3 min.

5. Set the "POWER" switch on the "ALIGN" control panel in the "OFF" position.

Enter the check results in the table. (at the end of section II.)

Adjust the pitch channel as follows:

6. Switch on the "POWER" switch on the "ALIGN" control panel. Connect the "+" terminal of the D.C. voltmeter, indi-

ated in step 2, to the "A" terminal on the control panel and "B" terminal of the voltmeter to the "B" terminal on the control panel.

After the "B" warning lights come on (but not earlier than 1 min. after power is supplied) press the "STOPPING" button.

7. When setting the potentiometer control knob of the control panel in the "STOP", "START" and "REVERSE" positions in turn, measure the voltage output signal from the I-gyro and H-gyro control panel output signal by the voltmeter connected.

8. Measure as specified in step 7 with the I-gyro unit turned about the lateral axis as follows:

- a. through the angles $0^\circ, 45^\circ, 90^\circ, 135^\circ$, reverse travel $135^\circ, 90^\circ, 45^\circ, 0^\circ$;
- b. through the angles $0^\circ, 45^\circ, 90^\circ, 135^\circ$, reverse travel $135^\circ, 90^\circ, 45^\circ, 0^\circ$.

Measure carefully with the I-gyro unit turned about the off-power supply set a short time using the "STOP" switch on the H-gyro control panel and then set the "STOPPING" command.

NOTE: Measure as specified in steps 7 and 8, for not more than 5 min.

9. Set the "STOP" switch on the H-gyro control panel in the "STOP" position. Enter the measurements obtained in table.

10. After opening the "STOP" switch on the H-gyro control panel, connect the "-" terminal of the voltmeter, indicated in step 2, to the "-" terminal on the control panel and "+" terminal of the voltmeter to the "H" terminal on the control panel.

After the "BATT" indicator warning lights come on (but not earlier than 3 min. after power is supplied), press the "UNLOADING" button.

11. Then setting the "UNLOADING" switch on "OFF" of the control panel in the "OFF", "STOP", "ON", and "RELOAD" positions in turn, measure supply voltage, output signal of the free port and the servo unit feedback output signal by the voltmeter connections.

12. Measure as specified in step 11 with the servo unit turned about its longitudinal axis as follows:

to the right through the angles $15^{\circ}, 30^{\circ}, 45^{\circ}$; reverse travel $15^{\circ}, 30^{\circ}, 45^{\circ}$.

to the left through the angles $15^{\circ}, 30^{\circ}, 45^{\circ}$; reverse travel $15^{\circ}, 30^{\circ}, 45^{\circ}$.

Before measuring with the servo unit turned to the left cut off power supply for a few seconds. Turn off the unit and return the control panel to the "OFF" position. Press the "UNLOADING" button.

13. Measure as specified in step 11 and 12, but now with the unit in a dia.

14. Put the "UNLOAD" switch on the "OFF" control panel in the "OFF" position, enter the control values indicated in the Table.

... ..
... ..
... ..

It is the responsibility of the supplier to store the missile in the factory or depot, maintaining the missile in conformity with the present instruction. In addition, instructions on preservation or storage of the missile should include with all the rocket unit installed or with the rocket unit removed from the missile for one year since the date of arrival to the point of destination.

NOTE: If the rocket unit is removed from the missile, it should be stored in the same conditions as the missile in the metal case manufactured according to drawing 39B.01.00.000 and 40.00.00.000.

The missile should be stored with a suspension device in the manner specified in the drawing for 3 months throughout the entire guaranteed service life.

It is permitted to store the rocket motor set or its individual units which were not installed on the missile and which were packed in the metal case, manufactured according to drawings 39B.01.00.000 and 40.00.00.000 for one year since the date of arrival to the point of destination.

3. The rocket motor set in the crate in the packing case prior to installation on the missile for not more than 3 months since the date of acceptance by the Customer at the firm's plant are permitted to be stored as specified in SWG 1-1.

3. It is permitted to keep the M-18 autopilot in the "M-18" missile covers with a tarpaulin cover in the open air for 3 days.

4. The depot intended for storage of outdoor in steps is and is must be kept well ventilated.

5. The depot must be equipped with the instruments to monitor its temperature and humidity. The temperature and humidity must be checked every day, in the morning, 2x at the end of each working day.

The results of the control must be entered in the log book.

6. The depot must have painted wooden floor, asphalt, tile, enamel or cement floor. Never store the equipment in the depots having an earthen floor.

7. The depot must be free from acid and alkali vapours, petroleum or coal dust and also free from flammable vapours.

8. The depot must be clean, the floor must be cleaned by means of wet method or by using vacuum cleaners. Do not sweep the floor, do not pour or splash water on the floor.

9. The M-18 autopilot set of spare parts, tools and devices (110) as furnished by the Chief Plant and comprises the following equipment and tools:

Table No. 2

No.	Name	Code	-4 per one set	Req.No.
1				5
1.	Wire unit	W-1	1	10000000
2.	Nerve unit	N-1	1	10000000
3.	Timer	T-1	1	10000000
4.	Relay regulator	R-1	1	10000000

1	2	3	4	5
5.	Relay, certificate POM, 2.0.0.0	100-0	1	PX, 4.0.0.014171
6.	Fuse, glass	10-0	5	677.539.339-97
7.	Fuse, glass	10-0	10	677.539.339-97
8.	W. tool kit		1	677.01.00.000
9.	Shipping box for W. tool kit		1	677.01.00.000
10.	Box for W. gyro unit		1	677.03.00.000
11.	Box (100 lbs.) containing POM, 2.0.0.0 and (10-0 units)		1	677.04.00.000
12.	Shipping box		1	677.05.00.000
13.	Rotationalmeter		1	677.06.00.000
14.	Relay, certificate POM, 2.0.0.0	100-0	1	PX, 4.0.0.014171
15.	Box for W. gyro unit and rotationalmeter		1	677.07.00.000

The 100-0 rotational set of spare parts, tools and devices, box manufactured as per drawing to drawings 637.02.00.000, 637.03.00.000 and 637.04.00.000.

The set of spare parts, tools and devices is packed and stored in the same way as the 100-0 autopilot.

The difference is:

a) Installed on the missile is cost 637.04.00.000 instead of 400.00.00.000. The mountings with 54-110 relay regulators and boxes with 410 polarized relays and 7-10 and 1-10 fuses.

b) Boxes with tool kits are packed in a wooden box (arg. 637.07.00.000).

REMARKS: It is permitted to keep the autopilot tool kit in the general tool kit for the "KC" missile.

When servicing, periodically check the autopilot units incorporated in the set of spare parts, tools and devices in the same manner as the autopilot and its individual units which were not installed in the "KC" missile and which are stored in the cans.

It is permitted to store the 410-3 autopilot in the "KC" missile, 77 version covered with a tarpaulin cover in an indoor storage room throughout the entire guaranteed service life.

10. STORAGE OF THE AIR-3B AUTOPILOT IN THE "KC" MISSILE

When storing the AIR-3B autopilot in the "KC" missile (or with the 410-3B gyro unit removed from the missile) preserve in accordance with the present 80-05-101, edition III, instructions on preservation and extended storage of the "KC" winged missile, check after every 4 months 10% of the AIR-3B autopilots of the batch but not less than 3 autopilots.

NOTE: The ^{the} batch is $\frac{1}{2}$ number of autopilots subjected to $\frac{1}{2}$ checks per month.

2. When storing two (2) autopilots in the "B" missile covered with a tarpaulin cover in the hanger, check all 100% of the autopilots not less than once a month.

3. When storing the "A" autopilots, which were not installed in the "B" missile, and the autopilot individual units packed in cases, check after at least a month 10% of the "A" autopilots (their individual units) at least but not less than 2 autopilots (units).

4. Periodically check as specified in step 3 the "A" autopilots which were not checked during the previous period checks.

5. When storing, periodically check the temperature in the rooms and a room the requirements outlined in step 10 during the day and night temperature in the room must be within $\pm 5^{\circ}$ to $\pm 10^{\circ}$.

NOTE: When necessary, do not refer to step 10.

6. The time of the $\frac{1}{2}$ autopilots in the hanger.

7. The time, required for a continuous operation of the autopilot energized during all the checks specified in these instructions, must not exceed an hour or a follow-up of an interval of not less than half an hour.

8. If necessary, it is permitted to change the succession of checks in accordance with the autopilot programmed operation and the system programmer (initially) to check such as the first 30 min after the autopilot is switched on.

7. If the AIR-5 autopilots, taken for the next check in turn, are defective (corrosion included), check an additional number of the autopilots equal to the initial number of the autopilots to be checked.

If similar or some other defects are found in the autopilots checked, check all the AIR-5 autopilots included in the batch.

8. If during the check of an additional number of the AIR-5 autopilots (checked accord. to step 8), defects are not found, all the autopilots of the batch checked (defective excluded) can be admitted to a further storage.

The way of delivering the unsatisfactory reports and elimination of defects in the defective units is given in the "Instructions for making up the unsatisfactory reports".

9. During each periodic check enter the results of checks and information on all the operations performed during the inspection and checks in the certificate for the autopilot and its individual units.

10. The AIR-5 autopilot operating time, required for the periodic checks during storage, is determined by the time required for the checks specified by these Instructions.

11. After the expiration of the AIR-5 autopilot storage life (for all specified storage conditions), check all the

autopilots as specified in these instructions for the periodic checks during storage.

The decision on the ANK-5B autopilot further storage and operation is adopted by the commission appointed by the organization commander.

12. CHECKING THE ANK-5B AUTOPILOT OPERATION IN STORAGE WITHOUT REMOVING IT FROM THE "KC" MISSILE

1. After decompressing the "KC" missile and attaching the missile wings, remove the H-3 gyro unit from the missile.

Visually inspect all the autopilot units. Check that the units and cables outer surfaces are free from damage.

If corrosion is found on the autopilot units, proceed as outlined in steps 7-8, par. 20, these instructions.

2. Disconnect plug connectors No.32 and 33 from the missile wiring system and check the H-4 servo unit as indicated in par. 6 (steps 3-6): when checking the H-4 rudder servo unit, connect plug connector No.32 to the H-1 panel, when checking the H-4 elevator servo unit, connect plug connector No.33 and when checking the H-4 ailerons servo unit connect plug connector No.35.

NOTE: During this check the H-1 servo unit outlet shaft direction of rotation indicated in

par. 6 (steps 3-6) corresponds to deflection of the control surface (ailerons) connected to the H-4 servo unit to be checked.

2. When checking at a temperature below 0°C , (when storing the "KC" missile in the hangar), the H-4 servo units sensitivity must be:

with the "WINDING SELECTOR SWITCH" in "1", "2" and "3" positions...0.3-1.56 mA and in "4" position0.62-2.82 mA

When checking sensitivity use the [H-] panel with the H-70 test instruments at a temperature of -5°C and with the M5-2 test instruments at a temperature of -40°C .

3. Check the H-4 rudder and elevator servo units without disconnecting plug connectors Nos. 32 and 34 via plug connector 31 by means of the connecting cable. After checking the H-4 servo units, connect plug connectors Nos. 32 and No. 33 to the missile wiring system.

4. During the ANK-5B autopilot storage under normal conditions the sensitivity of the H-4 servo units installed on a fixed base should be 0.5-1.2 mA with the "WINNING SELECTOR SWITCH" in "1", "2" and "3" positions and 0.95-2.22 mA - in the "4" position.

3. Disconnect plug connectors Nos 40 and 41 of the missile wiring system from the HAF-10A inverters and check the inverters operation as outlined in par. 6 (steps 8-10).

NOTE: When checking the HAF-10A inverters at a temperature below 0°C (when storing the "KC" missile in the hangar) use the H-3 panel with the H-70 and H-70 test instruments only to check rotation of the H-3 panel gyro motors without measuring the input and output current and the voltage generated by the inverter.

4. Install the H-3 gyro unit on the H-5 turn table and connect the gyro unit plug connectors as indicated in par. 8 (steps 3 and 4).

5. Check the autopilot operation as specified in par. 8 (steps 5-13).

NOTES: When checking at a temperature below 0°C (when storing the "KC" missile in the hangar):

- a) apply the "UNCAGING" command, 6 min. after power is supplied;

b) the elevator must return to the initial position 40-43 sec. after the "II-18MO START." button is pressed.

6. Check the time required for the yaw and pitch gyro bases to match in the zero position as follows:
switch on the "POWER" switch on the II-I control panel. After the "BASES ZERO" warning lights come on, set the "POWER SELECTOR SWITCH" in the "BOARD CHECK" position and switch on the "CHECK" switch. The "BOARD CHECK" and "CHECK" warning lights must come on.

Fully turn the "RUDDER" knob on the control panel to the "RIGHT". The rudder must smoothly, without jerks, deflect to the right and the right aileron must deflect up. Wait for 7 min. Set the "RUDDER" knob in the zero position and the "CHECK" switch in the "OFF" position. The rudder must move to the neutral position. After 4.5-6.5 min. the ailerons must move to the neutral position and the "BASES ZERO" warning lights must come on.

Switch on the "CHECK" switch and repeat the check with the "RUDDER" knob turned to the "LEFT".

After the "BASES ZERO" warning lights come on switch on the "CHECK" switch and fully turn the "ELEVATOR" knob upward.

The elevator must smoothly, without jerks deflect up. Make an interval for 4 min. Set the "ELEVATOR" knob in the zero position and the "CHECK" switch in the "OFF" position. The elevator must move to the neutral position. After 2-3.5 min the "BASES ZERO" warning light must come on.

Switch on the "CHECK" switch and repeat the check with the "ELEVATOR" knob turned to the "DOWN" position.

Check the time required for the bases to match at a supply voltage of 26 V.

7. Check the autopilot transmission ratios as indicated in par. 15, step 6.

NOTES:

1. When checking at a temperature below 0°C (when storing the "KC" missile in the hangar):
 - a) make an interval for 7.5 min. when sending the "DIRECTION" signal; in this case the "BASES ZERO" warning lights must come on 4-7 min. after the "CHECK" command is removed.
 - b) when sending the "PITCH" signal, make an interval for 5 min.; in this case the "BASES ZERO" warning lights must come on 1.5-4.0 min. after the "CHECK" command is removed.
 - c) do not check the autopilot transmission ratios.

2. When storing the "KC" missiles in the hangar, check the time required for the bases to match once in 6 months.

8. Set the "POWER" switch on the II-1 control panel in the "OFF" position. Disconnect the II-2 gyro unit plug connectors and remove the gyro unit from the turn table. Install the II-2 gyro unit in the "KC" missile and check the autopilot operation using the THK ground test control panel as outlined in par. 8 (steps 17-24).

9. Enter the results of checks and time required for each of the units and autopilot set energized in the certificate of the individual units and AHK-5B autopilot set.

10. It is permitted to check the H-4 servo unit in a reference or any other serviceable autopilot set system as indicated in par. 6 (steps 14-23).

In this case do not check the autopilot stored in the set but check the H-4 servo unit, H-1810 timer and HAF-10A inverter which are stored in the missile as follows:

- a) H-4 servo units - as outlined in par. 6 (steps 3-6);
- b) H-1810 timers - as outlined in steps 11-13, this par.
- c) HAF-10A inverters - as outlined in par. 6 (steps 8-10)

11. Check the H-1810 timers as follows:

disconnect plug connector No. 33 from the missile wiring system. Set the "POWER" switch of the H-1 panel in the "OFF" position.

Supply power of 26 V. d.c. to the control panel. Connect the H-1810 timer plug connector No. 33 to the panel via the connecting cable. Set the "DANGLE" selector switch in the "H-1810" position and the "DANGLE SELECTOR SWITCH" in the "ON" position.

12. Switch on the "POWER" and "VELOCITY" switches. The elevator must rise to the initial position (2.5° - 5° Up from the geometric neutral position).

Switch on the "H-1810 START" switch and simultaneously start the stop-watch. 2-3 sec. after the "H-1810 START" switch is on the elevators must deflect through an angle of 9 - 9.5° Up from the initial position (12 - 12.5° Up from the geometric neutral position) and 40-42 sec. after the switch is ON the elevator must return to the required initial position.

Start the H-18MO timer twice. When starting the timer for the first time, check the elevator angle of deflection and the program starting time (2-3 sec.), to do this, start the stop-watch when the elevator deflects upward. When starting the timer for the second time, check the time of the program completion (40-42 sec.): to do this, stop the stop-watch when the elevator begins moving to the initial position. The second check is performed 20-30 seconds after the first actuation of the program is over.

- NOTES:
1. It is permitted to adjust the H-18MO timer rheostat if the elevator fails to deflect through an angle of 12° - 12.5° up from the geometric neutral position.
 2. If it is necessary to check the programmed operation for the third and subsequent times, bear in mind, that the H-18MO timer operating duty is intermittent consisting of 6 cycles followed by a complete cooling. A cycle implies one actuation of the program.
 3. If two stop-watches are available, check the program at a single switching-on of the H-18MO timer.

12. Set the "POWER" switch on the panel in the "OFF" position. Disconnect the panel from the H-18MO timer plug connector and connect this plug connector to the missile wiring system.

13. CHECKING THE AHA-5B AUTOPILOT OPERATION IN STORAGE WITH SOME UNITS REMOVED FROM THE MISSILE

1. After the AHA-5B missile is depreserved and its wings are attached, visually inspect the H-1 control panel, H-1 servo units, H-10M timer and HAP-1MA inverters which are stored installed in the missile. Open the case with the H-2 gyro unit as indicated in par. 3. and visually inspect the unit. Check that the units outer surfaces and cables are free from damage.

If corrosion is detected, proceed as outlined in steps 7-8, par. 20.

2. Check the AHA-5B autopilot as indicated in par. 12 without checking the autopilot set by means of the TBM ground test control panel.

After checking the H-2 gyro unit, pack it in a metal case as indicated in par. 4 (without packing the H-1 control panel). Enter the results of checks and time required for checking the units and autopilot set energized in the certificates for the individual units and AHA-5B autopilot set.

14. CHECKING THE AHA-5B AUTOPILOT WHEN STORING IT PACKED IN CASE

1. Inspect the packing cases. Check the cases for presence of seals and for freedom from damages. Unpack the autopilot units as indicated in par. 3. Inspect all the units. Check the outer surfaces of the units and cables for freedom from damages.

13. CHECKING THE AHK-5B AUTOPILOT OPERATION IN STORAGE WITH
SOME UNITS REMOVED FROM THE MISSILE

1. After the "FC" missile is depreserved and its wings are attached, visually inspect the H-1 control panel, H-4 servo units, H-10M timer and HAP-10A inverters which are stored installed in the missile. Open the case with the H-2 gyro unit as indicated in par. 3. and visually inspect the unit. Check that the units outer surfaces and cables are free from damage.

If corrosion is detected, proceed as outlined in steps 7-8, par. 20.

2. Check the AHK-5B autopilot as indicated in par. 12 without checking the autopilot set by means of the TBM ground test control panel.

After checking the H-2 gyro unit, pack it in a metal case as indicated in par. 4 (without packing the H-1 control panel). Enter the results of checks and time required for checking the units and autopilot set energized in the certificates for the individual units and AHK-5B autopilot set.

14. CHECKING THE AHK-5B AUTOPILOT WHEN STORING IT PACKED
IN CASE

1. Inspect the packing cases. Check the cases for presence of seals and for freedom from damages. Unpack the autopilot units as indicated in par. 3. Inspect all the units. Check the outer surfaces of the units and cables for freedom from damages.

If corrosion is found on the autopilot units, proceed as outlined in steps 7-8, par. 20, these instructions.

2. Check the H-4 servo units as indicated in par. 6 (steps 3-6); in this case, under normal conditions the sensitivity of the H-4 servo units installed on a fixed base is equal to 0.5-1.2 mA with the "WINDING SELECTOR SWITCH" in "1", "2" and "3" positions and 0.95-2.22 mA in the "4" position.

3. Check the HAI-12A inverters as indicated in par. 6 (steps 8-10).

4. Check the autopilot set operation as outlined in par. 6 (steps 14-23) and time required for the bases to match as outlined in par. 12 (step 6).

After the check is completed, pack the autopilot units in the metal case as indicated in par. 1 and enter the results of checks and time required for checking the units and autopilot set energized in the certificates for the individual units and set of the AJC-5B autopilot.

15. PROCEDURE OF REPLACING THE AJC-5B AUTOPILOT INDIVIDUAL UNITS AND COMPONENTS

1. If during the AJC-5B autopilot operation and storage defects are found, replace the H-1, H-2, H-4, H-18MO units, H2-1, H2-2, H2-3, H2-4, H2-6AM, ^{H2-6K} components, polarized relay and trimming rheostat in the H-2 gyro unit, H2-1MO component in the H-4 servo unit and H-4-1MO component polarized relay.

2. Remove and install the units to be replaced in the missile in accordance with the "Maintenance and Operating Instructions for the "K" Winged Missile", Book I.

3. Replace the H4-IMO component in the H-4 servo unit as follows:

remove the seal and unscrew by socket wrench two studs attaching the defective H4-IMO component to the H-4 servo unit and remove the component from the unit. Install a new H4-IMO component on the H-4 servo unit.

Carefully insert two attaching studs of the component into the holes in the component casing and tighten the studs by the socket wrench; tighten the studs alternately, and evenly, secure the studs with a locking wire and seal it with the using organization seal.

4. Replace the PHO polarized relay in the H-2 gyro unit as follows:

Unscrew 6 screws attaching the H-2 gyro unit side cover. Unscrew 4 screws attaching the defective relay to the H2-6M (H2-6AM) component and remove the relay out of the unit. Carefully install (without touching the electric wires) a new polarized relay in the H2-6M (H2-6MA) component and tighten the relay attaching screws; tighten the screws alternately and evenly. Secure the screws with AK-20 nitroglue according to instructions No. MB-62I (see the appendix). Screw the H-2 unit side cover, in this case safety the screws with AK-20 nitroglue according to instructions No. MB-62I.

5. Replace the trimming rheostats as follows:

Remove the H-2 gyro unit lower cover.

Unsolder the wires from the trimming rheostat to be replaced and measure the resistance set for the given rheostat.

3. Replace the H-110 component in the H-1 servo unit as follows:

Remove the seal and unscrew by socket wrench two studs attaching the defective H-110 component to the H-1 servo unit and remove the component from the unit. Install a new H-110 component on the H-1 servo unit.

Carefully insert two attaching studs of the component into the holes on the component casing and tighten the studs by the socket wrench; tighten the studs alternately, and evenly, secure the studs with a locking wire and seal it with the using organization seal.

4. Replace the H-10 polarized relay in the H-2 gyro unit as follows:

Unscrew 6 screws attaching the H-2 gyro unit side cover. Unscrew 4 screws attaching the defective relay to the H-2-5M (H-2-5MA) component and remove the relay out of the unit. Carefully install (without touching the electric wires) a new polarized relay in the H-2-5M (H-2-5MA) component and tighten the relay attaching screws; tighten the screws alternately and evenly. Secure the screws with AK-20 nitro glue according to instructions No. H-2-11 (see the appendix). Screw the H-2 unit side cover, in this case safety the screws with AK-20 nitro glue according to instructions No. H-2-521.

5. Replace the trimming rheostats as follows:

Remove the H-2 gyro unit lower cover.

Unsolder the wires from the trimming rheostat to be replaced and measure the resistance set for the given rheostat.

3. Remove the defective component in the H-1 servo unit as follows:

Remove the seal and unscrew by socket wrench two studs attaching the defective H-1A component to the H-1 servo unit and remove the component from the unit. Install a new H-1A component on the H-1 servo unit.

Carefully insert two attaching studs of the component into the hole in the component using one tightened the studs by the socket wrench; tighten the studs alternately, and evenly, secure the joints with a locking wire and seal it with the using cyanoacrylate seal.

4. Replace the H-1A polarized relay in the H-1 gyro unit as follows:

Unscrew and remove the H-1 gyro unit side cover. Unscrew 4 screws attaching the defective relay to the H-1A (H-1A) component and remove the relay out of the unit. Carefully install (without touching the electric wires) a new polarized relay in the H-1A (H-1A) component and tighten the relay attaching screws; tighten the screws alternately and evenly. Secure the screws with H-10 nitro glue according to instructions No. H-1A (See the appendix). Screw the side cover, in this case safety the screws with H-10 nitro glue according to instructions No. H-1A.

5. Replace the trimming rheostats as follows:

Remove the H-1 gyro unit lower cover.

Unselow the wires from the trimming rheostat to be replaced and measure the resistance set for the given rheostat.

2. Remove the $100\text{-}\Omega$ component in the $10\text{-}1$ servo unit as follows:

Remove the $100\text{-}\Omega$ component by socket wrench the studs attached to the $100\text{-}\Omega$ component to the $10\text{-}1$ servo unit and remove the component from the unit. Install a new $100\text{-}\Omega$ component in the $10\text{-}1$ servo unit.

Remove the $100\text{-}\Omega$ component by attaching studs of the component into the $100\text{-}\Omega$ component using and tighten the studs by the socket wrench. Tighten the studs alternately, one screw at a time, with a locking wire and seal it with the epoxy to prevent rust.

3. Replace the $100\text{-}\Omega$ component relay in the $10\text{-}1$ gyro unit as follows:

Insert a screwdriver into the $10\text{-}1$ gyro unit side cover. Insert a screwdriver into the defective relay to the $10\text{-}1$ ($10\text{-}1$) and remove the relay out of the unit. Carefully inspect the electric wires and attach a new $100\text{-}\Omega$ component ($10\text{-}1$) component and tighten the attaching screws; tighten the screws alternately and use the screws with $10\text{-}1$ nitro glue (see the appendix) No. $10\text{-}1$. (See the appendix) Remove the $10\text{-}1$ side cover, in this case safety the screws $10\text{-}1$ according to instructions No. $10\text{-}1$.

4. Replace the trimming rheostat as follows:

Remove the $100\text{-}\Omega$ unit lower cover.

Use a screwdriver to remove the trimming rheostat to be replaced and measure the resistance set for the given rheostat

5. Remove the defective component in the I-1 servo unit as follows:

Remove the top and unscrew by socket wrench two studs attaching the defective component to the I-1 servo unit and remove the component from the unit. Install a new I-1 component in the I-1 servo unit.

Securely insert the attaching studs of the component into the unit and components using and tighten the studs by the socket wrench. Tighten the studs alternately, and evenly, on opposite sides with a locking wire and seal it with the usual instructions seal.

6. Replace the I-2 polarized relay in the I-2 gyro unit as follows:

Insert the I-2 gyro unit side cover. Insert the defective relay to the I-2 (I-2) component and remove the relay out of the unit. Carefully (avoid contact touching the electric wires) a new polarized relay of the I-2 (I-2) component and tighten the attaching screws; tighten the screws alternately and evenly. Secure the screws with I-2 nitro dielectric insulators No. I-2 (See the appendix). Remove the I-2 gyro unit side cover, in this case safety the screws should be given according to instructions No. I-2.

7. Replace the trimming rheostats as follows:

Remove the I-2 gyro unit lower cover.

Insert the rheostat for the trimming rheostat to be replaced and compare the resistance set for the given rheostat

3. Remove the $12-11$ component in the $12-1$ servo unit as follows:

Remove the seal and unscrew by socket wrench two studs attaching the $12-11$ component to the $12-1$ servo unit and remove the component from the unit. Install a new $12-11$ component in the $12-1$ servo unit.

Carefully insert the attaching studs of the component into the holes in the component being and tighten the studs by hand. Put a wire clip over the studs alternately, one evening, to hold the studs with a locking wire and seal it with the unit's outer case seal.

4. Replace the $12-11$ polarized relay in the $12-1$ gyro unit as follows:

Loosen the screws attaching the $12-1$ gyro unit side cover. Increase the current of the defective relay to the $12-11$ (the $12-11$ is the relay) and remove the relay out of the unit. Carefully inspect the unit touching the electric wires; a new $12-11$ component (the $12-11$) component and tighten the attaching screws. Tighten the screws where necessary. Use the screws with $12-11$ nitro glue sealant. Refer to paragraph 12-1. (See the appendix) Lock the $12-1$ side cover, in this case safety the screws should be tightened according to instructions in the manual.

5. Replace the trimming rheostat as follows:

Remove the $12-1$ gyro unit lower cover.

Unscrew the screws from the trimming rheostat to be replaced. Measure the resistance set for the given rheostat.

3. Install the [redacted] component in the [redacted] servo unit as follows:

Remove the [redacted] and unscrew [redacted] socket wrench the studs attaching the [redacted] [redacted] component to the [redacted] servo unit and remove the component from the unit. Install a new [redacted] component on the [redacted] servo unit.

Carefully insert the attaching studs of the component into the [redacted] [redacted] component using care tighten the studs by the [redacted] and tighten the studs alternately, and evenly, until the [redacted] with a locking wire and seal it with the usual combination seal.

4. Install the [redacted] polarized relay in the [redacted] gyro unit as follows:

Insert [redacted] [redacted] the [redacted] gyro unit side cover. Unscrew [redacted] [redacted] the defective relay to the [redacted] [redacted] [redacted] [redacted] and remove the relay out of the unit. Carefully [redacted] [redacted] touching the electric wires) a new [redacted] relay of the [redacted] ([redacted]) component and tighten the relay attaching screws; tighten the screws alternately and evenly. Secure the screws with [redacted] [redacted] nitro glue according to instructions No. [redacted] (See the appendix). Remove the [redacted] [redacted] cover, in this case safety the screws with [redacted] [redacted] glue according to instructions No. [redacted].

5. Replace the trimming rheostats as follows:

Remove the [redacted] gyro unit lower cover.

Unscrew the screws from the trimming rheostat to be replaced and measure the resistance set for the given rheostat

Unscrew the screws attaching the plate with the trimming rheostats to the servo unit casing. Unscrew the nut attaching the rheostat to be removed and remove the rheostat.

Install a new rheostat in place. Secure the rheostat by a screw with a nut (place a washer under the nut).

Install the rheostat without any cant, the adjusting screws must have a clearance between the screw head and hole in the upper plate.

Set the rheostat resistance equal to that measured before the rheostat is replaced.

Reattach the wires to the trimming rheostat. Attach the plate with the trimming rheostats to the servo unit casing using the screws (place a washer under the screw heads).

Tighten the locking screws and nuts with NK-39 nut driver according to instructions No. 75-101.

6. After the servo unit is replaced, proceed as follows:

a) Check the auto pilot actuator configuration as outlined in steps 5-13, para. 5 (auto pilot unit removed in the case of missile or if the unit received from the manufacturer as outlined in steps 5-13, para. 4 (when the auto pilot is stored in the case).

b) Check the auto pilot transmission ratio as described below:

- NOTE:
1. Check the auto pilot transmission ratio at a temperature not below 30°C.
 2. The method of checking the NK-39 auto pilot gear reduction ratios refer to storage of the auto pilot servo unit installed in the NK missile.

If the autopilots are packed in the cases the methods of checking the autopilot transmission ratios are the same; in this case the amount of the H-4 servo units outlet shafts turn must be:

With the H-3 gyro unit deviated in yaw; direction control surface (rudder) - $2.25-2.75^{\circ}$ (instead of $2.1-2.9^{\circ}$)
roll control surface (aileron) $4-5^{\circ}$ (instead of $3.8-5.3$)

With the H-2 gyro unit deviated in pitch:

elevator - $4.5-5.5^{\circ}$ (instead of $4.3-5.8$)

With the H-1 gyro unit deviated in roll:

roll control surface (aileron) - $4.5-5.5^{\circ}$ (instead of $4.3-5.8$).

3. Check the autopilot transmission ratios at a power supply of 26 V d.c.

Check the rudder transmission ratio and the angle of the H-4 aileron servo unit turn controlled by the coordination signals as follows:

After sending the "UNSAFE" command, turn the H-2 gyro unit in yaw through an angle of 5° . The rudder must deflect $2.1-2.9^{\circ}$ and ailerons - through an angle of $3.8-5.3^{\circ}$.

Turn the H-2 unit in opposite direction through an angle of 5° in yaw. The rudder and ailerons must deflect respectively through the angles of $2.1-2.9^{\circ}$ and $3.8-5.3^{\circ}$ to the opposite side.

- NOTES:
1. The difference in the ailerons deflection in both directions must not exceed 0.5° .
 2. If the rudder deflection does not meet the required value, adjust the H-2 gyro unit rheostat No.3 connected in the yaw free gyro circuit. To do this, remove the lower cover of the H-2 gyro unit and rotate rheostat No.3 screw till the required deflection of the rudder is obtained. It is permitted to adjust the rheostat No.3 within 290 ± 29 ohms. The place of the bridge connection for checking the resistance value is given in Table No.3.
 3. If the ailerons deflection does not meet the required value, adjust rheostat No.12 connected in the coordination signal circuit. It is permitted to adjust rheostat No.12 within the range of 300 ± 30 ohms.

Check the elevator transmission ratio as follows:

after sending the "UNCAGING" command, turn the H-2 gyro unit in pitch through an angle of 5° . The elevator must deflect $4.3-5.3^{\circ}$. Turn the H-2 gyro unit in pitch through an angle of 5° in the opposite direction. The elevator must deflect through an angle of $4.3-5.3^{\circ}$ in the opposite side.

NOTE: If the elevator deflection does not meet the required value, adjust rheostat No.5 connected in the pitch free gyro circuit. It is permitted to adjust rheostat No.5 within the range of 115 ± 11.5 ohms.

Check the ailerons transmission ratio as follows:

After sending the "UNCAGING" command, turn the H-2 gyro unit in roll through an angle of 10° . The ailerons must deflect $4.3-5.8^\circ$.

Turn the H-2 gyro unit in roll through an angle of 10° in the opposite direction.

The aileron must deflect $4.3-5.3^\circ$ in the opposite side.

NOTE: If the ailerons deflection does not meet the required value, adjust rheostat No.10 connected in the roll feedback circuit. It is permitted to adjust rheostat No.10 within the range of 100 ± 5 ohms.

Table No.6

Resistor No.	Name of electric circuit	Pins across which measurement is performed.	Resistance ohms
3	Pitch free gyro signal circuit	31/3-42/2	290 ± 29
5	Pitch free gyro signal circuit	31/22-42/4	115 ± 11.5
10	Roll feedback signal circuit	35/11-35/13	100 ± 5
12	Bank coordination signal circuit	35/7-35/8	300 ± 30

- NOTES:
1. Check resistance by a d.c. bridge having the degree of precision not less than 2.5.
 2. The plug connectors pins are arbitrarily designated: the numerator shows the number of the plug connector and the denominator - the number of the plug connector pin.
 3. When checking, connect the plugs to the units mating receptacles. Connect the measuring bridge wires to the pins (sockets) of the plug connected.
 4. Pins 31/3-42/2; 31/22-42/4 refer to II-2 gyro unit and are manufactured according to a special order with connector plug No.42. Measure resistors 2,5 of the production units across their contacts.
 7. After replacing the II-4 unit or II-11MO component (or polarized relay in this component) check as outlined in par. 6 (steps 3-6) and check transmission ratio of the corresponding channel of the autopilot as described in step 6, this paragraph).
 8. After replacing the II-11MO timer check as indicated in step 8, par. 8 (when storing the II-11MO timer in the missile) or as in step 17, par. 6 (when storing the timer in a packing case).
 9. After replacing the II-1 control panel, check as outlined in steps 2-9, par. 8 (when storing the panel in the missile) or as in steps 13-14, par. 6 (when storing the panel in a packing case).

10. After the П2-6M, П2-6AM components or ППС polarized relay in the П2 gyro unit are replaced, check as specified in steps 7, 10 and 11, par. 3 (when storing all the autopilot units installed in the П2 missile or with the П2-gyro unit removed from the missile) or as in steps 10, 12 and 20 par. 6 (when storing the autopilot units in packing cases).

11. After replacing the П2-1 or П2-2 component in the П2 gyro unit, check as indicated in steps 5, 7-11, par. 3 (when storing all the autopilot units installed in the П2 missile or with the П2 gyro unit removed from the missile) or as in steps 10, 10-22, par. 6 (when storing the autopilot units in packing cases) and check the transmission ratio of the corresponding channel as outlined in step 6, this paragraph.

12. After replacing the П2-3 component in the П2-gyro unit, check as indicated in steps 5, 9, 12 par. 3 (when storing all the autopilot units installed in the П2 missile or with the П2 unit removed from the missile) or as in steps 14, 18, 22, par. 6 (when storing the autopilot in packing cases) and check the all-around collection transmission ratio as indicated in step 6, this paragraph.

13. After replacing the П2-4 component in the П2 gyro unit, check as specified in step 5, par. 3 (when storing all the autopilot units installed in the missile or with the П2 gyro unit removed from the missile) or as in step 15, par. 6 (when storing the autopilot units in packing cases).

14. After replacing, trimming racestate No. 3, 5, 10 and 12, check the transmission ratio of the corresponding channel as outlined in step 6, par. 10.

15. 23. 0. ... resistors, type D1-111, ... resistors type D1-111, ... relay, ... the date of ...

16. ... on the account of ... reports to the ...

17. ... similar ... replacement.

18. ... the re-quired ... autopilot individual ...

SECTION IV

PRE-FLIGHT CHECKS OF THE AIR-TO-AIR MISSILE

1. PRE-FLIGHT CHECKS OF THE AIR-TO-AIR MISSILE

1. Perform a separate check of the AIM-54 autopilot during its pre-flight preparation as outlined below, bear in mind that:

a) the autopilot be stored/installed in the "P" missile must not be subjected to preliminary checks;

b) the autopilot, whose individual units are stored being removed from the "P" missile, must be preliminarily checked, irrespective of the time of the previous periodic checks, as outlined in para. 1, and after that the "P" missile unit be installed in the missile;

c) the autopilot stored in packing cases must be preliminarily checked, irrespective of the time of the previous periodic checks, as outlined in para. 1, and after that all the autopilot units must be installed in the missile.

2. Being prepared, place the "P" missile from the carrier cart on an airfield cart.

3. Connect plug connector No. 26 of the ground test control panel via the connecting cable to the autopilot (verify check plug connector No. 26 and plug connector No. 12 of the panel through the connecting cable - to the missile wiring system plug connector No. 12, having disconnected this plug connector from the H1-101 unit.

with a total power of 1000 watts and a supply power of 2000 watts.

4. The power supply is connected to the control panel. The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable.

The power supply is connected to the control panel through a power supply cable.

5. The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable.

The power supply is connected to the control panel through a power supply cable.

6. The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable.

The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable.

The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable. The power supply is connected to the control panel through a power supply cable.

3. If two stop-watches are available, check the program at a single switching-on of the "H-1000" timer.
4. Check as outlined in this step and step 11, this paragraph during the first 30 minutes after the autoriset is ON.
5. Upon checking at a temperature below 30°⁰, the elevator must return to the initial position (stop) and, after the "H-1000" button is pressed.

6. Incline the missile by the wind to the right. The right aileron must deflect down. Incline the missile to the left. The right aileron must deflect upward. In this case, the original position in this case, the ailerons must be set in the neutral position.

7. Push on the "DOWN" No. 17 switch on the control panel. The "DOWN" No. 17 warning light must come on. Turn the "DOWN" knob on the panel. The rudder and ailerons must deflect. Set the "DOWN" knob in the zero position; in this case the rudder and ailerons must move to the neutral position. Repeat the check with the "DOWN" knob turned in the opposite direction.

Turn the "UP" knob on the panel. The elevator must deflect. Set the "UP" knob in the zero position, the elevator must move to the neutral position. Repeat the check with the "UP" knob turned in the opposite direction.

NOTE: Time, required for sending a signal of one pulse, must not exceed 12 seconds.

10. Switch on the "POWER" No. 2" switch on the panel. The "COMMAND No. 1" warning light must come on. Check how the control surfaces are controlled by the "WHEEL" and "ELEVATOR" pre-set units on the panel in the same way as when sending command No. 1: In this case when setting the "WHEEL" and "ELEVATOR" knobs in the zero positions, the control surfaces and ailerons must not deflect to the neutral position. Set the "POWER", "COMMAND No. 1" and "WHEEL" No. 2" switches on the panel in the "OFF" position.

11. Using the "POWER" switch on the 1-1 control panel cut off power supply for a short time. The "WHEEL" warning light must come on. The control surfaces and ailerons must occupy the neutral position and the "WHEEL" warning light must become illuminated.

Press the "WHEELING" button on the control panel. The "WHEEL" warning light must go out. After 2 minutes check the free gyros precession. The gyro rigidity must be so that the control surfaces deflection for 2 minutes would not exceed:

rudder $\pm 1.25^{\circ}$

elevator $\pm 2.5^{\circ}$

ailerons $\pm 1.25^{\circ}$.

NOTE: The ailerons deflection also depends on the gyro free gyro precession due to a signal picked up from the operational potentiometer. Therefore, before determining the roll from gyro precession, switch on the "WHEEL" switch on the panel and send the direction control signal of a low value and such a polarity that the rudder would move to the neutral position.

after that quickly remove the control signal. In this case the deflection of ailerons from the neutral position will correspond to the roll gyro procession.

12. Put the "OFF" switch on the [] control panel in the "OFF" position. Disconnect the ground test control panel from plug connectors No.36 and 42.

Connect the missile wiring system plug connector No.12 to the K1-13M unit.

Re-energize the missile electrical system.

17. REPAIRING THE MISSILE ELECTRICAL SYSTEM
 1. REPAIRING THE MISSILE ELECTRICAL SYSTEM

1. To check whether the K1-33 autopilot and K-17 station separate system, connect the ground test control panel plug connector No. 46, to the autopilot board. Check plug connector No.36 with the connecting cable.

Switch on the "ON" switch on the panel and supply power of 28 ± 0.1 V d.c. to the missile electrical system.

2. Repairing the K1-33 station. The "ON" No. 17 warning light on the panel must come on. Wait till zero control currents are read from the station to the autopilot (check by using the K1-24M panel).

Switch on the "OFF" button on the [] control panel. The "ON" No. 17 warning light on the panel must come on. After that, press the "STOPPING" button.

3. Repairing the K1-33 station in regime

17.

When sending the "RIGHT" signal, the rudder must deflect to the right and the right aileron - up. When removing the signal the rudder and ailerons must move to the neutral position.

When sending the "LEFT" signal, the rudder must deflect to the left and the right aileron - down. When removing the signal the rudder and ailerons must move to the neutral position. When sending the "UP" signal, the elevator must deflect upward. When removing the signal, the elevator must move to the zero position.

When sending the "DOWN" signal, the elevator must deflect down. When removing the signal, the elevator must move to the zero position.

NOTE: Time, required for sending a signal of one polarity must not exceed 15 seconds.

4. Push the "STOP" switch on the H-I control panel out off lever usually for a short time. The "STOP" warning light must come on.

Wait, till the control surfaces are set in the neutral position and the "STOP" warning light becomes illuminated. Set the "STOP" switch on the H-I control panel in the "OFF" position.

5. Send command No. 2 from the H-1 station. The "STOP" No. 2" warning light on the panel must come on. Wait till zero control currents are supplied from the station to the autopilot.

Switch on the "CAGE" switch on the H-I control panel. The "CAGE" and "R. H. SIDE" warning lights on the panel must come on. After 3 minutes press the "PURSUING" button.

Send control signals in regime "B" from the Y-14 station to the autopilot.

The direction of the control surfaces deflection must be the same as in step 3. When removing control signals the control surfaces must not move to the neutral position.

6. Re-energize the autopilot as indicated in step 4. Disconnect the ground test control panel from plug connector No.36.

SECTION V

AIM-33 ADAPTER TEST BEFORE TAKE-OFF

18. TESTING THE AIM-33 AUTOPILOT BY USING THE CARRIER-
- AIRCRAFT EQUIPMENT

1. Connect the ground test control panel plug connector No.38 to the autopilot board check plug connector No.37 through the connecting cable.

Check that the "POWER" switches on the E-I control panel and H-13M units are in the "OFF" position.

2. Switch on the "ADAPTER POWER" and "AP AND E-1" switches on the bombardier control panel in the front cabin. The "AP AND E-1 DISCONNECT" warning light on the bombardier's panel comes on.

3. Check the autopilot operation using the ground test control panel:

a) switch on the "POWER" switch on the E-I control panel. The "EAGERS" and "BASED ZERO" warning lights on the panel must come on.

b) after 3 minutes, press the "UNCRAGING" button on the panel.

The "CAGALS" warning light must go out.

Press the "H-13MO START" button on the panel and keep it pressed for 3-10 seconds. The elevator must deflect 9-9.5° up from the initial position (12-12.5° up from the geometric neutral position). Wait, till the elevator returns to the initial position.

c) switch on the "MAG" switch on the panel, send the control signals by turning the "RUDDER" and "ELEVATOR" pre-set units knobs, when sending the direction signal the rudder and ailerons must deflect and when sending the pitch signal the elevator must deflect. Set the "MAG" switch on the panel in the "OFF" position.

d) Using the "MAG" switch on the panel control panel cut off power supply for a short time. The "MAG" warning light must come on. Also, till the control surfaces and ailerons are set in the neutral position and the "MAG" warning light comes on.

4. Calibrate the panel signals and check the auto-pilot operation by the instruments in the front cabin:

a) calibrate the panel signals: the "MAG" warning light on the panel must be illuminated and the roll and pitch indicators pointers must be in the middle positions; switch on the "MAG" switch on the panel in the front cabin. Turn the "RUDDER" pre-set unit knob 10° down, the indicator pointer on the panel must deflect "DOWN" approximately two dividers.

Press the "MAG" button, the "MAG" warning light on the bombardier control panel must come on and the "MAG" missile elevator must deflect $10 \pm 2^\circ$ down from the initial position. Measure the actual value of the elevator deflection angle.

Set the pre-set unit knob on the panel in the zero position.

Switch off and after 5-10 seconds switch on the "M" and "M-1" switch on the bombardier's control panel.

The "A.I. UNDOABLE" warning light must go out. The "BASES ZERO" warning light on the IIR-175 panel must be illuminated.

Repeat the calibration with the pre-set unit knob turned 3° , 4° , 6° "DOWN", and then "UP" for each value indicated by the pre-set unit; the elevator must respectively deflect "DOWN" or "UP" with a tolerance of $\pm 0.5^{\circ}$ for the value indicated by the pre-set unit.

NOTE: When calibrating the angles of 3° , 4° , 6° (and the 1°) the "A.I. UNDOABLE" warning light must go out.

Calibrate the left suspension in the similar way.

Using the results of measurements make a calibration chart of the elevator deflection angles versus the position of the IIR-175 panel pre-set unit knob.

b) Check the elevator deflection angles caused by the IIR-175 panel signals as outlined in step 4a, this section with the pre-set unit knob turned 1° , 3° , 4° , 6° "UP" and "DOWN" according to the calibration chart.

In this case the difference between the actual values of the elevator deflection angles and values given in the calibration chart must not exceed 0.5° .

c) In flight the IIR-175 panel pre-set unit is set for a required angle by the carrier-aircraft crew in accordance with the "IIR-175 pre-set unit operating instructions".

d) Press the "UNDOABLE" button on the bombardier's control panel. The "A.I. UNDOABLE" warning light must come on.

Press the "BASES ZERO" button on the bombardier's panel and keep it pressed for 5-10 seconds. The "PECH" indicator pointer on the IIR-175 panel must sharply deflect. After the

program is completed this pointer must return to the zero position.

e) Switch off and on the "A.P. and E-1" switch on the bombardier's control panel. The "A.P. UNLAGED" light must go out. The "DAMES ZERO" warning light on the ~~100-174~~ panel must be illuminated.

5. Set the "SYSTEM POWER" and "A.P. and E-1" switches on the bombardier's control panel in the "OFF" position.

The "A.P. and E-1" ENERGIZED warning lights on the bombardier's control panel and the "B. IN ZERO" on the panel must go out.

Set the "POWER" switch on the ~~E-1~~ control panel in the "OFF" position.

Disconnect the ground test control panel from plug connector No.36.

6. Before a flight, set the "POWER" switch on the ~~E-1~~ control panel in the "ON" position and then close the access door.

program is completed this pointer must return to the zero position.

e) Switch OFF "A-1" on the "A-1" and "K-1" switch on the bombardier's control panel. The "A-1 UNLATCH" light must go out. The "BARBS ZERO" warning light on the "A-1" panel must be illuminated.

5. Set the "UNLATCH DOWN" and "A-1" and "K-1" switches on the bombardier's control panel in the "OFF" position.

The "A-1" and "K-1" UNLATCH warning lights on the bombardier's control panel and the "BARBS ZERO" on the panel must go out.

Set the "POWER" switch on the "K-1" control panel in the "OFF" position.

Disconnect the ground test control panel from plug connector No. 36.

6. Before a flight, set the "POWER" switch on the "K-1" control panel in the "ON" position and then close the access door.

S E C T I O N VI

AHK-5B AUTOPILOT PERIODIC MAINTENANCE OPERATIONS

19. AHK-5B AUTOPILOT PERIODIC MAINTENANCE OPERATIONS

PROCEDURES

1. The autopilot maintenance operations are periodic checks of the AHK-5B autopilot units condition which are performed to determine the autopilots serviceability for operation and further storage and also to prepare them so that they would meet the specifications.

2. The periodic maintenance operations are performed by the using organization mechanical personnel of the corresponding speciality.

The record of the periodic maintenance operations is made by the organization engineer or senior technician in the special log Book or certificates for the autopilot units and set.

NOTE: The form of the periodic maintenance operation log Book must correspond to the Aircraft Maintenance Manual.

3. The periodic maintenance operations are scheduled to the period of periodic inspections performed as outlined in paragraph 11, these Instructions.

10. PERIODIC MAINTENANCE OPERATIONS RECORD

Nos.	Operations Performed	Devices, Tools, materials
1.	<p>Visually inspect all the autopilot units. Make sure that the external surfaces of the units and mountings are free from damages. Remove dust and dirt from the units external surfaces.</p> <p>If corrosion is detected proceed as outlined in step 7, this paragraph.</p> <p>Remove the lower cover of the gyro unit and inspect the windings of the trimming rheostats on the unit mounting for condition. If corrosion (green coating) is found on the rheostat winding surface, proceed as specified in step 8, this paragraph.</p>	<p>Portable lamp, mirror, rags.</p>
2.	<p>Disconnect the units plug connectors. Inspect the plug connector pins. If the pins contacting surfaces are dirty, clean them with a bristle brush slightly dampened with 1-70 gasoline and blow with compressed air at a pressure of 1-2 atm. Connect and safety the plug connectors.</p>	<p>1-70 gasoline, hair brush.</p>

Nos.	Operations Performed	Devices, Tools, materials
3.	<p>Remove the end cap from the HAN-10A rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with #70 gasoline and clean the commutator with #000 sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>95</p> <p>Test kit #70 gasoline. Rags #000 sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other HAN-10A inverter, incorporated in the autopilot set.</p>	
5.	<p>Check the autopilot units and set as specified in:</p> <p>paragraph 12 - when storing the AN-3B autopilot installed in the "KC" missile.</p> <p>paragraph 13 - when storing the AN-3B autopilot with some units removed from the "KC" missile.</p> <p>paragraph 14 - when storing the AN-3B autopilot in the packing cases.</p>	<p>Test Instruments set.</p>

Nos.	Operations Performed	Devices, Tools, materials
3.	<p>Remove the end cap from the <u>WAF-11A</u> rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with <u>W-70</u> gasoline and clean the commutator with <u>W-70</u> sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Test bit <u>W-70</u> gasoline. Rags "00" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other <u>WAF-11A</u> inverter, incorporated in the autopilot set.</p>	
5.	<p>Check the autopilot units and set as specified in:</p> <p>paragraph 12 - when storing the <u>AIH-5B</u> autopilot installed in the "W" missile.</p> <p>paragraph 13 - when storing the <u>AIH-5B</u> autopilot with some units removed from the "W" missile.</p> <p>paragraph 14 - when storing the <u>AIH-5B</u> autopilot in the packing cases.</p>	<p>Test instruments set.</p>

Nos.	Operations Performed	Devices, Tools, materials
3.	<p>Remove the end cap from the TAI-1A rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with 1-70 gasoline and clean the commutator with "00" sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Wool Nit 1-70 gasoline. Rags "00" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other TAI-1A inverter, incorporate in the autopilot set.</p>	
5.	<p>Place the autopilot units and set as specified in: paragraph 12 - when storing the AIB-2B autopilot installed in the "40" missile. paragraph 13 - when storing the AIB-2B autopilot with some units removed from the "40" missile. paragraph 14 - when storing the AIB-2B autopilot in the packing cases.</p>	<p>Test In- struments set.</p>

Nos.	Operations Performed	Devices, Tools, mate- rials
3.	<p>Remove the end cap from the IAP-1QA rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with E-70 gasoline and clean the commutator with "00" sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Tool kit E-70 gasoline. Rags "00" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other IAP-1QA inverter, incorporated in the autopilot set.</p>	
5.	<p>Check the autopilot units and set as specified in:</p> <p>paragraph 12 - when storing the AIR-5B autopilot installed in the "KC" missile.</p> <p>paragraph 13 - when storing the AIR-5B autopilot with some units removed from the "KC" missile.</p> <p>paragraph 14 - when storing the AIR-5B autopilot in the packing cases.</p>	<p>Test In- struments set.</p>

95

Nos.	Operations Performed	Devices, Tools, materials
3.	<p>Remove the end cap from the HAP-1GA rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with E-70 gasoline and clean the commutator with "00" sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Tool kit E-70 gasoline. Rags "00" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other HAP-1GA inverter, incorporated in the autopilot set.</p>	
5.	<p>Check the autopilot units and set as specified in:</p> <p>paragraph 12 - when storing the AHC-5B autopilot installed in the "KC" missile.</p> <p>paragraph 13 - when storing the AHC-5B autopilot with some units removed from the "KC" missile.</p> <p>paragraph 14 - when storing the AHC-5B autopilot in the packing cases.</p>	<p>Test Instruments set.</p>

Nos.	Operations Performed	Devices, Tools, materials
3.	<p>Remove the end cap from the <u>MAP-1QA</u> rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with <u>E-70</u> gasoline and clean the commutator with "00" sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Tool kit <u>E-70</u> gasoline. Rags "00" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other <u>MAP-1QA</u> inverter, incorporated in the autopilot set.</p>	
5.	<p>Check the autopilot units and set as specified in:</p> <p>paragraph 12 - when storing the <u>AIM-5B</u> autopilot installed in the "KC" missile.</p> <p>paragraph 13 - when storing the <u>AIM-5B</u> autopilot with some units removed from the "KC" missile.</p> <p>paragraph 14 - when storing the <u>AIM-5B</u> autopilot in the packing cases.</p>	<p>Test Instruments Set.</p>

Operations Performed

Devices,
Tools, mate-
rials

1. Remove the end cap from the HAP-104 rear end housing assembly and take out the brushes from the brush holders. Inspect the brush holder surface of the commutator. Clean it with clean rag slightly dampened with 70% alcohol and align the commutator with 100% sand paper. Measure the holder brush length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.

Tool Kit
S-5B
paralane
tag
100% sand
paper

2. Close the inverter rear end housing assembly with the end cap.

3. Perform the operations outlined in step 3 on the other HAP-104 Inverter, incorporated in the autopilot set.

4. Check the autopilot units and set as specified in:
 - paragraph 12 - when storing the ANK-5B autopilot installed in the "KC" missile.
 - paragraph 13 - when storing the ANK-5B autopilot with some units removed from the "KC" missile.
 - paragraph 14 - when storing the ANK-5B autopilot in the packing cases.

Test In-
struments
Set.

Nos.	Operations Performed	Devices, Tools, materials
3.	<p>Remove the end cap from the IAP-10A rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with E-70 gasoline and clean the commutator with "00" sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Tool kit E-70 gasoline. Rags "00" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other IAP-10A inverter, incorporated in the autopilot set.</p>	
5.	<p>Check the autopilot units and set as specified in:</p> <p>paragraph 12 - when storing the AIR-5B autopilot installed in the "KC" missile.</p> <p>paragraph 13 - when storing the AIR-5B autopilot with some units removed from the "KC" missile.</p> <p>paragraph 14 - when storing the AIR-5B autopilot in the packing cases.</p>	<p>Test Instruments set.</p>

Nos.	Operations Performed	Devices, Tools, materials
3.	<p>Remove the end cap from the IAP-10A rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with E-70 gasoline and clean the commutator with "00" sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Tool kit E-70 gasoline. Rags "00" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other IAP-10A inverter, incorporated in the autopilot set.</p>	
5.	<p>Check the autopilot units and set as specified in:</p> <p>paragraph 12 - when storing the AIR-5B autopilot installed in the "KC" missile.</p> <p>paragraph 13 - when storing the AIR-5B autopilot with some units removed from the "KC" missile.</p> <p>paragraph 14 - when storing the AIR-5B autopilot in the packing cases.</p>	<p>Test Instruments Set.</p>

Nos.	Operations Performed	Petries, Tools, Mate- rials
------	----------------------	-----------------------------------

3.	<p>Remove the end cap from the III-111 rear end housing assembly and turn out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, dip it into an orange slightly dampened with 50% gasoline and clean the commutator with 100% sand paper. Use the inverted crucible brush. Brushes worn to 1/2 mm. or less must be replaced with new ones. Inspect and brush the brush holders.</p>	<p>100% sand paper.</p>
----	--	-------------------------

Place the inverted rear end housing assembly with the end cap.

4.	<p>Remove the quadrant obtained in step 3 or another III-111. Inspect, measure with a micrometer.</p>	
----	---	--

5.	<p>Read the autopilot manual and the special letter paragraph 4. Check steering, etc. Paragraph 4. Check the autopilot manual in the III-111. Paragraph 4. Check during the autopilot of the autopilot manual. Paragraph 4. Check during the autopilot of the autopilot manual. Paragraph 4. Check during the autopilot of the autopilot manual.</p>	
----	--	--

Nos.

Operations Performed

Devices, Tools,
materials

rating surface by moving the
slightly pressed chamois along the
potentiometer winding turns. Clean two
or three times, check the potentiometer
cleanliness by means of a magnifying
glass (14) having a four-fold enlarge-
ment; when cleaning, change dirty
chamois:

a) wipe current-carrying elements
(silver of the slip ring) units
potentiometer by means of slightly
dampened with 70% alcohol.

Note: When cleaning the potentiometer
do not touch the brushes.

2. Clean the potentiometer assemblies
slip rings and contacts:

a) manually change the gear assembly
and move the corresponding slip ring
to the stop:

Welder stick,
hair brush,
magnifying
glass, etc.

b) carefully clean the slip ring
surface by means of a sharp (2-3 mm
wide) smooth end of a stick made of
thick wood (beech or linden prefer-
able); check the surface for clean-
liness by means of a magnifying glass
having a four-fold enlargement;

Nos.	Operations Performed	Levants, F. A. S., Materials
------	----------------------	---------------------------------

c) remove dirt on dust from the slip ring surface by a soft hair brush.

NOTE: When cleaning the slip rings, do not touch the brushes.

3. Clean the potentiometer unit potentiometer as follows:

1) Move the potentiometer wiper in one of the extreme positions by rotating the unit outlet shaft (do not rotate to the brush stack).

Small amount of
acetone
cleaning
brush
rod, sign, in
place.

2) With a cotton swab or a wooden stick (use carefully) clean the contact slip ring surfaces with acetone solution. Do not touch the potentiometer surface or scratch the slip ring contact surface. Clean the potentiometer winding wires.

3) Clean the contact lines checking the potentiometer alignment by means of a magnifying glass (using a four-fold enlargement) and cleaning dirty contact

4) Clean the current-carrying plate (brush contact) with alcohol solution (acetone with revealed brush).

NOTE: When cleaning the potentiometer, do not touch the wires.

4. Clean the rotary mechanism case, plate and support in the same way as the assembly as follows.

Nos.	Operations Performed	Devices, Tools, Materials
a)	manually unscrap the [] assembly and move the inner and outer gimbal wings so that the large and small cams operating surfaces are clearly seen.	
b)	use the sharp end of a wooden stick (2-3 mm wide) a strip of chamois slightly suspended with rectified alcohol and wipe the cams, blade and tappet operating surfaces.	wooden stick, strip of chamois, rectified alcohol.
c)	perform the operations outlined in steps "a" and "b" on the [] assembly.	screwdriver, support, wooden stick, strip of chamois, strip of
d)	unscrew 4 screws attaching the [] assembly. Unscrew 6 hex-head screws attaching the [] assembly. Slightly lift the [] assembly and remove the [] assembly. Install the [] assembly in place. Install the [] assembly on the support (plate, 10x17x25 mm).	chamois, rectified alcohol.
e)	clean the [] assembly cams, blade and tappet as indicated in steps "a" and "b".	
f)	slightly lift the [] assembly, install the [] and then [] assembly in place and secure them by attaching screws placing split washers under the screw heads.	

Nos.	Operations Performed	Inches, Tools, Materials
------	----------------------	--------------------------

Notes: When cleaning, do not touch the gunblow-off rig and all other brushes.

7. If corrosion is found on the outer surfaces of the unit having metal or varnish coating, proceed as follows:

a) wipe the area subjected to corrosion with a clean cloth slightly dampened with 70% gasoline.

Cotton cloth,
70% gasoline,
Hair brush.

b) remove corrosion products by hair brush.

Hair brush,
black nitro-

c) wipe the treated area with a clean cloth slightly dampened with 70% gasoline.

70% varnish.

d) apply a thin coating of black nitro varnish to the surface.

8. If corrosion is noted on the surface of the winding rheostat winding, proceed as follows:

a) if corrosion is not considerable, use the following: pull on a sharp end of a wooden stick (3-4 inches) a strip of emery cloth, dampened with 70% gasoline and wipe the rheostat winding surface moving the slightly rounded tip down along the rheostat winding.

Wooden stick,
emery cloth, 70% gasoline.

101

Nos.	Operations Performed	Devices, Tools, Materials
------	----------------------	---------------------------

b) replace the rheostat, if corrosion cannot be removed completely.

NOTES:

1. It is not permitted to perform the operations outlined in step 1, when performing every month maintenance operations on the missile.
2. After accomplishing the operations described in paragraphs 15, 16, the 1-3 and 4-1 units must be closed with the covers and secured with seals of the using organization. The manufacturer's guarantee will remain valid.

SECTION VII

AIR-5B AUTOPILOT TEST EQUIPMENT

21. AIR-5B AUTOPILOT TEST EQUIPMENT

1. The AIR-5B autopilot combined checkout in the "AS" missile with the H-1 gyro unit removed from the missile and also the autopilot checkout on the test stand is performed by means of the test equipment set.

2. Check the AIR-5B autopilot installed in the "AS" missile by means of the H-1 ground test control panel.

3. The set of the test equipment (dwg. 379.00.00.000) incorporates:

HIA-1	control panel	- 1
HIA-2	mounting	- 1
HIA-3	simulator	- 3
HIA-4	junction box	- 3
HIA-5	turn table	- 1
	connecting cables	- 1 set.

NOTE: When checking the AIR-5B autopilot installed in the missile, the HIA-3 simulators and HIA-4 junction boxes are not used.

The test equipment set is shown in Fig. 12.

HIA-1 control panel (dwg. 379.00.00.000) (dwg. 379.00.00.000) is a variable speed motor. The speed of rotation is respectively 10, 20, 30, 40, 50, 60, 70, 80, 90, 100, 110, 120, 130, 140, 150, 160, 170, 180, 190, 200, 210, 220, 230, 240, 250, 260, 270, 280, 290, 300, 310, 320, 330, 340, 350, 360, 370, 380, 390, 400, 410, 420, 430, 440, 450, 460, 470, 480, 490, 500, 510, 520, 530, 540, 550, 560, 570, 580, 590, 600, 610, 620, 630, 640, 650, 660, 670, 680, 690, 700, 710, 720, 730, 740, 750, 760, 770, 780, 790, 800, 810, 820, 830, 840, 850, 860, 870, 880, 890, 900, 910, 920, 930, 940, 950, 960, 970, 980, 990, 1000, 1010, 1020, 1030, 1040, 1050, 1060, 1070, 1080, 1090, 1100, 1110, 1120, 1130, 1140, 1150, 1160, 1170, 1180, 1190, 1200, 1210, 1220, 1230, 1240, 1250, 1260, 1270, 1280, 1290, 1300, 1310, 1320, 1330, 1340, 1350, 1360, 1370, 1380, 1390, 1400, 1410, 1420, 1430, 1440, 1450, 1460, 1470, 1480, 1490, 1500, 1510, 1520, 1530, 1540, 1550, 1560, 1570, 1580, 1590, 1600, 1610, 1620, 1630, 1640, 1650, 1660, 1670, 1680, 1690, 1700, 1710, 1720, 1730, 1740, 1750, 1760, 1770, 1780, 1790, 1800, 1810, 1820, 1830, 1840, 1850, 1860, 1870, 1880, 1890, 1900, 1910, 1920, 1930, 1940, 1950, 1960, 1970, 1980, 1990, 2000, 2010, 2020, 2030, 2040, 2050, 2060, 2070, 2080, 2090, 2100, 2110, 2120, 2130, 2140, 2150, 2160, 2170, 2180, 2190, 2200, 2210, 2220, 2230, 2240, 2250, 2260, 2270, 2280, 2290, 2300, 2310, 2320, 2330, 2340, 2350, 2360, 2370, 2380, 2390, 2400, 2410, 2420, 2430, 2440, 2450, 2460, 2470, 2480, 2490, 2500, 2510, 2520, 2530, 2540, 2550, 2560, 2570, 2580, 2590, 2600, 2610, 2620, 2630, 2640, 2650, 2660, 2670, 2680, 2690, 2700, 2710, 2720, 2730, 2740, 2750, 2760, 2770, 2780, 2790, 2800, 2810, 2820, 2830, 2840, 2850, 2860, 2870, 2880, 2890, 2900, 2910, 2920, 2930, 2940, 2950, 2960, 2970, 2980, 2990, 3000, 3010, 3020, 3030, 3040, 3050, 3060, 3070, 3080, 3090, 3100, 3110, 3120, 3130, 3140, 3150, 3160, 3170, 3180, 3190, 3200, 3210, 3220, 3230, 3240, 3250, 3260, 3270, 3280, 3290, 3300, 3310, 3320, 3330, 3340, 3350, 3360, 3370, 3380, 3390, 3400, 3410, 3420, 3430, 3440, 3450, 3460, 3470, 3480, 3490, 3500, 3510, 3520, 3530, 3540, 3550, 3560, 3570, 3580, 3590, 3600, 3610, 3620, 3630, 3640, 3650, 3660, 3670, 3680, 3690, 3700, 3710, 3720, 3730, 3740, 3750, 3760, 3770, 3780, 3790, 3800, 3810, 3820, 3830, 3840, 3850, 3860, 3870, 3880, 3890, 3900, 3910, 3920, 3930, 3940, 3950, 3960, 3970, 3980, 3990, 4000, 4010, 4020, 4030, 4040, 4050, 4060, 4070, 4080, 4090, 4100, 4110, 4120, 4130, 4140, 4150, 4160, 4170, 4180, 4190, 4200, 4210, 4220, 4230, 4240, 4250, 4260, 4270, 4280, 4290, 4300, 4310, 4320, 4330, 4340, 4350, 4360, 4370, 4380, 4390, 4400, 4410, 4420, 4430, 4440, 4450, 4460, 4470, 4480, 4490, 4500, 4510, 4520, 4530, 4540, 4550, 4560, 4570, 4580, 4590, 4600, 4610, 4620, 4630, 4640, 4650, 4660, 4670, 4680, 4690, 4700, 4710, 4720, 4730, 4740, 4750, 4760, 4770, 4780, 4790, 4800, 4810, 4820, 4830, 4840, 4850, 4860, 4870, 4880, 4890, 4900, 4910, 4920, 4930, 4940, 4950, 4960, 4970, 4980, 4990, 5000, 5010, 5020, 5030, 5040, 5050, 5060, 5070, 5080, 5090, 5100, 5110, 5120, 5130, 5140, 5150, 5160, 5170, 5180, 5190, 5200, 5210, 5220, 5230, 5240, 5250, 5260, 5270, 5280, 5290, 5300, 5310, 5320, 5330, 5340, 5350, 5360, 5370, 5380, 5390, 5400, 5410, 5420, 5430, 5440, 5450, 5460, 5470, 5480, 5490, 5500, 5510, 5520, 5530, 5540, 5550, 5560, 5570, 5580, 5590, 5600, 5610, 5620, 5630, 5640, 5650, 5660, 5670, 5680, 5690, 5700, 5710, 5720, 5730, 5740, 5750, 5760, 5770, 5780, 5790, 5800, 5810, 5820, 5830, 5840, 5850, 5860, 5870, 5880, 5890, 5900, 5910, 5920, 5930, 5940, 5950, 5960, 5970, 5980, 5990, 6000, 6010, 6020, 6030, 6040, 6050, 6060, 6070, 6080, 6090, 6100, 6110, 6120, 6130, 6140, 6150, 6160, 6170, 6180, 6190, 6200, 6210, 6220, 6230, 6240, 6250, 6260, 6270, 6280, 6290, 6300, 6310, 6320, 6330, 6340, 6350, 6360, 6370, 6380, 6390, 6400, 6410, 6420, 6430, 6440, 6450, 6460, 6470, 6480, 6490, 6500, 6510, 6520, 6530, 6540, 6550, 6560, 6570, 6580, 6590, 6600, 6610, 6620, 6630, 6640, 6650, 6660, 6670, 6680, 6690, 6700, 6710, 6720, 6730, 6740, 6750, 6760, 6770, 6780, 6790, 6800, 6810, 6820, 6830, 6840, 6850, 6860, 6870, 6880, 6890, 6900, 6910, 6920, 6930, 6940, 6950, 6960, 6970, 6980, 6990, 7000, 7010, 7020, 7030, 7040, 7050, 7060, 7070, 7080, 7090, 7100, 7110, 7120, 7130, 7140, 7150, 7160, 7170, 7180, 7190, 7200, 7210, 7220, 7230, 7240, 7250, 7260, 7270, 7280, 7290, 7300, 7310, 7320, 7330, 7340, 7350, 7360, 7370, 7380, 7390, 7400, 7410, 7420, 7430, 7440, 7450, 7460, 7470, 7480, 7490, 7500, 7510, 7520, 7530, 7540, 7550, 7560, 7570, 7580, 7590, 7600, 7610, 7620, 7630, 7640, 7650, 7660, 7670, 7680, 7690, 7700, 7710, 7720, 7730, 7740, 7750, 7760, 7770, 7780, 7790, 7800, 7810, 7820, 7830, 7840, 7850, 7860, 7870, 7880, 7890, 7900, 7910, 7920, 7930, 7940, 7950, 7960, 7970, 7980, 7990, 8000, 8010, 8020, 8030, 8040, 8050, 8060, 8070, 8080, 8090, 8100, 8110, 8120, 8130, 8140, 8150, 8160, 8170, 8180, 8190, 8200, 8210, 8220, 8230, 8240, 8250, 8260, 8270, 8280, 8290, 8300, 8310, 8320, 8330, 8340, 8350, 8360, 8370, 8380, 8390, 8400, 8410, 8420, 8430, 8440, 8450, 8460, 8470, 8480, 8490, 8500, 8510, 8520, 8530, 8540, 8550, 8560, 8570, 8580, 8590, 8600, 8610, 8620, 8630, 8640, 8650, 8660, 8670, 8680, 8690, 8700, 8710, 8720, 8730, 8740, 8750, 8760, 8770, 8780, 8790, 8800, 8810, 8820, 8830, 8840, 8850, 8860, 8870, 8880, 8890, 8900, 8910, 8920, 8930, 8940, 8950, 8960, 8970, 8980, 8990, 9000, 9010, 9020, 9030, 9040, 9050, 9060, 9070, 9080, 9090, 9100, 9110, 9120, 9130, 9140, 9150, 9160, 9170, 9180, 9190, 9200, 9210, 9220, 9230, 9240, 9250, 9260, 9270, 9280, 9290, 9300, 9310, 9320, 9330, 9340, 9350, 9360, 9370, 9380, 9390, 9400, 9410, 9420, 9430, 9440, 9450, 9460, 9470, 9480, 9490, 9500, 9510, 9520, 9530, 9540, 9550, 9560, 9570, 9580, 9590, 9600, 9610, 9620, 9630, 9640, 9650, 9660, 9670, 9680, 9690, 9700, 9710, 9720, 9730, 9740, 9750, 9760, 9770, 9780, 9790, 9800, 9810, 9820, 9830, 9840, 9850, 9860, 9870, 9880, 9890, 9900, 9910, 9920, 9930, 9940, 9950, 9960, 9970, 9980, 9990, 10000, 10010, 10020, 10030, 10040, 10050, 10060, 10070, 10080, 10090, 10100, 10110, 10120, 10130, 10140, 10150, 10160, 10170, 10180, 10190, 10200, 10210, 10220, 10230, 10240, 10250, 10260, 10270, 10280, 10290, 10300, 10310, 10320, 10330, 10340, 10350, 10360, 10370, 10380, 10390, 10400, 10410, 10420, 10430, 10440, 10450, 10460, 10470, 10480, 10490, 10500, 10510, 10520, 10530, 10540, 10550, 10560, 10570, 10580, 10590, 10600, 10610, 10620, 10630, 10640, 10650, 10660, 10670, 10680, 10690, 10700, 10710, 10720, 10730, 10740, 10750, 10760, 10770, 10780, 10790, 10800, 10810, 10820, 10830, 10840, 10850, 10860, 10870, 10880, 10890, 10900, 10910, 10920, 10930, 10940, 10950, 10960, 10970, 10980, 10990, 11000, 11010, 11020, 11030, 11040, 11050, 11060, 11070, 11080, 11090, 11100, 11110, 11120, 11130, 11140, 11150, 11160, 11170, 11180, 11190, 11200, 11210, 11220, 11230, 11240, 11250, 11260, 11270, 11280, 11290, 11300, 11310, 11320, 11330, 11340, 11350, 11360, 11370, 11380, 11390, 11400, 11410, 11420, 11430, 11440, 11450, 11460, 11470, 11480, 11490, 11500, 11510, 11520, 11530, 11540, 11550, 11560, 11570, 11580, 11590, 11600, 11610, 11620, 11630, 11640, 11650, 11660, 11670, 11680, 11690, 11700, 11710, 11720, 11730, 11740, 11750, 11760, 11770, 11780, 11790, 11800, 11810, 11820, 11830, 11840, 11850, 11860, 11870, 11880, 11890, 11900, 11910, 11920, 11930, 11940, 11950, 11960, 11970, 11980, 11990, 12000, 12010, 12020, 12030, 12040, 12050, 12060, 12070, 12080, 12090, 12100, 12110, 12120, 12130, 12140, 12150, 12160, 12170, 12180, 12190, 12200, 12210, 12220, 12230, 12240, 12250, 12260, 12270, 12280, 12290, 12300, 12310, 12320, 12330, 12340, 12350, 12360, 12370, 12380, 12390, 12400, 12410, 12420, 12430, 12440, 12450, 12460, 12470, 12480, 12490, 12500, 12510, 12520, 12530, 12540, 12550, 12560, 12570, 12580, 12590, 12600, 12610, 12620, 12630, 12640, 12650, 12660, 12670, 12680, 12690, 12700, 12710, 12720, 12730, 12740, 12750, 12760, 12770, 12780, 12790, 12800, 12810, 12820, 12830, 12840, 12850, 12860, 12870, 12880, 12890, 12900, 12910, 12920, 12930, 12940, 12950, 12960, 12970, 12980, 12990, 13000, 13010, 13020, 13030, 13040, 13050, 13060, 13070, 13080, 13090, 13100, 13110, 13120, 13130, 13140, 13150, 13160, 13170, 13180, 13190, 13200, 13210, 13220, 13230, 13240, 13250, 13260, 13270, 13280, 13290, 13300, 13310, 13320, 13330, 13340, 13350, 13360, 13370, 13380, 13390, 13400, 13410, 13420, 13430, 13440, 13450, 13460, 13470, 13480, 13490, 13500, 13510, 13520, 13530, 13540, 13550, 13560, 13570, 13580, 13590, 13600, 13610, 13620, 13630, 13640, 13650, 13660, 13670, 13680, 13690, 13700, 13710, 13720, 13730, 13740, 13750, 13760, 13770, 13780, 13790, 13800, 13810, 13820, 13830, 13840, 13850, 13860, 13870, 13880, 13890, 13900, 13910, 13920, 13930, 13940, 13950, 13960, 13970, 13980, 13990, 14000, 14010, 14020, 14030, 14040, 14050, 14060, 14070, 14080, 14090, 14100, 14110, 14120, 14130, 14140, 14150, 14160, 14170, 14180, 14190, 14200, 14210, 14220, 14230, 14240, 14250, 14260, 14270, 14280, 14290, 14300, 14310, 14320, 14330, 14340, 14350, 14360, 14370, 14380, 14390, 14400, 14410, 14420, 14430, 14440, 14450, 14460, 14470, 14480, 14490, 14500, 14510, 14520, 14530, 14540, 14550, 14560, 14570, 14580, 14590, 14600, 14610, 14620, 14630, 14640, 14650, 14660, 14670, 14680, 14690, 14700, 14710, 14720, 14730, 14740, 14750, 14760, 14770, 14780, 14790, 14800, 14810, 14820, 14830, 14840, 14850, 14860, 14870, 14880, 14890, 14900, 14910, 14920, 14930, 14940, 14950, 14960, 14970, 14980, 14990, 15000, 15010, 15020, 15030, 15040, 15050, 15060, 15070, 15080, 15090, 15100, 15110, 15120, 15130, 15140, 15150, 15160, 15170, 15180, 15190, 15200, 15210, 15220, 15230, 15240, 15250, 15260, 15270, 15280, 15290, 15300, 15310, 15320, 15330, 15340, 15350, 15360, 15370, 15380, 15390, 15400, 15410, 15420, 15430, 15440, 15450, 15460, 15470, 15480, 15490, 15500, 15510, 15520, 15530, 15540, 15550, 15560, 15570, 15580, 15590, 15600, 15610, 15620, 15630, 15640, 15650, 15660, 15670, 15680, 15690, 15700, 15710, 15720, 15730, 15740, 15750, 15760, 15770, 15780, 15790, 15800, 15810, 15820, 15830, 15840, 15850, 15860, 15870, 15880, 15890, 15900, 15910, 15920, 15930, 15940, 15950, 15960, 15970, 15980, 15990, 16000, 16010, 16020, 16030, 16040, 16050, 16060, 16070, 16080, 16090, 16100, 16110, 16120, 16130, 16140, 16150, 16160, 16170, 16180, 16190, 16200, 16210, 16220, 16230, 16240, 16250, 16260, 16270, 16280, 16290, 16300, 16310, 16320, 16330, 16340, 16350, 16360, 16370, 16380, 16390, 16400, 16410, 16420, 16430, 16440, 16450, 16460, 16470, 16480, 16490, 16500, 16510, 16520, 16530, 16540, 16550, 16560, 16570, 16580, 16590, 16600, 16610, 16620, 16630, 16640, 16650, 16660, 16670, 16680, 16690, 16700, 16710, 16720, 16730, 16740, 16750, 16760, 16770, 16780, 16790, 16800, 16810, 16820, 16830, 16840, 16850, 16860, 16870, 16880, 16890, 16900, 16910, 16920, 16930, 16940, 16950, 16960, 16970, 16980, 16990, 17000, 17010, 17020, 17030, 17040, 17050, 17060, 17070, 17080, 17090, 17100, 17110, 17120, 17130, 17140, 17150, 17160, 17170, 17180, 17190, 17200, 17210, 17220, 17230, 17240, 17250, 17260, 17270, 17280, 17290, 17300, 17310, 17320, 17330, 17340, 17350, 17360, 17370, 17380, 17390, 17400, 17410, 17420, 17430, 17440, 17450, 17460, 17470, 17480, 17490, 17500, 17510, 17520, 17530, 17540, 17550, 17560, 17570, 17580, 17590, 17600, 17610, 17620, 17630, 17640, 17650, 17660, 17670, 17680, 17690, 17700, 17710, 17720, 17730, 17740, 17750, 17760, 17770, 17780, 17790, 17800, 17810, 17820, 17830, 17840, 17850, 17860, 17870, 17880, 17890, 17900, 17910, 17920, 17930, 17940, 17950, 17960, 17970, 17980, 17990, 18000, 180




FIG. 12. Test Equipment Set.

- 1. - KIA-1 control panel; 2 - KIA-2 mounting; 3 - KIA-3 simulator; 4 - KIA-4 junction box;
- 5 - KIA-5 turn table; 6 - connecting cables.

Shock-mounted to the control panel casing is the face panel carrying all the control panel electrical units and the clock showing the time during which the autopilot is energized. The clock is started by a special electromagnetic relay built-in the control panel which is actuated whenever the autopilot is energized.

The autopilot supplies D.C. power of 26 V to plug connector No.43 to feed the control panel circuits. The panel is provided with a special "POWER SELECTOR SWITCH" used to change the modes of the control panel functioning; with the "POWER SELECTOR SWITCH" in the "BOARD CHECK" position, the autopilot is checked via the board check plug connector, and with the switch in the "K-17M SIMULATOR" position, the autopilot check is simulated by means of the K-17M panel of the carrier-aircraft and with the switch in the "K-1M SIMULATOR" position a combined operation of the autopilot and K-1M station is simulated.

The KHA-1 control panel schematic diagram is given in Fig.13.

The control panel operating temperature range:

- a) control panel with test instruments model HMA and HMA-70 (dwg.3790100000) - 20°C to +50°C.
- b) control panel with test instruments model MS-2 (dwg. 3370000000) - 35°C to +50°C.

NOTE: When operating at a temperature below zero do not use the clock of the panel (dwg.37901.00.000); when operating the panel (dwg.3370000000) close the "CLOCK HEAT" switch.

KIA-2 mounting (dwg. 3790200000) is intended for attaching the II-2 gyro unit to the KIA-5 turn table. The II-2 gyro unit is secured on three steel posts screwed in the mounting base. The mounting attachment holes are displaced from the line of symmetry to shift the C.G. position of the II-2 gyro unit together with the mounting from the turn table axis of rotation when attaching the unit to the turn table.

This shift is made to prevent the turn table plays from affecting the accuracy of the turning angles measurement. The mounting weight is not more than 8.5 kg.

KIA-3 simulators (dwg. 379.03.00.000) are designed to indicate the II-4 servo units outlet shafts turning angles when checking the autopilot on the stand.

The simulator scale is graduated from 0 to $\pm 15^\circ$. Each degree division is divided into 10 parts i.e. the scale division value is equal to 6 minutes of arc. The angles are indicated by the pointer attached to the outlet shaft of the II-4 servo unit to be checked. The simulator weight is not more than 7.2 kg.

KIA-4 junction boxes (dwg. 379.04.00.000) are connected to the autopilot circuit when checking the autopilot on the stand to permit switching-on and checking of the II-4 servo units various control circuits. The junction box weight does not exceed 1 kg. The junction box schematic diagram is given in Fig. 14.

KIA-5 turn table (dwg. 379.05.00.000) is designed to set the II-2 gyro unit angle of turn about 3 mutually perpendicular axes. Angles of the table turn (see Fig. 15):

The turn tables mentioned above are in operation by careful handling and periodic maintenance operations performed as follows:

- a) once a month thoroughly wipe (without disassembling) the frictional surfaces of the lower and upper semi-cylinders with a clean cloth or rags and then cover them with a light coating of OKG-12-7 lubricant;
- b) adjust the angular play by means of eccentric bearings and locking screws.

The turn table weight is not more than 21 kg.

Connecting cables (dwg. 379.06.00.000) are intended to connect the autopilot units when checking the autopilot on the stand and to connect the H-2 gyro unit, removed from the missile, to the missile wiring system and KHA-I control panel when checking the autopilot in the missile.

Incorporated in the test equipment set are 12 connecting cables and KHA-I control panel power supply cable.




Fig. 15. KLA-5 Turn Table from Diagram.

THE GROUND TEST CONTROL PANEL (Type 71-10, 00.000) is a portable metal case containing (Fig. 16). The panel dimensions are 240mmx245 (prior to 1957) and 202x252x70 (after 1957).

The panel weight is not more than 1.5 kg. mounted in the panel using in the test panel carrying all the electrical units.

The auto pilot supplies 24V power at 26 A through plug connector No. 11 to the auto pilot board (rock plug connector to feed the test panel circuits).

The test panel schematic diagram is given in Fig. 17.

Furnished with the ground test control panel are 2 connecting cables to connect it to the auto pilot (one cable plug connector and special wiring power plug connector No. 12 (to simulate a combined operation of the auto pilot and K-12 station).

The test panel operation temperature ranges:

- a) panel with test instruments type 71-10, -20° to +50°.
- b) panel with test instruments type 71-10, -25° to +50°.




Fig. 16. THK Ground Test Control Panel

00.000) is a portable metal case construction (Fig. 16).
 The panel dimensions are 343x233x15 (front panel before 1957)
 and 302x252x32 (after 1957).

The panel weight is not more than 10 lb. and mounted to
 the panel casing in the form panel enclosure and the electrical
 units.

The autotest supplies 240 V through plug
 connector No. 12 to the autotest test plug connector
 to feed the test panel circuit.

The test panel operating voltage is 240 V.

Furnished with the ground test plug connector and
 connecting cables to connect it to the autotest test plug
 plug connector and circuit wiring ground plug connector
 No. 12 (to simulate combined operation of an autotest and
 T-1W station).

The test panel operating temperature range:

- a) panel with test instruments type T-1W, -21⁰ to 50⁰.
- b) panel with test instruments type T-1W, -21⁰ to 50⁰.





Fig. 16. IRLK Ground Test Control Panel



- 1) Board check
- 2) Power
- 3) Yaw
- 4) Pitch
- 5) Command No. 1
- 6) Command No. 2
- 7) Roll
- 8) Bases zero
- 9) Caged
- 10) All ready
- 11) Check
- 12) Emergency
- 13) 11-18 MD start
- 14) 11-18 MD unit simulator
- 15) Control surfaces position indicators (1-0-1MA)

Fig. 16. Ground Test Control Panel





Fig. 18. KP-1 Control Panel




- 1) Power 26 V . 2) Power.
- 3) Off 4) On 5) 17-18MG start
- 6) Winding selector switch
- 7) Signal. 8) 17-18MG timer
- 9) Panel. 10) 17-4 Servo unit
- 11) Feedback. 12) Receptacle
- 13) Key to diagram

A - D.C. ammeter with the scale range of 0-10 A,
2.5 degree of precision

V - D.C. voltmeter with the scale range of 0-30 V,
3.5 degree of precision

MA - milliammeter model M5-2 with the scale range
of 1-0-1 with $\omega_1, \omega_2, \omega_3$ shunts connected, the
scales are respectively 1.5-0-1.5; 2.5-0-2.5, 50-0-50.

Fig. 19. III-1 Control Panel (continued)



- 1) Power 26 V . 2) Power.
- 3) Off 4) On. 5) 7-18MO start
- 6) Winding selector switch
- 7) Signal. 8) 7-18MO timer
- 9) Panel. 10) 7-4 Servo unit
- 11) Feedback. 12) Receptacle.


13) Key to diagram

A - D.C. ammeter with the scale range of 0-10 A,
2.5 degree of precision

V - D.C. voltmeter with the scale range of 0-30 V,
3.5 degree of precision


MA - milliammeter model M5-2 with the scale range
of 1-0-1 with $\omega_1, \omega_2, \omega_3$ shunts connected, the
scales are respectively 1.5-0-1.5, 2.5-0-2.5, 60-0-60.

Fig. 19. MI-I Control Panel Schematic Diagram




- 1) View without protective cover (5) and cover (2)
- 2) Inspection Department stamp here
- 3) View on arrow A, Scale 1:2

Fig. 20. KI-5 Control Panel




- 1) Gyromotors No. 489 00 02 000
- 2) Phase selector switch
- 3) Selector switch 578H
- 4) Load
- 5) Off
- 6) On
- 7) power
- 8) Off
- 9) On

Fig. 21. Control panel of the gyromotor




- 1) Gyromotors No 489 00 04 004
- 2) Phase selector switch
- 3) Selector switch 608W
- 4) Load
- 5) Off
- 6) On
- 7) power
- 8) Off
- 9) On




- 1) Gyromotors No. 489 00 04 060
- 2) Phase selector switch
- 3) Selector switch 5786
- 4) Load
- 5) Off
- 6) On
- 7) Power
- 8) Off
- 9) On

Fig. 21. 1-3) Gyromotor No. 489 00 04 060




- 1) Gyromotors No 489 00 04 060
- 2) Phase selector switch
- 3) Selector switch 578H
- 4) Load
- 5) Off
- 6) On
- 7) power
- 8) Off
- 9) On



- 1) Gyromotors No.489 00 04 000
- 2) Phase selector switch
- 3) Selector switch 578H
- 4) Load
- 5) Off
- 6) On
- 7) power
- 8) Off
- 9) On

Fig. 21. Control system of the gyromotors.



- 1) Gyromotors No.489 00.04.000
- 2) Phase selector switch
- 3) Selector switch 578H
- 4) Load
- 5) Off
- 6) On
- 7) power
- 8) Off
- 9) On

Fig.21. KI-5 Control Panel Schematic Diagram

The following information was obtained from a review of the files of the [redacted] and [redacted] and is being furnished to you for your information. It is noted that the [redacted] and [redacted] have been advised of the contents of this report and have indicated that they have no objection to its release to you.

The following information was obtained from a review of the files of the [redacted] and [redacted] and is being furnished to you for your information. It is noted that the [redacted] and [redacted] have been advised of the contents of this report and have indicated that they have no objection to its release to you.

The following information was obtained from a review of the files of the [redacted] and [redacted] and is being furnished to you for your information. It is noted that the [redacted] and [redacted] have been advised of the contents of this report and have indicated that they have no objection to its release to you.

The following information was obtained from a review of the files of the [redacted] and [redacted] and is being furnished to you for your information. It is noted that the [redacted] and [redacted] have been advised of the contents of this report and have indicated that they have no objection to its release to you.

The following information was obtained from a review of the files of the [redacted] and [redacted] and is being furnished to you for your information. It is noted that the [redacted] and [redacted] have been advised of the contents of this report and have indicated that they have no objection to its release to you.

The following information was obtained from a review of the files of the [redacted] and [redacted] and is being furnished to you for your information. It is noted that the [redacted] and [redacted] have been advised of the contents of this report and have indicated that they have no objection to its release to you.

The following information was obtained from a review of the files of the [redacted] and [redacted] and is being furnished to you for your information. It is noted that the [redacted] and [redacted] have been advised of the contents of this report and have indicated that they have no objection to its release to you.



Секретно

№ 1



1948

Секретно

№ 1

1948

1948

Секретно

2 14

SECRET

- 1. Introduction
- 2. Objectives
- 3. Scope
- 4. Methodology
- 5. Results
- 6. Discussion
- 7. Conclusions
- 8. Recommendations
- 9. References
- 10. Appendix
- 11. Glossary
- 12. Bibliography
- 13. Index
- 14. Distribution
- 15. Revision History
- 16. Approval
- 17. Revision
- 18. Distribution
- 19. Revision History
- 20. Approval

SECRET

- 21. Revision
- 22. Distribution
- 23. Revision History
- 24. Approval

Page 14

1. The ...

2. ...

The ...

... the ...

... the ...

c) ...

3. ...

...

...

... the ...

b) ...

c) ...

4 14

d) that a maximum error of the command initiating at the minimum A.G.C. voltage, is no more than $\pm 5\%$ of an established value;

e) when the command initiating missile is at a power level -45 dbm, the command is initiated at the distance "AII -K-48-B" under conditions, which are listed in the table N 1.

Table N 1.

Distance between mother-ship and missile	angle of missile deviation from target direction	linear missile deviation from target direction
10 km	24°	4.5 km
30 km	10°	5.45 km
50 km	6°	5.4 km
70 km	4.5°	4.5 km

- B. Unit dimensions: 170 x 170 x 170 mm³
- C. Unit weight: 3.5 kg/cm³

3. The elementary circuit description

The unit "C-48-B" is a relay device, which gives away the execution command (+27 v) for missile "KC" self-destroying to the autopilot elevation driver when the Radar A-regime A.G.C. output voltage is less than a preestablished value. The A.G.C. goes through the plug-connection "III -20" pin N 5. When missile "KC" guidance is normal beam-riding, the A.G.C. output voltage, applied to the balanced network, cutoff the unit from

Имя	К. № инж.	Инициал	Дата	Подпись	Код	№ докум.	Инициал	Дата	Подпись
Ф. А. А.									

- 6 -

Per. Inct 6 Micro 44

autopilot elevation driver. If the missile "XO" goes out from the K-118 beam, the A.G.C. voltage starts decreasing.

When it becomes less than a level necessary to hold the relay K2 in its "on" position, the +100 v is disconnected from the "memory" circuit capacitor C1.

The capacitor C1 starts discharging across the resistor R7 and the relay K1 windings and some time later the relay K1 opens its contacts and switches off +100 v from the relay K2 winding. With the relay K1 winding winding will be closed and the +100 v network voltage will be applied to the winding of the relay K5, which interlocks and gives away a control voltage +25 v through the plug III-21 to the relay K4 driver network.

The potentiometer R9 and the resistor R10 form the voltage divider of +25 v network. The potentiometer R9 serves for releasing the relay K1 releasing, lowest, when A.G.C. voltage level at the tube A2 control grid is constant.

The relay K2 provides the unit "6A 40-11" self-destroying command in the case, when the unit 6A-58P A.G.C. detector tube 6A-43 is defective. When this fact takes place the unit 6A-58E gives away a voltage approximately equal to +25 v + -30 v, the relay opens its contacts K 2 and K 3, +100 v is disconnected from the "memory" circuit and it will produce self-destroying command.

The resistor R6 is patched so, that the relay K2 operates, when the plug III-20 pin N 5 voltage is equal to 20 v ± 2v.

Исполн.	Проверен.	Дата	Подпись	Подпись	Дата	Подпись

The resistor R5 limits current flowing in the circuit's driver relay winding. The jack "P-I" provides monitoring of relay P-I releasing in checking the unit sensitivity.

№	Дата	№ пр.	Подпись	Дата	Лит. взм.	Кол	№ пр.	Подпись	Дата	Проверил

Лист 8 Агрегат

II. The unit operational instruction

1. General

- When the unit "CJ-10" is used it is necessary to:
- a) Set a necessary operating sensitivity of the unit.
 - b) Install the unit into the cable "A" and check its efficiency.
 - c) Check the unit efficiency, when several checking on the ground and in the air waves, etc.

2. Procedure of the unit operation when it is used in the control and in the detection:

Procedure

- a) after checking the wiring for Diagram 3-10 and the autopilot, do not switch off the equipment "CJ-10"; disconnect the cable "A" from the board 3-19 and connect it to the unit "CJ-10";
- b) connect the d.c. voltmeter (class 2.5 and scale range 0 - 100 v) to the jack "B-1" and to the ground;
- c) switch on the board 3-19, set an "A" input signal power equal to -43 dbm;
- d) turn the unit "CJ-10" potentiometer R9 knob "sensitivity" clockwise as far as it will go; when it will be done, the voltmeter must indicate voltage at the jack "B-1";
- e) turn slowly the potentiometer R9 knob counter-clockwise until the jack "B-1" voltage disappears;
- f) increase the signal power up to -43 dbm; voltage must appear at the jack "B-1" in this case;

Имя	Подпись	Дата	Проверка

- 11 -

[REDACTED] 11/14

c) measure time interval between the Radar 3-III transmitter switching off and the moment of the unit "3A-11" dive signal appearance. When the unit is operating normally, the pointer of the board "3K-17M" elevator indicator must deviate to the left at 2 ± 1 division in 0 ± 2 sec after the moment of the Radar 3-III transmitter switching off.

d) release the barrier "3K-17M", the indicator pointer must be set to the zero position.

Working conditions of the unit "3A-11" and the unit "3-III" are described in [REDACTED]

5. Requirements for storage of units

1. The units "3A-11" are allowed to be stored:

- a) in the object "3-III" in accordance with the object "3-III" work instructions;
- b) in separate units in [REDACTED] cases, which are [REDACTED].

5.1.2.1: Storage rooms must be ventilated (temperature, within $+5^{\circ} + +30^{\circ}$, relative humidity no more than 80 percent). Storage of the units together with acids, alkalies and poisonous substances is prohibited.

2. All the units must be packed, using board boxes (drawing N B П-4-180-015). Boxes, containing units, should be protected with a polychloropropyl cover and stored in a packing case (drawing N BR-39-00) in fours in each case.

Approved For Release 2011/02/07 : CIA-RDP82-00038R001400030001-4

11/14

- 12 -

Лист 12

Лист 14

6. Transportation of the units

I. The units are allowed to be transported in the above-mentioned packing.

a) by truck:

- max. distance 500 km at a speed no more than 30 km/hour (natural road) and at a speed of 40 km/hour (highway).

b) by rail, by water and by air:

- any distance.

7. Regulation works

I. Regulation works include:

a) superficial examination,

b) electrical parameter checking.

2. When the units C AKC-1A are installed in the objects "KC", the regulation works are to be carried out simultaneously with the regulation works of the object "KC".


3. When the units C KC-1A are stored in storehouses the regulation works must be carried out monthly.

8. Manufacturer's guarantee


The manufacturer guarantees 1000 operational cycles during 12 months from the date of arrival in the port of destination.

Ит. №	К-во	№ прик.	Подпись	Дата	Лит. ИЗМ.	Кол.	№ прик.	Подпись	Дата	Проверка	Разрб.

Ф. А. Ва




Appendix 12



N1	tube 6X15		
N2	tube 6X15		
R1	resistor MIT-1-10000-I	100 kohm	
R2	resistor MIT-1-10000-I	100 kohm	
R3	resistor MIT-25-6300-I	6.3 kohm	
R4	resistor MIT-1-63000-I	51-91 Kohm	
R5	resistor 1198-10-2400-100	24 ohm	
R6	resistor MIT-25-6300-I	6.3-12 Kohm	
R8	resistor 1198-10-7500-100	75 ohm	
R9	resistor 1103-11-1000-001	1000 ohm	
R10	resistor MIT-1-30K ± 1%	30 Kohm	
R11	resistor MIT-2-180-I	180 ohm	
P1	relay PNC-5		
P2	relay PNC-5		
P3	relay PDC-7		
P4	relay PIR-2		
P5	relay PIT-3		
W-21	socket WAP004378		
W-20	socket WAP83267WE		
C1	monitoring jack capacitor K61-2-206-251	25 uF	
Symbol	name and mark		


Appendix 12.



A1	tube 6XK15		
A2	tube 6XK15		
R1	resistor MIT-1-100000-2	100 Kohm	
R2	resistor MIT-1-10000-2	100 Kohm	
R3	resistor MIT-05-6800-2	6.8 Kohm	
R4	resistor MIT-1-68000-2	51-91 Kohm	
R5	resistor 198-10-240M-10%	24 ohm	
R6	resistor MIT-02-6800-2	6.8-12 Kohm	
R8	resistor 198-10-750M-10%	75 ohm	
R9	resistor 1173-11-1000-0%	1000 ohm	
R10	resistor MIT-1-302 ± 1%	30 Kohm	
R11	resistor MIT-2-180-2	180 ohm	
P1	relay PRC-5		
P2	relay PRC-5		
P3	relay PDC-7		
P4	relay PRT-2		
P5	relay PRT-3		
W-21	socket WP2004378		
W-20	socket WP48326742		
F1	monitoring jack		
C1	capacitor K511-2-200-6-25%	25 MF	
Symbol	name and mark		

The unit CMC-14 elementary diagram


Appendix 12.



A1	tube 6X15		
A2	tube 6X15		
R1	resistor MIT-1-10000-Ω	100 Kohm	
R2	resistor MIT-1-10000-Ω	100 Kohm	
R3	resistor MIT-05-6800-Ω	6.8 Kohm	
R4	resistor MIT-1-68000-Ω	51-91 Kohm	
R5	resistor 119A-10-240Ω-10%	24 ohm	
R6	resistor MIT-02-6800-Ω	6.8±12 Kohm	
R8	resistor 119A-10-75Ω±10%	75 ohm	
R9	resistor 1173-11-1000Ω	1000 ohm	
R10	resistor MIT-1-30Ω ± 1%	30 Kohm	
R11	resistor MIT-2-180-Ω	180 ohm	
D1	relay P1C-5		
D2	relay P1C-5		
D3	relay P1C-5		
D4	relay P11-2		
D5	relay P11-3		
W-21	socket WIP2004378		
W-20	socket WIP483267.W2		
J1	monitoring jack		
C1	capacitor K60-2-200-6-25-Ω	2.5 μF	
Symbol	name and mark		

The unit CMC-14 elementary diagram

Appendix 1/2



U-21	4	+27v
	3	+27v
	2	to driver
	1	to driver
U-20	1	to driver
	5	to driver
	2	-27v
	21	to driver
	26	+27v
	22	+130v reg
	14	command
P1		tube 6X15
P2		tube 6X15
R1		resistor MIT-1-10000-Ω
R2		resistor MIT-1-10000-Ω
R3		resistor MIT-25-6800-Ω
R4		resistor MIT-1-6300-Ω
R5		resistor 198-10-240Ω-10%
R6		resistor MIT-45-6800-Ω
R7		resistor 198-10-75Ω-10%
R8		resistor 198-11-1000-Ω
R9		resistor MIT-1-30Ω ± 1%
R10		resistor MIT-2-180-Ω
P1		relay PNC-5
P2		relay PNC-5
P3		relay PD47
P4		relay P11-2
P5		relay P11-3
U-21		socket WIP2014378
U-20		socket WIP483267142
T1		monitoring jack
C1		capacitor K50-2-200-6-25-T
Symbol		name and mark

The unit C1K-1A elementary diagram

**INVERTER MODEL ΠΑΓ-1ΦΑ
DESCRIPTION**

INVERTER MODEL HAI-10A

DESCRIPTION

INVERTER, MODEL HAT-10A

DESCRIPTION

I. GENERAL

The HAT-10A inverter is designed for feeding special units with a three-phase 400 c.p.s. A.C. and represents a unit consisting of a D.C. motor with compound field winding and a three-phase A.C. generator excited by a rotor permanent magnet.

The inverter is provided with a special filter (see the diagram) used for suppressing the inverter radio-noise, the filter consists of three interlocking and one duct capacitors and a choke.

The inverter is connected to the missile electrical system by means of a five-pin plug connector.

The inverter is provided with a built-in adjusting resistor connected in the electric motor shunt winding circuit for maintaining the generator frequency and voltage constant at different ratings.

II. TECHNICAL DATA

A. FOR THE ELECTRIC MOTOR

- 1. Terminal voltage 27 ± 10 % V
- 2. Current drawn not more than 3.5 A
- 3. No-load current at supply voltage of 27 V not more than 2.2 A

- 4. Speed of rotation 8000±10% r.p.m.
- 5. Duty continuous
- 6. R.H. direction of rotation
(as viewed from the commutator end)

B. FOR THE GENERATOR:

- 7. Voltage 36 ± 4 V
- 8. Output current not more than 0.51 A
- 9. Power factor 0.65
- 10. Frequency 400 ± 10% c.p.s.

C. MTC-7 BRUSHES ("7" - a specific Mir's Mark)

- 11. SIZE 6.5x7x14 mm.
- 12. Quantity 2
- 13. Tension on brushes 225±25 gr

D. MAGNETO-TYPE BALLBEARINGS No. 6007... 2

E. Weight not more than 3.5 kg.

III. INVERTER ELECTRICAL SYSTEM

The inverter wiring schematic diagram is given in Fig.1.

IV. DESIGN

The inverter is provided with a fan-assisted cooling (Fig.2).

The iron laminations of the electric motor and generator stators are mounted in a common casing (1), cast integral with a support.

The electric motor armature and generator are mounted on a common shaft (2). The electric motor magnet system rotor

s two-pole. The electric motor field coils windings (3) are connected in series.

The end of the series field winding is connected to the positive brush-holder.

The end of the shunt field winding is connected to the regulated adjusting resistor (12) located in the support.

The negative brush-holder wire is directly connected to the plug connector, and the common field winding end-to the plug connector (Fig.1) via the duct capacitor and the choke mounted on the end housing assembly (4).

The generator stator winding ends and electric motor filter wires are connected to the plug connector (6) through the holes in the end housing assembly.

The inverter plug connector pins designation corresponds to those in the schematic diagram (Fig.1).


The adjusting resistor (12) mounted in the support is designed for adjusting the A.C. frequency with the inverter operating at a nominal load.

The position of the adjusting resistor slider in the electric motor shunt winding circuit is set at the Mfr's plant and is unchangeable during operation.

Mounted in the support beside the resistor, is the capacitor (11) connected in the filter circuit. The generator rotor is a permanent magnet made in the form of a six-pointed star.

Brushes are inserted in brass brush-holders mounted on the brush-holders bracket (7) which can be turned for adjustment purpose.

Two openings in the end housing assembly (5) covered with



- 1 Shunt.
- 2 Series.
- 3 Armature.
- 4 Generator.
- 5 Choke

Fig.1. Inverter Wiring Schematic Diagram




Fig.2. Inverter Cross-Section View

- 1 - Casing; 2 - shaft; 3 - field coil; 4 - end housing assembly; 5 - end housing assembly; 6 - plug connector;
- 7 - brush-holders bracket; 8 - end cap; 9 - stud; 10 - ball-bearing; 11 - capacitor; 12 - resistor.

the end cap (8) permit to inspect brushes with the end cap removed.

The end housing assemblies made of aluminium alloy are attached to the casing by two studs (9).

The armature is mounted on the magneto-type ball-bearings (10) which facilitate the inverter assembly and disassembly. The armature end play is compensated by four cylindrical springs producing an axial pressure on the ball-bearing outer race, from the commutator end.

V. INVERTER DISASSEMBLY AND RE-ASSEMBLY PROCEDURE

After the guaranteed service life has expired, disassemble the inverter when a trouble detected can't be remedied without disassembling the inverter and when it is necessary to replenish the ball-bearings lubricant.

If the generator rotor magnet was removed from the stator assembly it must be magnetized and stabilized at the MCr's plant. The armature should not be removed from the inverter if unnecessary.

Disassemble the inverter as follows:

- a) Remove the end cap from the end housing assembly;
- b) Disconnect the brushes and pull them out of the brush-holders;
- c) Disconnect the field winding end from the brush-holder and disconnect the wire leading from the brush-holder to the plug connector;
- d) Release the studs;

e) Disconnect the plug connector from the end housing assembly and unsolder the wires from the receptacle pins;

f) Remove the end housing assembly (5) from the casing; move the end housing assembly (4) 20-30 mm. away from the casing, unsolder the wires from the capacitors and choke, and remove the end housing assembly;

g) Pull the armature ^{out} of the casing from the generator end.

When pulling the armature out of the casing, tightly enclose the rotor in a steel tube to prevent the permanent magnet demagnetizing.

Re-assemble the inverter reversing the disassembly procedure. In this case do the following:

a) Before re-assembling the inverter, wash the ball-bearings with clean gasoline. Pack the bearing with a limited quantity of UNATIM-201 lubricant; apply the lubricant only to one side of the ball-bearing so that the lubricant would be flush with the bearing ball;

b) Insert the brushes into the brush-holders only after the inverter re-assembly is completed to prevent them from being damaged by the commutator butt.

Pay particular attention to proper fitness of the brushes to the commutator surface. Otherwise, fit the brushes to the commutator by using sandpaper 220 (ГОСТ 3647-47).

If the commutator is burnt, wipe it with a clean cloth slightly dampened with gasoline. Clean the commutator with sandpaper 220 (ГОСТ 3647-47).

c) Lock all attachment parts in the same way as they were locked before disassembly.

After the inverter reassembly is completed, check the armature for free rotation turning it by hand.

When rotating, the armature must not contact the poles and the commutator-the brush-holders.

Stiff or unsmooth rotation of the armature may result from misalignments due to a poor re-assembly.

The inverter insulation is tested:

a) on the motor side - by applying 330 volts A.C. for 10 sec. in this case the electrical circuit must be disconnected from the casing by raising the negative brush and
B9B-26X-85-II resistor clamp;

Apply the test voltage as follows:

one pole - to the inverter casing, the other - to the plug connector contact "1";

b) On the generator end - by applying 500 volts A.C. for 1 min.

Connect the terminals of the power supply source as follows:

one - to the casing, the other - to one of the plug connector contacts "3", "4", "5".

Check the insulation resistance by using a corresponding megohmmeter, connecting its terminals in the same way as they were connected when the insulation was tested.

In both cases the insulation resistance must be not less than 5 megohms.

VI. INVERTER INSTALLATION AND OPERATION INSTRUCTIONS

1. The inverter is installed in horizontal position, and attached by screws inserted through the support holes.

2. The inverter is designed for direct connection to the missile electrical system without any starting relays.

3. After the inverter is connected to the missile electrical system, fully tighten the plug connector coupling nut.

4. During the inverter service, periodically check its brushes and commutator for condition.

At normal operation the operating surface of the commutator is brown and not burnt.

If the commutator is burnt, clean the commutator as outlined in Section V.

Brushes worn by 10 mm. long or less must be replaced with the new ones of the same type.

The a.c. wires must be twisted inside the inverter and shielding conduits.

5. The inverter operates at:

- a) Altitude above sea level.....up to 15000 m.
- b) Ambient air temperature from -60° to $+50^{\circ}$ C.
- c) Relative humidity up to 93%.

**INVERTER MODEL ΠΑΓ-ΙΦΑ
DESCRIPTION**

**ILLUSTRATED LIST
FOR SPI II**






ILLUSTRATED







LIST










FOR GROUND EQUIPMENT
AND INDIVIDUAL SET








1:1








AIRCRAFT

Detail and equipment No	Case No	Name
<p>08K/04K</p> 		<p>Front shield.</p> <p>1 in set.</p>
<p>08K/015</p> 		<p>Rear shield.</p> <p>1 in set.</p>
<p>KC-9710-0</p> 	<p>1 item.</p>	<p>Fuselage front</p> <p>4 in set.</p>
		<p>Fuselage end.</p> <p>1 in set.</p>
<p>KC-7106-1110</p> 	<p>1-1</p>	<p>Cradle bonding strip.</p> <p>2 in set.</p>

Detail and equipment No	Case No	Name
<p>KC-9512-20</p> 	<p>Installed on item.</p>	<p>Wing rod-support 2 in set</p>
<p>08KC1054A</p> 		<p>Cover for preservation of item "KC" 1 in set</p>
	<p>1-1</p>	<p>Cover for front and rear cover of engine 2 in set</p>
<p>KC-9310-0</p> 		<p>Hangar trolley 1 in set</p>
<p>Артукун 4043</p> 		<p>Documentation bag 1 in set</p>
<p>MA-500M</p> 	<p>1-1</p>	<p>Converter spare parts 1 set</p>

Detail and equipment No	Case No	Name
4A-250M 	1-1	Spare parts for convertor. 1 set.
K1-M 	1-1	Spare parts for each radar station. 1 set.
KP-1 	1-1	Starting coil spare parts. 1 set.
	1-1	Electrical actuator. 1 set.
630613 	1-1	Stopvalve gaskets. 2 in set.
	1-1	Spare brush. 4 in set.
K1-3-0-002 	1-1	Wave guide section gasket. 5 in set.
	1-1	Brushes for electrical actuator. 2 in set.
	1-1	Spare parts for generator. 1 set.

Detail and equipment No	Case No	Name
		Illustrated List ground equipment 1 set.
	1-1	P.C.V. Bag for cradle attachment bolts. 1 in set.
<p>155H555-5-16-14</p> 	1-1	Bolt for hatch attachment. 20 in set.
<p>15A49-6</p> 	1-1	Spring washer. 4 in set.
<p>KC-7106-102</p> 	1-1	Cradle attachment bolts. 2 in set.
<p>KC-1800-80</p> 	1-1	Nut for wing attachment. 4 in set.
<p>KC-9530-30</p> 	1-1	Key for wing attachment. Supplied with each 2 item KC. 1 in set.
<p>KC-7901-3056x</p> 	1-1	Washer for wing pickups. 2 in set.

Detail and equipment No	Case No	Name
291C50-2-19-150 	1-1	Spring for wing attachment. 2 in set.
155H555-6-16-12 	1-1	Bolt for hatch attachment. 50 in set.
117-10 	1-1	Delayed action fuse. 2 in set.
KC-6100-18 	1-1	Ring gasket for KC-6100-140 valve ring. 5 in set.
KC-9530-50 	1-1	Key for cradle rigid mount bolts. Supplied with each 3 item KC 1 in set.
KC-8400-110 	1-1	Safety-bar extractors. 1 set
KC-6100-202 	1-1	Gasket for stop valve 1 in kit.

Inspector

SUPPLEMENT TO INSTRUCTION No. 369-13

I N S T R U C T I O N S

FOR CHECKING REFERENCE INSTRUMENTS ON PANELS

OF 369 ITEM TEST EQUIPMENT

I. INTRODUCTION

This instruction is to be adhered to, when checking the reference instruments on the ~~IIA-369~~ test equipment panels during their service and storage within the guaranteed service life. The checks are performed together with the periodic maintenance operations in accordance with this instruction.

II. GENERAL

The tests are to be carried out under the following conditions:

- a) at an ambient air temperature of $+20^{\circ} \pm 5^{\circ} \text{C}$;
- b) at an air pressure equal to the atmospheric pressure in the place of the test;
- c) at a relative air humidity of 30 to 80 per cent;
- d) the reference instruments should have valid certificates which certify their serviceability.

III. PERIODIC MAINTENANCE OPERATIONS IN SERVICE AND STORAGE

The periodic maintenance operations consist in checking the test panels and are performed to determine their serviceability or possibility of their further storage and also to bring them into conformity with the specifications, if necessary.

The periodic maintenance operations are performed by the technicians of the using organization or the Mfr's plant. Entries about the periodic maintenance operations performed are made in a special book by the engineer or chief technician of the organization.

The periodic maintenance operations are performed in the following manner and sequence.

After every 2 months:

1. Inspect all the plug connectors of the connecting cables for damage and corrosion, and remove dust and dirt from them. If corrosion signs are found on the pins, wash the pins with a brush dampened in alcohol and wipe with a cloth.

2. Remove the covers from the KMA-I, MI-I, MI-5, MEK test panels, inspect the outer surfaces of the panels, instrument panels and plug connectors for damage, panels for proper attachment and shock mounting.

Wipe the outer surfaces with a cloth to remove dust and moisture.

If the plug connector contacts are dirty or affected by corrosion, wash and wipe them clean as described in para. 1 of this instruction.

3. Check the knobs for attachment and tighten those loose.

4. If in operation of the MI-I test panel an unsmooth movement of the "Signal" milliammeter pointer occur due to a

dirty potentiometer, remove the panel and wipe the potentiometer with a chamois cloth slightly dampened in rectified alcohol.

- NOTE: a) Carry out the above described operations immediately after a defect is detected during the panel operation irrespective of the time the periodic maintenance operations are to be performed.
- b) When installing the panel on shock mounts, seal the panel with sealing compound by filling the sealing cup with the compound and place the cup under the panel attachment screw.

5. Check the panel electric instruments for accurate readings, taking into consideration that the test equipment for the 360 item is manufactured in the following two versions:

1) with reference instruments ensuring operation of the test equipment panels within the temperature range of -35° to $+50^{\circ}\text{C}$ (M5-2, S-42I, BI-4C).

2) with reference instruments ensuring operation of the test panels within the temperature range of -20° to $+50^{\circ}\text{C}$ (HMI-70, DMC, HMI-70, BI-4C).

Given below are permissible errors of the reference instruments for both versions of the test equipment. Therefore, when checking an instrument, refer to the tolerances for the type of the instrument whose error is to be checked.

Checking the Reference Instruments of AIA-I Test Panel

1. Check the operation of the control surfaces position indicators on the AIA-I test panel as follows:

- a) supply 26 V. D.C. to the 43/12(-)-43/13(+) pins;
- b) set the "PANEL POWER SUPPLY" switch to the "BOARD CHECK";
- c) supply 26 V.D.C. via a 20 kohms resistor to the 15-14, 16-17, 18-19 pins of plug connector Nq.43 in turn with the polarity indicated in table No.1.

In this case the indicator pointers should move to the right.

Table No.1.

Supplied voltage polarity		Indicator	Direction of indicator pointer deflection
+	-		
15	14	"Direction"	to the right
16	17	"Pitch"	to the right
18	19	"Bank"	to the right

Change the polarity of the supplied voltage; in this case the indicator pointers should move to the left.

2. Check the reading error of the panel power supply voltmeter by connecting to the 43/12-43/13 pins a d.c. reference voltmeter (0.5 degree of precision with the scale graduated from 0 to 30 V).

Difference in the readings of the two voltmeters should not exceed:

0.9 V - for the M5-2 voltmeter,

0.6 V - for the M5-10 voltmeter.

3. Check the control signal indicators for reading errors. For this purpose connect a d.c. reference milliammeter (0.5 degree of precision with a 4-0-1 ma scale to the 43/1-43/2 pins. Perform the check with the "PANEL POWER SUPPLY" switch in the "BOARD CHECK" position and the K_1 and K_2 buttons pressed. Turning the knobs of the signal preset units to both sides, compare the readings of the reference milliammeter and the control signal indicators at the scale points 0; 0.2; 0.4; 0.6; 0.8; 1. Difference in their readings, should not exceed:

0.04 ma for the IEMC milliammeter,
0.06 ma for the M5-2 milliammeter.

Checking the Reference Instruments of IEMC Test Panel

Test the control surface position indicators for proper functioning.

Supply 26 volts via a 20 kohms resistor in turn to the 14-15, 16-17, 18-19 pins of plug connector No.36 with the polarity indicated in table No.2, In this case the indicator pointers should move to the right.

Table No.2


Indicator	Polarity of voltage supplied to pins of plug connector No.36		Direction of indicator pointer deflection
	+	-	
"Direction"	15	14	to the right
"Pitch"	16	17	to the right
"Bank"	18	19	to the right

Change the supplied voltage polarity; this done, the indicator pointers should move to the left.

Checking the Reference Instruments of III-I Test Panel

1. To check the supply voltmeter reading error, proceed as follows:

- a) Supply +26 volts to the "+" terminal, and -26 volts to the "-" terminal of the panel;
- b) connect a reference voltmeter (0.5 degree of precision) and ammeter (0.5 deg. of precision) to the 1-2 sockets of the plug connector according to the following diagram:



c) switch on the "PANEL POWER SUPPLY" switch; in this case the pointers of all the voltmeters and ammeters should move to the right, and the difference in their readings should not exceed:

- 0.9 V for the M5-2 voltmeters
- 0.6 V for the IIM-70 voltmeters
- 0.28 A for the M5-2 ammeters
- 0.18A for the IIM-70 ammeters.

NOTE: To take the voltmeter readings, open the ammeter circuit by the switch K.

2. To check the "SIGNAL" milliammeter reading errors proceed as follows:

a) to the 3-4 plug connector sockets connect in series the reference milliammeter of 0.5 degree of precision with a 0-3 scale and the resistor of 100 ohms $\pm 10\%$;

b) set the "RANGE" switch to the "I-4" position;

c) set the "POWER SUPPLY" switch to the "ON" position;

d) set the "WINDING" selector switch to the "1" position, and the "SIGNAL" switch to the "1mA" position. Turn the "SIGNAL" preset unit knob on the panel clockwise, and compare the readings (on the points, marked with figures) of the panel milliammeter with those of the reference milliammeter. Difference in their readings should not exceed 0.07 mA.

e) change the polarity of the reference milliammeter connected and make a similar check, with the "SIGNAL" preset unit knob turned counterclockwise;

f) make a similar check, with the "Signal" switch in the "1.5 mA" and "2.5 mA" positions.

With the switch in those positions, the readings of the "Signal" milliammeter and the reference milliammeter should not differ in more than 0.09 mA and 0.14 mA respectively.

NOTE: For the KM-1 test panel whose "SIGNAL" milliammeter of IM-70 type has a "3-0-3" mA scale, the check is performed in a similar manner; difference between the readings of the milliammeters in this case must not exceed 0.11 mA.

Checking the Reference Instruments of NL-5 Test Panel

1. Check the power supply circuit voltmeter readings for error:

a) supply +26 volts to the "+26 V" terminal, and -26 volts to the "-26 V" terminal of the panel;

b) connect a reference voltmeter (0.5 degree of precision, 0-30 V scale) and an ammeter (0.5 degree of precision, 0-5A scale) to the 1-2 sockets of the cable plug connector according to the following diagram:




Diagram No. 1a

NOTE: If an static voltmeter (0.5 degree of precision) is used, disconnect the latter, when checking the ammeter.

c) switch on the "PANEL POWER SUPPLY" switch, this done, the voltmeter pointers should move to the right and difference between their readings should not exceed:

0.9 V for M5-2 voltmeters,

0.6 V for EE-70 voltmeters,

d) close the ammeter circuit by the "K" switch; in this case the ammeter pointers should move to the right and difference between the readings of both ammeters should not exceed:

0.15 A for M5-2 ammeters,

0.1 A for EE-70 ammeters.

2. Check the a.c. voltmeter and ammeter for loading error proceeding as follows:

a) set the phase selector switch to the "0" position;

b) connect a reference ammeter (0.5 degree of precision, 0-1A scale) and a reference voltmeter (0.5 degree of precision, 0-60 V scale) to the 5-4 sockets of the panel plug connector and supply voltage according to the following diagram:




Diagram No. 2.

c) switch on the "LOAD" switch on the panel: the panel ammeter and voltmeter pointers should move to the right.

In this case difference in the readings of the electric instruments should not exceed:

1.0 V for a 0-15 voltmeter,

0.03 ma for a 0-421 ammeter,

0.03 ma for a 0-70 ammeter.

When taking the voltmeter readings, open the ammeter circuit by the "K" switch.

