

INFORMATION REPORT INFORMATION REPORT

CENTRAL INTELLIGENCE AGENCY

This material contains information affecting the National Defense of the United States within the meaning of the Espionage Laws, Title 18, U.S.C. Sec. 793 and 794, the transmission or revelation of which in any manner to an unauthorized person is prohibited by law.

12 MAY 1965


S-E-C-R-E-T  
NO FOREIGN DISSEM

|                   |  |             |                      |
|-------------------|--|-------------|----------------------|
| COUNTRY           | USSR   | REPORT      |                      |
| SUBJECT           | Soviet English-Language Manuals on MIG-17 [FRHSCO] and MIG-21 [FISHBED] Aircraft | DATE DISTR. | 10 May 1965 50X1-HUM |
|                   |  | NO. PAGES   | 1                    |
|                   |  | REFERENCES  |                      |
| DATE OF INFO.     |  |             | 50X1-HUM             |
| PLACE & DATE ACQ. |  |             |                      |
| THRU              |  |             |                      |

The two Soviet English-language manuals described below  
shown on the manuals. No publishing data are

- | Att. No. | Title  |          |
|----------|--|----------|
| 1        | <u>Pilot's Instructions on Operation and Flying Technique of MIG-17 Aircraft and Its Modifications.</u> [108 pages]. Pages 38 and 39 are missing from the text.              | 50X1-HUM |
| 2        | <u>Maintenance of Airframe and Engine. Process Charts. Supplement to Instruction Guide No. 21.</u> [389 pages]. Pages 112, 113, 157, 184, and 185 are missing from the text. | 50X1-HUM |

Comment: No mention is made in the manual of an aircraft designation; however, the drawings in the manual show the MIG-21. A large number of parts designations begin with Ye6 and 72 [FISHBED C].



5  
4  
3  
2  
1

S-E-C-R-E-T  
NO FOREIGN DISSEM

GROUP 1  
Excluded from automatic  
downgrading and  
declassification

|       |         |           |           |     |     |     |     |     |
|-------|---------|-----------|-----------|-----|-----|-----|-----|-----|
| STATE | DIA     | ARMY      | NAVY      | AIR | NSA | NIC | OCR | SAC |
|       | Air/FTD | Army/FSTC | Navy/STIC |     |     |     |     |     |

(Note: Field distribution indicated by "#")

INFORMATION REPORT INFORMATION REPORT

**SECRET**  
NO FOREIGN DISSEM

50X1-HUM

**PILOT'S INSTRUCTIONS ON OPERATION  
AND FLYING TECHNIQUE OF MIG-17 AIRCRAFT  
AND ITS MODIFICATIONS**

**SECRET**  
NO FOREIGN DISSEM

GROUP 1  
Excluded from automatic  
downgrading and  
declassification



SECRET/NO FOREIGN DISSEM

50X1-HUM

PILOT'S INSTRUCTIONS ON OPERATION  
AND FLYING TECHNIQUE OF MiG-17 AIRCRAFT  
AND ITS MODIFICATIONS

SECRET/NO FOREIGN DISSEM

SECRET/NO FOREIGN DISSEM

50X1-HUM

PREFACE

The tactical fighter F4U-17 and its modifications F4U-17A (A, B), equipped with engine M-18 (or M-18), are noted for their high performance, powerful armament and special equipment, which allow them to carry out their combat missions at all altitudes, up to the maximum ceiling, in standard and adverse weather conditions in the daytime and at night.

The present instructions are meant as a pilot's guide on the operation and piloting technique of the F4U-17 aircraft and its modifications.

I. PREPARATION FOR FLIGHT

1. Before the flight, the pilot should receive a report from the ground engineer on the readiness of the aircraft for the flight mission and on the amount and grade of fuel (T-1, T-1 or T-2) filled into the fuel tanks.

INSPECTION OF AIRCRAFT

2. Examine the aircraft visually, acting with due care to avoid accidental firing of aircraft guns. While doing so, check to see that:

- (a) no dents or any other damage is observed on the fuselage skin, wing and tail units;
- (b) the deflection of the nose and main landing gear wheel tyres is normal;
- (c) the covers are removed from the guns and the pitot-static tube and no play is detected in the attachment bracket of the extension tubes;
- (d) the trim tabs of the elevator and ailerons are in the neutral position;
- (e) the organic glass panels of the cockpit canopy have no cracks and are clean.

3. If drop fuel tanks are available, check them for proper attachment and tightness, and see if the tank synchronized automatic jettison selector switch, mounted under the left cantilever of the aircraft wing, is in the ON (DOWN) position.

- 4. With air bombs suspended from the aircraft, check whether:
  - (a) the caliber and type of air bombs comply with the bombing missiles;
  - (b) the fuses which the bombs are equipped with are adequate;
  - (c) the air bombs are properly suspended and attached to the bomb racks, and the bomb doors are properly locked;
  - (d) the tank synchronized automatic jettison selector switch is set in the OFF (DOWN) position.

FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

DEFINITION OF COCKPIT

5. Examine the cockpit using a special lens-to holder installed at the port side of the aircraft cockpit. While doing so, check to see that:
  - (a) no foreign objects are found inside the cockpit;
  - (b) no water (ice) or foreign objects are present on the cockpit floor under the seat;
  - (c) the seat harness is properly straightened; the harness straps should be engaged with the hooks on the cockpit walls;
  - (d) the fire control push-button of gun H-37 mounted on the aircraft control stick and the air bomb tactical release push-button are covered with safety guards;
  - (e) the safety red cap is fitted on the air bomb emergency release push-button (which is located on the bomb assessment electric control panel);
  - (f) the canopy ejection levers (also used as the ejection seat firing mechanism) are tightly fitted to the seat arm rests;
  - (g) the ground locks are installed on the canopy ejection levers;
  - (h) the ground locks are installed into the ejection seat firing mechanism head;
  - (i) the flexible cord safety pin, connected with the sliding hood, is fitted into the firing mechanism head socket;
  - (j) the canopy ejection locks are securely fixed and the parts of the guiding beam locks, and the canopy rollers are free of dirt, ice crust or damage;
  - (k) the safety harness time release mechanism AL-5 is securely fastened on the right-hand seat belt and the mechanism pull cord is connected with the cord of the safety harness lock;
  - (l) the AL-3 time release mechanism is set for a time delay of 1.5 sec;
  - (m) the flexible pin of the AL-3 time release mechanism is locked and the flexible pin ripcord is fastened to the aircraft board;
  - (n) the control stick lock is released.
6. On aircraft mounting ejection seats with face screens the pilot should check to see that the ground safety lock is removed from the firing mechanism head in the rear section of the seat headrest, the air safety lock wire snap hook is connected to the canopy ring, and the safety lock is fitted into its seat.

PREPARATION OF ANTI-G SUIT HMK-I

7. The anti-G suit serves as a means for increasing the pilot's resistance to considerable G-loads, both in magnitude and time, arising during the flight.
8. Each fighter pilot should properly select the size of the HMK-I anti-G suit and fit it to suit his height (the sizes of the anti-G suits in relation to the pilot's height are given in the Operating Instructions on Anti-G Suit HMK-I). Depending on the season, the anti-G suit may be fitted both above the shirt, trousers and narrow-top high boots over the flying suit, and inside the fur or wide-top high boots.
9. The time required for fitting the suit must be about 5 to 8 minutes, and that necessary for putting on the fitted suit is 1 to 2 minutes.
10. While fitting or putting on the suit before the flight, check to see that the air bladder tightly fits the pilot's abdomen, the suit lacing is thoroughly tucked into the suit and the zipper on the trouser legs face inside. The anti-G suit should allow free movement on the ground and must not restrict the pilot's

actions inside the cockpit when operating the aircraft fittings and when entering the aircraft.

PREPARATION OF PARACHUTE

10. Before putting on the parachute, the pilot examines it and checks:
  - (a) the HMK-3 parachute release control unit for proper operation time adjustment (the unit's altitude adjustment must ensure parachute opening at an altitude of minimum 7000 m above the overflown terrain);
  - (b) the flexible pin of the parachute release control unit for proper locating and the ripcord for proper packing;
  - (c) the parachute release control unit flexible hose for a sound condition and secure connection to the flexible hose of the parachute;
  - (d) the parachute release control unit flexible hose for proper connection to the bearing strip of the parachute pack flap;
  - (e) connection of the parachute release control unit cord to the parachute ripcord and proper locking of the ripcord pin.
11. Close the parachute pack flap and put on the parachute.
12. It is allowed to lay the fitted parachute on the seat pan before the flight. In the latter case, the pilot or ground engineer attaches the parachute release control unit ripcord to the seat arm rest, before taking seat in the cockpit, and fastens the rip chain of the parachute oxygen apparatus to the ring on the left-hand control panel and connects the hoses of the parachute and aircraft apparatus.
13. Having taken his seat in the cockpit, the pilot should only put on and buckle the parachute harness. While doing so, he should make certain that the clothing and equipment items will not shift the canopy ejection lever in flight.

CHECKING OF AIRCRAFT EQUIPMENT AND FITTINGS AFTER ENTERING COCKPIT

14. Make sure the aircraft battery and all circuit breakers both on the right and left panels are cut off; pay special attention to the circuit breakers of aircraft armament.
15. Place the toes on the pedals under the straps and adjust the pedals according to the length of the legs.
16. Check height adjustment of the ejection seat (the eyes should be on a level with the sight reflector).
17. Check the fastening of the parachute release control unit flexible pin ripcord to the left arm rest of the ejection seat.
18. Release the shoulder harness, lifting the harness locking lever all the way up. After raising the shoulder harness to the rearward position, lock them by lowering the locking lever all the way down.
19. Lock the seat belt and shoulder harness, lean tightly against the back of the ejection seat and tighten up; first, the seat belt and, then, the shoulder harness. Check to see that the shoulder harness metal loops are properly aligned in the lock.
20. Give a command to the ground engineer to remove the ground safety lock pins from the ejection seat firing mechanism head and from the canopy ejection right-side handle.
21. Check if the ground safety lock pins are removed.
22. Check operation of the shoulder harness locking mechanism, for which purpose:
  - (a) lift the shoulder harness locking lever to the uppermost position;

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

- 6 -

- (b) leaning the body forward, check the tension of the shoulder harness springs.
- (c) Lean tightly against the back of the ejection seat, lower the shoulder harness loading lever all the way down and, tilting the body, check if the harness is locked.
- 20. Make sure the sliding hood is properly closed and can be easily opened.
- 21. Check the aircraft engine control lever for smooth travel.
- 22. Check to see that the reserve of compressed air in the air supply system is sufficient. Air pressure should be:
  - (a) in the main bottles - minimum 120 kg/sq.cm;
  - (b) in the landing gear emergency bottle - minimum 30 kg/sq.cm;
  - (c) in the flight emergency bottle - minimum 120 kg/sq.cm.
- 23. Check the braking system for airtightness and the brakes for proper adjustment. With the brake lever pressed right hand and the pedals in the neutral position, there must be no hissing of escaping air and the pressure gauge should read  $11 \pm 1$  kg/sq.cm. The deflection of the pedal should be followed by a rapid pressure drop to zero in the braking system of the wheel which is opposite to the depressed pedal. During the braking cycle (at the end of travel of the brake first-stage lever), the pressure gauge should read 8 kg/sq.cm.
- 24. Check the control stick and pedals for freedom of movement and the control surfaces for proper response.
- 25. Close the canopy and check the canopy locks for proper engagement; check the canopy pressurizing hose for condition, for this purpose, turn the pressurizing valve handle to the right, thereby filling the hose with air. While doing so, no hissing of the escaping air should be heard.
- With the check over, set the pressurizing valve handle in the original position, thus releasing air from the hose, then, open the canopy.
- Caution.** Do not check the condition of the pressurizing hose with the canopy open, to avoid the break of the hose.
- 26. Check if the control knob of cockpit pressure controller P2-22W is properly secured.
- 27. Check the charging of aircraft battery under load, for which purpose cut in the battery and the radio set circuit breaker and press the voltmeter push-button (the battery voltage should be minimum 26 V). After checking, cut off the radio set.
- 28. Give a command **UT IS HERE SUPPLY** and, on receiving the ground engineer's back report **POWER SUPPLY OK**, check by the voltmeter scale if external power supply is properly connected (the voltage should be minimum 24 V).
- 29. Cut in the gyro horizon circuit breaker and the NFM remote-reading gyroscopic compass to prepare them for operation. The ground of the AF-1 gyro horizon develops a speed ensuring normal operation of the gyro horizon three minutes after power supply has been cut in. The serviceability of the NFM remote-reading gyroscopic compass is restored one minute after cutting in the circuit breaker.
- Note.** To provide for the minimum time space required to bring the AF-1 gyro horizon to the operating condition, before cutting in the AF-1 gyro horizon, keep the button pressed for 3 - 4 seconds and then release it. When the temperature is below  $-30^{\circ}\text{C}$ , keep the push-button pressed for 5 - 8 seconds.
- 30. Put in the circuit breaker of the trim tab and check operation of their electric actuators. If the elevator trim tab switch is pressed forward, the trim

- tab must deflect upward and if the switch is depressed back, the trim tab should deflect downward.
- When pressing the aileron trim tab selector switch to the left, the trim tab should deflect downwards, and when pressing it to the right, the trim tab should deflect upwards.
- Set the trim tab neutral (the elevator trim tab is set by the white signal lamp).
- 31. Check the landing gear warning system for proper functioning. With the warning system operating properly, three green warning lights should flash up and the landing gear strut position indicators on the wing and fuselage should be in the extended position. To check the condition of the landing gear UP position warning lights, press the check button; as a result, the red warning lights should flash up.
- 32. Cut in the instrument circuit breaker. While doing so, the pointers of the fuel and oil pressure gauges should be set at zero, the oil thermometer pointer should read the inlet oil temperature, and the fuel level gauge pointer should cross against scale division 1050 litres.
- 33. Check the readings of the clock and wind it, if necessary.
- 34. Set the altimeter pointer at zero.
- Caution.** Before the flight, check the condition of the barometric altimeter, comparing the value of its surface pressure obtained from the pressure-logical station with the pressure read by the altimeter set at zero altitude.
- 35. Check the operation of the gyroscopic compass, for which purpose, pressing the push-button allows the systems of the NFM remote-reading gyroscopic compass. The compass index pointer should read the aircraft heading card, with the rack and pinion shifted to the left or to the right, the compass pointer should follow the turning scale.
- 36. Check the condition of the gyro horizon (for tilt of the instrument gyroscope). Then, cut off the instruments.

RADIO EQUIPMENT OPERATION CHECK

- 37. To check the operation of the radio set, proceed as follows:
  - (a) connect the detachable plug socket of the telephone cord;
  - (b) set the selector switch on the radio set control panel in the RECEPTION (REPR) position;
  - (c) cut in the RADIO (RADIO) circuit breaker;
  - (d) wait 4 or 2 minutes and, then, cut in the necessary radio channel by pressing the push-button on the control panel;
  - (e) press the transmitter switching button and call the ground radio station;
  - (f) using the volume regulator on the control panel, select the necessary volume of signals received;
  - (g) check the operation of the radio set on the other three channels after receiving the ground station clearance.
- After checking the operation of the radio set, switch on the necessary radio channel and cut off the radio circuit breaker.

SECRET/NO FOREIGN DISSEM

Peep Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

## AIRCRAFT TRANSMITTER CHECK

39. To check the operation of the aircraft transmitter proceed as follows:
- cut in the AF-5 automatic radio compass and aircraft transponder circuit breaker, and the twin switch on the aircraft transponder control desk, as a result, the green signal lamp; and, thence (see second letter), the yellow signal lamp mounted on the control desk should light up;
  - set the required code on the aircraft transponder control desk;
  - cut off the aircraft transponder.

## AFK AUTOMATIC RADIO COMPASS CHECK AND TUNING

39. Check the operation of the AFK automatic radio compass in the following order:
- close the cockpit canopy (since the loop is located on the sliding hood);
  - set its operating zone and frequency of the outer homing station on the control panel;
  - set the remote radio compass range selector switch to the OUTER HOMING STATION (ZAKHODNAYA) position, cut in the selector switch whose operating zone is within the frequency of the inner homing station;
  - set the selector switch on the control panel of communication radio set (AFK) in the AFK position;
  - put the function switch on the radio compass control panel in the LOOP position;
  - cut in the AFK - BAKOR (AFK - MALYEP) circuit breaker and wait 1 - 2 minutes until the receiver lamps warm up;
  - rotating the receiver tuning handle, see that the tuning indicator pointer is shifted to the right as far as possible;
  - place the VOICE - ELY (IZP - IZT) selector switch on the compass control panel in the ELY position;
  - listen to the call signs of the homing station and make sure it is properly tuned to the outer homing station; set the required volume, if necessary, by turning the VOLUME CONTROL (PROMUKT) knob;
  - switch over the radio compass to the inner homing station, for which purpose, cut the INNER HOMING STATION - OUTER HOMING STATION (ZAKHODNAYA - ZAKHODNAYA) switch to the INNER HOMING STATION position;
  - listen to the call signs of the inner homing station and make sure the radio compass is properly tuned to it without additional trisling. If necessary, trim the radio compass to the inner homing station and, then, check tuning to the outer homing station;
  - set the selector switch in the COMPASS (KOMPASS) position and by reference to the AFK radio compass indicator make sure that the compass functions properly;
  - put the selector switch in the LOOP (PROMUKT) position and using the loop thumb lever, shift the indicator pointer 30 to 60° aside;
  - set the selector switch in the COMPASS position and make sure the indicator pointer has returned to the initial position;
  - cut off the radio compass circuit breaker.

## PB-2 RADIO ALTIMETER OPERATION CHECK

40. To check the operation of the PB-2 radio altimeter, proceed as follows:
- cut in the PB-2 - BAKOR (PB-2 - MALYEP) circuit breaker;
  - cut in the radio altimeter by turning the instrument handle, bearing the inscription G, in the clockwise direction;
  - set a range of 0 to 120 m by turning the RANGE (ZAKHODNAYA) handle to the left and wait 1-2 minutes until the transmitter-receiver valves are warmed up. With the radio altimeter functioning properly, the altitude indicator pointer should clear the lower stop and stop at the zero index-line, accurate within ±2 m;
  - cut off the radio altimeter circuit breaker.

## AIRCRAFT CHECK BEFORE THE FIRING AND BOMBING MISSION

41. Receive a report from the armament mechanic on the readiness of the aircraft armament and camera gun for firing. This report should include the following data:
- the guns which are prepared for firing;
  - the number of shells loaded per each gun;
  - the colours of shells (in case of practice firing);
  - the number of chafings required;
  - the types of bombs suspended and their fuses, and the value of time delay set.
42. Check if the sight reflector is clean.
43. Cut in the SIGHT HEATER (OSOPLET OPTIKALNAYA), SIGHT (OPREDEL), RADIO-RANGE FINDER (PAPAS) circuit breakers and check:
- the sight reticle lighting for smooth change;
  - operation of radio-range finder by changing the range setting from 450 to 900 m, with the base line being equal to 15 m, and the base setting from 7 to 45 m. For this purpose, set the RADIO - OPTICS (PAPAS - OPTIKALNAYA) change-over switch on the sight selector switch in the OPTICS position;
  - gyroscope electric motor for proper operation and the reticle for clear display when the switch handle is set to the GYRO (TRUP) position;
  - operation of radio-range finder (whether the high voltage lamp burns).
44. During this check, the sight selector switch should be set in the RADIO position.
44. Make sure there are two spare lamps for illuminating the sight in the cockpit.
45. Lock the sight gyroscope by setting the switch handle in the FIXED (ZEMELNAYA) position.
46. Check the bomb armament warning system, for which purpose put the ARMED - SAFE (BOPUS - NEBOPUS) change-over switch in the ARMED position. Cut in the air bomb tactical and emergency release circuit breakers and check:
- whether the two upper white warning lamps are lit up, indicating that air bombs are suspended from the bomb racks;
  - if the lower red warning lamp burns, indicating that air bombs will be released at ARMED.
47. After checking the bomb armament warning system, cut off the air bomb tactical and emergency release circuit breakers. Cut off the sight circuit breakers in the reverse order, i.e. first, cut off the RADIO - RANGE FINDER circuit breaker and, then, the SIGHT and SIGHT HEATER circuit breakers.

SECRET/NO FOREIGN DISSEM

Peer Original

**COCKPIT CHECK BEFORE NIGHT FLIGHT**

48. Before entering the aircraft, check:
    - (a) parachute oxygen apparatus and its boxes for anterior damage;
    - (b) oxygen pressure in the bottles of the parachute oxygen apparatus. The oxygen pressure indicator should read 150 kg/cm<sup>2</sup>;
    - (c) if the seal on the apparatus cover is intact;
    - (d) if the discharge pin is locked.
  49. Check the discharge pin of the parachute oxygen apparatus for proper position and seal length, absence of leaks at the pin ends and correct fitting into the safety ring.
  50. On entering the cockpit, connect the pull chain to the ring on the left-hand panel and attach the hose of the inboard oxygen regulator with the intermediate hose of the parachute oxygen apparatus. With the hose being shaken, oxygen should not leak from the parachute oxygen apparatus.
  51. Check the condition of the oxygen apparatus, oxygen mask, hose, oxygen-flow indicator, and pressure gauge; make sure they are free of anterior damage.
  52. Thoroughly fit the oxygen mask to the face and check the mask-to-face tightness, for which purpose clamp the corrugated hose and take a breath. If breathing proves impossible, the mask is airtight.
  53. Check the connection of the oxygen hose to the apparatus and the attachment of the oxygen mask to the corrugated hose.
  54. Check the airtightness of the oxygen low pressure system, for which purpose close the oxygen valve and the airtightness switch and take a breath. If breathing proves impossible, the low pressure system is airtight.
  55. Open the oxygen valve to repeatedly and make sure, by the pressure gauge readings, that the amount of oxygen available is sufficient.
  56. Check the supply of oxygen by the indicator, taking two - three breaths. While doing so, the indicator blinker segments should get apart during inhalation and close in during exhalation.
  57. Check the oxygen emergency supply system, opening the oxygen reducer emergency valve. With the emergency oxygen supply system functioning properly, the indicator blinker segments should get fully apart.
  58. After checking, close the emergency valve of the oxygen reducer.
- WARNING:** While checking the oxygen emergency supply system, do not hamper the flow of oxygen by holding over or compressing the corrugated hose of the oxygen mask.

**AIRCRAFT CHECK BEFORE NIGHT FLIGHT**

59. Refer to night flights, check the night lighting equipment, for which purpose:
  - (a) using the white lamp rheostat, set the required light brightness;
  - (b) set the landing gear warning lights blind in a position for a night flight;
  - (c) set in the navigation lights circuit breaker and make sure the navigation lights are in a sound condition;
  - (d) using the ultraviolet light rheostat, light up the ultraviolet lamps and

- after checking the lamps for proper condition, close the light filters and set the lamps approximately in the operating position;
- (e) set the headlight circuit breaker and switch in the EXTENDED (EXTENDED) position, make sure the headlight is in a sound condition and the light beam is properly directed, set the headlight switch in the EXTENDED (EXTENDED) position and cut off the headlight circuit breaker;
  - (f) cut in the sight circuit breaker and adjust the brightness of the sight device to the required value;
  - (g) open the blinds on all warning lamps, make sure they are in a sound condition and, then, close the blinds to obtain the desired light brightness;
  - (h) adjust the illumination of the instrument scales on the radio compass control panel by rotating the ILLUMINATION (ILLUMINATION) handle;
  - (i) check the condition and correctness of blind installation above the instrument panel for eliminating patches of light and reflection of instruments on the canopy glass;
  - (j) direct the part ultraviolet light on the flight instruments, and the starboard light - on the engine control instruments.

**TOWING OF AIRCRAFT**

59. The aircraft may be towed by a truck at a speed of 10 to 15 km/hr on a concrete tending strip and runway, and 5 to 6 km/hr, on an unprepared runway. During the towing, the pilot (or the ground engineer) should remain in the cockpit and keep his hand on the brake lever to brake the wheels, if necessary.
60. Aircraft towing at night should be performed with the navigation lights on.

**ENGINE GROUND STARTING**

61. The engine is started either from an external power source or from an aircraft power supply.
62. Before starting the engine, check to see that:
  - (a) the fire-fighting means are present nearby the aircraft;
  - (b) the wheel chocks are placed under the aircraft wheels;
  - (c) the aircraft battery and generator are cut in;
  - (d) the external power supply is cut in (when starting is performed from external power supply);
  - (e) the sight control handle is set in the FIXED position;
  - (f) the stopcock is closed (the stopcock lever is set in the UP (ВЕРХ) position);
  - (g) the GROUND - AIR (ЗЕМЛЯ - ВОЗДУХ) switch is set in the GROUND position (i.e. switched off).
63. Cut in the circuit breaker of the AN gyro horizon and the ANS pressure-reading gyrocompass and give the command BATTERY PLUGS, and on receiving the ground engineer's back report PLUGS REMOVED, prepare the equipment for starting the engine to this end:
  - (a) cut in the power plant control instrument circuit breakers IGNITION, STARTING PUMP (КАРТАЖИНА, ПУЩАЮЩАЯ НАСОС) and STARTING PUMP KEYS (ПРИЗ ВКЛЮЧЕН НАСОС) (while doing so, the red signal lamp will light up);
  - (b) cut in the circuit breaker of the fuel booster pump; in so doing, the starting pump red signal lamp will go out, thus testifying to the normal operation

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

- 12 -

(c) cut in the circuit breaker of the fuel transfer pump which pumps fuel from the rear fuel tank. With the pump operating properly and fuel available in the tank, the green signal lamp will light up and will cut immediately.

64. Before starting the engine call ALL CLEAR and on receiving assurance that all is clear, start the engine; for this purpose: (a) pull the engine control lever all the way back; (b) press the engine starting push-button for 1 - 2 seconds. On receiving the signal PLANK KEYS from the ground engineer, with the engine running at a speed of about 600 r.p.m., but not later than 10 - 12 seconds after pressing the starting push-button, shift the stopcock control lever to the starting (intermediate) position. As an ambient air temperature below 0°C, smoothly and quickly shift the stopcock control lever (after the engine has gained about 600 r.p.m.) to the fully open position (hereafter, the intermediate position) and in 1.5 - 2 seconds move it to the starting (intermediate) position.

After the engine has reached a speed of 900 to 1200 r.p.m., remove the stopcock control lever from the starting (intermediate) stop and smoothly shifting it at a slow rate, put the lever in the fully open position within 1.5 - 2 seconds, checking the temperature of exhaust gases, which should not exceed 650°C or 690°C, when the ambient air temperature is below -10°C.

Notes: 1. The starting of the engine may involve surging which is normally accompanied by a specific "rattling" noise. 2. In case of intensive "rattling" followed by failure of engine to pick up RPM and by excessive increase of exhaust gas temperature beyond the rated limits, cut off fuel supply, i.e., rapidly shift the stopcock control lever to the starting (intermediate) position and after the engine gains the starting (intermediate) position smoothly shift the lever within 1.5 - 2 seconds in the fully open position. If heavy "rattling" is repeated with the stopcock in the fully open position, cut off fuel supply again. 3. In case engine "rattling" may also take place with the stopcock lever in the starting (intermediate) position. If this is the case, cut off fuel supply by shifting the stopcock lever to the starting (intermediate) position, smoothly shift the lever to the CRV (CRUPTO) position.

Caution: If the engine control lever is pulled back incompletely, the engine will not start, since the power supply circuit interlock is cut in only when the lever is pulled all the way back.

65. With the engine control lever pulled all the way back, the engine gains the idle rating, at which the engine speed should be 2400 to 2600 r.p.m., the temperature of gas in the tail pipe should not exceed 540°C, and the oil pressure should not be more than 0.2 kg/cm<sup>2</sup>. Run the engine at the above rating for 1 minute and, then, proceed to test the engine. If the engine is intended to be operated for long at idle rating, prior to the testing (but not later than 15 minutes after the starting moment), first smoothly bring the engine speed to 6000 - 7000 r.p.m., then, wait 3 - 4 seconds and gradually decrease speed down to the idle rating.

66. Should the temperature of gas in the tail pipe be above or 550°C during the engine starting, stop starting the engine by clearing the stopcock. Repeat the engine starting after setting the normal voltage of current for starting place, with the voltage value being the normal voltage of the electric starter. Repeat the engine starting after setting the normal voltage of current for starting place, with the voltage value being the normal voltage of the electric starter. Repeat the engine starting after setting the normal voltage of current for starting place, with the voltage value being the normal voltage of the electric starter. Repeat the engine starting after setting the normal voltage of current for starting place, with the voltage value being the normal voltage of the electric starter.

67. Should unstable operation of the engine, followed by rattling, be observed in starting the engine, slightly shut off the stopcock (until rattling ceases), bear in mind that the engine starting cycle lasts at 2 - 3 seconds after which the starter is automatically cut off.

- 13 -

68. If during the engine starting, no ignition of fuel takes place, immediately close the stopcock, wait a little until the turbine stops rotating, scavenge (cold-start) the engine from the electric starter, with ignition cut off. Begin the repeated starting of the engine only after the end of scavenging (after the turbine has come to a standstill).

ENGINE GROUND TEST

69. After starting the engine and gaining steady idle rating (2400 - 2600 r.p.m.), give a signal for disconnecting the external power supply by waving the hand in the face level. Having made certain that the power supply is cut off, switch on the aircraft battery and generator immediately. Gradually bring the engine speed to 4000 r.p.m., make certain the generator functions properly; the red signal lamp GENERATOR CUT should go out as the engine gains a speed of 3200 to 3700 r.p.m. The operation of the aircraft generator can also be checked at a speed of 6000 to 6500 r.p.m. by the voltmeter, with the aircraft battery cut off; the voltage value should be within 26.5 - 28.5 volts.

70. Check the operation of the isolating valve, for which purpose set the engine speed at 6500 - 7500 r.p.m., cut in the isolating valve circuit breaker (the isolating valve signal lamp should light up) and determine the engine speed change as compared with the initial speed.

Operation limit of the engine speed drop, with the isolating valve on, is 250 r.p.m. The engine speed growth is not limited.

If, with the isolating valve cut in, no change of engine speed has occurred, check the valve for proper functioning at other speed rates, without getting beyond the speed limits of 6500 to 7500 r.p.m. Constant engine speed or its drop by more than 250 r.p.m., with the isolating valve cut in, testifies to the valve unserviceability.

Out off the isolating valve. As a result, the engine speed should resume the initial speed.

71. Warm up the engine at 8500 - 9000 r.p.m. within a minute at an ambient air temperature above -10°C, and at least within 2 minutes when the temperature of ambient air is -10°C and less.

Notes: 1. Take-off with a cold engine is allowed to be performed only in case of an electric take-off. 2. Do not run the engine at maximum speed, with oil pressure in the oil pump less than 1.5 kg/cm<sup>2</sup>.

72. Check the engine speed with the engine control lever set on the intermediate position. The engine speed should be 11,350 ± 50 r.p.m.

73. Check the operation of the engine at the take-off rating. The rate of travel of the engine control lever, with the speed increased from the isolating valve check rating up to the take-off speed, equals 4 - 6 seconds. With the engine running at the maximum speed, cut in the isolating valve and check the value of the speed increase. When the isolating valve is cut in at the take-off rating, the engine speed increases by not more than 50 r.p.m. or the engine speed drop by not more than 200 r.p.m. is allowed.

The readings of the engine control instruments during engine ground test at take-off rating are presented in Table 1.

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Table I  
Readings of Engine Control Instruments  
During Engine Ground Test at Take-Off Rating

| Parameters  | Instrument readings |
|---|---------------------|
| Engine speed, r.p.m.                                | 11,560-110          |
| Gas temperature, °C                                 | Maximum 630         |
| Fuel pressure before burners (reduced), kg/sq.cm    | 4.5 ± 0.2           |
| Fuel pressure (as read by pressure gauge), kg/sq.cm | Not more than 7.5   |
| Oil pressure, kg/sq.cm                              | 1.4 to 3.5          |
| Oil temperature, °C                                 | From -40 to +90     |

74. Check the operation of the APT-83 acceleration control unit from 5000 r.p.m. up to the maximum speed, for which purpose shift the engine control lever from the position corresponding to 5000 r.p.m. to the foremost position within 1 - 2 seconds, wait until the engine starts running at a steady maximum rating, then, pull the engine control lever to the rearward position.

With the acceleration control unit functioning normally, the engine should be accelerated from 5000 r.p.m. to the maximum speed within 11 - 15 seconds and short-time gas overtemperature should not exceed 770°C.

Short-time maximum overtemp caused by abrupt movement of the engine control lever, should not exceed 11,800 r.p.m.

75. In the course of the engine test run the pilot checks the cockpit pressurization, for which purpose he will:

- (a) close the cockpit canopy;
- (b) pressurize the cockpit by turning the cockpit pressurizing valve to the **FIGHT IN THE COCKPIT PRESSURIZED (АВИАЦИЯ ПЕРВОНАЧАЛЬНО)** position (up to the beginning of the coloured panel blue section). While doing so, a slight clicking sound should be heard.

Further turning of the pressurizing valve up to the next fixed position (at the end of the coloured panel blue section) will feel cold air into the cockpit, while turning the valve to the third fixed position (at the end of the coloured panel pink section) will feel warm air into the cockpit.

The cockpit tightness check is accomplished at engine take-off rating, with the pressurizing valve open completely.

The presence of smoke and oil or hydraulic fluid exhalation in the cockpit is not tolerated and indicates that the airdrafts in the engine section or in the cockpit are faulty.

**CHECK OF ALTIMETER DEVICE HXK-1**

76. To check the HXK-1 device with compressed air and the maximum G-load warning system, proceed as follows:

- (a) connect the rubber hose of the HXK-1 device (by means of a detachable coupling) to the aircraft supply line;
- (b) run the aircraft engine at 7000 to 8000 r.p.m.;

(c) set the HXK-1 automatic pressure controller and the HX-45 change-over switch in the **MINIMUM (МНН)** position and, then, in the **MAXIMUM (МНМ)** position, press the automatic pressure controller push-button in each of the above positions and make sure (by the pressure increase in the altimeter suit) that the controller functions properly.

**HYDRAULIC SYSTEM OPERATING CHECK**

77. While checking the engine, set the engine speed at 6000 r.p.m. and check the operation of the hydraulic system. The pressure readings of the hydraulic system gauges, with the valve in a neutral position, should be 60 to 70 kg/sq.cm. While doing so, the time interval between the shifts of the pressure relief valve should be within 2.5 minutes.

78. Move the flap control handle from the neutral to the take-off position, and after keeping it in this position for 1 - 2 seconds, send it to the flaps-down position (full down); the flaps should be fully extended within 2 - 3 seconds. The extension of flaps is checked by the light of the green signal lamp and by the complete protrusion of the mechanical indicator on the port wing. Synchronized extension of the right and left flaps is checked by the ground engineer.

79. To retract the flaps, shift the flap control handle to the flaps-up position (full up) without delaying in the take-off and neutral positions, while doing so the flap signal lamp should go out.

After the flap operational check is over, set the flap control handle to the neutral position.

80. To check the operation of the speed brakes, cut in the change-over switch on the aircraft port to the **OPEN (ОТКРЫТО)** position and make certain, by the light of the signal lamp, that the speed brakes are open. Retract the speed brakes, shifting the change-over switch to the **CLOSED (ЗАКРЫТО)** position. Check the operation of the speed brakes by providing the jamming on the aircraft control stick and ascertain their normal operation from the ground engineer's report.

At the time of the speed brakes retraction and extension the pressure in the system may drop below 60 kg/sq.cm.

81. Check the operation of the HX-1 altimeter control booster. The pressure in the system, with the hydraulic booster engaged, should be 60 - 65 kg/sq.cm. Apply pressure to the control stick and smoothly move it full left and full right 3 - 4 times. The control stick must move easily without binding or jerks. The movement of the control stick changes the pressure in the system within 15 - 15 kg/sq.cm (limited); the pressure returns to normal when the control stick movement stops.

Open and close the altimeter control booster valve two or three times. The valve must open and close easily without binding, with the altimeter control booster cut off, check the control stick for jamming, stoppages or excessive altimeter stick forces.

The time interval between the shifts of the automatic pressure relief valve, with the control stick in the neutral position and the altimeter control booster cut off, should be minimum 40 seconds.

**PREPARATION FOR FLIGHT-CHECK AND FLIGHT POINTS**

82. Having ascertained that the engine, instruments and aircraft assembled function properly, the canopy locks are correctly engaged (the red hatchmarks on the locks should align), and that the cockpit pressurization operates properly, lock the canopy harness, cut in the radio set circuit breaker, establish contact with the

SECRET/NO FOREIGN DISSEM

Peer Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

- 16 -

- 17 -

flight control officer and request clearance for taxiing out. Slave the EMV, re-  
tracting aerodynamic compass. To prevent overloading of the RP-1000 generator  
and protect the capacity of the battery, cut in the aircraft transponder, AIX-5  
automatic radio compass, and the radio-range finder sight before the flight.  
The above-indicated consumables may be cut in for a short time only.

91. Make certain the elevator trim tab is set in the NORMAL (NEUTRAL) position (to be checked by the signal lamp).  
Move the control stick to the left and ascertain that the trim tab on the port  
aileron is neutral.

92. When taking off from a limited runway or with drop fuel tanks, extend the  
flaps by 20°. This will reduce the take-off run by about 100 m.

93. Give the signal EMERG ASIR (by moving the hand palms to both sides on the  
head level) and brace the wheels.

94. Having made sure that the chocks are pulled away (the ground engineer stands  
ahead of the aircraft, check operation of the brakes. For this purpose, holding the  
aircraft in place by application of the brakes, move the engine control lever forward  
increasing engine speed to 10,000 r.p.m. Then, return the engine control lever to  
the idle cut-off position. The symmetrical operation of the brakes is checked  
during taxiing by changing the taxiing direction.

95. Having made certain once more that no obstacles are ahead in the direction  
of intended taxiing, increase the engine speed to start taxiing. With drop tanks and  
fuel tanks the taxiing speed must not exceed 30 km/hr on artificial runways and  
15 km/hr on covered runways.

Change the direction of taxiing by applying the brakes.  
Longitudinal rocking of the aircraft during taxiing should be eliminated by  
releasing the engine speed and by making use of the brakes.

96. The engine speed required for taxiing on paved runways is 1500 to 4500 r.p.m.  
and that on unpaved and rolled snow-covered runways is 2000 to 3000 r.p.m.  
While taxiing over boggy ground, accelerate the engine slowly to avoid its  
overheating.

When several aircraft are taxiing on dusty airfields, take into account the  
direction of wind and the distance between the aircraft to ensure operation of ad-  
vance constant dust clouds.

In winter cases, the taxiway leading to the runway may be covered with ice  
crust, and taxiing proves rather difficult, especially when the wind exceeds 6 m/sec.  
To avoid icing of the cockpit canopy and pitot-static tubes, caused by precipi-  
tation water that formed by the aircraft's landing in front, taxi the aircraft in  
short staccato runs with due consideration of the wind direction. The heater of the main  
pitot static tube and emergency pitot tube (MIPS) should be cut in.

97. While approaching the runway, look around and make sure the runway is free  
and there is no aircraft approaching for landing, then, request clearance to line  
up.

98. On entering the runway, roll the aircraft 5 - 10° ahead to align the nose  
with the runway. Release the landing gear control handle and cut in the land-  
ing gear circuit breaker.

99. Before taking off in adverse weather conditions and at night, make sure  
that the gyro horizon and generator functions properly and that the read-  
ing of the EMV retracting aerodynamic compass are correct.

92. Cut in the aircraft transponder, AIX-5 automatic radio compass, CFI-1  
radio-range finder sight and the pitot-static tube heater.  
Request take-off clearance.

II. TAKE-OFF AND CLIMBING

TAKE-OFF

93. Look around and make sure there are no obstacles ahead.  
94. On obtaining clearance for take-off, perform take-off immediately to clear  
the runway.

95. Holding the aircraft in place by application of brakes, increase engine  
speed to 8000 - 9000 r.p.m. and after ascertaining that the instruments read normally,  
release the brake lever and start the take-off run. In the course of the take-off run  
increase the engine speed to attain take-off power setting.

On aircraft equipped with an intermediate retainer on the engine control lever, an  
perform take-off at an engine speed of 11,350 ± 50 r.p.m. The take-off procedure at  
engine speed of 11,350 is the same and differs in that the take-off run in the later  
case is increased by 5 - 7%.

Note. When taking-off or while in flight for intermediate an actual air tem-  
perature, and also in other unfavorable cases (take-off from a short runway or soft  
ground), the pilot is allowed to run the engine at a rating of 11,350 r.p.m.

Whenever necessary, it is allowed to begin taking off without holding the air-  
craft in place by application of brakes, and also immediately after entering the  
runway so as not to stop the movement of the aircraft.

96. At the beginning of take-off run, keep the control stick in the neutral posi-  
tion. If the aircraft tends to turn to either side, counteract the tendency by ap-  
plying momentary pressure to the brake lever. With the aircraft translational speed  
increasing, maintain the take-off direction by deflecting the rudder.

In the process of the take-off run the aircraft is stable to maintain direc-  
tion without any tendency to turn. A crosswind of 90° and up to 30 m/sec velocity  
does not initially affect directional control.

97. After the aircraft has gained a speed of 170 km/hr, smoothly apply back  
pressure to the control stick and raise the nose wheel off the runway, keep the air-  
craft in this attitude until unstuck. At a speed of 220 to 230 km/hr the aircraft  
smoothly leaves the ground. It has no tendency to ballooning or stalling.

After unsticking, gradually gain altitude and simultaneously build up speed.

98. Retract the landing gear at an altitude of 40 to 45 m. During the retraction  
of the landing gear the speed of the aircraft should not exceed 300 km/hr. With  
the aircraft flying at a higher speed, the landing gear retraction time will in-  
crease and the landing gear may retract incompletely. The time normally required for  
retracting the landing gear is 6 to 8 seconds.

Check the retraction of the landing gear by the warning lights, mechanical indi-  
cators, and by the hydraulic system pressure, which must reach its full value.

Set the landing gear control handle in the NORMAL (NEUTRAL) position.  
If the landing gear has failed to retract or has retracted incompletely, check  
if the landing gear electrical switch is cut in. At an altitude of at least 500 m,  
decrease the engine speed up to 350 km/hr by performing shallow climbing and set the  
landing gear control handle for retraction.

After retracting the landing gear, set the control handle in the NORMAL posi-  
tion.

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

99. If take-off was made with flaps down, raise the flaps at an altitude of 100 m (after retracting the landing gear). Do not remove the hand from the flap control handle until retraction is completed; after this, set the flap control handle in the NEUTRAL position. While retracting the flaps, the pilot has almost no sinking sensation.

**TAKE-OFF FROM UNPAVED AND SNOW-COVERED RUNWAYS**

100. Take-off from unpaved and snow-covered runways with an even and sufficiently firm surface does not differ much from that performed from concrete runways. While taking off from unpaved runways having an uneven surface, the running aircraft experiences pitching and rolling, which cause heavy vibration to the control stick. With the speed increasing, the vibration of the control stick decreases and, then, disappears altogether without any interference on the part of the pilot. The rolling and pitching of the aircraft during the take-off run make it difficult for the pilot to determine the noise wheel position, therefore the nose wheel should be raised somewhat later, i.e. after the aircraft has reached a speed of 180 - 190 km/hr.

Longitudinal and lateral separation between the aircraft during formation take-off from an unpaved runway must be not less than 50 m. To avoid aircraft icing caused by precipitation of water dust in winter time, the aircraft must be spaced on the runway at a distance of minimum 50 m.

**CLIMBING**

101. After retracting the landing gear and flaps, unlock the safety harness, use the elevator and aileron trim tabs to counteract the control forces and continue to climb at a gentle angle, simultaneously increasing the flying speed to obtain the highest rate of climb speed at an altitude of 1000 m.

**Caution.** In aircraft equipped with irreversible hydraulic boosters in the elevator and aileron control system, do not use trim tabs in flight with the hydraulic boosters engaged.

102. Perform climbing at engine nominal rating (11,200 r.p.m.) and, whenever necessary to speed up climbing - at take-off (combat) rating (11,500 r.p.m.).

**Caution.** Continuous operation of the engine at take-off (combat) rating may be allowed in climbing for not more than 30 minutes. The operation of the maximum engine operation at nominal rating should not exceed 1 hour.

103. To gain the maximum rate of climb, the pilot will perform climbing by maintaining the trim stopped (as read by the trim pointer) equal to 720 km/hr at engine neutral rating, and 750 km/hr at take-off (combat) rating. With the altitude increasing, the indicated airspeed (as read by the thick pointer) will decrease by 30 - 25 km/hr per each thousand of meters (Table 2).

**Table 2**  
**Vertical Climb Speed and Indicated Airspeed VS**  
**FLIGHT ALTITUDE AND CLIMB TIME (min)**

| Flight altitude, m | n = 11,550 r.p.m.                  |                          | Vertical speed, m/sec | Climb time, min |
|--------------------|------------------------------------|--------------------------|-----------------------|-----------------|
|                    | Optimum rate of rapid climb, km/hr |                          |                       |                 |
|                    | V <sub>TAS</sub> , km/hr           | V <sub>TAS</sub> , km/hr |                       |                 |
| 1000               | 748                                | 750                      | 47.0                  | 0.35            |
| 2000               | 686                                | 750                      | 44.0                  | 0.7             |
| 3000               | 654                                | 750                      | 41.0                  | 1.1             |
| 4000               | 624                                | 750                      | 38.0                  | 1.5             |
| 5000               | 594                                | 750                      | 35.0                  | 2.0             |
| 6000               | 564                                | 750                      | 32.0                  | 2.5             |
| 7000               | 536                                | 750                      | 29.0                  | 3.0             |
| 8000               | 509                                | 750                      | 26.0                  | 3.6             |
| 9000               | 481                                | 750                      | 23.0                  | 4.3             |
| 10,000             | 454                                | 750                      | 20.0                  | 5.1             |
| 11,000             | 427                                | 750                      | 17.0                  | 6.0             |
| 12,000             | 399                                | 750                      | 14.5                  | 7.1             |
| 13,000             | 366                                | 750                      | 12.0                  | 8.6             |
| 14,000             | 340                                | 750                      | 10.0                  | 10.7            |
| 15,000             | 320                                | 750                      | 8.6                   | 14.6            |

**Notes:** 1. The climb time given in Table 2 does not allow for the time space needed for take-off run and acceleration of the aircraft up to climb speed, with the engine running at 11,550 r.p.m. only for 15 minutes, from any initial altitude.  
2. The required climb time, with the engine running at 11,350 r.p.m., increases on the average by 20 - 25%.

When climbing with the engine control lever kept constant on the intermediate position stop, the engine speed increases with the increase of altitude and may reach a value of 11,500 - 11,600 r.p.m. at altitudes of 8000 to 9000 m, depending on the flying speed value. Therefore, to keep the engine speed constant (11,350 r.p.m.), while climbing, the engine control lever should be gradually moved back.

104. During practice and training flights, when maximum rate of climb is not required, climb will be executed at an engine speed of 10,500 to 10,800 r.p.m.

105. Watch the readings of the engine control instruments, especially the temperature of gases, and see that the temperature of gases does not exceed 1100°C, with the gas temperature being in excess of the above value, decelerate the engine.

**III. MAXIMUM PERMISSIBLE FLYING SPEEDS**

106. The maximum permissible flying speeds are:  
(a) for altitudes below 3000 m - 1200 km/hr TAS;  
(b) for altitudes from 3000 to 7000 m - 1200 km/hr TAS;

SECRET/NO FOREIGN DISSEM

Peos Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

- 20 -

101. For altitudes above 7000 m the speeds of the aircraft are unlimited. Flying at maximum speed does not affect aircraft controllability.

102. If for some reasons the flying speed has become greater than the maximum permissible one, decrease it by extending the speed brakes and simultaneously changing the engine to the idle setting.

103. With the indicated airspeed reduced down to 200 - 250 km/hr, the aircraft loses its stability and stalls, with the landing gear and flaps retracted and with the engine running at idle rating.

The minimum maneuvering speed at all altitudes equals 300 km/hr IAS. At this speed the aircraft is fairly stable and the controls are sufficiently effective.

CHECK FLIGHT AND BALANCING OF AIRCRAFT NOT EQUIPPED WITH HYDRAULIC BOOSTER IN ELEVATOR CONTROL SYSTEM

109. If the MiG-17 fighters have been delivered to military units disassembled, carry out a check flight and a flight at maximum permissible speed after assembling the aircraft.

110. While carrying out a check flight, check the operation of engine, readings of instruments, flight control and navigation equipment, and other aircraft units, as well as the lateral and longitudinal balancing of the aircraft.

To check the lateral balancing of the aircraft in level flight at an altitude of 3000 to 4000 m, cut in the aileron hydraulic booster, increase indicated airspeed to 300 km/hr and use aileron trim tab to relieve the control stick of the aileron force. The longitudinal balancing check should be accomplished in the course of climbing immediately after the green warning lamp of the speed fuel tank has lit up (with fuel reservoir equal to 970 lit, and the C.C. location at 20.5% MAC).

With the elevator trim tab in the neutral position, the aircraft must balance (must have zero control force on the control stick) in climb from 3000 to 5000 m at engine nominal rating and at an indicated airspeed of 300 - 350 km/hr.

After landing, check the position of the aileron trim tab. If the aileron trim tab is deflected by not more than 250 mm and the longitudinal balancing corresponds to the specified value, and if no malfunction is detected in the operation of the aileron and other units, then, after a repeated detailed examination, the aircraft is considered fit for a check flight at maximum permissible airspeed.

111. To check the correctness of aircraft adjustment which ensures normal operation of the aircraft at maximum permissible airspeed, balance the aircraft longitudinally and laterally at an altitude of 3000 to 4000 m and an indicated airspeed of 300 km/hr, with the hydraulic booster engaged. Then, at an altitude of 3000 to 3500 m speed up the aircraft in level flight, with the engine running at a take-off (combat) rating (a = 11,500 RPM), up to an indicated speed of 1000 km/hr, under the above conditions the aircraft should not bank.

If necessary, the aircraft may be accelerated without slight descent. During acceleration check the aircraft slipping from the turn-around by instant 111). If banking occurs at a speed of less than 1000 km/hr, check the bank by turning the control stick.

In case the deflection of the control stick by 1/3 of its full travel fails to check the bank, stop accelerating the aircraft. For which purpose cut down the engine speed to the idle rating, extend the speed brakes and, after the speed has decreased by 30 - 40 km/hr, smoothly assume climb attitude, stop further checking the aircraft adjustment and perform landing.

The aircraft develops banking at an indicated speed of less than 1000 km/hr, and requiring deflection of the control stick by more than 1/3 of its full travel to counteract the banking, will be not considered airworthy and are subjected to further adjustments by the Manufacturer.

Note. Building-up of positive G-load at altitudes from 0 to 5000 m intensifies banking, therefore, to stop banking, it is necessary first, to decrease the aircraft speed by extending the speed brakes and turning from the engine to the idle setting, then, to speed the aircraft into climb.

During flights intended for checking the adjustment of the aircraft at maximum permissible speed rates, the pilot should not exceed the indicated airspeed of 1000 km/hr and descend to an altitude of less than 800 m.

The results of aircraft adjustment check in flight will be entered by the pilot in the aircraft Service log.

Caution. On aircraft equipped with irreversible hydraulic boosters in the elevator and aileron control system, do not use trim tabs during flights, with the hydraulic boosters engaged.

112. If the stabilizer is set properly, the elevator control forces on the control stick, with the trim tab being neutral, in flights at altitudes from 3000 to 7000 m and at flying speeds from minimum maneuvering speed to the maximum one, change but slightly and, therefore, there is no need to use the trim tab even during execution of flight maneuvers.

At altitudes up to 3000 m and at speeds close to maximum ones, it is advisable to balance the aircraft by using the elevator trim tab at an indicated airspeed of 300 to 500 km/hr.

At altitudes of 30,000 m, the pilot is advised to balance the aircraft by using the elevator trim tab at an indicated airspeed of 300 km/hr.

BALANCING OF AIRCRAFT EQUIPPED WITH IRREVERSIBLE HYDRAULIC BOOSTERS IN ELEVATOR AND AILERON CONTROL SYSTEM

Internal Balancing

113. To check the correctness of aircraft adjustment which ensures normal operation of aircraft at maximum permissible speed, disengage the hydraulic booster at an altitude of 5000 - 6000 m and an indicated airspeed equal to 450 - 500 km/hr (as read by the trim pointer of the speed indicator).

Balance the aircraft, if necessary, at the above speed by the aerodynamic trim tab of the aileron. Check the control force on the control stick equals zero. Note that, the aileron aerodynamic trim tab should not be used. This done, engage the hydraulic booster and check the lateral balance of the aircraft throughout the speed range.

Permissible deflection of the control stick for receiving the bank at maximum permissible speed is up to 1/3 of its full travel.

Note. The aileron control force on the control stick in a straight and level flight (without banking) at all speeds and altitudes, with the hydraulic

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

- 22 -

booster engaged, should not exceed 3 - 5 kg. If the control force exceeds the above limits, decrease it by respectively deflecting the ground-adjustable trim tabs on the trailing edge of the wing (but not on the aileron), when the aircraft is on the ground.

After carrying out the above-indicated lateral balancing, the position of the trim tab is considered balanced and the trim tab position should be checked before each start flight. The balanced position of the trim tab should be written down in red paint on the trim tab skin; the inscription should state the deflection value in millimeters.

Do not use the aerodynamic trim tab of the aileron when flying with the hydraulic booster engaged.

Longitudinal Balancing

114. With the aircraft flying at an altitude of 3000 to 4000 m at an indicated airspeed of 400 - 500 km/hr (as read by the thick pointer of the instrument), disengage the elevator hydraulic booster. Make sure the aircraft is changed to hand control. This done, speed up the aircraft (at engine nominal rating) until, if necessary, the elevator aerodynamic trim tab, to a true airspeed of 900 - 950 km/hr, at which the pressing force on the control stick should equal 5 - 7 kg.

Note. While performing a flight for aircraft balancing, the pilot should always keep in mind the standard diagram showing the change of the control forces on the stick depending on the true airspeed.

Then, without using the trim tab, continue to accelerate the aircraft and determine the true airspeed corresponding to the lowest point of the force versus speed curve, which should be approximately within 1000 - 1100 km/hr.

Stop accelerating the aircraft after ascertaining, by the sharply increasing pressing control forces, that the aircraft has passed the lowest point of the force versus speed curve.

On finishing the acceleration, reduce the engine speed and dissipate speed down to the speed value corresponding to the lowest point of the force versus speed curve.

Balance the aircraft by the elevator trim tab at the above true airspeed in a straight and level flight (without G-load), so that the force on the control stick is approximately equal zero (small pressing control force of 2 - 3 kg is tolerated).

After that, the elevator aerodynamic trim tab should not be used. This done, dissipate flying speed down to indicated airspeed of 450 - 500 km/hr and engage the elevator hydraulic booster. With the above balancing performed, the position of the trim tab is considered balanced and the trim tab position should be checked before each start flight.

The balanced position of the trim tab should be put down in red paint on the trim tab skin; the inscription should state the deflection value in millimeters.

Note: 1. If the hydraulic booster fails or cuts off, use can be made of the aerodynamic trim tab for decreasing the control force on the stick within the speed range from V<sub>0</sub> to 900 km/hr down to the landing speed.  
2. At flying speeds from 900 km/hr down to the landing speed, with the hydraulic booster disengaged, the aerodynamic trim tab should not be used.  
3. One should bear in mind that excessive friction in the hydraulic booster system, with the hydraulic booster disengaged, impairs the elevator control and may result in the aircraft pitching, especially during landing.

SECRET/NO FOREIGN DISSEM

- 23 -

With the elevator hydraulic booster engaged and the trimming effect mechanism set in the neutral position, the aircraft should balance (the control force on the stick should equal zero) in climbing from an altitude of 3000 to 6000 m, with the engine running at nominal rating at an indicated airspeed of 650 ± 50 km/hr.

ENGINE CONTROL IN FLIGHT

115. Table 3 provides the main engine ratings in flight.

Table 3

Main Engine Ratings in Flight

| Rating  | Engine speed, r.p.m.          | Gas temperature, °C | Continuous operation at given rating, min |
|---|-------------------------------|---------------------|---|
| Take-off (combat) rating up to H = 10,000 m (in level flight) | 11,560 <sup>+50</sup><br>-100 | 690                 | Not to exceed 5                           |
| Take-off (combat) rating above H = 10,000 m (in level flight) | 11,560 <sup>+50</sup><br>-110 | 690                 | Not to exceed 10                          |
| Take-off (combat) rating in climbing (at all altitudes)       | 11,560 <sup>+50</sup><br>-100 | 690                 | Not to exceed 10                          |
| Normal rating   | 11,200 <sup>+50</sup><br>-110 | -                   | Not to exceed 1 hr                        |
| Idle rating   | See Note                      | -                   | See Note                                  |

Note: 1. The speed value corresponding to the position of the engine control lever on the scale rating 4000 kg is variable and depends on the altitude and flying speed.  
2. With the engine running at 10,870 r.p.m. and above, the oil pressure should be minimum 1.4 kg/sq.cm, but should not exceed 2.5 kg/sq.cm.  
3. The oil temperature should be within -40 to +90°C.

116. With the flight altitude increasing, the temperature of exhaust gases increases too.

If the exhaust gas temperature exceeds 600°C, decrease the engine speed to return the gas temperature within the permissible limits.

117. In flight, the engine control lever may be advanced from idle to take-off (combat) rating within 2 seconds.

When carrying out any training exercise, do not allow sharp multiple advances of the engine control lever.

118. While in flight, do not exceed the engine speed of 11,350 + 50 r.p.m., except for cases of combat employment and correction of error in carrying out ascending maneuvers.

The time of engine continuous run at 11,350 + 50 r.p.m. is the same as for the take-off (combat) rating.

Continuous flights at ratings of 10,800 - 11,100 r.p.m. are inadvisable for engines, models EK-1 and EK-1A, and should not be used unless necessitated by the flight conditions.

119. If a new aircraft is received or when the engine has been replaced, check the operation of the AF-88 acceleration control unit in flight, for which purpose

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

- (a) check the engine maximum speed at an altitude of 10,000 - 11,000 m and a maximum flying speed (this check may be performed simultaneously with the aircraft high-speed stalling check). Under these conditions the maximum engine speed should be within 11,460 to 11,600 r.p.m.
- (b) at an altitude of 10,000 - 11,000 m set the indicated airspeed of 300 km/hr, with the engine control lever in the rearmost position. Then, move the engine control lever to the foremost position within 1 - 2 seconds and wait until the engine runs smoothly at maximum rating. If the acceleration control unit operates normally, the engine must attain take-off (cruise) rating without surging (individual slight back flares are tolerated), and the steady maximum speed of the engine should be within 11,460 to 11,600 r.p.m.
- (c) at an altitude of 10,000 to 11,000 m set the maximum level flight speed by smoothly moving the engine control lever, and check the steady maximum speed of the engine, which, with the AP7-53 acceleration control unit operating normally, should be within 11,460 - 11,600 r.p.m.
- (d) at an altitude of 14,000 - 14,500 m repeat the procedure indicated in Item (b).

**Procedure 1.** After checking the operation of the acceleration control unit, the maximum engine speed, and the maximum engine speed, the pilot should check the engine speed at an altitude of 14,000 - 14,500 m in good weather conditions. Prior to checking, the pilot should refresh his memory on position "Engine Starting in Flight".

**OPERATION OF PRESSURIZED COCKPIT**

- 120. Prior to flight at the flight altitude the MiG-17 aircraft should be flown with the cockpit pressurized.
- 121. Pressurize the cockpit on the ground before taxiing out to the runway.
- 122. Set the pressurization valve for feeding cold or hot air into the cockpit, depending on weather conditions and on the temperature of the ambient air.
- 123. In a warm season, when flying at an altitude of up to 5000 m in standard weather conditions, the pilot is advised to set the pressurization valve for feeding cold air into the cockpit.
- 124. While flying at altitudes above 5000 m as well as in a cold season, or when breaking clouds, the pilot is advised to set the pressurization valve for feeding hot air in order to avoid excessive cooling of the cockpit and dimming of the cockpit canopy.
- 125. When the cockpit canopy is dimmed, it is allowed to set the feed valve to the HOT (WARM) position in all flight conditions.
- 126. Depending upon flight altitude cockpit pressure is automatically maintained by the PZ-24 cockpit pressure controller.
- 127. The cockpit pressure is checked by the PZ-24 cockpit altitude and pressure differential gauge. Permissible pressure differential at altitudes above 5500 m, with the pressurized cockpit functioning normally, is within 0.26 to 0.32 kg/cm<sup>2</sup>.
- 128. To check the normal operation of the cockpit pressurizing system, the following rule should be used: upon the operation of the cockpit pressurizing system, the following hold the aircraft at the altitude:
  - 129. If the PZ-24 cockpit pressure controller fails to operate normally and the cockpit pressure increases by more than 0.32 kg/cm<sup>2</sup>, set the altitude pressure differential by turning the knob (cockpit pressure manual adjustment knob) on the PZ-24 cockpit pressure controller to the left.

- 127. Should smoke or unusual smell be detected in the pressurized cockpit during the flight at an altitude of up to 4000 m, immediately unpressurize the cockpit and cut in the velocity head ventilation.
- 128. If the flight is performed at an altitude of 4000 m, descend to 3000 m, since flying in an unpressurized cockpit will result in a negative pressure differential due to air reaction, which increases with the increase of flying speed. The difference between the true altitude and the cockpit "altitude" (as read by the cockpit altitude-and-pressure differential gauge) amounts to 4000 m.
- 129. Gliding will be performed only with the pressurizing valve set in a position for delivery of hot air. If canopy dimming is detected when descending from a high altitude, proceed as follows:
  - (a) check to see that the pressurizing valve is set in a position corresponding to delivery of hot air into the cockpit;
  - (b) when at an altitude of 6000 to 7000 m, turn the knob on the PZ-24 cockpit pressure controller all the way to the left.
- 130. If canopy dimming interferes with landing, increase engine speed up to nominal one for 1 - 4 min at an altitude of minimum 500 m. With the speed increasing 550 - 600 km/hr, extend speed brakes to prevent speed increase.
- 131. It is advisable to use the cockpit velocity head ventilation shutter at altitudes up to 25000 m in summer, when the temperature inside the cockpit is rather high.

**USE OF OXYGEN IN FLIGHT**

- 130. Fly the aircraft only with the parachute oxygen apparatus connected to the aircraft oxygen supply system. Put on the oxygen mask and cut in oxygen supply on the ground. When flying at altitudes above 8000 m, cut off the air-dilution switch and use pure oxygen.
  - 131. When using the oxygen equipment in flight, watch the consumption of oxygen by the pressure gauge, and the oxygen supply by the indicator. If oxygen pressure in the bottle is less than 30 kg/cm<sup>2</sup>, descend to an altitude, where no oxygen supply is required.
  - 132. In all cases of improper functioning of the aircraft oxygen apparatus, unpressurizing of cockpit, or when conducting an air battle, cut in the emergency oxygen supply.
  - 133. If the oxygen supply system fails to operate properly (the indicator blinker segments are either still or respond weakly), pull out the disconnecter pin, pass over to oxygen supply from the KM-23 parachute oxygen apparatus, and discontinue the high altitude flight.
  - 134. On detecting smoke or unusual smell in the cockpit, close the air-dilution switch on the oxygen apparatus. When flying above 5000 m, descend to an altitude below 3000 m, unpressurize the cockpit gradually and open the velocity head ventilation shutter.
  - 135. Cut off oxygen supply and remove the oxygen mask, after high-altitude flying, at an altitude of maximum 2000 m.
- FLIGHT WITH DROP TANKS**
- 136. The aircraft is designed to carry two drop fuel tanks of 400-lit capacity each.
  - 137. Take-off with drop fuel tanks filled to capacity does not differ from that

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

When drop fuel tanks are used for the increased length of take-off run, location of take-off run and landing speed. Before take-off, make sure the circuit breaker on the right-hand electric panel bearing the inscription BOMBS (BOMBS), is set in the OFF (BARRIÈRE) position. On the left switch 2B-45, bearing the inscriptions TACTICAL RELEASES (DÉPARTÉMENT DÉROGÉ), ARMED (ARMEMENT HAUT POURS), DROP TANKS (CONTROLES SAUF) on the left control panel, and the circuit breaker with the inscriptions EMERGENCY BOMB RELEASE, JETTISONING OF TANKS (ARRÊTÉMENT DÉROGÉ BOMBS, DÉROGÉ SAUF) on the right-hand electric panel.

143. Flights with drop tanks are performed within the following maximum speed limits:

- (a) from H = 0 to H = 4000 m - at an indicated airspeed of 900 km/hr;
  - (b) from H = 4000 m and above - at a true airspeed of 900 km/hr.
- Maximum permissible load factor with fuel tanks filled to capacity is not to exceed 4.5, and that with empty tanks - 6.5.

The behaviour of the aircraft in the above conditions is similar to that of the aircraft not carrying drop tanks.

144. Fuel consumption from the drop tanks is checked by means of a warning lamp which lights up when fuel is used up completely from the tanks.

Note: 1. The drop tank warning lamp may light up when fuel in the drop tanks is used up incompletely, with the engine running at a speed less than 800 km/hr. If, with the engine speed exceeding 800 km/hr, the warning lamp does not go out, it means that fuel has been fully used up from the drop tanks.

2. During continuous flight at high indicated airspeeds and high altitudes, the rate of fuel consumption from the drop tanks is allowed down (with the engine running at constant and constant ratings at H = 10,000 m, the fuel from the drop tanks will be consumed within 53 - 54 minutes).

145. The landing procedure of the aircraft with two empty fuel tanks of 800-litre capacity each, does not differ from that without tanks. If fuel has not been used up from the drop tanks (owing to malfunction of aircraft equipment), it is allowed to perform landing with the filled fuel tanks at a gliding speed of 290 - 300 km/hr. 146. In case one of the drop fuel tanks has been swept off and the automatic tank jettison control unit (AUC) has failed to operate, take measures for jettisoning the other tank. If for some reason or other the second drop fuel tank could not be released, land the aircraft with one drop tank. Landing with one non-jettisoned fuel tank filled to capacity in one drop tank. Landing with one non-jettisoned towards the non-jettisoned tanks; therefore, such a landing requires special attention on the part of the pilot and appropriate disposition of the control stick to the deflection to check the bank, during floating before landing, will increase with the landing speed.

147. Crosswind landing with one drop tank filled with fuel will be made into the wind or with the remaining tank before up the wind. Speed gliding for landing will attain the following speeds:

- (a) with the fuel tank filled with fuel to 50% of 290 km/hr, the landing pattern should be performed normal;
- (b) with the tank filled to capacity - minimum 300 km/hr.

148. Crosswind landing should be performed at a higher speed than normal. Performed only when the fuel tank is filled to not more than 50% and the wind velocity does not exceed 5 m/sec. If this is the case, maintain the gliding speed of not less than 290 km/hr, perform floating and touchdown at a higher speed than normal.

144. Landing with one fuel tank filled to capacity, when a crosswind is blowing from the side of the jettisoned tank, is prohibited.

145. When making approach for landing with one remaining fuel tank, perform turns, if it is possible, to the side of the jettisoned tank at a bank not exceeding 40°.

Note: The amount of fuel left in the remaining tank can be approximately determined by the pilot before making approach for landing of the prescribed steepest descent required for reaching the bank. While gliding at an indicated airspeed of 350 km/hr, the amount of control stick movement will be about 1/3 of its full travel with the empty tank, and more than 2/3 of its full travel with the tank filled to capacity.

146. To jettison drop tanks, press the EMERGENCY BOMB RELEASE, JETTISONING OF TANKS (ARRÊTÉMENT DÉROGÉ BOMBS, DÉROGÉ SAUF) push-button. Fuel tanks may also be dropped by cutting in the tactical release push-button on the control stick, having first switched on the BOMBS (BOMBS) circuit breaker on the right-hand electric control panel. While doing so, the drop fuel tank warning lamp will light up. After the tanks are dropped, the warning lamp will go out. The drop of fuel tanks is checked visually.

Fuel tanks are jettisoned at the following indicated airspeeds:

- (a) unfilled tanks - from 350 to 900 km/hr;
- (b) finless tanks - minimum 650 km/hr;
- (c) finned tanks - minimum 400 km/hr.

Note: With the tanks dropped, immediately cut off the switches on the bomb control panel bearing the inscriptions TACTICAL RELEASES (DÉPARTÉMENT DÉROGÉ), ARMED (ARMEMENT HAUT POURS), DROP FUEL TANKS (ARRÊTÉMENT DÉROGÉ), to avoid the firing of the bomb rack drive solenoid winding.

FLIGHT WITH BOMB LOAD

147. The MiG-17 aircraft mounts bombing equipment which allows the suspension of two 70-, 100-, and 250-kg air bombs from bomb racks 1A-50 and makes it possible to carry out dive, horizontal and loess (or loess) bombing.

148. The take-off in the MiG-17 aircraft with suspended bombs does not differ from that performed without bombs. While in flight, the suspended air bombs do not have any noticeable effect on the behaviour and controllability of the aircraft.

149. The maximum permissible speeds of the MiG-17 aircraft with suspended air bombs are set for conditions of zero vibration, which begins:

- (a) at altitudes less than 3000 m - at 870 km/hr IAS;
- (b) at an altitude of 4500 to 5000 m - at 935 to 945 km/hr IAS;
- (c) at an altitude of 5500 to 80,000 m - at 955 to 965 km/hr IAS.

150. Should vibration appear on the aircraft flying with suspended air bombs at flying speeds less than the maximum permissible ones, stop increasing the airspeed and perform the flight at speeds at which no vibration is observed.

151. Flying the aircraft with one 100-kg air bomb does not practically differ from piloting with two suspended bombs. Piloting and landing with one 250-kg air bomb are similar to piloting and landing with non-suspended fuel tanks.

152. Landing with two suspended 100-kg air bombs is no different from that without bombs; landing with 250-kg air bombs is performed in the same way as landing with non-suspended fuel tanks.

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

160X1-HUM

SECRET FLIGHT

151. Start the engine and taxi out the aircraft at night in the usual way. While taxiing, the pilot will switch on the taxiing light only for a short time when it is necessary to clear the ground ahead.

Prior to take-off switch off the utility lights. The port ultraviolet lights should be directed to the flight and navigation instruments and the starboard light to the engine control instruments.

154. The take-off procedure is the same as in the daytime. Maintain the distance of take-off run by referring to the light points of the runway. After breaking contact with the ground, increase the speed to 350 km/hr, gradually flying off the ground, and then, assume cruising altitude.

155. The procedure of flying the aircraft at night does not differ considerably from the daytime flying procedure. If the natural horizon is not seen, perform instrument flying.

156. At dark night, the patches of light and the reflection of instruments on the cockpit canopy glass can be eliminated by adjusting the canopy lighting and by changing the position of the blinds on the sight bracket inside the cockpit.

157. During approach for landing at night the base leg turn will be executed in the same way as in the daytime. The aircraft will be recovered from the final turn at an altitude of 250 - 300 m.

158. Judgment for landing at night is somewhat more complicated than in the daytime, since at night it is more difficult to determine the distance to the landing field. The pilot should pay special attention to the distance to the landing field.

The pilot should pay special attention to the distance to the landing field.

159. Landing at night on the runway lit by floodlights presents no particular difficulties; night landing procedure is similar to the daytime procedure.

The aircraft is equipped with a landing light which allows the pilots, well experienced in night flying, to land without ground floodlights. Aircraft landing with a landing light is more complicated and requires special attention and high accuracy of flying technique on the part of the pilot.

160. When landing at night with a landing light without ground floodlights, proceed as follows:

- (a) cut in the landing light at an altitude of 400 to 500 m;
- (b) maintain at least 500 r.p.m. down to the leveling-off height, then, smoothly retard the engine control lever full back.

RANGE AND ENDURANCE

161. To increase the range and endurance, fly the aircraft at high altitudes (10,000 to 12,000 m).

162. To obtain a maximum range of flight, maintain the indicated airspeeds given in Table 4 (speeds are equal for each of flying with drop tanks and without them).

163. Perform climbing at a speed of the highest rate of climb.

Table 4. Speeds and Flying Ranges at Different Altitudes

| Flight altitude, m | Indicated airspeed corresponding to maximum range of flight, km/hr | Possible stage distance till engine failure (without drop tanks), km | Possible stage distance till engine failure (with drop tanks, 600-lit capacity each), km |
|--------------------|--|--|--|
| 5000               | 300 - 400  | 795  | -  |
| 10,000             | 310 - 300  | 1185   | 1775 (without tank jettisoning)  |
| 12,000             | 400 - 460  | 1295   | 2070 (without tank jettisoning)  |
| 12,000             | 400 - 460  | -  | 2150 (with tank jettisoning)   |

164. Perform gliding with a retracted landing gear and the engine control lever set on the idle rating stop, at the following indicated airspeeds (either without drop tanks or with them):

- from an altitude of 12,000 down to 10,000 m, at 500 km/hr IAS;
- from an altitude of 10,000 down to 5000 m, at 550 km/hr IAS;
- from an altitude of 5000 down to 500 m, at 450 km/hr IAS.

165. To obtain a maximum endurance, carry out the flight at an indicated airspeed of 300 - 320 km/hr at altitudes indicated in Table 5.

Table 5. Speeds and Endurance at Different Altitudes

| Flight altitude, m | Indicated airspeed corresponding to maximum endurance, km/hr | Block time till engine failure (without drop tanks), min | Block time till engine failure (with drop tanks, 600-lit capacity each), min |
|--------------------|--|--|--|
| 5000               | 300  | 68   | -  |
| 10,000             | 300  | 108  | 160  |
| 12,000             | 300  | 114  | 173  |

Note. When calculating the range and endurance, allowance has been made for fuel consumption, with the engine running on the ground for 5 minutes.

166. After the fuel from the rear tank has been fully used up and the green warning lamp of the fuel transfer pump has flashed up, cut off the circuit breaker of the transfer pump (the pump warning lamp should go out) and continue the flight, checking the remainder of fuel by the fuel quantity gauge.

167. When 300 litres of fuel remains in the front tank, the emergency fuel level red warning lamp will light up. If this is the case, discontinue the flight mission.

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

- 30 -

and land the aircraft, since the amount of fuel left will last for 10 - 15 minutes of flight with a speed of 540 - 550 km/hr at altitudes of 1000 to 5000 m.

Note: When filling the aircraft fuel tanks with fuel T-2 instead of T-1, the flight range and endurance will decrease by 2%.

ARMAMENT CONTROL PROCEDURE IN FLIGHT

- 168. Prepare the aircraft sight for firing in the following ways:
  - (a) cut in the SIGHT RANGE (CHIFFER SPHERA) circuit breaker;
  - (b) switch on the SIGHT (CYLIND) circuit breaker;
  - (c) cut in the RADIO-BASE FINDER (FALAN) circuit breaker.

Caution: Do not cut in the radio-range finder until the sight circuit breaker has been switched on.

- 169. Prior to firing, proceed as follows:
  - (a) set the sight change-over switch lever in the CYRO (HPO) position;
  - (b) check the sight operation by executing shallow turns; the movable reticle should shift to the side opposite to the turn;
  - (c) check and adjust the sight reticle illumination.

170. Cut in the armament circuit breaker and the egress gun, and charge the guns, for which purpose press the charging push-buttons of the respective guns in due succession with a 2 to 3-second delay.

The readiness of aircraft weapons for firing is indicated by the red signal lamps located on the bomb armament electric control panel (on aircraft where these are installed).

171. Set the target base (wing span and overall dimensions of air or ground target) on the sight scale.

172. To fire the H-37, aircraft gun press the upper firing button, and for firing the H-23 gun (or H-23) press the front push-button by the binged safety guard. To conduct salvo fire from all the guns, press simultaneously the upper and the front push-buttons (provided the aircraft is equipped with two-button firing control).

173. Provided the aircraft is equipped with one-button firing control, fire is conducted from guns H-23 and H-37 by one front push-button. Whenever necessary to breakers.

174. Should any of the aircraft guns fail to fire, charge the inoperative gun by pressing the respective charging push-button, then, continue to fire. If this is impossible to determine which of the port guns has failed, charge both guns.

Note: When conducting salvo fire from aircraft guns, the duration of fire bursts should be determined by gun H-37.

175. After the end of firing, charge the weapons, put the safety guard on the upper push-button, mounted on the control stick, cut off the armament circuit breaker and set the sight change-over lever in the HPO position (thereby locking the gyroscopes).

176. When flying at individual altitudes of 700 to 700 km/hr, the aircraft slightly oscillates round its vertical and fore-and-aft axes. These oscillations slightly disturb gun sighting, especially during coordinated turns performed at a speed of flying speed, if possible.

177. Before bombing in flight, do the following:

- (a) cut in the circuit breaker, as well as the tactical and emergency air bomb release circuit switches;
- (b) throw back the bomb tactical release push-button safe guard and press the push-button.

With the bomb release push-button pressed, make sure the air bombs have been released, for which purpose check if the warning lamps have gone out. If this is the case, cut off the circuit breakers of aircraft bomb armament.

178. Should the tactical release electric circuit fail to operate, throw back the safety cap of the emergency push-button and press the push-button.

179. Whenever necessary to immediately release air bombs over friendly territory, use the emergency release push-button. In the latter case, the bomb release circuit switch should be cut off (the air bombs will be released at HAP).

IV. FLIGHT MANEUVERS

GENERAL

180. The MiG-17 aircraft is capable of performing all confidence and aerobatic maneuvers, and vertical maneuvers (half-rolls and diving), with the aircraft entering the half-rolls and diving at maximum level flight speeds from an altitude of 8000 m up to the service ceiling. While performing flight maneuvers, short-time negative G-loads are allowed.

Inverted flight in the MiG-17 aircraft mounted a tank with an inverted flight valve and hydraulic pump "Equipment 623", may be performed during not more than 15 seconds, provided the remainder of fuel in the fuel tanks is minimum 550 litres.

Acrobatic flight maneuvers should be performed at an engine speed of 11,350 ± 50 r.p.m. up to an altitude of 6000 m. The procedure of execution of these maneuvers at an engine speed of 11,560 r.p.m. is the same.

To correct faults, it is allowed to accelerate the engine up to 11,560 r.p.m. in the process of executing of the above maneuvers.

181. To check the correct performance of flight maneuvers (especially above clouds and in conditions of poor visibility of the natural horizon), the pilot can make use of the MiG-17 gyro horizon, which makes it possible to:

- (a) exactly determine the values of the established banks, diving or pitching-up (slipping or climbing) angles, and check them during the flight;
- (b) check the coordinated movements of the control surfaces when entering the flight maneuver, in the process of their execution, and when recovering the aircraft to level flight;
- (c) determine the aircraft attitude in space relative to the natural horizon and recover the aircraft to level flight;
- (d) determine the errors (banks, slipping, uncoordinated handling of controls), especially when carrying out vertical flight maneuvers.

Note: While performing an oblique loop or crossing the horizon line at a climbing or diving angle in excess of 60°, the spherical scale of the gyro horizon rotates through 180°. As a result, at the above angles the MiG-17 gyro horizon cannot be used to check the bank.

182. Execute all flight maneuvers with the elevator trim tab in the neutral position, while performing the maneuvers, the pulling forces, as a rule, will be applied to the control stick, irrespective of the kind of maneuver executed.

183. While performing flight maneuvers at various altitudes with high values of G at high altitudes with comparatively small G-loads (3.5 to 4.5), the

SECRET/NO FOREIGN DISSEM

Peer Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

...characteristic of critical angles of attack (wing-to-wing rolling and yawing vibration before entering a spin), are likely to occur. If this is the case, release the pressure applied to the control stick until rolling and heavy vibratory disturbance (light vibration can be tolerated, making full use of the aircraft maneuverability). While piloting on the verge of pre-stall vibration, the aircraft has a sufficient tolerance margin before entering a spin.

114. While carrying out half-rolls and dives at altitudes above 5000 m, with the aircraft entering the maneuver at maximum level flight speed, the speed limitations cannot be exceeded; therefore, the pilot may not watch the speed indicator readings but should watch the altimeter readings.

115. While performing descending vertical maneuvers (half-rolls and dives), the speed and altitude indicators mounted in the aircraft cockpit read the values of speed and altitude which are considerably higher than actual ones at the given aspect of flight, owing to the delay in transmitting static pressure from the pitot-static tube to the instruments, and the error in measuring the amount of static pressure by the pitot-static tube. The delay in transmitting static pressure from the pitot-static tube normally takes place at a sufficiently high vertical speed.

The maximum delay values are obtained at the vertical section of half-rolls and dives entered at an altitude of 10,000 m when the difference between the instrument readings and the actual values can reach 80 to 120 km/hr (in TAS) and 800 to 1000 m (in altitude).

At close-to-zero and sonic speeds the pressure in the pitot-static tube deviates from the actual value. The instrument reading correction involved by this error, i.e. the "zero correction", makes up 20 to 30 km/hr TAS.

If the speed indicator readings during descending vertical flight maneuvers exceed the limitations specified for the given aircraft, it does not mean that the aircraft has reached or exceeded the speed limit.

Permissible increases of speed indicator readings as compared to the actual speed values of the aircraft for each of the vertical flight maneuvers are indicated in the description of the flying technique of these maneuvers.

100. To speed up the entry into the flight maneuver, accelerate or decelerate the aircraft not in level flight but in descent or climb, respectively, with speed brakes extended.

While performing flight maneuvers involving the descent of the aircraft (after give speed at diving angles not in excess of 30° (depending on the diving speed), so as to enter the vertical maneuver from level flight, with sufficient speed available for carrying out the maneuver at the prescribed engine speed.

107. Pilots will be admitted to the flight maneuver, accelerate or decelerate high-speed half-rolls or dives, with the aircraft entering the half-roll or dive at maximum level flight speed, only after they have mastered flying maneuvers at normal speeds and medium altitudes.

108. While performing flight maneuvers with maximum speed at low, medium and high altitudes, bear in mind the specific features of the aircraft on which the flight maneuver is being executed (the speed of commencement of spontaneous bending).

109. The following flight maneuvers are not allowed to be performed in the MiG-17 aircraft in accordance with the aircraft speed limitations:

(a) half-rolls and vertical dives, with the aircraft entering the half-roll or dive at maximum level flight speed at altitudes below 8000 m;

(b) diving with the engine running at combat rating when the aircraft is entered into a dive from a half-roll at a maximum level flight speed.

106. While recovering from vertical flight maneuvers (zooms or ascending rolls), with the amount of fuel in the fuel tanks being less than 500 - 900 litres and G-loads close to zero (from +0.1 to -0.5) acting during more than 7 seconds, the fuel system of the aircraft does not ensure reliable supply of fuel to the engine. Therefore, while recovering the aircraft from vertical flight maneuvers, avoid close-to-zero G-loads (from +0.1 to -0.5) of more than 1-sec duration.

**BANKED TURN**

197. To properly perform the banked turn, set the specified speed before entering the banked turn and, then, enter the maneuver by applying coordinated pressure to the control stick and pedals, simultaneously increasing the engine speed up to the maximum value.

Check the execution of the banked turn by the turn-and-slip, speed, and rate-of-tilt indicators.

Recover the aircraft from the banked turn by coordinated movement of the control stick and pedals, simultaneously decreasing the engine speed so as to assume level flight attitude without changing the flying speed.

198. The aircraft is stable in the banked turn. In the process of the banked turn execution, considerable pulling forces (at a normal speed of balancing) appear on the control stick.

199. There is no difference in execution of the right-hand and left-hand banked turns.

194. High-altitude banked turns up to 30° can be executed at all speeds up to maximum one. The banked turn procedure at maximum speeds is the usual one, but in the latter case considerable elevator and rudder forces appear on the controls.

195. If excessive pressure is applied to the control stick during the banked turn, the aircraft begins to vibrate and, then, to roll. With further pulling of the control stick, the aircraft energetically recovers from the bank and performs a descending roll in the direction of the banked turn. Application of back stick procedure stops the rolling and rotation of the aircraft around the fore-and-aft axis and the aircraft enters a state of stable flying.

If the aircraft starts rolling while performing the banked turn, decrease back pressure on the control stick, until the rolling stops.

196. Perform an optimum banked turn at a 65 to 70° bank, with the engine running at combat rating and the indicated airspeeds specified in Table 6 below.

Table 6

Indicated Airspeed's and Duration of Optimum Banked Turn (65 to 70° bank) at Different Altitudes

| Altitude, m | Indicated airspeed, km/hr | Duration of banked turn, sec |
|-------------|---------------------------|------------------------------|
| 2000        | 470 - 500                 | 32 - 35                      |
|             | 450 - 480                 | 36 - 60                      |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

When flying at altitudes above 10,000 m, perform backed turns at an indicated airspeed of altitude 350 km/hr.

FIGURE EIGHT

197. The procedure of execution of the figure eight is similar to that of the backed turn.

The change from one direction of backed turn to the other should be performed by continuous and coordinated movement of control stick and pedals, with the position of the engine control lever being unaltered. While changing from one turn to the other, watch the rate-of-climb indicator and altimeter to see that the flight altitude is properly maintained.

CHANDELLE

198. Carry out the chandelle at combat or normal rating of aircraft engine with flying speeds not in excess of the maximum permissible level flight speeds.

199. Before entering the chandelle, accelerate the engine up to the maximum (normal) rating, speed up the aircraft to the given speed and, then, by smoothly applying back pressure to the control stick in the direction of the chandelle and by simultaneously slightly pressing the pedal into the same direction, start climbing at speed equal with an initial bank of 5 to 10 degrees, taking care not to exceed 45 to 70 degrees bank at the end of the second third of the chandelle.

After the aircraft has turned through 180 to 190 degrees, the bank and climb angles should be gradually decreased by simultaneously, moving the control stick forward and into the reversal of the turn, and pressing the pedal into the control stick forward and changing the movement of the controls in such a way as to recover the aircraft from the chandelle into a level flight at the heading which is exactly 180 degrees from the original heading and at a speed of 350 km/hr.

200. Overcontrolling with the stick during the chandelle will result in vibration and wing-to-wing rolling of the aircraft which serves as a warning that the aircraft approaches critical angle of attack and may develop spin entry speed. If this is the case, stop the vibration of the aircraft and ease on the control stick until the rolling of the aircraft disappears.

201. While performing the chandelle, with the aircraft entering the maneuver at an altitude of 5000 m at maximum level flight speed and recovering from it at a speed of 350 km/hr, the aircraft gains 2000 to 3000 m of altitude.

202. If the chandelle is to be performed within minimum length of time, irrespective of the amount of altitude gain, bank the aircraft at 75 to 20 degrees on reaching the half of the oblique loop. At the top of the chandelle, when the aircraft attitude is first close to the inverted dive, which corresponds to the aircraft attitude is from the original direction of flight, and the aircraft ascends through 160 to 200 degrees horizon, start rolling the aircraft level, by applying coordinated control stick and pedal into the reversal of the turn. During the recovery, the aircraft will continue to turn and intercept the heading which is exactly 180 degrees from the original heading. When the aircraft reaches the level flight attitude, set the controls in the neutral position. The recovery speed should be at least 350 km/hr IAS.

HALF-ROLL

203. The half-roll can be performed at all altitudes from 2000 to 10,000 m. Depending on the altitude, the half-roll entry speed (IAS) must be:

- at altitudes from 2000 to 3000 m - 350 km/hr;
- at altitudes from 3000 to 6000 m - 300 to 400 km/hr;
- at altitudes from 6000 to 10,000 m - 300 to 500 km/hr;
- at altitudes from 10,000 to 12,000 m - 300 to 400 km/hr;
- at altitudes from 12,000 to 14,000 m - 300 to 350 km/hr.

Carry out the half-roll at the beginning of training in flying technique within the given flight zone at altitudes of 3000 to 6000 m, with the engine running at 2000 rpm.

204. As the aircraft flies level, before entering the half-roll, set the engine speed which corresponds to the altitude of flight, assume pitching angle of 10 to 15 degrees by applying back pressure to the control stick, then, deflect the control stick and pedal into the desired half-roll so as to assume the wheels-up position within 2 to 3 seconds. With the aircraft turning to the wheels-up position, pull the engine control lever all the way back.

When the aircraft is in low wheels-up position, stop the aircraft rotation by coordinated movement of the control stick and pedal and, without flaring the aircraft in this position, smoothly apply back pressure to the control stick so as to recover the aircraft from the dive and to assume level flight attitude at an indicated airspeed of 350 to 400 km/hr.

During the recovery of the aircraft from the dive the control forces on the stick are always the pulling forces.

205. During the recovery of the aircraft from the dive, do not allow excessive or slow pulling of the control stick.

Overcontrolling with the stick results in vibration and, then, in wing-to-wing rolling of the aircraft. If this is the case, slow down the rate of the control stick backward movement until rolling stops and, then, smoothly pull the aircraft stick backward movement until rolling stops and, then, smoothly pull the aircraft stick to level flight. Recovering the aircraft from the half-roll under slight vibration conditions, especially at high altitudes, will decrease the loss of altitude and result in a lesser rate of speed increase.

A too slow rate of the control stick pull results in a rapid increase of speed, involving considerable growth of forces on the control stick and great loss of altitude. If this is the case, recover the aircraft by more energetic pulling of the control stick without allowing the aircraft to roll.

206. The altitude loss during the half-roll, when the aircraft enters the maneuver without application of the speed brakes at varying speeds and altitudes is given in Table 7.

Table 7  
Altitude Loss During Half-Roll, when Aircraft Enters Maneuver without Application of Speed Brakes at Varying Speeds and Altitudes

| Entry altitude, m | Entry speed (IAS), km/hr | Loss of altitude during half-roll, m | Recovery speed (IAS), km/hr | Maximum G-load during recovery |
|-------------------|--------------------------|--------------------------------------|-----------------------------|--------------------------------|
| 1                 | 2000                     | 150                                  | 350                         | 3.0 - 4.0                      |
| 2                 | 3000                     | 150                                  | 350                         | 3.0 - 4.0                      |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

- 36 -

- 37 -

| 1      | 2   | 3         | 4    | 5       |
|--------|-----|-----------|------|---------|
| 3300   | 350 | 1400      | 540  | 5.0-6.5 |
| 5300   | 350 | 1500      | 600  |         |
| 5300   | 450 | 1700      | 650  |         |
| 5300   | 550 | 1900      | 700  |         |
| 5300   | 600 | 2100      | 750  |         |
| 8000   | 300 | 2100-2400 | 600  | 4.5-6.5 |
| 8000   | 350 | 2300-2500 | 650  |         |
| 8000   | 400 | 2400-2600 | 700  |         |
| 8000   | 450 | 2500-2700 | 750  |         |
| 8000   | 500 | 2600-2800 | 800  |         |
| 10,000 | 300 | 2700-2900 | 850  | 4.0-5.0 |
| 10,000 | 350 | 2800-3000 | 900  |         |
| 10,000 | 400 | 2900-3100 | 950  |         |
| 10,000 | 450 | 3100-3300 | 1000 |         |
| 10,000 | 500 | 3300-3500 | 1050 |         |
| 12,000 | 300 | 3200-3500 | 720  | 3.5-4.5 |
| 12,000 | 350 | 3000-3300 | 680  |         |
| 12,000 | 400 | 3200-3500 | 640  |         |

From an altitude of 8000 to 14,000 m the half-roll may be performed with speed brakes applied and the aircraft brought into the maneuver at maximum level flight at maximum level flight speed, with the aircraft entering the maneuver at maximum level flight speed, the half-roll may be performed without applying the speed brakes.

207. While performing the half-roll, with the aircraft entering the maneuver at maximum speed and the speed brakes applied, speed up the aircraft at the prescribed altitude (at minimum 5000 m) up to the maximum level flight speed, then, set the speed brakes change-over switch for extension. After the speed brakes extension signal lamp has lit up, perform the half-roll by deflecting the ailerons and rudder.

During the aircraft roll, pull the engine control lever all the way back. At the moment the aircraft assumes the stable-up position pull the control stick to recover the aircraft from the half-roll.

Depending on the altitude at which the aircraft enters the half-roll, the pilot should proceed as follows:

(1) When performing the half-roll from an altitude of 8000 m, pull the control stick with a force of 6 - 10 kg. While doing so, the aircraft reduces its speed in spite of the aileron loss and assumes a flight attitude involving considerable vibration at G-load of 4.0 - 4.5. The vibration disappears at a negative diving angle of 45 to 50°, after which the pulling force applied to the control stick should be increased up to 13 - 15 kg.

With the force applied to the control stick retained, at the end of the

roll when the angle of dive is 25 to 30°, the aircraft experiences a slight vibration which increases with the decrease of the diving angle and flying speed. In the latter case, the forces applied to the control stick should be gradually decreased for recovering the aircraft on the verge of vibration.

If more energetic pull-out is required, the aircraft can be recovered from the half-roll with considerable vibration. When the pedals are in the neutral position, the vibration of the aircraft does not result in a stall.

The maximum speed during the recovery from the half-roll should not exceed the speed at which the aircraft enters the half-roll. The loss of altitude during the half-roll amounts to 2000 - 3500 m.

(2) While entering the half-roll from an altitude of 10,000 m, energetically move the control stick backward to about 1/3 of its full travel with a force of 10 - 15 kg. In this case, the aircraft starts vibrating as in case of a half-roll entered from 8000 m, but the G-load does not exceed 3.0 to 3.5.

After moving the control stick backward, the flying speed decreases but at a slower rate than in case of a half-roll entered from 8000 m. As the aircraft approaches the vertical section of the dive increase the pulling force on the control stick up to 20 - 25 kg, and the vibration of the aircraft should stop. The aircraft flying speed at the dive vertical section increases reaching its maximum value 1100 - 1130 km/hr (as read by the narrow indicator pointer).

When the diving angle closes to 90°, the forces applied to the control stick are not decreased, the aircraft flying at a diving angle of 35 to 30° approaches the conditions of slight vibration.

Pull out the aircraft on the verge of vibration. The loss of altitude during the half-roll makes up 4000 - 4500 m.

(3) In carrying out the half-roll from 12,000 m, move the control stick backward by about 1/3 of its full travel with a force of 20 to 25 kg. The value of G-load at the beginning of the half-roll takes up 2.5 to 2.7.

With the diving angle closes to 90°, the forces applied to the control stick should be increased up to 30 to 35 kg, thereby increasing the G-load up to 3.0 - 3.5.

After the aircraft has passed the vertical section, the G-load gradually increases even when the forces on the control stick are slightly decreased, and when the aircraft is 30 to 25° short of the level flight attitude, it starts slightly vibrating. The aircraft should also be recovered on the verge of vibration.

The maximum speed of the aircraft during the half-roll amounts to 1170 - 1180 km/hr (as read by the thin pointer) at an altitude of 9300 m. The loss of altitude during the half-roll makes up 4500 - 5000 m.

(4) While performing the half-roll from an altitude of 14,000 m, energetically move the control stick backward to about 1/3 of its travel. The forces on the control stick (after moving it back) increase at a lower rate than in half-rolls performed from lower altitudes.

As the aircraft approaches the half-roll vertical section, with the position of elevator being unchanged, the value of G-load takes up 2.0 - 2.4 and the forces on the control stick increase from 10 to 25 kg.

After passing the vertical section of the half-roll, the G-load increases even when the pulling forces on the control stick are decreased, and when the aircraft is 25 to 30° short of the level flight attitude, it starts slightly vibrating as in case of a half-roll entered from 10,000 m. The maximum speed at an altitude of about 11,000 m (as read by the thin pointer) is 1100 km/hr. The actual speed while per-

SECRET/NO FOREIGN DISSEM

Peer Original

maneuver is performed at positive angles of attack, and the other - at negative angles of attack) and the pilot experiences varying G-load effects.

To perform the slow roll, establish level flight condition at 600 km/hr IAS, assume 15 - 20° nose-up attitude and, after fixing this attitude, smoothly applying the control stick into the roll, rotate the aircraft round its fore-and-aft axis, facilitating the rotation by pushing the pedal also into the roll. When the aircraft reaches 45° bank point, slightly push the control stick to prevent the aircraft from yawing and simultaneously ease on the pedal applied into the roll, at the same time holding the aircraft from nose-dropping by the reverse pedal.

On reaching the 90° point, keep moving the control stick backward so that, with the aircraft in the wheel-up position, the aircraft nose is 40 - 45° above the horizon while doing so, gradually decrease pressure on the reverse pedal. With the aircraft in the wheel-up position, the pedals should be neutralized. On reaching the 225° point, press the pedal into the roll to prevent the aircraft from nose-dropping (the maximum pressure applied to the pedal should be at a bank of 90°), then, gradually ease on the pedal so as to set the pedals in a neutral position by the end of the roll.

After the aircraft has reached the 270° point, gradually move the control stick forward to prevent the aircraft from nose-dropping.

With the aircraft reaching the level flight attitude, set the controls for recovery and, after the aircraft has stopped rotating, set them neutral.

**DOUBLE (MULTIPLE) HORIZONTAL ROLL**

215. Double (multiple) horizontal rolls are a combination of two (or more) rolls. The latter aircraft may be used for carrying out both steep and slow controlled double (multiple) horizontal rolls. The speed at which the aircraft is brought into the double horizontal roll at medium flight altitudes should be at least 600 km/hr. The flying technique used in performing multiple horizontal rolls is similar to that used when executing single rolls.

**LOOP**

216. The loop is entered at a speed of 600 km/hr. Before entering the loop, set the assigned speed and, then, apply back pressure to the control stick to assume climbing attitude and, without releasing back pressure on the control stick, keep the aircraft on the curved trajectory in the vertical plane. Pull the control stick so as to ensure nearly constant rate of aircraft rotation (angular velocity) and a speed of 300 to 350 km/hr by the moment the aircraft assumes the wheel-up position. While executing the loop, check the aircraft bank, since the bank results in the loop being performed not in one plane.

At the top of the loop, decrease the engine speed down to the idle one; the procedure of diving and recovery of the aircraft to level flight is the same as during half-roll execution.

217. For training purposes, the loop must be performed at altitudes of 1500 to 6000 m. If the pilot is properly trained, the normal loop may be performed from an altitude of 2000 m, with the speed at the top of the loop being 300 km/hr.

218. While performing a loop at high altitudes, with the aircraft entering the maneuver at reduced speeds and the movement of the control stick during the first half of the loop being slow or too brisk, the aircraft may lose its speed 30 - 40° before

reaching the top of the loop. In these cases, the pilot will have to pull the control stick until the aircraft drops its nose and starts diving. Decrease the engine speed only after the aircraft has dropped the nose through 20 - 30° below the horizon. Keep the pedals strictly neutral.

**OBLIQUE LOOP**

219. If before entering the normal loop the pilot establishes 40 to 45° bank relative to the horizon and performs the loop, maintaining the established bank throughout the maneuver, the aircraft will describe a closed curve in a plane inclined to the horizon. This maneuver is called the oblique loop.

220. The procedure of execution of the oblique loop is mainly the same as that of the normal loop, though during the execution of the former the pilot must be particularly accurate with the controls and maintain the established bank throughout the oblique loop.

It must be taken into consideration that the main problem consists in maintaining the established bank when the aircraft approaches the loop top and, especially, when the latter is being passed. With the aircraft in the wheel-up position, when the habitual idea of ground and horizon is reversed, the pilot should be able to determine and maintain the bank of the aircraft relative to the constant horizon line and, consequently, at the top of the loop the port wing of the aircraft should be dropped relative to the horizon during the left-hand bank (when the oblique loop was entered with the left bank), while the starboard wing should be raised.

After the aircraft has assumed diving attitude, press the pedal to the side opposite to the bank to retain the direction of flight during recovery. When returning the aircraft to level flight, remove the bank and, gradually decreasing the deflection of the pedals, set them neutral. During execution of the second half of the oblique loop, do not let the aircraft rotate round its fore-and-aft axis, especially in the direction of the bank increase, since this may result in the aircraft changing into the tight spiral.

221. During the initial execution of the oblique loop, the latter must be entered with a bank not exceeding 20°. The altitudes and speeds of the oblique loop entry are similar to those of normal loop entry.

If the pilot is not confident of correct execution of the first half of the oblique loop, he must remove the bank by deflecting the ailerons and perform the second half of the normal loop.

**LOOP AND ROLL-OFF**

222. Enter the loop and roll-off at a speed of 700 km/hr. The procedure of entry of the loop and roll-off first half is the same as that of the first half of the loop.

With the aircraft in the wheel-up position at the top of the loop and roll-off (the flying speed should be 350 - 300 km/hr), move the aircraft through 150° about its fore-and-aft axis (slowly performing the half-roll), for which purpose the pilot should apply the control stick and pedal into the desired roll.

The rate and amount of control stick movement should be such as to turn the aircraft within 2 - 3 seconds.

After the aircraft has reached the 90° point of the turn round the fore-and-aft axis move the control stick into the roll and at the same time aushaft forward to maintain directional control and decrease the angle of attack to prevent loss of speed. The moment the aircraft returns to level flight, stop the rotation of the aircraft. After the rotation of the aircraft has stopped, decelerate the engine.

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

223. If the speed is less than 300 km/hr, when the aircraft is in the wheel-up position, the pilot must perform the normal loop. In this case he should not attempt to execute the loop and roll-off as the aircraft may develop spin when the pedals are used at low speed.

224. When the loop and roll-off is performed from an altitude of 5000 m, the aircraft gains an altitude of 2000 - 2500 m.

225. For training purposes the initial altitude for execution of the loop and roll-off must not exceed 6000 m.

226. When the loop and roll-off is entered at a speed exceeding 700 km/hr, the pilot smoothly applies back pressure to the control stick at the beginning of the maneuver entry so that the aircraft speed at the top of the loop and roll-off is not more than 400 km/hr.

**SOON**

227. The soon should be entered at a speed not exceeding the maximum level flight speed at the given altitude.

The soon can be performed at various angles of climb including vertical climbing.

The pilot recovers the aircraft from the soon by performing the turn. To recover the aircraft, establish a bank and, then, by applying coordinated pressure to the control stick and pedal enter the turn assuming cross-heavy attitude. The aircraft is also recovered by changing it to a banked turn.

228. The soon recovery speed should be minimum 400 - 450 km/hr if the angles of climb are 60 to 90°, and 350 to 400 km/hr if the angles of climb are less than 60°.

229. The altitude gain in the soon depends on the speed, angle of climb and soon entry altitude.

**HANGOVER STALL**

230. The soon is entered at a speed not exceeding the maximum level flight speed at the given altitude.

To perform the hangover stall, apply back pressure to the control stick, and raise the speed to climb at an angle of 60 - 70° to the horizon and maintain this attitude until the speed decreases down to 450 km/hr. At this moment, apply smooth back pressure to the pedal and control stick, without changing the angle of climb enter the turn, i.e., press the pedal into the turn and at the same time apply pressure to the control stick to establish a bank into the turn. The bank should not exceed 20°.

With the movement of pedals increasing, deflect the control stick slightly back through the horizon, decelerate the engine. After the aircraft nose has dropped dive at an angle equal to the angle of climb. The aircraft must be brought into a pull out the aircraft at the angle of climb.

Altitude loss from the top of the hangover stall to the moment the aircraft returns to level flight, varies up to 750 to 900 m.

**180° AND 190° ASCENDING AND DESCENDING ROLLS**

231. Ascending and descending rolls of the aircraft are allowed at a flying speed up to the maximum permissible one and at all altitudes ensuring safety of aircraft recovery from the dive after performing the descending roll.

The entry of aircraft rolls around the fore-and-aft axis should be started with practicing 180° descending rolls, then, 90° rolls at diving angles of 60 to 70° and rolls in vertical diving. Having mastered the descending rolls, pass over to practicing ascending rolls in the same sequence. During the first period of training in 90° and 180° rolls, practice diving after the half-roll or the second half of the loop, soon, loop and loop and roll-off, with the aircraft brought into the above maneuvers at normal speeds. Then, perform ascending and descending rolls in combination with the other flight maneuvers at increased speeds and high altitudes.

To perform 180° or 90° roll in the dive, apply brisk forward pressure to the control stick, fix the given angle and roll the aircraft round its fore-and-aft axis through 180 or 90° by coordinated and energetic movements of the control stick and pedals into the desired roll and, when the aircraft is 10 to 15° short of the preset recovery reference point, stop rotating. Check the altitude and speed and recover the aircraft from the dive.

The flying technique of 180 and 90° rolls at climbing angles up to 40° is no different from that used in diving rolls. Rolls through 90° can be properly performed only on a vertical straight-line with an angle of turn equal to 90°. At the beginning of the roll, the flying speed should be minimum 450 km/hr. The aircraft may be recovered from the 180° or 90° roll to any flight attitude or maneuver, depending on the flying speed.

To ensure accurate performance of 180° and 90° rolls at climbing angles of up to 60 - 70°, the pilot should make use of typical ground reference points which may be clearly visible on the sky line (ground). To determine the amount of roll at climbing angles of 60 to 70°, the pilot should avoid use of the sun and separate clouds (if possible). He should also be able to determine the amount of aircraft roll by the rate of roll within a fixed time limit.

**VERTICAL REVERSMENT**

232. The vertical reversion is executed at all altitudes from 2000 to 90,000 m. The speed at which the aircraft enters the vertical reversion may be from 600 km/hr up to the maximum permissible level flight speed.

For training purposes the vertical reversion will be entered from an altitude of 4000 to 20000 m with the soon entry speed of 600 to 650 km/hr. Vertical reversion from an altitude below 2000 m or above 6000 m, with the soon entry speed of more than 650 km/hr, are allowed to be performed only by those pilots who have mastered flying techniques in the given type of aircraft to perfection.

Before entering the maneuver, the pilot sets the engine at desired rating, speeds up the aircraft in level flight up to the given speed and, by smoothly applying back pressure to the control stick, sends the aircraft into climb the soon at a speed of 600 km/hr on speed command. Thus, with the aircraft entering the soon at a speed of 600 to 650 km/hr, the angle of climb should be 60 to 90°.

Having gained a speed of 300 to 400 km/hr in the soon smoothly apply the stick controls into the desired direction to roll the aircraft round its fore-and-aft axis through 180° thereby making a half-roll and after the aircraft nose has

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

pitched the horizon, decelerate the engine r.p.m. to the minimum ones, send the aircraft into dive by applying back pressure to the control stick, and, then, return the aircraft to level flight.

If the zoom is entered at a speed close to the maximum permissible one, and the angle of climb equals 60 - 80°, the pilot should start 180° turn of the aircraft round the fore-and-aft axis at a speed of 550 to 500 km/hr and assume the wheel-up position planning to obtain a speed of not less than 300 km/hr at the top of the vertical movement, when the aircraft nose is level with the horizon line.

540° INVERTING ROLL

231. The 540° ascending roll is a combination of an ascending single roll with a half-roll performed for the subsequent inverted flight or for sending the aircraft into a dive.

Depending on the speed at which the aircraft enters the zoom, the 540° ascending rolls may be performed at angles of climb up to 60°. The ascending roll flying technique is the same as that of the controlled horizontal roll.

While mastering aerobatic maneuvers, perform 540° ascending rolls at angles of climb up to 45°. Before entering the flight maneuver, set the engine at nominal rating and assume climbing attitude at a speed of up to 700 km/hr and an altitude of minimum 3500 m.

As soon as the airspeed of 600 km/hr is reached at the present climb angle, use short coordinated movement of the controls to perform the 540° roll. With the aircraft flying in the wheel-up position, stop the aircraft rotation and, at a speed of 750 km/hr, apply back pressure to the control stick to recover the aircraft from the roll.

If, with the aircraft in the wheel-up position, the flying speed exceeds 300 km/hr, slow down the rate of control stick backward movement, decrease the angle speed and attend the speed brakes.

MULTIPLE ASCENDING ROLL

234. Multiple ascending rolls may be performed at climbing angles from 30 to 60° and at flying speeds up to the maximum permissible ones. The larger the climbing angle, the higher should be the roll entry speed. The minimum roll entry speed should be not less than 700 km/hr, while the recovery speed must be minimum 400 km/hr.

The peculiarity of multiple ascending rolls consists in the fact that, with the increase of the angle of climb and, consequently, of the roll entry speed, the movement of the rudder should be less than in performing horizontal rolls; to retain a constant angle of climbing in the process of performing each of the series of rolls, it is necessary to apply forward pressure to the control stick, while in the wheel-up position, and move it back when recovering the aircraft from the roll. After executing a series of ascending rolls, send the aircraft into a turn, banked turn, half-roll, etc., depending on the recovery speed.

VERTICAL FIGURE OF EIGHT

235. The vertical figure of eight is a combination of two loops combined by ascending and descending 180° allround rolls.

While executing the vertical figure of eight, with the aircraft rolling round the fore-and-aft axis in the ascending maneuver, the speed at which the aircraft is brought into each loop should be 50 km/hr higher than the speed prescribed for

executing a normal loop, while the allround roll should be performed at the end of the first quarter of each loop, i.e., when the aircraft is at a climbing angle of 40 to 90°.

When performing a vertical figure of eight, with the aircraft rolling in the descending maneuver, the speed at which the aircraft is brought into each loop should be normal, while the allround roll must be executed at the end of the third quarter of each loop, i.e., when the aircraft is descending at a close-to-vertical diving angle.

HALF-LOOP AND ROLL

236. To perform the half-loop and roll, set an airspeed of 750 km/hr and send the aircraft into a climb as in executing the normal half-loop.

As the aircraft nose nears the top of the half-loop (15 to 20° short of the horizon), check the speed and, with the indicated airspeed of minimum 400 km/hr, roll the aircraft in the desired direction by coordinated movement of the control stick and pedal. After executing the half-loop, perform a horizontal roll without changing the position of the controls. If, at the top of the half-loop, the speed is less than 400 km/hr, do not perform the roll but end the maneuver in normal half-loop.

ASCENDING DOUBLE CHANDELLE

237. The ascending double chandelle is a combination of the first half of a chandelle with the ascending half-roll performed in the same direction, and the second half of the chandelle performed in the opposite direction.

The aircraft may be brought into a double ascending chandelle at all altitudes and flying speeds up to the maximum permissible ones.

Accelerate the aircraft at the given altitude to the required speed and send it into an ascending spiral, with an initial bank of 10°, by coordinated movement of the controls.

At the moment the aircraft has turned through 30° from the direction of the maneuver entry, stop the angular rotation of the aircraft without changing the angle of climb and, applying coordinated movement of the control stick and pedals, perform a controlled 180° roll into the bank.

As soon as the aircraft reaches the opposite 50 to 60° bank, stop the aircraft rolling and continue the ascending turn up to 90° in the new direction. The recovery of the aircraft from the second half of the ascending chandelle should be finished at a speed of minimum 350 km/hr.

DIVE

238. Due to considerable loss of altitude and rapid increase of speed when pulling the aircraft out of the dive, maintain the following dive angles at altitude above 2000 m:

- (a) when the engine is running at minimum speed, with the speed brakes applied - up to 70°;
- (b) with the engine running at minimum speed, without applying the speed brakes - 60°;
- (c) with the engine running at increased speed (up to the normal rating) without applying the speed brakes - up to 50°.

239. Enter the dive from altitudes minimum 2000 m with the engine running at the minimum speed and dive angles not exceeding 45°.

240. The minimum dive entry altitude at an angle of 45° equals 1000 m.

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

241. The dive may be entered from turn, half-roll or straight flight. The low altitude loss and speed growth during the entry will be obtained when the dive is entered from turn.

Do not enter the dive from a half-roll at altitudes less than 3000 m.

242. Enter the dive at an indicated airspeed of 350 km/hr.

243. When flying at altitudes above 5000 m, the aircraft may be brought into the dive at increased airspeeds:

- (a) from an altitude of 5000 to 6000 m - at an indicated airspeed of up to 500 km/hr;
- (b) at altitudes above 8000 m - at all level flight speeds up to the maximum.

244. When diving, check the airspeed at altitudes above 5000 m by the altitude indicator readings, and at altitudes less than 5000 m - also by the speed indicator readings.

245. Start the dive recovery in such a way that the pull-out speed would not exceed the maximum permissible value.

246. Pull out the aircraft by energetic backward movement of the control stick, without allowing the aircraft to roll. If rolling is observed, slightly decrease the pulling forces on the control stick and continue to pull the aircraft out of the dive after the rolling has stopped.

247. During the dive, watch the horizon and the ground reference points to prevent the aircraft from rotating round its fore-and-aft axis.

248. Should the aircraft start rotating round its fore-and-aft axis during the diving maneuver, apply coordinated movement of the control stick and pedals to stop rotation, reverse the bank and recover the aircraft from the dive.

249. If the rotation of the aircraft round its fore-and-aft axis has not been stopped when recovering the aircraft from the dive, the spiral bank and angular momentum will increase. This is normally accompanied by rapid buildup of speed and considerable loss of altitude.

250. In case of steep diving, with the aircraft rotating round its fore-and-aft axis, or when performing a tight spiral, start recovering the aircraft at an indicated airspeed not exceeding 500 km/hr, keeping in mind that the speed gain during the pullout may be up to 50 km/hr.

The dive recovery at speeds exceeding the above-indicated speed becomes more complicated due to the following reasons:

- (a) reduced aircraft efficiency, which calls for considerable deflection of ailerons and longer time for rotation stoppage;
- (b) effect of aircraft banking (when the aircraft rotates in the direction of the bank);
- (c) necessity of applying considerable pressure to the control stick to build up G-load, which hampers aerostatic recovery, with simultaneous maximum use of ailerons for stopping the rotation of the aircraft.

251. When flying at altitudes above 11,000 m, in case of sudden unpressurizing or the onset of failure of the engine at an altitude of above 11,000 - 13,000 m, it is allowed to descend at maximum speed to reduce the descending time.

While doing so, bear in mind that a considerable rate of descent is gained during the dive with the engine running at low speed and the speed brakes applied. In emergency cases dive from high altitudes will be performed as follows:

- (a) apply the speed brakes and bring the aircraft into the dive at an angle of 30 to 40°;
- (b) shift the engine control lever to low speed;
- (c) on reaching the given dive angle, keep it constant;
- (d) after gaining an altitude of 11,000 - 13,000 m, smoothly move the control stick backward to pull the aircraft out without allowing it to bank. The efforts applied to the control stick during the pullout, may reach considerable values. However, the aircraft pulls out reliably.

VERTICAL DIVE

252. Vertical dives both with the speed brakes used and without them are allowed from altitudes of 12,000 m and above at all speeds up to the maximum level flight speed.

Bring the aircraft into the vertical dive at its maximum level flight speed by performing the half-roll. While rolling the aircraft over to the wheel-up position, pull the engine control lever all the way back. The behaviour of the aircraft, when approaching the vertical section of the dive is the same as in performing half-rolls.

253. To keep the aircraft in the vertical dive, move the control stick forward, checking the position of the aircraft by the horizon or by ground reference points.

254. The efforts required for holding the aircraft in vertical dive, with the speed brakes applied, increase with the increase of diving speed. When the dive is entered at maximum level flight speed at an altitude of 14,000 m, the speed of the aircraft at an altitude of about 13,000 m reaches its maximum value of 1260 to 1250 km/hr (as read by the thin pointer of the speed indicator), with the pressing forces on the control stick equal to 30 - 40 kg. If the above forces are maintained on the control stick, the pilot is unable to keep the aircraft in the vertical dive. In spite of the large pressing forces on the control stick, the aircraft gradually decreases the diving angle down to 70 - 75° before it reaches an altitude of 3000 m and reduces the speed to 1100 km/hr (as read by the thin pointer).

255. Start the vertical dive recovery, with the speed brakes applied, at an altitude of 3000 m (as read by the altimeter). To recover the aircraft, energetically move the control stick back with an effort of 20 to 25 kg.

In this case, the aircraft pulls out at an altitude of above 5000 m without reaching the flight conditions at which banking is likely to be observed.

256. While at the vertical dive section of the maneuver performed with the speed brakes applied, from an altitude of 14,000 m, with the aircraft brought into the dive at maximum level flight speed, the aircraft responds too slowly to longitudinal (pitch) control.

Though the pressing force on the control stick does not exceed 20 kg, the aircraft experiences load of 1.6 to 1.8 G for 10 - 8 seconds at the vertical section of the dive, still in performing the half-roll, without applying the speed brakes, from an altitude of 14,000 m with a pulling force of about 30 kg, the value of load at the vertical section of the trajectory amounts to 1.8 - 2.0 G.

The aircraft gains the maximum speed of 1340 to 1350 km/hr (as read by the thin pointer of the speed indicator) on the vertical dive section at altitudes of 5000 to 11,000 m, when entering the dive at an altitude of 14,000 m. In this case, the true airspeed of the aircraft does not exceed 1230 to 1250 km/hr.

In spite of the value of pressing force on the control stick, amounting to 20 kg the dive angle and speed of the aircraft gradually decrease. On reaching an altitude of 3000 m (as read by the altimeter), the aircraft dive angle decreases down to 65° and the diving speed - to 1130 km/hr (as read by the thin pointer).

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

through at the time aircraft on the vertical section of the dive and half-roll, when entering the dive and half-roll at the maximum level flight speed, with the speed brakes retracted (and all the more with the speed brakes extended), do not exceed the permissible speeds specified for the aircraft, the pilot may not see the speed indicator but should rather check the altimeter scale readings.

257. When pulling the aircraft out of the vertical dive performed without playing the speed brakes also at an altitude of not less than 5000 m (as read by the altimeter), the control stick forces required for pulling out the aircraft shall be 20 to 25 kg. The aircraft pulls out level at an altitude of about 5000 m.

Do not keep the aircraft diving at a steep 50-60° angle at an altitude of less than 5000 m, with the aircraft brought into the dive at speeds close to the maximum level flight speed.

No vibration or any other phenomena interfering with aircraft piloting are observed in these cases.

The efforts to be applied for recovering the aircraft from the vertical dive, with the speed brakes applied at the beginning of the entry, are considerably decreased.

At the end of the pullout, the pilot has to keep the aircraft from changing to larger angles of attack and from vibration by pressing the control stick.

POWER DIVE WITH ENGINE RUNNING AT COMBAT RATING

256. Power dive with the engine running at combat rating, without applying the speed brakes, when the aircraft is brought into the dive from a straight and level flight may be performed at any flying speeds up to the maximum level flight speed.

Dive entry at altitudes of 10,000 - 14,000 m and below from a straight and level flight at maximum level flight speed at an angle of more than 50°, proves practically impossible owing to the rapidly increasing pressing forces on the control stick with the flying speed increase.

At lower altitudes, the maximum dive angle attained when entering the half-roll based at an altitude of 5000 m, cannot exceed 25 to 30°.

When performing the dive with the aircraft brought into the dive from a level flight, the pilot may not watch the speed indicator readings. With the flying speed increased, the aircraft itself starts recovering from the dive. The efforts to be applied for keeping the aircraft in the dive attitude amount to 30 - 50 kg before the aircraft gains the maximum permissible flying speed.

259. To bring the aircraft into the dive at an angle of 45 - 50° from a level flight, at the maximum level flight speed, energetically push the control stick and an effort of up to 15 - 20 kg to obtain a sufficiently large dive angle, before the aircraft gains a speed causing large pressing forces on the control stick.

If the aircraft is brought into the dive too slowly, it may result in pressing forces from 15 to 30 kg appearing on the control stick at small dive angles so that further increase of the dive angle will prove impossible.

260. To hold the aircraft on the maximum section of the dive, with the engine running at combat rating, apply pressing forces of up to 25 - 30 kg to the control stick. With the dive angle equal to 45 - 50° and the pressing forces on the control stick amounting to 50 kg, the aircraft gains a speed of 1240 km/hr (as read by the indicator thin pointer) at an altitude of 10,500 m, and 1220 km/hr - at an altitude of 5000 m.

However, the true airspeed at 5000 m

261. Do not apply the elevator trim tab in the dive. The change of elevator trim tab position in the power dive with the engine running at combat rating does not have any considerable effect on the behaviour of the aircraft. The efforts to be applied for keeping the aircraft in the dive attitude rapidly increase in both extreme positions of the trim tab.

262. The varying location of the aircraft C.G. during power dives with the engine running at combat rating does not cause any considerable changes in the behaviour of the aircraft.

The forces to be applied for keeping the aircraft in the power dives, with the engine running at combat rating, rapidly increase with the increase of the flying speed at any location of aircraft C.G.

The speeds gained during the dive, at equal values of control stick pressing forces, on an aircraft with a forward C.G. location are higher than on an aircraft with a rear C.G. location. With the extreme forward C.G. position corresponding to 20-25 MAC, the speed developed at an altitude of 10,000 m, with the forces applied to the control stick equal to 30 - 35 kg, does not exceed 1240 km/hr, and that at an altitude of 5000 m - 1220 km/hr (as read by the thin pointer).

263. Recover the aircraft from the dive when the value of pulling forces on the control stick are up to 25 - 30 kg. The recovery of the aircraft does not result in any considerable G-loads due to worsening of aircraft controllability.

The forces required for building up a load of one G, when recovering the aircraft from the dive, sharply increase with the increase of flying speed and reach about 50 kg per G-unit at an altitude of 10,000 m and a speed of 1160 - 1210 km/hr (as read by the thin pointer). This means that the change of control stick force from pressing (25 kg) to pulling (25 kg), with the aircraft pulled out at an altitude of 10,000 m and a speed of 1160 to 1210 km/hr (as read by the thin pointer), builds up a load of about 2 G. In dive recovery, with the decrease of the flying speed, the G-load gradually increases, with the pressing forces being the same.

The extension of the speed brakes facilitates the recovery of the aircraft, since it results in a more rapid decrease of flying speed. Besides, the extended speed brakes involve a pitching moment which helps the pilot in recovering the aircraft from the dive.

264. Change the diving aircraft to the chandelle at maximum permissible flying speeds in the same way as at low speeds. When flying at close-to-maximum speed rates, the aircraft responds to the deflection of radar and ailerons too slowly and, therefore, the chandelle entry becomes somewhat lengthened.

The MiG-17 aircraft does not have any reverse bank effect to the deflection of the radar.

265. When diving at altitudes less than 3000 m, with the speed indicator and see that the airspeed developed at the above altitude does not exceed the indicated airspeed of 1000 km/hr (as read by the thick pointer of the indicator), since in some types of aircraft, the excessive flying speed may result in the aircraft banking.

When reaching the maximum permissible indicated airspeed of 950 km/hr, the pressing forces on the control stick at the above altitudes decrease with the decrease of flight altitude and make up 5 to 8 kg at an altitude of 500 - 1000 m, with the trim tab in the neutral position.

At an altitude of about 5000 m the banking of the pulling out aircraft, with the positive G-load present, begins at an indicated airspeed of 950 to 1000 km/hr.

SECRET/NO FOREIGN DISSEM

Peer Original



In rectilinear diving, the aircraft banking develops gradually and may be recovered by the ailerons, and the flying speed may be increased by 10 - 20 km/hr when the ailerons lose their efficiency which involves full or partial deflection of the ailerons.

To stop banking in rectilinear diving, as well as in the level flight, decrease the engine and extend the speed brakes, and only then start recovering the aircraft from the dive.

**SPIRAL**

266. The spiral is normally performed with a 45° bank at a speed of 500 km/hr, with the engine running at the minimum speed.

Before entering the spiral, assume gliding attitude at a speed of 450 - 500 km/hr and, then, enter the spiral with a bank of not more than 45° by coordinated movements of the control stick and pedal.

267. Decrease or increase flying speed during the spiral by respectively changing the aircraft's fore-and-aft axis angle of inclination relative to the horizon (by raising or lowering the aircraft's nose). In all other respects the spiral execution procedure is similar to that of the banked turn.

268. During one turn of the spiral entered at an altitude of 5000 m the aircraft loses about 1200 m of altitude. With the aircraft properly recovered from the spiral at an angle of 30 to 45°, and the flying speed before recovery increased to 600 - 700 km/hr IAS, at an altitude of about 2500 m, the loss of altitude during one turn rises up to 500 to 400 m.

When recovering the aircraft from more tight spirals, with the speed before the recovery increased to 700 - 800 km/hr IAS, the loss of altitude is minimum 3500 - 2000 m.

269. With the landing gear and flaps extended, the spiral is performed at increased engine speed (8000 to 8500 r.p.m.) at a flying speed of 350 km/hr.

270. The aircraft is recovered from the spiral by coordinated movements of the control stick and pedal, simultaneously increasing the speed while recovering to the level flight. The engine speed may be increased also after spiral recovery, during a gliding.

271. While recovering from a tight spiral, with the aircraft fore-and-aft axis inclined to the horizon at an angle exceeding 30°, first, remove the bank and, then, recover the aircraft from the dive.

**SLIP**

272. Slip the aircraft, with the flaps and landing gear extended, at an indicated airspeed of 250 km/hr, with the engine running at idle rating.

273. To enter the slip, establish a bank, and simultaneously press the pedal to the direction opposite to the bank, to prevent the aircraft from turning. The aircraft slips steadily with a bank of not more than 70° and the rudder fully deflected.

To recover the aircraft from the slip, remove the bank by the control stick and release the pedal in proportion with the value of the bank decrease, then, establish a normal gliding angle.

274. With the landing gear and flaps retracted, slip is normally performed at an indicated airspeed of 300 km/hr.

**FLYING TECHNIQUE IN ANTI-G SUIT USE**

275. Carry out training flights with the UH-1 anti-G suit on in accordance with training exercises intended for mastering individual flying technique and air combat.

Carry out the first flight in the anti-G suit for determining G-tolerance at low (minimum) or high (maximum) pressure, since owing to the individual specific features of the pilot's organism, one and the same G-load can be easier tolerated by one part of flying personnel at low pressure, and by the other part - at high pressure.

Build up G-load not exceeding 3 - 4 during the first flights and increase it during the next flights to 6 - 7.5 by performing confidence and acrobatic maneuvers at increased speeds.

Do not build up G-load exceeding 8, since it may lead to residual strains in the aircraft structure. The higher the flight altitude, the lesser the G-loads which may be attained. Thus, due to the aerodynamic properties of the aircraft, it is impossible to gain G-load equal to 8 at altitudes above 6000 m. The maximum G-load (8 G) can be obtained at altitudes down to 5000 m. To ease an accelerometer is not installed in the aircraft, the maximum permissible G-load can be determined by the red warning lamp located to the left of the stick. If the warning lamp lights up, decrease the G-load until the lamp goes out.

The warning lamp, however, can light up within certain G-load limits owing to inaccurate operation of the AL-5 pressure control unit and G-20A and G-21A pressure warning units. It is worth noting, however, that on the UH-1 aircraft, which is not equipped with a hydraulic booster in the elevator control system, a G-load of 6 and above is practically impossible, when the aircraft's O.G. location is properly adjusted, due to the large forces acting on the control stick and the large amount of elevator deflection.

A considerable pressure built up in the UH-1 anti-G suit serves as a warning signal indicating that a considerable G-load has been reached.

When recovering the aircraft from the dive, with the engine running at a speed less than 8000 r.p.m., the pressure in the engine compressor may be found less than 2 kg/cm<sup>2</sup> and, consequently, the pressure set up in the anti-G suit by the AL-5 pressure control unit may prove insufficient and does not conform with the value of G-load imposed. Therefore, while recovering the aircraft from the dive, the pilot should not let the engine run at a speed less than 8000 r.p.m. or should recover the aircraft more smoothly without building up high G-loads.

When G-loads are built up during the flight, the pressure supply into the suit should be smooth. Sudden change of pressure may result in unpleasant sensations and, with the AL-5 pressure control unit out of order, even in unconsciousness.

Sudden buildup of pressure in the anti-G suit, if it is not accompanied by the AL-5 pressure control unit being defective. In this case, disconnect the suit hose from the aircraft air supply line and decrease G-load, if necessary.

Short-time pressure buildup in the UH-1 anti-G suit, by pressing the push-button on the AL-5 pressure control unit, may reduce the pilot's fatigue during a long-term flight.

Peer Original

V. SPIN

274. The aircraft spins inadvertently only in those cases when the pilot... The spin performed in the direction of the aircraft rotation is stable, as is the case of rotation, spins may be regular and irregular.

AIRCRAFT BEHAVIOUR AT VARIOUS FLYING SPEEDS AND SPIN CHARACTERISTICS

277. When the aircraft loses stability, the minimum values of indicated airspeed with the engine running at idle rating, are as follows: (a) with the landing gear and flaps retracted - 220 to 200 km/hr;

(b) with the landing gear and flaps extended - 200 to 150 km/hr. When climbing at maximum engine rating, with the landing gear and flaps retracted, the minimum indicated airspeed is 150 km/hr.

278. Flying with the landing gear and flaps up (with the speed brakes extended) back pressure to the control stick, with the pedals in the neutral position (the stick control lever being shifted to the idle rating position), at a speed of 200 km/hr, may result in a warning vibration which increases with the further decrease of the airspeed. In this case, the efficiency of ailerons decreases but is still sufficient to prevent the aircraft from stalling.

279. When the flying speed drops to 200 - 190 km/hr IAS will result in wing-tips stall and with the control stick deflected all the way back, the aircraft will stall.

280. The aircraft may stall if the speed decreases to 180 - 170 km/hr and the aircraft may yaw-roll because more energetic. In this case, the aircraft nose has dropped 30 - 40° below the horizon (with the control stick deflected all the way back), the aircraft speed then rises up to 240 - 250 km/hr and the aircraft enters a normal stall.

281. In all cases forward pressure applied to the control stick at low flying speeds causes the aircraft to immediately drop its nose, the flying speed increases and the aircraft enters a normal stall.

282. When the aircraft steadily maintains the flight attitude up to an indicated airspeed of 190 km/hr. In this case, the warning vibration starts at an indicated airspeed of 240 - 230 km/hr. The aircraft enters the spin only after the full deflection of the control stick is moved all the way back.

283. When the aircraft with extended landing gear and flaps, with the engine running at idle rating, the aircraft steadily maintains the flight attitude up to the indicated airspeed of 210 - 190 km/hr.

284. The warning vibration of aircraft, before entering the spin, is less than with the retracted landing gear and flaps. In the latter case, the aircraft is more stable at the indicated airspeed.

285. With the pedal fully pressed and control stick moved all the way back, the aircraft stalls in the direction of the pressed pedal and enters the spin less energetically than in case when the landing gear and flaps are retracted.

The moment the aircraft enters the spin is indicative by considerable vibration in ailerons (vibration) on the control stick and pedals.

286. Overcontrolling with the stick during the banked turn, stall and loop is accompanied by considerable vibration which warns the pilot well in advance about the onset of spin.

287. In case of stick overcontrolling during the banked turn at a speed of 400 - 450 km/hr, the aircraft recovers energetically from the banked turn and, then, into the banked turn, and makes a descending roll.

288. When performing a climb with stick overcontrolling at a speed of 400 to 450 km/hr, at the last quarter of the climb the aircraft stalls in the direction of the turn and makes a descending roll.

289. As the aircraft approaches the top of the loop, with the stick overcontrolled, the aircraft rolls through 180° round its fore-and-aft axis after which it stalls with considerable vibration and makes a descending roll.

290. If at the moment of vibration the pedal is pressed fully and the control stick is moved all the way back, the aircraft enters the spin in the direction of the pressed pedal.

291. In all cases of aircraft vibration during the performance of flight maneuvers, step pulling the control stick or push it slightly until vibration discontinues.

292. While breaking into the spin, the deflection of ailerons into the spin (with a left-hand spin, the control stick is shifted to the left) or against the spin (with a right-hand spin, the control stick is shifted to the right) does not have any considerable effect on the nature of stall.

AIRCRAFT BEHAVIOUR IN SPIN

293. The behaviour of the Mi-17 aircraft in the spin, with the controls fully deflected into the spin (with the ailerons in the neutral position), slightly differs from that of other (unrepaired wing) fighters and is similar to the behaviour of the Mi-17 aircraft in spin.

294. The spin of the Mi-17 aircraft is stable in the direction of rotation without spontaneous change of rotation direction in the process of the spin.

295. The rotation of the aircraft both in the left-hand and the right-hand spin, with the controls fully deflected into the spin and the ailerons in the neutral position, is, as a rule, irregular. In some cases, mostly in the right-hand spin, rotation can be regular.

296. In case of an irregular spin, the aircraft stops rotating every half or three quarters of a turn. In the process of the spin, the aircraft periodically rolls and drops its nose and at the moment the rotation of controls retained, banks in the opposite direction. However, with the deflection of controls in the desired direction the aircraft does not change to a reverse spin but keeps on rotating in the desired direction. After the rotation has stopped, the vibration of the aircraft increases and small alternating loads are felt on the control stick and pedals.

297. The angle of inclination of the fore-and-aft axis of the aircraft to the horizon varies during irregular spin from 20 to 70°, the duration of one turn is about 4 seconds, and the loss of altitude per turn rises up to 400 - 450 m.

298. The rotation of the aircraft in the right-hand spin is, as a rule, more uniform than in the left-hand one. Uniform rotation is settled in the right-hand spin through one - two turns. In some types of aircraft the rotation in the left-hand spin through one - two turns.

Peer Original

than in the regular spin, the aircraft rotates continuously without stops or delays; the angle of inclination of the aircraft fore-and-aft axis to the horizon varies within 40 to 60° and the alternating loads on the control stick and pedals are less noticeable.

The duration of one regular spin turns is 3 seconds and the loss of altitude per one turn during the regular spin makes up 300 - 350 m.

288. The type of spin depends on the position of ailerons when performing the maneuver.

The deflection of the ailerons into the spin in the process of the maneuver execution (the control stick being shifted to the left in a left-hand spin, and to the right in a right-hand spin) increases the irregularity of the aircraft rotation. The aircraft stops rotating more frequently and for a longer time, raises its nose above the horizon, and the moment the rotation stops banks into the opposite side without entering the spin of another direction. Stops in the aircraft rotation result in considerable vibration and forces on the control stick and pedals, which tend to shift the controls to the neutral position.

With the ailerons deflected against the spin in the process of the maneuver execution, the rotation of the aircraft in the right-hand and the left-hand spins is uniform without slowing down (the angle of inclination of the aircraft fore-and-aft axis to the horizon being 40 - 60°) and with a very slight rise and drop of the aircraft nose. In this case, no alternating forces are felt on the control stick and pedals; the control stick is pulled full back.

Setting the ailerons in the neutral position, while performing the spin and keeping the controls applied into the spin, does not affect the nature of spin and the rotation of the aircraft remains regular.

289. With the control stick moved full back, the aircraft spin becomes steeper and more energetic.

The aircraft rotates energetically almost continuously with an inclination angle of 60 to 70° and the forces on the control stick and pedals are of a variable nature.

290. When the speed brakes are applied, the spin characteristics and its recovery procedure remain practically unaltered.

291. The change of aircraft C.G. location within the C.G. operating limits does not have any considerable effect on the spin characteristics and the recovery from it.

292. The G-loads during the spin are inconsiderable and are not practically felt by the pilot.

SPIN RECOVERY

293. Recover the aircraft from the spin in the following sequence:

(a) energetically apply full pedal against the spin, then, after a quarter or half a turn move the control stick full forward; the control stick being moved forward and in the process of the spin recovery the ailerons should be held neutral;

(b) when the aircraft has stopped rotating, immediately set the pedals neutral and, on reaching 300 km/hr IAS, gradually pull the aircraft out of the dive.

If, after the pedal has been pressed for recovery, the rotation of the aircraft slows down before the aircraft has been pressed for recovery, the rotation of the aircraft must be moved correspondingly earlier, at the moment the aircraft rotation has stopped.

After shifting the control stick forward, the aircraft drops its nose in case cases here down by 50° with increase of rotational speed and stops rotating approximately after a quarter or half a turn.

294. In case of an irregular spin, the deflection of controls for recovery at the moment the rotation has stopped, results in immediate recovery from the spin without delay. In this case, to recover the aircraft, it is necessary to set the pedals neutral, move the control stick beyond the neutral position and when the flying speed of 300 km/hr is reached, pull the aircraft out of the dive.

With the controls deflected for recovery at the moment the aircraft rotation has stopped, the aircraft recovers from the spin after not more than one turn.

From a regular spin, the aircraft recovers after energetic and full deflection of controls for recovery in a proper sequence (first the pedal and, then, the control stick) within one and a half turns.

The forces to be applied to the controls to recover the aircraft from a regular spin, are somewhat higher than in recovering the aircraft from an irregular spin.

295. The deflection of the ailerons into the spin, with the control stick moved forward, does not affect the recovery of aircraft from the spin.

With the ailerons deflected against the spin, while pushing the control stick, the aircraft recovers from an irregular spin with much delay and fails to recover from a regular spin.

Therefore, when recovering the aircraft from the spin, do not apply the ailerons against the spin.

296. With the pressure on the pedals and control stick released in the process of an irregular spin, the pedals set in the neutral position, the control stick moves beyond the neutral position and the aircraft changes from the spin into a tacked dive. The aircraft does not recover from a regular spin with the controls released.

297. If the sequence of deflection of the controls is not properly observed when recovering from an irregular spin (simultaneous application of the pedals and control stick; deflection of the control stick and, then, of the pedal; incomplete deflection of the controls for recovery from the spin), the aircraft recovers from the spin with a delay of up to one turn.

Inobservance of the proper sequence of deflection of the controls, as well as slow deflection of the controls when recovering from a regular spin, result in a recovery delay of up to two and even more turns, and may even lead to the failure of the aircraft to recover from the spin.

298. Loss of altitude after two spin turns with subsequent recovery to a level flight makes up 1000 to 2200 m.

299. If the aircraft fails to recover from the spin, apply the controls late the spin again, i.e. press full pedal into the direction of the aircraft rotation and apply back pressure to the control stick; half a turn later, repeat the recovery from the spin. While doing so, check to see that the ailerons are not applied against the spin.

300. If the aircraft fails to recover from the spin, the pilot must abandon the aircraft at an altitude of 2000 m.

INADVERTENT SPIN RECOVERY

301. If inadvertent spin occurs, bring the aircraft into level flight before it has developed a steady spin by pressing the pedal in the direction opposite to the turn and applying forward pressure to the control stick, then, when the aircraft is level flight.

302. If the pilot fails to keep the aircraft from spinning and the latter enters the spin, he must proceed as follows:

(a) shift the engine control lever all the way back!

Peer Original

- (b) determine the direction of aircraft rotations;
- (c) apply the controls into the spin and neutralize the ailerons;
- (d) use the spin recovery procedure, discussed above.

**INVERTED SPIN AND INVERTED SPIRAL**

303. The F4U-7 aircraft can inadvertently enter the inverted spin or the inverted spiral only in case of flagrant errors in flying technique or in case of abrupt pushing of the pedal and control stick, with the controls being fixed for a long time in the deflected positions.

(a) when performing flight maneuvers at an indicated airspeed less than 220 km/h, with the aircraft in the wheels-up position;

(b) in level flight when losing speed and dropping into a normal spin;

(c) when improperly handling the controls in recovering from a normal spin. With the aircraft entering the inverted spin from the wheels-up position, it performs an irregular (with negative G-load) half-roll or a 540° roll, then, makes energetically a nose-down-wing-over, assumes the wheels-up position and enters the inverted spin.

Abrupt pushing of the pedal and control stick and their fixing in the above position in level flight, at the moment the aircraft drops into a normal spin, will make the aircraft energetically lower its nose, roll into the wheels-up position and enter the inverted spin.

If the ailerons are deflected against the spin, the aircraft performs an irregular roll with a descent: in the direction of the deflected pedal, then, energetically make nose-down-wing-over, assumes wheels-up position and enters the inverted spin. With the ailerons deflected into the spin, the aircraft does not enter the inverted spin but changes to diving, slowly rotating in the direction of the pressed pedal.

When recovering from the normal spin, the aircraft may enter the inverted spin only when the position of the controls deflected for recovery is retained after discontinuing the rotation of the aircraft and changing the latter to negative angles, especially when the control stick is fully deflected forward and to the side opposite to the pressed pedal.

When entering the inverted spin, the pilot is subjected to alternating negative G-loads, while the control stick and pedals experience shock-type loads.

**AIRCRAFT BEHAVIOUR IN INVERTED SPIN**

304. After entering the inverted spin, the aircraft makes one or one and a half turns of an unsteady inverted spin which is characterized by:

- (a) irregular rotation;
- (b) considerable vibration of the aircraft nose in the vertical planes;
- (c) alternating negative G-loads;
- (d) alternating forces on the controls.

After one or one and a half turns of the unsteady spin, the aircraft changes to a steady inverted spin which is characterized by:

- (a) regular rotation;
- (b) lesser vibration of the aircraft nose in the vertical planes;
- (c) more constant negative G-loads;
- (d) more constant forces on the controls.

When the aircraft is in a steady inverted spin, with the ailerons set in a neutral position, the angle of inclination of the aircraft fore-and-aft axis to the horizon

makes up approximately 130 - 140°. With the ailerons deflected against the spin, the spin becomes shallower.

In a steady inverted spin, with the ailerons in the neutral position and as well as with the ailerons deflected against the spin, the pilot does not see the natural horizon. Owing to the inverted attitude of the aircraft, the invisibility of the natural horizon and the effect of negative G-loads, the orientation in space and the location of aircraft direction of rotation are hampered. In an inverted spin the aircraft always rotates in the direction of the pressed pedal. The duration of one turn is 2.5 to 3.0 seconds and the loss of altitude per turn is 300 to 400 m. The right- and left-hand spins differ but slightly.

**AIRCRAFT BEHAVIOUR IN INVERTED SPIRAL**

305. During the first one or one and a half turns it is practically difficult to distinguish the inverted spiral from the inverted spin by the behaviour of the aircraft. However, by the end of the second turn the pilot can easily determine that the aircraft is in the inverted spiral which is normally characterized by:

- (a) increase of speed;
- (b) lower rate of angular rotation than in an inverted spin;
- (c) larger forces on the controls;
- (d) larger negative G-loads which increase with the increase of speed.

**RECOVERY FROM INVERTED SPIN AND INVERTED SPIRAL**

306. To recover the aircraft from an inverted spin or spiral, proceed as follows:

- (a) move the engine control lever backwards;
- (b) set the pedals and ailerons in the neutral position and simultaneously pull the control stick to slightly backward of neutral until rotation stops.

If, during the inverted spin recovery, full pedal is pressed into the spin, the aircraft may fail to recover from the spin. In this case, the aircraft may change from inverted to normal spin if the control stick is deflected backward and to the side opposite to the pressed pedal. Releasing of the controls in the inverted spin results in the aircraft recovering with a delay of up to two or three turns. If the aircraft has not recovered from the inverted spin down to an altitude of 2000 m, the pilot should abandon the aircraft.

The loss of altitude during the inverted spin recovery, beginning from the moment the pedals are set neutral and up to the moment the aircraft returns to level flight, makes up 1200 - 2000 m.

If, with the aircraft recovering from the inverted spin, the control stick is deflected backward and to the side opposite to aircraft rotation, the aircraft recovers from the spin with a greater delay (within one and a half or two turns).

If, during the inverted spin recovery, full pedal is pressed into the spin, the aircraft may fail to recover from the spin. In this case, the aircraft may change from inverted to normal spin if the control stick is deflected backward and to the side opposite to the pressed pedal. Releasing of the controls in the inverted spin results in the aircraft recovering with a delay of up to two or three turns. If the aircraft has not recovered from the inverted spin down to an altitude of 2000 m, the pilot should abandon the aircraft.

**FLYING IN WEATHER WITH GROUND INSTRUMENTS**  
**AIRCRAFT INSTRUMENTS FOR COLLECTING WEATHER DATA**  
**FOR ANALYSIS BY AIRCRAFT INSTRUMENT SYSTEMS**

307. The safety of flying in adverse weather conditions, accurate instrument approach and landing, using the OOI system and OOI with PCL-1 landing systems are ensured by:

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

- (a) good knowledge of operating instructions for flight instruments and aircraft radio navigation equipment;
  - (b) reliable operation of aircraft equipment and ground aids of the OOI and PCU-A landing systems;
  - (c) proper maintenance of flight attitude at all stages of instrument approach and landing;
  - (d) correct and timely estimation of flight weather conditions;
  - (e) regular training of pilots in flying under adverse weather conditions, using the OOI instrument landing system.
308. Flights in adverse weather conditions at the weather minimum prescribed for the given airfield are performed with mandatory implementation of the aircraft and airfield radio and lighting equipment.

BEFORE FLIGHT

309. Before the flight, the pilot should make sure that gyro horizon IZ-4, remote-reading geomagnetic compass IZK, low-altitude radio altimeter PB-2, automatic magnetic compass APK and other flight instruments operate reliably. Whenever necessary, check the above instruments additionally for proper functioning. Make certain the aircraft is filled with de-icing fluid.

310. To prevent the aircraft starting over in a flight with a faulty gyro horizon switch on gyro horizon IZ-4 at temperatures from +50 to -30°C not later than 3 minutes after the take-off, for such purpose, before switching on the instrument, press the starting push-button on the right side of the instrument and, then, release it the starting minimum (3 min) time of instrument readiness for operation. At temperatures below -30°C, cut in the instrument 4 minutes before the take-off.

311. Cut in the heater of the main pilot-static tube and emergency pilot tube IZ-156.

312. It is not allowed to begin the flight if the pilot finds the aircraft equipment inoperative or radio communication equipment and airfield radio navigation aid operate irregularly.

IN FLIGHT

313. Normal flying in adverse weather conditions largely depends on the correctness of gyro horizon readings.

To avoid errors occurring in the gyro horizon readings, proceed as follows:

- (a) perform ~~maneuver~~ at a bank of 20 to 45° when gyro horizon IZ-4 is established;
- (b) switch on the gyro horizon in flight only when the aircraft is in the level flight. The gyro horizon readings will be correct 2 minutes after it has been cut in them with those of turn indicator IZU-46 (or IZU-53), rate-of-climb indicator, and remote-reading geomagnetic compass IZK.

314. If the gyro horizon has failed, continue to fly by the readings of turn indicator IZU-46 (or IZU-53) operating in conjunction with other instruments (rate-of-climb indicator and compass IZK). Keep in mind that flights without a gyro horizon training.

UPWARD AND DOWNWARD CLIMB/PENETRATION, INSTRUMENT APPROACH AND LANDING USING INSTRUMENT LANDING SYSTEM AND PCU-A RADAR CONTROL LANDING SYSTEM

315. After take-off, retract the landing gear and, at an altitude of minimum 300 m, check the readings of the gyro horizon against the actual attitude of the aircraft relative to the natural horizon, then, gradually increasing the climbing angle, change the aircraft to climbing, bringing the true airspeed up to 250 km/hr, with the engine running at normal rating. While doing so, with the aircraft climbing, the indicated airspeed and the readings of the rate-of-climb indicator will decrease. Climbing and cloud penetration during alarm flights or flights for air target interception are performed at take-off (combat) engine rating (11,500 r.p.m.) and a true airspeed of 250 km/hr.

316. Instrument approach and landing, with implementation of the OOI instrument landing system or the PCU-A radar control landing system, may be performed by the straight-in approach procedure, two-180°-turn approach procedure or by the wide rectangular pattern approach procedure.

The main instrument approach and landing procedure used when landing approach is performed above clouds, is the straight-in approach procedure. If the approach to the runway is not accurate, or the pilot commits error in his judgement for landing, which requires go-around procedure, or if the visual landing approach by a small traffic pattern proves impossible, perform approach and landing using two-180°-turn approach procedure or the wide rectangular pattern approach procedure.

INSTRUMENT APPROACH AND LANDING USING STRAIGHT-IN APPROACH PROCEDURE

317. Approach the outer heading station at the assigned flight level or at 200 to 300 m above the cloud top from any direction, having first requested the flight control officer for instrument landing clearance and landing instructions.

318. After being cleared for an instrument approach and landing, set the value of ground pressure on the altimeter scale and the scale of the remote-reading geomagnetic compass - at the landing course, having matched the landing course with the label line on the fixed section of the scale.

319. Check the entry of the outer marker zone of action by the filtering of the signal lamp WARM (MAREP) and by the radio signal (bell ringing) up to an altitude of about 5000 m, and at altitudes above 5000 m - only by the unstable readings of the automatic radio compass bearing indicator. Fix the time the aircraft passes the outer heading station by the change of readings on the automatic radio compass bearing indicator from 0° to 180°.

320. Fly from the heading station on the course which is the reciprocal of the final approach course and perform a maneuver above clouds to intercept the final approach course at an indicated airspeed of 500 km/hr.

321. On intercepting the landing course, extend the landing gear and deflect the flaps 20° down, set an indicated airspeed of 450 km/hr and change the aircraft to a descending flight.

322. Depending on the altitude, the rate of descent, when on the landing course, should be: down to an altitude of 2000 m - 30 m/sec, from an altitude of 2000 down to 1000 m - 15 m/sec, from an altitude of 1000 down to 600 m - 10 m/sec, and from an altitude of 600 down to 200 m - 5 to 3 m/sec.

323. At an altitude of 200 m, assume a level flight attitude and continue flying

SECRET/NO FOREIGN DISSEM

Peer Original

At this altitude (in the clouds or under the cloud base) until entering the outer marker beacon zone, having decreased the flying speed down to 400 km/hr. The altitude of the aircraft when passing the outer marker is 200 m.

324. After entering the outer marker beacon zone, immediately shift the automatic radio compass range frequency back to the frequency of the inner marker beacon and, maintaining the radio station relative bearing equal to 0°, fly on the inner marker beacon. After passing the outer marker beacon, decrease the speed down to 300 km/hr, with the rate of descent equal to 2 - 3 m/sec, extend the flaps to the landing position and descend to an altitude of 400 m. The altitude of the aircraft when passing the inner marker beacon is 50 to 100 m.

325. Having passed the inner marker beacon, set a gliding speed of 260 km/hr, finalize the landing situation and perform a visual landing.

326. If it is impossible to land the aircraft right after cloud penetration (speed is too high or the aircraft is not accurately aligned with the landing runway, etc.), make a go-around and request clearance to make visual approach for landing below clouds or, depending on the weather conditions and terrain, instrument approach in clouds or below clouds using two-100° turn approach procedure or the wide rectangular pattern approach.

TWO-100° TURN APPROACH PROCEDURE

327. In case of missed approach, when the pilot decides to make a two-100° turn approach he should lock the time when the aircraft passes the inner marker beacon and climb to an altitude of 500 m at a vertical speed of 5 m/sec.

One minute after passing the inner marker beacon he makes 30° bank turn to intercept the course which is the reciprocal of the landing course.

Then, above the outer marker beacon, read the stop-watch readings, report the aircraft condition over the radio and continue to fly at a speed of 500 km/hr, introducing a drift correction. After the aircraft passes the inner marker beacon, report the aircraft position over the radio and make 30° bank turn to intercept the final approach course. In the second half of the turn, change the bank value to obtain simultaneous settling of the pointer of the AF-5 automatic radio compass at zero relative bearing, and the pointer of the RVM-5 radio-compassing gyrocompass, at the landing course. After the turn, perform level flight on the final approach heading for 30 seconds. Within the above time period, decrease speed down to 450 km/hr, extend the landing gear and deflect the flap 20° down, report the aircraft position over the radio and start descending with a vertical speed of 5 - 3 m/sec.

At an altitude of 200 m return the aircraft to level flight, decrease speed down to 400 km/hr and, without distracting attention to locate the runway or to identify the reference points, fly the aircraft by instruments until the outer marker beacon is reached, strictly maintaining an altitude of 200 m and zero relative bearing.

On receiving the outer marker beacon message, the pilot should switch the AF-5 automatic radio compass over to the inner marker beacon, make a correction turn if necessary, to obtain zero relative bearing, decelerate the engine and lower the flaps completely, and the aircraft into descent at 2 - 3 m/sec and report over the radio that the aircraft has passed the outer marker beacon.

On passing the inner marker beacon at an altitude of 50 to 100 m, make sure visually that the approach for landing is correct.

WIDE RECTANGULAR PATTERN APPROACH PROCEDURE

328. When going around for making a landing approach using the wide rectangular pattern procedure at a speed of 500 km/hr, climb the aircraft.

On the slope of estimated time, after passing the inner marker beacon, turn to crosswind leg through 90° and continue to climb up to an altitude of 500 m with a vertical speed of 5 m/sec. Having gained the prescribed altitude, return the aircraft to level flight, maintaining a speed of 500 km/hr.

On reaching 230° (130°) relative bearing of the radio station, perform the final leg turn with 30° bank to intercept the course, which is the reciprocal of the landing course.

Having reached 230° (130°) relative bearing of the radio station, make a bank leg turn through 90°, and on reaching 265° (125°) relative bearing of the radio station perform final turn in a horizontal plane to intercept the landing course.

After intercepting the final approach course, while on the 30-second level flight leg, decrease speed down to 450 km/hr, extend the landing gear and deflect the flap 20° down, report over the radio and descend the aircraft at a vertical speed of 5 m/sec. At an altitude of 200 m return the aircraft to level flight and reduce the speed down to 430 km/hr.

329. Henceforth, the flight procedure is the same as in case of two-100° turn approach procedure.

VII. EMERGENCY CASES  
330. EMERGENCY CASES

- 331. When approaching the airfield, check to see that:
  - (a) the circuit breakers of guns and bomb armament are out off;
  - (b) the safety guards are leaving the upper fire control push-button and the knob release push-button located on the control stick;
  - (c) the main air system is under pressure, and if the value of pressure is insufficient, check the emergency system filling valve for ease of opening to ensure normal functioning of the brakes.
- 332. Increase engine speed and, if necessary, apply the speed brakes to set a flying speed of 500 km/hr, then, enter the airfield traffic pattern at an altitude of 500 m.

LANDING GEAR EXTENSION

- 333. Extend the landing gear before making to base leg, then at a flying speed of 450 km/hr, by shifting the landing gear lever down (DOWN-GEAR). The normal duration of landing gear extension is 8 to 10 seconds.
- 334. The extension of landing gear is checked by the complete protrusion of mechanical indicators, by the flash of green warning lamps and by the full pressure value in the hydraulic system (160 to 170 kgf/cm²). Set the landing gear lever in the "DOWN-GEAR" position before making out the aircraft to the parking place and stopping the engine.
- 335. After establishing the landing gear, release the forces on the control stick by the elevator trim tab and lock the seat harness.

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

APPROACH AND LANDING

335. After extending the landing gear, fly the aircraft level and perform the turn at a speed of 300 to 310 m/hr. In the turn, fly at a speed of 350 m/hr. Before turning the aircraft to final 180°, lower the flaps, first in the take-off position (20° down) and, then, in the landing position, and check the extension of the flaps by the warning lights and the mechanical indicator located on the left wing.

Do not remove the hand from the flap control until the flaps are completely lowered.

336. The final turn should be executed at a speed of minimum 300 m/hr with increased engine speed. The aircraft must be recovered from the final turn at an altitude of minimum 200 m.

Having turned to final, set a speed of 260 to 250 m/hr and glide at the above speed up to the beginning of leveling-off.

The pilot will glide for landing depending on insufficient application of power and finalize the judgment by changing the engine speed.

337. In case of late rate approach which threatens the safety of aircraft landing, a missed approach procedure will be used.

338. The aircraft may initiate a missed approach procedure from any altitude open to the aerodynamic altitude (d = 7 m).

Having decided to go round, the pilot should accelerate the engine up to the speed required by adjusting the engine control lever to the maximum position within 1 to 2 seconds.

On gaining a speed of 300 m/hr, he will assume climbing attitude and gradually increase the flying speed.

At an altitude of 100 m and a speed of minimum 300 m/hr, retract the flaps at the same rate as for landing.

Note. In case of a missed approach, the warning lamp (located with celluloside of instrument panel), the pilot should immediately make a go-around. If the warning lamp has not been extended or has been extended incompletely.

LANDING

339. At an altitude of 30 - 20 m shift the gaze towards the ground to the left and forward at 10 - 15° angle, and downward at an angle of 15 - 20°, to the point of landing.

Start leveling-off at an altitude of 7 - 6 m, smoothly pulling the control stick (step descending) at an altitude of not more than 4 m.

340. Flare should be accompanied by gradual descent of the aircraft, due to which pressure on the control stick increases to a rate amounting to about 100 m/hr and establishes higher angles of attack for landing.

341. In the process of flare, the direction of vision towards the ground must be changed since it may lead to an error in determining the distance to the ground, and excessive reaction of vision to the wing edge may result in spontaneous ballooning while getting away of vision from the wing edge may lead to the nose wheel touching the ground first.

If during landing the pilot looks at the ground through the windshield of the cockpit canopy, then, with the aircraft ballooning (bouncing), the ground surface will be covered by the front section of the aircraft, creating a false impression of the height of ballooning. As a result, the pilot is likely to make other mistakes - excessive and energetic pushing of the control stick and, then, excessive and energetic pulling of the control stick, which may result in bad ballooning (bouncing) of the aircraft.

342. After two main wheels contact the ground, the pilot should not apply additional back pressure to the control stick but hold the control stick in the touchdown position until the nose wheel comes to touch the ground, the direction of pilot's vision being the same as during the floating procedure.

343. As soon as the nose wheel has lowered to the ground and the aircraft has started rolling on three wheels, the speed drops down to a value preventing the aircraft from lifting off the ground; the pilot must shift the gaze ahead and begin braking procedure.

The pilot brakes the wheels by smoothly applying pressure to the brake lever, i.e. by gradually increasing pressure so as to pull the lever to the first-stage stop by the end of the aircraft landing roll. Such a method of braking reduces the wear of tires and wheel checks to the minimum.

Whenever necessary to reduce the length of landing run to the minimum, press the brake lever in such a way as to pull the brake lever to the second-stage stop by the end of the landing roll.

344. Energetic braking at the end of landing roll may result in ground loop to either side. If this is the case, lower the brake lever to release the wheel, set the pilot to the neutral position and, then, gradually apply the wheel brake again.

345. If no ATR pressure is available in the main air supply system during the landing of the aircraft, immediately open the brake system emergency supply valve on the cockpit starboard after the aircraft has begun steady landing roll. The wheel brakes, in this case, will operate even though the air system is not airtight.

346. On terminating the landing roll, clear the runway, retract the flaps and speed brakes (if the latter have been applied); if necessary, depressure the cockpit, open the canopy and cut off the aircraft transporter and the ATR automatic engine stoppers.

347. After a flight mission involving firing practice, turn out the aircraft from the landing runway, place it in the direction safe for unloading the guns (removing the rocket shells) and, then, stop the engine.

Do not tow the aircraft after a flight involving firing practice, before unloading the guns (or removing the rocket shells).

348. If in the process of landing the aircraft balloons due to pilot's error in flying technique, the pilot, depending on the nature of the ballooning, must use one of the following procedures to prevent the error:

(a) when landing the aircraft on three wheels at an increased speed (300 to 325 m/hr), the pilot should stop pulling the control stick at the moment the aircraft brakes contact with the ground and prevent the aircraft from further ballooning by short and smooth pushing of the control stick; then, with the flying speed decreased and the aircraft approaching the ground, gradually pull the control stick and land the aircraft on two main wheels;

(b) with the aircraft landing on two main wheels at a normal or slightly increased speed (170 - 190 m/hr), the pilot, at the moment the aircraft leaves the ground, should stop pulling the control stick at the same time preventing it from pulling.

SECRET/NO FOREIGN DISSEM

Peer Original

and eliminate the tank by energetic application of the pedal against the tank. As the aircraft nears the ground, land it on two main wheels by applying full tank pressure to the control stick.

In case of high leveling-off (above 1 m), stop pulling the control stick and, then, with the landing speed decreasing and the aircraft nearing the ground, perform normal landing on two main wheels.

**CROSSWIND LANDING**

349. While landing in a crosswind, the pilot will correct the drift of the aircraft by carrying the upwind wing low.

Landing is crosswind at wind velocity up to 30 m/sec presents no special problems. However, at a higher velocity of the wind, the deflection of the rudder may prove insufficient to correct the drift, since with the rudder deflected completely and the ailerons applied, the aircraft bank while slipping before landing does not exceed 10°.

350. When landing with ammunition completely used up and an emergency fuel reserve, the forces on the control stick are rather small and during landing after landing the aircraft pitches more intensely and may strike against the ground with the fuselage fin. Landing in such conditions requires special attention on the part of the pilot.

**LANDING ON UNPAVED RUNWAY**

351. Landing on an even unpaved runway does not differ from that on a paved runway.

When landing on uneven ground, do not allow early lowering of the nose wheel, since the aircraft possesses high progressive speed and while contacting rough ground may fly off the ground again and produce bouncing.

When landing on unpaved runway the brakes must be used gently; the pressure must be 0.5 - 2 kg/sq.cm, at first, and, then, up to 4 - 5 kg/sq.cm. Before clearing the runway, increase the engine speed slightly beforehand so as to prevent the aircraft from stopping and clear the landing runway as quickly as possible.

While taxiing on soft ground, check the gas temperature.

**STOPPING ENGINE**

352. If the engine was running on the ground at a take-off (combat) rating, it should be cooled down before stopping. For this purpose, run the engine at 5000 r.p.m. for 1 min, set the engine control lever to the idle rating position and run the engine for 30 seconds, then, depressurize the cockpit (if the reactor has been pressurized).

353. With the engine control lever set to the idle rating position, close the fuel stopcock (lift the stopcock handle all the way up) and cut off all the circuit breakers, except for the circuit breaker of the aircraft battery and the fuel booster pump.

As soon as the engine turbine stops rotating, cut off the battery and booster pump circuit breakers by the signal of the ground engineer.

Set the landing gear control handle in the neutral position, leaving first shift of the latch to the right, and cut off the landing gear electric switch.

354. Before leaving the cockpit, the pilot should do the following:  
(a) disconnect the hose of the parachute oxygen apparatus from the hose of the aircraft oxygen apparatus;

(b) disconnect the pull chain of the parachute oxygen apparatus from the cockpit switch;

(c) disconnect the hose of the MK-1 anti-G suit;

(d) disconnect the cord of the parachute release control unit from the seat arm rest to avoid parachute opening.

To reduce the time necessary for preparing the pilot for the next flight, it is allowed to leave the parachute in the cockpit.

355. Give necessary instructions to the ground engineer for eliminating faults in aircraft equipment which have been detected in flight.

**VIII. EMERGENCY PROCEDURES**

**PROCEDURE ON ENCOUNTERING ENGINE FAILURE IN FLIGHT**

356. If the engine cuts off in flight under visual meteorological conditions, proceed as follows:

- (a) immediately close the fuel stopcock;
- (b) shift the engine control lever back to the idle rating position;
- (c) advise ATC on the engine failure, altitude and position;
- (d) cut off the GENERATOR and the circuit breaker of the aircraft transporter.

357. If the engine fails at an altitude below 2000 m, do not try to start it. Depending on the situation, proceed as follows:

- (a) if the aircraft is in the vicinity of the airfield and the altitude of flight permits the aircraft to reach the airfield by gliding, extend the landing gear and perform a landing;
- (b) if the flight is performed over even ground (meadow or ploughland), make a forced gear-up landing;
- (c) if the flight is performed over the ground unsuitable for a forced gear-up landing, abandon the aircraft using the ejection seat.

358. In the event of engine failure at an altitude above 2000 m, attempt to start the engine. If the pilot has failed to start the engine before the altitude of 2000 m is reached, he should proceed as indicated above.

359. If the engine fails at an altitude above 11,000 m, descend at the maximum possible vertical speed down to an altitude of 11,000 - 10,000 m, checking the value of flying speed.

360. In case of engine failure in flight under adverse weather conditions, the pilot flying at an altitude of above 2000 m, should proceed as follows:

- (a) close the fuel stopcock;
- (b) change the aircraft to descending attitude;
- (c) cut off the GENERATOR and the aircraft transporter;
- (d) advise ATC on the engine failure;
- (e) descend below the cloud base only in a straight line;
- (f) when coming out of the clouds above 2000 m, start the engine and cut in the GENERATOR and the aircraft transporter.

361. If, while descending in the clouds with a failed engine, the aircraft has not come out of the clouds before an altitude of 2000 m is reached, or has come out of the clouds over the ground not suitable for safe forced landing, the pilot should abandon the aircraft using the ejection seat.

362. In all cases of engine failure, while flying in clouds at an altitude below 2000 m, the pilot should abandon the aircraft, using the ejection seat.

363. When the engine fails during a night flight at altitudes above 2000 m, the

Peer Original



pilot should try to start it. If the engine has failed to start before an altitude of 2000 m is reached, and landing on the lighted runway of the home airfield proves impossible, the pilot should abandon the aircraft using the ejection seat.

ENGINE STARTING IN FLIGHT

364. After descending the aircraft to an altitude of 6000 m (or with the engine cut off at an altitude of less than 6000 m, directly after its cutting-off), set the indicated flying speed at 100-120 km/hr and start the engine, for which purpose:

- (a) put in the starting ignition by setting the change-over switch to the POSITION IN FLIGHT (MARKETEK B BALVIZ) position (the red signal lamp in this case will light up);
- (b) open the fuel stopcock 10 to 15 seconds after cutting in the ignition;
- (c) watching the speed and temperature of engine gases, smoothly shift the engine control lever forward (at a rate of 15 sec) up to the maximum speed stop. If the engine fails to start, shift the engine control lever at the same rate in the opposite direction, selecting the optimum condition for starting the engine;
- (d) as soon as the engine speed starts increasing, pull the engine control lever to the idle rating position to avoid excessive growth of the exhaust gas temperature;
- (e) as the engine gains the steady speed corresponding to the engine control lever set in the idle rating position, cut off the starting ignition (the signal lamp should go out). Do not accelerate the engine to the steady rating (cruising, etc.), before the starting ignition is cut off;
- (f) set the required engine rating and cut in all the previously switched off circuit breakers.

The entire process of engine starting in flight takes 40-45 sec. Should the engine fail to start at the first attempt, close the stopcock and set the engine control lever to the idle rating position, check if the engine control lever is set to the idle rating position. Start the engine again at a lower altitude but not earlier than 20-30 seconds after closing the stopcock. Make the last attempt to start the engine at an altitude of 3000 m. The reliability of engine starting increases with the decrease of altitude and flying speed. The reliable starting limits of engine EK-1 are characterized by the data presented in Table 8.

Table 8  
Reliable Starting Limits of Engine EK-1

| Altitude, m | Indicated speed, km/hr | Rotor speed of inoperative engine, min |
|-------------|------------------------|--|
| 5000        | 300-400                | 800-1150                               |
| 4000        | 300-500                | 800-1230                               |
| 3000        | 300-600                | 800-1350                               |

Note. Do not start the engine in flight without closing the stopcock, since it may result in a sudden rise of gas temperature and a general increase of engine temperature.

PECULIARITIES OF STARTING ENGINE, MODEL EK-1A, IN FLIGHT UNDER WINTER CONDITIONS

365. The altitude and flying speed at which reliable starting of engine EK-1A is ensured under winter conditions, depend on the temperature of fuel in the aircraft fuel tanks.

With the temperature of fuel in the fuel tanks equal to -16°C (which is usually the case when the aircraft is parked for a minimum 24 hours at a temperature of an ambient air down to -20°C), the reliable starting of engine EK-1A in flight on aircraft MiG-17 is ensured at altitudes and speeds specified for engine EK-1.

Engine starting at altitudes from 5000 to 6000 m is unreliable and at altitudes above 6000 m does not start at all, therefore, do not start the engine at altitudes above 6000 m.

Reliable starting of the engine in flight at altitudes and speeds indicated in Table 8 is also provided for after gliding the aircraft with cut-off engine from altitudes of 10,000 to 11,000 m, since in this case no overcooling of the engine takes place.

When the temperature of fuel in the aircraft fuel tanks is -20°C and less (the fuel temperatures which may be observed when the aircraft is parked for about 24 hours at a temperature of an ambient air of approximately -30°C and less), the altitude and speed at which reliable starting of the engine can be ensured in flight reduce in due ratio with the temperature of fuel in the fuel tanks. In this case, start the engine at altitudes below 4000 m with flying speeds of 100 to 150 km/hr.

On aircraft MiG-17 the engine may also be started in flight after a continuous gliding (up to 7 min) with cut-off engine and cut-in aircraft consumes necessary for carrying out a flight in adverse weather conditions.

In these cases it is advisable to start the engine at altitudes below 3000 m with indicated airspeeds of 100 km/hr.

The procedure to be taken by the pilot when starting the engine in flight under winter conditions is the same as in summer conditions. Reliable starting of the engine in flight at altitudes and speeds indicated in Table 8 is also provided for in cases when two attempts have been made to start the engine from the aircraft battery, prior to the flight.

In case of three or four attempts made to start the engine in flight, the parameters of the aircraft battery remain practically unaltered.

When starting the engine in flight under winter conditions, the ignition of fuel in the combustion chambers (which occurs the increase of engine speed) takes place, as a rule, 10 to 15 seconds after complete opening of the stopcock without sudden rise of gas temperature behind the turbine beyond the maximum permissible value (62°C).

A delay of fuel ignition of up to 25 sec may sometimes be observed. Therefore, to increase the reliability of starting of the EK-1A engine in flight, keep the engine stopcock in the open position up to 25 sec. If the engine still fails to start, close the stopcock and make another attempt to start the engine at a lower altitude and a lesser flying speed.

PROCEDURE ON EXHAUSTING ENGINE LOGGY

366. When the engine is idling, the engine speed does not increase with the engine control lever shifted forward, but remains unaltered slightly above the flight idle rating speed. In this case the pressure on fuel is low but not less than 8-10 kg/cm<sup>2</sup>.

Peer Original

and the temperature of gases is low too. The engine may become loggy at an altitude of more than 7000 m.

- 367. If the engine is loggy, proceed as follows:
  - (a) put the engine control lever to the IDLE RAMPING position;
  - (b) cut in the isolating valves;
  - (c) slightly moving the engine control lever forward, set the required engine speed;
  - (d) if the engine speed and gas temperature cannot be restored, descend to an altitude of 6000 m;
  - (e) after eliminating the engine logging, cut off the isolating valve and read for the landing airfield.

Notes: 1. The loggy engine restores its normal operation without any interference on the part of the pilot with the aircraft descending down to an altitude of 6000 m.  
2. One should bear in mind that a loggy and a spontaneously cut-off engine can sometimes be confused.

PROCEDURE ON ENCOUNTERING ENGINE SURGING

368. Engine surging can be detected by the change of usual sound produced during operation, the drop of engine speed, and rapid rise of gas temperature behind the turbine. Surging is mostly observed at transient engine ratings, when accelerating the engine from low to medium or maximum speed.

369. To recover the engine from surging, decrease fuel feed at transient rating by partially pulling the engine control lever until surging discontinues. With surging stopped, gain the required engine rating.

370. Engine surging may occur also when flying at a high altitude in climb, with the engine running at maximum speed.

In this case, to eliminate engine surging, decelerate the engine, speed up the aircraft and decrease the flight altitude.

PROCEDURE ON ENCOUNTERING RADIO COMMUNICATION FAILURE

371. In all cases of sudden failure of radio communication, proceed as follows:
 (a) check the attachment of plug connector in the helmet adapter cord;
 (b) check if the volume control knob is set at maximum audibility;
 (c) check the radio communication on other channels.

If radio communication fails when flying under the cloud base, do not enter the clouds, discontinue the flight mission and land the aircraft.

372. Should radio communication fail when flying in clouds or above the cloud top, discontinue the flight mission, check if the aircraft transponder is cut in, ring the distress signal, home on the airfield radio station, strictly maintaining the flight conditions, and, using the radio set as a transmitter, perform the landing approach.

373. If radio communication fails during a night flight, proceed in the same way as when flying in clouds, and fire a flare of any colour when turning final or after floodlights.

Note. If the hoisting station is provided with additional equipment, the command of the pilot control officer can be received through the AFX automatic radio compass receiver, for which purpose, with the transmitter functioning properly:

- (a) advise the ground on switching-over to the AFX automatic radio compass;
- (b) set the RADIO CONTACT RECEIVER (RFRM AFX) channel to the required frequency.

RADIO COMPASS (AIX) position:
 (c) set the magnetic switch in the radio compass control panel in the LOOP (MAGNETIC) position, and the change-over switch EXT - MIC (EXT-119) - in the VOICE position.

On receiving the orders from the flight control officer, set the communication switch periodically in the COMMAN (COMMAN) position, otherwise, the course indicator will not show the direction to the hoisting radio station.

PROCEDURE ON ENCOUNTERING GYRO HORIZON FAILURE

374. Failure or incorrect readings of the gyro horizon in flight is determined in any flight attitude (level flight, climbing, descent or backed turn) only by comparing the readings of the whole group of flight instruments taken jointly.

375. If the gyro horizon is faulty, pass over to piloting the aircraft by the turn-and-slip indicator in conjunction with the speed indicator, rate of climb indicator, altimeter, and ILLUM remote-reading gyroscopic compass.

Maintain the flight attitude checking the roll control with the turn-and-slip indicator, pitch control - with the speed indicator, altimeter and rate-of-climb indicator, and directional control - by the turn indicator with additional check by the gyroscopic and automatic radio compasses.

PROCEDURE ON ENCOUNTERING SPEED INDICATOR FAILURE (total-pressure line defective)

376. The failure of speed indicator may occur not immediately but gradually. Therefore, first make sure that the speed indicator has failed. For this purpose, without changing the engine speed, constantly change the aircraft to descent or climb checking the attitude by gyro horizon AFX-1 and by the rate-of-climb indicator.

If the speed readings do not comply with the flight attitude, while the other instruments function normally, it means that total-pressure line has failed.

377. Should the speed indicator fail to operate, first check the switching of the pitot-static tube heater and change the supply of impact pressure from the main pitot-static tube to emergency pitot tube III-156.

Check the flight attitude by the readings of the gyro horizon, engine speed indicator, rate-of-climb indicator and altimeter.

In case the speed indicator fails to operate, it is advisable to maintain the engine speeds indicated in Table 9 at various flight attitudes and during a straight-in approach for landing.

Table 9

| Flight attitude                       | Pitch angle by AFX-1, deg |     |    |        |   | Notes                            |
|---------------------------------------|---------------------------|-----|----|--------|---|----------------------------------|
|                                       | 1                         | 2   | 3  | 4      | 5 |                                  |
| Climb                                 |                           | 500 | 15 | 10,500 | 5 | Landing gear and flaps retracted |
| Level flight at altitude below 6000 m |                           | 500 | 0  | 9500   | 0 | Same                             |
| Maximum endurance conditions          |                           |     |    |        |   |                                  |
|                                       | at altitude 3000 m        |     | 0  | 7700   | 0 | Same                             |
|                                       | at altitude 5000 m        |     | 0  | 8300   | 0 | Same                             |

Peer Original

| 1                                 | 2   | 3     | 4           | 5  | 6   |
|-----------------------------------|-----|-------|-------------|----|---|
| Glides:                           |     |       |             |    |   |
| to altitude 2000 m                | 450 | 30    | 7500        | 12 | Landing gear extended, flaps deflected 30° down |
| from 2000 to 1000 m               | 450 | 15    | 8000 - 8500 | 5  | Same  |
| from 1000 to 600 m                | 450 | 10    | 9200        | 3  | Same  |
| from 600 to 200 m                 | 450 | 5 - 3 | 9600        | 2  | Same  |
| Level flight at altitude of 200 m | 400 | 0     | 9500-10,000 | 0  | Same  |

Note: When flying with drop fuel tanks, maintain the engine speed by 200 r.p.m. higher than the speeds given in this table.

**PROCEDURE ON ENCOUNTERING SPEED INDICATOR, RATE-OF-CLIMB INDICATOR AND ALTITUDE FAILURE (pitot-static tube line defective)**

375. Simultaneous failure of speed indicator, rate-of-climb indicator and altimeter (pitot-static tube line faulty) is first detected by the behaviour of the rate-of-climb indicator whose pointer settles abruptly in the zero position or slowly responds to the deflection of the controls, and also by the readings of the altimeter which remain unaltered with the aircraft assuming the climbing or descending attitude. The main instrument ensuring piloting of the aircraft in adverse weather conditions with the pitot-static tube line defective, is the AIK-1 gyro horizon, operating in conjunction with the engine speed indicator.

When flying above 2000 m the flight altitude is determined by the readings of the FRII cockpit altitude and pressure differential gauge (with the cockpit pressurizing valve open to capacity, the cockpit "altitude" equals approximately half the aircraft flight altitude).

At altitudes below 2000 m, it is practically impossible to determine the flight altitude by the FRII cockpit altitude and pressure differential gauge.

From an altitude of 1200 m down to the ground surface, the flight altitude is determined by the readings of the P-2 radio altimeter.

379. Perform approach for landing when flying over the cloud top. Intercept the landing course above the cloud top as accurate as possible. After extending the landing gear and flaps, set the necessary rate of descent and without changing it enter the clouds.

Avoid turning when descending in clouds on the landing course. While descending, maintain the flight conditions indicated in Table 30.

Table 30

| Altitude                                      | Pitch angle (read on gyro horizon), deg | Engine speed, r.p.m. | Special notes |  |
|---|---|----------------------|---------------|--|
|   |   |                      | 1             | 2  |
| Up to 4000 m (cockpit altitude equals 2000 m) | 10                                      | 7500                 |               | The readings of the AIK remote gyro-magnetic compass conform to the landing course and |

| 1                        | 2 | 3           | 4  |
|--------------------------|---|-------------|--|
| From 4000 down to 1200 m | 5 | 8500        | the AIK automatic radio compass reads zero. Keep the readings of the IIR remote GY magnetic compass and AIK automatic radio compass unaltered. |
| From 1200 down to 200 m  | 0 | 9500-10,000 |  |

With the aircraft coming out below the cloud base, fly it by the engine speed and the pitch angle, thoroughly checking the altitude by the P-2 radio altimeter and by commands from the instruments have failed under weather conditions allowing the piloting of the aircraft in pair, and the pilot has been trained in downward cloud penetration in close pair formation (see the aircraft's seat by the flight control officer, when flying over the outer bombing station and perform an approach for landing in pair.

361. If the thickness of clouds is very large and the altitude of the cloud base is too low (below 200 m), or in case of poor visibility under the cloud base and insufficient training of the pilot in downward cloud penetration by the readings of the gyro horizon pitch angle in conjunction with the engine speed value, the pilot should take a decision to abandon the aircraft by ejection on the permission of the flight control officer.

**PROCEDURE ON ENCOUNTERING IIR REMOTE-READING GYRO-MAGNETIC COMPASS FAILURE**

382. The failure of the remote-reading gyro-magnetic compass is determined by the following indications:

- (a) the compass readings do not correspond to the actual aircraft heading;
- (b) the compass course indicator oscillates to both sides or remains stationary;
- (c) when executing a banked turn, the compass course indicator fails to read the change of aircraft heading or the change of the compass readings is jerky.

383. If the compass fails to operate, first make certain the compass circuit breaker is cut in. Report the matter to the flight control officer. Approach the bombing station by the radio compass, periodically checking the direction of flight by calling the radio direction finder.

In adverse weather conditions and at night the landing approach should be performed with the help of the radio compass in conjunction with the radio direction finder data, and by the commands received from the flight control officer.

**PROCEDURE ON ENCOUNTERING AIK-5 AUTOMATIC RADIO COMPASS FAILURE**

384. The AIK automatic radio compass failure is determined by the stationary position of compass pointer, with the direction of flight changed, and by the continuous rotation or oscillation of the radio compass pointer.

If the radio compass fails, save sure the radio compass circuit breaker is cut in and the function switch mounted on the radio compass control panel is set in the OFF (STOP) position. Report the matter to the flight control officer on the operation of the heading station and check the adjustment of the AIK-5 radio compass. Maintain the flight attitude by the gyro-magnetic compass when approaching the flight zone. Periodically check the correctness of approach to the airfield by requesting the

Peer Original

radio bearing and by interrogating the landing airfield control post. Should the radio compass fail when flying in clouds or above the cloud top, perform a landing approach with the help of the gyroscopic compass, by requesting the radio bearing as by commands of the flight control officer.

Note. If the pilot is in doubt as to the correctness of the radio compass reading, it is normal practice to listen to the call signs of the landing airfield radio compass by means of the definition of the alignment indicator pointer. Change the radio compass mode to GYRO. Check the direction of flight by the gyroscopic compass and by requesting the radio bearing.

PROCEDURE ON ENCOUNTERING LIGHTING EQUIPMENT FAILURES DURING NIGHT FLIGHT

385. If the navigation lights fail to operate, act with due care, especially when approaching the airfield, and report the position of the aircraft to the flight control officer. With the headlight in a sound condition, periodically cut in the headlight for marking the position of the aircraft.

Note. The headlight may be used at a flying speed not in excess of 400 km/hr for illuminating the ultraviolet lamp. Use the cockpit white-light lamp if the light filter has fallen out of the ultraviolet lamp, thus result in blinding the pilot, immediately cut off the lamp wipers.

FORCED LANDING PROCEDURES

386. In case of power-off forced landing the pilot will make approach for landing with retracted landing gear and flaps at a glide speed of 350 km/hr. He should extend the landing gear and flaps using the emergency procedure only if he is absolutely sure that his judgement for landing on the airfield has been done correctly. With the landing gear and flaps extended, the speed in glide should be 260 to 270 km/hr.

387. Perform forced landing outside the airfield only with the landing gear retracted, the flaps lowered by means of emergency procedure, and the suspended loads released. The gliding speed in this case should be kept at 270 to 280 km/hr.

Caution: 1. Perform forced landing with the landing gear retracted only on natural ground. Parachute landing on a concrete or metal runway leads to the breakdown of fuel tanks and pipelines. 2. Before gear-up landing, at an altitude of minimum 400 m, the pilot should open the sliding hood and cut off the aircraft battery, and before touchdown, remove the toes from the pedals and place the feet nearer to the seat pan.

388. In case of forced landing on unfriendly territory, the pilot should destroy the transmitter receiver of the aircraft transponder, for which purpose he should press the destruction button (the red lamp on the destruction control panel will come on) and take necessary measures for destroying the aircraft.

LANDING GEAR AND FLAPS EMERGENCY EXTENSION PROCEDURES

389. If the main extension system fails to extend the landing gear, the pilot will resort to the gear emergency extension procedure, for which purpose he should proceed as follows:

- (a) put the landing gear control lever in the neutral position;
(b) pull the right-hand clip for emergency disengagement of the nosewheel and starboard wheel strut latches;
(c) pull the left-hand clip for disengagement of the port wheel strut locks;
(d) check if the struts have come off the locks (the warning lamps should go out and the mechanical indicators should come out slightly);

- (e) set the landing gear control lever for extension;
(f) open the landing gear emergency air bottle valve on the cockpit right-hand panel;
(g) check the landing gear extension and struts locking by the warning lamps and the mechanical indicators;
(h) close the emergency system valve after accomplishing the flight and cutting off the engine.

Caution. Do not retract the landing gear in flight after emergency extension of landing gear.

Should the main and emergency extension systems fail to extend landing gear, land the aircraft only on an auxiliary unpaved runway.

- 390. For emergency extension of flaps, proceed as follows:
(a) shift the flap control lever all the way down (55°);
(b) open the flaps emergency air bottle valve on the right-hand panel of the cockpit;
(c) check the extension of flaps (by the warning lamp on the left-hand panel and by the mechanical indicator on the left-hand wing);
(d) close the flap extension emergency valve after accomplishing the flight and cutting off the engine.

PROCEDURE ON ENCOUNTERING FUEL PRESSURE DROP AFTER FIRST TAKE OFF

391. If the lamp of the fuel pressure warning unit has flashed up during the flight, check if the circuit breaker of the booster electric pump is cut in.

If the booster pump is cut out, switch on its circuit breaker when flying at an altitude of less than 5000 m, without changing the engine rating, and while flying at an altitude of 9000 m and above, first set the engine speed at 10,000 r.p.m. and, then, cut in the circuit breaker of the booster pump.

392. Do not fly the aircraft at altitudes above 9000 m with the fuel pressure warning unit lamp burning.

PROCEDURE ON ENCOUNTERING ENGINE FIRE

- 393. The indications of fire in the engine zone are:
(a) burning of the red warning lamp on the left-hand panel;
(b) smoke strip behind the aircraft tail, which can be easily detected during the backed turns;
(c) probable increase of exhaust gas temperature and presence of smoke inside the cockpit.

- 394. To extinguish fire, proceed as follows:
(a) close the stopcock and turn the engine control lever full back;
(b) cut off the fuel booster and transfer pumps;
(c) decrease the flying speed down to 300 - 350 km/hr, using the speed excess for climbings;
(d) press the extinguisher starting button.

395. Should smoke get into the cockpit, close air dilution on the oxygen regulator, depressurize the cockpit and cut in the ventilation.
396. After the fire has been stopped, do not start the engine in flight and land the aircraft with the engine out off.

Peer Original

PROCEDURE ON ENCOUNTERING GENERATOR FAILURE

397. The failure of generator in flight can be detected by the burning of red warning lamp and by the ammeter readings; the instrument pointer reads zero.

398. If the generator fails when flying in clouds or during a night flight, do the following:
(a) when flying at altitudes below 5000 m, switch on the radio station receiver, gyro horizon, magnetic compass, turn-and-slip indicator, the engine rating control instruments, pitot-static tube heater, ultra-violet and navigation lights (the last two only in night flight). On in the radio compass, the radio station transmitter, and aircraft transponder intermittently, in due succession, if necessary.

(b) when flying at altitudes above 3000 m, engage the booster fuel pump in addition to the consumers indicated above. The pump should be cut off after the aircraft has descended below 3000 m.

(c) with the MK-5 radio compass or the aircraft transponder cut in intermittently in a night flight, when the ultra-violet lamps go out and light up again in 1-2 minutes, and the visibility of control instruments is impaired, make use of the time lamp.

399. With the generator failing and the consumers fed from the aircraft battery in accordance with the procedure discussed in Item 398, the safe flying time of the aircraft makes up 14 to 22 minutes for day and night flights.

Note. The above safe flight limits are given for battery 32 CAU-20 having 75% net capacity, provided the battery has been used for one engine starting.

If, with the generator failing in flight, all the power supply consumers are cut in, the flight time within which the aircraft battery ensures flying safety makes up 5 to 6 minutes (on the average).

400. The indications of battery complete discharge are the failure of radio station to operate in the daytime and that of the ultra-violet lights during night flights (in this case, the MK-1 gyro horizon and the MKG-3 remote-reading gyrocompass cease to operate).

401. When the flight is performed under instrument meteorological conditions and the pilot is obliged to make instrument approach for landing using instrument landing following ways: cut in PA-2, MARKER (PA-2, MARKER) and AIL, MARKER (AIX, MARKER) circuit breakers 4-5 sec before reaching the holding station of the main or alternate airfield and home to the station by the AIX radio compass.

402. On determining the amount of the holding station reserves, cut off the PA-2, MARKER and AIL, MARKER circuit breakers and using the gyrocompass compass receiver, the aircraft into the final approach course and, then turning final end 30-60° PA-2 radio altimeter and AIX radio compass and keep them on until the aircraft is landed.

PROCEDURE ON ENCOUNTERING ENGINE SPEED DROP IN FLIGHT

403. With the engine decelerating during take-off (in the process of the take-off roll), the pilot should discontinue the take-off and take measures to rapidly stop the aircraft.

404. If the engine speed drops in flight at an altitude of up to 3000 m, cut in the isolating valve without changing the engine rating. At altitudes above 3000 m,

lift the engine control lever to the idling rating position, before cutting off the isolating valve. With the isolating valve cut in, set the required engine rating by smooth and slow movement of the engine control lever.

Note. When flying at high altitudes, with the isolating valve cut in, the engine speed ratios are likely to exceed the permissible limits; therefore, avoid the engine speed and, if necessary, decelerate the engine by retarding the engine control lever.

405. Engine speed drop, involving switching-on of the isolating valve, testifies to a serious defect in the fuel pumps. If this is the case, discontinue the flight and land the aircraft on the main or alternate airfield. Cut off the isolating valve circuit breaker only after landing.

PROCEDURE ON ENCOUNTERING ALLERON BOOSTER FAILURE

406. The alleron booster failure is recognized by great allerons forces on the control stick and by booster system pressure gauge readings (the pressure drops to zero). If the alleron booster fails to operate, cut it off with the help of the control valve.

Level flight with the alleron booster cut off is safe. However, the landing of aircraft with the alleron booster cut off requires higher attention on the part of the pilot to aircraft flying due to considerable growth of alleron forces on the control stick.

Caution. Do not practice confidence and acrobatic maneuvers if the alleron booster is unserviceable.

PROCEDURE ON PREVENTING ICE FORMATION

407. In all cases of ice formation the pilot should check whether the heater of the main pitot-static tube and emergency pitot tube TS-156 is cut in and should make proper use of the aircraft anti-icing system. In case of ice formation during upward cloud penetration, cut in the anti-icing system in level flight when passing the aircraft above the cloud top. During downward cloud penetration, do not change the flight attitude, use the anti-icing system down to an altitude of 3000 m and finally remove the ice crust from the canopy windshield in level flight after the aircraft has come below the cloud base.

If the windshield is covered with ice when penetrating clouds by a group of aircraft, remove the ice crust before the group assembly. If a group of aircraft gets into the icing zone, the group leader should take necessary measures to leave the icing zone and, with the anti-icing devices used by the pilots, he must separate the group laterally at safe intervals to ensure safety of flight.

Out in the anti-icing device intermittently by 3 to 5-second pulses at 30 to 15-second intervals, with minimum consumption of fluid before encountering the enemy and prior to landing the aircraft after accomplishing the flight mission.

For better removal of ice crust, increase, if possible, the indicated airspeed to 200 km/hr at medium altitudes, and the true airspeed up to 600 km/hr at high altitudes.

CANOPY POSITION AND EJECTION PROCEDURE

408. The ejection procedure is the most reliable method to abandon the aircraft in emergency. The ejection is safe both at high flying speeds and at various attitudes of the aircraft in space.

409. All the movements and actions of the pilot should be practised on the ground

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

to perfection. The pilot should be able to find by finger feel the ejection system firing mechanism lever (face screen).

410. To abandon the aircraft equipped with the ejection seat, whose firing mechanism is actuated only from the levers located on the seat arm rests, proceed as follows:

- (a) change the aircraft to level flight, if possible, and reduce the speed;
- (b) take the toes off the pedals and put the feet on the seat foot rests;
- (c) lean tightly against the seat back, press the head against the head plate and lock the seat harness;
- (d) jettison the canopy, for which purpose snift the canopy jettison lever all the way forward; the canopy jettison mechanism makes it possible to jettison the canopy only from the front (closed) position both with the pressurized and the unpressurized cockpit at any speed.

Note. If the canopy failed to jettison after pushing the canopy jettison lever, the pilot can drop it by pressing with the thumbs of both hands against the tail sections of the lock control levers, having first unpressurized the cockpit.

- (e) make sure the canopy is jettisoned, rest the feet against the seat foot rests, and the hands - against the seat arm rests, without bending the arms in the elbows, then, press the hands tightly to the body, without lifting the lower back from the parachute rest, strain muscles and close the eyes and mouth;
- (f) without changing the posture, press the firing lever with the fingers of the right hand.

411. If, with the above measures taken, the canopy still fails to jettison, the pilot can abandon the aircraft through the canopy. While doing so, proceed as follows:

- (a) pull the red "bulb" fastened to the canopy above the pilot's head and remove the safety pin from the socket of the firing mechanism head which is connected with the sliding hood;
- (b) assume the necessary posture in the seat, and eject the seat by pressing the levers on the seat arm rests.

While abandoning the aircraft, keep the assumed posture.

412. To leave the aircraft equipped with a face-screen ejection seat, the pilot should proceed as follows:

- (a) tightly press the back against the seat;
- (b) lock the seat harness;
- (c) put the feet on the foot rests;
- (d) rest the feet against the foot rests, straighten the back and press it against the seat back, press the head tightly against the head rest;
- (e) take the face screen with both hands, close the mouth and eyes tightly, strain the muscles of the whole body and energetically pull the screen down, shifting out the firing mechanism safety lock of the travel will jettison the sliding hood and pulling accomplished during the second half of screen travel.

Retain the assumed posture at the moment the ejection (firing) beam falls to jettison. In the latter case, without changing the assumed posture drop the cockpit canopy by the emergency method, i.e. by turning the canopy jettison handle all the way back, and eject using the arm rest levers or the face screen. Bear in mind that after canopy emergency jettisoning by turning the handle, the ejection seat face screen may be thrown by the air stream behind the head plate. Should the canopy fail to eject, pull out the safety pin from the socket of

the firing mechanism head which is connected with the sliding hood, for which purpose pull the hook (ring) located on the left side of the head rest plate and eject through the canopy using the face screen or the arm rest levers.

413. After the ejection, proceed as follows:  
(a) free yourself from the seat 1.5 seconds after the ejection by pushing the seat away with the hands and feet, having first made sure that the seat harness is unlocked by the A1-3 mechanism;

(b) if the seat harness lock has not been released by the A1-3 mechanism, open the lock manually 1.5 - 2 seconds after the ejection and clear the seat.

414. When the ejection takes place at altitudes below 500 m, immediately open the parachute after clearing the seat by pulling the parachute rip cord.

While ejecting at altitudes above 500 m (up to the service ceiling of the aircraft) keep falling until the parachute is released by the MAI-3 parachute release control unit, which takes place as soon as the altitude set on the instrument is reached, or 2 seconds after clearing the seat when ejecting at a flight altitude below that set on the instrument.

If the parachute does not open from the MAI-3 parachute release control unit, open the parachute by pulling out the ring at an altitude of minimum 500 m above the ground surface.

415. Whenever necessary to open the parachute at an altitude exceeding the altitude set on the MAI-3 parachute release control unit (intensive rotation while falling, sharp ear pain, abandoning the aircraft over high ground), open the parachute 5 seconds after clearing the seat but at an altitude of not more than 900 m.

416. When ejecting at altitudes above 9000 m, open the parachute only after a 10-second delay per each thousand metres of elevation above 9000 m (Table 41).

Table 41

| Ejection altitude, m         | 90,000 | 11,000 | 12,000 | 13,000 | 14,000 |
|------------------------------|--------|--------|--------|--------|--------|
| Parachute opening delay, sec | 10     | 20     | 30     | 40     | 50     |

417. When ejecting in condition of poor ground visibility (night flight in clouds), open the parachute manually in accordance with the instructions laid down in items 414, 415.

PROCEDURE ON ENCOUNTERING COCKPIT DEPRESSURIZATION AT HIGH ALTITUDES

418. Unpressurizing the cockpit will result in a typical "leak" and pressure in the ears; the MAI cockpit altitude and pressure differential gauge shows a sharp increase of cockpit "altitude" and the pressure differential drops.

If the cockpit has been unpressurized by reasons other than the breakdown of cockpit glass pane (after the resumption of sliding hood, open the emergency oxygen supply valve, decrease the flight altitude, if necessary, report the failure to the flight control officer and discontinue the flight mission).

419. Should the canopy glass be broken or the canopy sliding hood torn off, immediately lower the goggles onto the eyes, lean forward towards the instrument panel, cut the emergency oxygen supply, decrease the altitude and reduce flying speed to 350 km/hr, report the airstap to the flight control officer and discontinue the flight mission.

SECRET/NO FOREIGN DISSEM

Peer Original

TRAINING EFFECT ELECTRIC MECHANISM AND SPRING FEEL MECHANISM OF M4P-17 AIRCRAFT EQUIPPED WITH IRREVERSIBLE HYDRAULIC BOOSTERS IN ELEVATOR AND AILERON CONTROL SYSTEM

GENERAL

420. To reduce the forces on the control stick, the latest-make fighter M4P-17 is equipped with irreversible hydraulic boosters B3-1M (operating on the irreversible cycle) in the elevator and aileron control systems.

The installation of an irreversible hydraulic booster in the elevator control system has sensitively improved the longitudinal controllability of the aircraft at high flying speeds (especially at high altitudes), but has simultaneously increased the elevator stick forces at low flying speeds, as compared to those on the M4P-17 aircraft not equipped with irreversible hydraulic boosters.

The replacement of irreversible hydraulic booster B3-1M in the aileron control system has improved the lateral controllability of the aircraft (at high speeds) but slightly.

421. On aircraft equipped with irreversible hydraulic boosters in the elevator and aileron control systems, all the aerodynamic loads caused by the elevator and ailerons are carried by the hydraulic boosters. The limitation on forces on the control stick is accomplished by means of special spring-feel mechanisms in which the springs are compressed in the ratio to the deflection of the control stick and consequently of the control surfaces, and forces are also set up by the balance tab in case of G-loads.

422. In order to reduce the deflection of the control stick, the larger the force to be applied to the stick, with maximum deflection (forward or backward) of the control stick, the force vector (as checked on the ground) amount to 9 - 10 kg. When G-loads are built up in flight due to the presence of a balance tab in the elevator control system, it is necessary to apply additional forces to the control stick proportional to the change of load (0.5 kg per G-load unit change). With the control stick moved all the way to the right or to the left, the forces caused by the aileron spring-feel mechanism may be up to 5 kg.

423. One should bear in mind that the power of the elevator booster is sufficient for taking off aerodynamic loads from the elevator in almost any flight attitude, whereas the power of the aileron booster in conditions of supersonic flying speeds (at an altitude of 5000 m and below) proves insufficient, which results in an intensive increase of forces required for deflecting the ailerons in the above flight attitudes.

424. Due to the presence of a spring-feel mechanism in the elevator control system, the control stick is fixed longitudinally in a preset position, with the hydraulic system operating and the hydraulic booster cut in, and can be deflected from this position only by applying some effort to it. This position of the control stick can be changed by switching on the training effect electric mechanism which forces the specific feel of the M4P-17 aircraft equipped with irreversible hydraulic boosters.

425. The forces applied to the control stick by the spring of the elevator spring-feel mechanism can be trimmed in flight by the training effect electric mechanism which is controlled by a pressure change-over switch (see the elevator trim tab on the M4P-17 aircraft not equipped with irreversible hydraulic boosters). In this case, the aileron and elevator trim tab circuit breaker on the right-hand cockpit electric panel should be switched on.

The forces applied to the control stick can be completely removed by the training effect electric mechanism in a flight attitude corresponding to elevator deflection of maximum 5°.

426. With the training effect electric mechanism set at zero, the control stick is fixed by the spring-feel mechanism in the neutral position, and the elevator trim tab warning lamp lights up.

427. The piloting of the aircraft with irreversible hydraulic boosters in the elevator control system at low altitudes and high indicated airspeeds, beginning with 600 km/hr and above, requires of the pilot such movement of the elevator control and trim tabs in piloting technique, since owing to the high efficiency of the control surfaces at high indicated airspeeds, short but energetic pulling of the control stick leads to sharp increases of the angle of attack and subsequent slight but brief pitching of the control stick results in considerable negative G-loads.

428. Flying the aircraft at high indicated airspeeds by feeling the forces on the control stick may result in excessively high positive or negative G-load and wing-lowering rolling.

429. With the aircraft pitching, the pilot should fix the control stick in the position at which the pitching has started, decrease the speed and assume the required flight attitude.

430. Cut off the elevator booster by the change-over switch located on the left-hand control panel of the cockpit.

431. If the booster hydraulic system fails to operate, or if the elevator booster is cut off by the change-over switch located on the left-hand control panel, the spring-feel mechanism gets automatically switched off and the elevator aerodynamic trim tab is switched on instead, the latter being controlled by the pressure change-over switch of the elevator trim tab. In this case, the circuit breaker of the aileron and elevator trim tabs on the right-hand control panel of the cockpit should also be cut in.

PRE-FLIGHT CHECK OF HYDRAULIC BOOSTERS

432. After starting the engine, check pressure in the booster hydraulic system, which should be from 60 - 65 to 80 - 85 kg/cm<sup>2</sup>.

433. Check the aileron control (with the hydraulic booster switched on or off) in the same order as on the M4P-17 aircraft not equipped with irreversible boosters.

434. Cut in the aileron and elevator trim tab circuit breaker on the right-hand electric panel of the cockpit; set the aileron trim tab in the NEUTRAL (СЕРТИФИКАЦИОННОЕ) position as on the M4P-17 aircraft not equipped with irreversible hydraulic boosters.

435. Cut off the elevator booster by the change-over switch located on the cockpit left-hand panel and use the pressure change-over switch to set the elevator aerodynamic trim tab in the NEUTRAL position after which the signal lamp should light up.

436. Check the elevator control with the hydraulic booster cut off (the change-over switch on the cockpit left-hand panel is cut off). At the moment the control stick is moved forward or backward, the pilot should feel only the forces caused by friction in the joints of the control system and by the load set up in the system, since in this case, the spring-feel mechanism is automatically cut off from the control system.

437. Considerable forces on the control stick during the check testify to the spring-feel mechanism engaging and decomposing cylinder being defective or to the FA-74 booster cut-off hydraulic valve being out of order.

438. Cut in the elevator booster by the change-over switch mounted on the cockpit left-hand panel and check ease and smoothness of the elevator control. With the control stick deflected forward or backward, the pilot should feel inconsiderable forces. When released, the control stick should return to the neutral position.

439. Check the operation of the training effect electric mechanism, with the

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

elevator booster cut in (the circuit breaker of the aileron and elevator trim tabs is switched on), in the following sequence:

(a) set the elevator trim tab pressure change-over switch in the **PISTON (HAY-PUSHKIN)** position until the trimming effect electric mechanism is out in completely as a result, the control stick should move backward (the elevator should deflect 5° up);

(b) set the pressure change-over switch in the **PISTON (HAY-PUSHKIN)** position until the trimming effect electric mechanism is out in completely. As a result, the control stick should move forward (the elevator should deflect 5° down);

(c) use the elevator trim tab pressure change-over switch to set the control stick (and consequently the elevator) in the neutral position, after which the elevator trim tab lamp should light up.

**TAKE-OFF**

432. Take-off in the MiG-17 aircraft equipped with irreversible hydraulic boosters does not differ from that performed in the MiG-17 aircraft without irreversible hydraulic boosters, except for the fact that the pilot feels more considerable pulling forces on the control stick. To raise the nose wheel, the pilot should pull the control stick with an effort of about 6 to 8 kg (since the deflection of elevator during the take-off makes up about 3/4 of its full upward deflection). These forces remain practically unaltered until the aircraft clears the ground.

**CLIMB**

433. The climbing attitude of the aircraft equipped with hydraulic boosters is the same as on the aircraft without hydraulic boosters. After unsticking, when accelerating the aircraft with the trimming effect electric mechanism in the neutral position (the signal lamp burns), the pulling forces decrease with the increase of speed, and equal zero at a speed of 600 ± 50 km/hr.

Climb at optimum speed rating results in pulling forces on the control stick owing to the increase of the elevator deflections required with the altitude increase. The trimming forces can be relaxed with the help of the trimming effect electric mechanism by pulling the elevator trim tab change-over switch. However, to re-use change-over switch more frequently (approximately every 1000 - 1500 m) than to the trim tab change-over switch in the MiG-17 aircraft not equipped with irreversible hydraulic boosters.

Climbing can also be accomplished without changing the position of the trimming effect electric mechanism, but in the latter case the pulling forces on the control stick will gradually increase and amount to about 6 - 8 kg at an altitude of 14,000 - 15,000 m.

**STRAIGHT FLIGHT**

434. In a straight flight (level or descending), the forces on the control stick, with the trimming effect electric mechanism in the neutral position, increase with the increase of the flying speed in excess of 650 km/hr.

However, at sonic and supersonic flying speeds the control stick forces in the aircraft equipped with irreversible hydraulic boosters grow weaker than in the aircraft without hydraulic boosters. At maximum flying speeds gained during straight flight the value of the pressing forces does not exceed 10 kg.

When flying level, the forces on the control stick may be relaxed by the trimming effect electric mechanism practically throughout the speed and altitude range.

**FLIGHT MANEUVERS**

435. In aircraft equipped with irreversible hydraulic boosters flight maneuvers are performed with the trimming effect electric mechanism in the neutral position (the elevator trim tab signal lamp burns).

The peculiarity of flying technique in the MiG-17 aircraft equipped with irreversible hydraulic boosters is the increase of pulling forces on the control stick with the decrease of the flying speed in the process of executing flight maneuvers. Irregular change of forces on the control stick, dependent on the characteristics of the spring of the spring-feel mechanism, slightly complicates piloting as compared to the MiG-17 aircraft not equipped with irreversible hydraulic boosters.

**MANEUVER TURN AND SPIRAL**

436. The flying technique of the banked turn and spiral in the aircraft equipped with irreversible hydraulic boosters has practically remained unaltered, except for the fact that larger forces are required for banking up G-load.

The presence of an irreversible elevator booster makes it possible to obtain the maximum permissible G-load (before the vibration starts) at altitudes above 6000 m, by deflecting the control stick with 6 - 10 kg pulling forces, and the maximum operating G-load (G) at altitudes below 6000 m with 10 - 14 kg pulling forces.

When flying at altitudes above 6000 m at supersonic speeds (over Mach speed, as read by the indicator thin pointer, exceeds 1000 km/hr), the elevator efficiency reduces, which results in an increase of the control stick deflection required for performing the flight maneuver. The increase of the control stick deflection may be accompanied by an increase of forces on the control stick up to 20 - 30 kg, owing to insufficient power of the elevator booster at the above ratings.

**CHANDLLE**

437. With the aircraft energetically brought into the chandelle at any possible flying speed, the pulling forces on the control stick are less than in the aircraft not equipped with irreversible hydraulic boosters (the forces do not exceed 10 - 14 kg). As the flying speed is being reduced, the control stick pulling forces slightly decrease. However, at the end of the chandelle they slightly increase again to 6 - 8 kg due to the fact that the deflection of the elevator increases, when reaching the top of the flight maneuver, thus causing a respective increase of forces as a result of the compression of the spring in the spring-feel mechanism.

**NORMAL LOOP AND HALF-LOOP**

438. When performing a normal loop and half-loop in the MiG-17 aircraft equipped with irreversible hydraulic boosters, the pulling forces to be applied to the control stick, when approaching the top of the maneuver, gradually increase up to 7 - 10 kg, with the speed decreased, the elevator deflection angle should be acceptably increased.

If the pulling forces on the control stick are insufficient, it may result in a loss of speed when reaching the top of the flight maneuver.

SECRET/NO FOREIGN DISSEM

Peer Original



- 82 - SECRET/NO FOREIGN DISSEM

50X1-HUM

HALF-ROLL

439. The flying technique of half-rolls in the MiG-17 aircraft equipped with irreversible hydraulic boosters is the same as in the MiG-17 aircraft not provided with the above boosters. The forces on the control stick, when recovering from the half-roll, do not exceed 8 - 12 kg.

440. The half-roll, with the aircraft brought into the maneuver at maximum level flight speed, is allowed at all altitudes specified for the MiG-17 aircraft not equipped with irreversible hydraulic boosters. The aircraft gains practically the same flying speeds as the MiG-17 aircraft not equipped with irreversible hydraulic boosters.

The pulling forces on the control stick, while executing half-rolls, do not exceed 12 kg.

VERTICAL DIVE

441. The vertical dive in the MiG-17 aircraft mounting irreversible hydraulic boosters, with the aircraft brought into the dive from maximum level flight speed, is allowed from the same altitudes as in the MiG-17 aircraft not equipped with irreversible hydraulic boosters.

Bringing the aircraft into the vertical dive from maximum level flight speed by executing the half-roll. While rolling the aircraft to the wheel-up position, pull the engine control lever all the way back.

After the aircraft has reached a diving angle of 90°, move the control stick full forward.

When an altitude of 10,000 - 9000 m is gained, with the control stick moved full forward, the aircraft has a tendency to change the dive angle towards negative diving, and with further decrease of altitude it tends to pull out, while the pressing forces on the control stick increase at the vertical dive section and may amount to 10 kg.

Start recovering the aircraft at an altitude of minimum 8000 m (as read by the altimeter) in such a way as to pull it out level at an altitude of about 4500 to 5000 m. While recovering the aircraft from the vertical dive, the pulling forces on the control stick do not exceed 10 - 12 kg.

In case of late recovery from the vertical dive with the speed brakes retracted, when the aircraft banking is likely to arise at high indicated airspeeds at altitudes below 5000 m, immediately apply the speed brake to decrease the airspeed.

The maximum speed (as read by the thin pointer) of 1340 - 1350 km/hr is gained on the vertical section of the dive at an altitude of 9000 to 8000 m, when the aircraft is brought into the dive at the maximum level flight speed from an altitude of 14,000 m with the speed brakes retracted. In such a case, the actual flying speed does not exceed 1250 - 1250 km/hr with further diving the speed starts decreasing.

POWER-ON DIVE WITH ENGINE RUNNING AT COMBAT RATING

442. The power-on dive of the aircraft with the engine running at combat rating and the speed brakes retracted, when the aircraft is brought into the dive from a straight flight, may be performed at any speed up to the maximum level flight speed. When entering the dive at the maximum level flight speed, the control stick may be moved all the way forward (up to the stop).

With the stick moved all the way forward, when entering the dive at the maximum

level flight speed from an altitude of 12,000 to 14,000 m, the aircraft reaches a certain dive angle not in excess of 50° relative to the horizon. While diving from lower altitudes, the dive angle value decreases and makes up 25 to 30° when the dive is entered at an altitude of 5000 m.

When bringing the aircraft into the dive, smoothly move the control stick forward. Energetic push of the control stick may result in negative G-load, and if the pilot is inadequately tied to the seat, he may strike his head against the cockpit canopy.

443. In the process of the dive execution, the pressing forces on the control stick, with the latter pushed all the way forward, do not exceed 10 kg. However, when diving from an altitude of 12,000 to 14,000 m, the forces on the control stick increase up to 20 - 25 kg at an altitude of 5000 to 6000 m due to insufficient power of the elevator booster.

In this case, the deflection of elevator is decreased and the aircraft itself gradually decreases the dive angle.

444. When diving with the engine running at combat rating, the aircraft gains the maximum speed when the dive is entered from a straight flight at a maximum level flight speed from an altitude of 14,000 m.

In the latter case, the flying speed (as read by the thin pointer) reaches 1300 - 1330 km/hr at an altitude of 5000 to 6000 m due to delay in transmitting static pressure to the speed indicator.

The actual speed of the aircraft, in this case, does not exceed the maximum permissible one.

Since the flying speed in diving at 50° and lesser dive angles, with the aircraft brought into the dive from a straight flight at maximum level flight speed, does not exceed the permissible speeds specified for the aircraft, the pilot flying at altitudes above 3000 m may not watch the speed indicator but will only check the altimeter readings.

445. While diving at altitudes below 3000 m, the pilot should watch the speed indicator as in case of the MiG-17 aircraft not equipped with irreversible hydraulic boosters, and should not exceed the maximum permissible indicated airspeed of 1000 km/hr (as read by the indicator thin pointer), specified for these altitudes.

FLYING WITH HYDRAULIC BOOSTERS CUT-OFF

446. Flying (take-off, landing and piloting) with a cut-off elevator booster differs from that in the MiG-17 aircraft not provided with irreversible hydraulic boosters by slightly increased forces on the control stick in all flight attitudes, which are due to friction in the booster piston and in the elevator control system joints. Besides, in flights involving G-loads, it is necessary to apply additional forces to the control stick, proportionate to the change of G-load (0.8 kg per G-unit), owing to the presence of a balance tab in the elevator control system.

With the aileron irreversible booster cut off, the controllability of the aircraft does not differ from that of the MiG-17 aircraft with cut off reversible hydraulic booster.

FLYING WITH HYDRAULIC BOOSTER SYSTEM FAILED

447. If the hydraulic booster system fails, cut off the boosters (using the change-over switch on the left-hand panel for cutting off the elevator, and the valve for cutting off the ailerons).

The aircraft should be piloted by the elevator and aileron aerodynamic trim tabs as in case of the MiG-17 aircraft not equipped with irreversible hydraulic booster.

SECRET/NO FOREIGN DISSEM

Peer Original

LANDING

SECRET/NO FOREIGN DISSEM

50X1-HUM

448. The specific feature of the aircraft in landing is the increased pulling forces on the control stick, which amount to 6 - 7 kg, since the upward movement of the elevator increases with the speed decrease, along with the proportionate increase of the forces imposed by the compression of the spring in the spring-feel mechanism.

REGULARITIES OF OPERATION AND FLIGHT TECHNIQUE OF AIRCRAFT MAI-17B

449. The MAI-17B aircraft is a modification of the production aircraft MAI-17 and differs from it mainly in that the MAI-17B aircraft mounts a radar sight which ensures the performance of tactical missions in the daytime in adverse weather conditions and at night in standard and adverse weather conditions.

450. Check the aircraft and engine before flight in the sequence laid down for the MAI-17 aircraft. Besides, examine the attachment units and check the fairings of the radar set manner and sighting serials for cracks.

PRE-FLIGHT CHECK OF RADAR SIGHT

451. The pilot checks the operation of the radar sight on the ground in the following cases:

(a) after elimination of faults detected in the sight during the previous flight; (b) when the flight has preceded by 100-hour scheduled maintenance involving the removal of the sight main units from the aircraft.

In all other cases, the pilot checks the sight units by visual inspection.

452. Before checking the radar sight on the ground, do the following:

(a) take care the DIM - NIGHT (NENB - B01B) change-over switch located on the cable box of the fuselage nose upper bay is set to the respective position;

(b) take care the external power unit is connected to the aircraft main;

(c) take certain the STARTUP-OFF (STARTUP - BUREL) change-over switch located on the control desk is placed in the OFF (BUREL) position, and the BRIGHTNESS (BIE) the extreme left-hand position (brightness is out).

453. To check the radar sight for proper functioning, the pilot should proceed as follows:

(a) switch on the sight; two - three minutes after switching, a raster, background

reticle and lines of the electronic gyro horizon appear on the indicator scope;

(b) adjust the BRIGHTNESS (BIE) and FOCUS (CEN.) handles to obtain a weak but

clear background on the scope with a ray in noise brightness within a zone from 2 to

5 - 6 km. The background noise should start at a range of 0.2 km and its upper boundary

should be restricted on a distance of 12 km and above. The azimuth background noise

the sight restricted on a zone of 60° on both sides of the azimuth zero line. With

late within 0 - 200 and 3 - 4 minutes after switching it on should settle in position

scale divisions 60 - 200, the pointer oscillation being not in excess of 10

instrument pointer should settle without oscillation between scale divisions 90 - 300

which purpose set the 1st CRYSTAL CURRENT and PRESSURE in the waveguide system, for

change-over switch in the 1st ORIGINAL CURRENT POSITION (1st 1st POINT - BANNING)

being normal, the instrument pointer should be located between scale divisions 60 -

200. Then, shift the 1st CRYSTAL CURRENT - PRESSURE change-over switch to the 2nd -

200 position. In this case, the instrument pointer should be located between scale

divisions 60 - 200.

(d) check the operation of the radar sight sighting unit by pressing the CHECK (KONTROL) push-button, with the sighting unit functioning properly, the following picture be observed:

- a target pip having the shape of a horizontal index-line, with a locked trace under it in the shape of a right line, appear on the indicator scope at a range of 600 m; the target pip moves gradually to the right and stops at the right boundary of the sighting zone square;

- a light artificial target image, whose brightness increases with its movement right upwards from the initial position, appears on the data transmission unit reflector. The dimensions of the artificial target image increase to a size corresponding to a range of 600 m;

- after releasing the CHECK push-button, the artificial target image retains its dimensions and brightness within one second and, then, returns to the initial position, decreasing its size and brightness.

Having made sure that the radar sight functions properly, set it in the OFF position.

OPERATING OF RADAR SIGHT IN FLIGHT

454. The radar sight is activated on and checked in flight in the same sequence as on the ground.

Three - four minutes after switching on the radar sight ground interference blips in the shape of index-lines and pipe should appear on the indicator scope at a range corresponding to the flight altitude. Ground interference decrease with the increase of the flight altitude and disappear completely at an altitude of 1500 m.

When flying at altitudes below 3000 m, it is difficult to observe the target pipe against the inhomogeneous background; therefore, the closest approach of the radar sight is limited by a minimum altitude equal to 2000 m.

Five - six minutes after switching on the sight in a level flight, check the reference point line of the electronic gyro horizon relative to the line of banks and, if necessary, adjust their relative layout. While doing so, check the level flight attitude by the flight instruments. Make sure by slight maneuvering that the electronic gyro horizon functions properly.

455. Permanent check of radar sight operation in flight is accomplished by the presence of noises on the scanning indicator and by the readings of the first crystal current. The radar sight is out of before landing.

456. After the radar sight is switched off, push the sliding section of the indicator tube all the way forward.

REGULARITIES OF FLIGHT TECHNIQUE

457. All the flight elements are performed in the MAI-17B aircraft according to the requirements of the present instructions, with allowance made for the specific features, which are characterized by:

(a) increased flying weight of the MAI-17B aircraft (by 220 kg) as compared to that of the MAI-17 aircraft;

(b) poor flight characteristics through the front hemisphere owing to the installation of the sight units on it;

(c) necessity to pay attention not only to instrument flying but also to operating the radar sight;

(d) need for watching the scope frame of the sight scanning reflector through the obscuring tube when flying in the daytime;

(e) change in layout of flight instruments on the instrument panel and of some

units in the cockpit;

(f) installation of landing gear wheels with more efficient wheel brakes.

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

458. The peculiarity of take-off in the MiG-17 aircraft is the poor field of vision through the front windshield of the cockpit canopy frame. Besides, due to the increase of aircraft flying weight, the nose wheel should be raised during the take-off run at a speed of 400 - 210 km/hr with a slight increase of the aircraft speed and, consequently, of the take-off run and distance. The flying technique of the MiG-17 aircraft is no different from that of the MiG-17 aircraft.

If the take-off is performed with the flaps lowered to the take-off position, they will be retracted at an altitude of minimum 70 to 100 m.

459. The climbing in the MiG-17 aircraft is accomplished at the same speeds and engine ratings as in the MiG-17 aircraft. The time required for climbing the MiG-17 aircraft is slightly increased as compared to that of production aircraft MiG-17 (comparative data are laid down in the Appendix). The service ceiling of the aircraft is 14,500 m.

460. The piloting technique in level flight has no peculiar features. The maximum permissible speed limitations at all altitudes are the same as for the MiG-17 aircraft, while the maximum level flight speeds are somewhat less (the speed values are presented in the Appendix).

461. The time required to speed up the aircraft, with the engine running at 14,560 r.p.m., is characterized by the data given in Table 12.

Table 12 Time (in seconds) Required to Accelerate Aircraft with Engine Power at 14,560 r.p.m.

Table with 4 columns: True airspeed range, km/hr; Altitude, m (1000, 5000, 10,000); and rows for speed ranges from 600 to 700, 700 to 800, 800 to 900, and 900 to 1000.

462. Aircraft deceleration, by only decreasing the engine speed to idle rating or by decreasing the engine speed down to the idling rating with simultaneous extension of the speed brakes, is characterized by the data indicated in Table 13.

Table 13 Time (in seconds) Required to Decelerate Aircraft by Decreasing Engine Speed Down to Idle Rating with Speed Brakes Extended or Retracted

Table with 6 columns: True airspeed range, km/hr; Altitude, m (1000, 5000, 10,000); and rows for deceleration from 1000 to 900 km/hr.

SECRET/NO FOREIGN DISSEM

463. As to the performance of flight maneuvers, the MiG-17 aircraft differs from production aircraft MiG-17.

464. The peculiarity of performing flight maneuvers in the MiG-17 aircraft is the increased orientation in space due to the late sphere field of vision through the front hemisphere caused by the installation of additional flight instruments and presence of shielded heater seal wires in some models of aircraft.

465. While executing ascending flight maneuvers the respective speed ratings which the aircraft is brought into the maneuver, specified for the MiG-17 aircraft, should be increased by 20 - 30 km/hr. The indicated airspeed in the upper part of the ascending flight maneuvers should be minimum 350 km/hr. The recommended maneuver entry speed should also be minimum 350 km/hr.

466. With the elevator trim tab in the neutral position, pulling forces arise on the control stick in all flight maneuvers; the value of these forces is substantially higher than in the MiG-17 aircraft. While flying at high altitudes, the maneuverability of the aircraft is more noticeable as compared to the MiG-17 aircraft.

467. The minimum flying speeds of the MiG-17 aircraft exceed the minimum flying speeds of the MiG-17 aircraft by 5 - 10 km/hr IAS.

468. The behavior of the MiG-17 aircraft at various flying speeds, its stall characteristics, and the conditions in which the aircraft enters both the normal and the inverted spin, as well as the nature of the spin proper and the recovery procedure, are the same as in the MiG-17 aircraft.

469. When approaching the airfield for landing, cut off the radar sight. The glide on the base leg and the turn to final leg will be performed at a speed of 350 km/hr. Perform gliding after turning to final leg, prior to leveling-off, at a speed of 320 km/hr.

470. While descending through clouds and making a straight-in approach for landing, or when approaching for landing using 180-degree turn or the wide rectangular pattern approach procedure, before reaching the outer marker, maintain an indicated airspeed of minimum 450 km/hr.

471. Due to poor vision through the front hemispheres, the pilot should give special attention to finalizing the disposition of landing, determining the time of leveling-off and distributing attention during landing.

472. In the process of executing cut at the moment of touchdown, look at the ground through the side glass panel of the cockpit canopy frame (10 - 15 degrees to the left and 30 - 40 degrees ahead).

473. The normal touchdown speed of the aircraft (with the fuel residue equal to 300 - 400 lbs) is 210 km/hr. After landing, the MiG-17 aircraft drops its nose more energetically as compared to the MiG-17 aircraft.

474. Apply the wheel brakes during the landing roll early and slowly, gradually increasing pressure in the process from 15 - 20 kg/cm2 at the beginning of the roll (after landing the tires should be 5 - 6 kg/cm2 or ahead of the landing roll).

475. In case of forced landing on natural ground, in addition to the procedure normally used in the MiG-17 aircraft, the pilot should extend the nose wheel, for which purpose:

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

- (a) disengage the landing gear as a check for the cockpit floor, to the right of the aircraft's main cabin door.
- (b) check by the mechanical indicator and visually if the nose wheel has come off from the lock.

**PECULIARITIES OF PILOTING IN THE AIR**

477. The peculiarities of piloting the MiG-17 during searching, approaching, attacking the target, or while operating in the air, as well as the safety measures to be observed in certain flights, are listed in the manual of the MiG-17 fighter-interceptor.

**II. PARTIALS OF THE AIRCRAFT'S SYSTEMS**

**INSPECTION OF AIRCRAFT**

478. Examine the aircraft in the sequence laid down for the MiG-17 aircraft. Besides that, the pilot should:

- (a) make sure that no foreign matter, debris or accumulation of fuel is observed in the nozzle and afterburner;

Note. When turning the engine rotor from the electric starter, with the booster pump, the engine rotor, or checking the operation of the afterburner, as well as afterburner jets is to be checked.

(b) examine the retractable cone and flaps of the engine adjustable nozzle for dents and deformation.

While examining the aircraft, the retractable cone of the engine jet nozzle may be in the rear or in the front position.

(c) check the operation of the afterburner ignition system owing to insufficient pressure in the hydraulic accumulator, retractable nozzle cone should be in the front position.

479. On entering the cockpit, check to see that:

- (a) the ENGINE AFTERBURNER (APR) (ENGINE EXHAUST) circuit breaker is out (at least one of the adjustable nozzle control flaps set in the front position);
- (b) the AFTERBURNER EMERGENCY CUT-OFF (AFTERBURNER EMERGENCY STOP) circuit breaker is out (at least one of the adjustable nozzle control flaps set in the front position);
- (c) the power supply cut off, check the ease of movement of the engine control lever to the cockpit and subsequent setting steps (when the control lever is moved forward beyond the cockpit rating speed limiter, an audible click of the microswitch should be heard).

**ENGINE STARTING AND STOPPING**

480. The starting and testing procedure of engine, model M-17, is similar to that of engine, model M-1.

481. Before starting the engine, check the operation of the afterburner ignition switch in the ENGINE AFTERBURNER circuit breaker, for which purpose: pressing the lower button to the forward position, shift the engine control lever to the afterburner position (rear position) beyond the full augmented rating speed, thereby starting the afterburner ignition for 2-3 seconds (without feeding

...the nozzle in the ...  
...if the nose wheel has

...searching, approach-  
...as well as the safety  
...aid for fly-

fuel to the burners). Sparking between the electrodes of the afterburner igniter plug, visible through the adjustable nozzle, testifies to the proper condition of the afterburner ignition system.

Simultaneously a clicking sound of the adjustable nozzle door control electromagnetic valve should be heard, indicating that the valve is in a proper condition.

Note. The afterburner system may be checked for proper functioning also at a pressure of more than 75 kg/cm<sup>2</sup> in the hydraulic system. A pressure of less than 75 kg/cm<sup>2</sup> may result in deformation of the adjustable nozzle cone due to elastic setting. Therefore, if the value of pressure in the hydraulic system is less than 75 kg/cm<sup>2</sup>, engine pressure down to 50 kg/cm<sup>2</sup> must be observed to check the operation of afterburner ignition system units.

482. Check the afterburner emergency cut-off circuit breaker for proper functioning, for which purpose switch on the AFTERBURNER EMERGENCY CUT-OFF circuit breaker and check by ear whether a clicking sound is heard when operating the afterburner emergency cut-off solenoid located on the lower fuel pump (M-17A) of the afterburner system. Checking over, set the AFTERBURNER EMERGENCY CUT-OFF circuit breaker in the OFF position.

483. Before starting the engine, cut in the engine afterburner circuit breaker on the left-hand electric panel and keep it switched on during the whole flight, irrespective of whether the afterburner is turned on or off.

484. The AFTERBURNER EMERGENCY CUT-OFF circuit breaker should be switched on.

Caution: 1. Do not shift the engine control lever before the engine gains the idle rating.

2. If, with the engine started, a heavy flame comes off the afterburner nozzle all over the cross-section of the nozzle, it indicates that the M-17A afterburner fuel distributor slide-valve is open for the main or other.

If this is the case, immediately switch on the afterburner emergency cut-off solenoid, by pulling the AFTERBURNER EMERGENCY CUT-OFF and M-17A AFTERBURNER circuit breaker to the rear position and, without stopping the engine, continue to start it. After starting the engine, pull the 6000 RPM lever, thus decelerate the engine and stop it by setting the stopcock, matching the setting positions on the M-17A mechanism of the afterburner valve or closing the shut-off fuel valve when the setting handles are mismatched.

After stopping the engine, start it only after locating the cause of the non-starting of the afterburner valve and eliminating the fault. Do not save the engine with fuel burning down in the afterburner when starting the engine with the M-17A valve open, since scavenging will only intensify the flame.

485. After starting the engine, with a pressure in the aircraft hydraulic system being minimum 75 kg/cm<sup>2</sup> and the engine running at 7000 to 6000 r.p.m., check the operation of the adjustable nozzle by cutting in or out the NOZZLE OPEN (NOZZLE OPEN) charge-over solenoid.

After cutting off the NOZZLE OPEN charge-over switch, make sure the adjustable nozzle is in the CLOSED (ZAKRYTO) position.

**OPERATING OF ENGINE ON GROUND**

486. On the ground the afterburner may be turned on only when it is necessary to check the operation of the afterburner after repairing the afterburner or one of its units. In this case, the time of engine operation at augmented rating need not exceed 10 seconds and the pressure of afterburner fuel should be not in excess of 100 kg/cm<sup>2</sup>. Before testing the afterburner, check whether the checks are properly placed under the aircraft wheels, along with the afterburner turned on, the engine thrust on the ground increases by 25%.

487. With the temperature of an exhaust air being below +10°C, and the engine run-

SECRET/NO FOREIGN DISSEM

Peer Original

ing at maximum speed, the gas temperature behind the turbine may increase beyond the permissible value (700°C).

In the latter case, the engine rating is limited by the gas temperature and, to obtain the permissible gas temperature, it is necessary to decelerate the engine.

488. To avoid overheating of the fuselage structure elements, the duration of engine continuous run on the ground, with the adjustable missile flaps closed, should not exceed 3 minutes.

If more continuous engine operation on the ground is required, open the adjustable missile flaps, for which purpose set the NOBLE OPER observe-over switch in the OPEN position. The temperature of gases in this case will drop by 30 - 40°C and the engine thrust will be below the rated value.

489. It is undesirable to run the engine on the ground at maximum speed for more than 1 minute.

490. Continuous engine run at idle rating should not exceed 10 minutes and the temperature of exhaust gases in this case should be not over 540°C.

491. The maximum permissible rate of engine control lever movement from the idle to the combat rating stop (without turning on the afterburner) should not exceed 1 - 2 seconds, while doing so, short-time overstep by 250 r.p.m. and gas overtemperature behind the turbine by not more than 50°C are allowed.

The time required to accelerate the engine to maximum speed should not exceed 15 seconds.

The reverse movement of the engine control lever from the combat to the idle rating position may be effected within not less than 1.5 - 2 seconds.

492. At an air temperature above +15°C, the engine acceleration ground test may be accomplished from a speed of not less than 5.00 r.p.m.

REGULITIES OF OPERATING ENGINE, MODEL BK-10, IN AIR WITHOUT AFTERBURNER TURNING-ON

493. When shifting the engine control lever in the ground or at low altitudes, the change-over from manual control of the RB-200A pump to automatic control takes place according to the engine control lever idle run is missing).

Increasing the flight altitude, when passing over from manual control of the RB-200A pump to automatic control, will result in an idle run section of the engine change-over section remains unshifted. At an altitude of about 10,000 m, the idle run between the idle rating position and 1/5 of the total travel and is located according to a ground speed of 1000 - 1200 r.p.m.

494. While descending from any altitude, with the position of the engine control lever over the manual control position, the RB-200A pump being constant (from the idle rating to 900 ± 200 r.p.m.), the engine speed will decrease.

REGULITIES OF AFTERBURNER TURNING-ON AND OFF IN FLIGHT

495. The afterburner will be turned on in flight at the engine maximum speed by shifting the engine control lever forward beyond the combat rating stop, thereby causing it automatically all the time, during the starting and operation of the afterburner.

The afterburner is turned off by shifting the engine control lever in the reverse direction.

506. Turning the afterburner on or off may result in short-time changes of the engine speed and gas temperature behind the turbine.

496. The afterburner can be turned on up to an altitude of 15,000 m.

497. With the afterburner turned on, the engine thrust increases, causing an increase of vertical climb speed, maximum level flight speed and service ceiling, and improving the maneuverability of the aircraft.

498. To turn on the afterburner, proceed as follows:

(a) set the indicated airspeed of at least 300 km/hr;

(b) accelerate the engine to the maximum speed (11,500 r.p.m.);

(c) press the button on the engine control lever and shift the lever beyond the combat rating stop so as to latch it in this position.

499. It is allowed to turn on the afterburner at the maximum cruising rating (10,870 r.p.m.) by continuous movement of the engine control lever with a rate of at least 1.5 seconds.

500. The afterburner starts operating 3 to 5 seconds after turning it on. The time required for increasing the engine thrust when turning on the afterburner, should not exceed 6 seconds.

Turning on the afterburner at altitudes below 10,000 m will result in large specific acceleration of the aircraft. The temperature of the exhaust gases increases by 10 to 40°C at altitudes above 10,000 m especially at low flying speeds, the turning-on of the afterburner is accompanied for a short time by intensive pops and the acceleration of the aircraft is considerably less.

501. The turning-on and operation of the afterburner should be checked by the temperature of the exhaust gases and by the acceleration of the aircraft.

The maximum temperature of the gases behind the turbine, when flying at augmented rating, should not exceed 700°C up to an altitude of 14,000 m and 740°C - above 14,000 m.

The maximum temperature of gases at take-off (combat) rating, with the afterburner turned off should not exceed 700°C at all flight altitudes.

If the fuel fails to ignite in the afterburner after turning it on, the gas temperature behind the turbine drops by 50 - 60°C and the flying speed decreases.

502. Continuous operation of the engine at augmented rating in climbing and level flight at altitudes up to 7000 m is allowed for not more than 3 min, and at altitudes above 7000 m - for maximum 10 min.

When climbing the aircraft at the maximum rate-of-climb speed immediately after take-off or from an altitude below 7000 m, the afterburner may remain turned on from the moment of take-off during 10 min continuously, since the altitude of 7000 m will be reached within less than 3 min. When in flight, the afterburner may be turned on several times whenever necessary, repeated switching of the afterburner is allowed only after cooling the afterburner, for 3 minutes with the engine running at 11,200 r.p.m.

The values of engine rating limitations are given in Table 14.

Table 14

| Engine rating               | Engine speed, r.p.m. | Gas temperature behind turbine, °C | G11             |                  | Time of continuous operation, min   |
|-----------------------------|----------------------|------------------------------------|-----------------|------------------|-------------------------------------|
|                             |                      |                                    | Temperature, °C | Altitude, m      |                                     |
| Combat, with afterburner on | 11,500 ± 100         | 700, at all altitudes              | 740             | 14,000 to 15,000 | At altitudes up to 7000 m - maximum |

Peer Original

| 1                            | 2                           | 3                    | 4           | 5               | 6   |
|------------------------------|-----------------------------|----------------------|-------------|-----------------|---|
|                              |                             | above 14,000 m - 745 |             | From -40 to +90 | 3 minutes; at altitudes above 7000 m - maximum 10 minutes   |
| Combat, with afterburner off | 11,500 <sup>±500</sup> -110 | 720                  | 1.4-1.5     |                 | In level flight at altitudes up to 10,000 m - maximum 6 minutes; at altitudes above 10,000 m - maximum 10 minutes; in climbing - 10 minutes |
| Normal                       | 11,200                      |                      |             |                 | 60 minutes  |
| Maximum cruising             | 10,870                      |                      |             |                 | Unlimited   |
| Idle rating on the ground    | 2500 <sup>±500</sup>        | 540                  | Minimum 0.2 |                 | Maximum 10 minutes  |

503. With the increase of flight altitude, the fuel pressure in the afterburner burner equals 60 to 80 kg/cm<sup>2</sup> at an altitude of 3500 m, the fuel pressure in the afterburner equals 10 to 15 kg/cm<sup>2</sup> and at an altitude of 14,000 m the pressure of fuel in the afterburner equals 2 to 5 kg/cm<sup>2</sup>.

504. To change the engine thrust at augmented rating in aircraft mounting engines with strengthened afterburners, provision is made for a throttling system which ensures the change of the engine speed without turning off the afterburner. The change of the engine speed, with the engine running at augmented rating, is effected by shifting the engine control lever from the combat rating stop to a special throttling stop set in a position corresponding to the engine speed of 10,870 - 70 r.p.m. To turn off the afterburner, shift the engine control lever backward through the throttling stop. While doing so, the afterburner gets turned off at the engine speed of 10,550 ± 50 r.p.m.

It is allowed to shift the engine control lever to the required engine speed only after making certain that the afterburner has been turned off (pressure in front of the afterburner jets drops down to zero).

505. In aircraft mounting engines with non-strengthened afterburners the throttling system is not provided and the throttling stop is not installed. The above aircraft have intermediate stops adjusted to the engine speed of 8600 r.p.m., which are intended for starting the movement of the engine control levers in order to protect

the afterburners from overheating when turning off the engine afterburners at flying speeds above 300 km/hr.

To turn off the afterburner in these aircraft, shift the engine control lever back to zero, the combat rating stop.

To directly turn on the afterburner, set the engine control lever at the intermediate stop or out in or out the afterburner circuit breaker.

Shift the engine control lever beyond the combat rating stop only after carrying out the above operations. This is normal procedure to prepare the electrical circuit for repeated turning on of the afterburner.

506. To prevent spontaneous cutting-off or loading of the engine at altitudes above 15,000 m with an indicated airspeed of less than 300 km/hr, operate the engine only at combat or augmented rating. When throttling the engine at these altitudes, gain the combat rating at altitudes of less than 15,000 m and an indicated airspeed of above 300 km/hr.

To prevent spontaneous cutting-off of engine, total EX-10, at altitudes above 16,000 m, the engine afterburner may be turned off at flying speeds of more than 300 km/hr IAS.

TAKE-OFF WITHOUT TURNING-ON AFTERBURNER

507. Before take-off, the pilot should make sure that the NOZZLE OFF (OFF/OFF-HP/TO) change-over switch is in the CLOSED (ZAKRYTO) position.

Caution. When taking off with the nozzle open, the length of take-off run is almost twice as much owing to the decrease of the engine thrust.

508. The take-off technique in the MiG-17 and MiG-17bis aircraft, with the afterburner turned off, does not practically differ from that in the MiG-17 aircraft. The take-off run length is somewhat greater than that of the MiG-17 aircraft. The maximum speed of the MiG-17bis aircraft, as compared to that of the MiG-17 aircraft, is increased by 10 - 20 km/hr.

TAKE-OFF WITH AFTERBURNER TURNED ON ON THE GROUND

509. Whenever necessary to reduce the length of the take-off run and take-off path, it is allowed to take off with the afterburner turned on.

510. While taking off with the afterburner turned on, the aircraft rapidly gains speed both during the take-off run and after the unticket, which considerably reduces the length of the take-off run of the MiG-17 aircraft down to 350 - 400 m, and the climbing time.

511. When taking off with turning on the afterburner for subsequent flying at low altitudes, the pilot should carefully watch the fuel residual, since the use of the afterburner at low altitudes involves considerable consumption of fuel.

Turn off the afterburner after take-off at an altitude of 150 - 200 m.

512. While flying the landing pattern, turn to base leg at a speed of 400 km/hr, glide on the base leg at a speed of 340 - 390 km/hr and perform the final leg turn at a speed of minimum 300 km/hr. After landing final, maintain the gliding speed of 240 - 270 km/hr.

513. While climbing, with the engine running at idle rating, bear in mind that engine acceleration time (time required to pick up speed from idle to take-off rating) makes up 15 seconds; therefore, the decision to add power or to go-around should be taken in due time.

514. The flying technique of the MiG-17 and MiG-17bis aircraft, with the afterburner turned off, does not practically differ from that of the MiG-17 aircraft.

Peer Original

SECRET/NO FOREIGN DISSEM

Table 15

Rate of Climb of Single Aircraft MiG-17<sup>1</sup> with Afterburner Turned On or Off

| Altitude, m | With afterburner turned off                            |                       |                    | With afterburner turned on                                  |                       |                    |
|-------------|--|-----------------------|--------------------|---|-----------------------|--------------------|
|             | True speed read by thin pointer during climbing, km/hr | Vertical speed, m/sec | Climbing time, min | True airspeed (read by thin pointer) during climbing, km/hr | Vertical speed, m/sec | Climbing time, min |
| 1000        | 750  | 39.6                  | 0.4                | -   | -                     | -                  |
| 2000        | 770  | 36.4                  | 0.9                | -   | -                     | -                  |
| 3000        | 770  | 35.9                  | 1.3                | 1075  | 75.8                  | 1.9                |
| 4000        | 750  | 31.3                  | 1.9                | 1000  | 70.4                  | 1.7                |
| 5000        | 750  | 25.8                  | 2.4                | 1000  | 65.0                  | 2.1                |
| 6000        | 750  | 26.2                  | 3.0                | 1000  | 59.7                  | 2.4                |
| 7000        | 750  | 23.6                  | 3.7                | 1000  | 54.4                  | 2.7                |
| 8000        | 750  | 21.0                  | 4.5                | 1000  | 49.0                  | 3.0                |
| 9000        | 750  | 19.4                  | 5.3                | 1000  | 43.8                  | 3.3                |
| 10,000      | 750  | 16.0                  | 6.2                | 1000  | 38.4                  | 3.7                |
| 11,000      | 750  | 13.4                  | 7.3                | 970   | 33.0                  | 4.2                |
| 12,000      | 750  | 10.0                  | 8.8                | 970   | 28.0                  | 4.7                |
| 13,000      | 750  | 7.0                   | 10.0               | 970   | 22.5                  | 5.4                |
| 14,000      | 750  | 5.9                   | 14.0               | 970   | 17.2                  | 6.3                |
| 15,000      | 750  | 0.8                   | 22.0               | 940   | 11.8                  | 7.4                |
| 16,000      | 750  | -                     | -                  | 910   | 6.7                   | 9.2                |

518. The climbing time at augmented rating is given for conditions of climbing flight up to 3000 m at engine combat rating, with the afterburner turned off.

519. Climb the aircraft, with the afterburner turned off, at the following speeds:

(a) in the MiG-17<sup>1</sup> aircraft - at true airspeed of 750 km/hr (as read by the thin pointer);

(b) in the MiG-17<sup>1</sup> aircraft - at a true airspeed of 700 km/hr (as read by the thin pointer).

518. Climbing at augmented rating should be performed:

(a) in the MiG-17<sup>1</sup> aircraft: up to an altitude of 10,000 m - at a true airspeed of 700 km/hr from an altitude of 11,000 to 16,000 m - at a true airspeed of 750 km/hr, and up to 16,000 m - at a true airspeed of 500 km/hr. The forces applied to the control stick, when climbing the aircraft at augmented rating up to 10,000 m, are prevailing forces and amount to 5 - 7 kg. At altitudes of 10,000 m and above, the forces on the control stick change into pulling forces and have an average value of up to 5 kg with the trim tab applied, the control stick forces are reduced;

(b) in the MiG-17<sup>1</sup> aircraft: up to an altitude of 10,000 m - at a true airspeed of 750 km/hr when climbing to altitudes above 10,000 m, reduce the true airspeed by 20 km/hr per each 1000 m.

517. Climb to altitudes above 16,000 m only in aircraft equipped with special high-altitude equipment.

SECRET/NO FOREIGN DISSEM

Peer Original

50X1-HUM

Table 16

Rate of Climb of Single Aircraft MiG-17<sup>1</sup> with Afterburner Turned On or Off

| Altitude, m | With afterburner turned off                                 |                       |                    | With afterburner turned on                                  |                       |                    |
|-------------|---|-----------------------|--------------------|---|-----------------------|--------------------|
|             | True airspeed (read by thin pointer) during climbing, km/hr | Vertical speed, m/sec | Climbing time, min | True airspeed (read by thin pointer) during climbing, km/hr | Vertical speed, m/sec | Climbing time, min |
| 0           | 740   | 38.4                  | 0                  | 970   | -                     | -                  |
| 1000        | 780   | 31.8                  | 0.5                | 970   | -                     | -                  |
| 2000        | 780   | 29.8                  | 1.0                | 970   | -                     | -                  |
| 3000        | 790   | 27.8                  | 1.6                | 990   | 59.5                  | -                  |
| 4000        | 780   | 25.8                  | 2.2                | 990   | 55.0                  | 2.5                |
| 5000        | 780   | 23.8                  | 2.9                | 990   | 50.5                  | 2.9                |
| 6000        | 750   | 21.8                  | 3.7                | 970   | 46.0                  | 3.2                |
| 7000        | 750   | 19.8                  | 4.5                | 970   | 41.5                  | 3.6                |
| 8000        | 750   | 17.8                  | 5.3                | 970   | 36.8                  | 4.0                |
| 9000        | 730   | 15.8                  | 6.4                | 970   | 32.3                  | 4.5                |
| 10,000      | 780   | 13.7                  | 7.6                | 970   | 28.0                  | 5.1                |
| 11,000      | 780   | 11.7                  | 8.9                | 970   | 22.8                  | 5.7                |
| 12,000      | 740   | 8.1                   | 10.5               | 970   | 16.5                  | 6.6                |
| 13,000      | 730   | 5.0                   | 13.1               | 920   | 11.1                  | 7.8                |
| 14,000      | 780   | 1.6                   | 23.5               | 920   | 5.6                   | 9.3                |
| 15,000      | -   | -                     | -                  | 920   | -                     | -                  |

Note: The climbing time at augmented rating is given for conditions of climbing flight up to 3000 m at engine combat rating, with the afterburner turned off.

518. While climbing at maximum speed to an altitude of 16,000 - 20,000 m, with the afterburner turned on, the consumption of fuel for climbing to an altitude above 10,000 m is less than that for climbing to the same altitude with the afterburner turned off.

LEVEL FLIGHT

519. The maximum level flight speeds (read by the thin pointer) of the MiG-17<sup>1</sup> and MiG-17<sup>2</sup> aircraft, with the engine running at augmented rating, increase as compared to the flying speeds with the engine running at combat rating. The speed values (in kilometers per hour) are specified in Table 17.

Table 17

| Aircraft            | Altitude, m |        |        |
|---------------------|-------------|--------|--------|
|                     | 5000        | 10,000 | 12,000 |
| MiG-17 <sup>1</sup> | 1130        | 1071   | 1054   |
| MiG-17 <sup>2</sup> | 1165        | 1052   | 1038   |

520. While flying level at the maximum speed, with the afterburner turned on at an altitude of less than 10,000 m (for aircraft MiG-17<sup>1</sup>), the pilot experiences prevailing forces on the control stick (the aircraft flies nose up). Thus, at an altitude of 5000 m with an indicated airspeed of 700 km/hr, the prevailing forces on the control stick make up 35 - 40 kg. In this case, the elevator trim tab proves ineffective to remove the above forces.

521. The maximum permissible flying speeds (in kilometres per hour) of the MiG-17<sup>3</sup> and MiG-17<sup>2</sup> aircraft at various altitudes equal respectively to the values given in Table 18.

Table 18

| Aircraft                                    | Altitude, m                   |                                 |   |
|---|-------------------------------|---------------------------------|---|
|   | up to 3000                    | up to 7000                      | above 7000  |
| MiG-17 <sup>3</sup> and MiG-17 <sup>2</sup> | 1060 (read by the instrument) | 1150 (read by the thin pointer) | Up to the service ceiling flying speed should not exceed 1400 km/hr (as read by thin pointer) |

AIRCRAFT BALANCING

522. The trim speed of the MiG-17<sup>3</sup> and MiG-17<sup>2</sup> aircraft (with zero forces on the control stick) at a climbing attitude, with the engine running at nominal rating at a speed of 11,200 r.p.m., at an altitude of 3000 - 5000 m (the elevator trim tab being in the neutral position), should rate up 600 ± 50 km/hr.

FLIGHT MANEUVERS

523. The flying technique of the MiG-17<sup>3</sup> and MiG-17<sup>2</sup> aircraft with the afterburner turned on differs but slightly from that with the afterburner turned off.

524. While performing vertical maneuvers at augmented ratings, with the same G-load as in flying with the afterburner turned off, the flight maneuvers become extended in altitude and the time required for performing them increases. The performance of banked turns at augmented rating may involve greater G-loads than in flying with the afterburner turned off; owing to greater G-loads the maneuvering time decreases.

The characteristics of optimum steady banked turns performed in the MiG-17<sup>3</sup> and MiG-17<sup>2</sup> aircraft at an altitude of 10,000 m are presented in Table 19.

Characteristics of Optimum Steady Banked Turns Performed at Altitude of 10,000 m

Table 19

| Banked turn characteristics | MiG-17 <sup>3</sup>                |                                     | MiG-17 <sup>2</sup>                |                                     |
|-----------------------------|------------------------------------|-------------------------------------|------------------------------------|-------------------------------------|
|                             | with afterburner on, 11,560 r.p.m. | with afterburner off, 11,560 r.p.m. | with afterburner on, 11,560 r.p.m. | with afterburner off, 11,560 r.p.m. |
| Speed, km/hr                | 440                                | 440                                 | 450                                | 450                                 |
| Time, sec                   | 64.4                               | 54.2                                | 62                                 | 62                                  |
| Radius, m                   | -                                  | -                                   | 2650                               | 2650                                |

Note. For the MiG-17<sup>2</sup> aircraft the steady banked turn characteristics are reduced to a weight of 5230 kg.

525. Flying at augmented rating has increased the flight maneuverability as follows:

- (a) banked turns of up to 45° may be performed at altitudes up to 15,000 m
- (b) 30° banked turns may be executed at an altitude of 15,000 m
- (c) the normal loop and half-loop may be entered at an altitude of 8000 m

526. Inverted flight at constant rating, with the afterburner turned off, is allowed for not more than 15 seconds, while that with the afterburner turned on may be performed for not more than 5 seconds, provided the remainder of fuel is minimum 550 litres.

Caution. Recover the aircraft from vertical maneuvers at augmented rating, when the aircraft is subject to positive G-load (above +0.7), since the zero head flight tank fill capacity is insufficient.

528. The spin characteristics of the MiG-17<sup>3</sup> and MiG-17<sup>2</sup> aircraft are similar to those of the MiG-17 aircraft; therefore, these aircraft are recovered from the spin in the same way as the MiG-17 aircraft.

RANGE AND ENDURANCE

528. To gain the maximum range and endurance in the MiG-17<sup>3</sup> aircraft, maintain the indicated airspeeds given in Table 20.

Indicated Airspeeds Corresponding to Maximum Range and Endurance

Table 20

| Flight altitude, m | Indicated airspeed corresponding to maximum range, km/hr | Indicated airspeed corresponding to maximum endurance, km/hr |
|--------------------|--|--|
| 5000               | 470-550  | 300-320  |
| 10,000             | 400-480  | 300-320  |
| 12,000             | 390-440  | 300-320  |

529. Guide the MiG-17<sup>3</sup> and MiG-17<sup>2</sup> aircraft with a retracted landing gear and the engine control lever set in the idle rating position, at the speeds indicated for the MiG-17 aircraft.

EMERGENCY PROCEDURES  
AFTERBURNER FAILS TO TURN OFF

530. In case the afterburner fails to turn off when actuated by the engine control lever, turn off the afterburner using the emergency procedure, for which purpose shift the AFTERBURNER EMERGENCY TURN-OFF (AERAPHOE BAKLAFKHE TOCHIAL) circuit breaker in the rear position. In addition, cut off the ENGINE AFTERBURNER (ENGINA ZAPALITEL) circuit breaker by shifting the switch to the rear position.

When turning off the afterburner using the emergency procedure, the APT-14A valve and the engine jet nozzle flaps may remain in the OPEN (OTKRIT) position, which will result in the engine thrust drop with the afterburner turned off, and to additional consumption of fuel by the engine (about 400 lit/hr) through the APT-14A valve.

After the afterburner has been turned off by the emergency procedure, discontinue the flight circuit since the engine will run at a decreased thrust with an increased fuel consumption. In this case, the pilot can return to the home airfield and land the aircraft.

If the afterburner has been turned off by the emergency procedure, stop the engine after landing only by the command of the ground engineer (unless absolutely necessary). The ground engineer should immediately check the position of setting the switches on

Peep Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

- 98 -

the K-2 mechanism of the APU-1-A valve. If the catches are aligned, stop the engine using the normal procedure, i.e., by closing the stopcock. However, if the catches on the K-2 mechanism are misaligned, stop the engine by closing the fuel shut-off valve, to avoid ignition of fuel in the afterburner and damage to the aircraft.  
Do not fly the aircraft before the afterburner turn-off trouble has been found and eliminated.

PROCEDURE ON ENCOUNTERING FIRE

531. Should a fire occur in flight with the engine running at augmented rating, turn off the afterburner using the emergency procedure and, then, proceed in the same way as in case of fire in the MiG-17 aircraft.

PROCEDURE ON ENCOUNTERING FORCED LANDING

532. In case of forced landing of the MiG-19 and MiG-17 aircraft on the ground, in addition to the operations performed in the MiG-17 aircraft, extend the landing gear nose leg using the emergency procedure for which purpose pull the emergency control handle located on the lower console of the instrument panel all the way back. This done, check by the mechanical indicator and warning lights if the landing gear nose leg has come off from the lock.

PROCEDURE ON ENCOUNTERING AFTERBURNER SPONTANEOUS TURN-OFF

533. Spontaneous turn-off of the afterburner 4 - 6 seconds after its switching-on, testifies to the operation of the interlock system due to the jet nozzle flaps failure to open. Spontaneous turn-off may involve short-time increase of the exhaust gas temperature up to 6000°C and the appearance of puffs, which, however, do not interfere with the normal operation of the engine. If this is the case, do not turn on the afterburner for the second time, discontinue the flight mission and return to the base airfield.

APPENDIX

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Aircraft Performance Reference Table for MiG-17 Aircraft and Its Modifications

| Date  | MiG-17        | MiG-17M       | MiG-17S       | MiG-17P         | Notes   |
|---|---------------|---------------|---------------|-----------------|---|
| 1   | 2             | 3             | 4             | 5               | 6   |
| Engines type<br>MK-16, kg   | MK-16<br>2700 | MK-16<br>2700 | MK-16<br>2700 | MK-16<br>2700   | With afterburner off<br>With afterburner on   |
| Fuel reserve, ltr:<br>without drop fuel tanks<br>with drop fuel tanks   | 1435<br>2235  | 1599<br>2270  | 1410<br>2270  | 1395<br>2155    | Capacity of drop fuel tanks, 2 x 400 ltr  |
| Flying weight, kg:<br>normal<br>maximum (with drop fuel tanks)  | 5100<br>6072  | 5550<br>6260  | 5194          | 5600<br>6352    |   |
| Steepest speed, km/hr   | 243-230       | 255           | 235           | 246             | Flaps retracted, without drop fuel tanks; afterburner turned off  |
| Length, m:<br>take-off run<br>take-off path   | 560<br>1500   | 606<br>1500   | 500<br>1300   | 730-920<br>1475 | Same  |
| Optimum climbing speed (as read by tachometer), km/hr:<br>at take-off (combat)<br>engine rating<br>at normal engine rating<br>at augmented rating up to an altitude of 10,000 m<br>at augmented rating from 10,000 to 15,000 m<br>at augmented rating from 15,000 to 16,000 m | 750<br>720    | 750<br>760    | 750<br>720    | 780<br>750      | With afterburner turned on for MiG-17P aircraft at an altitude of 1000 m; for MiG-17S aircraft at an altitude of 4000 m |
| Maximum rate of climb with engine running at take-off (combat) rating, m/sec:<br>at an altitude of 1000 m   | 47.0          | 36.7          |               |                 | From an altitude of 10,000 m, decrease the climbing speed by 20 km/hr per each 1000 m of altitude for MiG-17S aircraft  |
|   |               |               |               |                 | For MiG-17P aircraft flying at augmented rating at an altitude of 3000 m, and for MiG-17S at an altitude of 4000 m      |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| 1   | 2      | 3      | 4      | 5      | 6 |
|---|--------|--------|--------|--------|---|
| at an altitude of 5000 m                                      | 35.0   | 27.0   | 65.0   | 55.0   |   |
| at an altitude of 10,000 m                                    | 20.0   | 15.0   | 38.4   | 30.3   |   |
| at an altitude of 15,000 m                                    | 2.6    | -      | 11.8   | 5.6    |   |
| at an altitude of 16,000 m                                    | -      | -      | 6.7    | -      |   |
| Minimum climbing time at engine take off (combat) rating min  |        |        |        |        |   |
| 1000 m  | 0.35   | 0.4    | 0.4    | 0.5    |   |
| 5000 m  | 2.0    | 2.5    | 2.1    | 2.5    |   |
| 10,000 m  | 5.1    | 6.6    | 3.7    | 4.5    |   |
| 15,000 m  | 14.6   | -      | 7.4    | 9.8    |   |
| 16,000 m  | -      | -      | 3.2    | -      |   |
| Service ceiling, m with afterburner turned off                | 15,500 | 14,500 | 15,100 | 14,450 |   |
| with afterburner turned on                                    | -      | -      | 16,470 | 16,300 |   |
| Maximum speed at various altitudes, km/hr                     |        |        |        |        |   |
| at an altitude of 1000 m                                      | 1190   | -      | -      | -      |   |
| at an altitude of 5000 m                                      | 1098   | 1085   | 1130   | 1123   |   |
| at an altitude of 10,000 m                                    | 1048   | 1033   | 1071   | 1060   |   |
| at an altitude of 12,000 m                                    | 1030   | 1006   | 1054   | 1038   |   |
| Maximum permissible flying speeds up to an altitude of 3000 m | 1060   | 1060   | 1060   | 1060   |   |
| from 3000 to 7000 m   | 1200   | 1200   | 1150   | 1150   |   |
| above 7000 m  | 1100   | 1100   | 1100   | 1100   |   |
| Maximum speed with drop tanks                                 | 1300   | 1300   | 1300   | 1300   |   |
| Minimum maneuvering speed at all altitudes, km/hr IAS         | 340    | 340    | 340    | 340    |   |

For SuF-17 aircraft flying at augmented rating at an altitude of 5000 m, and for SuF-17M aircraft at an altitude of 4000 m

No climbing has been practiced above 16,470 m

| 1   | 2       | 3       | 4          | 5          | 6   |
|---|---------|---------|------------|------------|---|
| Minimum flying speed at which the air craft loses stability, km/hr      | 200-220 | 210-230 | 200-220    | 210-230    | The landing gear and flaps are retracted (idle rating)  |
| Speed corresponding to maximum range for an altitude of 10,000 m, km/hr | 490     | 480     | 490        | 480        | At other altitudes the specified speed is increased by 20 km/hr per each 1000 m of altitude decrease, and decreased by 20 km/hr per each 1000 m of altitude increase, as compared to the altitude of 10,000 m |
| Speed corresponding to maximum endurance, km/hr                         | 300-320 | 300-320 | 300-320    | 300-320    | For all altitudes (IAS)   |
| Maximum range (stage), km at an altitude of 1000 m                      | -       | -       | 430<br>730 | 470<br>720 | Enumerator indicates flight range without drop tanks  |
| at an altitude of 5000 m  | 765     | 790     | 670        | 690        |   |
| at an altitude of 10,000 m  | 1185    | -       | 990        | 1000       | Denominator indicates flight range with drop fuel tanks   |
| at an altitude of 12,000 m  | 1775    | -       | 1520       | 1530       |   |
| Maximum endurance (block), min  | 1595    | 1525    | 1594       | 1108       | Enumerator indicates endurance without drop fuel tanks, denominator indicates endurance with drop fuel tanks  |
| at an altitude of 1000 m  | 2150    | 1800    | 1670       | 1730       |   |
| at an altitude of 5000 m  | 28      | 28      | 21         | 22         |   |
| at an altitude of 10,000 m  | 108     | 108     | 124        | 124        |   |
| at an altitude of 12,000 m  | 113     | 113     | 101        | 97         |   |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  | 1         | 2       | 3         | 4       | 5 | 6  |
|--|-----------|---------|-----------|---------|---|--|
| Maximum aerodynamic quality:                       |           |         |           |         |   |  |
| with flaps and landing gear retracted              | 13.6      | 13.6    | 13.6      | 13.6    |   |  |
| with flaps and landing gear extended               | 5.6       | 5.6     | 5.6       | 5.6     |   |  |
| Slide landing speed with imperative engine, km/hr: |           |         |           |         |   |  |
| with landing gear and flaps retracted              | 320-350   | 325-350 | 320-350   | 325-355 |   |  |
| with landing gear and flaps extended               | 260-270   | 270-280 | 260-270   | 270-280 |   |  |
| Optimum gliding speed (IAS), km/hr:                |           |         |           |         |   | With or without drop fuel tanks                    |
| from an altitude of 12,000 to 10,000 m             | 500       | 500     | 500       | 500     |   |  |
| from an altitude of 10,000 to 5000 m               | 550       | 550     | 550       | 550     |   |  |
| from an altitude of 5000 to 500 m                  | 650       | 650     | 650       | 650     |   |  |
| Slide landing speed (before leveling-off), km/hr   | 260-270   | 270-280 | 260-270   | 270-280 |   |  |
| Landing speed, km/hr                               | 170-190   | 180-200 | 170-190   | 180-200 |   |  |
| Length, m: landing run                             | 800-850   | 850     | 800-850   | 885     |   | Without drop fuel tanks, flaps in landing position |
| landing path                                       | 1000-1050 | 1050    | 1050-1100 | 1050    |   |  |

Notes: With the maximum engine speed decreased from 11,560 to 11,350 + 50 r.p.m., the aircraft performance changes as follows:

(a) maximum level flight speed (IAS) decreases by 20 - 30 km/hr. at altitudes up to 5000 m, and by 30 - 20 km/hr. at altitudes above 5000 m;

(b) the service ceiling increases approximately by 500 m;

(c) take-off run increases by 20 - 25%;

(d) climb rate increases by 20 - 25%;

(e) time of take-off run increases by 15 - 20% at low altitudes, and by 30 - 35% at high altitudes (about 10,000 m).

CONTENTS

|  | Page |
|--|------|
| PREFACE . . . . .  | 3    |
| I. PREPARATION FOR FLIGHT . . . . .  | 3    |
| Inspection of Aircraft . . . . .   | 3    |
| Inspection of Cockpit . . . . .  | 3    |
| Preparation of Anti-G Suit HRI-1 . . . . .   | 4    |
| Preparation of Parachute . . . . .   | 4    |
| Checking of Aircraft Equipment and Fittings after Entering Cockpit . . . . .   | 5    |
| Radio Equipment Operation Check . . . . .  | 7    |
| Aircraft Transponder Check . . . . .   | 7    |
| APX Automatic Radio Operation Check and Tuning . . . . .   | 8    |
| PE-2 Radio Altimeter Operation Check . . . . .   | 8    |
| Aircraft Check before Gun Firing and Bombing Missions . . . . .  | 9    |
| Cockpit Check before High-Altitude Flight . . . . .  | 9    |
| Aircraft Check before Night Flight . . . . .   | 10   |
| Taxiing of Aircraft . . . . .  | 10   |
| Engines Ground Starting . . . . .  | 11   |
| Engines Ground Test . . . . .  | 11   |
| Check of Anti-G Berries HRI-1 . . . . .  | 13   |
| Hydraulic System Operation Check . . . . .   | 14   |
| Preparation for Taxiing-Out and Taxiing Procedure . . . . .  | 15   |
| II. TAKE-OFF AND CLIMBING . . . . .  | 17   |
| Take-Off . . . . .   | 17   |
| Take-Off from Unpaved and Snow-Covered Runways . . . . .   | 17   |
| Climbing . . . . .   | 18   |
| Climbing . . . . .   | 19   |
| Climbing . . . . .   | 19   |
| III. LEVEL FLIGHT . . . . .  | 19   |
| Permissible Speeds . . . . .   | 19   |
| Check Flight and Balancing of Aircraft Not Equipped with Hydraulic Booster in Elevator Control System . . . . .      | 20   |
| Balancing of Aircraft Equipped with Irreversible Hydraulic Boosters in Elevator and Aileron Control System . . . . . | 21   |
| Lateral Balancing . . . . .  | 21   |
| Longitudinal Balancing . . . . .   | 21   |
| Engine Control in Flight . . . . .   | 22   |
| Operation of Pressurized Cockpit . . . . .   | 23   |
| Use of Oxygen in Flight . . . . .  | 24   |
| Flight with Drop Tanks . . . . .   | 25   |
| Flight with Fuel Load . . . . .  | 27   |

SECRET/NO FOREIGN DISSEM

Peer Original

|  | Page |
|--|------|
| Night Flight . . . . .   | 28   |
| Escape and Egress . . . . .  | 28   |
| Attendant Control Procedure in Flight . . . . .  | 30   |
| IV. FLIGHT MANEUVERS . . . . .   | 30   |
| General . . . . .  | 31   |
| Banked Turn . . . . .  | 31   |
| Figure Eight . . . . .   | 33   |
| Chandelle . . . . .  | 34   |
| Half-Loop . . . . .  | 34   |
| Roll . . . . .   | 35   |
| Double (Multiple) Horizontal Roll . . . . .  | 39   |
| Loop . . . . .   | 40   |
| Oblique Loop . . . . .   | 40   |
| Loop and Roll-Out . . . . .  | 41   |
| Egos . . . . .   | 41   |
| Evensided Stall . . . . .  | 42   |
| 90° and 180° Ascending and Descending Falls . . . . .  | 42   |
| Vertical Escrowment . . . . .  | 43   |
| SAC Ascending Roll . . . . .   | 43   |
| Multiple Ascending Roll . . . . .  | 44   |
| Vertical Figure of Eight . . . . .   | 44   |
| Half-loop and Roll . . . . .   | 44   |
| Aerobics Double Chandelle . . . . .  | 45   |
| Dive . . . . .   | 45   |
| Vertical Dive . . . . .  | 45   |
| Power Dive with Engine Running at Combat Rating . . . . .  | 47   |
| Spiral . . . . .   | 48   |
| Slip . . . . .   | 50   |
| Flying Technique in Anti-G Suit . . . . .  | 50   |
| V. SPIN . . . . .  | 51   |
| Aircraft Behaviour at Minimum Flying Speed and Spin Characteristics . . . . .  | 52   |
| Aircraft Behaviour in Spin . . . . .   | 52   |
| Spin Recovery . . . . .  | 53   |
| Inadvertent Spin Recovery . . . . .  | 54   |
| Inverted Spin and Inverted Spiral . . . . .  | 55   |
| Aircraft Behaviour in Inverted Spin . . . . .  | 56   |
| Recovery from Inverted Spin . . . . .  | 56   |
| Recovery from Inverted Spiral . . . . .  | 57   |
| VI. FLIGHT IN ADVERSE WEATHER CONDITIONS, INSTRUMENT APPROACH AND LANDING . . . . .  | 57   |
| USING GUN INSTRUMENT LANDING SYSTEM AND FC-1A RADAR CONTROL LANDING SYSTEM . . . . .   | 57   |
| Before Flight . . . . .  | 57   |
| In Flight . . . . .  | 58   |
| Upward and Downward Cloud Penetration, Instrument Approach and Landing Using GUN Instrument Landing System and FC-1A Radar Control Landing System . . . . .              | 58   |
| Instrument Approach and Landing Using Straight-In Approach Procedure . . . . .   | 59   |
| Two 180° Turn Approach Procedure . . . . .   | 59   |
| Wide Rectangular Pattern Approach Procedure . . . . .  | 60   |
| VII. TERMINATION OF FLIGHT . . . . .   | 61   |
| Pre-Traffic Pattern Check . . . . .  | 61   |
| Landing Gear Extension . . . . .   | 61   |
| Approach for Landing . . . . .   | 62   |
| Landing . . . . .  | 62   |
| Crosswind Landing . . . . .  | 62   |
| Landing on Unpaved Runway . . . . .  | 64   |
| Stopping Engines . . . . .   | 64   |
| VIII. EMERGENCY PROCEDURES . . . . .   | 65   |
| Procedure on Encountering Engine Failure in Flight . . . . .   | 65   |
| Engine Starting in Flight . . . . .  | 66   |
| Particularities of Starting Engine, Model 52-1A, in Flight under Winter Conditions . . . . .   | 67   |
| Procedure on Encountering Engine Jogg . . . . .  | 67   |
| Procedure on Encountering Engine Surging . . . . .   | 67   |
| Procedure on Encountering Radio Communication Failure . . . . .  | 68   |
| Procedure on Encountering Gyro Horizon Failure . . . . .   | 69   |
| Procedure on Encountering Speed Indicator Failure (total pressure line defective) . . . . .  | 69   |
| Procedure on Encountering Speed Indicator, Rate-of-Climb Indicator and Altimeter Failure (pitot-static tube line defective) . . . . .                                    | 70   |
| Procedure on Encountering AFM1 Resonance-Reading of Magnetic Compass Failure . . . . .   | 71   |
| Procedure on Encountering AFM1 Automatic Radio Compass Failure . . . . .   | 71   |
| Procedure on Encountering Lighting Equipment Failure during Night Flight . . . . .   | 72   |
| Preced Landing Procedure . . . . .   | 72   |
| Landing Gear and Flaps Emergency Extension Procedure . . . . .   | 72   |
| Procedure on Encountering Fuel Pressure Drop after First Tank Pump . . . . .   | 73   |
| Procedure on Encountering Engine Fire . . . . .  | 73   |
| Procedure on Encountering Generator Failure . . . . .  | 74   |
| Procedure on Encountering Engine Speed Drop in Flight . . . . .  | 74   |
| Procedure on Encountering Altimeter Receiver Failure . . . . .   | 75   |
| Procedure on Encountering Ice Formation . . . . .  | 75   |
| Cannopy Jettison and Ejection Procedure . . . . .  | 75   |
| Procedure on Encountering Cockpit Depressurizing at High Altitudes . . . . .   | 77   |
| IX. PARTICULARITIES OF OPERATION AND FLIGHT TECHNIQUE OF F4U-17 AIRCRAFT EQUIPPED WITH I-REVERSIBLE HYDRAULIC BOOSTERS IN MANEUVER AND ALLIANCE CONTROL SYSTEM . . . . . | 78   |
| General . . . . .  | 78   |
| Pre-Flight Check of Hydraulic Boosters . . . . .   | 79   |
| Take-off . . . . .   | 80   |
| Climb . . . . .  | 80   |
| Straight Flight . . . . .  | 81   |
| Flight Maneuvers . . . . .   | 81   |
| Banked Turn and Spiral . . . . .   | 81   |
| Chandelle . . . . .  | 81   |
| Barrel Roll and Half-Loop . . . . .  | 81   |
| Half-Loop . . . . .  | 82   |
| Vertical Dive . . . . .  | 82   |

Peer Original

|   |    |
|---|----|
| Power-On Dive with Engine Running at Combat Rating . . . . .  | 82 |
| Flight with Hydraulic Boosters Out-Off . . . . .  | 83 |
| Flight with Hydraulic Booster System Failed . . . . .   | 83 |
| Landing . . . . .   | 84 |
| <b>I. PECULIARITIES OF OPERATION AND FLYING TECHNIQUE</b>   |    |
| <b>OF AIRCRAFT MiG-17s</b>  |    |
| Pre-Flight Check of Radar Sight . . . . .   | 84 |
| Operating of Radar Sight in Flight . . . . .  | 84 |
| Peculiarities of Flying Technique . . . . .   | 85 |
| Emergency Procedures on Encountering Forced Landing . . . . .   | 85 |
| Peculiarities of Piloting in Other Cases . . . . .  | 87 |
| <b>II. PECULIARITIES OF OPERATION AND FLYING TECHNIQUE OF AIRCRAFT MiG-17s AND MiG-17s EQUIPPED WITH ENGINES, MODEL EK-18</b> | 88 |
| Inspection of Aircraft . . . . .  | 88 |
| Engines Starting and Testing . . . . .  | 88 |
| Operating of Engine on Ground . . . . .   | 88 |
| Peculiarities of Operating Engine, Model EK-18, in Air without Afterburner Turning-On . . . . .                               | 89 |
| Procedures of Afterburner Turning-On and -Off in Flight . . . . .   | 90 |
| Take-Off without Turning-On Afterburner . . . . .   | 90 |
| Take-Off with Afterburner/Turned On on the Ground . . . . .   | 93 |
| Level Flight . . . . .  | 93 |
| Aircraft Balancing . . . . .  | 95 |
| Flight Maneuvers . . . . .  | 96 |
| Range and Endurance . . . . .   | 96 |
| Emergency Procedures . . . . .  | 97 |
| Afterburner Fails to Turn Off . . . . .   | 97 |
| Procedure on Encountering Fire . . . . .  | 97 |
| Procedure on Encountering Forced Landing . . . . .  | 98 |
| Procedure on Encountering Afterburner Spontaneous Turn-Off . . . . .  | 98 |
| <b>APPENDIX</b>   | 99 |

Peep Original

**SECRET**  
NO FOREIGN DISSEM

50X1-HUM

**MAINTENANCE OF AIRFRAME AND ENGINE  
PROCESS CHARTS  
SUPPLEMENT TO INSPECTION GUIDE No. 21**

**SECRET**  
NO FOREIGN DISSEM

GROUP 1  
Excluded from automatic  
downgrading and  
declassification

50X1-HUM

SECRET/NO FOREIGN DISSEM

**SECRET**

MAINTENANCE OF AIRFRAME AND ENGINE  
PROCESS CHARTS

SUPPLEMENT TO INSPECTION GUIDE No. 21

SECRET/NO FOREIGN DISSEM

*Post Original*



SECRET/NO FOREIGN DISSEM

PREFACE

The present Process Charts are used as instructive documents during scheduled maintenance operations on the airframe and engine which are listed in the Inspection Office Form.

All the assemblies, mechanisms and units of the airframe and engine indicated in the present book are subject to inspection and check-out even in case their operation has been faultless. The reason is that the purpose of inspections and scheduled maintenance operations consists mainly in prevention of troubles rather than in correction of faults.

- Indicated in the Process Charts are:
- the scope of the operations performed during scheduled maintenance;
  - the technical requirements for the units and systems of the airframe and engine;
  - the operations carried out to correct faults in units and systems which fail to meet the existing technical requirements;
  - the approximate time quotes (in man-hours) for each operation.

SECRET/NO FOREIGN DISSEM

SECRET/NO FOREIGN DISSEM

50X1-HUM

**TACTICAL SUGGESTIONS OF MAINTENANCE OPERATIONS OF AIRFRAME AND ENGINE**  
**IN TERMS OF AIRCRAFT FLYING HOURS**  
 (Indicated in the columns are the numbers of Process Charts which deal with the corresponding maintenance operations)

| After first 50 hours of engine operation | After first 1000 flying hours | After first 2500 flying hours  | After every 2500 flying hours  | After every 5000 flying hours   | After every 10000 flying hours | After every 6 months of operation | After every 12 months of operation   | Notes |
|--|-------------------------------|--|--|---|--------------------------------|-----------------------------------|--|-------|
| 64                                       | 13, 18                        | 11, 13, 14, 15, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 72 | 1, 2, 3, 4, 5, 9, 10, 11, 12, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 72 | 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 72 | 55                             | 53, 56                            | <ol style="list-style-type: none"> <li>Process Chart No. 51. ATF-10 hydraulic fluid is changed in L.O. Shock struts every 3 years of operation</li> <li>Airtightness checks of de-icer system (Fuel 1 of Process Chart No. 63) are carried out once every 100 flying hours</li> <li>Process Chart No. 70. Operations are performed during engine replacement and in case fuselage is disjuncted</li> <li>Process Chart No. 71. Operations are performed during corrosion-preventive treatment of engine</li> </ol> |       |

Note: The terms of maintenance operations are given in strict conformity with those indicated in the Inspection Guide No. 21, Second Edition.

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

GENERAL

1. Scheduled maintenance operations on the aircraft should be performed in compliance with the Inspection Guide No. 21, the present Process Charts, aircraft service manuals and Manufacturer's Bulletins.

2. Scheduled maintenance operations on the airframe, engine and equipment systems of the aircraft should be carried out in terms which depend upon the number of aircraft flying hours: i.e. after the first 501, 1002 and 2003 flying hours and after every 2505, 5010 and 10020 flying hours, as well as after every 6 and 12 1/2 months of operation.

3. If the engine or any other unit has been replaced on the aircraft, maintenance operations on these are performed in terms depending on the number of flying hours, i.e. after 2505, 5010 and 10020 flying hours.

4. To ensure trouble-free operation of the aircraft equipment in adverse climatic conditions (high humidity, dust accumulation, etc., etc.), or when specific missions impose heavier loads on particular units of the aircraft (the landing gear is subjected to strenuous use and the like), ahead-of-schedule maintenance operations on all or separate aircraft (or units) may be authorized for performance during engine replacement work or when the aircraft is withdrawn from flying missions for a long period of time. These non-scheduled operations should be carried out in compliance with the Inspection Guide No. 21.

5. Prior to forwarding the aircraft to maintenance teams it is necessary to discharge the seat ejection gun, the canopy ejection gun and the drop tank ejection system, as well as the aircraft's main, rocket launcher systems and the ejection signal flare launcher, type RZP-45. When discharging, all the necessary safety precautions should be taken. The next step in the inspection is the scope of the post-flight inspection procedure, with checking of

all the faults detected. The troubles revealed during the inspection should be entered in the appropriate Service Logs and then eliminated (but for those which can be remedied only in the course of special maintenance procedures).

6. Before the beginning of the scheduled maintenance operations the aircraft should be inspected in the scope of the post-flight inspection procedure.

7. Special preparations should be carried out at the maintenance site in the following sequence:

- (a) select and arrange conveniently the tools, fixtures and accessories which are required for maintenance operations. The tools should be contained in special tool boxes or in bags which bear identification inscriptions;
- (b) remove the canvas covers from the aircraft;
- (c) attach the walks on the wing;
- (d) open the necessary access-hole panels on the wing and fuselage.

8. All maintenance operations should be performed with serviceable and marked tools and accessories attached to the airframe and engine.

Prior to, and after maintenance operations on the aircraft, it is necessary to checklist all the tools in order to make sure that not a single tool has been lost or left in the aircraft.

9. When carrying out inspections and maintenance operations the external surfaces of the units of the airframe, armament items, flight control and navigating equipment, the radio and radar equipment, as well as their connecting lines and wires should be cleaned from dirt, dust and old lubricant.

10. Never remove dirt with air-kerosene mixture.

11. Remove dirt from the aircraft skin with water making use of a hair brush or clean rags.

12. Remove ice and hoar-frost from the aircraft skin

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

with warm air fed from a heater. The surface cleaned from ice should be dried with warm air. The air temperature should be not over 70 - 80°C.

**WARNING.** Never attempt to tear frost-encrusted canvases from aircraft skin since otherwise the varnish coating of skin will be damaged.

Use warm air to unfreeze canvases before removing them from aircraft.

12. All the holes in units, pipelines and all the plug connectors which are opened during maintenance operations on the aircraft should be sealed with plugs or PTC film immediately upon completion of the operations.

**WARNING.** It is forbidden to wipe and stop the ends of pipelines with cotton wool, hemp and the like when disconnecting pipelines of systems. Only clean rags should be used for cleaning operations.

13. At parking the canopy glazing and the cockpit pressurization rubber tube should be protected against effect of sun rays; for this purpose the canopy should be covered.

14. All the maintenance operations and cases of fault correction should be recorded in the airframe and engine Service Logs and in the Aircraft Pre-Flight Inspection Log.

15. The aircraft technician superintends all the operations concerning repair, adjustment and correction of faults which were detected during aircraft inspections before the scheduled maintenance operations.

Safety Precautions

16. Before beginning inspection and maintenance operations on the aircraft take all the necessary precautions to prevent accidental firing, drop tank jettisoning, fuel tank venting gear retraction and spontaneous

engagement of electric units since these may result in grave accidents and failure of aircraft equipment.

To obviate these undesirable cases open the canopy, install the ground safety lockpins in the operating runs of the canopy recover guns and, without climbing into the cockpit, make sure that:

- the seat ejection gun and the canopy recover gun are discharged;

- the ground safety pins are installed in the 215K drogue gun and in the 2150 canopy recover gun actuating rollers; safety covers are fitted over the seat arm-rests;

- the ground safety pin is inserted in the canopy autonomous jettison lever and the lever is locked; the lever of the duplicating canopy unlock system is locked;

- the drop tank emergency jettison control button on the instrument panel is capped and the drop tank jettison gun is discharged;

- the landing gear control handle is locked in the neutral position;

- all the switches and automatic circuit-breakers of the electric equipment in the cockpit (with the exception of those which are locked) are in the OFF (BURNISHED) position (the automatic circuit-breakers located under the right-hand transparent panel may be left ON but for the ARMD - R172 (SOPMS-REKRPAP) circuit-breaker);

- the IFF unit destruction circuit is OFF, i.e. safety pin in the cockpit is installed, and the switch on the IFF destructor control panel in the nose accessory compartment is in the OFF (BURNISHED) position.

17. When mounting the drop tank on the aircraft do not switch on the storage battery before completion of drop tank mounting operations.

18. Before inspecting the frost air holes on the armrest systems open the cross-feed pipe (located in the wall of the right L.G. leg) and lock it with a diagonal

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

safety pins when normally open the air brakes. Prior to extending the cross-feed cock reduce the pressure in the hydraulic system to zero.

18. It is forbidden to extend the air brakes for inspection by pressing the air brake control gun located on the pilot's control stick.

19. It is forbidden to stay in the cockpit when the cells of the landing gear, flaps and air brakes are being inspected with the hydraulic system under pressure.

20. It is forbidden to extend the air brakes with the aid of the live hydraulic system (for operation in the wall of the air brakes).

21. Before working in the wall of the rear air brake disconnect the hydraulic cylinder operating rod from the air brake with the pressure in the main hydraulic system reduced to zero.

22. Upon termination of inspection and maintenance operations in the air brake walls close the cross-feed cock.

23. It is forbidden to fly the aircraft with the cross-feed cock open.

24. Only ordnance specialists are authorized to load and unload the seat ejection gun, the canopy remover gun and the drop tank jettison gun; to check the control of the drop tank jettison gun firing group, to test-fire the explosive charge-actuated mechanisms with special primers and to check the charge-actuated mechanisms for proper functioning.

25. The mechanical control lines of the explosive charge firing mechanisms of the seat ejection gun and canopy jettison gun should be adjusted by specialists included in the aircraft maintenance team.

26. All the maintenance, preparations and adjusting operations on the seat ejection gun, canopy remover gun,

and drop tank jettison gun should be carried out with the explosive charges removed.

27. It is forbidden to demount the canopy from the aircraft together with the interlock cable.

28. During loading and unloading operations of the aircraft armament systems it is necessary to place a red flag (or a red lantern when dark) at a distance of 3 to 5 metres fore of the aircraft nose. In addition a red flag (lantern) should be also placed behind the tail section of the aircraft when special units (pods) are being attached. The flag (lantern) indicates that staying or passing in front of or behind the aircraft is prohibited.

29. When fuelling the aircraft it is forbidden to stay under the aircraft or to work from a service ladder at the fuselage tail section since otherwise sudden settling-down of the aircraft under the gravity of the tank-filling fuel may result in grave injuries to the personnel.

30. It is forbidden to fuel the aircraft which is within the reach of gas streams from other taxiing aircraft or in close downwind proximity to the aircraft with running engines.

31. During maintenance operations on the aircraft never place foreign objects on the parts, assemblies and units of the airframe and engine. Upon completion of maintenance operations make certain that no foreign objects are left in the access holes, compartments, and on the units and accessories of the airframe and engine.

32. Before the first starting of the engine, as well as after every disconnection of fuel and hydraulic system lines of the engine or airframe for units replacement, pump the systems through to eliminate air locks, especially if there are indications of such locks.

33. If oil has been drained from the engine oil system, before starting the engine charge oil to the normal level (necessary with the aid of the dip stick) the

SECRET/NO FOREIGN DISSEM

Peer Christian

SECRET/NO FOREIGN DISSEM

50X1-HUM

level should be  $11 \pm 0.5$  litres). Then start the engine and let it run at 20% normal rating during 30 seconds. After the engine is stopped check the oil level and add oil into the tank till the required level.

**NEVER FILL OIL OVER CAPACITY.**

30. It is forbidden to add oil into the engine oil system with the engine running since otherwise undesirable splash-out of oil may happen.

31. After scheduled maintenance operations and upon elimination of troubles the engine should be started and tested only at grounds specially assigned and equipped for this purpose.

32. Never start the engine unless brake chocks are placed under the landing gear wheels. Before starting the engine for testing at augmented rating near the aircraft by means of cables.

33. Before ground check-running of the engine install

protective screens on the additional air intake shutter ports and remove these screens before taxiing to the take-off position. At parking, plug the additional air intake shutter ports.

34. During the first starting and check-running of the engine after the scheduled maintenance operations check (with the engine running idle and with the engine compartment access hole covers open) for leakage of fuel and oil from the joints of pipelines and units. Only after this check it is allowed to carry out engine checking at higher power ratings.


35. In the course of the entire service life or storage of the engine on the aircraft the engine system should be filled with fuel. In case the fuel system of the engine is emptied it is necessary to subject the system to internal corrosion-preventive treatment no later than in twenty four hours after fuel drainage.

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |                              |
|---|--|--|------------------------------|
| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 1  |  | In 2 sheets<br>Sheet 1       |
| FUEL SYSTEM   | WARNING FILTER IN SPECIAL VALVE CONTROL PRESSURE LINE OF FUEL SYSTEM   |  | Ins-hours<br>required - 2.30 |
| Procedure   | Technical requirements   | Fault correction   |                              |
| <ol style="list-style-type: none"> <li>1. Remove drop fuel tank and drop tank pylon</li> <li>2. Disconnect hydraulic cylinder operating rod from left L.G. door and lift door</li> <li>3. Open panel of access hole leading to pump of tank 3 (on fuselage port side, between frames Nos 16 and 20), (see Fig.1)</li> <li>4. Remove filter from special valve control pressure line. To this end, remove control pressure pipe; screw off two nuts, disconnect electric connector from unit 495-A2, remove non-return valve, remove Tee-connection, screw off nut from filter body and release clamp</li> <li>5. Disassemble filter and wash it in clean (unleaded) gasoline, blow with compressed air and inspect</li> </ol> | <p>Note: Carry out maintenance operations with tanks empty</p>                         | <p>FIG. 1. INSTALLING FILTER IN SPECIAL VALVE CONTROL PRESSURE LINE OF FUEL SYSTEM</p> <p>1 - Filter, 2 - non-return valve, 3 - pump 45A, 4 - electric connector, 5 - Tee-connection and manual pressure system pump, 6 - fuel system pipe</p> |                              |
|   | <p>Filter should be clean; filter parts should not be clogged with dirt and should be viewed through unobstructedly. No mechanical damage to filter shall be tolerated</p> | <p>Mechanically damaged filter should be replaced</p>  |                              |

SECRET/NO FOREIGN DISSEM

Poor Quality

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                              |
|---|---|------------------|------------------------------|
| Synthesis & Fabrication<br>Gate No. 1   | PROCESS CHART No. 1   |                  | In 2 sheets<br>Sheet 2       |
| FUEL SYSTEM   | SAGGING FILTER IN SPECIAL VALVE CONTROL<br>PRESSURE LINE OF FUEL SYSTEM   |                  | Man-hours<br>required - 2.50 |
| Procedure   | Technical requirements  | Fault correction |                              |
| 6. Re-install filter in special<br>valve control pressure line of fuel<br>system; screw it in as far as it will go<br>and safety with locking wire MIL-O-8<br>7. Fuel all tanks, engage pumps and<br>check system for airtightness<br>8. Close access hole panel and lock<br>it |   |                  |                              |
| Accessories   | Tools   |                  |                              |
|   | Wrenches, 14 x 17; 24 x 27 and 30 x 52<br>Multi-purpose flat-nose pliers<br>Screwdriver<br>Screwdriver for cross-slotted screws |                  |                              |

SECRET/NO FOREIGN DISSEM

*Poor Original*



SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide 59.21   | PROCESS CHART No. 2   |   | In 3 sheets<br>Sheet 1       |
|--|---|---|------------------------------|
| FUEL SYSTEM  | WASHING AND INSPECTING GASOLINE SYSTEM FILTER   |   | Man-hours<br>required - 0.30 |
| Procedure  | Technical requirements  | Fault correction  |                              |
| 1. Open gasoline tank access hole panel on fuselage port side and remove filter neck cover<br>2. Open panel of access hole leading to fire extinguishing cylinder and hydraulic accessories (on right bottom side of fuselage). Filter 9 is installed between tank and pump HSPD-96 (Fig. 2)<br>3. Drain gasoline from tank into clean container by pressing upon drain cock 1 (Fig. 3)<br>4. Unlock filter<br>5. Scribe off pipe nuts and remove filter. 2. Demount filter together with Tee-connection 4<br>6. Wash filter in pure gasoline and blow with compressed air | Protect disconnected pipe ends with plugs or cellophane<br><br>Filter gause and soldering places should be free from damage and deformation | In case of deteriorated filter gause or soldering, repair or replace filter |                              |


11

SECRET/NO FOREIGN DISSEM

Peer Christian

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |
|---|--|--|
| PROCEDURE CHART No. 2<br>WASHING AND INSPECTING GASOLINE SYSTEM FILTERS   |  | In 3 sheets<br>Sheet 3<br>Rep-Items<br>Required - 6.30 |
| Procedure<br>7. Inspect filter gaskets and soldering pieces<br>8. Re-mount filter, tighten nuts and lock them<br>9. Fill tank with gasoline<br>10. Inspect filter connections and make sure there is no gasoline leakage<br>11. Close access hole panel and lock it | Technical requirements<br>Filter should be clean                     | Fault correction                                       |
| Accessories<br>Gasoline<br>Hair brush   | Tools<br>Filter<br>Screwdriver<br>Wrench, 19 x 22<br>Wrench, 32 x 36 |  |

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM


|  |   |   |
|--|---|---|
| Suppressor to Inverters<br>W412-70,71  | PROCESS CHART No.5  | In showing<br>Sheet 1   |
| FUEL SYSTEM  | WASHING WING TANK FILTERS   | Man-hours<br>required - 0.35  |
| Procedure  | Technical requirements  | Fault correction  |
| <ol style="list-style-type: none"> <li>1. Remove cover of access hole leading to W-18 pump located on wing under surface at most sections of ribs 13 - 14 (before doing this dismount special rack, if any)</li> <li>2. Remove screws which attach electric connections of pods and move these away from filter cover to ensure free removal of filter cover (Fig.4)</li> <li>3. Unlock and unscrew filter cover</li> <li>4. Withdraw filter element from body</li> <li>5. Re-mount filter cover on filter body to close filter opening</li> <li>6. Wash filter element in clean gasoline, blow with compressed air and inspect</li> <li>7. Remove cover and insert filter element in filter body</li> <li>8. Screw in filter cover and secure it with locking wire KX-G-8</li> <li>9. Attach and fasten in place electric connections of special racks</li> <li>10. On aircraft beginning with Serial No.2215 open panel of access hole leading to antecabin located between</li> </ol> | <p style="text-align: center;">Filter gauze should be clean and free from damage or crumpling. Soldered joints should be intact</p> | <p style="text-align: center;">Filter elements with damaged gauze or soldered joints should be replaced</p> |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |                           |  |                              |
|--|---------------------------|--|------------------------------|
| Subject to Inspection<br>Guide No. 21  | PROCESS CHART No. 3       |  | In 3 sheets<br>Sheet 2       |
| FUEL SYSTEM  | WASHING WING TANK FILTERS |  | Man-hours<br>required - 0.30 |
| Procedure  | Technical requirements    | Fault correction   |                              |
| <p>flange Nos 15 and 16a on fuselage port side (foam filter is housed in body connected with non-return valves of wing fuel compartments)</p> <p>11. Remove pipe assembly which is coupled to non-return valves of wing fuel compartments, drop tank and special valve of tank 2</p> <p>12. Undo coupling flange bolts of non-return valve body and filter body and remove filter</p> <p>13. Wash filter in clean gasoline and clean it. Filter gauze should not be damaged mechanically</p> <p>14. Re-install filter and connect bodies reversing the disassembly procedure</p> |                           |  <p>FIG. 2 INSTALLING WING TANK FILTER<br/>1 - New filter, 2 - Fuel transfer pump<br/>RF-1-4 3 - New cover, 4 - electric<br/>cable (omitted)</p> |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                              |
|---|--|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 3  |                  | In 3 sheets<br>(sheet 3)     |
| FUEL SYSTEM   | MASKING WING TAKE PLATES   |                  | Man-hours<br>required - 0.30 |
| Procedure   | Technical requirements   | Fault correction |                              |
| 15. Re-mount complete assembly on<br>aircraft, attach and lock pipes<br>16. Refuel tanks, engage pumps and<br>check system for airtightness<br>17. Re-install access hole cover<br>and make it fast with screws |  |                  |                              |
| Accessories   | Tools  |                  |                              |
|   | Screwdriver for cross-slotted screws, 72-7894-95<br>Special wrench for fuel system<br>Flat-nose pliers |                  |                              |

SECRET/NO FOREIGN DISSEM

*Poor Original*

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |  |                              |
|---|---|--|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHECK No. 4   |  | In 3 sheets<br>Sheet 1       |
| FUEL SYSTEM   | INSPECTION OF DROP FUEL TANK GAUGE FILTER   |  | Man-hours<br>required - 0.30 |
| Procedure   | Technical requirements  | Fault correction   |                              |
| 1. Drain fuel from drop tank (Fig. 5) into clean container or refueller.<br>2. Unlock and screw plug out of drop tank drain hole.<br><br>3. Wash gauge filter with clean gasoline and blow with compressed air. | <u>WARNING.</u> Screw out plug with special wrench; never use additional lever for unscrewing since otherwise welded joint of tank filler neck is likely to get damaged.<br><br>If plug of drain hole fails to be screwed out with wrench, remove upper plug of tank, fill tank with 5 litres of clean kerosene and rinse tank. Inspect gauge filter through tank upper filler neck and make sure it is intact.<br><br>Filter should be clean, its filtering gauge and soldered joint should be free from damage. | Replace filter with damaged filtering gauge or soldered joint. |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM  
in 3 sheets  
Sheet 1

Supplement to the section  
Guide No. 21

PROCESS CHART No. 1




FIG. 5. DROP TANK WITH PYLON.  
 1 - drop tank; 2 - pylon; 3 - vertical pipe connection; 4 - fuel vent; 5 - vent  
 hole; 6 - ground connection system; 7 - fuel valve; 8 - partition; 9 - vent  
 screen; 10 - fuel nozzle; 11 - ground; 12 - attachment of rear support  
 strut; 13 and 14 - floor and rear strut; 15 - panel of access hole leading to  
 fuel venting pipe; 16 - fuel nozzle; 17 - oxygen pressure sensor; 18 -  
 explosive pressure indicator; 19 - fuel venting pipe; 20 - ground safety  
 pin; 21 - rear support pin; 22 - ground clearance mark of tank; 23 - corner  
 brace; 24 - support of anchor pin.

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM



|   |   |                  |                              |
|---|---|------------------|------------------------------|
| Reference to Inspection<br>Guide No.21  | PROCESS CRAFT No.4                              |                  | In 3 sheets<br>Sheet 3       |
| FUEL SYSTEM   | INSPECTION OF D50P FUEL TANK GAUGE FILTER       |                  | Man-hours<br>Required - 0.20 |
| Procedure   | Technical requirements                          | Fault correction |                              |
| 4. Inspect filter<br>5. Make sure that tank bottom and<br>area around drain hole are free from<br>dirt and sediment<br>6. Re-install filter, screw in plug<br>and secure it with locking wire KOK-0.6 |   |                  |                              |
| Accessories   | Tools   |                  |                              |
|   | Special wrench, 72-7804-360<br>Flat-nose pliers |                  |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


|  |   |  |
|--|---|--|
| Supplement to Inspection<br>Guide No. 21   | <b>PROCESS CHART No. 5</b>  | In 3 sheets<br>Sheet 1   |
| <b>FUEL SYSTEM</b>   | INSPECTION OF NEGATIVE-8 VALVE AND INTERIOR OF FUEL TANK No. 3  |  |
| <b>Procedure</b>   | <b>Technical requirements</b>   | <b>Parts connection</b>  |
| <ol style="list-style-type: none"> <li>1. Remove drop fuel tank and drop tank pipes</li> <li>2. Disconnect hydraulic cylinder and free left air brake and lift air brake</li> <li>3. Open cover of access hole leading to pump of tank No. 3 (on fuselage port side between frames Nos 16 and 20)</li> <li>4. Unlock and disconnect electric connection of pump 495A2 (Ref. No. 2 in Fig. 6)</li> <li>5. Disconnect fuel pipeline running from pump 495A2 to engine; to this end unlock and cover off four nuts and reserve bolts</li> <li>6. Disconnect the drain pipes from the connection 4 mounted on connection pipe of pump 495A2</li> <li>7. Disconnect fuel pipe and electric connection from warning unit CE-3, cover off fastening bolt of bracket 2 (Fig. 7) of warning unit and remove warning unit together with bracket</li> <li>8. Unlock and cover off bolts 4 which attach plate 5 of negative-8 valve</li> </ol> | 100% Carry out maintenance operations with tanks empty<br><br><br><br> | FIG. 6. GENERAL VIEW OF FUEL PUMP 495A<br>1 - pump 495A2; 2 - electric connection of pump<br>3 - engine fuel supply pipeline; 4 - nut<br>FIG. 7. ATTACHMENT OF PRESSURE WARNING UNIT CE-3<br>1 - pressure warning unit CE-3; 2 - warning unit mounting bracket; 3 - negative-8 valve plate; 4 - bolts attaching valve plate to tank edging; 5 - pressure warning unit, type CE-3 |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 23   | PROCESS CHART No. 5   |   | In 3 sheets Sheet 2       |
|---|---|---|---------------------------|
| FUEL SYSTEM   | INSPECTION OF NEGATIVE-G VALVE AND INTERIOR OF FUEL TANK No. 3  |   | Man-hours required - 1.00 |
| Procedure   | Technical requirements  | Fault correction  |                           |
| <p>9. Hook slightly pipe union of pump #5512 to carefully lower plate with negative-G valve (Fig. 8)</p> <p>10. Using extension lamp inspect (through inspection hole in tank No. 3 of negative-G valve) tank interior and make sure that tank walls are neither scuffed nor laminated and that there is no sediment on tank bottom.</p> <p>When through with inspection of tank interior close access hole with cover and out of this duralumin sheet to match negative-G valve plate. Attach cover with four screws</p> <p>11. Inspect to make sure that elements and locking fittings of negative-G valve assemblies are intact and that inner space is clean. Check sealing rubber in valve seat (Fig. 8) for condition. Inspect point at which weight hangs on valve body</p> <p>12. Check operation of negative-G valve mechanism to this end turn valve handle clockwise over by 180° to inverted position of aircraft</p> | <p><b>Note.</b> Perform operations with fuel drained off tanks</p> <p>Tank walls should be even (but for glued joints); there should be neither spot corrosion nor lamination of walls. Tank bottom should be free from sediment (sludge or solidified fluid or metal dust)</p> <p>Clearance between weight and valve body in normal (non-inverted) position should be not smaller than 2 mm. Sealing rubber should be intact; no crumbling of rubber shall be tolerated. At weight bumping points no metal separation shall be present. In inverted position valve mechanism should tighten close after opening so seats, valve should move smoothly in its guides, without sticking</p> |  <p>FAC &amp; NEGATIVE-G VALVE ASSEMBLY WITH FULL PLATE GSA</p> <p>1 - pump GSA, 2 - valve plate, 3 - cover, 4 - weight, 5 - fuel drain for negative-G flying conditions</p> <p>If clearance is less than 2 mm file weight.</p> <p>Replace rubber if cracked or crumbled.</p> |                           |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM



|   |   |                              |
|---|---|------------------------------|
| Subjacent to Inspection Guide No. 21  | PROCESS CHART No. 5   | Is 3 sheets<br>Sheet 3       |
| FUEL SYSTEM   | INSPECTION OF NEGATIVE-G VALVE AND INTERIOR OF FUEL TANK No. 3  | Man-hours<br>required - 4.00 |
| <b>Procedure</b>  | <b>Technical requirements</b>   | <b>Fault correction</b>      |
| <p>13. Check drain cock on negative-G valve plate</p> <p>14. Check airtightness at valve seat, in inverted position (valve closed by gravity) at air pressure of 0.2 kg/cm<sup>2</sup> inside valve body during 5 minutes</p> <p>15. Install plate with negative-G valve in tank. Before installation, inspect tank walls in area of valve weight travel for absence of corrugation since corrugation may result in valve binding. No corrugation in this area shall be tolerated</p> | <p>Valve should be absolutely airtight</p> <p><b>Note:</b> Clearance between pump shroud (hood) and valve body should be not smaller than 1 mm</p>  |                              |
| <b>Accessories</b>  | <b>Tools</b>  |                              |
|   | <p>Wrenches, 5 x 7; 9 x 11; 14 x 17; 9 x 11 (socket wrench)</p> <p>Flat-screw pliers</p> <p>Screwdrivers: ordinary and for cross-slitted screws</p> |                              |


50X1-HUM

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |  |
|--|---|--|
| Supplement to Inspection<br>Guide No.21  | PROCESS CHART No. 6   | In 3 sheets<br>Sheet 1                         |
| FUEL SYSTEM  | INSPECTION OF FLOAT VALVES OF TANKS Nos 1 AND 3   | Man-hours<br>required - 3.00                   |
| Procedure  | Technical requirements  | Fault correction                               |
| 1. Drive out screws and demount assembly near section to obtain access to float valve plate of tank No.1<br>2. Open cover of fuel tank No.3 (on fuselage port side)<br>3. Unlock and disconnect control and vent pipelines from tanks Nos 1 and 3<br>4. Unlock and screw out bolts which attach float valve plates of tanks Nos 1 and 3<br>5. Carefully rocking pipe unions remove valve plates of tanks Nos 1 and 3 (Fig.9) |  <p>FIG. 9 FLOAT VALVE OF TANK No. 1 COMPLETE WITH PLATE (PLATE REMOVED FROM TANK)<br/>                 1 - float valve, 2 - control pipe union, 3 - vent pipe union<br/>                 Note: When air is supplied to valve at pressure of 0 to 1.5 kg/cm<sup>2</sup>, no air bubbles are allowed</p> | Replane valves with corroded and damaged parts |
| 6. Inspect parts of float valves to make sure that they are free from corrosion and mechanical damage<br>7. Check float valve for airtightness to this end:<br>(a) shut off one of valve pipe unions<br>(b) supply air pressure to other union   | Corroded and damaged parts will not be tolerated  | Replane valves with corroded and damaged parts |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 6   |   | In 3 sheets sheet 2       |
|---|---|---|---------------------------|
| FUEL SYSTEM   | INSPECTION OF FLOAT VALVES OF TANKS NOS 1 AND 3   |   | Man-hours required - 3.00 |
| Procedure   | Technical requirements  | Fault correction  |                           |
| <p>(b) immerse valve into water and, holding float in lower position (ball valves are closed), build up air pressure of 0 to 1.5 kg/cm<sup>2</sup>.</p> <p>In case of bubbling check valve additionally for airtightness by fuel; to this end fill benzene into valve body and build up pressure of 0 to 1.5 kg/cm<sup>2</sup>.</p> | <p>If bubbles are detected, test valve additionally.</p> <p>When air is supplied during 1 minute at 0 to 1.5 kg/cm<sup>2</sup> to benzene-filled valve, the valve under test is considered airtight if its leakage is not heavier than 10 drops per minute.</p> | <p>In case of poor airtightness of valve amount it and transfer to repair workshop.</p> |                           |
|   |   |   |                           |
| <p>FIG. 16. CHECKING FLOAT VALVE FOR AIRTIGHTNESS</p> <p>1 - test stand; 2 - stop; 3 - pressure gauge; 4 - control valve; 5 - measuring device; 6 - container for fuel.</p>   |   |   |                           |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


|   |  |                  |                              |
|---|--|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 6  |                  | In 3 sheets<br>Sheet 3       |
| FUEL SYSTEM   | INSPECTION OF FLOAT VALVES OF TANKS NOS 1 AND 5  |                  | Man-hours<br>required - 3.00 |
| Procedure   | Technical requirements   | Fault correction |                              |
| 8. Using extension lamp, inspect<br>(through plate hole) tank walls for con-<br>dition and make sure that tanks are free<br>from foreign objects<br>9. Re-install plates of float valves,<br>tighten and lock bolts<br>10. Connect and lock pipelines |  |                  |                              |
| Accessories   | Tools  |                  |                              |
| Extension lamp<br>Device for air supply at 0 to 1.5 kg/cm <sup>2</sup> to float valve<br>(See Diagram in Fig. 2)  | Screwdriver for cross-slitted bolts and ordinary screwdriver<br>200 mm<br>Socket wrench, 9 x 11, and nut wrenches, 14 x 17; 19 x 22;<br>24 x 27 and 22 x 26<br>Flat-nose pliers<br>Wrench for round nuts 3106-85 |                  |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |                  |                              |
|--|--|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 7  |                  | In 2 Blocks<br>Sheet 1       |
| FUEL SYSTEM  | DRAINAGE OF SEDIMENT AND NON-EXPENDABLE FUEL<br>REMAIN FROM WING FUEL COMPARTMENTS   |                  | Man-hours<br>required - 1.00 |
| Procedure  | Technical requirements   | Fault correction |                              |
| <p>1. Drain fuel from wing compartments through drain cock of main fuel line, to this end:</p> <ul style="list-style-type: none"> <li>(a) ground aircraft and containers into which fuel is being drained;</li> <li>(b) open filler neck of tank No. 2;</li> <li>(c) open left access panel of engine to obtain access to drain cock, connect fuel drain hose to drain cock, stretch hose toward container for drainage and open cock (Fig. 11);</li> <li>(d) switch on ground electric supply source and engage pump II of service tank group and wing fuel compartment pump.</li> </ul> <p>2. Drain sediment and non-expendable fuel remain from wing tanks; to do this, the following operations should be performed in turn on each wing:</p> <ul style="list-style-type: none"> <li>(a) unlock drain plug;</li> <li>(b) screw special device for wing fuel tank drain plugs into plug seat (Fig. 12);</li> <li>(c) rack up wing opposite to that which is fitted with drain plug device (lift wing by 200 mm);</li> </ul> |  <p>FIG. 11. DRAINING FUEL FROM TANKS<br/>                 1 - drain cock; 2 - fuel drain hose.</p> |                  |                              |


SECRET/NO FOREIGN DISSEM

Peer Original



SECRET/NO FOREIGN DISSEM

50X1-HUM



|   |  |  |                           |
|---|--|--|---------------------------|
| Supplement to Inspection Guide No. 21   | PROCESS-CHART No. 7  |  | In 2 sheets<br>Sheet 2    |
| FUEL SYSTEM   | DRAINAGE OF SEDIMENT AND NON-EXPENDABLE FUEL REMAINS FROM WING FUEL COMPARTMENTS     |  | Man-hours required - 1.00 |
| Procedure   | Technical requirements   | Fault correction   |                           |
| (d) using device screw out plug and drain fuel remain into specially prepared container<br><br>NOTE: Before carrying out operation under item 2 open filler neck of tank No. 2 and ground drainage container and aircraft as in item 1. |  |  |                           |
| Accessories   |  | Tools  |                           |
| Fuel drain hose (72-7604-320)<br>Device for drain plugs of wing fuel compartments (72-7804-370)   |  | Wrench, 24 x 27<br>Screwdriver, 200 mm<br>Flat-nose pliers |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |   |                         |
|---|---|---|-------------------------|
| Supplement to Inspection Guide No. 22   | PROCESS CHART No. 8   |   | In 2 sheets<br>Sheet 1  |
| FUEL SYSTEM   | INSPECTION OF BIG FUEL TANKS AND LOWER SECTIONS OF FUEL SYSTEM PART FOR PROPER CONDITION AND RELIABLE ATTACHMENT  |   | Man-hours required-1.50 |
| Procedure   | Technical requirements  | Fault correction  |                         |
| <p>1. Turn out screws attaching panels of access holes which lead to tank attachment studs at fuselage port and starboard sides and in superstructure section; then open access panels (Figs 13 and 14)</p> <p>Note: To demount fuel tanks act as follows:</p> <p>(a) Turn out access panel attachment screws of fuel tanks at upper and lower fuselage port and starboard sides (Fig. 13);</p> <p>(b) Detach attachment rods of fuel tank access panels (Fig. 15).</p> <p><b>WARNING</b></p> <p>Do not open access panels of tanks for 4, 5 and 6 until attachment rods are removed since otherwise access panel hinge loops will be sheared.</p> <p>2. Remove access panels of tanks Nos. 4, 5 and 6.</p> <p>Do check to see if there are any cracks, signs or tank attachment studs.</p> |  <p>FIG. 13 LAYERS OF FUSELAGE STARBOARD SIDE ACCESS HOLES LEADING TO FUEL TANK ATTACHMENT RODS AND OF FUEL TANK ATTACHMENT PANEL ATTACHMENT SCREWS.</p> <p>Note should be tightly craned and reliably locked on studs as shown in Fig. 14.</p> |  <p>FIG. 14 GENERAL VIEW OF FUEL TANK ATTACHMENT TO FUSELAGE PORT SIDE.</p> <p>Fig. 14 - Section 1 - Tanking view 224.</p> |                         |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |   |                            |
|---|---|---|----------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 4   |   | In 2 sheets<br>Sheet 2     |
| FUEL SYSTEM   | INSPECTION OF BAG FUEL TANKS<br>AND LOWER PORTION OF FUEL SERVICE TANK<br>FOR PROPER CONDITION AND RELIABLE ATTACHMENT            |   | Man-hours<br>required-1.50 |
| Procedure   | Technical requirements  | Fault correction  |                            |
| <p>4. Check safety fittings on nuts for condition</p> <p>5. Re-install panels of access holes leading to attachment studs and secure them with screws</p> <p>6. Turn out screws which attach access panel of fuel service tank lower section (from fuselage port side, in landing gear leg well)</p> <p>7. Looking through access hole check condition of service fuel tank lower section</p> <p>8. Re-install and secure with screws access hole cover</p> | <p>Inner walls of fuel tank should be free from cracks, spots of attrition, as well as from lamination and swelling of rubber</p> | <p>Should cracked surface, attrition resulting in exposure of fabric, lamination or swelling of rubber be detected, discard faulty tank and install new one</p> |                            |
| Accessories   | Tools   |   |                            |
|   | <p>Screwdriver for cross-slotted screws</p> <p>Multi-purpose flat-nose pliers</p> <p>Wrench, 9 x 11</p> <p>Screwdriver</p>        |   |                            |

SECRET/NO FOREIGN DISSEM

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                            |
|---|---|----------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CH - 21 No. 9   | In 2 sheets<br>Sheet 1     |
| FUEL SYSTEM      REMOVING GASOLINE SYSTEM PRESSURIZATION UNIT AND DUST FILTER   |   | Man-hours<br>required-1.00 |
| <b>Procedure</b><br><br>1. Unlock and turn two nuts off gasoline system pressurization pipelines<br><br>2. Screw two nuts off bolts which fasten pressurization unit yokes<br>3. Carefully bring yokes apart and remove pressurization unit from yokes<br><br><i>Note:</i> In case of failure to dismount pressurization unit remove retaining valve at the left side<br><br>4. Remove spring ring and withdraw dust filter from pressurization unit<br>5. Wash filter in clean gasoline and dry<br>6. Drain condensate from pressurization unit cylinder | <b>Technical requirements</b><br><br><i>Note:</i> Gasoline system pressurization unit is installed on rear wall of right L-30 leg well where it is attached by means of two yokes | <b>Fault correction</b>    |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                  |                            |
|--|---|------------------|----------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 9   |                  | In 2 sheets<br>Sheet 2     |
| FUEL SYSTEM  | REPAIRING GASOLINE SYSTEM PRESSURIZATION UNIT AND FUEL FILTER         |                  | Man-hours<br>required-1.00 |
| Procedure  | Technical requirements  | Fault correction |                            |
| <p>7. Insert filter in cylinder and install spring ring</p> <p>8. Install pressurization unit back in place (the arrow on cylinder should be directed upward), fasten it in position with screws, connect pipes and secure pipe nuts</p> |   |                  |                            |
| Accessories  | Tools   |                  |                            |
|  | <p>Wrenches, 14 x 17; 19 x 22 and 9 x 11.</p> <p>Flat-nose pliers</p> |                  |                            |

31

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 12  |                  | In 4 sheets<br>Sheet 1     |
|--|---|------------------|----------------------------|
| FUEL SYSTEM  | CHECKING FUEL SYSTEM, OXYGEN SYSTEM<br>AND HYDRAULIC RESERVE PRESSURIZATION<br>SYSTEM PIPELINE FOR AIRTIGHTNESS   |                  | Man-hours<br>required-1.00 |
| Procedure  | Technical requirements  | Fault correction |                            |
| <p><u>Checking Airtightness of Fuel System</u></p> <ol style="list-style-type: none"> <li>1. Operate through lower access hole (at left, between frames Nos 25 - 26) to close cut-off valve of fuel system</li> <li>2. On starboard side of fuselage tail section (above flap), in metal screen-protected recess, disconnect two valves of main tank pressurization system; plug disconnected ends</li> <li>3. Use rubber plug to shut off end of pipe which runs from sealed box of drop tank pressurization system safety valve over fuselage skin on port side, fore of engine oil filler neck</li> <li>4. Operating through access hole on fuselage port side between frames Nos 25 - 26, disconnect hydraulic system pressurization pipe and engine air intake pipe from four-way connection; plug pipe unions</li> </ol> | <p>Fuel system should be checked for airtightness:</p> <ol style="list-style-type: none"> <li>(a) with fuel tanks filled to capacity;</li> <li>(b) with excessive air pressure in pressurization system of 0.3 kg/cm<sup>2</sup>; excessive air pressure is built up with the aid of special device;</li> <li>(c) with drop tank and pylon removed. Fuel pipeline of air pressurization system on fuselage should be closed with special plugs</li> </ol> |                  |                            |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                              |
|---|---|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 19  |                  | No. 4-42000<br>Sheet 2       |
| FUEL SYSTEM   | CHECKED FUEL SYSTEM, GASOLINE SYSTEM<br>AND HYDRAULIC RESERVOIR DEMONSTRATION<br>SYSTEM PROCEDURES FOR AIRCRAFT |                  | Non-Aircrew<br>required-1.00 |
| Procedure   | Technical requirements  | Fault correction |                              |
| 5. Using rubber plug close drain<br>pipe which runs from drain (circular)<br>pipeline over fuselage skin, down at<br>frame No. 29.<br>6. All drain cocks of pumps and<br>system should be closed.<br>7. Connect pipeline with rubber plug<br>(running from ground installation) to<br>fuel system vent connection pipe located<br>to the left on superstructure section aft<br>of frame No. 28A.<br>8. Insert rubber plug of device<br>E6-9820-00 in pressure head air intake<br>connecting pipe.<br>9. Build up air pressure of<br>1.0 kg/cm <sup>2</sup> in system and maintain this<br>pressure during 15 minutes. | Air pressure drop and excessive<br>leakage shall not be tolerated.  |                  |                              |
| <u>Checking Airtightness of Gasoline System<br/>and Hydraulic Reservoir<br/>Pressurization Pipeline</u>   |   |                  |                              |
| 1. Fill tank with gasoline and<br>install special pressure gauge-fitted<br>cover on tank filler neck  |   |                  |                              |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 10  |                  | In 4 sheets Sheet 3      |
|---|---|------------------|--------------------------|
| FUEL SYSTEM   | CHECK: FUEL SYSTEM, GASOLINE SYSTEM AND HYDRAULIC RESERVOIR PRESSURIZATION SYSTEM PIPELINE FOR AIRTIGHTNESS |                  | Man-hours required - 1.2 |
| Procedure   | Technical requirements  | Fault correction |                          |
| <p>2. Remove hydraulic reservoir filler neck cover from hydraulic booster chamber (at fuselage port side) and install new cover provided with pressure gauge; before doing this, check level of hydraulic fluid AMF-10 in reservoir</p> <p>3. Operating through left-hand engine access hole (down, at frame No. 27), disconnect pressurization pipe running to gasoline tank and hydraulic reservoir from four-way connection. Connect hose with adapter together with wheel tube inflation device to tube</p> <p><b>Note.</b> If it is only gasoline system which is being checked for airtightness, it is necessary to operate through access hole down at fuselage port side (at frame No. 20) to disconnect from two-connection that pipe which is used for hydraulic reservoir pressurization; then the corresponding end of two-connection should be plugged</p> <p>4. Connect air-charged ground bottle to device, open bottle valve with retaining valve remaining closed, and, slowly</p> |   |                  |                          |

SECRET/NO FOREIGN DISSEM

Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |   |                              |
|--|---|---|------------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 10  |   | In 4 sheets<br>Sheet 4       |
| FUEL SYSTEM  | CHECKING FUEL SYSTEM, GASOLINE SYSTEM<br>AND HYDRAULIC RESERVOIR PERFORMANCE<br>SYSTEM PIPELINE FOR AIRTIGHTNESS  |   | Man-hours<br>required - 1.00 |
| <p>Procedure</p> <p>opening reducing valve, build up 10 kg/cm<sup>2</sup> pressure</p> <p>5. Make sure that gasoline tank pressure gauge reads 0.4<sup>+0.05</sup> kg/cm<sup>2</sup>, and hydraulic reservoir pressure gauge indicates 1.6 to 2.45 kg/cm<sup>2</sup>; then close reducing valve and maintain this pressure in system during 15 min</p> <p>6. Restore initial pressure in system</p> <p>7. Open fuel cut-off cock and lock it with KOK-0.8 wire</p> <p>8. With engine control lever in CUT-OFF (C/OFF) position, engage all fuel system pumps for 5 to 10 minutes</p> | <p>Technical requirements</p> <p>Neither decrease in pressure indications nor gasoline leakage at pipe joints shall be tolerated</p> <p>Leakage of kerosene from pipeline joints and vent system is not permissible</p> | <p>Fault correction</p>   |                              |
| <p>Accessories</p> <p>Plug for fuel pipeline used when pylon is removed (IS-6100-2825)</p> <p>Airtightness test fixture for cockpit and fuel system (IS-2520-00)</p>   |   | <p>Tools</p> <p>Screwdriver for cross-slotted screws</p> <p>Wrenches, 27; 19 x 22; 14 x 17 and 46</p> <p>Flat-nose pliers</p> |                              |


35

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


| Appendix to Inspection Guide No. 21   | PROCESS CHART No. 11   |  | In 3 sheets Sheet 1       |
|---|--|--|---------------------------|
| FUEL SYSTEM   | CHECKING PRE-OPERATION VALVES IN FUEL, GASOLINE AND HYDRAULIC SYSTEMS WITH SPECIAL EQUIPMENT. CHECKING AMOUNT OF FUEL IN FUEL COMPARTMENTS OF AIRCRAFT BODIES WITH SPECIAL NO. 0005  |  | See-Chart required - 6, 7 |
| Procedure   | Technical requirements   | Fault correction   |                           |
| <p>1. Open covers of access holes and filler necks of fuel (kerosene and gasoline) tanks and hydraulic reservoir and fill them with fuel (kerosene and gasoline) and MK-10 hydraulic fluid</p> <p>2. Tightly close filler neck covers of fuel tanks and hydraulic reservoir (with the exception of covers specified in item 3 below)</p> <p>3. Install special caps with pressure gauges (see Figs 16 and 17) in place of caps of filler neck of fuel tank No. 4, filler neck of gasoline tank, filler neck of drop tank and filler neck of hydraulic booster chamber (at the left side) or of hydraulic reservoir main</p> | <p>During pressurization valve checks fuel tanks (both kerosene and gasoline) should be filled to capacity:</p> <ul style="list-style-type: none"> <li>- fuel level in fuselage and drop fuel tanks should be below lower edge of filler necks by 20 to 30 mm in summer and 10 to 20 mm in winter;</li> <li>fuel level in gasoline tank should be below lower edge of filler neck by 40 mm in winter and in summer;</li> <li>- hydraulic system reservoir (its both sections) should be fully charged (within the limits of dip stick or gauge glass divisions)</li> </ul> |  <p>FIG. 16. INSTALLING PRESSURE GAUGES IN PLACE OF FILLER NECK COVERS IN GASOLINE AND KEROSENE TANKS</p> |                           |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 11  |  | In 3 sheets Sheet 2       |
|--|---|--|---------------------------|
| FUEL SYSTEM  | CHECKING PRESSURIZATION VALUE IN FUEL, GASOLINE AND HYDRAULIC SYSTEMS WITH ENGINE RUNNING. CHECKING HEIGHT OF PRESSURIZATION IN WING FUEL COMPARTMENTS OF AIRCRAFT ENGINEING WITH SERIAL NO. 0619   |  | See hours required - 0.30 |
| Procedure  | Technical requirements  | Fault correction   |                           |
| <p>4. Start engine and make it run at 70 - 85% normal rating. At this rating drop tank fuel consumption indicator light should go out</p> <p>5. Check pressurization value by pressure gauge installed in tank filler neck</p> | <p>Pressurization air pressure should be:</p> <ul style="list-style-type: none"> <li>- in tank No. 4 - 0.21-0.23 kg/cm<sup>2</sup></li> <li>- in gasoline tank - 0.4-0.5 kg/cm<sup>2</sup></li> <li>- in drop tank 0.81 - 0.83 kg/cm<sup>2</sup></li> <li>- in hydraulic reservoir - 1.60 - 2.45 kg/cm<sup>2</sup></li> </ul>  <p>FIG. 11. INSTALLING PRESSURE GAUGE IN PLACE OF HYDRAULIC RESERVOIR FILLER NECK COVER</p> | <p>If tank pressurization value is lower than specified, act as follows:</p> <ul style="list-style-type: none"> <li>- detect point of air leakage from system by application of soapy water at pipeline connections and manually</li> <li>- correct fault by tightening joints (before doing this bleed air from system by gradually screwing off filler neck caps)</li> </ul> |                           |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |   |                             |
|---|---|---|-----------------------------|
| Supplement to Inspection<br>Order No. 21  | PROCESS CHART No. 11  |   | In 3 sheets<br>Sheet 3      |
| FUEL SYSTEM   | CHECKING PRESSURIZATION VALVE IN FUEL, GASOLINE AND HYDRAULIC SYSTEMS WITH ENGINE RUNNING. CHECKING LEAKS OF PRESSURIZATION IN WING FUEL COMPARTMENTS OF AIRCRAFT EQUIPPED WITH SERIAL No. 0615   |   | Man-hours<br>required - 4.5 |
| <b>Procedure</b>  | <b>Technical requirements</b>   | <b>Fault correction</b>   |                             |
| 6. Reduce engine speed to idling rating and run it at this rating for 1 min.  | Pressure should drop to not lower than:<br>(a) 0.17 kg/cm <sup>2</sup> in tank No. 4;<br>(b) 0.41 - 0.45 kg/cm <sup>2</sup> in wing fuel compartments (for aircraft beginning with Serial No. 0615)   |   |                             |
| 7. Stop engine. Fifteen minutes after engine stoppage, check air pressure in gasoline tank and hydraulic reservoir                                | In 15 minutes after engine stoppage, air pressure should be:<br>(a) 0.4 <sup>+0.05</sup> kg/cm <sup>2</sup> in gasoline tank;<br>(b) 1.6 to 2.45 kg/cm <sup>2</sup> in hydraulic reservoir.<br>If the above requirements are observed, pressurization system is considered operative and airtight | It is not advisable to tighten up of pipeline connections with system pressurized |                             |
| <b>Accessories</b>  | <b>Tools</b>  |   |                             |
| Fixture for checking pressurization of main and drop fuel tanks, and of hydraulic system reservoir (CM-92199-00, 96-9362-00)<br>Drop tank trolley | Filters, flat-nose  |   |                             |

36

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                           |
|---|--|------------------|---------------------------|
| Supplement to Inspection Guide No. 21   | PROCEDURE CHART No. 12   |                  | In 3 sheets<br>Sheet 1    |
| FIRE-FIGHTING SYSTEM  | CHECKING FIRE-FIGHTING SYSTEM UNITS AND PIPELINES FOR CONDITIONS AND ATTACHMENT  |                  | Man-hours required - 0.10 |
| Procedure   | Technical requirements   | Fault correction |                           |
| 1. Check the following units and pipelines of fire-fighting system for proper condition and attachment:<br>(a) fire extinguisher cylinder attached between frames Nos 21 and 22;<br>(b) discharge ring (if engine is removed, check orifices for cleanliness);<br>(c) pipelines running from fire extinguisher cylinder to discharge ring;<br>(d) fire detectors (thermocouples). | Once used (in fire fighting or accidentally), fire extinguisher should be removed from aircraft and transferred for recharging.<br>When replacing fire extinguisher (no matter charged or discharged) from aircraft, screw cap with hose on to operating connection. Fit cap over connection immediately upon disconnection of pipeline; this done, dismount fire extinguisher from bracket.<br>Fire cylinder surface should be clean and properly painted.<br>Pipelines should have no frayed spots deeper than 0.2 mm. Cylinder mounting bracket should be free from cracks. |                  |                           |
| 2. Check continuity of electric circuit between fire extinguisher operating button and fire extinguisher cylinder discharge switch (carry out the check alternatively with electrical equipment maintenance specialists); to this end:<br>(a) in cockpit, close STORAGE BATTERY MAIN SWITCH (AUGMENTED MOTOR).  |  |                  |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                  |                             |
|--|---|------------------|-----------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 12  |                  | In 3 sheets<br>Sheet 2      |
| FIRE-FIGHTING SYSTEM   | CHECKING FIRE-FIGHTING SYSTEM UNITS AND<br>PIPELINES FOR CORRECTNESS AND ATTACHMENT |                  | Man-hours<br>required - 0.2 |
| Procedure  | Technical requirements  | Fault correction |                             |
| <p>ASPOFOM.) circuit-breaker on right-hand console and FIRE-FIGHTING EQUIPMENT CIRCUIT BREAKER, CUTOFF VALVE (CVALP, CR, EPUMBOCSKIL, OGRAP, REP, IFAE) circuit-breaker on left-hand front control board;</p> <p>(b) insert 2 - 3 megohm resistor between pipe (fire detector) and air-frames: this should result in operation of EC-2 electronic amplifier, and in illumination of FIRE (OGRAP) indicator light.</p> <p>When resistor of 5 megohms is introduced, EC-2 amplifier does not operate</p> |   |                  |                             |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                           |     |     |     |     |    |     |     |     |     |     |     |                    |    |    |    |    |    |    |    |    |    |    |    |     |  |  |  |
|---|--|------------------|---------------------------|-----|-----|-----|-----|----|-----|-----|-----|-----|-----|-----|--------------------|----|----|----|----|----|----|----|----|----|----|----|-----|--|--|--|
| Supplement to Inspection Guide No. 22   | PROCESS CHART No. 12   |                  | In 3 sheets Sheet 3       |     |     |     |     |    |     |     |     |     |     |     |                    |    |    |    |    |    |    |    |    |    |    |    |     |  |  |  |
| FIRE-FIGHTING SYSTEM  | CHECKING FIRE-FIGHTING SYSTEM WIRING AND PIPELINES FOR CORROSION AND ATTACHMENT  |                  | Man-hours Required - 0.10 |     |     |     |     |    |     |     |     |     |     |     |                    |    |    |    |    |    |    |    |    |    |    |    |     |  |  |  |
| Procedure   | Technical requirements   | Fault correction |                           |     |     |     |     |    |     |     |     |     |     |     |                    |    |    |    |    |    |    |    |    |    |    |    |     |  |  |  |
| <p>3. Remove and check fire extinguisher cylinders for proper charging by weighing them at charging station.</p> <p>4. Re-install fire extinguisher cylinders and connect electric wires and pipelines from discharge ring to them.</p> | <p>Cylinder pressure should be as specified below:</p> <table border="1"> <tr> <td>°C</td> <td>-55</td> <td>-45</td> <td>-35</td> <td>-25</td> <td>-15</td> <td>-5</td> <td>0</td> <td>+5</td> <td>+15</td> <td>+25</td> <td>+35</td> <td>+45</td> </tr> <tr> <td>kg/cm<sup>2</sup></td> <td>30</td> <td>35</td> <td>40</td> <td>45</td> <td>50</td> <td>55</td> <td>60</td> <td>65</td> <td>70</td> <td>80</td> <td>90</td> <td>100</td> </tr> </table> | °C               | -55                       | -45 | -35 | -25 | -15 | -5 | 0   | +5  | +15 | +25 | +35 | +45 | kg/cm <sup>2</sup> | 30 | 35 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 80 | 90 | 100 |  |  |  |
| °C  | -55  | -45              | -35                       | -25 | -15 | -5  | 0   | +5 | +15 | +25 | +35 | +45 |     |     |                    |    |    |    |    |    |    |    |    |    |    |    |     |  |  |  |
| kg/cm <sup>2</sup>  | 30   | 35               | 40                        | 45  | 50  | 55  | 60  | 65 | 70  | 80  | 90  | 100 |     |     |                    |    |    |    |    |    |    |    |    |    |    |    |     |  |  |  |
| Accessories   | Tools  |                  |                           |     |     |     |     |    |     |     |     |     |     |     |                    |    |    |    |    |    |    |    |    |    |    |    |     |  |  |  |
|   | Multi-purpose flat-nose pliers<br>Screwdriver  |                  |                           |     |     |     |     |    |     |     |     |     |     |     |                    |    |    |    |    |    |    |    |    |    |    |    |     |  |  |  |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 15  |                  | In 20 above Sheet 1      |
|--|---|------------------|--------------------------|
| HYDRAULIC SYSTEM   | CHANGING AMP-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEMS, REPLACEMENT OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS  |                  | Man-hours required - 1.5 |
| Procedure  | Technical requirements  | Fault correction |                          |
| <p><u>Drainage AMP-10 Fluid from Hydraulic Systems</u></p> <ol style="list-style-type: none"> <li>1. Jack aircraft up so as to obtain clearance not smaller than 50 cm between ground and wheels</li> <li>2. Connect ground electric power supply source</li> <li>3. In cockpit: close circuit-breakers of landing gear, flaps, air brakes and aileron hydraulic boosters</li> </ol> | <p>Hydraulic fluid in hydraulic systems should be changed for the first time after first 2500 flying hours, without desounting and washing of hydraulic reservoir</p> <p>Subsequent changing of hydraulic fluid in hydraulic systems which involves desounting and washing of hydraulic reservoir should be carried out after every 200 flying hours (2 years of operation)</p> |                  |                          |

SECRET/NO FOREIGN DISSEM

Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21  |   | PROCEDURE No. 13  | In 20 checks<br>Sheet 2      |
|---|---|---|------------------------------|
| HYDRAULIC SYSTEM  |   | CHANGING ANT-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEM. REPLACEMENT OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS | Man-hours<br>required - 3.00 |
| Procedure   | Technical requirements  | Fault correction  |                              |
| <p>4. Connect ground hydraulic pump to main hydraulic system and build up pressure of 200 - 210 kg/cm<sup>2</sup></p> <p><b>WARNING.</b><br/>Before retracting landing gear and extending air brakes and flaps make sure that there is nobody staying near landing gear, air brakes and flaps. As a measure of protection, give order: KEEP AWAY FROM LANDING GEAR (KEEP AWAY FROM AIR BRAKES, KEEP AWAY FROM FLAPS); start retraction procedure only after the order has been acknowledged</p> | <p><b>Note.</b> Following dirt prevention measures should be taken:<br/>(a) before connecting ground pump wash aircraft connections and hose tips with clean gasoline;<br/>(b) upon completion of ground pump operation, thoroughly wipe aircraft connections and hose tips, and close them with their respective plugs</p> |   |                              |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 13   |                  | Lo 2<br>Elev.    |
|---|--|------------------|------------------|
| HYDRAULIC SYSTEM  | CHANGING ANT-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEMS, REPLACEMENT OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS |                  | Sub-<br>require. |
| Procedure   | Technical requirements   | Fault correction |                  |
| 5. Retract landing gear, extend air brakes and flaps, and disengage ground hydraulic pump (for more effective cleaning of system repeat this procedure several times) |  |                  |                  |
| 6. Reduce pressure in main hydraulic system to zero by moving aircraft control stick forward and backward   |  |                  |                  |
| 7. Disconnect hoses of ground hydraulic pump from aircraft connections  |  |                  |                  |
| 8. Connect hydraulic fluid drain fixture to suction connection of aircraft hydraulic system and drain hydraulic fluid from hydraulic reservoir                        |  |                  |                  |
| 9. Place landing gear control to <b>RETRACTED (DOWN)</b> and extend landing gear with the aid of emergency pneumatic system by slowly opening cock valve              |  |                  |                  |
| 10. Evacuate air from landing gear hydraulic cylinders; to this end disconnect pipes between cylinder and hydraulic lock  |  |                  |                  |
| 11. Open filler necks of hydraulic reservoir  |  |                  |                  |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


|  |   |                                |                                  |
|--|---|--------------------------------|----------------------------------|
| <p>Supplement to Inspection Guide No. 21</p>   | <p>PROCESS CHART No. 13</p>   |                                | <p>In 20 sheets<br/>Sheet 4</p>  |
| <p>HYDRAULIC SYSTEM</p>  | <p>CHANGING AMT-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEM, REPLACEMENT OF PNEUMATIC FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS</p>   |                                | <p>Man-hours required - 3.10</p> |
| <p><b>Procedure</b></p> <p>1. Place air brake and flap control valves to EXTENDED (JEPARO) and retract air brakes and flaps manually; as a result of this action, AMT-10 hydraulic fluid should be forced from cylinders and hydraulic reservoir.</p> <p>2. Drain AMT-10 hydraulic fluid from hydraulic reservoir of hydraulic booster system.</p> <p><b>Removal and Washing of Hydraulic Reservoir of Hydraulic System</b></p> <p>1. In order to prevent contamination of hydraulic systems wash all connections with clean gasoline. Remove locking arrangements and screw off nuts which attach pipes to hydraulic reservoir.</p> <p>2. Remove and fit plugs over open ends of hydraulic connections of hydraulic reservoir or covers open ends with PTC tape in order to prevent penetration of dirt into pipes and hydraulic reservoir.</p> | <p><b>Technical requirements</b></p> <p><b>WARNINGS:</b></p> <ol style="list-style-type: none"> <li>1. Decant and wash hydraulic reservoir only after every 200 flying hours (2 years of operation)</li> <li>2. Never bend disconnected pipes since otherwise they are likely to get damaged. Bending of pipes may also result in mounting stresses after re-installation of pipes.</li> </ol> <p>If pipe fits connection tightly, release nut on opposite end of pipe or release pipe attachment fitting</p> | <p><b>Fault correction</b></p> |                                  |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Order No. 21  | PROCESS CHART No. 13  |                       | In of size<br>Sheet 3 |
|---|---|-----------------------|-----------------------|
| HYDRAULIC SYSTEM  | CHANGING AN-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEM. REPLACEMENT OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS  |                       | Required - 11         |
| Procedure   | Technical requirements  | Fault correction      |                       |
| <p>2. Unlock and screw off nut of hydraulic reservoir fastening yoke; screw off nuts and remove bolts on hydraulic reservoir mounting brackets (see Fig. 18)</p> <p>3. Demount hydraulic reservoir from aircraft and wash it with clean (un-leaded) gasoline, blow with compressed air and inspect. When inspecting hydraulic reservoir pay special attention to cleanliness of inner surfaces and condi-</p> | <p>so as to make it possible to move pipe away from connection without exerting undue effort</p>  <p>FIG. 18 ATTACHMENT OF HYDRAULIC RESERVOIR TO FUSelage FRAME No. 11</p> <p>Interior of hydraulic reservoir should be clean.<br/>Cracks in hydraulic reservoir shall not be tolerated</p> | <p>Weld up cracks</p> |                       |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



|   |  |                  |                              |
|---|--|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 13   |                  | In 20 sheets<br>Sheet 5      |
| HYDRAULIC SYSTEM  | CHANGING ANT-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEMS. REPLACE-<br>MENT OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEMS   |                  | Man-hours<br>required - 3.10 |
| Procedure   | Technical requirements   | Fault correction |                              |
| of welded joints; make sure that<br>are no cracks at areas where<br>their mounting brackets are fitted<br>2. Re-install hydraulic reservoir,<br>fit fast on brackets by means of<br>and lock in place<br>3. Remove plugs from reservoir pipes<br>connections, and connect pipes to<br>their<br><br>Replacement of Fine Filtering Elements<br>in Hydraulic Systems.<br>Location of Coarse Filters<br>1. Remove cover of access hole lead-<br>units of hydraulic system (at<br>are starboard and port sides between<br>Figs 25 and 27), see Figs 19 and<br>filter cup and pipe connections<br>contamination of system<br>check and access cut filter elements | Notes: 1. First replacement of<br>fine filtering elements<br>of 110-4 filter of<br>10-3-20 pump outer circula-<br>tion line in main hydrau-<br>lic system should be per-<br>formed after first<br>10 - 2 flying hours<br>2. Further replacements of<br>fine filtering elements<br>in 110-4 (10-3) filters<br>of main hydraulic system<br>should be carried out |                  |                              |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |                      |   |
|---|----------------------|---|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 13 | In 20 sheets<br>Sheet 7   |
|    |                      |    |
| <p>FIG. 19. POSITION OF 6T-11 PRESSURE LINE FILTER (REF. NO. 1) AND 13-18-4 DRAIN LINE FILTER (REF. NO. 2) AS VIEWED FROM FUSELAGE STARBOARD SIDE (FILTER 6T-11 INSTEAD OF 13-18-4 ON AIRCRAFT OF EARLIER MODELS)</p> |                      | <p>FIG. 20. PORTION OF PRESSURE LINE FILTER 6T-11 (REF. NO. 1) AND PYROTECHNIC BOOSTER SYSTEM GAUGE FILTER (REF. NO. 2) AS VIEWED FROM FUSELAGE PORT SIDE</p> |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 13  |                  | In 20 sheets Sheet 3      |
|---|---|------------------|---------------------------|
| HYDRAULIC SYSTEM  | CHANGING AND-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEMS. REPLACEMENT OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS  |                  | Man-hours required - 3.10 |
| Procedure   | Technical requirements  | Fault correction |                           |
| <p>NOTE: When replacing fine filtering elements in filters of straight-through type it is necessary to dismount complete filter assembly having previously washed filter and pipe connections externally. Open ends of pipes should be plugged.</p> | <p>after every 25 ± 5 flying hours, while in filters of hydraulic booster system - once every 50 ± 5 flying hours. Simultaneously, coarse filters should be cleaned and checked for secure attachment.</p> <p>Pipe filters are located as follows:</p> <p>(a) in pressure line of main hydraulic system: filter 6L-11, fuselage starboard side, between frames Nos 25 - 27; filter 1110-A (6L-31 on aircraft of earlier makes), in fin, before EV-51M hydraulic booster</p> <p>- in return line of main hydraulic system: filter 6L-11, fuselage starboard side, between frames Nos 25 - 27; filter 1110-A in forward part of superstructure, see Fig. 22;</p> <p>(b) in pressure line of hydraulic booster system: filter 6L-11, fuselage port side, between</p> |                  |                           |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |
|---|--|--|
| Supplement to Inspection Guide No. 21   | PROCESS CHART, No. 13  | In 20 sheets<br>Sheet 5  |
| HYDRAULIC SYSTEM  | CHANGING AND-10 HYDRAULIC FILTERS IN HYDRAULIC SYSTEMS. MAINTENANCE OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS   |  |
| <p>Procedure</p> <ol style="list-style-type: none"> <li>3. Remove fine filtering element from filter (Fig. 21)</li> <li>4. Wash coarse filtering element and filter cup with clean gasoline and blow with compressed air</li> <li>5. Inspect coarse filter and filter cup; make sure that gasket in chest and soldered joints are intact</li> <li>6. Install new filtering element and screw in filter sleeve</li> <li>7. Lock filter with EKK-0.8 wire and wipe filter externally</li> </ol> | <p>Technical requirements</p> <p>Frames Nos 25 - 27 (see Fig. 20, Ref. No. 1); filter 1174-1 in film, before EV-518 hydraulic booster (Fig. 23)</p> <p>- in return line of hydraulic booster system: gauge filter 2 (see Fig. 20)</p> <p>Coarse filtering element should be clean and free from dents and deterioration of soldered joints. When removing coarse filter be careful not to damage it.</p> | <p>Fault correction</p> <p>If dirt remains in filter cup, remove and re-wash it.</p> |

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |                              |                                 |
|--|------------------------------|---------------------------------|
| <p>Supplement to Inspection<br/>Guide No. 21</p> | <p>PROCESS HEAD - No. 22</p> | <p>In 22 above<br/>Sheet 20</p> |
|--|------------------------------|---------------------------------|

**FIG. 21. REMOVAL OF FINE FILTERING ELEMENT**  
 (a) view of filter before removal of fine filtering element; the arrow shows the direction in which the filter should be shifted for removal; (b) view of filter after removal of fine filtering element; the arrow shows the correct view.

**FIG. 22. PORTION OF OUTER CIRCULATION LINE FILTER 117A-4 OF MAIN HYDRAULIC SYSTEM PUMP**  
 22-24-22

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART, No. 13

In 20 sheets  
Sheet 11




FIG. 2. POSITION OF MAIN HYDRAULIC SYSTEM PRESSURE LINE FILTER (1) AND HYDRAULIC BOOSTER SYSTEM PRESSURE LINE FILTER (2) ON AIRCRAFT OF EARLIER MAKES (REF. No. 1 AND 2) AND FILTER OF HYDRAULIC BOOSTER SYSTEM PRESSURE LINE

1 - Main hydraulic system pressure line filter, 2 - Hydraulic booster system pressure line filter.

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                           |
|---|---|---------------------------|
| Supplement to Inspection Guide No. 21   | PROCESS REPORT No. 23   | In 20 sheets Sheet 12     |
| HYDRAULIC SYSTEM  | CHANGING AMT-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEMS. REPLACEMENT OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS  | Man-hours required - 3.10 |
| <b>Procedure</b>  | <b>Technical requirements</b>   | <b>Fault correction</b>   |
| <p><u>Demount and Service Gauge Filter on Return Line of Hydraulic Booster System</u></p> <ol style="list-style-type: none"> <li>1. Wash filter and pipe connections</li> <li>2. Unhook and demount filter (see Fig. 20).</li> </ol> <p>Close pipe ends with clean plugs</p> <ol style="list-style-type: none"> <li>3. Disassemble filter, wash it in clean gasoline and blow with compressed air</li> <li>4. Inspect filter gauge and soldered joints</li> </ol> <p><u>Washing Throttles of Anti-Surge Shutters</u></p> <ol style="list-style-type: none"> <li>1. Remove throttles of anti-surge shutter and intake tube lines, installed on wheel L.G. strut wall</li> <li>2. Wash throttles in clean gasoline, blow with compressed air and inspect</li> </ol> <p><u>Washing Hydraulic System</u></p> <ol style="list-style-type: none"> <li>1. Install washing filter in place removed operating filter 2F-11, AMT and gauge filter of return line of hydraulic booster line</li> </ol> | <p><b>Note.</b> First removal and washing of gauge filter should be carried out after first 10 ± 2 flying hours</p> <p>Filter gauge and soldered joints should be intact</p> <p><b>Note.</b> Successive washing of throttles should be carried out after every 50 ± 5 and 100 ± 10 flying hours</p> <p><b>WARNING.</b><br/>Hydraulic system is subject to washing during scheduled changing of AMT-10 hydraulic fluid after 200 flying hours or ahead</p> |                           |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                  |                           |
|--|---|------------------|---------------------------|
| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 13  |                  | In 20 parts (Sheet 1)     |
| HYDRAULIC SYSTEM   | CHANGING ANY-TO HYDRAULIC FLUID IN HYDRAULIC SYSTEMS. REPLACEMENT OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS  |                  | Maintenance required - 12 |
| Procedure  | Technical requirements  | Fault correction |                           |
| <p>2. Install through connections in place of removed throttles in anti-surge shutoff control lines.</p> <p>3. Engage engine jet shutoff flap control system for ground operation with engine inoperative in accordance with the operating instructions.</p> <p>4. Charge hydraulic system with fresh or filtered fluid.</p> <p>5. Connect ground pump to aircraft connections of main hydraulic system.</p> <p>6. Connect ground electric power supply source, turn on BOOSTER FILTER (AIRFLOW) switch and all circuit-breakers of takeoff and landing equipment.</p> <p>7. Engage ground hydraulic pump and pump fluid through main hydraulic system. To this end:</p> <p>(a) retract and extend landing gear, flaps, air brakes and anti-surge shutoffs 10 to 12 times.</p> | <p>of schedule in case mechanical impurities have been detected in hydraulic fluid.</p> <p><b>Notes:</b> The following equipment should be used for washing hydraulic systems:</p> <p>1. Set of washing filters: 6-11, 1170-4 and coarse filter of return line in hydraulic booster system (these are taken from maintenance kit).</p> <p>Washing filters differ from operating ones (with the exception of coarse filter) in that their safety valves are plugged.</p> <p>2. Set of through connections used in place of throttles in control lines of anti-surge shutoffs and landing gear.</p> <p><b>WARNING:</b> Washing filters and through connections should be painted red, and caution flags should be attached to them.</p> |                  |                           |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |                                |                               |
|--|--|--------------------------------|-------------------------------|
| Supplement to Inspection Guide No. 21  | PROCEDURE CHART No. 15   |                                | 16 20 sheets<br>Sheet 14      |
| HYDRAULIC SYSTEM   | CHANGING AM-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEM. REPLACEMENT OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS   |                                | See notes<br>required - 5, 10 |
| <p><b>Procedure</b></p> <p>(b) set engine jet nozzle flaps 10 to 12 times in succession at FLAPS CLOSED (CYCLOPE MANUVAL), REVERSE POSITIONED (REVERSE POSITION) and POSITION ADJUSTED (MANUAL POSITION) positions;</p> <p>(c) retract landing gear and flaps, extend air brakes and anti-surge shutters;</p> <p>(d) disengage ground hydraulic pump;</p> <p>(e) turn on circuit-breaker and change-over switch BOOSTER SYSTEM DISCONNECT (OVER. EJECT. CRUISE) and move control stick forward and backward to reduce main system pressure to zero;</p> <p>(f) turn off storage battery and circuit-breaker</p> <p>6. Connect ground hydraulic pump aircraft connections of hydraulic booster system</p> <p>9. Turn on STORAGE BATTERY (AUXILIARY) change-over switch and circuit-breaker of stabilizer and aileron hydraulic booster control system</p> | <p><b>Technical requirements</b></p> <p><u>WARNING.</u><br/>When retracting and extending landing gear, flaps, etc., take all precautions recommended in Item 4 of Section "Draining AM-10 fluid from hydraulic systems"</p> | <p><b>Fault correction</b></p> |                               |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                  |                           |
|--|---|------------------|---------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 33  |                  | In 20 sheets<br>Sheet 15  |
| HYDRAULIC SYSTEM   | CHANGING AND-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEMS, REPLACEMENT<br>OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS |                  | No-Tests<br>Required - 12 |
| Procedure  | Technical requirements  | Fault correction |                           |
| <p>10. Sponge ground hydraulic pump<br/>11. Turn on BOOSTER SYSTEM DISCONNECTIVE change-over switch and pump fluid through aileron hydraulic booster lines during 5 to 6 minutes manipulating aileron control stick over entire operating range.<br/>Move aileron control stick right and left at a rate of 25 to 30 full-range resettings per one minute<br/>12. Pump hydraulic fluid through stabilizer hydraulic booster line in the course of 5 to 6 minutes by operating stabilizer control handle. Move stabilizer control handle forward and backward at a rate of 10 to 12 full-range resettings per one minute. During these manipulations AP7-33 automatic transmission ratio controller should be set at its bigger end<br/>13. Disengage ground hydraulic pump<br/>14. Reduce pressure to zero by operating stabilizer and aileron control stick</p> |   |                  |                           |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |                                |                              |
|--|--|--------------------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 15   |                                | In 20 sheets<br>Sheet 16     |
| HYDRAULIC SYSTEM   | CHANGING AMT-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEMS. REPLACE<br>MOST OF THE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS  |                                | Man-hours<br>Required - 5.10 |
| <p><b>Procedure</b></p> <p>15. Turn off change-over switches, circuit-breakers and electric supply</p> <p>16. Drain AMT-10 hydraulic fluid in accordance with Item 7 through 13 of Section "Draining AMT-10 fluid from hydraulic systems"</p> <p>17. Disassemble, wash filters, disassemble them and inspect for cleanliness</p> <p>18. Re-install operating filters</p> <p>19-21. IIF-4 and gauge filter of hydraulic booster system return line. Safety connections with locking wire, type IIX-0.8</p> <p>22. Remove washing through connections and re-install throttles of anti-gauge shutters and intake cone control pins. Safety connections with IIX-0.8 locking wire</p> <p><u>Checking Hydraulic Systems with AMT-10 Fluid</u></p> <p>1. Check amount of nitrogen, and, if necessary, fill hydraulic accumulators with nitrogen to capacity</p> | <p><b>Technical requirements</b></p> <p><u>WARNING.</u></p> <p>Should dirt, sand or other foreign matter be detected in filtering elements of 0f-11 and IIF-4 filters or gauge filter of hydraulic booster system return line, wash dirty filters, re-install them and re-wash the given hydraulic system</p> <p>Nitrogen pressure in spherical and cylindrical hydraulic accumulators should be equal to <math>50 \times 10^5 \text{ kg/cm}^2</math>.</p> | <p><b>Fault correction</b></p> |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                              |
|---|--|------------------|------------------------------|
| Supplement to Report<br>Guide No. 23  | PROCESS CHART No. 33   |                  | In 20 sheets<br>Sheet 17     |
| EXPANDED VIEW   | CHARGING AMT-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEMS, REPLACEMENT OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS   |                  | Man-hours<br>required - 3.10 |
| Procedure   | Technical requirements   | Fault correction |                              |
| <p>2. Open covers (on fuselage) of access holes leading to hydraulic reservoir filler necks and, if reservoir has not been dismantled and washed, wipe cap and reservoir filler neck with clean cloth (for hydraulic reservoirs with open-type filling of AMT-10 hydraulic fluid).</p> <p>3. Fill both sections of hydraulic reservoir with AMT-10 hydraulic fluid (fill approximately 2.5 litres into main system section, and approximately 6.5 litres of hydraulic fluid into hydraulic booster system section; use dip stick for measurements).<br/>                 Total amount of hydraulic fluid in both systems and hydraulic reservoir is about 36 litres.</p> <p>4. Connect ground electric power supply source. In cockpit: turn on STRIKE SWITCH change-over switch and circuit-breakers of landing gear, flaps, air brakes, anti-surge diverters, cone, engine idle flaps and hydraulic boosters.</p> | <p>When charging hydraulic systems observe the following requirements for dirt prevention:</p> <p>(a) AMT-10 fluid to be used in hydraulic system should be kept in special sealed containers;</p> <p>(b) prior to filling charging cart with AMT-10 fluid from special containers, thoroughly wipe filler necks of charging cart and special containers with clean cloth; make absolutely sure that no traces of dirt remain on them;</p> <p>(c) fill AMT-10 fluid into charging cart in closed location taking all dust preventive precautions;</p> <p>(d) before opening hydraulic reservoir thoroughly wipe filler neck and cap and wash charging gun tip in clean gasoline;</p> <p>(e) hydraulic reservoir should remain open only during recharging operations. When filled with AMT-10 fluid, hydraulic reservoir should be immediately closed, and its cap and</p> |                  |                              |

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |                  |                           |
|--|--|------------------|---------------------------|
| Supplement to Inspection Guide No. 21  | PROCEEDS CHART No. 13  |                  | In 20 sheets<br>Sheet 15  |
| HYDRAULIC SYSTEM   | CHANGING AM-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEMS, REPLACE MOST OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS |                  | Man-hours required - 3.25 |
| Procedure  | Technical requirements   | Fault correction |                           |
| 5. Place landing gear control valve handle to RETRACTED (HUPPER) and press LANDING (NOCAENA) button at flap control panel of left-hand horizontal console<br>6. Connect ground pump to aircraft connections of both hydraulic systems<br>7. Engage ground hydraulic pump and build up service (operating) pressure in system. Reduce pressure to zero by operating aircraft control stick<br>8. Open (in turn) filler necks of hydraulic reservoir and add AM-10 hydraulic fluid into reservoir<br>9. Pump fluid through main hydraulic system and hydraulic booster system. To this end:<br>(a) initiate 10 or 12 retraction-<br>extension cycles of landing gear, air<br>brakes, flaps, anti-surge shutters<br>and engine nozzle flaps;<br>(b) move aircraft control stick 15 to<br>20 times over entire operating ranges<br>forward and backward and from right to<br>left. | filler neck - wiped  |                  |                           |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM



50X1-HUM

| Supplement to Inspection<br>Order No. 21  | PROCESS CRAFT No. 13  | In 20 sheets<br>Sheet 19     |
|---|---|------------------------------|
| HYDRAULIC SYSTEM  | CHANGING AND/OE HYDRAULIC FILTED IN HYDRAULIC SYSTEMS. REPLACE-<br>MENT OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS  | Man-hours<br>required - 1.10 |
| Procedure   | Technical requirements  | Fault correction             |
| <p>Leave landing gear in extended position, and flaps, air brakes, cone, anti-swing shutters and engine jet nozzle flaps - in retracted position</p> <p>10. Pump fluid through nosewheel turning mechanism (if any).</p> <p>To this end:</p> <p>(a) reduce pressure in nosewheel shock strut to 5 - 7 kg/cm<sup>2</sup>;</p> <p>(b) engage nosewheel turning mechanism;</p> <p>(c) apply foot bars 10 to 12 times</p> <p>Charge strut with nitrogen and discharge nosewheel turning mechanism.</p> <p>11. Disengage ground hydraulic pump and reduce pressure in systems by operating aircraft control stick</p> <p>12. Engage PUMP TEST (EACQUEAR CHAINEZ) circuit-breaker on right-hand vertical console.</p> | <p>Reduction of pressure in hydraulic booster system to 155 <sup>±10</sup> kg/cm<sup>2</sup> should be indicated by illumination of BOGGER (EYKREPHAD) indicator light and should result in automatic engagement of H-27 pump (pump engagement will be audible)</p> |                              |

62

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |   |   |  |
|--|--|---|---|---|--|
| Supplement to Inspection Guide No. 21  |  | PROCESS CHART No. 13  |   | Is 20 sheets<br>Sheet 20  |  |
| HYDRAULIC SYSTEM   |  | CHANGING AIR-10 HYDRAULIC FLUID IN HYDRAULIC SYSTEMS. REPLACEMENT OF FINE FILTERING ELEMENTS IN HYDRAULIC SYSTEM FILTERS                |   | Man-hours required - 3.10   |  |
| Procedure  |  | Technical requirements  |   | Fault correction  |  |
| <p>13. Disengage pump unit circuit-breaker and reduce pressure in system to zero by moving aircraft control stick from one extreme position over to the other</p> <p>14. Check fluid level in hydraulic reservoir using cap-mounted dip sticks or glass gauges on reservoir of closed filling type</p> <p>15. Close filler neck caps of hydraulic reservoir and wipe them with clean cloth</p> |  | <p>With landing gear extended and air bracket, flaps and cone retracted, fluid level should be within reference marks on dip sticks</p> |   | <p>If fluid level is lower or higher than specified, add or drain AKI-7C fluid through suction valves for ground pump, before level adjustment operations it is necessary to open filler necks of reservoir</p> |  |
| Accessories  |  |   | Tools   |   |  |
| Ground hydraulic pump unit   |  |   | <p>Wrenches, 19 x 22 and 24 x 27<br/>                 Special wrench, 19 mm<br/>                 Flat-nose pliers<br/>                 Screwdriver for cross-slotted screws</p> |   |  |

51

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 14  |                  | In 2 sheets<br>Sheet 1       |
|--|---|------------------|------------------------------|
| HYDRAULIC SYSTEM   | CHECKS UPPER CHAMBERS OF CYLINDRICAL HYDRAULIC ACCUMULATORS<br>FOR AIRTIGHTNESS   |                  | Man-hours<br>required - 1.30 |
| Procedure  | Technical requirements  | Fault correction |                              |
| <p>1. At fuselage port side (near file) open cover of access hole leading to cylindrical hydraulic accumulators</p> <p>2. Unblock and disconnect pipelines from hydraulic accumulators of hydraulic systems. Plug open ends of pipes and connections of hydraulic accumulator</p> <p>3. Deaerate hydraulic accumulators from aircraft (if hydraulic accumulators bear no identification marks as to which system they belong to, make such marks)</p> <p>4. Turn hydraulic accumulators with air chamber connections down and drain leaked-in AMP-10 hydraulic fluid from both chambers</p> <p>5. Re-install hydraulic accumulators on aircraft, attach them with yokes and lock in position</p> <p>Note: Re-install hydraulic accumulators strictly in accordance with their former positions</p> | <p>If more than 100 cubic centimeters of AMP-10 fluid is found accumulated in air chamber this testifies to intolerably poor airtightness of sealing cups; in this case hydraulic accumulator is subject to replacement</p> <p>Mounted at the right should be hydraulic accumulator of main hydraulic system, and at the left - hydraulic accumulator of hydraulic booster system</p> |                  |                              |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                           |
|---|---|------------------|---------------------------|
| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 1A  |                  | In 2 sheets Sheet 2       |
| HYDRAULIC SYSTEM  | CHECKING INNER CHAMBERS OF CYLINDRICAL HYDRAULIC ACCUMULATORS FOR AIRTIGHTNESS                      |                  | Max-Hours required - 1.30 |
| Procedure   | Technical requirements  | Fault correction |                           |
| <p>6. Connect pipelines to hydraulic accumulators and secure them in position with locking fittings</p> <p>7. Build up working (service) pressure in hydraulic systems and make sure that there is no leakage of AK-10 hydraulic fluid from pipeline connections and joints</p> |   |                  |                           |
| Accessories   | Tools   |                  |                           |
|   | Screwdriver for cross-slotted screws<br>Flat-nose pliers<br>Wrenches, 14 x 17, 19, 24 x 27, 19 x 22 |                  |                           |

69

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 15   |   | In 2 sheets<br>Sheet 1    |
|--|--|---|---------------------------|
| HYDRAULIC SYSTEM   | INSPECTION AND PACKING OF GAUGE FILTERS INSTALLED IN HYDRAULIC BOOSTERS IN F-4U AIRCRAFT |   | Man-hours required - 1.30 |
| Procedure  | Technical requirements   | Fault correction  |                           |
| <ol style="list-style-type: none"> <li>1. On port side of fin screw out screws and remove cover of access hole leading to HY-21M hydraulic booster of stabilizer.</li> <li>2. Unlock inlet connections of main hydraulic system and of hydraulic booster system, and screw out connections.</li> <li>3. Withdraw gauge filters and inspect them. Make sure that soldered joints of filters are intact.</li> <li>4. On undersurface of right and left outer wing panels turn out screws and remove covers of access holes which lead to HY-45 hydraulic boosters of ailerons.</li> <li>5. Unlock inlet connections of hydraulic boosters and screw out these connections.</li> <li>6. Remove and inspect gauge filters.</li> <li>7. Re-install filters, screw connections tight and lock them.</li> </ol> | <p>Filters should be clean and intact</p>  | <p>Should metal particles or chips be detected in filter, remove hydraulic booster and transfer it to repair workshop for disassembly and checking. Filter with damaged gauge or deteriorated soldered joints should be replaced.</p> |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                         |                              |
|---|---|-------------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21                                    | PROCESS CHART No. 15  |                         | In 2 sheets<br>Sheet 2       |
| HYDRAULIC SYSTEM  | INSPECTION AND WASHING OF GAUGE FILTERS INSTALLED IN<br>HYDRAULIC BOOSTER INLET CONNECTIONS |                         | Man-hours<br>required - 1.30 |
| <b>Procedure</b>  | <b>Technical requirements</b>   | <b>Fault correction</b> |                              |
| 8. Re-install access hole panels<br>and fasten them in position with screws |   |                         |                              |
| <b>Accessories</b>  | <b>Tools</b>  |                         |                              |
|   | Screwdriver for cross-slotted screws<br>Flat-nose pliers<br>Wrenches, 14 x 17; 19 x 22      |                         |                              |

65

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                             |
|---|---|------------------|-----------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 15  |                  | In 2 sheets<br>Sheet 1      |
| HYDRAULIC SYSTEM  | REMOVING AND RE-MOUNTING PRESSURIZATION UNIT OF<br>HYDRAULIC SYSTEMS  |                  | Man-hours<br>required - 1.5 |
| Procedure   | Technical requirements  | Fault correction |                             |
| <ol style="list-style-type: none"> <li>1. Check union nuts of pipes coupled to unit and unscrew these nuts (pipe running from pressure regulator to unit should be disconnected at pressure regulator end, and unit should be de-mounted complete with this pipe)</li> <li>2. Screw off two nuts of bolts which couple unit fastening yokes</li> <li>3. Carefully bring yokes apart and remove unit</li> <li>4. Remove spring ring and withdraw dust filter from unit</li> <li>5. Wash filter in clean gasoline and dry it</li> <li>6. Brads condensate from unit bottle</li> <li>7. Re-install filter in bottle and fit spring ring tight in place</li> <li>8. Re-install unit (arrow on bottle should be directed upward), make it fast in yokes, connect pipes and lock union nuts of pipes</li> </ol> | <p>Note: Hydraulic system pressurization unit is mounted on rear wall of left L.S. wheel well with the aid of two yokes</p> |                  |                             |

66

SECRET/NO FOREIGN DISSEM

Peer Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                              |
|--|---|------------------------------|
| Supplement to Inspection<br>Guide No. 21 | PROCESS CHART No. 15  | In 2 sheets<br>Sheet 2       |
| HYDRAULIC SYSTEM                         | ERECTING AND RE-MOUNTING PRESSURIZATION UNIT OF<br>HYDRAULIC SYSTEMS  | Man-hours<br>required - 1.20 |
| Procedure                                | Technical requirements  | Fault correction             |
|  |   |                              |
|  |   |                              |
|  |   |                              |
|  |   |                              |
| Accessories                              | Tools   |                              |
|  | Wrench, 9 x 11<br>Multi-purpose flat-nose pliers<br>Wrench, 13 x 17<br>Wrench, 19 x 22<br>Round-nose pliers |                              |

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 17   |   |
|--|--|---|
| HYDRAULIC SYSTEM   | CHECKING HYDRAULIC SYSTEM FOR INTERNAL AND EXTERNAL AIRTIGHTNESS   |   |
| Procedure  | Technical requirements   | Fault correction  |
| <p>1. Jack up aircraft until wheels clear ground</p> <p>2. Check level of AK-10 fluid in hydraulic reservoir sections of system (if systems were not filled or replenished with AK-10 hydraulic fluid right before maintenance operations)</p> <p>3. Check nitrogen pressure in spherical hydraulic accumulators with the aid of special fixture (if this check was not performed during previous scheduled inspection)</p> <p>4. Check position of cross-feed cock</p> <p><u>Internal Airtightness Check of Main Hydraulic System</u></p> <p>5. Disconnect non-return valve installed in delivery line before spherical hydraulic accumulator (on fuselage starboard side between frames Nos 26 and 27)</p> | <p>During internal airtightness check of main hydraulic system hydraulic pressure in hydraulic booster system should be zero</p> <p>Level of AK-10 fluid in hydraulic reservoir sections should be within reference graduations on dip stick</p> <p>Nitrogen pressure should be at least <math>50 \pm 5 \text{ kg/cm}^2</math></p> <p>Cross-feed cock should be closed (ground safety lock B5-95A-00 should be removed)</p> <p>In aircraft of latent series (beginning with Serial No. 24201) main hydraulic system has no pressure drop limiting valve which is replaced with non-return valve which is replaced with spherical hydraulic accumulator. This</p> | <p>Add hydraulic fluid if its level is below reference graduation marks</p> |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |                  |                           |
|--|--|------------------|---------------------------|
| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 17   |                  | In 7 sheets<br>Sheet 2    |
| HYDRAULIC SYSTEM   | CHECKING HYDRAULIC SYSTEMS FOR INTERNAL AND EXTERNAL AIRLEAKAGES   |                  | Man-hours required - 3.40 |
| Procedure  | Technical requirements   | Fault correction |                           |
| <p>6. Install special maintenance adapter No. 7a-7801-1050 in place of de-mounted non-return valve.</p>                    | <p>valve isolates hydraulic accumulator from all consumers but hydraulic boosters and engine jet nozzle flaps control system</p> <p>Pressure gauge transmitter of main hydraulic system is installed after non-return valve and therefore after engine stoppage or disconnection of ground hydraulic pump pressure in main hydraulic system is not indicated by cabin-mounted pressure gauge. With this arrangement it is possible to relieve pressure in main system only with the aid of hydraulic boosters. Therefore internal air-tightness check of main hydraulic system calls for substitution of maintenance adapter No. 7a-7801-1050 for non-return valve (as instructed in Items 5 and 6 above).</p> |                  |                           |
| <p>7. Connect ground hydraulic supply adapter to aircraft connections of hydraulic system (on fuselage starboard side)</p> |  |                  |                           |

69

SECRET/NO FOREIGN DISSEM

Peer Driving

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 71  |   | PROCESS CHART No. 17   | In 7 sheets (Sheet 3) |
|--|---|--|-----------------------|
| HYDRAULIC SYSTEM   |   | CHECKING HYDRAULIC SYSTEMS FOR INTERNAL AND EXTERNAL AIRTIGHTNESS                                  |                       |
| Procedure  | Technical requirements  | Fault correction   |                       |
| <p>8. Open the following circuit-breakers on vertical panel of right-hand console: L.S. indication, air brakes, hydraulic booster system disengagement, hydraulic system isolation and L.W. flaps.</p> <p>9. With working hydraulic fluid in main system under pressure inspect all joints to make sure that system is airtight externally.</p> <p>10. To save up working fluid (in cold weather) and to evacuate air from hydraulic system operate units of hydraulic system as follows:</p> <p>(a) retract and extend landing gear, flaps, air brakes, cone, anti-surge shotters and engine jet nozzle flaps 10 - 12 times;</p> <p>(b) move aircraft control stick forward and backward at maximum possible rate 20 - 30 times;</p> <p>(c) turn L.S. nosewheel strut with turning mechanism engaged (on aircraft equipped with turning mechanism) 15 - 16 times.</p> | <p>Working fluid pressure should be equal to <math>210 \pm 10 \text{ kg/cm}^2</math>. Leakage of AM-10 fluid from joints to pipe-lines and units shall not be tolerated.</p> <p>REMARKS: 1. Before making test in aircraft cockpit to perform extension and retraction cycles of hydraulically operated units make sure that nobody works in close proximity of landing gear, flaps and air brakes.</p> <p>2. During operation of hydraulic units, an inspector should be standing at aircraft wing to watch retraction-extension procedure.</p> <p>3. During operation of nosewheel strut turning mechanism nitrogen pressure in shock strut should be relieved to <math>5 - 7 \text{ kg/cm}^2</math>.</p> | <p>In case of poor airtightness reduce pressure to zero and tighten union nut of faulty joint.</p> |                       |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| PROCEDURE CHART No. 22   |  | To 7 sheets - Sheet 4     |
|--|--|---------------------------|
| HYDRAULIC SYSTEM   |  | Man-hours required - 0.40 |
| CHECKING HYDRAULIC SYSTEMS FOR INTERNAL AND EXTERNAL AIRCRAFTNESS  |  |                           |
| Procedure  | Technical requirements   | Fault correction          |
| <p>11. Build up working pressure in hydraulic system and place unit control cocks in cockpit to following positions:</p> <p>(a) aileron hydraulic booster cock - to OFF (EAKM4EHO);</p> <p>(b) aileron strut turning mechanism control cock (if any) - to OFF (EAKM4EHO);</p> <p>(c) L.G. cock - to NEUTRAL (EAKM4EHO);</p> <p>(d) flap control cock - to RETRACTED (EAKM4EHO);</p> <p>(e) anti-surge slatter control cock - to OFF (EAKM4EHO).</p> <p>12. Maintain working pressure in main hydraulic system for 1 to 2 minutes and discharge hydraulic pump of ground supply kit.</p> <p>13. Determine time of pressure drop from 180 to 150 kg/cm<sup>2</sup> in main hydraulic system by pressure gauge installed in main hydraulic system.</p> <p>14. If pressure drop is not as indicated under Point 13, check for internal aircraftness and correct as placed in other operating instructions as indicated under Point 11.</p> | <p>Aircraft control stick should be fixed in neutral position. Pressure in hydraulic booster system should be equal to zero.</p> <p>Time of pressure drop from 180 to 150 kg/cm<sup>2</sup> in main hydraulic system should be not less than 10 seconds.</p> |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 17   |                  | In 7 sheets Sheet 5      |
|---|--|------------------|--------------------------|
| HYDRAULIC SYSTEM  | CHECKING HYDRAULIC SYSTEMS FOR INTERNAL AND EXTERNAL AIRLEAKAGES   |                  | Man-hours required - 0.4 |
| Procedure   | Technical requirements   | Fault correction |                          |
| <p>(with the exception of aileron hydraulic booster control cock which should be OFF)</p> <p>15. With main hydraulic system under working pressure, return cocks to positions indicated in Point 11, and engage aileron hydraulic booster control cock</p> <p>16. Operate aircraft control cock over entire operating range from right to left and back again; accomplish 20 to 30 full cycles at maximum possible rate</p> <p>17. Disengage ground hydraulic pump and measure time during which pressure in system drops from 120 to 150 kg/cm<sup>2</sup> with aileron hydraulic boosters engaged</p> <p>18. Operate aircraft control stick to reduce pressure in hydraulic system to zero and disconnect ground hydraulic pump</p> <p>19. Then through with check, remove maintenance adapter and re-install non-return valve</p> <p><b>Note:</b> When re-installing non-return valve be sure to position it with arrow on valve body directed towards aileron hydraulic accumulator</p> | <p>Time during which main hydraulic system pressure drops from 120 to 150 kg/cm<sup>2</sup> should be at least 5 sec</p> |                  |                          |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |   |                           |
|---|--|---|---------------------------|
| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 17   |   | In 7 sheets<br>Sheet 6    |
| HYDRAULIC SYSTEM  | CHECKING HYDRAULIC SYSTEMS FOR INTERNAL AND EXTERNAL AIRTIGHTNESS  |   | Air-holds required - 0.40 |
| Procedure   | Technical requirements   | Fault correction  |                           |
| <p>20. Check all non-return valve-to-pipeline connections for airtightness</p> <p><u>Airtightness Check of Hydraulic Booster System</u></p> <ol style="list-style-type: none"> <li>1. Connect hoses from ground hydraulic pump to hydraulic booster system connections on fuselage port side</li> <li>2. Build up working pressure in system and examine connections and joints for external airtightness</li> <li>3. Operating from cockpit, engage all aileron boosters and move aircraft control stick forward and backward and from left to right at maximum possible rate during 2 minutes</li> <li>4. Place aircraft control stick to neutral position and disengage ground hydraulic system</li> </ol> | <p>Pressure in hydraulic booster system should be <math>210 \pm 5</math> kg/cm<sup>2</sup>. No leakage of AMT-10 fluid at connections and joints of pipelines and units shall be tolerated</p> <p>Pressure in main hydraulic system should be zero</p> <p>Note. The following amounts of AMT-10 fluid are allowed to be seeped out at moving surfaces during operations of <i>Steady</i> and <i>Steady</i> hydraulic boosters:<br/>                 (a) 10-15 ml booster<br/>                 2 drops per one operating hour</p> | <p>At parking tolerated leakage is up to 2 drops per 24 hours for <i>Steady</i></p> |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 17  |  | In 7 sheets Sheet 7       |
|---|---|--|---------------------------|
| HYDRAULIC SYSTEM  | CHECKING HYDRAULIC SYSTEMS FOR INTERNAL AND EXTERNAL LEAKAGES   |  | Man-hours required - 0.40 |
| Procedure   | Technical requirements  | Fault correction                                   |                           |
| <p>5. Measure time required for system pressure to drop from 150 to 150 kg/cm<sup>2</sup></p> <p>6. Build up working pressure in system and disengage alleron hydraulic boosters</p> <p>7. Disengage ground hydraulic pump and measure time during which hydraulic system pressure drops from 150 to 150 kg/cm<sup>2</sup></p> <p>8. Relieve pressure in system to zero. Disconnect ground hydraulic pump</p> | <p>(b) EF-45 boosters: 4 cm<sup>2</sup> per one operating hour (or two drops per minute).</p> <p>Pressure in system should drop from 150 to 150 kg/cm<sup>2</sup> during not shorter than 10 seconds</p> <p>With alleron hydraulic boosters disengaged, rate of pressure drop from 150 to 150 kg/cm<sup>2</sup> should be at least 35 sec</p> | <p>booster and up to 1 cm on for EF-45 booster</p> |                           |
| Accessories   | Tools   |  |                           |
| <p>Fixture for testing nitrogen pressure in hydraulic accumulators</p> <p>Ground hydraulic installation</p>   | <p>Flat-nose pliers</p> <p>Screwdriver</p>  |  |                           |

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |                  |                             |
|--|--|------------------|-----------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCEDURE CHART No. 15   |                  | In 4 sheets<br>Sheet 1      |
| HYDRAULIC SYSTEM   | CHECKING EMERGENCY PUMP UNIT (E-27) PUMP RELEASER<br>OPERATION   |                  | Man-hours<br>Required - 0.1 |
| Procedure  | Technical requirements   | Fault correction |                             |
| <ol style="list-style-type: none"> <li>1. Connect ground electric power supply source to aircraft</li> <li>2. Connect ground hydraulic pump to aircraft connections of hydraulic booster system</li> <li>3. Operating from cockpit, turn on circuit-breakers bearing inscriptions DISENGAGEMENT OF BOOSTER SYSTEM, HYDRAULIC SYSTEM INDICATOR ( OTRASH, ETC., CVCT, CHB, IHMP.) and LIGHT CONTROL, LIGHT INDICATOR PANEL, FUEL REMAIN, TRIMMING EFFECT MECHANISM INDICATOR ( KORSPOLE IALIN, TASHO, OCT, POPET, CHB, IPHM, 300.)</li> <li>4. Operating from cockpit, turn on toggle switch bearing inscription STORAGE BATTERY AIRCRAFT-GROUND ( ARKUMVARTOP I'OPTOBOI ABOEOPAEH )</li> <li>5. Engage ground hydraulic pump and build up working pressure in hydraulic booster system</li> <li>6. In cockpit turn on circuit-breaker with inscription PUMP UNIT ( HAPYCHAH OYAPAH )</li> </ol> | <p>This action should result in illumination of two indicator lights: BOOSTER ( EYCTEPAP ) and MAIN ( OCBCHAH ) on instrument panel.</p> <p>As fluid pressure in system reaches 195 kg/cm<sup>2</sup>, BOOSTER indicator light should go out, MAIN light remaining on.</p> |                  |                             |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 15  | In 4 sheets Sheet 2      |
|--|---|--------------------------|
| HYDRAULIC SYSTEM   |   | Man-hours Required - 0.1 |
| CHECKING EMERGENCY PUMP UNIT ES-27 FOR RELIABLE OPERATION  |   |                          |
| Procedure  | Technical requirements  | Fault correction         |
| <p>7. Disengage ground hydraulic pump and smoothly move aircraft control stick backward and forward to check beginning of automatic operation of ES-27 pump unit</p> <p>8. Disengage pump unit and aileron hydraulic boosters, and operate aircraft control stick to reduce pressure in hydraulic booster system to 130 kg/cm<sup>2</sup></p> <p>9. Set aircraft control stick neutral and, holding it fixed, engage pump unit. Note time during which pressure built up by ES-27 unit increases from 130 to 170 kg/cm<sup>2</sup></p> <p>10. Run pump unit for 30 seconds</p> | <p>As soon as working pressure of hydraulic fluid in system drops to 165 ± 10 kg/cm<sup>2</sup> BOOSTER light should come on, and pump unit should engage automatically</p> <p>Engagement of ES-27 pump unit shall be ascertained visually, by noise of electric motor and pump</p> <p>With aircraft control stick in fixed position and aileron hydraulic boosters disengaged pressure in hydraulic booster system should increase from 130 to 170 kg/cm<sup>2</sup> during not longer than 7 seconds</p> <p>If in the course of 30-sec. operation of pump unit pressure of working fluid in hydraulic booster system remains stable at 160 kg/cm<sup>2</sup> means that safety valve installed in pump unit line and pump unit ES-27 proper function normally</p> |                          |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   |   | PROCESS CHART No. 1A   | In a sheet<br>Sheet 2       |
|---|---|--|-----------------------------|
| HYDRAULIC SYSTEM  |   | CHECKING EMERGENCY PUMP UNIT E1-27 FOR RELAY OPERATION   | Man-hours<br>required - 0.1 |
| Procedure   | Technical requirements  | Fault correction   |                             |
| <p>11. Having checked E1-27 pump unit engage alleron hydraulic boosters</p> <p>12. Without disengaging pump unit check its automatic disconnection from aircraft electric mains. To this end:</p> <p>(a) engage ground hydraulic pump;</p> <p>(b) build up working pressure in hydraulic booster system.</p> <p><b>Notes:</b></p> <p>1. In order to extend service life of electric motor of E1-27 pump unit it is advisable that during ground checks of pump unit it is engaged for continuous operation for not longer than 3 minutes.</p> <p>2. Remember that with E1-34 pump inoperative, E1-27 pump unit cannot be disengaged automatically; therefore, during ground checks E1-27 unit should be disengaged (in case of necessity) manually, by opening PUMP UNIT circuit-breaker.</p> <p>3. Emergency pump units which were operated in flight for about 15 minutes are subject to replacement.</p> | <p>At the moment hydraulic booster system pressure reaches 195 kg/cm<sup>2</sup> pump unit should be automatically disengaged (disengagement shall be determined by discontinuation of pump unit noise).</p> <p>Difference between E1-27 pump unit engaging and disengaging pressures should be not less than 12 kg/cm<sup>2</sup>.</p> | <p><b>WARNING:</b> To ensure normal operation of E1-27 pump unit and proper indication of pressure drop in hydraulic systems it is necessary to select pressure relays PA-135 (in case of replacement) which would be rated for engaging pressure of 165 kg/cm<sup>2</sup> and disengaging pressure of not over 195 kg/cm<sup>2</sup>.</p> <p>For relay characteristics refer to Certification of relays used.</p> |                             |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |                        |  |                  |                           |
|--|------------------------|--|------------------|---------------------------|
| Supplement to Inspection<br>Guide No. 21                             |                        | PROCESS CHART No. 18   |                  | In a photo<br>Sheet 1     |
| HYDRAULIC SYSTEM   |                        | CHECKING EMERGENCY PUMP UNIT ED-27 FOR RELIABLE<br>OPERATION |                  | Material<br>required: 0.1 |
| Procedure  | Technical requirements |  | Fault correction |                           |
|  |                        |  |                  |                           |
| Accessories  |                        | Tools  |                  |                           |
| Ground hydraulic installation<br>Ground electric power supply source |                        | Screwdriver<br>Multi-purpose flat-nose pliers                |                  |                           |

78

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |  |                              |
|---|---|--|------------------------------|
| Equipment to Inspection<br>Guide No. 21   | PROCESS PART No. 19   |  | In & Starts<br>Sheet :       |
| HYDRAULIC SYSTEM  | CHECKING H1-34 HYDRAULIC PUMPS, ALLIES HYDRAULIC BOOSTERS AND STABILIZER HYDRAULIC BOOSTERS FOR AIRLIFT OPERATIONS  |  | Man-hours<br>required - 0.60 |
| Procedure<br><br>1. Check nitrogen pressure in spherical hydraulic accumulators (if it has not been checked before) and cylindrical hydraulic accumulators with the aid of pressure gauges installed at fuselage port side<br>2. Check air brakes for tight fitting to fuselage skin<br>3. In order to prevent "sticking" of hydraulic booster control valve slide blocks in intermediate positions make sure before starting engine that alleron hydraulic boosters are engaged<br>4. Start engine. When pressure appears in hydraulic systems (this moment is indicated by pressure gauge pointers which will begin their travel from zero points) turn off ALLERON BOOSTERS (EVC-222 CONTROL) switch in order to prevent hydraulic fluid flow through hydraulic boosters during shut-out of engine<br>5. Starting pressure gauges check for pressure increase in hydraulic systems | Technical requirements<br><br>With zero pressure in both hydraulic systems, pressure in cylindrical and spherical hydraulic accumulators should be 50-55 kg/cm <sup>2</sup> . Air brake panels should be tightly pressed to fuselage skin<br>Cross-feed cock should be closed<br><br>When H.P. meter reaches 25% rating, pressure in both hydraulic systems | Fault correction<br><br>If air brake panels do not fit tightly to fuselage skin open cross-feed cock, manually press air brakes to fuselage skin and install screw clamps; close cross-feed cock |                              |

SECRET/NO FOREIGN DISSEM

Peer Chris

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21   |   | PROCESS CHART No. 19  | In 6 sheets<br>Sheet 2      |
|--|---|---|-----------------------------|
| HYDRAULIC SYSTEM   |   | CHECKING ED-34 REGULATING PUMPS, AIRBORNE HYDRAULIC BOOSTERS AND STABILIZER HYDRAULIC BOOSTERS FOR RELIABLE OPERATION | Man-hours<br>Required - 6.0 |
| Procedure  | Technical requirements  | Fault correction  |                             |
| 6. Check operation of ED-34 main hydraulic booster system to this end: at 50% RPM of engine turn on AIRBORNE BOOSTER system and several times move aircraft control stick diagonally at maximum possible rate  | Pressure (as indicated by pressure gauges) should rise from 0 to 210 $\pm$ 10 kg/cm <sup>2</sup> (keep aircraft control stick motionless during pressure rise)<br>Pressure in hydraulic booster system should not fall below 180 kg/cm <sup>2</sup> . If it is so, ED-34 pump of hydraulic booster system in aircraft control stick should move smoothly, without jamming or jerking. Efforts force artificial feel loading mechanism should be perceptible | If pressure in hydraulic booster system drops below 180 kg/cm <sup>2</sup> , replace ED-34 pump with new one          |                             |
| 7. Check operation of ED-34 pump of main hydraulic system. To this end: (a) at engine RPM of 50% normal rating press DISARMAMENT OF BOOSTER SYSTEM button at right-hand console; keep it in depressed position and move aircraft control stick several times diagonally at maximum possible rate. While doing this, check operation of hydraulic boosters from main hydraulic system and pressure in main hydraulic system | Pressure in main hydraulic system should not drop below 180 kg/cm <sup>2</sup> . If so, hydraulic pump of main hydraulic system should be considered sound  | If pressure in main hydraulic system drops below 180 kg/cm <sup>2</sup> , replace ED-34 pump                          |                             |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                           |
|---|--|------------------|---------------------------|
| Supplement to Inspection Guide No. 2)   | PROCESS CHART No. 19   |                  | 2A 5 sheets<br>Sheet 3    |
| HYDRAULIC SYSTEM  | CHECKING HI-3 HYDRAULIC SYSTEM, ALLISON HYDRAULIC BOOSTERS AND EMERGENCY HYDRAULIC BOOSTERS FOR RELIABLE OPERATION |                  | Man-hours required - 0.40 |
| Procedure   | Technical requirements   | Fault correction |                           |
| <p><b>WARNING:</b></p> <ol style="list-style-type: none"> <li>1. Continuous ground running time of engine at H.P. rotor R.p.m. lower than 500 in icing conditions (at temperatures of 0 to minus 10°C) should not exceed 5 minutes</li> <li>2. Never operate aileron hydraulic booster switch with electric supply on and no pressure in hydraulic systems unless this is extremely urgent. This is general rule that aileron hydraulic booster switch should be always ON</li> </ol> |  |                  |                           |
| <p><b>External Airtightness Check of Flight and Tests of Hydraulic Systems</b></p> <p>(a) Hydraulic Booster System</p> <ol style="list-style-type: none"> <li>1. On fuselage port side and wing covers of access holes leading to the pipelines of hydraulic booster</li> </ol>   |  |                  |                           |

SECRET/NO FOREIGN DISSEM

Poor Quality

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |   |                             |
|---|--|---|-----------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 19   |   | In 6 sheets<br>Sheet 4      |
| HYDRAULIC SYSTEM  | TESTING HM-10 HYDRAULIC PUMPS, MILROCK HYDRAULIC BOOSTERS AND STABILIZER HYDRAULIC BOOSTERS FOR RELIABLE OPERATION   |   | Man-hours<br>required - 6.0 |
| Procedure   | Technical requirements   | Fault correction                                    |                             |
| 2. Build up working pressure in hydraulic booster system from ground hydraulic pump<br>3. Maintain pressure in system during at least 10 minutes<br>a. Observing through open access holes inspect externally pipeline and unit connections and joints (in sections pump-hydraulic boosters) for leakage of HM-10 fluid<br>b. Relieve pressure in system by operation of aircraft control stick | Leakage of HM-10 fluid in connections and seals shall not be tolerated. When inspecting pipelines make sure that best sections of pipelines are round (out-of-roundness should not exceed 4%). Pipes are allowed to be worn down to, not more than 1/8" on size.<br>During pipeline mounting see to it that pipes are not stressed. With pipe disconnected, separation of pipe from connection should be not over 1 mm. Be absolutely sure that pipe centre line is co-centric with centre line of connection. | Should out-of-roundness be over 5% replace pipeline |                             |
| 4. Close access holes with respective covers and secure them with screws (or bolts)   |  |   |                             |

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |                  |                              |
|--|--|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 35   |                  | In 6 sheets<br>Sheet 5       |
| HYDRAULIC SYSTEM   | CHECKING E.H.-3 HYDRAULIC PUMPS, AIRBORNE HYDRAULIC BOOSTERS AND GROUND SERVICE BOOSTERS FOR RELIABLE OPERATION  |                  | Man-hours<br>required - 2.40 |
| Procedure  | Technical requirements   | Fault correction |                              |
| (b) Main Hydraulic System<br>1. On fuselage starboard side and wing open covers of access holes leading to accessories (units) of main hydraulic system<br>2. Build up working pressure in main hydraulic system from ground hydraulic pump<br>3. Observing through open access holes examine pipeline and unit joints for external airtightness in the following sections of main hydraulic system:<br>(a) L.O. retraction and extension systems, in three positions of L.O. control cocks: <b>NEUTRAL (RETRACTED)</b> , <b>RETRACTION (VEGETA)</b> , and <b>EXTENSION (BUDUCE)</b> ;<br>(b) flap control system, with control cock in two positions: <b>EXTRACTED (VEPASC)</b> and <b>LANDING (HOCALA)</b> ;<br>(c) air brake system, with control cock in two positions: <b>EXTENDED (REVE-NA)</b> and <b>RETRACTED (VEPASC)</b> ;<br>(d) system of anti-burgle shutters, with control cock in two positions: <b>DOWN (GOSLON)</b> and <b>UP (SAGSOM)</b> | Pressure should be maintained in hydraulic system for each position of control cocks during at least 10 minutes.<br><br>Check by outer inspection in lines: pump-cocks; cocks-cylinders; pump-hydraulic boosters of delivery and return lines.<br><br>Check above mentioned sections of hydraulic system simultaneously. Make sure that joints and connections of system pipelines and units show no traces of fluid leakage |                  |                              |

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                          |
|---|---|------------------|--------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 19  |                  | In 6 sheets<br>Sheet 4   |
| HYDRAULIC SYSTEM  | CHECKING H-3A HYDRAULIC PUMPS, AIRBORNE HYDRAULIC BOOSTERS AND STABILIZER HYDRAULIC BOOSTERS FOR RELIABLE OPERATION |                  | Man-hours required - 0.1 |
| Procedure   | Technical requirements  | Fault correction |                          |
| <p>(a) movable cone system, in three positions: RETRACTED (REAR), EXTENSION I (MID) and EXTENSION II (FORWARD);</p> <p>(b) jet nozzle flap system, with control cock in two positions;</p> <p>(c) nosewheel turning mechanism, with control cock in position FORWARD;</p> <p>(d) supply line of aileron and stabilizer hydraulic boosters</p> <p>4. Re-install access hole covers and fasten them in place with screws or locks</p> <p>5. Lower aircraft to ground by jacks</p> |   |                  |                          |
| Apparatus   | Tools   |                  |                          |
| Ground hydraulic installation<br>Ground electric power supply source  | Screwdriver for cross-slotted screws<br>Multi-purpose flat-edge pliers  |                  |                          |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

|  |   |                         |                           |
|--|---|-------------------------|---------------------------|
| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 20  |                         | In 2 sheets<br>Sheet 1    |
| HYDRAULIC SYSTEM   | CHECKING NITROGEN PRESSURE IN SPHERICAL HYDRAULIC ACCUMULATORS OF HYDRAULIC SYSTEMS   |                         | Man-hours required - 0.30 |
| <b>Procedure</b>   | <b>Technical requirements</b>   | <b>Fault correction</b> |                           |
| <p>1. Open left- and right-side covers of access holes leading to spherical hydraulic accumulators installed between Frames Nos 22 and 25.</p> <p>2. Unlock and screw off caps from connections of hydraulic accumulator charging valves.</p> <p>3. Screw nitrogen pressure gauge fixture onto hydraulic accumulator valve connection and check nitrogen pressure in hydraulic accumulators by pressure gauge indications (Fig. 24).</p> | <p>Nitrogen pressure in spherical hydraulic accumulators (at zero pressure in hydraulic systems) should amount to 50 kg/cm<sup>2</sup>.</p> |                         |                           |
| <b>Accessories</b>   | <b>Tools</b>  |                         |                           |
| <p>Fixture for charging L.G. shock struts and hydraulic accumulators with nitrogen and for checking nitrogen pressure in them (72-7604-256)</p> <p>Green nitrogen bottle</p>   | <p>Screwdriver</p> <p>Wrench, 14 x 17</p>   |                         |                           |

50X1-HUM

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 22

PROCESS CHART No. 20

In 2 sheets  
Sheet 2




FIG. 24 SPECIAL DEVICE FOR CHECKING SPHERICAL HYDRAULIC ACCUMULATOR FOR NITROGEN CHARGE PRESSURE

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


|   |  |   |                           |
|---|--|---|---------------------------|
| Supplement to Inspection Guide No. 21   | P. 2. 2. 2. 2. CHART No. 21  |   | In 5 sheets<br>Sheet 2    |
| HYDRAULIC SYSTEMS   | CHECKING OPERATION OF L.G. MAIN AND NOSEWHEEL STRUTS AND FITTINGS WITH SPECIALTY, GRADE GRAZE-201  |   | Man-hours required - 2.30 |
| Procedure   | Technical requirements   | Fault correction  |                           |
| 1. Lift aircraft until its wheels clear ground; do this with the aid of hydraulic jacks installed under wings and nose.<br><br>2. Wash joints of main and nosewheel L.G. struts with gasoline and blow them with compressed air (Figs 25 and 26).<br><br>3. Using magnifier glass examine parts of main and nosewheel L.G. struts and of main L.G. strut turning mechanism for cracks.<br><br>Pay special attention to the following places:<br>(a) welded joints of parts;<br>(b) pass-over areas;<br>(c) axle shaft of main L.G. strut, wear plug of wheel shaft turning mechanism lever.<br><br>4. Press-charge L.G. strut hinges and fittings with GRAZE-201 lubricant. | Having lifted aircraft fix operating rods of hydraulic jacks with the aid of locking sleeves.<br><br>Joints and parts of main and nosewheel L.G. struts should be clean, especially at welded joints and couplings.<br><br>Cracks in joints and parts of struts shall not be tolerated. Replace struts and assemblies if they are cracked. | Should cracks be suspected, remove paint from examined area with solvent and check with paint method. Should this method prove ineffective remove strut or part and test it with magna-flux method. |                           |
| Main wheel fittings to hubs of main and wheel mounting shafts.  | Joints shall be considered insufficiently lubricated if fresh lubricant appears in clearance of joint being lubricated.  | If no fresh lubricant appears in clearances between assembly elements, disassemble faulty group of parts, wash lubrication holes in parts with gasoline.  |                           |

SECRET/NO FOREIGN DISSEM

Poor Quality

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 21

In 5 sheets  
Sheet 3




FIG. 21. LANDING GEAR NOSEWHEEL STRUT

- 1 - strut cover tube; 2 - lower assembly; 3 - universal joint; 4 - fork; 5 - wheel KY-36 (D20 x 100); 6 - shock absorber with associated spring mechanism; 7 - strut actuating cylinder; 8 - strut extended position stop; 9 - strut up-lock; 10 - nosewheel axle control mechanism drive; 11 - No. 24 frame or a; 12 - strut retracted position microswitch; 13 - strut extended position microswitch; 14 - nosewheel strut extension microswitch; 15 - STRUT EXTENDED position indicator; 16 - STRUT EXTENDED indicator light; 17 - L.G. nosewheel strut door; 18 - nosewheel strut door extension mechanism; 19 - landing lamp; 20 - nosewheel fairlead device; 21-22 -

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 21

In 3 above  
Sheet 4




FIG 21. LAYOUT OF GREASE FITTINGS

30

SECRET/NO FOREIGN DISSEM

Peer Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |  |
|---|---|--|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 21  | In 5 sheets<br>Sheet 5   |
| HYDRAULIC SYSTEM  | CHECKING COLLECTION OF L.G. WALS AND COMPONENT GROUPS, TESTS AND PRESSURE-CHECKS OF SELECTED GROUPS, CHECKING VENTILATION WITH LUBRICANT, OILING VALVES-201   | Five hours<br>required - E-30  |
| <b>Procedures</b>   | <b>Technical requirements</b>   | <b>Fault correction</b>  |
| <p>ated closer to wing front spar should be lubricated with L.G. struts half-retracted.</p> <p>5. Lower aircraft to ground with the aid of jacks installed under wings and aircraft nose.</p>   | <p>Only MILITARY-201 lubricant should be used for all L.G. assemblies. NEVER use other lubricants.</p> <p>Before lowering aircraft act as follows:</p> <ul style="list-style-type: none"> <li>(a) build up counterpressure in hydraulic jacks;</li> <li>(b) release locking sleeves of jacks;</li> <li>(c) smoothly open by-pass valve</li> </ul> | <p>and re-assemble the group. Repeat lubrication procedure.</p> <p>If these requirements are not met, it may occur that upon opening of valve operating rods of hydraulic jacks, under gravity of aircraft, may start abruptly downward which will result in aircraft falling down from hydraulic jacks.</p> |
| <b>Accessories</b>  | <b>Tools</b>  |  |
| <p>Hydraulic jack for wing, 5200-00E (two jacks)<br/>Hydraulic jack for fuselage nose section (5200-00E)<br/>Hydraulic 4750-170<br/>Tray 01-0857-00<br/>Wrench, 21-in. plate<br/>Wrench, 18-in. plate<br/>Wrench, 12-in. plate, 130, State Standard TUCT 7594-55<br/>Screw driver for examination of hard-to-get-at places,<br/>Screw driver<br/>Screw cup M-7804-1A0</p> |   |  |

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 22   |   | In 3 sheets<br>Sheet 1       |
|--|--|---|------------------------------|
| LANDING GEAR   | CHECKING TOTAL PLAYS OF L.G. STRUTS, DOORS AND FAIRINGS  |   | Man-hours<br>required - 1.10 |
| Procedure  | Technical requirements   | Fault correction  |                              |
| <p>1. Use hydraulic jacks to lift aircraft until its wheels clear ground</p> <p>2. Prepare special fixture for measuring plays of L.G. struts and install it near L.G. strut wheel</p> <p>3. Check total plays in longitudinal and lateral directions in main and nose-wheel struts (Fig. 25)</p> <p>For measuring total play it is necessary to use dynamometer to move strut in one direction (forward), to bring moving graduated horizontal pin (set at zero) to wheel and to move wheel through dynamometer in opposite direction; while doing this read total play value by graduations on measuring fixture pin. (See Fig. 25)</p> <p>4. Check plays in doors and fairings of main and nose-wheel L.G. struts</p> | <p>Prior to measuring total plays in L.G. struts make sure that working fluid pressure in main hydraulic system equals zero. Then an effort of up to 20 kg is gradually applied to wheel axle (in both directions), total play in main L.G. strut should be:</p> <p>(a) not over 8 mm in longitudinal direction;</p> <p>(b) not over 10 mm in lateral direction. Total play of nose-wheel struts in both longitudinal and lateral directions should not exceed 5 mm</p> <p>Play of doors and fairings is measured at lower edges</p> | <p>If total play exceeds maximum specified values locate joint assembly which is worn most heavily, and replace parts of this joint or complete strut</p> |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 22

In 3 sheets  
Sheet 2

50X1-HUM




FIG. 22 MEASURING TOTAL PLAY OF MAIN L.E. STRUT WITH SPECIAL FIXTURE  
(a) measuring lateral play (b) - measuring longitudinal play 1 - total play occurring  
Dimension 2 - displacement

SECRET/NO FOREIGN DISSEM

Pear Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |                  |                              |
|--|--|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21                             | PROCESS CHART No. 22   |                  | In 3 sheets<br>Sheet 3       |
| LANDING GEAR   | CHECKING TOTAL PLAYS OF L.G. STRUTS, DOORS AND FAIRINGS  |                  | Man-hours<br>required - 1.15 |
| Procedure  | Technical requirements   | Fault correction |                              |
| 5. Operate hydraulic jacks to lower aircraft to ground               | Main L.G. strut wheel door should play by not more than 12 mm.<br>Rear wheel door should play by not over 7 mm.<br>No play shall be tolerated in strut fairings and crosspieces.<br>Efforts applied to doors and fairings during play check-out should be within 2 to 3 kg |                  |                              |
| Accessories  | Tools  |                  |                              |
| Special fixture for measuring total plays in L.G. struts, 15-9835-00 | Dynamometer rated for up to 20 kg  |                  |                              |


94

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |   |                            |
|---|--|---|----------------------------|
| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 23   |   | In 2 sheets Sheet 1        |
| LANDING GEAR  | CHECKING CLEARANCE BETWEEN STOP ON FRAME No. 6 AND UPPER ARM OF ROCKER STRUT   |   | No. Items Required - 6, 30 |
| Procedure   | Technical requirements   | Fault correction  |                            |
| 1. Lock aircraft up until wheels clear ground.<br>2. Use feeler gauge to measure clearance between stop on frame No. 6 and upper arm of L.G. nosewheel strut (Fig. 29)<br> <p>FIG. 29. MEASURING CLEARANCE BETWEEN STOP ON FRAME No. 6 AND NOSEWHEEL STRUT UPPER ARM (BOTTOM VIEW)</p> <p>1 - upper end of nosewheel strut, 2 - stop on frame No. 6, 3 - operating rod of nosewheel strut actuating cylinder, 4 - top of lower blade, 5 - frame No. 6, 6 - cable of stop position mechanical indicator, 7 - airman's lock.</p> | When hand effort of up to 20 kg is applied to strut wheel axle in direction of flight, and with landing gear control cock in neutral position, checked clearance should be not over 0.45 mm.<br>When adjusting clearance be extremely careful and attentive since absence of clearance will result in poor alignment of hydraulic booster operating rod and ball lock. On the other hand, excessive clearance will result in impact loads on joints. | If clearance is greater or smaller than specified adjust it as follows:<br>(a) unlock and disconnect from strut L.G. nosewheel strut actuating cylinder rod eyebolt;<br>(b) to increase clearance turn eyebolt out, and vice versa. |                            |

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |  |                             |
|--|--|---|--|-----------------------------|
| Supplement to Inspection<br>Guide No. 21   |  | PROCESS CHART No. 23  |  | In 2 sheets<br>Sheet 2      |
| LANDING GEAR   |  | CHECKING CLEARANCE BETWEEN STOP ON FRAMES No. 6 AND UPPER ARM OF NOSEWHEEL STRUT  |  | Man-hours<br>Required - 6.5 |
| Procedure  |  | Technical requirements  | Fault correction   |                             |
| <p>3. Release nitrogen pressure in shock strut to 4 - 6 kg/cm<sup>2</sup></p> <p>4. Engage strut turning mechanism and, with main hydraulic system under pressure, several times move foot control bar in cockpit from one extreme side position to the other</p> <p>5. With turning mechanism disengaged, turn nosewheel manually in both directions as far as it will go</p> <p>6. With control mechanism engaged, extend flaps</p> <p>7. Retract flaps and half-retract landing gear (full retraction is forbidden since otherwise nosewheel strut failing may get damaged)</p> <p>8. Charge shock strut with nitrogen</p> <p>9. Operate hydraulic jacks to lower aircraft to ground.</p> |  | <p>Nosewheel should turn by 45° ± 5°. Travel margin of turning lever should be at least 1" (linear equivalent - 2.5 mm by lag of lever)</p> <p>Mechanism should become disengaged</p> | <p>Should eyebolt adjustment fail to correct fault, place plate of required thickness (0.3 - 0.5 mm) under stop on frame No. 6</p> |                             |
| Accessories  |  | Tools   |  |                             |
| Special fixture for measuring nosewheel turn angle   |  | Set of feeler blades, 0.05-2 mm, State Standard<br>TUCZ 682-41  |  |                             |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 24   | In 2 steps Sheet 2   |
|--|--|--|
| LANDING GEAR   | CHECKING CONDITION OF CONTROL CABLES EXTENDING FROM MAIN L.G. STRUT LOCKS TO L.G. DOOR LOCKS | Man-hours required - 0.15  |
| Procedure  | Technical requirements   | Fault correction   |
| 1. Wipe control cables running from main L.G. strut locks to L.G. door locks with rags soaked in gasoline<br>2. Inspect cables externally and move hand over them to make sure that cables are neither rusted nor ragged<br>3. Check cable termination in and lugs for condition<br>4. Coat cables with grade HEATEM-201 lubricant<br>5. Remove and inspect bolts which couple three-are lever 4 (Fig. 30) with strut and wing door up-locks. Replace bolts if they are worn out by more than 0.2 mm deep<br>Coat bolts with grade HEATEM-201 lubricant and re-install | Cable should be free from corrosion and raggedness   | In case of rust traces wipe affected section with rags soaked in kerosene, then wipe it dry and coat with grade HEATEM-201 lubricant. If cable is ragged (separate strands are broken) replace cable. Cables with strand projecting at termination should be replaced. |
| Accessories  | Tools  |  |
|  | Screwdriver, ordinary<br>Flat-nose pliers<br>Wrenches, 5 x 7 and 9 x 11                      |  |

97

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM



50X1-HUM


SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM



50X1-HUM

|   |  |  |                                  |
|---|--|--|----------------------------------|
| <p>Refer to Inspection Guide No. 21</p>   | <p>PROCESS CHART No. 25</p>  |  | <p>1x 2 sheets<br/>Sheet 1</p>   |
| <p>LANDING GEAR</p>   | <p>WASHING, INSPECTION AND LUBRICATION OF WHEEL DOOR ATTACHMENT JOINTS AND OF WHEEL TURNING MECHANISM CONTROL ROD LINKS</p>  |  | <p>Man-hours required - 0.25</p> |
| <p>Procedure</p>  | <p>Technical requirements</p>  | <p>Fault correction</p>  |                                  |
| <p>1. Disconnect L.G. door operating cylinder rod from door; to this end, remove locking fittings and screw out bolt (Fig. 31)</p> <p>2. Remove pins and wash L.G. wheel door attachment joints (Fig. 31) and hinge joints of wheel turning mechanics control rods with clean gasoline; then blow with compressed air (Fig. 32)</p> |    | <p>FIG. 31. GENERAL VIEW OF MAIN L.G. STRUT WHEEL DOOR<br/>1 - door; 2 - strut attachment pin; 3 - door operating cylinder operating rod attachment lever; 4 - door operating cylinder operating rod; 5 - holding pin of L.G. door in retracted position.</p>                |                                  |
| <p>3. Inspect pins and attachment joints of wheel doors for cracks and corrosion</p> <p>4. Inspect hinge joints of wheel turning mechanics control rods and make certain that nuts are locked securely</p>  | <p>Wheel door should rotate about its hinge freely, without jamming.<br/>If pin head rotates with opposite and remaining motionless, the pin in question is surely broken.</p> | <p>If door turns with difficulty and if pin is found broken, demount wheel door, wash joints with clean gasoline and repair (if necessary). Should traces of corrosion be detected, clean them off with polishing paper No. 200.<br/>In case of heavy corrosion (result-</p> |                                  |

SECRET/NO FOREIGN DISSEM

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 25  |  | In 2 sheets<br>Sheet 2       |
|---|---|--|------------------------------|
| LADING GEAR   | WASHING, INSPECTION AND LUBRICATION OF WHEEL DOOR ATTACHMENT JOINTS AND OF WHEEL TURNING MECHANISM CONTROL ROD HINGE JOINTS |  | Man-hours<br>Required - 0.25 |
| Procedure   | Technical requirements  | Fault correction   |                              |
| <p>5. Coat pins, wheel door attachment joints and wheel turning mechanism control rod hinge joints with lubricant, grade <b>HEATEX-201</b>.</p>  |   | <p>ing in pitting) replace faulty joints (assembly) or pin</p> <p><b>FIG. 22. HINGE JOINTS OF WHEEL TURNING MECHANISM</b><br/>                     1 - steel f. c. wire, 2 - wheel turning mechanism control rod attachment point in steel, 3 - steel turning mechanism control rod, 4 - lower control rods of wheel turning mechanism, 5 - grease cup, 6 - lower bearing, 7 - crosspiece shaft.<br/>                     8 - steel.</p> |                              |
| Accessories   | Tools   |  |                              |
| <p>Bottle with compressed air<br/>Lubricant, grade <b>HEATEX-201</b><br/>Grease cup</p>   | <p>Syringe<br/>Brush<br/>Wrench, 14 x 17</p>  |  |                              |

300

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No.21  | PROCESS CHART No.25  |  | Is 4 sheets Sheet 1       |
|---|--|--|---------------------------|
| LANDING GEAR  | REMOVAL, WASHING AND LUBRICATION OF BOLTS OF SUSPENSION BRACK BRACK UNIVERSAL JOINT AND MAIN L.G. BRACK CROSSPIECES  |  | Man-hours required - 4.10 |
| Procedure   | Technical requirements   | Fault correction   |                           |
| <p>1. Use hydraulic jacks to lift aircraft so that wheels clear ground (if aircraft is not jacked up)</p> <p>2. Unscotterpin and screw nuts off bolts of L.G. nosewheel universal joints (Fig.33)</p> <p>3. Remove bolts and universal joints wash them in clean gasoline and blow with compressed air</p> <p>4. Inspect surfaces of bolts and universal joints for corrosion, cracks and scores</p> <p>5. Coat surfaces of bolts and openings of universal joints with thin layer of grade LMATM-201 lubricant</p> <p>6. Re-install universal joints, screw nuts onto bolts and lock them</p> <p>7. Use syringe to grease universal joint bolts with grade LMATM-201 lubricant</p> | <p>Inner lubrication spaces of bolts and universal joints should be clean.</p> <p>Ball socket of upper universal joint should rotate freely, without jamming</p> <p>No corrosion, cracks and scores are allowed on surfaces of bolts and universal joints</p> <p>Appearance of lubricant in assembly clearances indicates sufficient lubrication</p> | <p>In case of stiff rotation of ball socket obtain easy rotation by repeated gasoline washing with the aid of syringe</p> <p>If corrosion has been detected on ball socket replace universal joint. Bolts with surface cracks and scores should be replaced.</p> |                           |

SECRET/NO FOREIGN DISSEM

Peer Origin

50X1-HUM

SECRET/NO FOREIGN DISSEM

Replacement to Inspection  
Guide No. 21

PROCESS SHEET No. 25

In 4 sheets  
Sheet 2




FIG. 28. GENERAL VIEW OF UNIVERSAL JOINT AND CROSSPIECE OF L.S. SIDEWHEEL STRUT (ARROWS SHOW BOLTS SUBJECT TO REMOVAL)  
1 - universal joint, 2 - cross piece, 3 - strut nut tube, 4 - bolt.




FIG. 31. GENERAL VIEW OF MAIN L.S. STRUT CROSSPIECE (DISASSEMBLED)  
1 - inner tube of main L.S. strut, 2 - lower end of crosspiece, 3 - upper end of crosspiece, 4 - crosspiece bearing, 5 - cross spring mechanism control rod of main L.S. strut, 6 - lower end of bolt, 7 - lower control rods of wheel turning mechanism, 8 - wheel.

102

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 26  | In 4 sheets<br>(Sheet 3)   |
|---|---|--|
| LANDING GEAR  | REMOVAL, WASHING AND LUBRICATION OF BOLTS OF ROSEBERG<br>SHOCK STRET UNIVERSAL JOINTS AND MAIN L.G. STRET CROSSPIECES   | Man-hours<br>required - 4.10   |
| Procedure   | Technical requirements  | Fault correction   |
| <p>8. Unscrew nuts and screw nuts off bolts of crosspieces of right and left main L.G. struts (upper, middle and lower bolts, see Fig. 24)</p> <p>9. Remove crosspieces and bolts; wash them in clean gasoline and blow with compressed air</p> <p>10. Examine bolts and crosspieces for corrosion, cracks and scores</p> <p>11. Coat surfaces of bolts and crosspiece openings with thin layer of grade GRAITEK-201 lubricant</p> <p>12. Re-install crosspieces and bolts; screw on nuts and lock them with cotter pins</p> <p>13. Use syringe to grease bolts and crosspieces with lubricant, grade GRAITEK-201</p> | <p>Inner lubrication spaces of bolts and crosspieces should be clean</p> <p>Corrosion, cracking and scoring of bolts and crosspieces shall not be tolerated</p> <p>Appearance of lubricant in assembly clearances is indicative of sufficient lubrication</p> | <p>Bolts with surface cracks or scores should be replaced</p> <p>In case of minor surface corrosion of bolts remove rust with cloth and re-install clean bolts</p> <p>Heavily corroded (pitted) bolts should be replaced</p> |

SECRET/NO FOREIGN DISSEM

Peer Chris

50X1-HUM

SECRET/NO FOREIGN DISSEM

|  |  |  |                             |
|--|--|--|-----------------------------|
| Supplement to Inspection<br>Guide No. 21 | PROCESS CHART No. 25   |  | In 4 sheets<br>Sheet 4      |
| LANDING GEAR                             | REMOVAL, WASHING AND INSPECTION OF BOLTS OF ROSEHULL<br>SERVO SERVO UNIVERSAL JOINT AND MAIN L.G. SERVO CROSSMEMBERS |  | Man-hours<br>required = 4.0 |
| Procedure                                | Technical requirements   | Fault correction   |                             |
|  |  |  |                             |
|  |  |  |                             |
|  |  |  |                             |
| Accessories                              |  | Tools  |                             |
| Brass cup                                |  | Wrenches, 22 x 24; 5 x 7; 24 x 27 and 32 x 36<br>Flat-nose pliers<br>Hammer<br>Drift pin, duralumin or copper<br>Screwdriver, ordinary |                             |


104

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |  |                           |
|--|---|--|---------------------------|
| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 27  |  | In 10 sheets<br>Sheet 1   |
| LANDING GEAR   | CRACKING WHEELS, BRAKING AND BRAKE SYSTEM FOR CONVOYS   |  | Man-hours required - 2.05 |
| Procedure  | Technical requirements  | Fault correction   |                           |
| 1. Use hydraulic jacks to lift aircraft until its wheels clear ground.<br>2. Dismantle ET-32 or ET-32M wheels of main landing gear struts and disassemble them (Fig. 35); to this end:<br>(a) disconnect brake control pneumatic line from connection on wheel;<br>(b) disconnect electric wires and remove JAZ3/2M anti-skid detector (transmitter) 4 from wheel;<br>(c) release locking ring and remove wheel cover;<br>(d) unlock and screw nut off wheel axle;<br>(e) remove outer roller bearing, wheel, second roller bearing and gland from wheel axle;<br>(f) release bolt joint by unscrewing nuts 7 of brake (on wheel axle flange);<br>(g) remove wheel brake from wheel axle;<br>(h) disassemble wheel brake (Fig. 36) | Wheel brake and cylinder assembly should be disassembled with the aid of special fixtures (Figs. 37 and 38) |  <p>FIG. 36. BRAKE OF ET-32 WHEEL (WHEEL REMOVED).</p> <p>1 - shock absorber tube, 2 - stationary brake flange, 3 - wheel axle shaft, 4 - transmitter (anti-skid detector) JAZ3, 5 - brake cylinder assembly, 6 - brake shoe-to-cylinder assembly (brake shoe), 7 - wheel brake-to-axle shaft flange attachment bolts.</p> |                           |

205

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM




FIG. 20. WHEEL STRUT OF MAIN L.A. STRUT (CROSS-SECTIONAL VIEW)  
 1 - wheel; 2 - wheel hub; 3 - wheel hub flange; 4 - wheel drum; 5 - spring of the wheel; 6 - wheel hub; 7 - wheel hub; 8 - wheel hub; 9 - wheel hub; 10 - wheel hub; 11 - wheel hub; 12 - wheel hub; 13 - wheel hub; 14 - wheel hub; 15 - wheel hub; 16 - wheel hub; 17 - wheel hub; 18 - wheel hub; 19 - wheel hub; 20 - wheel hub.

SECRET/NO FOREIGN DISSEM

Peer Original





SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspecting  
Guide No. 21

PROCESS CHART No. 27

In 24 sheets  
Sheet 3



307

SECRET/NO FOREIGN DISSEM

Poor Chris

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 27   |   | In 24 Hours<br>Sheet 4      |
|--|--|---|-----------------------------|
| LANDING GEAR   | CHECKING WHEELS, BRAKES AND BRAKE SYSTEM FOR CONDITION   |   | Man-hours<br>required - 2.4 |
| Procedure  | Technical requirements   | Fault correction  |                             |
| <p>3. Wash parts with clean gasoline.<br/>Check condition of brake and powder metal discs, brake system cylinder assembly, roller bearings and other parts of main landing gear wheel.</p> | <p>Wheels, type K1-82, use brake discs made from powder metal, grade 9K1-8, with friction coefficient <math>\mu = 0.15</math> to <math>0.16</math>.<br/>Wheels, type K2-82, use brake discs made from powder metal, grade 9K2-11, with friction coefficient <math>\mu = 0.20</math> to <math>0.22</math>.<br/>Any number of minor cracks in cast iron portion, as well as annular scores not deeper than 0.5 mm are allowed on working surfaces of bimetallic sectors of brake discs.<br/>Open cracks running across entire width of sector and spreading over entire depth of cast iron portion down to steel frame shall not be tolerated.<br/>Powder metal discs, pressure disc and powder metal facing of frame butt end may be affected with any number of cracks if powder metal portion.<br/>Cracks running through powder metal portion and steel frame are not permissible. Warpage of bimetallic</p> | <p>If heavier-than-tolerated cracks have been detected on at least one set replace faulty brake disc.<br/><br/>If cracks affect powder metal portion and extend through steel frame, replace disc.<br/><br/>Discs with warpage which cause braking of wheel with brake released should be replaced.</p> |                             |

108

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |   |                              |
|---|---|---|------------------------------|
| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 27  |   | In 1st sheet<br>Sheet 5      |
| LANDING GEAR  | CHECKING BEARINGS, BEARINGS AND BRAKE SYSTEM FOR CORROSION  |   | Man-hours<br>required - 2.05 |
| Procedure   | Technical requirements  | Fault correction  |                              |
| <div data-bbox="552 1302 722 1606"> </div> <p data-bbox="535 1606 738 1648">                     FIG. 27. MEASURING TOTAL PLAY OF PRESSURE DISC<br/>                     1 - wheel flange; 2 - brake cylinder assembly;<br/>                     3 - measuring pin; 4 - maximum location of disc. (Ref. 12-4237-24)                 </p> <p data-bbox="487 1680 776 1722">                     4. Lubricate roller bearings with HI-50 grease (both in winter and summer).                 </p> | <p data-bbox="787 1291 1063 1354">                     and powder metal discs shall be tolerated if this defect does not cause braking of wheel with brake released. Intermediate and pressure discs and support flange are allowed to have crumbling of powder metal on sector edges all along contour over 12 mm of the width of chipped edge. Powder metal discs may be worn down to thickness of 6 mm, and bi-metallic discs - to level of links which interconnect the discs. Total wear of bi-metallic and metal discs should ensure that pressure disc displaces from butt end of cylinder assembly by 25 mm (Fig. 39). It is forbidden to use wheels with pressure discs travelling by 25 or more than 25 mm when pressure is supplied to cylinders. Return springs should be intact and their surfaces should be free from corrosion.                 </p> | <p data-bbox="1079 1354 1380 1396">                     Discs with powder metal chipped over more than 12 mm should be replaced. Powder metal discs narrower than 6 mm, as well as bi-metallic discs worn down to below link level should be replaced. In case of heavier displacement replace pressure discs which have been worn down most severely.                 </p> |                              |

SECRET/NO FOREIGN DISSEM

Poor Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 27   |                  | In 14 sheets Sheet 6     |
|---|--|------------------|--------------------------|
| LANDING GEAR  | CHECKING WHEELS, BRAKES AND BRAKE SYSTEM FOR CONDITION   |                  | No. hours required - 2.5 |
| Procedure   | Technical requirements   | Fault correction |                          |
| <p>and brake cylinder pistons - with grade MILAETH-201 lubricant</p> <p>5. Re-assemble main L.G. lag brakes and wheels in the order reverse to disassembly, and mount them onto strut axles</p> <p>Inflate wheels using special inflation device</p> <p>6. Demount and disassemble L.G. nosewheel (Fig. 40). To this end:</p> <p>(a) disconnect wheel brakes control pneumatic line from two connections;</p> <p>(b) disconnect electric wires from JA-24/2 anti-skid detector (transmitter) (do not remove detector);</p> <p>(c) unlock and screw out off wheel axle;</p> <p>(d) withdraw wheel axle from strut fork and from wheel with the aid of special puller and disassemble wheel</p> | <p>Inflation pressure in wheels of main L.G. struts should be:</p> <p>(a) <math>8 \pm 0.5 \text{ kg/cm}^2</math> for normal take-off weight;</p> <p>(b) <math>10 \pm 0.5 \text{ kg/cm}^2</math> for maximum take-off weight</p> <p>Brake lining is fit for operation irrespective of number of minor cracks provided these cracks do not extend across entire thickness of cast iron portion, and irrespective of similar scores on working surface of lining</p> <p>If working surface of blastallite brake lining is cracked through entire thickness of cast iron portion and</p> |                  |                          |

110

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  |  | PROCESS CHART No. 27   |  | In-14 Shows Sheet 7       |
|--|--|--|--|---------------------------|
| LANDING GEAR   |  | CHECKING WHEELS, BEARINGS AND BRAKE SYSTEM FOR CORROSION   |  | Man-hours Required - 2.00 |
| Procedure  | Technical requirements   | Fault correction   |  |                           |
| <p>7. Wash parts with clean gasoline and check condition of brake linings, shoes, chambers, gears, roller bearings and other parts of wheel.</p> <p>When inspecting parts for condition, pay special attention to the following:</p> <p>(a) integrity of teeth of driven gear, intermediate shaft gear and transmitter gear; make sure there are no cracks at tooth roots;</p> <p>(b) absence of corrosion and cracks on races and rollers of bearings;</p> <p>(c) ball bearings of transmitter intermediate shaft</p> <p>8. Lubricate roller bearings with M-50 grease (both in winter and in summer), and drive gears with ball bearings with grade LAMP-201 lubricant</p> | <p>cracks extend across entire thickness of cast iron portion to outer end, replace brake lining or wheel</p> <p>Brake shoes are serviceable when their thickness is not smaller than 8 mm</p> <p>Gear teeth should be intact and free from cracks</p> <p>Corrosion and cracks on rollers and races shall not be tolerated.</p> <p>Intermediate shaft of JK-24/2 transmitter drive system should rotate in bearings freely, without crunch and jamming</p> | <p>If brake shoe thickness is smaller than 8 mm, replace faulty shoe</p> <p>In case of broken or cracked teeth replace drive</p> <p>In case of corrosion or cracks replace faulty bearing.</p> <p>In case of stiff rotation of shaft as well as in case of crunch wash ball bearings with clean gasoline (wash several times if necessary), blow with compressed air and lubricate. If the above actions fail to correct faults, replace drive</p> |  |                           |

SECRET/NO FOREIGN DISSEM

Poor Quality

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21  |   | PROCESS CHART No. 27   | In 14 cases<br>Sheet 11 |
|---|---|--|-------------------------|
| LANDING GEAR  |   | CHECKING WHEELS, BRAKING AND PNEUMATIC SYSTEM FOR CONDITION  | Man-hours<br>required   |
| Procedure   | Technical requirements  | Fault correction   |                         |
| <p>11. Check pressure of air supplied to brakes of each wheel. To do this:</p> <p>(a) connect type KB-30 or KB-60 pressure gauge to brake system hose;</p> <p>(b) operating from cockpit press brake control lever on aircraft control stick as far as it will go;</p> <p>(c) open emergency brake control valve.</p> <p>Check right and left wheels in succession. Upon completion of check, re-connect tubes (hoses).</p> | <p>Pressure gauge should read <math>16 \pm 0.5 \text{ kg/cm}^2</math>.</p> <p>With emergency brake control valve open, pressure gauge should read <math>16 \pm 1 \text{ kg/cm}^2</math>.</p> <p>When brake control lever on aircraft control stick is pressed, two-pointer pressure gauge KB-12 should indicate <math>6 \pm 0.5 \text{ kg/cm}^2</math> pressure in system. Difference between indications of left and right pointers of pressure gauge should not exceed <math>0.5 \text{ kg/cm}^2</math>.</p> <p>In aircraft equipped with type 3U-03/1 boosters instead of type 3U-04-00-2 boosters, the 1F-7 valve should be adjusted for <math>5.5 \pm 0.5 \text{ kg/cm}^2</math> pressure, and KB-12 pressure gauge should read <math>5.5 \pm 0.5 \text{ kg/cm}^2</math>, same-value air pressure being applied to brake of nosewheel.</p> <p>Air loss per cm braking cycle is equivalent to pressure loss of 50 to <math>60 \text{ kg/cm}^2</math>.</p> | <p>In case hoses are serviceable the pipelines by disconnecting and blowing them with air successively; trace plan of clogging and eliminate defect.</p> |                         |

114

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                  |                              |
|--|---|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS START No. 27  |                  | Is in check<br>Sheet 21      |
| LANDING GEAR   | CHECKING WHEELS, BRAKES AND BRAKE SYSTEM FOR OPERATION  |                  | Man-hours<br>required - 2.05 |
| Procedure  | Technical requirements  | Fault correction |                              |
| 12. Connect hoses to wheel pipe<br>and check airtightness of main and<br>emergency brake control systems:<br>(a) check airtightness of main pneu-<br>matic system;<br>(b) check airtightness of emergency<br>pneumatic system. To this end, close emer-<br>gency extension control and emergency<br>air charging valves; | Type 7U-24-00-2 deboosters with<br>1:1.5 ratio are installed in brake sys-<br>tem of K1-62X wheels.<br>The check should show the follow-<br>ing pressure values in brakes:<br>(a) $16 \pm 0.5 \text{ kg/cm}^2$ in main wheel<br>brakes;<br>(b) $10.5 \pm 0.5 \text{ kg/cm}^2$ in nose-<br>wheel brakes.<br>Wheels, type K1-62X, feature re-<br>duced idle volume of brake cylinders.<br>Therefore air consumption per one<br>braking cycle equals 25 to 30 $\text{kg/cm}^2$ .<br>Both right and left main L.G.<br>struts should be equipped with K1-62X<br>wheels if this type is used.<br>Main pneumatic system should be<br>checked for airtightness with refer-<br>ence to main system pressure gauge<br>2K-150. Main hydraulic system, when<br>fully charged to 110 - 120 $\text{kg/cm}^2$ is<br>considered airtight if pressure re-<br>duction does not exceed 5 $\text{kg/cm}^2$ in<br>the course of 2 hours (system from<br>main air bottles to pressure consumer) | [Blank]          |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Date No. 21   | PROCESS CHART No. 17  |                  | In 1A sheets<br>Sheet 12    |
|---|---|------------------|-----------------------------|
| LANDING GEAR  | CHECKING WHEELS, BEARINGS AND BRAKE SYSTEM FOR CONDITION  |                  | Man-hours<br>required - 2.0 |
| Procedure   | Technical requirements  | Fault correction |                             |
| <p>(c) check airtightness of brake system (Fig. 41). To this end: with valves closed and nosewheel braked press brake control lever on aircraft control stick and keep it engaged until a <math>0.5 \text{ kg/cm}^2</math> pressure is obtained in brake system (as read by two-pointer pressure gauge K5-12); this being done, EF-8 valve should be in one of extreme positions (check in succession, by applying pedals to right or left);</p> <p>(d) check airtightness of emergency brake system; to do this, open emergency brake control valve and keep it open for braking during 30 minutes</p> | <p>Check with reference to 26-150 pressure gauge of emergency system. Air pressure is allowed to drop by up to <math>0.5 \text{ kg/cm}^2</math> during 30 minutes (for right and left positions of pedals, separately). Check pressure by 26-150 pressure gauge of main system.</p> <p>In the course of these 30 minutes pressure in emergency brake system is allowed to drop by not more than <math>30 \text{ kg/cm}^2</math>.</p> <p>Check through reference to 26-150 pressure gauge of emergency brake control system.</p> |                  |                             |

116

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 27

In 14 sheets  
Sheet 23




FIG. 47. WHEEL BRAKE SYSTEM

1 - reducing valve; 2 - wheel brake cylinder; 3 - reducing valve; 4 - solenoid-operated control valve; 5 - emergency valve; 6 - diaphragm valve; 7 - reducing valve; 8 - solenoid valve; 9 - emergency brake control valve; 10 - pressure gauge; 11 - automatic emergency brake; 12 - emergency brake control valve; 13 - solenoid brake control valve; 14 - valve; 15 - solenoid valve; 16 - solenoid valve.

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 28   |                  | In 5 sheets Sheet 1       |
|--|--|------------------|---------------------------|
| LANDING GEAR   | INSPECTION OF TAPER BUSHING AND CHECK SURFACE OF MAIN L.G. STRUT INNER TUBE  |                  | Man-hours required - 0.30 |
| Procedure  | Technical requirements   | Fault correction |                           |
| <p>1. Demount wheel of main L.G. strut without removing brake discs; to do this, open access hole in wheel leading to wheel nut, unlock and screw off nut.</p> <p>2. Disconnect main L.G. wheel turning mechanism control rod (Fig. 42)</p> <p>3. Press lower bellcrank of wheel turning mechanism retaining brake discs by hand, and smoothly turn wheel axle vertically (if necessary, jack up aircraft)</p> <p>4. Inspect pin (its taper portion), taper bushing and check surface of main L.G. strut inner tube (Fig. 43); for inspection, remove wheel axle complete with brake discs</p> | <p>If traces of wear or scoring are detected on check surface of inner tube at check-to-pin contact points work affected area with emery cloth No. 200, thoroughly wash it with gasoline and coat with grade 151728-011 lubricant.</p> <p>Do not pack lubricant into bushing especially in cold seasons otherwise pin will fail to enter bushing.</p> <p>If bushing is worn down by more than 0.3 mm replace it. Make a pattern for measuring wear depth. If no spare bushings are available, use old bushing (turned by 180° as an exception)</p> |                  |                           |

SECRET/NO FOREIGN DISSEM

*Peer Original*

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Outline No. 21

PROCESS CHART No. 28

In 5 sheets  
Sheet 2




FIG. 2. MAIN L.G. WHEEL AXLE SHAFT TURNING MECHANISM  
ON AIRCRAFT UP TO SERIAL No. 815  
1 - shaft; 2 - ring; 3 - nut; 4 - stop; 5 - bearing; 6 - pin; 7 - bush;  
8 - axle shaft; 9 - crosspiece upper arm; 10 - crosspiece lower arm; 11 - nut;  
12 - nut; 13 - tube; 14 - nut; 15 - nut; 16 - bearing; 17 - nut; 18 -  
upper outer tube; 19 - pin of bearing; 20 - outer crosspiece; 21 - inner  
tube; 22 - bush.




FIG. 3. LOWER PART OF MAIN L.G. STRUT POWER  
TUBE (THE APPLICABLE POINTS AT THE TAPER  
BUSHING)

230

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Regulment to Inspection<br>Guids No.21   | PROCESS CHART No.28   |   | In 5 sheets<br>Sheet 5           |
|--|---|---|----------------------------------|
| LANDING GEAR   | INSPECTION OF TAPER BUSHING AND CHECK SURFACE OF MAIN L.G. STRUT INNER TUBE   |   | Max-tolerance<br>required - 0.30 |
| Procedure  | Technical requirements  | Fault correction  |                                  |
| <p>5. Upon replacement of taper bushing act as follows:</p> <p>(a) place strut axle horizontally lifting it by brake discs and lowering turning mechanism lever;</p> <p>(b) re-adjust wheel;</p> <p>(c) check clearance between strut inner tube and stop on strut axle. If necessary, adjust clearance as instructed in Process Chart No.33</p> <p>6. Retract and extend L.G. struts three times to make sure that pin securely locks wheel axle in extended and retracted positions</p> <p>7. Check functioning of axle shaft turning mechanism and of kinematic lock which fixes axle shaft of main L.G. struts:</p> <p>(a) check closed position of axle shaft lock with strut extended; to this end, insert feeler pin, 3 mm in diameter, in check hole located on kinematic link</p> | <p><i>Note.</i> Aircraft beginning with Serial No. 740915 use main L.G. struts fitted with wheel turning mechanism of new design; the mechanism is provided with kinematic lock which fixes wheel axle shaft in both retracted and extended positions (Fig.44)</p> <p>When lock is closed completely feeler pin should enter freely by length of 21 - 23 mm.</p> <p>If feeler pin fails to enter in</p> | <p>Full closing of lock is ensured by adjusting control rod length by means of adjusting bushing (Fig.44, Ref. No.5, Joint 1)</p> |                                  |

SECRET/NO FOREIGN DISSEM

Poor Ori

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |   |                           |
|---|---|---|---------------------------|
| Supplement to Inspection Guide No. 21   |   | PROCESS CHART No. 23  | In 5 sheets Sheet 4       |
| RAMPING UP  |   | INSPECTION OF PAPER BEARING AND CLEAR SURFACE OF MAIN L.G. STRUT INNER TUBE   | Man-hours required - 0.30 |
| Procedure   | Technical requirements  | Fault correction  |                           |
| <p>of lock (Fig. 44, Ref. Nos 10 and 11);</p> <p>(b) when sure that axle shaft lock is fully closed check clearance between strut inner tube and head of thrust bolt on axle shaft (Fig. 44, Ref. Nos 7 and 8). For convenience's sake in measuring this clearance it is allowed to disconnect brake hose from wheel and electric wires - from wheel brake transmitters (anti-skid detectors)</p> | <p>check hole this means that holes in kinematic links are misaligned and lock is not closed</p> <p>With lock fully closed, clearance between head of thrust bolt and strut inner tube (on jacked-up aircraft) should be within 0.03 to 0.25 mm</p> | <p>If clearance exceeds 0.25 mm re-plate thrust bolt</p> <p>When installing new thrust bolt see deposits welding on bolt head to obtain 0.03 - 0.1 mm clearance (see Fig. 44) between bolt head and strut inner tube. Make sure that bolt head-to-axle shaft contact surface covers not more than 75% of entire thrust surface (check and adjust by paint patterns)</p> |                           |
| Accessories   |   | Tools   |                           |
| <p>Clearance gauge with set of feeler blades</p> <p>Feeler pin, dia. 3 mm</p>   |   | <p>Brush for wheel nut</p> <p>Flat-nose pliers</p> <p>Screwdriver</p>   |                           |


122

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Peer Drive

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |                          |
|--|--|---|--------------------------|
| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 29   |   | In 5 sheets Sheet 1      |
| LANDING GEAR   | CHECKING L.G. EMERGENCY EXTENSION SYSTEM FOR PROPER FUNCTIONING AND AIR PRESSURE   |   | Man-hours required - 1.5 |
| Procedure  | Technical requirements   | Fault correction  |                          |
| <p>1. Use cabin pressure gauge to check pressure in emergency pneumatic system</p> <p>2. Accomplish the following connections:</p> <p>(a) connect ground hydraulic installation to aircraft pipe unions and build up pressure in system;</p> <p>(b) connect electric power supply source and turn on all circuit-breakers</p> <p>3. Command maintenance personnel to clear landing gear; upon receiving acknowledgement of command, throw lock up and reset landing gear control cock from neutral to RETRACTED ( JEPAHO ) position (up)</p> | <p>Air pressure in emergency pneumatic system should be not lower than 110 kg/cm<sup>2</sup></p> <p>If landing gear retracts and becomes locked in retracted position normally, red indicator lights L.G. RETRACTED ( MACHE JEPAHO ) on light indication panel No. 6 and three red lights on L.G. indication panel should illuminate.</p> <p>Keep L.G. control cock in retraction position during 10 to 15 seconds, and then set it neutral. This done, L.G. RETRACTED indicator lights should be still on</p> | <p>If pressure is lower than 110 kg/cm<sup>2</sup> charge system additionally</p> |                          |

124

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 29   |   |
|---|--|---|
| LANDING GEAR  | CHECKING L.G. EMERGENCY EXTENSION SYSTEM FOR PROPER FUNCTIONING AND AIRTIGHTNESS   |   |
| Procedure   | Technical requirements   | Fault correction  |
| <p>4. Relieve pressure in main hydraulic system to zero by moving aircraft control stick backward and forward</p> <p>5. Place L.G. control cock to EXTENSION ( RA KENJUE )</p> <p>6. Open valve of L.G. emergency extension pneumatic system.<br/>Landing gear extended, observe light and mechanical indicators to make sure that landing gear struts are locked; make leak test and close air valve of emergency extension pneumatic system</p> <p>7. Expell air from main L.G. strut actuating hydraulic cylinder; to this end, screw off union nut of strut extension line pipe (running from hydraulic cylinder of main L.G. strut).<br/>Evacuate air from hydraulic cylinder of L.G. nosewheel struts; to this end, screw off nut of hydraulic cylinder pipe (in cylinder bottom portion)</p> | <p>In one minute after L.G. retraction disengage ground hydraulic pump without disconnecting supply hoses from aircraft pipe unions</p> <p>Landing gear should extend completely and become fixed by ball locks of hydraulic cylinders.</p> <p>Green lights L.G. EXTENDED (SADON KENJUEHO) on light indication panel No.6 should flash up and mechanical indicator in fuselage nose section should go out completely</p> | <p>In the course of emergency extension of landing gear, ejection of AIR-10 hydraulic fluid from inner space of hydraulic reservoir of main hydraulic system (right-hand section of hydraulic reservoir, as viewed in direction of flight) should not be considered abnormal. They should be placed under fuselage to collect ejected fluid</p> |

SECRET/NO FOREIGN DISSEM

Poor Quality



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |                        |   |  |                             |
|---|------------------------|---|--|-----------------------------|
| Supplement to Inspection<br>Guide No. 21  |                        | PROCESS CHECK No. 29  |  | In 3 sheets<br>Sheet 3      |
| LANDING GEAR  |                        | CHECKING L.G. EMERGENCY EXTENSION SYSTEM FOR PROPER<br>FUNCTIONING AND AIRCRAFTNESS |  | Man-hours<br>required - 1.0 |
| Procedure   | Technical requirements | Fault correction  |  |                             |
| <p>8. Engage ground hydraulic installation and pump AMP-10 hydraulic fluid through main hydraulic system; when pumping, fulfill 10 to 12 retraction-extension cycles of landing gear.</p> <p>9. Charge emergency pneumatic system additionally to 110 - 130 kg/cm<sup>2</sup>, and add AMP-10 hydraulic fluid to hydraulic reservoir to capacity.</p> <p>10. Disconnect ground hydraulic installation from aircraft pipe unions.</p> <p>11. Disconnect ground electric power supply source.</p> |                        |   |  |                             |
| Accessories   |                        | Tools   |  |                             |
| Ground hydraulic installation<br>Ground electric power supply source  |                        | Branches, 14 x 17 and 19 x 22<br>Flat-nose pliers                                   |  |                             |


126

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART 90-30   |   |
|---|---|---|
| LANDING GEAR  | CHECKING AMF-10 HYDRAULIC FLUID LEVEL IN L.G. SHOCK STRUTS AND NOSEWHEEL STEERING LINES   |   |
| Procedure   | Technical requirements  | Fault correction  |
| <p>1. Lift aircraft by means of jacks until wheels clear ground. This should be done if maintenance operations on landing gear are carried out before dis-jointing of fuselage</p> <p>2. Remove plugs from charging valves and screws on fixtures for charging L.G. shock struts and hydraulic accumulators with nitrogen; check pressure in shock struts and hydraulic accumulators, and, using special fixture, relieve nitrogen pressure from shock struts (Fig. 45)</p> <p>3. Screw-out charging valve and drain hole plug from shock strut of L.G. nosewheel</p> <p>4. Use syringe to fill shock strut (through holes in charging valve) with 100 cu. cm of AMF-10 hydraulic fluid</p> | <p>Screw out charging valve first. If hissing sound of escaping nitrogen is audible when charging valve is being unscrewed, discontinue valve unscrewing until nitrogen escapes completely</p> <p>Charge totals of shock struts are:</p> <p>(a) 2400 cu. cm for main L.G.</p> <p>(b) 650 cu. cm for nosewheel strut</p> |  <p>FIG 45 SPECIAL DEVICE FOR GAUGING NITROGEN PRESSURE IN MAIN L.G. SHOCK STRUT</p> |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

In 7 sheets  
Sheet 2

| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 30  |   | Man-hours<br>required - 2 1/2 |
|---|---|---|-------------------------------|
| LANDING GEAR  | CHECKING AMP-10 HYDRAULIC FLUID LEVEL IN L.G. SHOCK STRUTS<br>AND ROCKER ARM SHOCK DAMPER   |   |                               |
| Procedure   | Technical requirements  | Fault correction  |                               |
| 5. Gradually lower aircraft nose to obtain full compression of nosewheel shock strut and keep aircraft in this position during at least 20 minutes until excessive AMP-10 fluid is fully drained. | Strut should be in vertical position.<br>Excess of AMP-10 fluid will be drained from compressed shock struts through charging valve hole. | If no fluid escapes from shock strut, add hydraulic fluid to shock strut to 100 cc. cm and then drain fluid excess. |                               |
| 6. Turn in charging valve and drain hole plug, raise aircraft nose until wheels clear ground and charge nosewheel shock strut with technical nitrogen.  |   |   |                               |
| 7. Screw out charging valves of main L.G. shock struts and, operating through holes in struts, fill each shock strut with 100 cc. cm of AMP-10 hydraulic fluid (use syringe for charging).        |   |   |                               |
| 8. Gradually lower aircraft (by means of wing jacks) to obtain full compression of main L.G. shock struts and keep aircraft in this position during 20 minutes.                                   | Adjust jacks to obtain vertical position of struts with shock struts fully compressed.  | If hydraulic fluid fails to be drained, add fluid into shock struts and drain excessive fluid.                      |                               |
| 9. Screw in charging valves and operate wing jacks to lift aircraft until wheels clear ground.  |   | If it is necessary to charge L.G. shock struts with fresh AMP-10 fluid, L.G. struts should be disconnected.         |                               |

122

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |                  |                           |
|--|--|------------------|---------------------------|
| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 30   |                  | In 7 Sheets Sheet 3       |
| LANDING GEAR   | CHECKING AMP-10 HYDRAULIC FLUID LEVEL IN L.G. SHOCK STRUTS AND ENGINEER SEEDY DAMPER   |                  | Man-hours required - 2.50 |
| Procedure<br><br>10. Use special fixture to charge shock struts with compressed technical nitrogen | Technical requirements<br><br>Nitrogen pressure in shock struts should be:<br>(a) $30 \pm 1 \text{ kg/cm}^2$ in main L.G. shock struts;<br>(b) $34 \pm 1 \text{ kg/cm}^2$ in nosewheel shock strut.<br><br>If in cold seasons shock struts are being charged in heated rooms, it should be taken into consideration that ambient air temperature decrease results in reduced pressure in shock struts. In this case it is necessary to increase pressure in shock struts by $1.2 \text{ kg/cm}^2$ per every $10^\circ\text{C}$ difference between temperature in charging room and outdoor ambient air temperature | Fault correction |                           |

129

SECRET/NO FOREIGN DISSEM

Poor Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

|                                       |   |                                      |
|---------------------------------------|---|--------------------------------------|
| Supplement to Inspection Guide No. 21 | PROCESS CHART No. 30  | In 7 sheets<br>Sheet 4               |
| LANDING GEAR                          | CHECKING AM-10 HYDRAULIC FLUID LEVEL IN L.G. SHOCK STRUTS AND SUSPENSION SEIZURE DAMPER | Man-hours required - 2.50            |
| Procedure                             | Technical requirements  | Fault correction                     |
| Basic Technical Data of Landing Gear  |   |                                      |
| Characteristics                       | Main strut  | Noosewheel strut                     |
| 1                                     | 2   | 3                                    |
| Type of shock strut                   | Hydraulic-nitrogen  | Hydraulic-nitrogen                   |
| Operating fluid used in shock struts  | AM-10 (FOCF 679A-53)  | AM-10 (FOCF 679A-53)                 |
| Shock strut full travel               | 230 $\pm$ 2 mm  | 90 $\pm$ 2 mm                        |
| Wheel type and dimensions             | 660 x 20B (KX-82)   | 500 x 180A (KX-38)                   |
| Initial pressure in shock struts      |   |                                      |
| (a) at nominal take-off weight        | 30 $\pm$ 1 kg/cm <sup>2</sup>   | 34 $\pm$ 1 kg/cm <sup>2</sup>        |
| (b) at maximum take-off weight        | 30 $\pm$ 1 kg/cm <sup>2</sup>   | 34 $\pm$ 1 kg/cm <sup>2</sup>        |
| Wheel tire inflation pressure:        |   |                                      |
| (a) at nominal take-off weight        | 6 <sup>+0.5</sup> kg/cm <sup>2</sup>  | 6 <sup>+0.5</sup> kg/cm <sup>2</sup> |
| (b) at maximum take-off weight        | 10 <sup>+0.5</sup> kg/cm <sup>2</sup>   | 6 <sup>+0.5</sup> kg/cm <sup>2</sup> |

130

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No.21 | PROCESS CHART No.30   |                  | In 7 sheets Sheet 5       |   |   |                               |  |  |  |                                |                                    |             |  |                                 |                                    |           |  |                         |  |  |  |                                |       |       |  |                                 |       |       |  |  |  |
|--------------------------------------|---|------------------|---------------------------|---|---|-------------------------------|--|--|--|--------------------------------|------------------------------------|-------------|--|---------------------------------|------------------------------------|-----------|--|-------------------------|--|--|--|--------------------------------|-------|-------|--|---------------------------------|-------|-------|--|--|--|
| LANDING GEAR                         | CHECKING AN-10 HYDRAULIC FLUID LEVEL IN L.G. SHOCK STRUTS AND FORK/HEEL SHIMMY DAMPER   |                  | Man-hours required - 2.50 |   |   |                               |  |  |  |                                |                                    |             |  |                                 |                                    |           |  |                         |  |  |  |                                |       |       |  |                                 |       |       |  |  |  |
| Procedure                            | Technical requirements  | Fault correction |                           |   |   |                               |  |  |  |                                |                                    |             |  |                                 |                                    |           |  |                         |  |  |  |                                |       |       |  |                                 |       |       |  |  |  |
|                                      | <table border="1"> <thead> <tr> <th></th> <th>1</th> <th>2</th> <th>3</th> </tr> </thead> <tbody> <tr> <td>Ground compression (closure):</td> <td></td> <td></td> <td></td> </tr> <tr> <td>(a) at normal take-off weight:</td> <td>140<sup>+5</sup><sub>-6</sub> mm</td> <td>54.5 ± 3 mm</td> <td></td> </tr> <tr> <td>(b) at maximum take-off weight:</td> <td>117<sup>+5</sup><sub>-6</sub> mm</td> <td>34 ± 3 mm</td> <td></td> </tr> <tr> <td>Ground tire deflection:</td> <td></td> <td></td> <td></td> </tr> <tr> <td>(a) at normal take-off weight:</td> <td>40 mm</td> <td>25 mm</td> <td></td> </tr> <tr> <td>(b) at maximum take-off weight:</td> <td>45 mm</td> <td>30 mm</td> <td></td> </tr> </tbody> </table> |                  | 1                         | 2 | 3 | Ground compression (closure): |  |  |  | (a) at normal take-off weight: | 140 <sup>+5</sup> <sub>-6</sub> mm | 54.5 ± 3 mm |  | (b) at maximum take-off weight: | 117 <sup>+5</sup> <sub>-6</sub> mm | 34 ± 3 mm |  | Ground tire deflection: |  |  |  | (a) at normal take-off weight: | 40 mm | 25 mm |  | (b) at maximum take-off weight: | 45 mm | 30 mm |  |  |  |
|                                      | 1   | 2                | 3                         |   |   |                               |  |  |  |                                |                                    |             |  |                                 |                                    |           |  |                         |  |  |  |                                |       |       |  |                                 |       |       |  |  |  |
| Ground compression (closure):        |   |                  |                           |   |   |                               |  |  |  |                                |                                    |             |  |                                 |                                    |           |  |                         |  |  |  |                                |       |       |  |                                 |       |       |  |  |  |
| (a) at normal take-off weight:       | 140 <sup>+5</sup> <sub>-6</sub> mm  | 54.5 ± 3 mm      |                           |   |   |                               |  |  |  |                                |                                    |             |  |                                 |                                    |           |  |                         |  |  |  |                                |       |       |  |                                 |       |       |  |  |  |
| (b) at maximum take-off weight:      | 117 <sup>+5</sup> <sub>-6</sub> mm  | 34 ± 3 mm        |                           |   |   |                               |  |  |  |                                |                                    |             |  |                                 |                                    |           |  |                         |  |  |  |                                |       |       |  |                                 |       |       |  |  |  |
| Ground tire deflection:              |   |                  |                           |   |   |                               |  |  |  |                                |                                    |             |  |                                 |                                    |           |  |                         |  |  |  |                                |       |       |  |                                 |       |       |  |  |  |
| (a) at normal take-off weight:       | 40 mm   | 25 mm            |                           |   |   |                               |  |  |  |                                |                                    |             |  |                                 |                                    |           |  |                         |  |  |  |                                |       |       |  |                                 |       |       |  |  |  |
| (b) at maximum take-off weight:      | 45 mm   | 30 mm            |                           |   |   |                               |  |  |  |                                |                                    |             |  |                                 |                                    |           |  |                         |  |  |  |                                |       |       |  |                                 |       |       |  |  |  |
|                                      | <p>Notes: 1. The normal take-off weight is the weight of the aircraft with full load of fuel, oil, ammunition, less the drop tank and special external loads.</p> <p>2. The maximum take-off weight is the weight of the aircraft with full load of fuel, oil, ammunition, fuelled drop tank, and external loads.</p> <p>3. The ground compression (closure) of a shock strut is the distance between shock strut outer tube end and pin of inner tube head (Figs 46 and 47).</p>   |                  |                           |   |   |                               |  |  |  |                                |                                    |             |  |                                 |                                    |           |  |                         |  |  |  |                                |       |       |  |                                 |       |       |  |  |  |

SECRET/NO FOREIGN DISSEM

Poor Quality

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 22  | PROCESS CHART No. 30  |   | In 7 sheets Sheet 5      |
|--|---|---|--------------------------|
| LANDING GEAR   | CHECKING AMT-10 HYDRAULIC FLUID LEVEL IN L.G. SHOCK STRUTS AND ROSSIGNOL SHIMMY DAMPER  |   | Man-hours required - 2.5 |
| Procedure  | Technical requirements  | Fault correction  |                          |
| <p>11. Check amount of AMT-10 hydraulic fluid in nosewheel shimmy damper (carry out the checks on struts with wheel turning mechanism removed):</p> <p>(a) if red reference mark on rod is not seen or is located at a distance of not less than 7 mm above cover, add AMT-10 fluid into shimmy damper;</p> <p>(b) if white reference mark on rod coincides with cover surface or stands somewhat above it (by 1 - 2 mm maxima), as well as in case white reference mark is not seen while red mark is located at a distance greater than 7 mm, no additional charging of shimmy damper chamber is needed.</p> <p>In cold seasons shimmy damper should be removed and transferred to heated room for warming</p> | <p>If there are no reference marks on rods, take into consideration the following standard dimensions of rod extension:</p> <p>(a) with compensation chamber filled normally at 20 ± 5°C temperature rod should be out by 16.5 mm from top of filler neck cap to chamber cover;</p> <p>(b) minimum operational extension of rod cap top to chamber cover amounts to 10 mm</p> | <p>Add AMT-10 fluid into compensation chamber as follows:</p> <p>(a) fix shimmy damper in operating position and screw filler neck cap from compensator rod (carry out these operations at 20 ± 5°C);</p> <p>(b) screw adapter into rod and couple adapter to syringe head for pressure filling of AMT-10 hydraulic fluid;</p> <p>(c) supply AMT-10 fluid under pressure and watch movement of rod. Supply pressure until rod extends by 2 mm;</p> <p>(d) disconnect syringe and screw adapter out of rod;</p> <p>(e) using duralumin rod, intermittently press ball of non-return valve and simultaneously watch lowering of rod making sure not to miss moment when reference mark on rod coincides with surface of upper cover of chamber body. In</p> |                          |



132

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |   |   |
|---|---|---|---|
| Supplement to Inspection<br>Guide No. 21  | PROCESS-O-RARY No. 30   |   | In 7 sheets<br>Sheet 7  |
| LANDING GEAR  | CHECKING AMP-10 HYDRAULIC FLUID LEVEL IN L.G. SHOCK STRUTS<br>AND ROD-ENDS, STRUT DAMPER  |   | Man-hours<br>required - 2.50  |
| Procedure   | Technical requirements  | Fault correction  |   |
| 12. Operate jacks to lower aircraft<br>to ground  |  <p>FIG. 4A. GROUND COMPRESSION OF<br/>MAIN L.G. STRUT</p> |  <p>FIG. 4B. GROUND COMPRESSION OF<br/>NOSE WHEEL STRUT</p> | <p>this position AMP-10 fluid will flow<br/>from rod hole. Screw in filler neck cap<br/>and lock it with type ERE-C-8 wire;<br/>(*) re-mount shims on strut</p> |
| Accessories   | Tools   |   |   |
| Fixture for charging shock struts and hydraulic accumulators and checking pressure in them, 72-7804-250 | French, 1 1/2 x 17<br>Syringe<br>Flat-nose pliers   |   |   |

135



SECRET/NO FOREIGN DISSEM

Peer Origin



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |  |                              |
|---|---|--|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 11  |  | In 7 sheets<br>Sheet 1       |
| LANDING GEAR  | CHANGING ANT-10 HYDRAULIC FLUID IN L.G. SHOCK STRUTS AND<br>ROSSIGNOL SHOCK DAMPER  |  | Man-hours<br>required - 2.50 |
| Procedure   | Technical requirements  | Fault correction   |                              |
| 1. Lift aircraft by means of jacks<br>until wheels clear ground<br>2. Demount main L.G. struts in the<br>following order:<br>(a) drain fuel from wing tanks into<br>clean vessels or fuelbells; to this end,<br>screw out drain plug from wing tanks--<br>drain holes and install special fixture<br>in place of them (Fig. 4B);<br>(b) drive out screws and remove ac-<br>cess panels on wing;<br>(c) remove fuel transfer pump<br>HMP-1M of wing tanks;<br>(d) remove electric accessory box;<br>(e) remove main L.G. strut EXHAUST<br>limit switch;<br>(f) demount wheel and brake discs<br>from wheel axle shafts;<br>(g) demount strut and crosspiece<br>fairings;<br>(h) screw off nut and unjoint con-<br>trol rod of wheel turning mechanism at<br>upper end of crosspiece<br>(A) screw off union nuts of three<br>air hoses; |  <p>FIG. 4B. PLUG OF WING TANK DRAIN HOLE<br/>                 1 - wing undercarriage side, 2 - drive plug, 3 - locking<br/>                 nut K26-1.</p> |  <p>FIG. 4A. LOCK FITTINGS OF MAIN L.G. STRUT<br/>                 ATTACHMENT NUT<br/>                 1 - main strut shaft, 2 - nut, 3 - lock fitting.</p> |                              |



130

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   |  | PROCESS CHART No. II   |   | In 7 sheets<br>Sheet 2    |
|---|--|--|---|---------------------------|
| LASTING GEAR  |  | CHARGING AN-10 HYDRAULIC FLUID IN L.G. SHOCK STRUTS AND FOREWHEEL SHOCK DAMPER   |   | Man-hours required - 2.50 |
| Procedure   |  | Technical requirements   | Fault correction  |                           |
| <p>(d) unscrew nut and disjoint hydraulic cylinder rod and floating bolt of strut;</p> <p>(e) unscrew nut and remove fixing bolt of main L.G. strut axle;</p> <p>(f) unlock and screw off nut which secures main L.G. strut axle in attachment joints (Fig. 49);</p> <p>(g) screw special fixture into strut mounting axle (Fig. 50) and rotate fixture to remove axle. During this operation strut should be supported by two men. For easier removal it is recommended to rock axle in direction of flight</p> <p>3. Screw cap off strut charging valve, screw on special fixture and reduce nitrogen pressure in main L.G. shock strut to zero</p> <p>4. Screw out charging valve, place strut horizontally with connection down and drain AN-10 fluid. For more effective drainage it is recommended to rock strut</p> <p>5. Place strut horizontally but a little inclined with axle shaft down end.</p> |  |  <p>FIG. 50. FIXTURE FOR REMOVING MAIN L.G. STRUT SHAFT</p> |  <p>FIG. 51. CHARGING MAIN L.G. SHOCK STRUT</p> |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 11  |                  | In 9-4000 Sheet 3    |
|---|---|------------------|----------------------|
| LANDING GEAR  | CRANKING AFT-10 HYDRAULIC FLUID IN L.G. SHOCK STRUTS AND ROCKER/SHOCK SHIMMY DAMPER |                  | Number required - 23 |
| Procedure   | Technical requirements  | Fault correction |                      |
| <p>using syringe (Fig. 51), fill strut with 400 cc. of AFT-10 fluid.</p> <p>To re-mount strut on aircraft reverse dismounting procedure.</p> <p>6. Dismount nosewheel strut as follows:</p> <p>(a) unlock and screw off nut and disconnect hydraulic cylinder rod from strut;</p> <p>(b) dismount wheel;</p> <p>(c) remove panel (with antenna) of access hole leading to nosewheel strut and disconnect strut position mechanical indicator from strut;</p> <p>(d) disconnect nosewheel turning mechanism control rod;</p> <p>(e) open covers of access holes leading to L.G. nosewheel axle;</p> <p>(f) unlock and screw off strut shaft mounting nut (use special wrench for this purpose);</p> <p>(g) disconnect strut-mounted hydraulic system pipes running to wheel turning mechanism;</p> <p>(h) disconnect air supply pipes running to wheel brakes.</p> |   |                  |                      |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Equipment to Inspection<br>(Article No. 2)  | PROCESS CHART No. 1  |   | In 7 sheets<br>Sheet 6       |
|---|--|---|------------------------------|
| LANDING GEAR  | CHARGING AN-10 HYDRAULIC FLUID IN L.G. NOSEWHEEL STRUTS AND NOSEWHEEL SHOCK DAMPER |   | Man-hours<br>required - 2.50 |
| Procedure   | Technical requirements   | Fault correction  |                              |
| <p>(1) Disconnect electric connector from N2A2/2 transmitter (antiskid detector);</p> <p>(2) collapse struts; do this by pressing landing gear downlock downwards by means of handle bars;</p> <p>(3) remove strut mounting axle; during this operation strut should be supported by two men</p> <p>7. Secure special fixture onto strut, relieve nitrogen pressure to zero and drain AN-10 fluid from L.G. nosewheel</p> <p>8. Fill 690 cu.cm. of AN-10 hydraulic fluid into L.G. nosewheel strut (Fig. 52)</p> <p>9. Re-mount nosewheel strut on aircraft in the order reverse to dismounting</p> <p>10. Charge main and nosewheel L.G. struts with nitrogen from ground nitrogen bottle</p> <p>11. Remove wheel shimmy damper from nosewheel strut</p> <p>12. Clean shimmy damper from dirt and wipe it with clean cloth or blow with compressed air</p> |  | <div data-bbox="820 1354 1112 1543" data-label="Image"> </div> <p data-bbox="820 1543 1112 1627"> <b>FIG. 52 CHARGING NOSEWHEEL SHOCK STRUT</b><br/>                     1 - shock strut; 2 - connection of strut through charging valve (valve removed); 3 - connection for charging strut with hydraulic fluid; AN-10 hydraulic fluid may be charged either through connection Ref. No. 2 or through connection Ref. No. 3; 4 - injection gas.                 </p> |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 31  |                  | In 7 sheets<br>Sheet 5       |
|---|---|------------------|------------------------------|
| LANDING GEAR  | GRADING AMT-10 HYDRAULIC FLUID IN L.G. SHOCK STRUTS AND<br>ROCKERS, SHIMMY DAMPER |                  | Man-hours<br>required - 2.50 |
| Procedure   | Technical requirements  | Fault correction |                              |
| <p>13. Screw compensator from shimmy damper body, screw out filler hole plugs and thoroughly drain old AMT-10 hydraulic fluid from shimmy damper.</p> <p>14. Using clean fresh AMT-10 fluid wash inner spaces of operating chambers, central chamber of shimmy damper and compensation chamber of compensator. Drain washing fluid from shimmy damper.</p> <p>15. Place shimmy damper horizontally, with bellcrank down. Operating through filler holes, fill operating chambers with clean AMT-10 hydraulic fluid to level of body top edge.</p> <p>16. Screw compensator into shimmy damper body. Before doing this, check condition of sealing ring. When screwing in compensator be sure not to damage sealing elements.</p> <p>17. Screw plug out of compensator rod, screw adapter into rod and connect adapter for filling AMT-10 hydraulic fluid.</p> | <p>Parking fluid temperature should be <math>20 \pm 5^{\circ}\text{C}</math></p>  |                  |                              |

139

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 31  |                 | In 7 sheets<br>Sheet 6    |
|---|---|-----------------|---------------------------|
| LANDING GEAR  | CHANGING AMT-10 HYDRAULIC FLUID IN L.G. SHOCK SPRINGS AND ROCKER ARM SHOCK DAMPER |                 | No. hours required - 2.50 |
| Procedure   | Technical requirements  | Fuel connection |                           |
| <p>18. Using syringe, charge AMT-10 fluid until fluid begins to pour out in clean air bubble-free jets from filler holes of operating chambers</p> <p>19. Screw plugs into filler holes of operating chambers and effect three or four full turns of bellcrank arm from one extreme position to the other</p> <p>20. Set arm neutral and again screw plugs out of filler holes of operating chambers</p> <p>21. Once more pump AMT-10 fluid with syringe into shimsy damper until it is ejected from filler holes of operating chambers in clean jets, after which stop fluid pumping</p> <p>22. Screw plugs into filler holes of operating chambers and lock them</p> <p>23. Using syringe, fill compensation chamber with AMT-10 hydraulic fluid. Charge compensation chamber until compensator rod extends by 24 in.</p> <p>Keep shimsy damper in this position during 1 hour; no leakage of fluid at body joints shall be tolerated</p> |   |                 |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |                        |   |  |                          |
|---|------------------------|---|--|--------------------------|
| Supplement to Inspection Guide No. 21   |                        | PROCESS CHART No. 31  |  | In 7 sheets<br>Sheet 7   |
| LABORING STEP   |                        | CHANGING AND-10 HYDRAULIC FLUID IN L.G. SHOCK STRUTS AND NOSEWHEEL SHOCK DAMPER   |  | Man-hours required - 2.5 |
| Procedure   | Technical requirements | Fault correction  |  |                          |
| <p>24. Using aluminum rod, immediately press ball of compensator rod non-return valve to drain hydraulic fluid from compensator. This being done, compensator rod will travel down. Disconnect fluid drainage as soon as white reference mark on rod becomes aligned with compensator cover surface.</p> <p>25. Screw plug into filler hole of compensator rod and lock it. Lock compensator to shimmy damper body.</p> <p>26. Re-mount shimmy damper on strut and lock nuts of attachment bolts and hinge joints of shimmy damper ballcrank.</p> |                        |   |  |                          |
| Accessories   |                        | Tools   |  |                          |
| <p>Fixture for drain plugs of wing fuel tanks, 72-7806-370</p> <p>Bucket</p> <p>Syringe</p>   |                        | <p>French for nut of main L.G. strut shaft, 72-7806-30</p> <p>Wrench for dismounting L.G. nosewheel strut, 72-7804-57</p> <p>Wrenches, 9 x 11; 14 x 17 and 19 x 22</p> <p>Screwdriver for cross-slotted screws</p> <p>Screwdriver, ordinary</p> <p>Flat-nose pliers</p> |  |                          |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 32   |   | In 6-000000 Sheet 1       |
|--|--|---|---------------------------|
| LANDING GEAR   | CHECK RETRACTION AND EXTENSION OF LANDING GEAR   |   | Man-hours required - 0.30 |
| Procedure  | Technical requirements   | Fault correction  |                           |
| 1. Lift aircraft by means of hydraulic jacks until its wheels clear ground.<br>2. Make sure that main hydraulic system is charged with AHT-10 hydraulic fluid; to check, open filler neck cap of main system section reservoir and check amount of AHT-10 fluid by means of dip stick. | Fluid level in hydraulic reservoir should be between upper and lower reference marks on dip stick.     | If fluid level is below lower reference mark on dip stick, add AHT-10 fluid into reservoir. |                           |
| 3. Check position of L.G. control valve change-over switch handle in cockpit.  | Handle of L.G. control valve change-over switch should be fixed in NEUTRAL (EESTPAIBEO) position.      |   |                           |
| 4. Connect hoses from ground hydraulic pump to aircraft connections of main (Fig. 53) hydraulic system of aircraft; these connections are located at fuselage starboard side; connect ground electric power supply source to terminals of aircraft electric main (Fig. 54).            |  |   |                           |
| 5. In cockpit: turn on circuit-breakers bearing inscriptions L.G. (BACCH) and FLAPS (BAPKABEB).  |  |   |                           |
| 6. Engage ground hydraulic pump and build up pressure in main hydraulic system.  | Pressure in main hydraulic system (as read by pressure gauge) should be $210 \pm 10 \text{ kg/cm}^2$ . |   |                           |

161

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 32

In 6 sheets  
Sheet 2




FIG. 32. CONNECTING GROUND-HYDRAULIC INSTALLATION TO HYDRAULIC SYSTEM  
1 - delivery line hose, 2 - return line hose, 3 - hydraulic reservoir to prevent suction air to pump hoses





FIG. 34. CONNECTING GROUND ELECTRIC POWER SUPPLY SOURCE

142

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


| Supplement to Inspection Guide No. 21  | PROBET'S CHECK No. 22   |                  | In 8 steps Sheet 3         |
|--|---|------------------|----------------------------|
| LANDING GEAR   | CHECK RETRACTION AND EXTENSION OF LANDING GEAR  |                  | Time-hours required - 0.50 |
| Procedure  | Technical requirements  | Fault correction |                            |
| <p>7. Command: CLEAR LANDING GEAR! (OT BACK). Upon return of LANDING GEAR CLEAR! (BACK) acknowledgment reset L.G. control valve change-over switch handle to RETRACTED (JERFED). In the course of landing gear retraction check the following:</p> <p>(a) synchronism in retraction of main and nosewheel landing gear struts and retraction time;</p> <p>(b) operating reliability of strut turning mechanism;</p> <p>(c) sound operation of sequence valves;</p> <p>(d) sound engagement of struts and wheel doors by up-locks;</p> <p>(e) clearance between main L.G. strut fairing and wing skin; clearances between wheel doors and fuselage skin and clearances between nosewheel strut fairing and fuselage skin (Fig. 55);</p> <p>(f) operating reliability of automatic wheel braking system at retraction.</p> | <p>Nosewheel and main L.G. struts, as well as wheel doors should retract and get engaged by their respective up-locks with specific clicks; this should be accompanied by illumination of three red indicator lights on L.G. indication board in instrument panel and by illumination of red lights LANDING GEAR EXTENDED (BACK JERFED) on light indication panel No. 6</p> <p>When retracted, L.G. doors and fairings should conform to contours of wing and fuselage. Clearances between fairings and wing skin should be as specified in Fig. 55</p> <p>Two-pointer pressure gauge MB-12 installed in cockpit should read <math>4 \frac{kg}{cm^2}</math></p> |                  |                            |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



246

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                  |                           |
|--|---|------------------|---------------------------|
| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 32  |                  | In 8 charts<br>Sheet 5    |
| LANDING GEAR   | CHECK REFRACTICS AND EXTENSION OF LANDING GEAR  |                  | Man-hours required - 0.50 |
| Procedure  | Technical requirements  | Fault correction |                           |
| <p>Ten to fifteen seconds after flashing up of red indicator lights place landing gear control valve change-over handle to <b>NEUTRAL</b> and fix it in this position;</p> <p>(c) extend flaps and check functioning of <b>EXTEND LANDING GEAR (EM/EXTEND)</b> light indication on landing gear indication board and aircraft instrument panel. Retract flaps</p> <p>8. Extend landing gear: give command: <b>CLEAR LANDING GEAR</b> and, upon receiving <b>LANDING GEAR CLEAR</b> answer, place landing gear control valve change-over handle to <b>EXTENDED (EM/EXTEND)</b> position</p> | <p>Nosewheel and main L.G. struts should extend and get fixed by ball locks in landing gear actuating cylinders;</p> <ul style="list-style-type: none"> <li>- L.G. <b>EXTENDED</b> green indicator lights should illuminate on landing gear indication board;</li> <li>- nosewheel strut position mechanical indicator should go out from its socket</li> </ul> |                  |                           |

245

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 12   |                  | In 8 sheets<br>Sheet 6       |
|---|--|------------------|------------------------------|
| LANDING GEAR  | CHECK RETRACTS AND EXTENSION OF LANDING GEAR   |                  | Man-hours<br>required - 0.50 |
| Procedure   | Technical requirements   | Fault correction |                              |
| <p>Ten to fifteen seconds after illumination of green L.G. indicator lights place landing gear control valve change-over handle to NEUTRAL and fix it in this position.</p> <p>9. Check operation of automatic wheel braking system; to this end:</p> <p>(a) disconnect electric connector of JA-2 transmitter (antiskid detector) (on right or left main L.G. wheel);</p> <p>(b) in cockpit: turn on circuit-breaker of wheel automatic braking system;</p> <p>(c) operate cock to engage J233/1 valve of EP-35 nonwheel brake system;</p> <p>(d) press brake control lever and build up 4 - 5 kg/cm<sup>2</sup> pressure in brake system;</p> | <p>This operation should be carried out collectively with electrical equipment specialists.</p> <p>Note. Aircraft beginning with Serial No. 747015 has EP-35 brake wheels with braking discs made from powder metal, grade GM-11 with friction coefficient of 0.2 to 0.22; brake system employs J234/1 valve with 1:1.5 reduction ratio.</p> |                  |                              |

146

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |  |                              |
|---|---|--|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHECKLIST No. 22  |  | In 2 sheets<br>Sheet 7       |
| LANDING GEAR  | CHECK EXTRACTION AND EXTENSION OF LANDING GEAR  |  | See hours<br>required - 0.50 |
| Procedure   | Technical requirements  | Fault correction   |                              |
| (e) close terminals of YA-23 transmitter (antiskid detector) connectors on right or left K-82 main L.G. wheel;                                      | Closing of terminals should result in operation of two J253/1 valves of main L.G. strut wheel and nosewheel being checked<br>J253/1 valves relieve air pressure, and wheels become unbraked.<br>Opening of terminals should result in braking of wheels | <b>Note:</b> Carry out checks on right and left wheels in succession. Check system for proper functioning by hand-spraying of brake and released wheels and by sound produced by air escaping from J253/1 valves |                              |
| (f) couple electric connector of YA-23 transmitter of main L.G. wheel under test and uncouple electric connector of YA-24 transmitter of nosewheel; | This should result in operation of J253/1 valve of nosewheel, and nosewheel should become released (earwhile main L.G. wheels remain braked). Opening of terminals should result in braking of nosewheel  |  |                              |
| (g) couple electric connector of YA-24 transmitter  |   |  |                              |
| 10. Check all three L.G. wheels for synchronous braking and releasing; check braking time; this should be 2 seconds maximum                         |   |  |                              |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                              |
|---|---|------------------|------------------------------|
| Supplement to Inspection Guide No. 21                   | PROCESS CHART No. 12  |                  | In 5 sheets<br>Sheet 8       |
| LANDING GEAR  | CHECK EXTRACTION AND EXTENSION OF LANDING GEAR  |                  | Man-hours<br>required - 0.50 |
| Procedure   | Technical requirements  | Fault correction |                              |
| 11. Operate hydraulic jacks to lower aircraft to ground |   |                  |                              |
| Accessories   | Tools   |                  |                              |
| Ground hydraulic installation                           | Branch, 1 1/2 x 17, for connection of hydraulic reservoir transmission pipe<br>Branch, 3/4 x 40, for connecting hoses to aircraft pipe unions |                  |                              |

145

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |   |                              |
|--|--|---|---|------------------------------|
| Supplement to Inspection Guide No. 21  |  | PROCESS START No. 23  |   | In 2 sheets<br>Sheet 1       |
| LANDING GEAR   |  | CHECKING CLEARANCE BETWEEN STOP ON WHEEL AXLE SHAFT AND BOTTOM OF MAIN L.G. STRUT STOP INNER TUBE   |   | Man-hours<br>Required - 0.30 |
| <p><b>Procedure</b></p> <p>1. Use hydraulic jacks to lift aircraft until its wheels clear ground.</p> <p>2. With main L.G. struts extended and mechanic locks of axle shafts closed check clearance between stop on wheel axle shaft and inner tube bottom (Figs 56 and 57). For checking, lift wheel as far as it will go.</p> <p>3. Operate hydraulic jacks to lower aircraft.</p> |  | <p><b>Technical requirements</b></p> <p>Clearance between stop on wheel axle shaft and inner tube bottom should be within 0.03 to 0.25 mm</p> | <p><b>Fault correction</b></p> <p>If clearance between stop and inner tube bottom is smaller or greater than specified, adjust clearance by screwing intermediate bushings of wheel turning mechanism control rod. Having adjusted clearance, lock end lugs of control rod and check control rod tension. Control rod should freely turn under hand effort about its axis in ball supports.</p> <p>It is absolutely forbidden to file down head of stop (bolt) on wheel axle shaft with a view to increasing clearance.</p> |                              |
| <p><b>Accessories</b></p>  |  | <p><b>Tools</b></p> <p>Set of feeler blades (0.01 to 1 mm)</p>  |   |                              |

349

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS HEAD No. 33

In 2 sheets  
Sheet 2




FIG. 34 MEASURING CLEARANCE BETWEEN STOP ON STRUT  
AXLE SHAFT AND SHOCK STRUT INNER TUBE BOTTOM CLEAR  
VIEW OF AXLE SHAFT



FIG. 35 MEASURING CLEARANCE BETWEEN STOP ON STRUT  
AXLE SHAFT AND SHOCK STRUT INNER TUBE BOTTOM

150

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 34  | In 7 sheets Sheet 1  |
|---|---|--|
| WING  | INSPECTION AND LUBRICATION OF WING ATTACHMENT JOINTS. CHECKING CONDITION OF PIPELINES AND ELECTRICAL WIRING HARNESS   | Non-locks required - 0.40 (0.25 when wing jacking bolts are removed)                 |
| Procedure   | Technical requirements  | Fault correction   |
| <p>1. Remove fairings (fillets) in front and middle parts of wing panel</p> <p>2. Extend flaps to gain access to wing-to-frame No. 28 attachment joint (Fig. 59)</p> <p>3. Wash wing-to-fuselage attachment joints with clean (unleaded) gasoline and blow them with compressed air</p> <p>4. Inspect attachment joints for cracks (use magnifier glass for inspection). When examining attachment joints pay special attention to areas of sharply bent elements (fillets).<br/>Make sure that bolt nuts and wing-to-frame No. 28 attachment bolt head are securely locked.<br/>When faults or fault traces are detected (such as shearing of nut locking fittings, loose fitting of bolt heads or nuts to attachment joint structure, etc.) remove bolts of all attachment joints</p> | <p>Wing panel is attached to fuselage by means of five attachment joints at frames Nos 13, 16, 22, 25 and 28 (Fig. 56)</p> <p>Front fairing fastening screws should be driven out only by means of special screwdrivers provided with pinned blade since otherwise screw locking arrangements will be damaged</p> <p>It is prohibited to shear locking cotter pin by nut rotation. When examining attachment joints and bolts for cracks pay special attention to areas where bolt heads end and bolt</p> | <p>If cracking is suspected test part concerned with magnifier inspection method</p> |

SECRET/NO FOREIGN DISSEM

Poor Original


SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 34

In 7 sheets  
Sheet 2



152

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 34  |                  | 12 1/2 sheets<br>Sheet 3   |
|--|---|------------------|--|
| TITLE  | INSPECTION AND LUBRICATION OF WING ATTACHMENT JOINTS.<br>CHECKING CONDITION OF PIPELINES AND ELECTRIC WIRING HARNESS  |                  | Man-hours re-quired - 0.40<br>(0.25 when wing attaching bolts are removed) |
| Procedure  | Technical requirements  | Fault correction |  |
| <p>and unjoint wing panel as instructed below</p> <p>Unjoint wing panel from fuselage as follows:</p> <p>(a) extend flap to clear access to attachment joint on frame No. 20;</p> <p>(b) reduce pressure in hydraulic systems to zero by operating aircraft control stick;</p> <p>(c) reduce pressure in oxygen systems to zero;</p> <p>(d) reduce pressure in pneumatic systems (main and emergency) to zero;</p> <p>(e) lift aircraft by means of hydraulic jacks until its wheels clear ground and install trestles (jack horses) under frames Nos 22 and 26;</p> | <p>shanks begin, as well as to areas of sharp structural angling in attachment joints. In case bolt shank is work-hardened or stepped, replace faulty bolt.</p> <p><b>WARNING.</b> It is forbidden to eliminate work-hardening, scores and "stepping" on outer surfaces of bolts by filing or grinding.</p> <div data-bbox="820 1470 1096 1659" style="text-align: center;"> </div> <p><b>SEE ACCESS TO WING-FUSELAGE ATTACHMENT JOINT ON FRAME NO. 25 FLAP EXTENDED</b></p> <p>1 - wing to fuselage attachment joint on frame No. 20.<br/>2 - wing flap; 3 - flap; 4 - wing; 5 - locking groups of bolt.</p> |                  |  |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 3A   |                  | In 7 sheets   |
|--|--|------------------|---|
| WING   | INSPECTION AND LUBRICATION OF WING ATTACHMENT JOINTS, CHECKING CONDITION OF PIPELINES AND ELECTRIC WIRING HARNESS  |                  | Sheet 4<br>Manufacture required - 6.45 (6.45 when wing jointing bolts are received) |
| Procedure  | Technical requirements   | Fault correction |   |
| <p>(f) Lower aircraft to jack horses under frames Nos 22 and 23;</p> <p>(g) bring trolleys to under wing panels and adjust them in height;</p> <p>(h) remove fairings and fillets from wing leading edge and middle sections;</p> <p>(i) remove covers of access holes in wing leading edge section at fuselage;</p> <p>(j) disconnect aileron control rod from ballcrank at wing attachment joint;</p> <p>(k) disconnect L.C. strut mounting and lock emergency opening cable;</p> <p>(l) disconnect pipelines of hydraulic and pneumatic systems at wing attachment joint;</p> <p>(m) disconnect fuel system pipelines running from wing fuel compartment;</p> <p>(n) disconnect pipelines of oxygen system;</p> <p>(o) disconnect electric and radio connections;</p> | <p>Trolley should be installed under its respective wing; ball socket of wing should fit tightly over ball projection of trolley. The arc-shaped support of trolley should fit tightly to wing leading edge.</p> <p>To prevent penetration of dirt and foreign objects into pipelines of fuel, hydraulic, pneumatic and oxygen systems after their disconnection it is necessary to plug open ends or wrap them with PTC film. Electric and radio connection terminals should be</p> |                  |   |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



| Supplement to Inspection Guide No. 21   |   | PROCESS CHART No. 3  | In 7 steps  |
|---|---|--|---|
| WING  |   | INSPECTION AND LUBRICATION OF WING ATTACHMENT JOINTS.<br>CHECKING CONDITION OF PIPELINES AND ELECTRIC WIRING HARNESS                 | Step 5<br>Sub-step re-<br>quired - 6, 4, 0<br>(6, 4, 0 when wing<br>jointing bolts<br>are required) |
| Procedure   | Technical Requirements                    | Fault correction   |   |
| <p>(p) uncocker pin and screw off nuts of wing jointing bolts at frames Nos 13, 16, 22, 25 and 28;</p> <p>(q) using special puller (Fig. 60) remove bolts of wing-to-fuselage attachment joints. On attachment joint at frame No. 16: remove lower bolt first, then - horizontal bolt, and next remove upper bolt using special wrench. The last to be removed is bolt of attachment joint at frame No. 13;</p> <p>(r) carefully rocking wing panel by tip, move trolley-mounted wing away from fuselage.</p> <p>To re-joint wing panel reverse un-jointing procedure.</p> <p>Having jointed wing panel to fuselage and having coupled pipelines of hydraulic, pneumatic and fuel systems and electric and radio connections, check operation of aileron, flap, landing gear and special equipment controls</p> | <p>wrapped in clean cloth or PVC film</p> |  |   |
|   |   |    |   |
|   |   | <p>FIG. 60. PULLER FOR BOLT-TO-FUSELAGE JOINTING (APPLY)</p> <p>1 - puller; 2 - wing attachment joint on frame No. 22; 3 - wing.</p> |   |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 15  | In 2 sheets<br>Sheet 1   |
|--|---|--|
| TASK<br>INSPECTION AND LUBRICATION OF ALLERON ATTACHMENT JOINTS.<br>CHECKING WEIGHT BALANCE BOLTS FOR SEVERE LOCKING   |   | Man-hours<br>required - 2.40   |
| Procedure  | Technical requirements  | Fault correction   |
| <p>1. Screw out attachment screws of alleron bellcrank fairing and remove fairing (Fig. 61)</p> <p>2. Uncorktopia and screw off nut; remove bolt which couples alleron control rod with alleron-mounted bellcrank</p> <p>3. Move alleron down, uncorktopia and screw nuts off bolts of attachment joints in alleron root portion, and remove bolts (Fig. 62)</p> <p>4. Moving alleron down, remove from its middle attachment joint two bolts (Fig. 63) which connect alleron link (shackle) with wing bracket</p> <p>5. Lower alleron until middle attachment joint link comes out of wing bracket. Bring alleron close to fuselage, release cantilever (rod hinge) attachment elements of alleron and demount alleron by moving it down.</p> <p>6. Wash attachment joints and open bearings with clean (unleaded) gasoline and inspect them for cracks and corrosion. Make sure that bearings rotate freely, without jamming</p> | <p>Note: The Process Chart envisages removal of alleron</p>  <p>FIG. 61 ALLERON CONTROL BELLCRANK FAIRING REMOVED<br/>1 - bellcrank; 2 - nut; and 3 - alleron bellcrank; 4 - alleron; 5 - nutting</p> |  <p>FIG. 62 ALLERON ROOT SECTION ATTACHMENT JOINT</p> |


155

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  |  | PROCESS CHART No. 35  |  | To 2 sheets Sheet 2       |
|--|--|---|--|---------------------------|
| WING   |  | INSPECTION AND LUBRICATION OF ALLERON ATTACHMENT JOINTS.<br>CHECKING EIGHT BALANCE BOLTS FOR SECURE LOCKING |  | Man-hours required - 2.40 |
| Procedure  |  | Technical requirements  | Fault correction   |                           |
| 7. Check alleron weight balance bolts for secure locking<br>8. Lubricate attachment joints and bearings with grade HEATEM-201 lubricant and re-mount allerons on wing (if they have been dismounted) reversing dismounting procedure |  |   |  <p>FIG. 41 ALLERON WING MIDDLE ATTACHMENT JOINT (BOTTOM VIEW)</p> |                           |
| Accessories  |  | Tools   |  |                           |
| Syringe<br>Magnifier glass, X10<br>Brush<br>Pocket, zinc<br>Tray   |  | Socket wrenches, 14 and 17<br>Screwdriver for cross-slotted screws<br>Flat-nose pliers                      |  |                           |

159


SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM



| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 36   | In 3 sheets<br>Sheet 1   |
|---|--|--|
| NAME  | INSPECTION AND LUBRICATION OF FLAP CARRIAGES   | Man-hours<br>required - 0.50   |
| Procedure   | Technical requirements   | Fault correction   |
| <ol style="list-style-type: none"> <li>1. Drive out screws and remove fairing at end of outer guiding rail</li> <li>2. On aircraft of earlier makes: remove clamp from end of inner guiding rail. On this end, withdraw cotter pins and remove the locking pins</li> <li>3. Remove flap (Fig. 64)</li> <li>4. Unbolt and screw off nut, and disconnect hydraulic cylinder operating rod from flap attachment joint (Fig. 65)</li> <li>5. Roll flap backward until carriages clear guiding rails (Fig. 66)</li> <li>6. Remove carriage bearings and wash them in clean gasoline</li> <li>7. Inspect carriages and bearings for cracks and dirt</li> <li>8. Lubricate bearings with grade GRADE-201 lubricant</li> <li>9. Wash guiding rails with clean gasoline, inspect them and coat with grade GRADE-201 lubricant</li> </ol> | <p>Flaps can be hinged by 26°30'. Deflection angle is determined by measuring distance between flap root rib and wing; this distance should be 368 ± 8 mm (this distance is mean standard; it may differ for each individual aircraft, and is indicated in Levelling Diagram supplemented to each aircraft's Service Log). Difference in distances for right and left flaps should not exceed 2 mm. Width of gap between wing skin and flap as measured at rib No. 2 with flap extended, should be equal to 52 ± 4 mm</p> <p>Carriage bearings should rotate smoothly, without jamming or squeak</p> <p>Outer races should be securely held in bearing and should be free from cracks. Cages and balls should be intact</p> <p>Guiding rails should be free from scoring and dents. Grooving caused by side bell supports shall be tolerated</p> |  <p>FIG. 64. GENERAL VIEW OF FLAP</p> <p>1 - No. 2 - ball carriage, 3 - race carriage, 4 - attachment point of the control cylinder operating rod</p> <p>If bearings run with binding or squeak, replace them</p> |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |   |                              |
|---|---|---|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 35  |   | In 5 sheets<br>Sheet 2       |
| WING  | INSPECTION AND LUBRICATION OF FLAP CARTRIDGES   |   | Man-hours<br>required - 0.50 |
| Procedure<br><br>10. Reinspect flap on wing reversing disassembling procedure<br><br> <p>FIG. 45 FLAP HYDRAULIC CYLINDER OPERATING ROD (FLAP REMOVED)<br/>                 1 - operating rod of flap control hydraulic cylinder;<br/>                 2 - cylinder; 3 - locknut; 4 - wing.</p> | Technical requirements<br><br>Due to the fact that flowmeters are removed from flap control hydraulic system, it may occur that during flap extension and retraction checks on ground their full extension travel will be non-synchronous, i.e. one flap just starts to move while the other has been already extended through full travel range. In this case it is necessary to disconnect hydraulic cylinder operating rod from lagging flap and to check flap for easy movement on guiding rails by applying tractive effort of not over 5 kg at middle part of flap trailing edge. Flap should go out completely; if this in the case this means that flap is not jammed in guiding rails. Non-synchronous will not be present in flight due to motion of dynamic pressure upon flaps. | Fault correction<br><br> <p>FIG. 46 CENTRAL VIEW OF FLAP CARTRIDGE</p> |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |                  |                              |
|--|--|---|------------------|------------------------------|
| Supplement to Inspection Guide No. 21  |  | PROCESS CHART No. 36  |                  | In 3 sheets<br>Sheet 3       |
| TITLE  |  | INSPECTION AND LUBRICATION OF FLAP CARRIAGES  |                  | Man-hours<br>required - 0.50 |
| Procedure  |  | Technical requirements  | Fault correction |                              |
| 11. Check flap play at trailing edge<br>12. Check flaps for proper adjustment and synchronous extension from ground hydraulic installation |  | Adjust extension and retraction motions of flap by means of eyeing of hydraulic cylinder operating rod; eyeing should be screwed in or out (see Fig. 62)<br>Play of extended flap should be 11 mm, and that of retracted flap - 2 mm<br>Lateral play of flap should be within 0.5 to 1 mm |                  |                              |
| Accessories  |  | Tools   |                  |                              |
|  |  | Screwdriver for cross-slitted screws<br>Flat-nose pliers<br>Wrenches, 14 x 17 and 19 x 22   |                  |                              |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 37  |                  | In 5 sheets, Sheet 1      |
|---|---|------------------|---------------------------|
| WISG  | INSPECTION OF GUIDING RAILS AND ROLLERS OF FLAPS.<br>CHECKING FLAPS FOR SIMULTANEOUS EXTENSION AND RETRACTION   |                  | Man-hours required - 0.50 |
| Procedure   | Technical requirements  | Fault correction |                           |
| <p>1. Command from cockpit:<br/>CLEAR FLAPS! Upon receiving FLAPS CLEAR acknowledgement, extend flaps by placing FLAPS ( SAFTMIR ) controls to EXTENSION</p> <p>2. Wash guiding rails 2 (Vigs 67 and 68) with clean (unleaded) gasoline</p> <p>Note. It is forbidden to carry out maintenance operations in cockpit when maintenance operations in flap wells are being done</p> <p>3. Inspect guiding rails and their attachment joints to make sure that locking fittings of attachment joint bolts are intact and guiding rails are free from scores</p> <p>4. Check flap actuating hydraulic cylinder for secure fastening to attachment joint on wing, and rod - for reliable attachment to flap; make sure that locking fittings are intact and attachment joint nuts are tightened</p> <p>5. Coat guiding rails and bearings of flap carriages with grade EMATEM-201 lubricant</p> | <p>Flaps should go down synchronously and through full travel range; guide rollers should assume extreme rear position in guiding rails</p> <p>Guiding rails should be clean. Rail races should be free from scoring. Up to 0.5 mm deep grooving on rail webs caused by support balls shall be tolerated. Attachment joints of guiding rails should be securely fastened</p> <p>Nuts of hydraulic cylinder-to-wing attachment joint bolts should be screwed fully on and locked. Hydraulic cylinder operating rod should be fastened to attachment joint on flap and locked in position</p> <p>Apply EMATEM-201 lubricant to guiding rails and ball bearings separately</p> |                  |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |                              |
|---|--|--|------------------------------|
| Supplement to Inspection<br>Guide No. 22  | PROCESS CHART No. 37   |  | In 3 sheets<br>Sheet 2       |
| TITLE   | INSPECTION OF SLIDING RAILS AND ROLLERS OF FLAPS.<br>CHECKING FLAPS FOR SYNCHRONOUS EXTENSION AND RETRACTION |  | Man-hours<br>required - 0.50 |
| Procedure   | Technical requirements   | Fault correction   |                              |
| 6. Retract and extend flaps, and check them for synchronous movement.<br>7. Check flap actuating hydraulic cylinders for leakage of AMJ-10 hydraulic fluid. Inspect from the side of operating rod and from the side of hydraulic cylinder cover. | Flaps should be retracted and extended in synchronism during not longer than 2 seconds.                      | If flaps movement is out of synchronism or if their extension or retraction time exceeds 2 seconds inspect associated units and flap control system pipeline connections for external air-tightness (examine for leakage of AMJ-10 hydraulic fluid). If leakage of AMJ-10 fluid has been detected, remove faulty unit and eliminate leakage or, in case of failure to do this, replace unit. If hydraulic fluid leakage has been detected in pipeline connection, screw off nut and examine pipeline at heading for cracks and quality of heading. When through with checking pipeline tighten nut by turning it on as far as it will go. See to it that neither misalignment nor overtightening is involved when pipeline is being coupled to connection. |                              |
|   |  |  |                              |
| FIG. 6. COVER SLIDING RAIL OF FLAP (ART. 7)   |  |  |                              |


164

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                              |
|---|---|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 37  |                  | In 5 sheets<br>Sheet 3       |
| TITLE   | INSPECTION OF GUIDING RAILS AND EDGES OF FLAPS.<br>CHECKING FLAPS FOR SIMULTANEOUS EXTENSION AND RETRACTION |                  | Man-hours<br>required - 0.30 |
| Procedure   | Technical requirements  | Fault correction |                              |
|  |   |                  |                              |
| FIG. 21. OUTER CUTTING RAIL OF FLAP (PART 72)                                       |   |                  |                              |
| Accessories   | Tools   |                  |                              |
| Syringe   | Flat-nose pliers<br>Wrench  |                  |                              |


365

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |                                      |  |  |
|---|--------------------------------------|--|--|
| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 35                 |  | In 10 sheets<br>Sheet 1  |
| FUSelage  | FUSelage DISASSEMBLY AND RE-JOINTING |  | See-burns procedure - 8 for unjointing and dismounting 12 for re-jointing and remounting |
| Procedure   | Technical requirements               | Fault correction   |  |
| <p>1. Place aircraft on level ground to obviate breakage of units and pipelines of engine and airframe during unjointing of fuselage tail section. Relieve working fluid pressure in main hydraulic system and hydraulic booster system to zero.</p> <p>2. Operate hydraulic jacks to lift aircraft until its wheels clear ground.</p> <p>3. Open covers of access holes leading to fuselage tail section-to-fuselage nose section attachment joints on frame No. 25 (Fig. 69) and screw off four nuts of lower fuselage jointing bolts to provide installation of trolley.</p> <p>a. Bring special trolley to under fuselage tail section and fasten fuselage tail section on it; place tray under fuselage in area of frame No. 25 (Figs 70 and 71).</p> <p>5. Open covers of access holes leading to aircraft controls and disconnect control rods (Fig. 72). Remove impact pressure intake dust arrangements and uncouple electric connector.</p> |                                      |  <p>FIG. 8. LOCATION OF JOINTING BOLTS OF FUSelage NOSE AND TAIL SECTIONS ON FRAME NO. 25.<br/>A) access cover closed, B) access cover open.</p> |  |

166

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   |  | PROCESS CHART No. 30  |  | In 10 sheets<br>Sheet 2   |  |
|---|--|---|--|---|--|
| FUSELAGE  |  | FUSELAGE DISCONNECTING AND RE-JOINING   |  | Man-hours Required<br>- 6 for unloading<br>and disconnecting; 12<br>- for re-joining<br>and re-mounting |  |
| Procedure   | Technical requirements   | Fault correction  |  |   |  |
| 6. Deflect stabilizer leading edge section down (Fig. 73).<br>7. Screw-out attachment screws, remove vent pipe (Fig. 74) and demount tail fairing. Open access holes on top at frame No. 30 and disconnect bolts which fasten hydraulic cylinder cooling branch pipes.<br>8. On fuselage top, starboard, open cover of access hole leading to stabilizer controls and uncouple synchronization (slaving) transmitter electric connector. Disconnect six attachment joints of afterburner removable section control rods (Fig. 75).<br>9. Disconnect two hydraulic system pipes which run to jet nozzle flaps control cylinder (Fig. 76).<br>10. Remove front ring with nozzle flap control hydraulic cylinders (Fig. 77).<br>11. Remove drag chute with container and extract drag chute container screen and thermocouple. | <p>FIG. 30. POSITION OF SPECIAL TROLLEY UNDER FUSELAGE TAIL SECTION<br/>                     1 - fuselage tail section, 2 - support rails placed under fuselage tail section, 3 - frame No. 28, 4 - frame No. 25</p> | <p>FIG. 77. REMOVING FUSELAGE TAIL SECTION ON SPECIAL TROLLEY AT FRAME NO. 30<br/>                     1 - fuselage tail section, 2 - trolley, 3 - frame No. 28, 4 - frame No. 25</p> |  |   |  |



SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |  |   |
|---|---|--|---|
| <p>Supplement to Inspection Guide No. 21</p>  | <p>PROCESS CHART No. 30</p>   |  | <p>In 30 sheets<br/>Sheet 3</p>   |
| <p>FUSELAGE</p>   | <p>FUSELAGE DISMANTLING AND RE-JOINING</p>  |  | <p>Man-hours required<br/>- 8 for unjointing and dismantling; 12 for re-joining and reoutting</p> |
| <p>Procedure</p>  | <p>Technical requirements</p>   | <p>Fault correction</p>  |   |
| <p>12. Disconnect vent pipeline of afterburner (Fig. 76) and vent pipeline accessible through hole behind frame No. 25</p> <p>13. Remove on starboard side loop of WFO-26 II marker receiver to obtain access to thermocouples (Fig. 78)</p> <p>14. Disconnect and remove from connections four thermocouple transmitters (Fig. 80)</p> <p>15. Disconnect wires from engine afterburner ignition plug (Fig. 81) and receiver adapter</p> <p>16. Disconnect main fuel tank pressurization pipeline (Fig. 82): access from fuselage port side</p> <p>17. Disconnect four connections of hydraulic pipes (Fig. 83) at quick-disconnect valves (pressure in hydraulic systems should be zero)</p> <p>18. Disconnect air system pipe (at zero pressure in air system)</p> <p>19. Disconnect fuel system pipelines in fuselage superstructure</p> |  <p>FIG. 71 POSITION OF STABILIZER SECTIONS BEFORE FUSELAGE JACKING</p> |  <p>FIG. 72 INSTALLING STABILIZER AND ELEVATOR CONTROL BELLCRANKS THE AIRCRAFT ON CONTROL ROD CONNECTION POINTS</p> |   |


153

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No.21  | PROCESS CHART No.20   |   | In 10 sheets<br>Sheet 4  |
|---|---|---|--|
| FUSELAGE  | FUSELAGE DIS-JOINTING AND RE-JOINTING   |   | 2 1/2 hours required - 6 for unjointing and dismounting 12 - for re-jointing and re-mounting |
| Procedure   | Technical requirements  | Fault correction  |  |
| <p>20. Disconnect twelve electric and radio connectors (perform this operation collectively with electric and radio equipment specialists). Uncouple connectors with due care since they are not attached to airframe structure.</p> <p>21. Unlock attachment fittings (rollers) of engine tailpipe at frame No.36 (Fig. 74).</p> <p>22. Screw off eighteen nuts of jointing bolts on frame No.25.</p> <p>23. Insert drift bars in access holes along reference line of aircraft both at starboard and port sides and, using drift bars as levers and gradually moving trolley off, carefully move fuselage tail section away from fuselage. As fuselage tail section is being moved, make sure that there is no catching of parts inside fuselage.</p> | <p>To obviate damage when rolling out fuselage tail section see to it that fuselage structural members do not touch engine parts.</p> <p>As soon as fuselage tail section is separated from fuselage by about 300 mm backward and tailpipe rollers clear rails it is necessary to screw rollers out to ensure that fuselage tail section passes through nozzle flaps.</p> |  <p>FIG. 74 CONNECTION OF FUEL SYSTEM VENT PIPE</p> |  |


169

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |                         |
|--|--|---|-------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 20   |   | In 16 sheets<br>Sheet 5 |
| FUSELAGE   | FUSELAGE DISJOINTING AND RE-JOINTING   |   |                         |
| Procedure  | Technical requirements   | Fault correction  |                         |
| <p>24. Screw tailpipe rollers out as required (Fig. 25)</p> <p>25. Re-joint tail and nose sections of fuselage reversing unjointing procedure</p> <p>26. Upon re-jointing of fuselage carry out external inspection to make sure that all parts, units and locking fittings are in their proper places. This done, close access hole covers which have been removed</p> <p>27. After inspecting parts and units for proper installation it is absolutely necessary to check fuel system, aircraft controls and units located in fuselage tail section for proper functioning</p> | <p>Tighten jointing bolt nuts at frame No. 25 uniformly, screwing on diagonally opposite nuts in succession</p>  <p>FIG. 25 LOWER ATTACHMENT JOINT BY AFTERBURNER REMOVABLE SECTION THE AIRCRAFT'S CONTROL POD CONNECTION</p> | <p>Left roller should be driven out by 4.7 mm distance from bushing end, and right roller - by 0.5 mm</p> |                         |



120

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |                                     |   |  |
|---|-------------------------------------|---|--|
| Supplement to Inspection Guide No. 21   | PROCEDURE SHEET No. 36              |   | In 10 sheets<br>Sheet 6  |
| FUSELAGE  | FUSELAGE DISJOINTING AND RE-JOINING |   | Man-hours required<br>- 8 for unfastening and disassembling; 12 - for re-joining and re-assembly |
| Procedure   | Technical requirements              | Fault correction  |  |
|  |                                     |    |  |
| <p>FIG. 76. GENERAL ARRANGEMENT OF PIPELINES ON FUSELAGE PORT SIDE</p>              |                                     | <p>FIG. 77. FRONT END WITH NOZZLE FLAP CONTROL HYDRAULIC CYLINDER</p>   |  |
| Accessories   |                                     | Tools   |  |
| Tray<br>Hydraulic jacks (1 set)<br>Trolley for fuselage tail section, E2-7804-100   |                                     | Screwdriver, 150 and 200 mm<br>Screwdriver for cross-slitted screws<br>Flat-coke pliers<br>French, 76, E2-7804-95<br>French, 800 park-disconnect valve of main hydraulic system<br>72-7804-100<br>French for thermocouple, E2-7804-66<br>French, E2-7804-105<br>French, spool, 24, for engine tailpipe, E2-7804-100 |  |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHECK No. 38

In 10 sheets  
Sheet 7




FIG. 76. CONNECTING VENT PIPE OF TELESCOPE  
P/C COUPLING




FIG. 75. VIEW OF COMPARTMENT WITH MTU-M MARKER RADIO  
RECEIVER LOOP REMOVED





FIG. 74. ACCESS HOLE LEADING TO THERMOCOUPLE TRANSMITTERS (ON FUSELAGE RIGHT UPPER PART)

NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM




SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCEDURE SHEET No. 38

To 10 sheets  
Sheet 10




FIG. 88. TURNING OUT ROLLERS OF ENGINE TAILPIPE

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |  |                           |
|---|---|--|---------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 59  |  | In 5 sheets<br>Sheet 1    |
| Fuselage  | INSPECTION OF FUSELAGE INNER SKIN, INSPECTION AND CHECKING<br>CONDITION OF FITTING ATTACHMENT FITTINGS, SEALING RUBBER,<br>DISC VALVES AND ACCESSORIES (EXITS) LOCATED IN ENGINE<br>COMPARTMENT AND FUSELAGE TAIL SECTION   |  | Man-hours<br>required - 1 |
| Procedure   | Technical requirements  | Fault correction   |                           |
| 1. Unjoint fuselage tail section from<br>nose section<br>2. Inspect fuselage inner skin and<br>make sure that it is free from deforma-<br>tion (wraps), burnt through spots and<br>cracks<br>3. Inspect pipelines and accessories<br>(units) for leakage of AFR-10 hydraulic<br>fluid and fuel; pay special attention to<br>connections and joints; make sure that<br>pipelines and electric harness are attach-<br>ed securely, that there are no worn down<br>spots and that pipes and electric wires<br>do not touch adjacent parts; make certain<br>that locking fittings are in their right<br>places and intact<br>4. Inspect tailpipe attachment rollers<br>for condition. Check rollers for free<br>rotation by hand<br>5. If engine is removed, examine<br>rubber sealing of engine nose cone and<br>air intake; make sure that rubber is<br>neither deteriorated nor swollen and that<br>rubber ring does not project from its<br>bearing recess (Fig. 56); check condition | Pipes and bunched electric conduc-<br>tors should not touch adjacent parts<br>and should be securely attached<br>Maintain at least 3-mm clearances<br>between fixed parts and 5-mm clearances<br>between moving parts<br><br>Rollers should rotate freely,<br>without jamming<br><br>Rubber sealing should lie even in<br>recess and should be free from bulging<br>and deterioration<br>Limit ends of valves controlling<br>air flow should be bent out by 8 mm<br>from air cooler shell | In case pipes bear traces of rubbing<br>with worn down spots deeper than 0.2 mm,<br>replace faulty pipes<br><br>If rollers fail to rotate, remove<br>them and wash in gasoline. Replace rollers<br>if washing fails to correct trouble<br>Replace bulged or deteriorated rubber<br>sealing |                           |

176

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 99

In 5 sheets  
Sheet 2




FIG. 66. GENERAL VIEW OF RUBBER SEALING ON ENGINE NOSE CONE AND ARRANGEMENT OF AIR COOLER PLATE VALVES  
1 - air cooler; 2 - rubber sealing ring; 3 - plate valve of air cooler; 4 - frame No. 22; 5 - discharge ring of hydraulic system; 6 - frame No. 22.




FIG. 67. ATTACHMENT OF ENGINE NOZZLE FLAP CONTROL HYDRAULIC CYLINDER  
1 - covering nut of jet nozzle flap control cylinder; 2 - cylinder; 3 - jet nozzle flap control yoke; 4 - hydraulic unit attachment nut.

SECRET/NO FOREIGN DISSEM

Poor Ori

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |                        |  |  |                           |
|--|------------------------|--|--|---------------------------|
| Supplement to Inspection<br>Guide No. 21   |                        | PROCESS CHART No. 39   |  | In 5 sheets<br>Sheet 3    |
| PURPOSE  |                        | INSPECTION OF FUELER INNER SEAL; INSPECTION AND CHECKING<br>CONDITION OF FUELER MOUNTING FITTINGS, SHIMMED BRASS,<br>PRESS VALVES AND ACCESSORIES (GYP) MOUNTED IN ENGINE<br>COMPARTMENT AND FUELER TAIL SECTION |  | Man-hours<br>required - 1 |
| Procedure  | Technical requirements | Fault correction   |  |                           |
| of air ocular plate valve (make sure<br>that they are intact)<br>a. Check rubber sealing at<br>Cross No. 25 for condition<br>7. Check condition of jet nozzle flap<br>central hydraulic cylinder, attachment<br>rods of removable ring and skid rails<br>certain that these elements are intact<br>(Fig. 87) |                        |  |  |                           |
| Accessories  | Tools                  |  |  |                           |
| Inspectoscope (adjustable mirror for inspection of hard-to-<br>get-at places)<br>Extension lamp EI-36  | Servedriver            |  |  |                           |

178

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                             |
|---|--|------------------|-----------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS SHEET No. 30   |                  | In 15 sheets<br>Sheet 2     |
| Packaging   | INSPECTION OF CONE AND ANTI-SURGE SEATTLE CONTROL MECHANISMS   |                  | Man-hours<br>required- 1.50 |
| Procedure   | Technical requirements   | Fault correction |                             |
| <ol style="list-style-type: none"> <li>1. Extend cone manually to forward position</li> <li>2. Turn out cone attachment screws (along the periphery) and demount cone. Remove cone with utmost care so as not to damage actuating system</li> <li>3. Demount radio and radar antennas (This job should be performed by radio equipment specialists)</li> <li>4. Drive out antenna-mounting ring fastening screws and remove ring</li> <li>5. Disconnect hydraulic cylinder operating rod from cone moving tube assembly, and remove cone moving tube</li> <li>6. Check cone mechanics (inner fixed and outer moving tubes, cone control cylinder-to-outer tube attachment joint) with clean unleaded gasoline, and inspect indicated parts and assemblies</li> <li>7. Inspect de-icer tank for proper attachment</li> </ol> | <p>When inspecting, make sure that fixed tube surface is perfectly (air-rod-like) clean; it should be free from cracks, scores and corrosion. Moving tube should displace freely without jamming</p> <p>De-icer tank is attached to wall of fixed cone by means of three joles</p> |                  |                             |

179

SECRET/NO FOREIGN DISSEM

Poor Orig

SECRET/NO FOREIGN DISSEM

50X1-HUM


| Supplement to Inspection<br>Guide No. 21  | PROCESS CHECK No. 40  | In 15 sheets<br>Sheet 2      |
|---|---|------------------------------|
| FUSELAGE  | INSPECTION OF CONE AND ANTI-SURGE SHUTTER CONTROL MECHANISMS  | Man-hours<br>required - 1.50 |
| Procedure   | Technical requirements  | Fault correction             |
| <p>8. Check condition of limit switch and cone control mechanism</p> <p>Wash and examine fixed cone surface</p> <p>9. Apply thin layer of grade HEATHS-201 lubricant to surface of fixed cone and cone control cylinder operating rod</p> <p>10. Re-mount radio antenna and cone reversing dismounting procedure</p> <p>11. Extend anti-surge shutters by manual control</p> <p>12. Wash control rods, attachment joints and hinge connections of bellcranks and anti-surge shutter control rods with gasoline and blow them with compressed air (Fig. 68)</p> <p>13. Inspect control rods, attachment joints, hinge connections of bellcranks and rods, and attachment fittings of by-</p> | <p>Fastening screws of yokes should be tightened up and locked with EDM-1 wire. There should be felt pads under yokes</p> <p>Surface of fixed cone should be even and free from spots of scoring or attrition</p> <p>Apply lubricant to surface of fixed cone with cotton wool wad. When doing so shift movable tube from one extreme position to the other</p> |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Poor Quality

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 40   |                  | In 16 sheets<br>Sheet 4      |
|---|--|------------------|------------------------------|
| TITLE   | INSPECTION OF COME AND ANTI-SURGE SHUTTER CONTROL MECHANISMS   |                  | Man-hours<br>required - 1.50 |
| Procedure   | Technical requirements   | Fault correction |                              |
| <p>Inspect cylinders and pipes for corrosion, cracks and other faults; examine locking fittings for integrity and proper installation.</p> <p>14. Lubricate all attachment joints and hinge joints of anti-surge shutters with <u>TRAYN-201</u> lubricant.</p> <p>15. Retract anti-surge shutters.</p> <p><u>Checking Come Control Mechanism and Anti-Surge Shutters for Proper Operation (Check of Automatic Controls).</u></p> <p>1. Connect ground electric power supply source to aircraft. Perform the following on right-hand console in cockpit: turn on circuit-breakers COME (ID-870), ENGINE STOPPING LEVER INTERLOCK (ENGINE STOP), REENGAGEMENT OF BOOSTERS, HYDRAULIC SYSTEM INDICATOR (CHECKS BY, CHECKS CTRL. TEST.) and FUEL RESERVE LIGHT PANEL LAMP TEST, WARNING EFFECT INDICATOR (WARNING LAMP TEST OCT. 10000. 1. CENTRAL THERM. CTRL. RESET); on left-hand console:</p> | <p>Check operation of come and anti-surge shutters collectively with aircraft equipment specialists.</p> |                  |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                              |
|---|--|------------------|------------------------------|
| Supplecant to Inspection<br>Guide No. 21  | PROCESS START No. 40                                       |                  | In 16 sheets<br>Sheet 5      |
| FUSelage  | INSPECTION OF COKE AND ANTI-SURGE REPTER CONTROL MECHANISM |                  | Man-hours<br>required - 1.50 |
| Procedure   | Technical requirements                                     | Fault correction |                              |
| <p>                     Turn on cone and anti-surge shatter operating change-over switches, select AUTO (AEROMAL) position, and turn on circuit-breaker MAXIMUM AUGMENTED (MCAK MAXIMUM). Turn on STORAGE BATTERY, AIRCRAFT-GROUNDED (AIRCRAFTOP BATTERY, AIRCRAFTGROUNDED) switch on starboard side.<br/><br/>                     Place ENGINE PROCESSING (EXCEPTIONS EXTRACTOR) switch in engine processing box (located down on starboard side in area of fuselage frame No. 16) to "T" position.<br/><br/>                     2. Connect KAY-3 tester to dynamic and static pressure holes of pilot-static tube.<br/><br/>                     3. Connect ground hydraulic installation to aircraft connections of main hydraulic system and build up working pressure in system.<br/><br/>                     Disengage electric interlock of TS and ESC limit switches in KAY-121 afterburner control box by turning screw "T" to DISENGAGED (EXCUMPHED) position (KAY-121 box is mounted down on star-                 </p> |  |                  |                              |

183

SECRET/NO FOREIGN DISSEM

Poor Quality



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |   |                              |
|---|--|---|------------------------------|
| Supplement to Inspection<br>Data, No. 21  | PROCESS CHART No. 40   |   | In 16 sheets<br>Sheet 8      |
| FUSelage  | INSPECTION OF CONE AND ANTI-SURGE SHUTTER CONTROL MECHANISMS   |   | Man-hours<br>required - 1.50 |
| Procedure   | Technical requirements   | Fault correction  |                              |
| 12. Move aircraft control stick forward towards neutral position (deflect stabilizer leading edge section up)<br>13. Reset engine control lever from MINIMUM ADJUSTED to MAXIMUM ADJUSTED stop<br><br>Checking Operation of Air Intake Cone<br>14. Raise pressure in dynamic pressure line of pitot-static tube to obtain pressure corresponding to second extended position of cone<br><br>15. Apply hand effort of 40 or 50 kg to cone in retraction direction<br><br>16. Reduce pressure in dynamic line of pitot-static tube by 0.2 to 0.3 kg/cm <sup>2</sup> with respect to pressure of second extended position of cone<br><br>17. Reduce pressure in pitot-static tube dynamic pressure line to value corresponding to first position of cone | As stabilizer leading edge section is deflected to angle smaller than -20°, anti-surge shutters should close. This should result in engagement of afterburner, ADJUSTED (SPECIAL) light should go out and anti-surge shutters should open<br><br>This action should result in cone extension to second position<br><br>Cone should not retract; this verifies to sound operation of hydraulic locks<br><br>Under this pressure the cone should retract to first position<br><br>As a result of this action cone should be retracted to initial retracted position; | When checking cone extension relative to Mach numbers, take into consideration errors of Mach relay and Mach meter as stated in Certificates of these instruments |                              |

126

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                  |                              |
|--|---|------------------|------------------------------|
| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 40  |                  | No. 15 sheet<br>Sheet 3      |
| FORSLAGE   | INSPECTION OF CONE AND ANTI-SURGE SHUTTER CONTROL MECHANISMS  |                  | No. hours<br>required - 1.50 |
| Procedure  | Technical requirements  | Fault correction |                              |
| <p>1A. Shift engine control lever back to OFF position and set screw "E" on 1A3-1JH afterburner control box to initial position</p> <p><u>Working Air Intake Duct Cone and Anti-Surge Shutter Manual Controls</u></p> <p>1. Secure pressure in dynamic and static lines of pitot-static system to zero</p> <p>2. Place movable cone operating side selector switch to MANUAL (P/UNCS) position, and anti-surge shutters control change-over switch - to CLOSED (M/STW) position</p> <p>3. Place movable cone operating side selector switch to first extended position</p> | <p>anti-surge shutters should get retracted; blocking system should get disengaged; CONE EXTENDED (CONEXT INDICATOR) indicator light should go out</p> <p>As engine control lever passes MAXIMUM AUTHORIZED stop anti-surge shutters should remain closed. Automatic stop should not hamper full retraction of engine control lever</p> <p>This should result in flashing up of CONEXT EXTENDED indicator light on E-4 light indication panel, and in extension of cone to first position</p> |                  |                              |

187

SECRET/NO FOREIGN DISSEM

Poor Quality

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 40  |                             |
|---|---|-----------------------------|
| INSPECTION  | INSPECTION OF COSE AND ANTI-SURGE SHUTTER CONTROL MECHANISMS  |                             |
|   |   | In 16 sheets<br>Sheet 10    |
|   |   | Man-hours<br>required - 1.5 |
| Procedure   | Technical requirements  | Fault correction            |
| 4. Place switch to second extended position   | This should result in cone extension to second position   |                             |
| 5. Place switch back to first extended position   | Cone should go back to first extended position  |                             |
| 6. Place switch to RETRACTION (RETRACT) position  | Cone should begin its retraction movement; COSE EXTENDED light should go out upon complete retraction of cone |                             |
| 7. Reset anti-surge shutter control change-over switch from CLOSED to OPEN (OPEN) position  | This should result in synchronous opening of anti-surge shutters  |                             |
| 8. Reset anti-surge shutter control change-over switch from OPEN to CLOSED position   | This should result in synchronous closing of anti-surge shutters  |                             |
| 9. Place anti-surge shutters control change-over switch and cone operating mode selector switch to AUTO (AUTOMATIC) and lock them with brass wire. 0.25 mm in diameter. Reset ENGINE PROCESSING (ENGINE PROCESSING) switch from "T" to OPERATION (PAROLA) |   |                             |
| 10. Disengage ground hydraulic installation, generator and turn off all circuit-breakers  |   |                             |


188

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |   |
|---|--|---|
| Supplement to Inspection Guide No.21  | PROCESS CHART No.4C  | In 16 sheets Sheet 11   |
| FUSelage  | INSPECTION OF CORE AND ANTI-SURGE SHUTTER CONTROL MECHANISM  | Man-hours required - 1.50   |
| Procedure   | Technical requirements   | Fault correction  |
| <p><u>Checking System for Blocking Engine Control Lever by Mach Number</u></p> <p>1. Turn out screws and remove access hole cover from casing under throttle control in cockpit</p> <p>2. Check presence and correct attachment of locking fittings (with seals) which couple SW02/2 electromagnet with locking nut and throttle control bracket (Fig.89)</p> <p>3. Check two-cycle operation of stop versus Mach number limitations from energized SW02/2 electromagnet.</p> <p>Check in the following succession:</p> <p>(a) with operating rod of SW02/2 electromagnet extended, stop flag should be raised and pin on engine control lever should pass under it with clearance not smaller than 1 mm, as shown in Figs 90 and 91.</p> |  <p>FIG. 89. ARRANGEMENT OF SOLENOID LOCKING FITTINGS</p> <p>1 - flange to electric control bracket;<br/>2, 5 and 6 - pins, upper and lower pin;<br/>3 - seal ring, 4 - locknut, 7 - solenoid (electromagnet) SW02/2 - locking nut K02-1.</p> | <p>If for some reason or other locking fittings are missing, call for electric equipment specialist to check SW02/2 electromagnets. Upon completion of check re-mount electromagnet and attach new locking fittings and seal</p> <p>A 1-mm displacement up or down from pin axis shall be tolerated. Fig. 91 shows stop blocking backward movement of engine control lever. In case of faulty operation (untimely tripping) of electromagnet or clearances other than those indicated in Figs 90 and 91 act as follows:</p> <ul style="list-style-type: none"> <li>- disconnect throttle control</li> <li>- disconnect SW02/2 electromagnet.</li> </ul> |

SECRET/NO FOREIGN DISSEM

Peer Origin A

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Equipment to Inspection Guide No. 21  | PROCESS CHART No. 49  | In 15 sheets Sheet 12  |
|---|---|--|
| PURPOSE   | INSPECTION OF COSE AND ANTI-SURGE SHUTTER CONTROL MECHANISMS  | Man-hours required - 1.50  |
| Procedure   | Technical requirements  | Fault correction   |
| <p>(3) with operating rod of 3M02/2 electromagnet retracted, stop flag should be lowered and bear along axis of pin on engine control lever.</p> <p>4. Check lifting of stop flag from emergency control button on throttle control</p> | <p>FIG. 30. POSITION OF PARTS FOR CHECKING STOPPING SYSTEM<br/>1 - stop flag, 2 - pin on engine control lever, 3 - engine control lever.</p> <p>Stop flag should rise and pin on engine control lever should pass with not smaller than 1-mm clearance as shown in Fig. 30. Stop flag is lifted as a result of compression of</p> | <p>from bellcrank installed before electromagnet 3M0</p> <p>- unlock and remove electromagnet 3M02/2</p> <p>Examine space before operating rod of 3M02/2 for absence of foreign objects</p> <p>Install electromagnet on throttle control in accordance with Fig. 89 maintaining 9-mm distance between flange and nut of 3M02/2 electromagnet.</p> <p>Check operation of stop versus mechanical limitation (see text above).</p> <p>If above mentioned clearance cannot be obtained in re-mounting, adjust it with the aid of adjustable threaded end tip (lug) of spring-loaded rod; adjustment over, safety rod with locknut and check as instructed under first three points of this Article</p> |



190

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |   |                              |
|---|---|---|------------------------------|
| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 40  |   | In 15 sheets<br>Sheet 13     |
| PURPOSE   | INSPECTION OF CORE AND ANTI-SURGE SHUTTER CONTROL MECHANISMS  |   | Man-hours<br>required - 1.50 |
| Procedure   | Technical requirements  | Fault correction  |                              |
| <p>Check as follows:</p> <p>(a) retract operating rod of 3K02/2 electromagnet;</p> <p>(b) de-energize 3K02/2 electromagnet;</p> <p>(c) attach bellcrank before 3K02/2 electromagnet so that it would be inoperative when operating rod of 3K02/2 electromagnet is retracted;</p> <p>(d) press emergency control button to throttle control.</p> <p>5. Having completed check lift emergency control button to fixed upper position, lock it with wire and seal as shown in Fig. 92.</p> <p><u>Checking Air Intake Duct Cone for Correct Position</u></p> <p>1. Connect ground hydraulic installation to aircraft connection of main hydraulic system and build up working pressure in system.</p> | <p>spring-loaded control rod which links 3K02/2 electromagnet with stop flag</p>  <p>FIG. 91. POSITION OF STOP FLAG FOR CHECKING ENGINE CONTROL LEVER BLOCKING<br/>1 - stop flag; 2 - pin on engine control lever; A - upward travel indicator; B - downward travel indicator.</p> <p>Position of air intake duct cone should correspond to data indicated in Levelling Diagram available in aircraft Service Log.</p> |  <p>FIG. 92. POSITION OF EMERGENCY CONTROL BUTTON LOCKING FITTINGS<br/>1 - locknut; 2 - emergency control button; 3 - loose wire, type 3026-B-2.</p> <p>If measured positions of cone differ from corresponding data indicated in Levelling Diagram by more than 32 mm, problem of whether to consider newly obtained position of cone as serviceable.</p> |                              |

151

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |   |                              |
|---|--|---|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART, No. 40  |   | In 16 sheets<br>Sheet 14     |
| TASKS   | INSPECTION OF CONE AND ANTI-SURGE SETTER CONTROL MECHANISMS  |   | Man-hours<br>required - 1.50 |
| Procedure   | Technical requirements   | Fault correction  |                              |
| <p>2. Place cone operating mode selector switch to MANUAL (OFF) position. Operating cone position selector switch perform 5 or 6 retraction-extension cycles of cone, with its fixation in three positions (retracted, extended to first position and extended to second position).</p> <p>3. Install special fixture (Fig-93) on cone to check cone extension travel with reference to fuselage nose cone seeing to it that inner surface of fixture fits tightly to movable cone surface.</p> <p>4. Operate selector switch to place cone to EXTENDED position and measure dimension "R" with the aid of ruler.</p> | <p>If cone operates properly, deviations within <math>\pm 2</math> mm in cone positions as compared to data indicated in Levelling Diagram shall be tolerated.</p> <p>If movable cone or hydraulic control cylinder has been replaced, as well as after all other operations which involve cone adjustments, obtain these dimensions of cone positions which are indicated in Levelling Diagram.</p> <p>Dimension "R" is distance between reference point "1a" on aircraft nose cone and point "2a" on movable</p> | <p>or to correct Levelling Diagram with a view to eliminating present discrepancy should be solved in each particular case jointly with Manufacturer.</p> |                              |


192

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



153

SECRET/NO FOREIGN DISSEM

Peer Origin



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                  |                              |
|--|---|------------------|------------------------------|
| Supplement to Inspection<br>Guide No.21  | PROCESS CHART No.40   |                  | In 16 sheets<br>Sheet 16     |
| PURPOSE  | INSPECTION OF CONE AND ANTI-SURGE SHUTTER CONTROL MECHANISMS  |                  | Man-hours<br>required - 1.50 |
| Procedure  | Technical requirements  | Fault correction |                              |
| <p>5. Extend cone to first position and measure dimension "K1" by means of ruler.</p> <p>6. Extend cone to second position and use ruler to measure dimension "K2". Cone extension dimensions should be measured three times.</p> <p>7. Remove fixture from cone. Place cone to fully retracted position and reset cone operating mode selector switch to AUTO (ABNORMAL).</p> <p>8. Disconnect ground installation from aircraft.</p> | <p>cone. This dimension should correspond to data indicated for given aircraft in its Levelling Diagram and should be within <math>21 \pm 5</math> mm.</p> <p>Dimension "K1" should meet specification of Levelling Diagram (431<math>\pm</math>5 mm).</p> <p>Dimension "K2" should be as specified in Levelling Diagram (491<math>\pm</math>5 mm).</p> |                  |                              |
| Accessories  | Tools   |                  |                              |
| <p>Fixture 7a-9871-850 for checking position of air intake duct cone</p> <p>Tester EHY-3</p> <p>Ground hydraulic installation</p> <p>Ground electric power supply source</p>   | <p>Screwdriver, ordinary</p> <p>Screwdriver for cross-slitted screws</p> <p>Flat-nose pliers</p>  |                  |                              |

394

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 41   |                  | In 5 sheets<br>Sheet 1       |
|--|--|------------------|------------------------------|
| FUSELAGE   | CHECKING OPERATION OF DRAG CHUTE SYSTEM  |                  | Man-hours<br>required - 0.30 |
| Procedure  | Technical requirements   | Fault correction |                              |
| <p>Checking of drag chute system (Fig. 34) should be carried out after re-joining of fuselage</p> <ol style="list-style-type: none"> <li>1. Place clean canvas under chute compartment of fuselage to protect chute from fouling</li> <li>2. Take seat in cockpit and make sure that pressure in pneumatic system is not lower than 50 kg/cm<sup>2</sup></li> <li>3. Turn on circuit-breaker bearing inscription DRAG CHUTE (TPEYOGPPO3 HAPAEHT)</li> <li>4. Press button on instrument panel bearing inscription CHUTE RELEASE (BIBYU3 HAPAEHTA)</li> </ol> | <p>Pressing CHUTE RELEASE button actuates electropneumatic valve which supplies air to chute doors opening cylinder. Doors should go open, and drag chute should drop under gravity from chute compartment container.</p> <p><u>Notes:</u> 1. Chute doors can be opened by turning bezagon of lock on outer door (indax part on lock bezagon should be placed to OFF (OCHPATO))</p> <ol style="list-style-type: none"> <li>2. Upon opening chute doors keep them with hands and be careful not to injure hands at</li> </ol> |                  |                              |

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 41

In 5 sheets  
Sheet 2




FIG. 14. DOORS OF DEAD CHUTE CONTAINER  
 1 - lock, 2 - air cylinder, 3 - 470° door, 4 - control rod, 5 - door lock, 6 - left door, 7 - guide cylinder with springs,  
 8 - bracket, 9 - one-eye hinge joint, 10 - right door, 11 - left door, 12 - door, 13 - shaft of lock, 14 - control rod,  
 15 - outlet for cable.

156

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |                              |
|--|--|---|------------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 41   |   | No 5 sheets<br>Sheet 3       |
| PURPOSE  | CHECKING OPERATION OF DRAG CHUTE SYSTEM  |   | Man-hours<br>required - 0.30 |
| Procedure  | Technical requirements   | Fault correction  |                              |
| 5. Pull chute cable from clamps and apply 5 to 15-kg effort to it. Press push-button (on cockpit port side) bearing inscription CHUTE JETTISON (CHPOC (LAFANVA))<br><br>6. Return system to initial position and safety chute compartment doors lock<br>7. Build up 30 kg/cm <sup>2</sup> pressure in pneumatic system and repeat check of drag chute system operation as instructed under Points 2 through 5 above<br>8. Wash chute door hinges with clean solvent and coat them with KEALIN-20 lubricant<br>9. Wash drag chute lock with clean gasoline. Inspect drag chute cable attachment hook and eliminate burrs if any | chute doors opening moment (doors are spring-loaded and go open in brief manner)<br>3. When opened, doors should remain in this position<br><br>Pressing chute jettison button should open attachment lock to release cable<br><br>At 30 kg/cm <sup>2</sup> pressure in pneumatic system chute system should function as properly as at 50 kg/cm <sup>2</sup> pressure | (This area contains faint, illegible text, likely bleed-through from the reverse side of the page.) |                              |

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                         |                              |
|---|---|-------------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 41                    |                         | In 5 sheets<br>Sheet 4       |
| FUSELAGE  | CHECKING OPERATION OF DEAD CHUTE SYSTEM |                         | Man-hours<br>required - 0.30 |
| <p>Procedure</p> <p>10. Check flaps on containers for integrity; in case of ruptures repair flaps.</p> <p>11. Place chute in container and mount container in chute compartment of fuselage. To this end:</p> <p>(a) fit chute cable ring into lock and close lock so that locking cylinder, acted upon by its spring, would return to initial position;</p> <p>(b) fit chute cable in clamps on fuselage;</p> <p>(c) arrange container with chute in fuselage compartment. Flap with rip cable (cord) loop should be at bottom;</p> <p>(d) cover drag chute with flaps;</p> <p>(e) close chute compartment doors (closed first should be door closest to ventral fin, and then - upper door), and drive cable fitted with safety pin and flag through doors;</p> | <p>Technical requirements</p>           | <p>Fault correction</p> |                              |

398

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                              |
|---|--|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 41   |                  | In 5 sheets<br>Sheet 5       |
| FUSILIAGE   | CHECKED OPERATION OF DRAG CABLE SYSTEM   |                  | Man-hours<br>required - 0.30 |
| Procedure   | Technical requirements   | Fault correction |                              |
| (f) close doors first with rear lock, and then with front lock by pressing lock heads. Index marks on both hexagons should be in closed position;<br>(g) use type EK-1 wire to secure rear lock (hexagon head) to abate door skin.<br>Cable fitted with safety pin and warning flag should be withdrawn before flight |  |                  |                              |
| Accessories   | Tools  |                  |                              |
|   | Combination tool (wrench) 72-7804-435/A<br>Screwdriver, 150 mm<br>Combined multi-purpose pliers,<br>State Standard (DCT) 6547-52 |                  |                              |

199

SECRET/NO FOREIGN DISSEM

Peer Crisis

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |   |                         |
|---|--|--|---|-------------------------|
| Supplement to Inspection Guide No. 22   |  | PROCESS CHART No. 42   |   | In 1 sheet<br>Sheet 1   |
| FUSelage  |  | CHECKING ATTACHMENT LOCKS AND SCREWS OF FUSelage MAINTENANCE ACCESS COVERS   |   | Man-hours required - 35 |
| Procedure   |  | Technical requirements   | Fault correction  |                         |
| <p>1. Check condition of locks and special screws which attach maintenance access hole covers to fuselage (both on port and starboard sides).<br/>Then screwing special screws in or out make use of special screwdriver intended for operations on cross-slitted or curved-slitt screws</p> <p>2. Check attachment screws of fuselage access hole covers for tightness</p> |  | <p><u>Note:</u> Carry out inspection of locks and screws after finishing all maintenance operations on fuselage and wing</p> <p>Access cover attachment locks should be intact and closed.<br/>When lock is closed, outer end of lock and pin should be flush with skin. Make two red marks on skin opposite lock slit as reference of closed position of lock</p> <p>Special screws shall be considered locked correctly if screw cores come out to bear flush with screw heads</p> | <p>If lock pin is depressed (sinks), this means that lock is not closed</p> <p>If special screw core fails to come out, turn out screw and either repair faulty screw or replace it</p> |                         |
| Accessories   |  | Tools  |   |                         |
|   |  | Screwdriver, special<br>Screwdriver, ordinary<br>Screwdriver for cross-slitted screws  |   |                         |

200

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                  |                            |
|--|---|------------------|----------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 43  |                  | 25 5 sheets<br>Sheet 1     |
| FUSelage   | CHECKING ATTACHMENT OF HYDRAULIC CYLINDERS<br>AND HINGE JOINTS OF AIR BRAKES  |                  | Man-hours<br>required - 60 |
| Procedure  | Technical requirements  | Fault correction |                            |
| <ol style="list-style-type: none"> <li>1. In cockpit: read pressure gauge indication to make sure the hydraulic fluid pressure in main system is zero</li> <li>2. Open cross-feed cock in right wheel well; to do this pull cock operating handle and fix it in new position with the aid of special safety lock fitted with red warning flag (Fig. 96)</li> <li>3. Open (manually) both side (forward) air brakes (Fig. 97)</li> <li>4. Open clamp lock on rear air brake and disconnect hydraulic cylinder rod from air brake (Figs 98 and 99, Ref. Nos 1, 2, 3 and 4)</li> <li>5. Secure air brake in open position by means of wire cord and transverse pin with rubber gasket (Fig. 99, Ref. No. 5)</li> <li>6. Wash air brake hinge joints, as well as hydraulic cylinder-to-fuselage and hydraulic cylinder rod-to-air brake</li> </ol> | <p><b>WARNING.</b></p> <p>To obviate accidents during operations in wells of side (front) air brakes it is forbidden to extend air brakes by working pressure of main hydraulic system (Fig. 95)</p> <p><b>WARNING.</b></p> <p>NEVER lower disconnected rear air brake fully down since otherwise belly skin of fuselage and air brake skin will be damaged</p> |                  |                            |


SECRET/NO FOREIGN DISSEM

Peer Origin



SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 43  |   | In 5 sheets Sheet 3     |
|--|---|---|-------------------------|
| FOREWORD   | CHECKING ATTACHMENT OF HYDRAULIC CYLINDERS AND HINGE JOINTS OF AIR BRAKES   |   | Non-Items required - 49 |
| Procedure  | Technical requirements  | Fault correction  |                         |
| <p>attachment joints with clean gasoline (Type 100 and 102)</p> <p>7. Using electric illumination, inspect air brake hinge joints and hydraulic cylinder-to-fittings and cylinder rod-to-air brake attachment joints to make sure that nuts are reliably tightened, nut locking arrangements and bending elements are intact and attachment joints are free from cracks</p> <p>8. Press-charge HEATHS-201 lubricant into grease fittings of hinge joints and attachment joints of operating rods of front and rear air brakes. Wash and lubricate ball sockets of universal joints which attach cylinders of side air brakes. Access to ball sockets is obtained by removing fairings and crossmembers. Wash ball sockets with gasoline, use syringe to charge them with HE-8 oil, and coat with HEATHS-201 lubricant.</p> <p>9. Having completed all maintenance operations:</p> <p>(a) connect hydraulic cylinder rod to rear air brake and close clamp lock the order reverse to disassembly;</p> | <p>Cracked parts are not serviceable. Fastening nuts of attachment joints should be screwed right home and locked.</p> <p>Bending elements should be intact and should neither get into attachment joints nor rub against adjacent parts.</p> <p><u>WARNING.</u></p> <p>Upon completion of all operations in air brake wells make sure that cross-feed cock is shut off</p> | <p>In case cracks are suspected remove dubious attachment joint from aircraft and examine it either with magnifying inspection or paint method.</p> <p>Faulty bending elements should be replaced</p> <div data-bbox="971 1486 1255 1661" style="text-align: center;"> </div> <p>FIG. 17. FRONT SIDE AIR BRAKES IN EXTENDED POSITION<br/>1 - air brake; 2 - ball socket connecting cylinder</p> |                         |

SECRET/NO FOREIGN DISSEM

Poor Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                            |
|---|---|------------------|----------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 43  |                  | In 5 sheets<br>Sheet 4     |
| PURPOSE   | CHECKING ATTACHMENT OF HYDRAULIC CYLINDERS<br>AND KING JOINTS OF AIR BRAKES |                  | Man-hours<br>required - 60 |
| Procedure<br><br>(b) press air brakes to fuselage;<br>(c) close cross-feed cock in right<br>wheel well; to this end, push valve stem<br>forward and remove safety lock with red<br>warning flag.<br>Acted upon by its spring, valve stem<br>should sink | Technical requirements  | Fault correction |                            |
| Accessories<br><br>Inspectoscope (having mirror for inspection of hard-to-<br>get-at places)<br>Grease cup<br>Springs<br>Extension lamp EB-36<br>Safety lock for stem of cross-feed cock of air brake,<br>EG-2644-00                                    | Tools   |                  |                            |




FIG. 43. CHECK AIR BRAKE CLAMPING PROCEDURE (AIR BRAKE EXTENDED)  
 a - stem closed, b - stem open, c - stem with lock on fuselage. 1 - rear air brake, 2 - clamp, 3 - lock,  
 4 - air brake attachment points.

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 45

In 5 sheets  
Sheet 5




FIG. 97. HYDRAULIC CYLINDER AND REAR AIR BRAKE IN EXTENDED AND FIXED POSITIONS  
1 - air brake actuating cylinder, 2 - cylinder attachment joint, 3 - clevis, 4 - air brake, 5 - wire used for securing air brake in extended position.




FIG. 98. ATTACHMENT JOINTS OF SIDE AIR BRAKE  
1 - air brake, 2 - cylinder, 3 - air brake attachment joint.  
4 - grease fittings.




FIG. 99. REAR AIR BRAKE ATTACHMENT JOINTS  
1 - attachment joint, 2 - grease fitting.

SECRET/NO FOREIGN DISSEM

Poor Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 44  |  | In 13 sheets Sheet 1   |
|--|---|--|------------------------|
| AIRCRAFT OPERABLE  | CHECKING CONDITIONS AND INSPECTIONS OF AIRCRAFT CONTROL RODS, CRANKS AND BEAR ATTACHMENT JOINTS, CHECKING BY-51M (BY-51MC) and BY-45 HYDRAULIC BOOSTERS FOR PROPER ATTACHMENT   |  | Man-hours required - 3 |
| Procedure  | Technical requirements  | Fault correction   |                        |
| <p>1. Turn out screws and remove covers of access holes leading to aircraft control assemblies located in fuselage superstructure, in wing (Fig. 104, Ref. Nos 1, 6, 10 and 12, and Figs 105, 106, 107 and 108) and in fuselage port side (Figs 109 and 110).</p> <p>Turn out screws and remove fairing from APY-3B automatic transmission ratio controller (Fig. 111), cover of access hole leading to trimming effect mechanism (Fig. 112) and cover of access hole leading to hydraulic booster BY-51M (BY-51MC), see Fig. 113, if they are still on.</p> <p>2. Wash hinge joints of aircraft controls with clean gasoline.</p> <p>3. Inspect control rods, ball bearings of control rods and bellcranks, bell cranks, support rollers of stabiliser, rudder and aileron control systems located in aircraft cockpit, fuselage superstructure, fin, wing and fuselage</p> | <p>Note: Stabiliser hydraulic boosters BY-51M and BY-51MC are interchangeable. When BY-51MC booster is installed in place of BY-51M booster, no friction sleeve is mounted on stabiliser beam.</p> <p>Ball bearings of closed type should not be washed with gasoline. These should be wiped externally with clean cloth and sparingly coated with grade GRAZE-221 lubricant.</p> | <p>Should there be no lubricant in closed ball bearing or should binding or crunch be present in rotating bearing, press-charge (by means of syringe) fresh GRAZE-221 lubricant into ball bearing.</p> |                        |


206

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |   |                         |
|---|---|---|-------------------------|
| Supplement to Inspection Guide No. 22   | PROCESS CHART No. 44  |   | In 13 sheets<br>Sheet 3 |
| AIRCRAFT CONTROLS   | CHECKING CONDITION AND INTEGRITY OF AIRCRAFT CONTROL RODS, BELLECRANKS AND THEIR ATTACHMENT SCHEMES, CHECKING BY-5LR (BY-5RMC) AND BY-45 HYDRAULIC BOSSSES FOR PROPER ATTACHMENT  |   | Man-hours required - 3  |
| <p><b>Procedure</b></p> <p>(Figs 102 through 115)</p> <p>During inspection make sure that control rods and bellcranks bear no traces of attrition caused by adjacent bending elements and aircraft structural members; see to it that locking fittings are intact.</p> <p>Check clearances between stabiliser and rudder control rods and support rollers; make sure roller pins are properly locked</p> <p>4. Use grade M2A2M-221 lubricant to lubricate ball bearings of control rods bellcranks and support rollers of aircraft control systems (Figs 114 and 115)</p> | <p><b>Technical requirements</b></p> <p>No rubbing of control rods and bellcranks against adjacent parts shall be tolerated. Clearance between control rods and aircraft parts should be not smaller than 5 mm.</p> <p>Eyebolts (end lugs) of control rods should be screwed into control rods up to reference (check) hole in control rod (check this by inserting wire in check hole of control rod.</p> <p>Wire end should, in case of correct position, thrust against eyebolt</p> <p>Support rollers should rotate freely, without jamming. Clearance between rods and rollers should be 0.05 to 0.3 mm</p> <p>Elements affected by high temperatures should be greased with grade M2A2M-221 lubricant</p> | <p><b>Fault correction</b></p> <p>If wire end freely passes through control rod this means that eyebolt (end lug) has been inserted into rod through insufficient depth. In this case remove control rod, measure position of screw in eyebolt, release locking nut and screw eyebolt out.</p> <p>If threaded portion of eyebolt is short of check (reference) hole when screwed in, replace faulty eyebolt (end lug). When length adjustments are involved, check general adjustment of corresponding control system.</p> <p>If clearance is smaller or greater than specified, adjust as follows:</p> <ul style="list-style-type: none"> <li>- unlock eccentric (tetrahedron-headed) bolt on support;</li> <li>- rotate this bolt to obtain required clearance with the aid of clearance gauge</li> </ul> |                         |

SECRET/NO FOREIGN DISSEM


Poor Original





SECRET/NO FOREIGN DISSEM

50X1-HUM




SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 44   |                  | In 15 sheets<br>Sheet 7   |
|--|--|------------------|---------------------------|
| AIRCRAFT CONTROLS  | CHECKING OPERATION AND LUBRICATION OF AIRCRAFT CONTROL RODS,<br>HYDRAULIC AND WHEEL ATTACHMENT JOINTS, CHECKING SY-51M<br>(SY-51MC) AND SY-45 HYDRAULIC HOUSTERS FOR PROPER ATTACHMENT   |                  | Man-hours<br>required - 3 |
| Procedure  | Technical requirements   | Fault correction |                           |
| <p><b>Checking APV-10 Automatic Transmission Ratio Controller System Before Airstart and Altitude Function Measurement</b></p> <p>(this work should be performed by special equipment specialists collectively with aircraft specialists)</p> <ol style="list-style-type: none"> <li>1. In cockpit: turn on AUTOMATIC TRANSMISSION RATIO CONTROLLER (ATRCAT) (ATP, APV) circuit-breaker on right-hand console and make sure that APV operating mode selector switch on left-hand console is in AUTO (AFCRAT) position.</li> <li>2. Disconnect static line from APV-106 transmitters to this end, un-couple U-shaped pipe bearing inscription "APV-106" from connections on starboard side and connect transmitter through adapter No. 72-7702-170 to hose of K17-3 tester.</li> <li>3. Connect one K17-3 tester to dynamic opening of pitot-static tube, and another K17-3 tester - to static opening of pitot-static tube.</li> </ol> | <ol style="list-style-type: none"> <li>1. Check functioning of automatic transmission ratio controller system with aircraft control stick released.</li> <li>2. When APV controller operating rod is reset from LOW SPEED (SMALL GROSSWEIGHT) to HIGH SPEED (NORMAL GROSSWEIGHT) and back, stabilizer leading edge will slightly deflect downward or upward, respectively; this will be accompanied by deflection of aircraft control stick.</li> <li>3. Remember that APV automatic control system is calibrated at standard atmospheric conditions; readings of APV indicator pointer</li> </ol> |                  |                           |


212

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |                        |
|--|--|---|------------------------|
| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 44   |   | In 13 sheets - Sheet 8 |
| AIRCRAFT CONTROLS  | CHECKING CONDITIONS AND INVESTIGATION OF AIRCRAFT CONTROL RODS, BELLECRANS AND PISTON ATTACHMENT POINTS, CHECKING BY-FILM (BY-FILM) AND BY-45 RETRAINED WAGGERS FOR PISTON ATTACHMENT  |   | Man-hours required - 3 |
| Procedure  | Technical requirements   | Fault correction  |                        |
| <p>4. In cockpit set dynamic line selector cock of pivot-static tube HBI and pitot tube TH-156 on left-hand console to CRANKING (PASOVL) position.</p> <p>5. Operating from right-hand console in cockpit turn on STORAGE BATTERY, AIRCRAFT-GROUND circuit-breaker; this should result in illumination of STABILIZER FOR LANDING (STABIL. NA HOCAL.) indicator light on T-4 light indication panel.</p> <p>6. Engage ground hydraulic pump and build up working pressure in hydraulic booster system.</p> <p>7. Build up gauge (excessive) pressure in dynamic line and gradually increase it to a value corresponding to 1010 km/hr IAS.</p> <p>8. Create vacuum in static line by gradually decreasing pressure to a value corresponding to 20,000 m altitude; then increase pressure to a value corresponding to 5000 m altitude.</p> | <p>will differ from those of aircraft altimeter pointer</p> <p>As soon as APY indicator pointer in its clockwise movement reaches 450 km/hr IAS, indicator light at E-4 indication panel should go out. Operating rod of APY controller should assume HIGH SPEED position.</p> <p>In position corresponding to 10,000 m altitude APY controller rod should assume LOW SPEED position. At value corresponding to 5000 m altitude APY operatin. rod should assume HIGH SPEED position.</p> |  <p>FIG. 19. ADJUSTING POSITION OF ALEXICON CONTROL BELLS CRANKS IN RELATION TO FRAME 104 AND 21 (AT RELEASE POINT LOCK)</p> <p>1 - Alexicon control rod; 2 - Alexicon control bell crank; 3 - structure valve of static pressure sensing system.</p> |                        |

213

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 44

In 25 sheets  
Sheet 9



FIG. 18. POSITION OF ENGINE CONTROL BELLCRANK  
IN FUSELAGE  
1 - engine control unit, 2 - bellcrank.




FIG. 19. POSITION OF A53-71 AUTOMATIC TRANSMISSION  
RATIO CONTROLLER  
1 - A53-71 controller, 2 - universal joint mechanism, 3 - shaft  
to drive control unit, 4 - rubber control unit.




FIG. 20. POSITION OF TRAILING EFFECT MECHANISM  
1 - universal joint mechanism, 2 - timing roller mechanism, 3 and 4 - rubber  
control unit, 5 - shaft to drive control unit.

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 44

In 33 sheets  
Sheet 10




FIG. 113. POSITION OF 67-514 HYDRAULIC BOOSTER AND 21-27 PUMP STATION  
1 - hydraulic booster 21-27; 2 - pump 21-27; 3 - under control unit of - modification  
part of set.

235

SECRET/NO FOREIGN DISSEM

Peer O'risin

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 44

In 15 sheets  
Sheet 11




FIG. 114. LUBRICATION POINTS OF AIRCRAFT CONTROL SYSTEM JOINTS IN FUSELAGE WING SECTION (SHOWN BY ARROWS).

216

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 66

In 45 sheets  
Sheet 12




FIG. 115 LUBRICATION POINTS OF A REAR CONTROL SYSTEM JOINTS IN FUSELAGE TAIL SECTION (SHOWN BY ARROWS)

217

SECRET/NO FOREIGN DISSEM

Peer Orising



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |   |                           |
|---|--|---|---------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 44   |   | Is 23 sheet<br>Sheet 13   |
| AIRCRAFT CURRENTS   | CHECKING OPERATION AND ADJUSTMENT OF AERIAL PHOTO CONTROL RODS,<br>HYDRAULICS AND WRENCH ATTACHMENT DEVICES, CHECKING 5V-51M<br>(5V-51MC) AND 5V-45 HYDRAULIC BOOSTERS FOR PROPER ATTACHMENT |   | Materials<br>required - 3 |
| <p>Procedure</p> <p>Make sure that AF7 indicator readings are correct (by altitude scale)</p> <p>9. Check full resetting of operating rod (from one extreme position to the other)</p> <p>10. Unplug connections and connect U-shaped pipe to connections</p> <p>11. Coat AF7 automatic transmission ratio controller operating rod with thin layer of OX-122-7 lubricant</p> <p>12. Re-install covers of access holes and fasten them in place with screws</p> | <p>Technical requirements</p> <p>Time of full resetting of operating rod should not exceed 22 sec</p>  | <p>Fault correction</p>   |                           |
| <p>Accessories</p>  |  | <p>Tools</p>  |                           |
| <p>Syringe<br/>Grease cup<br/>Clearance gauge with set of feeler blades</p>   |  | <p>Screwdriver for cross-slitted screws<br/>Screwdriver, ordinary<br/>Pliers, multi-purpose</p> |                           |

215

SECRET/NO FOREIGN DISSEM

*Peer Original*

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |  |                        |
|---|--|--|--|------------------------|
| Supplement to Inspection<br>Guide No. 21  |  | PROCESS CHART No. 45   |  | In 2 sheets<br>Sheet 1 |
| AIRCRAFT CONTROLS   |  | CHECKING PLAY IN RODS, CHARLIER AND ALLISON CONTROLS                                 |  |                        |
| Man-hours<br>required - 2.15  |  |  |  |                        |
| Procedures  | Technical requirements   | Fault correction   |  |                        |
| 1. Fix aircraft control stick in<br>normal position<br>2. Raise aileron by its trailing<br>edge section and check carefully to make<br>sure that there are no knock-accompanied<br>plays in aileron control assemblies and<br>that control rods and bellcranks are<br>not caught by elements of wing (check<br>with aileron hydraulic booster 57-4;<br>rigged)<br>3. Raise rudder by its trailing edge<br>section and check carefully to make sure<br>that there are no knock-accompanied plays<br>in rudder control assemblies and that<br>control rods and bellcranks are not<br>caught by elements of wing | Absence of plays in control rod<br>and bellcrank hinges will be deter-<br>mined by absence of knocking sound<br>in control assemblies when ailerons<br>(or rudder) are energetically hand-<br>led by their trailing edge.<br>No knocking in hinges shall be<br>tolerated | In case of knocking sound locate<br>faulty assembly and replace bolt or<br>bellcrank |  |                        |

SECRET/NO FOREIGN DISSEM

Peer Orising

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                              |
|---|---|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 45  | In 2 sheets<br>Sheet 2       |
| AIRCRAFT CONTROLS   | CHECKING PLAY IN RUDDER, STABILIZER AND AILERON CONTROLS                | Ins-Units<br>required - 0.15 |
| Procedure   | Technical requirements  | Fault correction             |
| 4. Moving aircraft control stick forward and backward and checking serially make sure that there are no knock-on assemblies and that control rods and bellcranks are not caught by elements of fuselage |   |                              |
| Accessories   | Tools   |                              |
|   | Flat-nose pliers<br>Screwdriver<br>Screwdriver for cross-slotted screws |                              |

220

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


|   |  |  |                           |
|---|--|--|---------------------------|
| Supplements to Inspection<br>Guide No. 21   |  | PROCESS CHART No. 45   | In 1 sheet<br>Sheet 1     |
| AIRCRAFT CONTROLS   |  | CHECKING WEIGHT BALANCES OF STABILIZER<br>AND RUDDER FOR PROPER ATTACHMENT | Man-hours<br>required - 5 |
| Preparatory   | Technical requirements   | Fault correction   |                           |
| 1. Check (manually) and portion<br>of stabilizer weight balancers to check<br>them for proper attachment to stabilizer<br>2. Check (manually) and portion<br>of rudder weight balancer to check it<br>for proper attachment to rudder | Secure attachment of balancers<br>should be determined by condition of<br>rivets which fasten balancer skin<br>to stabilizer (or rudder) skin<br>Noticeable sinking of rivets, as<br>well as their loose seating in skin<br>shall not be tolerated |  |                           |
| Accessories   | Tools  |  |                           |
|   | Screwdriver for cross-slotted screws<br>Screwdriver, ordinary  |  |                           |

SECRET/NO FOREIGN DISSEM

Peer Crisis

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 47   |   | In 4 sheets Sheet 1       |
|--|--|---|---------------------------|
| AIRCRAFT OPERATOR  | LUBRICATION OF STABILIZER BEAM BEARINGS AND CHECKLINE STABILIZER FRUITION DAMPER   |   | Man-hours required - 1.05 |
| Procedure  | Technical requirements   | Fault correction  |                           |
| <ol style="list-style-type: none"> <li>1. Lower stabilizer with leading edge down.</li> <li>2. Open cover of access hole leading to bearing (Fig. 116)</li> <li>3. Force GRAZE-201 lubricant into outer and inner bearings of stabilizer with the aid of syringe (Fig. 117)</li> <li>4. Remove fairings located under stabilizer to obtain access to stabilizer control rods and bellcranks (Fig. 118)</li> <li>5. Disconnect control rods from bellcranks, and bonding elements - from stabilizer control rod (Fig. 119)</li> <li>6. Fasten special screw clamp on one of stabilizer sections (halves) (Figs 120 and 121)</li> <li>7. Deflect trailing edge of one stabilizer section to extreme upper position (leading edge down)</li> <li>8. Hook dynamometer to screw clamp and lower stabilizer section by 50 to 70 kg, and then pull dynamometer handle down in direction normal to stabilizer chord</li> </ol> | <p>When lubricating bearings see to it that GRAZE-201 lubricant does not get into friction damper</p> <p>Remember that:</p> <p>(a) at low temperatures friction in stabilizer joints is increased and therefore greater effort is required to deflect stabilizer; after engine warm-up stabilizer-deflecting effort is back to normal;</p> <p>(b) indicated in Certificate of damper is friction moment obtained during stand trials of individual friction damper;</p> <p>(c) in the course of aircraft operation, as flying hours are accumulated, friction force present at damper may increase to 12 kg-m;</p> |  <p>FIG. 115 POSITION OF STABILIZER DURING PRESSURE LUBRICATION OF BEAM BEARINGS</p> <p>1 - bearing, 2 - friction damper, 3 - access hole cover by screw</p> |                           |

222

SECRET/NO FOREIGN DISSEM

Poor Original




SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 47

In 4 sheets  
Sheet 2




SECRET/NO FOREIGN DISSEM

Poor Quality

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |                              |
|--|--|---|------------------------------|
| Supplement to Inspection<br>Guide No. 41   | PROCESS CHART No. 47   |   | In 4 sheets<br>Sheet 4       |
| AIRCRAFT CONTROLS  | LUBRICATION OF STABILIZER PEAR BEARINGS AND CHECKING<br>STABILIZER FRICTION MOMENT   |   | Man-hours<br>required - 3.45 |
| Procedure  | Technical requirements   | Fault correction                            |                              |
| <p>9. Note reading of dynamometer at which stabilizer trailing edge begins to deflect down</p> <p>10. Connect control rods with stabilizer control bellcranks and safety wire with cotter pins (see Fig. 116)</p> <p>11. Be-mount fairing and access hole seals, and fasten them with screws</p> | <p>(d) trailing edge of stabilizer should be started into downward movement by effort of 13 to 21 kg as stabilizer moves.</p> <p>Stabilizer movement starting moment is not taken into consideration;</p> <p>(e) friction moment less than 10 kg-a should not be tolerated</p> |   |                              |
| Accessories  |  | Tools                                       |                              |
| <p>Grease cup 72-7804/1A0</p> <p>Friction moment test fixture (screw clamp), 26-9872-00</p> <p>Syringe</p> <p>Dynamometer</p>  |  | <p>Screwdriver for cross-slotted screws</p> |                              |

225

SECRET/NO FOREIGN DISSEM

Poor Origin



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |  |                             |
|--|---|--|-----------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 48  |  | Is 20 sheets<br>Sheet 1     |
| CANOPY AND COCKPIT   | CHECKING OPERATION OF CANOPY EMERGENCY JETTISON SYSTEM  |  | Man-hours<br>required - 1.5 |
| <p style="text-align: center;"><b>Procedure</b></p> <p><u>Checking Operation of Diaphragm Valve and Remover Gun of Canopy Emergency Jettison System</u></p> <p><u>From Ejection Seat Face Shield</u></p> <ol style="list-style-type: none"> <li>1. Open canopy, unload remover gun and charge it with two dummy cartridges (charges) fitted with primer caps</li> <li>2. Relieve air pressure from main air system and from canopy lifting bottle to zero. Bleed air with the aid of special fixture (fixture for testing pressure in canopy lifting bottle through connection located in rosewheel leg well. Check air pressure by cockpit-mounted pressure gauges and by pressure gauge installed on device (Figs 122 and 123)</li> <li>3. Charge canopy lifting bottle with compressed air using the same device</li> </ol> | <p style="text-align: center;"><b>Technical requirements</b></p> <p><u>WARNING:</u></p> <p>During all operations in cockpit with seat dismounted always have safety flooring laid.</p> <p>Unload and charge gun collectively with ordnance specialist</p> <p>Air pressure in canopy lifting bottle should be within 50 to 60 kg/cm<sup>2</sup>. Pressure in main air system should be zero. If these requirements are not, this means that non-return valve operates normally</p> | <p style="text-align: center;"><b>Fault correction</b></p> |                             |

226

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 71

PROCESS CHART No. 68

In 20 sheets  
Sheet 2




FIG. 122. CONNECTIONS IN NOSE WHEEL STRUT WILL BE USED FOR COCKPIT AIRTIGHTNESS CHECKS  
 1 - connection for track alignment check; 2 - bracket for dam extension and retraction cable assembly; 3 - U.S. standard wire strapping system




FIG. 123. COCKPIT AIRTIGHTNESS TEST DEVICE

SECRET/NO FOREIGN DISSEM

Poor Quality

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 48  |                  | In 20 sheets Sheet 5     |
|---|---|------------------|--------------------------|
| CANOPY AND COCKER   | CHECKING OPERATION OF CANOPY EMERGENCY JETTISON SYSTEM  |                  | Max-time required - 9.30 |
| Procedure   | Technical requirements  | Fault correction |                          |
| <p>4. Take seat in cockpit and lock canopy. Withdraw ground safety lock from autonomous canopy jettison handle so that it would not hamper checkout operations.</p> <p>5. Erratically pull seat blind and check manually that diaphragm valve and fusage charges of recoverer gun are actuated; take certain that locking wire on these and on trigger is broken loose.</p> <p>6. Relieve air from canopy pneumatic lifting cylinders and recoverer (tossing) system with the aid of firmure for testing pressure in canopy pneumatic lifting bottle.</p> <p>7. Open canopy manually; to this end:</p> <p>(a) turn canopy controls (Fig.124) backward (having retained control handle in SNGP (GTOD) position);</p> | <p>Pulling blind should initiate air supply through punctured diaphragm valve to pneumatic lifting cylinders to build up canopy removing (tossing) pressure.</p> <p>Canopy locks should go open after blind is pulled through 115 to 140 mm and explosive charge-actuated mechanism should be operated after 255-30 mm travel of blind; total travel of blind should be 336-420 mm. Effort applied to blind at explosive charge-actuated mechanism operation moment should not exceed 30 kg <u>WARNING.</u></p> <p>Never open canopy before air pressure in canopy pneumatic lifting cylinders is relieved.</p> |                  |                          |

228

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 68   |                  | In 25 sheets<br>Sheet 4   |
|--|--|------------------|---------------------------|
| CANOPY AND COCKPIT   | CHECKING OPERATION OF CANOPY EMERGENCY JETTISON SYSTEM                                       |                  | Man-hours required - 9.30 |
| Procedure  | Technical requirements   | Fault correction |                           |
| <p>(b) the man sitting in cockpit should lift manually rear part of canopy and the man operating from outside should lift canopy to required position. Install ground safety locks in operating rods of canopy lifting cylinders</p> <p>2. Remove diaphragm assembly; act as follows:</p> <p>(a) descend right-hand side screen (panel) and save right-hand section of instrument panel aside;</p> <p>(b) screw off nut of valve inlet connection and remove pipe with filter;</p> <p>(c) remove two valve attachment bolts and valve;</p> <p>(d) screw out inlet connection (from diaphragm side).</p> <p>Make sure that valve diaphragm is marked and that primer caps of dummy charges are punctured (Figs 125 and 126)</p> | <p>Diaphragm should be broken over an area not smaller than 50% of pipeline section area</p> |                  |                           |

SECRET/NO FOREIGN DISSEM

Peer Origin

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 48  |                  | In 20 sheets Sheet 6      |
|---|---|------------------|---------------------------|
| CANOPY AND COCKPIT  | CHECKING OPERATION OF CANOPY EMERGENCY JETTISON SYSTEM  |                  | Man-hours required - 9.30 |
| Procedure   | Technical requirements  | Fault correction |                           |
| 9. Clean diaphragm valve and filter from particles of broken diaphragm with compressed air, install new diaphragm in valve and screw on connection<br>10. Set diaphragm valve at operating position and safety it with MIL-0.5 locking wire | When replacing diaphragm in valve remember that bushing which carries diaphragm should be set with its taper portion inside valve; this is done to prevent breaking of diaphragm by sharp (taper) edges of body during assembly |                  |                           |
| 11. Return canopy emergency jettison system to initial position and lock it<br>From Canopy Emergency Jettison Handle  |   |                  |                           |
| 12.Unload revolver gun, load it with empty charges and lock with MIL-0.5 wire   |   |                  |                           |
| 13. Charge additionally bottle of canopy lifting system with compressed air using special fixture for this purpose.   | Air pressure in canopy lifting (tossing) system bottle should be 50 to 60 kg/cm <sup>2</sup>  |                  |                           |
| 14. Check operation of diaphragm valve and revolver gun from canopy emergency jettison handle; to this end:<br>(a) withdraw ground safety pins from operating rods of canopy lifting pneumatic cylinders;<br>(b) lock canopy.               |   |                  |                           |

SECRET/NO FOREIGN DISSEM

Poor Quality

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                           |
|---|---|------------------|---------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 48  |                  | In 20 shows<br>Sheet 7    |
| CANOPY AND COCKPIT  | CHECKS OPERATOR OF CANOPY EMERGENCY JETTISON SYSTEM   |                  | Rm-4000<br>required - 4.3 |
| Procedure   | Technical requirements  | Fault correction |                           |
| <p>(e) turn canopy emergency jettison handle fully down (to horizontal position); this should result in breakage of locking wire on handle and diaphragm valve, and in operation of diaphragm valve (diaphragm valve operates when handle is turned down by 45°);</p> <p>(d) slowly pull canopy emergency jettison handle backward as far as it will go; this should result in breakage of trigger locking wire</p> <p>15. Bleed air from canopy lifting cylinders and lifting system using special fixture for checking charging pressure of canopy lifting system bottle</p> <p>16. Manually open canopy acting as follows:<br/>- turn canopy control handle backward (having retained handle in STCP position)</p> | <p>Moving handle through 25 to 30 mm will result in puncturing of primer caps of recover gun dummy charges; further movement of handle by 35 to 40 mm unblocks seat ejection gun. Travel margin of handle in this case should be at least 5 mm.</p> |                  |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                           |
|---|--|------------------|---------------------------|
| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 46                                   |                  | In 20 sheets Sheet 8      |
| CANOPY AND COCKPIT  | CHECKING OPERATION OF CANOPY EMERGENCY JETTISON SYSTEM |                  | Man-hours required - 9.30 |
| Procedure   | Technical requirements                                 | Fault correction |                           |
| <p>- the man sitting in cockpit should lift rear part of canopy and the man operating from outside of cockpit should lift canopy farther upward to required position</p> <p>Re-install ground safety pins into operating rods of canopy lifting cylinders</p> <p>17. Carry out operations described under Points 8, 9, 10 and 11 of present Process Chart</p> <p><u>Checking Operation of Emergency Lock Draining System</u></p> <p><u>Pre-explosive charge-actuated system</u></p> <p>1. Remove canopy movable section as follows:</p> <p>(a) open cover of fuselage upper front access (hatch);</p> <p>(b) disconnect rubber hose of detector system manifold and remove manifold from front glass panel of canopy;</p> |  |                  |                           |

231

SECRET/NO FOREIGN DISSEM

Poor Quality



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |   |
|---|--|---|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 48   | In 20 sheets<br>Sheet 9                             |
| CANOPY AND COCKPIT  | CHECKING OPERATION OF CANOPY EMERGENCY JETTISON SYSTEM   |   |
| <p style="text-align: center;">Procedure</p> (e) open canopy, detach spring hook of seat ejection gun blocking system and make sure that ground safety pins are installed in seat ejection gun and canopy remover gun;<br>(f) retaining canopy with hands withdraw pins from operating rods of canopy lifting cylinders and remove ground safety pins from operating rods;<br>(g) operating from cockpit close canopy by placing control handle to ERG position;<br>(h) remove two bolts of front hinge locks of canopy;<br>(i) operator sitting in cockpit should lift alternately front and then rear part of canopy; meanwhile two operators should descend canopy from aircraft.<br>Canopy mounting is the reverse of dismounting.<br>2. Place canopy on special trestles with provision for access to lock loops | <p style="text-align: center;">Technical requirements</p> NEVER place canopy to rest on lock loops | <p style="text-align: center;">Fault correction</p> |

234

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   |   | PROCESS CHART No. 48                                    |  | In 20 sheets<br>Sheet 10     |
|---|---|---|--|------------------------------|
| CANOPY AND COCKPIT  |   | CHECKING OPERATION OF CANOPY EMERGENCY UNLOCKING SYSTEM |  | Man-hours<br>Required - 9.30 |
| Procedure   | Technical requirements  | Fault correction  |  |                              |
| <p>Suspend 5 to 10 kg weight (equal for each lock) to each lock loop as shown in Fig. 127</p> <p>3. Remove fairing from time delay locks.</p> <p>Remove AN15-1.6 locking wire and clean thixal compound from locks</p> <p>4. Screw locking plunger from receiver pin and connect special fixture for checking canopy lock operation to receiver pin body (Fig. 128). Couple ground air bottle to fixture</p> <p>5. Open bottle valve and, using pressure regulator, build up 6 kg/cm<sup>2</sup> pressure; this should result in breakage of locking wire on locks opening cylinders</p> <p>6. Close side locks of canopy (Fig. 129); to do this:<br/>(a) fit loop 2 into each side lock, turn arm 6 down and move down locking</p> | <p>Air fed to cylinder should operate lock emergency opening system, lock loops should clear locks, front hinge locks should go open, and rods of time delay locks should move to LOCKED position which will be determined by extension of operating rods from pneumatic cylinders (see Fig. 128, Ref. No. 4)</p> <p><b>WARNING:</b><br/>Protect lock loops from denting and other damage when they drop.</p> |   |  |                              |


235

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 46

In 20 sheets  
Sheet 22




FIG. 179. SIDE EMERGENCY LOCK AND POSITION OF SPRING-LOADED CATCH  
 1 - lock body; 2 - nose; 3 - pin; 4 - lock housing; 5 - catch pin; 6 - pin; 7 - perforator; 8 - locking lever;  
 9 - emergency release (emergency perforator) spring cover; 10 - attachment hole for weight or spring-loaded  
 catch.




FIG. 180. INDICATING CANOPY EMERGENCY JETTISON SYSTEM  
 MECHANISM WITH COVER REMOVED  
 1 - handle; 2 - roller; 3 - lock nose; 4 - spring-loaded catch.

237

SECRET/NO FOREIGN DISSEM

Poor Quality

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 48  |   | In 20 sheets Sheet 13    |
|---|---|---|--------------------------|
| CANOPY AND COCKPIT  | CHECKING OPERATION OF CANOPY EMERGENCY JETTISON SYSTEM  |   | Man-hours required - 4.3 |
| Procedure   | Technical requirements  | Fault correction  |                          |
| <p>lever 6 by pulling it out with the aid of thin (0.8 to 1 mm) wire (attach wire end to hole 1D in lever);</p> <p>(b) install spring-loaded catches with spring tension of 3 to 5 kg hooking them by lever attachment tag. (see Fig. 129).</p> <p>Next close front hinge locks (Fig. 131) as follows:</p> <p>- move bigger hook 2 and locking lever 4 backward and force both bell-cranks 7 forward simultaneously. As a result, system of control rods and bell-cranks moves forward and locks become closed.</p> <p>7. Close time delay locks (Fig. 132); to this end: using screwdriver sink rods 2 of time delay locks, align locking holes and safety elements with</p> | <p>Numbers of loops should correspond to numbers of locks:</p> <p>Right side (towards aircraft nose):</p> <ul style="list-style-type: none"> <li>(a) front side No. 2;</li> <li>(b) middle side No. 4;</li> <li>(c) rear side No. 5</li> </ul> <p>Left side (towards aircraft nose):</p> <ul style="list-style-type: none"> <li>(a) front side No. 1;</li> <li>(b) middle side No. 3;</li> <li>(c) rear side No. 5</li> </ul> <p>Check closing of side and front locks:</p> <ul style="list-style-type: none"> <li>(a) loops 2 (see Fig. 129) of side locks should not slip out;</li> <li>(b) arm 6 (see Fig. 125) should not rotate</li> </ul> | <p>If numbers are missing on locks, make them in red paint on lock under-surfaces in accordance with loop numbers.</p> <p>If loops slip out or arms rotate, check lock closing procedure again.</p> |                          |

238

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |  |                          |
|---|--|--|--|--------------------------|
| Supplement to Inspection Guide No. 21   |  | PROCESS CHART No. 48                                   |  | In 20 sheets<br>Sheet 14 |
| CANOPY AND COCKPIT  |  | CHECKING OPERATION OF CANOPY EMERGENCY JETTISON SYSTEM |  | Man-hours required- 9.30 |
| Procedure   | Technical requirements   | Fault correction                                       |  |                          |
| <p>type ANU-1.6 locking wire (Ref. No. 8).<br/>Fill hook holes with thimble compound, grade JB.<br/>Install fairings on locks<br/><u>From Handle of Duplicating Canopy Emergency Jettison System</u><br/>8. Suspend 5 to 10-lb weights from loops of canopy emergency locks as instructed in Point 2 above<br/>9. Grip handle of duplicating canopy emergency system and energetically pull it; this action should result in breakage of locking wire (Fig. 130)<br/>10. Return emergency lock opening system to initial position and close side and front locks of canopy as instructed in Point 6 above<br/>11. Remove cover from duplicating canopy emergency jettison control system, insert handle in mechanism and attach it to roller (see Fig. 130). Close mechanism cover and safety it in place</p> | <p>When energetically pulled, duplicating system control handle should go loose and separate from canopy. Under gravity of weights loops leave lock seats, front hinge locks go open<br/><br/>4-mm dia. holes in handle body and in roller inside body should be aligned and cable ball should fit into recess</p> |  |  |                          |

299

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 48

In 20 sheets  
Sheet 15

50X1-HUM




FIG 171 FRONT HINGE LOCK OF CANOPY

1 - handle, 2 - spring lever, 3 - return latch, 4 - locking lever, 5 - shaft, 6 - bolt of corresponding panel, 7 - roller guide, 8 - guide rollers, 9 - lock structure shaft.

A - opening view of lock. Position in which lock should be open. For most length of handle - 25 mm. B - no clearance is allowed. Check for tight fitting between roller rest, contact and lever - 207 mm. C - during opening of return lever clearance between the 15-0225-0200 5 BX and supporting portion of 15-0225-024. D - lever return spring is positioned marking. During assembly, in order to enter in cooperation of the opening of left and right sides of is allowed to be done. This is only the end of view 15-0225-029 on its operation with a roller. When through in the locking operation. Liberty given the upward end of the lever with grade 15-0225-021 roller rest.

240

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 71   | PROCESS CHART No. 48  |                  | In 20 sheets<br>Sheet 15     |
|--|---|------------------|------------------------------|
| CANOPY AND COCKPIT   | GENERAL OPERATION OF CANOPY EMERGENCY JETTISON SYSTEM   |                  | Man-hours<br>required - 9.30 |
| Procedure  | Technical requirements  | Fault correction |                              |
| <p>12. Again suspend the same weights (5 to 10 kg.) from lock loops as has been instructed above</p> <p>13. Grip handle and slowly pull it; as soon as all locks go open, discontinue handle pulling and make reference mark on handle cable; then pull handle until it completely separates from roller</p> <p>14. Set system to initial position (close locks as instructed in Point 6 of present Process Chart)</p> <p>15. Wash and lubricate parts of canopy locks and of canopy emergency jettison mechanism on fuselage and canopy</p> | <p>Travel margin of handle cable should be 5 mm</p> <p>Upon completion of all checks on canopy removal system and after lock opening checks charge canopy remover gun with two live charges.</p> <p>When charging remover gun make sure that big nut is screwed right loose but is at least 0.5 mm short of fastening yoke butt end. Otherwise striker will have a clearance which will cause misfiring</p> |                  |                              |

20


SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM




242

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |                           |
|---|--|--|---------------------------|
| Supplement to Inspection Guide No. 21   |  | PROCESS CHART No. 48                                   | In 20 sheets<br>Sheet 20  |
| CANOPY AND CONCEPT  |  | CHECKING OPERATION OF CANOPY EMERGENCY JETTISON SYSTEM | Man-hours required - 9.30 |
| Procedure   | Technical requirements   | Fault correction                                       |                           |
| 16. Safety system of locks and lock control mechanisms (Figs 133 and 134)   | Lockwire following parts:<br>(a) rear lock bellcrank;<br>(b) recover gun;<br>(c) diaphragm valve of canopy emergency jettison system;<br>(d) duplicating canopy emergency jettison control handle;<br>(e) canopy emergency jettison control handle;<br>(f) time delay lock |  |                           |
| Accessories   | Tools  |  |                           |
| Fixture for checking canopy emergency jettison system, CM7/2-98208-00<br>Fixture for checking canopy opening locks, 74-98206-00 | Pliers, multi-purpose<br>Wrenches: 14 x 17, 5 x 7 and 19 x 22<br>Screwdriver   |  |                           |

245

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                  |                           |
|--|---|------------------|---------------------------|
| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 49  |                  | In 8 sheets<br>Sheet 1    |
| PILOT AND COPILOT  | REMOVAL OF ALLEN-ACTUATED EJECTION SEAT FROM AIRCRAFT, WASHING, INSPECTION AND LUBRICATION OF MECHANISM MOVING PARTS AND CABLES     |                  | Man-hours required - 0.45 |
| Procedure  | Technical requirements  | Fault correction |                           |
| <p><u>PRECAUTIONARY MEASURES</u></p> <p>Make sure that ejection gun of seat is unloaded (if no firing has been made)</p> <ol style="list-style-type: none"> <li>1. If canopy has not been removed, lift it and move engine control lever forward</li> <li>2. Remove blocking ball out of funnel of ejection gun cylinder (Fig. 135, Ref. 19)</li> <li>3. Disconnect safety pin of ejection gun from rod of ejection control cable</li> <li>4. Unfasten snaphook of pull cord for AL-3 time release mechanism from yoke on frame</li> <li>5. Disconnect cable running to discharge valve</li> <li>6. Install tightening clamp on ejection seat stabilizing clamp to prevent flaps from opening when removing seat from aircraft.</li> <li>7. Withdraw inserts which fasten upper shackle of hoistrest to ejection gun journals</li> </ol> | <p><u>WARNING</u></p> <p>Ejection seat may be removed from aircraft after ejection gun has been operated by armament specialist</p> |                  |                           |

246

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 22  |   | Is 8 sheets Sheet 2 |
|---|---|---|---------------------|
| CANYON AND COCKPIT  | REMOVAL OF MILD-ARMORED EJECTION SEAT FROM AIRCRAFT, WASHING, INSPECTION AND LUBRICATION OF MECHANICAL MOVING PARTS AND CABLES  |   |                     |
| Procedure   | Technical requirements  | Fault correction  |                     |
| <p>8. Remove ejection seat from aircraft. When lifting seat along guide rails, make sure that OY-2 common connector (Fig. 135, Ref. 13) can be easily disconnected.</p> <p>Install ejection seat on special bench.</p>  |   |   |                     |
| <p>9. Wash all hinged connections of seat mechanisms with clean gasoline and blow them off with compressed air.</p> <p>10. Inspect seat frame, particularly its welded seams for cracks; examine hinges and cables for condition, corrosion and broken strands of cable (Fig. 135).</p> | <p>If cracks are found in seat frame, seat should be withdrawn from service. Hinged joints should rotate without binding.</p> <p>All strands of cables should be sound.</p> | <p>Cables with broken strands should be replaced with new ones.</p> |                     |
| <p>11. On seat examine shoulder and waist belt restraint mechanisms 4 and 14 and foot grip release mechanism 9.</p>   | <p>Harness belts should have no ruptures. Cable strands of harness lock should be sound and securely attached to harness unlock mechanism handle.</p>                       |   |                     |
| <p>12. Check operation of harness belts restraint mechanisms and AL-5 time release mechanism foot-grip release system as follows:</p>   |   |   |                     |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 49  | In 8 sheets Sheet 5       |
|--|---|---------------------------|
| CANOPY AND COCKPIT   | REMOVAL OF BLEED-DETECTED EJECTION SEAT FROM AIRCRAFT, MAINTENANCE, INSPECTION AND LUBRICATION OF MECHANISM MOVING PARTS AND CABLES   | Man-hours required - 6.45 |
| Procedure  | Technical requirements  | Fault correction          |
| (a) cock AI-3 time release mechanism and lock it with flexible pin (Fig. 135);<br>(b) cock middle plunger of spring mechanism and fix it in position with rod (Fig. 136);<br>(c) cock extreme and plungers of spring mechanism and lock them in position with rods;<br>(d) install lock sleeve connected with AI-3 time release mechanism;<br>(e) remove rods locking in position spring mechanism plungers;<br>(f) copy ejection seat with flying suit and parachute on, smooth out straps and close harness lock;<br>(g) lock foot gripe 9 by pressing step bearing of feet rests;<br>(h) withdraw flexible pin of AI-3 time release mechanism | AI-3 time release mechanism should be set to operate in 1.5 sec<br><br>Extreme plungers and lock sleeve should be installed flush with wall of spring mechanism<br><br>Foot gripe and harness straps lock should open quickly and without jamming |                           |


248

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |  |                             |
|--|--|--|-----------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 49   |  | In 2 sheets<br>Sheet 5      |
| AIRCRAFT AND COCKPIT   | REMOVAL OF BLIND-ATTACHED EJECTION SEAT FROM AIRCRAFT, VEHICLE,<br>INSPECTION AND INSURCTION OF ASSOCIATED MOVING PARTS AND CAUSES       |  | Man-hours<br>required - 4.0 |
| <p style="text-align: center;"><b>Procedure</b></p> <p>Report checking operation of harness straps restraint mechanisms and foot-grip release system.</p> <p>Check over, place whole system to operating position.</p> <p><b>Note:</b> Should foot grips close accidentally, open them by moving back shafts of grips coming out of ports in inner walls of foot rests.</p> <p>Lock flexible pin of AK-3 time release mechanism with special thread.</p> <p>13. Examine dampers of ejection seat foot rests and check them for proper operation. To this end:</p> <p>(a) remove bolts fastening rods of left-side and right-side dampers to seat rests;</p> <p>(b) lower foot rests and bring dampers out of casings;</p> <p>(c) make external inspection of dampers, wash hinged joints in gasoline and lubricate with grease MIL-G-2021;</p> <p>(d) pull rods out of dampers and make sure that they are free of dents, nicks and bends;</p> | <p style="text-align: center;"><b>Technical requirements</b></p> <p>For locking use twisted cord thread from core of strand line X-6</p> | <p style="text-align: center;"><b>Fault correction</b></p> |                             |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |                           |
|--|--|---|---------------------------|
| Supplement to Inspection Guide No. 21  | PROCEEDS CHART No. 49  |   | In 6 sheets<br>Sheet 6    |
| EMPTY AND OCCUPY   | REMOVAL OF BLIND-OPERATED EJECTION SEAT FROM AIRCRAFT, WASHING, INSPECTION AND LUBRICATION OF MECHANISM MOVING PARTS AND CABLES  |   | Man-hours required - 0.45 |
| <p><b>Procedure</b></p> <p>(e) move rods into cylinders, insert dampers into casings and secure dampers to arm rests</p> <p>(f) check dampers for proper operation by pulling out rods and applying load to foot rests.</p> <p>Coat with grease MIL-PRF-201 all hinge joints and cables</p> <p>14. Check shoulder belt restraint sensitive lock for proper operation. To this end:</p> | <p><b>Technical requirements</b></p> <p>Movement of foot rests should be uniform without any surging or jamming.</p> <p>Shk 1 kg load is applied to foot rests their lowering should take 3 - 5 sec.</p> <p>Folding of foot rests under load of 40 kg should take place within 3 - 10 sec.</p> | <p><b>Fault correction</b></p> <p>If lowering or folding of foot rests takes more or less time than required, it indicates that dampers contain insufficient amount of oil.</p> <p>Check dampers for quantity of AMT-10 oil</p> <p>If required, add oil to dampers as follows:</p> <p>(a) remove damper from seat;</p> <p>(b) compress it fully;</p> <p>(c) screw plug off filler connection and fill cylinder with oil AMT-10 to capacity, after which drain 1.5 cu. cm of oil;</p> <p>(d) screw plug on filler connection and lock it with wire KIM-0.5;</p> <p>(e) mount damper on ejection seat and check it again for proper operation</p> |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM:

|  |   |                  |                             |
|--|---|------------------|-----------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 49  |                  | In 8 sheets<br>Sheet 7      |
| CANOPY AND COCKPIT   | REMOVAL OF BLEED-ACTIVATED EJECTION SEAT FROM AIRCRAFT, WASHING,<br>INSPECTION AND LUBRICATION OF MECHANISM MOVING PARTS AND CABLES |                  | Man-hours<br>required - 0.6 |
| Procedure  | Technical requirements  | Fault correction |                             |
| <p>(a) place parachute on seat pan, take seat and fasten shoulder belts;</p> <p>(b) release shoulder belts and make sure that shoulder belt restraint mechanism operates properly;</p> <p>(c) lock belts successively in all points and make certain that shoulder belt restraint mechanism is engaged and that pilot can not lean forward.</p> <p>Pay particular attention to proper locking of belts in position required for ejection.</p> <p>15. Check stabilizing flaps mechanism for proper operation. For this purpose:</p> <p>(a) remove tightening clamp from stabilizing flaps;</p> <p>(b) check manually flaps for easy rotation;</p> <p>(c) lower flaps; this done, flaps should open fully and get locked in open position;</p> <p>(d) close flaps by pressing block through hole in horizontal flap of strut</p> |   |                  |                             |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |  |                              |
|---|--|--|--|------------------------------|
| Supplement to Inspection Guide No. 21   |  | PROCEDURE CHART No. 49   |  | In 6 sheets<br>Sheet 8       |
| CINOFF AND COCKPIT  |  | REMOVAL OF FIELD-ACTUATED EJECTION SEAT FROM AIRCRAFT, WASHING, INSPECTION AND LUBRICATION OF MECHANISM MOVING PARTS AND GAMES   |  | Man-hours<br>required - 0.45 |
| Procedure   | Technical requirements   | Fault correction   |  |                              |
| <p>and lower flap by pressing off wire latch; further movement of both flaps should be done simultaneously.</p> <p>Press flaps to head rest and mount tightening clamp on them</p> <p>15. Mount ejection seat on aircraft in reverse order</p>  | <p>After mounting ejection seat on aircraft remove tightening clamp as flaps are held from opening by guide rails</p> <p>When mounting ejection seat on aircraft, make sure that canopy emergency jettison handle engages forked rod of transmission mechanism of canopy jettison system</p> |  |  |                              |
| Accessories   |  | Tools  |  |                              |
| <p>Lubricating gun</p> <p>Device for removing canopy by means of crane</p> <p>Device for checking ejection seat</p> <p>Device for removing ejection seat by means of crane</p> <p>Clamp for tightening flaps of ejection seat (72-7804-220)</p> <p>Kit for loading spring mechanism of ejection seat (114C49-4-110)</p> |  | <p>Wrench, 12 x 14</p> <p>File</p> <p>Wrench (GK/804-794) for tightening nut of firing mechanism striker</p> <p>Wrench (E2-7804-115) for cocking striker of firing mechanism</p> |  |                              |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |   |                             |
|---|---|---|-----------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 50  |   | In 4 sheets<br>Sheet 1      |
| CANOPY AND COCKPIT  | CHECKING CONDITION OF CANOPY FRAME, LUBRICATION OF MECHANISMS FOR CANOPY INSIDE AND OUTSIDE CONTROL HANDLES   |   | Man-hours<br>Required - 6.5 |
| <p><b>Procedure</b></p> <p>1. Check canopy frame for cracks, broken seal and damaged protective coating.</p> <p>2. Examine canopy glass for cracks, silvery areas and dimming (poor transparency). When examining, pay particular attention to places where glass panels are built into canopy frame (in top and rear portion of canopy).</p> <p>3. Inspect canopy units made of magnesium alloy for corrosion.</p> | <p><b>Technical requirements</b></p> <p>Canopy with cracks and silvery areas (hairline cracks) is not fit for further use and should be withdrawn from service.</p> <p>When performing scheduled maintenance operations observe the following:</p> <p>(a) canopy should be covered with canvas (when on ground) to protect it from adverse effects of sunrays, dust, rain, snow and from mechanical damage;</p> <p>(b) should organic glass be fouled, clean it as follows:</p> <ul style="list-style-type: none"> <li>- wipe glass with clean soft cloth wetted with water and wrung;</li> <li>- wipe glass dry with soft cloth;</li> <li>- if any fat stains are found, remove fat by rubbing glass with dry soft cloth and some paste REAM-2.</li> </ul> <p>If no paste REAM-2 is available, wipe glass with soft cloth soaked in soapy water (3-5% solution) and wring out.</p> | <p><b>Fault correction</b></p> <p>Canopy with cracks or silvery areas on glass panels should be replaced by new one.</p> <p>If any hairline scratches or scores are found on glass panels of canopy, polish glass with paste REAM-2. Polishing should be made manually with water-absorbing cotton and small amount of paste.</p> <p>When polishing, rub glass first along scratch, then across it and finally rub area in circular movements without stopping to avoid heating of glass.</p> <p>Polishing may be performed over entire surface of glass. Never try to eliminate scratches and scores (irrespective of their location) by means of emery paper.</p> |                             |

254

SECRET/NO FOREIGN DISSEM

Page Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


| Supplement to Inspection Guide No. 21   |   | PROCESS CHART No. 50   | In's sheets Sheet 2       |
|---|---|--|---------------------------|
| CANOPY AND COCKPIT  |   | CHECKING CONDITION OF CANOPY FRAME, INVESTIGATION OF MECHANISM FOR CANOPY INSIDE AND OUTSIDE CONTROL HANDLES                     | Man-hours required - 0.25 |
| Procedure   | Technical requirements  | Fault correction   |                           |
| 4. Wash canopy outside and inside control handle mechanism (Fig. 137) in clean gasoline and blow it through with compressed air | Organic glass may contain the following minor defects:<br>(a) separate hairline scratches;<br>(b) shallow scratches or scores not longer than 30 mm scattered over wide surface of glass<br><b>Note:</b> When wiping glass, it is forbidden to use woolen or silk cloth that can induce electrical charge in organic glass as in this case surface of glass will attract dust particles | It is strictly forbidden to eliminate silvery areas by means of emery paper or by cleaning, polishing, grinding or local heating |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                           |
|---|--|------------------|---------------------------|
| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 50   |                  | In 4 sheets - Sheet 4     |
| CANOPY AND COCKPIT  | CHECKING CONDITION OF CANOPY FRAME, LUBRICATION OF MECHANISM FOR CANOPY INSIDE AND OUTSIDE CONTROL HANDLES |                  | Man-hours required - 0.25 |
| Procedure   | Technical requirements   | Fault correction |                           |
| <p>5. Check screw fastening toothed steel of canopy control lever for secure attachment. To this end, remove switchboard at left side of cockpit</p> <p>6. Coat with grease canopy control handle mechanism</p> |  |                  |                           |
| Accessories   | Tools  |                  |                           |
| Lubricating gun<br>Brush  | Screwdriver<br>Files   |                  |                           |

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |  |                             |
|---|---|--|-----------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 51  |  | In 2 sheets<br>Sheet 1      |
| COCKPIT AND COCKPIT   | CHECKING CABLES FOR MECHANICAL DEFECTS OF LANDING GEAR ROOST<br>STRUT INDEPENDENT EXTENSION LOCK, CHECKING CABLES RUBBER SEALING<br>BOLT FOR CORROSION  |  | No-hours<br>required - 0.90 |
| <p><b>Procedure</b></p> <p>1. Wipe the cable at cockpit side with cotton waste soaked in gasoline</p> <p>2. Inspect cable for mechanical opening of landing gear nose strut independent extension lock. Make particularly thorough inspection of cable-to-handle connection in cockpit and of cable termination near lock lever. Broken cable wires can be detected by passing bare hand over entire cable length</p> | <p><b>Technical requirements</b></p> <p>Note. If possible, perform operations on checking cable for mechanical opening of landing gear nose strut independent extension lock and on checking condition of rubber boot only after electric start and cover of cockpit floor have been removed. In view of this such operations are included in Section "Cockpit and Cockpit"</p> | <p><b>Fault correction</b></p> <p>Replace cables</p> |                             |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |                           |
|--|--|---|---------------------------|
| Supplement to Inspection Guide No. 21  |  | PROCESS CHART No. 51  | In 2 sheets<br>Sheet 2    |
| CASCOPT AND COCKPIT  |  | CHECKING CABLE FOR MECHANICAL OPENING OF LANDING GEAR WHEEL STOP MECHANISM; KICKDOWN LOCK; CHECKING CABLE WHEEL SEALING BOOT FOR CRACKS | Man-hours required - 0.50 |
| Procedure  | Technical requirements   | Fault correction  |                           |
| 3. Remove cable sealing boot and check it for condition. Remove dirt from boot.<br>4. Coat cable with thin layer of grease K1478-201 | If cracks are discovered on sealing boot of cable, replace defective boot by new one |   |                           |
| Accessories  |  | Tools   |                           |
| Grease K1478-201   |  | Files<br>Screwdriver  |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |  |  |                              |
|--|--|--|--|------------------------------|
| Supplement to Inspection<br>Guide No. 22   |  | PROCESS CHART No. 52   |  | In 2 sheets<br>Sheet 1       |
| CANNOPY AND COCKPIT  |  | CHECKING COORDINATION OF HOT LINE THERMAL INSULATION AND JOINTS<br>BETWEEN COCKPIT SUPPLY SYSTEM CONNECTING PIPE AND CANNOPY<br>AIR BLOW MANIFOLD                        |  | Man-hours<br>required - 0.15 |
| Procedure  | Technical requirements   | Fault correction   |  |                              |
| <ol style="list-style-type: none"> <li>1. Remove ejection seat from aircraft</li> <li>2. Check in pilot's cockpit thermal insulation of hot line for cockpit pressurization system (Fig. 138)</li> <li>3. Inspect joint between cockpit pressurization system connecting pipe and canopy air blow manifold</li> <li>4. Inspect cockpit air supply valve (Fig. 135), its attachment fittings and control cables. Coat cable with LUBRIC-201 lubricant</li> <li>5. Inspect pressure regulator APR-57D, temperature regulator TPTK-45X, make sure that they are securely attached; check pipeline for secure fastening</li> </ol> | <p>Wearing and breaking of pipeline thermal insulation are not allowed</p> <p>Gaps in joint between connecting pipe and canopy air blow manifold should be securely tightened and locked</p> | <p>If any wear or damage to thermal insulation is discovered, it should be eliminated</p> <p>If connection appears to be loose, tighten nuts or replace locking wire</p> |  |                              |
| Accessories  |  | Tools  |  |                              |
| Lubricating gun<br>Grease LUBRIC-201   |  | Special wrench (72-7804-1590)<br>Multi-purpose pliers<br>Screwdriver   |  |                              |


260

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |                           |
|---|--|--|---------------------------|
| Supplement to Inspection Guide No. 21   | PROCESS SHEET No. 53   |  | In 3 sheets Sheet 2       |
| CANOPY AND COCKPIT  | INSPECTION OF FAIRLEADS FOR AIRCRAFT CONTROL HOSES AND OF COCKPIT SEALING HOSES  |  | Man-hours required - 0.15 |
| <b>Procedure</b>  | <b>Technical requirements</b>  | <b>Fault correction</b>  |                           |
| 6. Inspect canopy sealing hose for wear and damage to ozone resistant coating (of black colour) | <p>Sealing hose should be provided with ozone resistant coating over its entire surface.</p> <p>Sealing hose should be free from deep chafing (of light colour) and cracks.</p> <p>When sticking sealing hose, use cement No. 66 and apply it only to bottom of hose, leaving sides of hose free of cement.</p> <p>It is allowed to use cement No. 88 for sticking gaskets not more than 2 mm thick made of material P267L.</p> <p>Sealing hose is allowed to project in curvilinear zone of cockpit outline by not more than 1.5 mm; in remaining areas - not more than 1 mm; slack of hose at any point over its entire length should not exceed 0.5 mm.</p> | <p>If hose is not protected with ozone resistant coating, be sure to restore it. To this end, cover bare areas with ozone resistant varnish ZSC4 (70 752).</p> <p>If deep chafing or cracks are detected, replace hose by new one.</p> <p><b>Replacing Sealing Hose</b></p> <ol style="list-style-type: none"> <li>1. Disconnect hose connecting pipe from air supply system, for which purpose, screw off check nut and nut in cockpit.</li> <li>2. Remove hose from chute.</li> <li>3. Clean chute from old cement making use of wash-out solution.</li> <li>4. Remove oil from surface of chute and from bottom of sealing hose making use of clean unleaded gasoline.</li> </ol> |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |   |
|--|---|---|
| Supplement to Inspection<br>Guide No. 21 | PROCESS CHART No. 53  | In 3 sheets<br>Sheet 3  |
| CANOPY AND COCKPIT                       | INSPECTION OF PANELS FOR AIRCRAFT CONTROL RODS<br>AND OF COCKPIT SEALING ROSE | Man-hours<br>required - 0.15  |
| Procedure                                | Technical requirements  | Fault correction  |
|  |   | 5. Apply thin layer of cement No. 28<br>to horizontal surface of chute and to<br>bottom of rose and wait for 10 min |
| Accessories                              | Tools   |   |
|  | Screwdriver<br>French, 12 x 14  |   |

254

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 54  | In 2 sheets<br>Sheet 1       |
|---|---|------------------------------|
| CABINET AND COCKPIT   | MOUNTING EJECTION SEAT TO AIRCRAFT, MOUNTING CANOPY<br>AND CHECKING IT FOR PROPER OPENING AND CLOSING | Man-hours<br>required - 2.00 |
| Procedure   | Technical requirements  | Fault correction             |
| <p>1. Mount face blind actuated ejection seat on aircraft reversing dismantling procedure. To this end:</p> <p>(a) install tightening clamps on stabilizing flaps;</p> <p>(b) connect lifting device cable to seat;</p> <p>(c) lift ejection seat and lower it into guide rails;</p> <p>(d) install inserts fastening upper clasp of seat headrest to journals of ejection gun;</p> <p>(e) connect cable running to discharge valve;</p> <p>(f) connect amp hook of pull cord for AR-3 time release mechanism to clamp on frame;</p> <p>(g) load ejection gun and connect blocking cables</p> <p>2. Mounting canopy on aircraft is the reverse of dismantling</p> |   |                              |

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |                  |                             |
|--|--|------------------|-----------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 54   |                  | In 2 sheets<br>Sheet 2      |
| EMBARK AND OCCUPY  | EMERGENCY EJECTION SEAT ON AIRCRAFT. MOVING CANOPY<br>AND CHECKING IT FOR PROPER OPENING AND CLOSING               |                  | Man-hours<br>required - 2.0 |
| Procedure  | Technical requirements   | Fault correction |                             |
| <p>3. Charge air to aircraft air system through charging connection located in right-side wall of landing gear main strut wheel.</p> <p>4. Perform check opening and closing of canopy by operating inside and outside canopy control handles. Check canopy emergency jettison system.</p> | <p>Canopy should open and close easily and smoothly, without jerks when operated by inside or outside handles.</p> |                  |                             |
| Accessories  | Tools  |                  |                             |
| <p>Hose for charging air into aircraft air system</p> <p>Tightening clamp</p> <p>Device for checking cockpit for tightness</p>   | <p>Special wrench</p> <p>Files</p> <p>Wrench, 14 x 17 (2 pieces)</p>   |                  |                             |

266

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 23  | PROCESS CHART No. 55   | In 2 sheets Sheet 2       |
|--|--|---------------------------|
| CANOPY AND COCKPIT   | REMOVING AND RESETTING EJECTION SEAT   | Man-hours required - 1.90 |
| Procedure  | Technical requirements   | Fault correction          |
| <p><u>Removal of Ejection Seat</u></p> <p>1. Open canopy<br/>                     2. Make sure that all ground safety pins are installed</p> | <p>Ground safety pins should be installed in the following points (Fig. 34C):</p> <p>(a) in head of ejection gun<br/>                     CX 2500-36;<br/>                     (b) in canopy emergency jettison handle;<br/>                     (c) in plungers of firing mechanisms 215F and 215D (in two cylinders);<br/>                     (d) in hinged supports brackets;<br/>                     (e) in arrears of ejection seat (arrears should be closed with metal covers);<br/>                     (f) in roller of four-link mechanism for control of firing mechanism 215G;<br/>                     (g) in foot restraints when in top position;<br/>                     (h) in firing mechanism 215I</p> |                           |

267

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

| Supplement to Inspection Guide No. 21  |                        | PROCESS CHART No. 55  | In 8 sheets<br>Sheet 2       |
|--|------------------------|---|------------------------------|
| CANOPY AND COCKPIT   |                        | REMOVING AND MOUNTING EJECTION SEAT   | Man-hours<br>required - 1.30 |
| Procedure  | Technical requirements | Fault correction  |                              |
| <p>3. Unload the following firing mechanisms:</p> <p>(a) seat ejection gun TCM-2500-38 (to be performed by the armament man);</p> <p>(b) firing mechanism 215H of drogue chute (one cylinder);</p> <p>(c) firing mechanism 2154 for disengaging and separating canopy from seat (two cylinders);</p> <p>(d) firing mechanism 215P for unlatching pilot's safety harness (one cylinder)</p> <p>4. Disconnect cable of pin for drogue chute firing mechanism 215C from attachment fitting on aircraft</p> <p>5. Disconnect control cable from pin of firing mechanism TCM-2500-38</p> <p>6. Disconnect cable of AL-3 time release mechanism from aircraft attachment fitting</p> <p>7. Disconnect cable for opening hinged supports (for canopy) from bracket on cockpit floor</p> |                        | <p><b>Note.</b> Firing mechanisms TCM-2500-38 and 215H should be loaded and unloaded with ejection seat installed on aircraft</p> <p>Firing mechanisms 215P and 2150 should be loaded and unloaded with ejection seat removed from aircraft</p> |                              |

268

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspector's  
Guide No. 21

PROCESS CHART No. 25

In 8 sheets  
Sheet 3




FIG. 140 GROUND SAFETY LOCKS SCHEMATIC ARRANGEMENT  
 1 - TCu-2220-30 rocket motor gun head base (one piece); 2 - head lock of 215P shoulder; 3 - head lock of 215B canopy removal gun (two pieces); 4 - head lock of 2147 trigger gun (one piece); 5 - head lock of canopy support (two pieces); 6 - head lock of canopy support (two pieces); 7 - lock of canopy trigger on head (two pieces); 8 - lock of canopy support (two pieces); 9 - lock of canopy support (two pieces).

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |  |                              |
|--|---|--|------------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 55  |  | In 8 sheets<br>Sheet 4       |
| BARRY AND COVER  | REMOVING AND REQUIRING EJECTION SEAT  |  | Man-hours<br>required - 1.30 |
| <p style="text-align: center;"><b>Procedure</b></p> <p>8. Remove lower block of comm<br/>                 connector CX-2 and close it with cover<br/>                 9. Screw off thrust screws of hooks<br/>                 locking journals of firing mechanism<br/>                 in attachment units on boom CX-5102-500<br/>                 10. Secure hoist (crane) on ejection<br/>                 seat journals and lift seat slowly.<br/>                 Uncouple plug connector of supply<br/>                 conductor for electric motor MV-100AM<br/>                 used for adjusting ejection seat to<br/>                 pilot's height. Two persons should<br/>                 watch the seat coming out of cockpit<br/>                 (on both sides of cockpit)<br/>                 11. Install ejection seat on special<br/>                 pyramidal<br/> <u>Mounting Ejection Seat on Aircraft</u><br/>                 1. Load firing mechanism 215F for<br/>                 disengagement and separation of canopy<br/>                 from ejection seat and firing mecha-<br/>                 nism 215F for unlocking pilot's harness,<br/>                 after which insert ground safety pins<br/>                 in plungers of firing mechanism<br/>                 2. Insert ground safety pins into<br/>                 holes of brackets on lingal and foot</p> | <p style="text-align: center;"><b>Technical requirements</b></p> <p>When removing seat, move engine<br/>                 control lever forward or rearward as<br/>                 required</p> | <p style="text-align: center;"><b>Fault correction</b></p> |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                              |
|---|---|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 55  |                  | In 8 sheets<br>Sheet 5       |
| CANOPY AND COCKPIT  | REMOVAL AND MOUNTING EJECTION SEAT  |                  | Man-hours<br>required - 1.50 |
| Procedure   | Technical requirements  | Fault correction |                              |
| <p>supports and in arm rests of ejection seat. Close arm rests with metal covers</p> <p>3. Install ejection gun TCM-2500-38 in aircraft attachment beam (provided ejection gun has been removed from aircraft). To this end:</p> <p>(a) turn off screws out of ejection gun journals;</p> <p>(b) deflect one of attachment rods (see Dwg. 96-9102-173/1) and connect rod to journal;</p> <p>(c) deflect second elastic rod sideways and connect it to journal;</p> <p>(d) turn screws with washers into journals (install screws on side white)</p> <p>4. Turn off thrust screws of locking hooks in joints of ejection seat attachment beam if they have been installed (see Dwg. CR-9102-533)</p> <p>5. Lift ejection seat by means of hoist (or crane) and move upper rollers into seat guide profiles</p> <p>6. Lower seat slowly inside cockpit, then make stop to couple power supply</p> | <p>When lowering seat, make sure that side pins of foot rests have entered guides in cockpit floor and that foot grips remain opened.</p> |                  |                              |

271

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |   |
|---|--|---|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 55   | In 8 sheets<br>Sheet 6                              |
| CANOPY AND COCKPIT  | REMOVAL AND MOUNTING EJECTION SEAT   | Man-hours<br>required - 1.30                        |
| <p style="text-align: center;">Procedure</p> <p>                     bunched conductor connector of electric motor for adjusting seat to pilot's height. This done, lower seat until upper journals of ejection gun bear against seat catches.<br/>                     7. Turn home thrust screws of hooks in ejection seat attachment beam joints (dsg. CR-9107-533), locking thereby journals of ejection gun 208-2500-38 in attachment joints.<br/>                     8. Connect to special lugs in cockpit the following elements:<br/>                     (a) cable from pin of drogue chute firing mechanism 2152;<br/>                     (b) cable of time release mechanism AK-3;<br/>                     (c) cable for opening canopy hinged supports (i.e. cable running from cross shaft which locks hinged supports).<br/>                     9. Connect lower block of common connector CPX-2 with cable to middle block of seat.<br/>                     10. Remove ground safety pins from plungers of firing mechanism 2150 and                 </p> | <p style="text-align: center;">Technical requirements</p> <p>                     When lowering seat, be careful not to damage throttle control lever, for which purpose, move throttle control lever forward and rearward while lowering seat.                 </p> | <p style="text-align: center;">Fault correction</p> |

272

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 52               |                  | In 2 sheets<br>Sheet 7       |
|---|------------------------------------|------------------|------------------------------|
| CANOPY AND COCKPIT  | REMOVAL AND MOUNTING EJECTION SEAT |                  | Man-hours<br>required - 1.30 |
| Procedure   | Technical requirements             | Fault correction |                              |
| <p>from brackets of foot grip hinged supports</p> <p>11. Load firing mechanisms XM-2500-38 and XM-2151, install ground safety pins and connect them to ground safety pin cable of ejection seat</p> <p><u>Mounting Drogue Chute on Ejection Seat</u></p> <p>1. Install container plates into shape of plunger of firing mechanism XM-2151 by aligning container plate holes retaining primer caps with holes in shape</p> <p>2. Making use of lock pins fasten shape of plunger together with container plates and harness belt ring, having previously placed belt ring between plates of container at its right side</p> <p>3. Lock pins with locking wire XM-65</p> <p>4. Remove wire with seals from ends of container plates, otherwise container will not release drogue chute in case of falling out</p> |                                    |                  |                              |

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM:

|  |                                    |                  |                              |
|--|------------------------------------|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 55               |                  | In 8 sheets<br>Sheet 8       |
| CANOPY AND COCKPIT   | REMOVAL AND RECOVERY EJECTION SEAT |                  | Man-hours<br>required - 1.20 |
| Procedure  | Technical requirements             | Fault correction |                              |
| <p>5. Fasten snap hook of strand<br/>Hinge cover to lug in right-side box<br/>of headrest.</p> <p>For removing ejection chute reverse<br/>installation procedure.</p> <p>Prior to rearing container seal it<br/>through end holes of its plates.</p> |                                    |                  |                              |
| Accessories  | Tools                              |                  |                              |
| Device for removing seat from cockpit (sable)<br>Crane   | Screwdriver<br>Pliers              |                  |                              |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


| Supplement to Inspection Guide No. 21  |  | PROCESS CHART No. 56  | In 26 sheets - Sheet 1    |
|--|--|---|---------------------------|
| CANNY AND COCKPIT  |  | CHECKING OF EJECTOR SEAT WIRING AND CABLES FOR PROPER OPERATION | Man-hours required - 3.00 |
| Procedure  | Technical requirements   | Fault correction  |                           |
| 1. Unload firing mechanisms TCM-2500-38 and 2157 (Fig. 141)<br>2. Remove ejection seat from aircraft<br>3. Unload firing mechanisms 2157 and 2159<br>4. After armament specialist has performed check of firing mechanisms for proper striking of primer caps and has cleaned mechanism, perform checking of seat.<br>Inspect and check the following control cables for burrs and proper fastening in cable shoes:<br>(a) cable running from seat arm rest release lever to cross shaft of seat pan;<br>(b) cable running from plunger lever of firing mechanism 2157 to pin of firing mechanism TCM-2500-38;<br>(c) cable running from shoulder lock reel via roller of firing mechanism 2157 to attachment point on seat frame; | Firing mechanisms are to be unloaded by armament specialist.<br><br><b>WARNING,</b><br>When accomplishing scheduled maintenance operations on ejection seat, it is forbidden to make any adjustments, since all mechanisms have been adjusted at manufacturing plant.<br><br>Cables should be free from broken wires (or burrs). Cables are to be checked visually and by hand-feeling them (at accessible places) | If broken wires are found, defective cable should be replaced.  |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS SHEET No. 36   |                  | In 26 sheets - Sheet 3    |
|--|--|------------------|---------------------------|
| CABIN AND COCKPIT  | CHECKING OF SEATING SEAT BELTS AND CABLES FOR PROPER OPERATION |                  | Man-hours required - 3.00 |
| Procedure  | Technical requirements   | Fault correction |                           |
| <p>(d) shoulder lock reel locking cable running from the ratchet pawl lever to shoulder harness control lever on left-side arm rest;</p> <p>(e) cables (one right-side and one left-side) for waist belt restraint mechanism, running from handle on right-side arm rest to locks on rear side of seat pans;</p> <p>(f) cable running from seat ejection handle to roller of firing mechanism 2156 for separation of canopy from seat;</p> <p>(g) cable running from pins fastening container of drogue chute to head of firing mechanism 2153;</p> <p>(h) cable running from pin of firing mechanism 2151 to aircraft structure;</p> <p>(i) side supports opening cable running from rocker of lock sectors cross shaft to lug (bracket) on cockpit floor.</p> <p>Checking of cables over, coat them with MIL-PRF-201 lubricant</p> |  |                  |                           |

277

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |                              |
|--|--|---|------------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 56   |   | In 25 sheets<br>Sheet 6      |
| CANOPY AND COCKPIT   | CHECKING OF EJECTION SEAT CABLES AND CABLES FOR PROPER OPERATION |   | Man-hours<br>required - 1.00 |
| <p style="text-align: center;">Procedure</p> <p>5. Inspect seat cables and parts for corrosion paying particular attention on parts made of aluminum and painted green</p> <p>6. Coat with MATEM-201 lubricant all hinged joints of seat cables and bearings of all shafts; see that they are liberally lubricated</p> <p>7. Check adjustable section of control cables for intact sealing and locking</p> <p>8. Remove cover from case of transfer roller and coat it with MATEM-201 lubricant</p> <p>9. Remove jacket from ejection seat lifting screw for adjusting seat by pilot's height and coat screw liberally with MATEM-201 lubricant</p> <p>10. Coat with MATEM-201 lubricant guide rails of seat</p> <p>11. Replace grease in housing of electric motor M7-100-411 reduction gear in the following manner:</p> | <p style="text-align: center;">Technical requirements</p>        | <p style="text-align: center;">Fault correction</p> |                              |

276

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHECKLIST No. 35   |                  | In 26 sheets<br>Sheet 5   |
|--|--|------------------|---------------------------|
| CASSETT AND COCKPIE  | CHECKING OF EJECTION SEAT WIRING AND CABLES FOR PROPER OPERATION |                  | Man-hours required - 3.00 |
| Procedure  | Technical requirements   | Fault correction |                           |
| (a) screw off plug provided in bottom of electric motor reduction gear housing;<br>(b) wash reduction gear compartment with <del>clean</del> gasoline and blow off with compressed air;<br>(c) put fresh lubricant MILITARY-201 into reduction gear housing<br>12. Put lubricant MILITARY-201 into reduction gear housing of worm wheel of seat pan lifting screw. To this end:<br>(a) unscrew bearing cover of vertical shaft which rotates seat screw;<br>(b) remove bearing with seat and put lubricant into housing.<br>Re-install bearing with seat and close it with cover<br>13. Check electric wiring of seat lifting mechanism for condition<br>14. Check ejection seat controls for proper operation; check all firing indicators for striking primer caps |  |                  |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 23  | PROCESS CHART No. 56  |                  | In 26 sheets<br>Sheet 6      |
|---|---|------------------|------------------------------|
| CANOPY AND COCKPIT  | CHECKING OF EJECTION SEAT UNITS AND CABLES FOR PROPER OPERATION   |                  | Man-hours<br>required - 5.00 |
| Procedure   | Technical requirements  | Fault correction |                              |
| <p><u>Checking Firing Mechanism 215P and TCM-2500-38 for Stripline Primer Caps</u></p> <p>Attach firing mechanism (ejection gun) TCM-2500-38 to seat.</p> <p>Load firing mechanisms ECM-2500-38 and 215P with special cartridges which do not contaminate firing mechanism during checking (checking procedure should be done by armament specialist).</p> <p>Connect controls to firing mechanisms.</p> <p>By slowly compressing release lever with protecting yoke actuate first mechanism 215P and then mechanism TCM-2500-38.</p> <p>Unload firing mechanisms TCM-2500-38 and 215P. Make certain primer caps have operated.</p> <p>Place locking plungers of firing mechanisms to initial position.</p> | <p>Checking seat units should be done with ejection seat installed on pyramid 76-9691-300</p> <p>The second firing mechanism 215P operates, pin of ejection seat firing mechanism TCM-2500-38 should remain stationary.</p> |                  |                              |

280

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 56   |                  | In 26 sheets<br>Sheet 7      |
|--|--|------------------|------------------------------|
| CANNOPY AND COCKPIT  | CHECKING OF EJECTION SEAT STRAPS AND CABLES FOR PROPER OPERATION           |                  | Man-hours<br>required - 3.00 |
| Procedure  | Technical requirements   | Fault correction |                              |
| <p><u>Checking Harness System Restraint Mechanism for Proper Functioning</u></p> <p>After parachute leg straps of harness system have been passed through loops of harness side straps, engage the ratchet buckles to connect waist belt restraint mechanism.</p> <p>Press from outside handle on left arm rest (Fig. 14L, Ref. 17) and deflect it rearward. While holding handle in this position, pull out fastening cable of shoulder restraint lock, as far as it will go.</p> <p>See certain fastening cable is locked in pulled out position.</p> <p>Note: On late ejection seats un-locking and locking of cable is performed manually.</p> <p>Roll waist restraint buckles 16 with pulleys having placed waist belt restraint handle 26 on right arm rest to extreme forward position.</p> | <p>In the course of locking cable makes return movement by 25 - 30 mm.</p> |                  |                              |

261

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                  |                             |
|--|---|------------------|-----------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 56  |                  | In 26 sheets<br>Sheet 8     |
| CAPSULE AND COCKPIT  | CHECKING OF EJECTION SEAT ENTRY AND CABLES FOR PROPER OPERATION |                  | Man-hours<br>required - 3.0 |
| Procedure  | Technical requirements  | Fault correction |                             |
| <p>Take seat and connect fastening cable of shoulder harness lock 50 to soft connecting strap of parachute harness.</p> <p>Pass leg straps of parachute harness through waist restraint buckles and secure them in central lock.</p> <p>Make waist belt restraint system operate by moving its handle on right arm rest fore and aft.</p> <p>Activate shoulder belt restraint mechanism. To this end, lean forward, pull out fully fastening cable of shoulder lock and then lean back against seat back. In this case spring of firing mechanism 215P should retract fastening cable into shoulder lock and secure it in this position.</p> <p>Unlock shoulder belt system by pulling handle 17 on left-side arm rest and by leaning forward pull shoulder lock cable as far as it will go.</p> |   |                  |                             |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 56  | Is 26 sheets<br>Sheet 7      |
|---|---|------------------------------|
| CANOPY AND OCCUPIE  | CHECKING OF EXTENSION STRAP CABLES FOR PROPER OPERATION   | Man-hours<br>required - 3.00 |
| Procedure   | Technical requirements  | Fault correction             |
| <p>Perform this procedure three times, then unlock shoulder belt system and disconnect soft connecting link of parachute harness system from shoulder lock cable.</p> <p>Pull out waist belt system cables by placing waist belt restraint handle on right-side arm rest to extreme forward position.</p> <p>Disconnect leg straps of parachute harness system from waist belt restraint handles.</p> <p>Check amount of extension of shoulder lock cable</p> | <p>The extension of shoulder lock cable should amount to 100 mm</p> <p>Note: By cable extension is meant distance between centre of leg, locked with cable in extended position, and top edge of hole in lock body minus distance from top edge of hole to centre of leg with cable in retracted position</p> |                              |

203

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                              |
|---|--|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 56   |                  | In 20 sheets<br>Sheet 10     |
| COVER AND SOCKET  | CHECKING OF EJECTION GEAR UNITS AND GAMES FOR PROPER OPERATION |                  | Man-hours<br>required - 3.00 |
| Procedure   | Technical requirements   | Fault correction |                              |
| <p>                     Checking Firing Mechanism 2154<br/>for Proper Function:                 </p> <ol style="list-style-type: none"> <li>1. Load firing mechanism 2159 with special explosive charge (to be performed by armament specialist)</li> <li>2. Set time release mechanism A1-3 (Inst. 2), for which purpose:                         <ol style="list-style-type: none"> <li>(a) Disconnect cable of A1-3 mechanism from cross shaft lever by removing axle;</li> <li>(b) cock time release mechanism by pulling out fully time release mechanism cable by means of ring with hook (supplied with time release mechanism);</li> <li>(c) insert flexible pin into time release mechanism A1-3 and lock it;</li> <li>(d) connect cable to lever of cross shaft;</li> <li>(e) lock spring intensifier for opening harness restraint locks</li> </ol> </li> <li>3. Remove flexible pin which will cause time release mechanism to operate and turn cross shaft that controls through rods locking plunger levers of</li> </ol> |  |                  |                              |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 56   | In 26 sheets<br>Sheet 11 |
|---|--|--------------------------|
| CASSETTE AND COCKPIT  | CHECKING OF ELECTRIC BOLT DRIVES AND CABLES FOR PROPER OPERATION |                          |
| Man-hours required - 3.00   |  |                          |
| Procedure   | Technical requirements   | Fault correction         |
| firing mechanisms 2150; as a result, firing mechanisms will operate. Check firing intensifier for proper engagement<br>4. Reload firing mechanisms and check whether primer caps have operated<br>5. Cock locking plunger of firing mechanisms 2150<br>6. Cock time release mechanism A1-3<br>7. Lock pin with thick thread<br>8. Turn cross shaft controlling firing mechanisms into initial position<br>9. Place locking plungers to their initial positions<br><br>Restrain System for Emergency Opening of Restraint Locks and Foot Straps<br><br>Lock spring intensifier.<br>By operating handle on right-side control actuate waist belt restraint system. Actuate shoulder restraint system.<br>Turn locking screws out of firing mechanism 2150, out of attachment clamp of firing mechanism 2151, out of rods for opening 2152 mechanism clamp after |  |                          |

285

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                  |                              |
|--|---|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART For-56  |                  | In 26 sheets<br>Sheet 12     |
| CAPOPY AND COCKPIT   | CHECKING OF EJECTION SEAT BRIGGS AND CABLES FOR PROPER OPERATION                      |                  | Map-Notes<br>required - 3, 6 |
| Procedure  | Technical requirements  | Fault correction |                              |
| <p>which bend off locking plate of rods of firing mechanism 215; clamp.<br/>Put feet into foot grips and lock them.<br/>Fit special extension pieces on journals of cross beam in order to turn canopy jettison levers.<br/>Through the use of extension pieces turn gradually canopy jettison levers 10 until they come in touch with levers 12 on cross shaft under base; keep turning levers further and make certain that attachment clamp of firing mechanism 215 has opened and that foot grips 22 have opened first or simultaneously (to release feet), then shoulder belt lock 31 and only then waist belt locks.<br/>Set whole system to initial position and cock shoulder belt lock, waist belt locks, and foot grip locks</p> | <p>After waist belt locks have opened, levers should be free to travel 10 or more</p> |                  |                              |

206

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Applicant to Inspection<br>Guide No. 21   | PROCESS CHART No. 56   |  | In 26 sheets<br>Sheet 13     |
|---|--|--|------------------------------|
| CAPACITY AND COCKING  | CHECKING OF MECHANICAL PARTS AND CLEARING FOR PROPER OPERATION |  | Man-hours<br>required - 3.00 |
| Procedure   | Technical requirements   | Fault correction   |                              |
| <p><u>Cocking Shoulder Belt Lock</u></p> <p>Disconnect rod connecting lever of cross shaft with lever on upper cross bar provided with journals. For this purpose remove lock pin used for attachment of rod to lever 12.</p> <p>Insert harness cable (strap) 30 into hole of shoulder belt lock and move it inside lock as far as it will go. Lock 31 should rotate in this case.</p> <p>Making access through hole in lock body, press pawl tongue with screw driver and bring pawl lug into strap loop, which will correspond to LOCKED (ЗАКРЫТО) position.</p> <p>While holding pawl with roller in this position by means of screwdriver, move plunger inside lock.</p> <p><u>Cocking Waist Belt Locks and Foot Grip Locks</u></p> <p>Turn levers with rockers turning to foot grips so as to bring stops into engagement with ratchets.</p> | <p>Pull harness strap to make sure that lock is closed</p>     | <p>If lock fails to get closed, repeat cocking procedure</p> |                              |

287

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                              |
|---|---|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 56  |                  | In 26 sheets<br>Sheet 14     |
| CARRY AND OCCUPY  | CHECKING OF EJECTION SEAT UNITS AND CANALS FOR PROPER OPERATION   |                  | Man-hours<br>required - 3.00 |
| Procedure   | Technical requirements  | Fault correction |                              |
| <p>Turn cross shaft of beam up by its levers until right-side lever (as viewed from aircraft rear) of vertical shaft touches with its lower slot rod pin connecting levers of waist belt locks. In this case rod running to control shaft for waist belt locks will travel to left and through leverage system will turn foot grip control shaft levers and bring them to foot grip levers.</p> <p>Put ends of waist belt restraint cables into locks.</p> <p>Close belt restraint locks.</p> <p>Move rod connecting levers of waist belt locks to left (as viewed from aircraft rear) so that lugs on lock lever which close grips prevent waist belt lock grips from coming out.</p> <p>Pull waist restraint cables to make sure that they are locked.</p> <p>Turn beam cross shaft by lifting its end levers so that right-side end of slot in lever of lower vertical shaft</p> | <p>Cross shaft levers should be placed so that their bolt heads and those on control rockers of foot grips coincide</p> |                  |                              |

288

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21   | PROCESS CONTROL No. 56   |                  | In 26 sheets<br>Sheet 15     |
|--|--|------------------|------------------------------|
| CARPET AND COCKPIT   | CHECKING OF ELECTRIC SEAT BELTS AND CABLES FOR PROPER OPERATION  |                  | Man-hours<br>required - 3.00 |
| Procedure  | Technical requirements   | Fault correction |                              |
| <p>removes pin of rod connecting levers of waist belt locks.</p> <p>As a result, control rocker of foot pedals will be locked through system of rods and levers</p> <p><u>Finalize Operation of Control Lever Supports and Pedaling Effort Required for Their Folding</u></p> <ol style="list-style-type: none"> <li>1. Make sure that safety pins are installed in hinged supports</li> <li>2. Turn shear locking screw out of left-side sector of control shaft for collapsible supports</li> <li>3. Remove ground safety pins from each support in turn having taken necessary precautions</li> <li>4. After taking necessary precautions turn control shaft</li> <li>5. Turn shear screw out of steps which lock moving spring pin in slot of support, strike stop with rods of 10-mm diameter. Check in this manner each support</li> </ol> | <p><u>Precautionary Remarks</u></p> <p>When turning hinged supports control shaft be sure that nobody is present close to supports.</p> <p>Supports should get opened (get turned through 90°) and locked by spring pins</p> |                  |                              |

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |  |                              |
|---|--|--|--|------------------------------|
| Supplement to Inspection Guide No. 21   |  | PROCESS CHART No. 56   |  | In 26 sheets<br>Sheet 16     |
| CAPTIV AND OCCUPY   |  | CHECKING OR EJECTION SEAT WIRING AND CABLES FOR PROPER OPERATION                               |  | Man-hours<br>required - 3.00 |
| Procedure   |  | Technical requirements   | Fault correction                                   |                              |
| <p>6. Tight spring pins and lock them with stops by turning in shear screws</p> <p>7. Connect dynamometer to each support in turn and measure initial efforts required to fold supports. Connect dynamometer to arm of support. When doing so unlock support by pressing pin with rod inserted through hole on top of bracket, after which bring rod back from hole</p> <p>8. Fold hinged supports using reverse procedure and install ground safety pins</p> <p><u>Removal of Drogue Chute and Checking It for Proper Folding</u></p> <p>1. Disconnect thistle of chute around lines from swivel of locking plunger of firing mechanism 2150</p> <p>2. Unfasten snap hook of chute around lines cover from lag in right-side recess of ejection seat head rest</p> <p>3. Seal drogue chute container through and holes in its plates</p> |  | <p>Spring finger should extend</p> <p>Effort for folding supports should be at least 18 kg</p> | <p>Replace spring if effort is less than 18 kg</p> |                              |
| <p>Checking and folding of drogue chute should be made in accordance with relevant instructions</p> <p><u>WARNING:</u> It is forbidden to take off with drogue chute container sealed as container will fall to release drogue chute at ejection</p>  |  |  |  |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                              |
|---|---|------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 56  |                  | In 25 sheets<br>Sheet 17     |
| OBJECT AND OBJECTIVE  | CHECKING OF EJECTOR SEAT SYSTEM AND GAGES FOR PROPER OPERATION  |                  | Man-hours<br>required - 5.00 |
| Procedure   | Technical requirements  | Fault correction |                              |
| 4. Dismantle and remove pins from<br>plates of container<br>5. Remove plates of container from<br>edge of locking plunger of firing mechanism 2150 and remove drogue chute. Install<br>pins of drogue chute in the reverse of<br>panel<br><u>Setting Safety Belt Locks for Proper<br/>                 Operation from Ejector Seat</u><br>1. Remove roller cover and mark position<br>of roller in slot. Mark recess which<br>accommodates lug of cable running to<br>hooklink reel in order to place lug of<br>cable in the same recess should it become<br>necessary to disconnect this cable<br>2. Arrange personnel parachute with<br>harness in seat pan and connect it to<br>tabs of shoulder and waist belt restraint<br>system<br>3. Occupy seat, put on harness,<br>attach central lock of harness, operate<br>shoulder and waist belt restraint mechanism<br>and close foot grips | Perform checking with spring<br>interlock locked and unlocked.<br>Locking plungers of firing<br>mechanism 2150 should operate.<br>All locks and foot grips should<br>open |                  |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   |   | PROCESS CHART No. 56   | In 26 sheets<br>Sheet 18     |
|---|---|--|------------------------------|
| CAPTIV AND COCKPIT  |   | CHECKING OF EJECTION SEAT SYSTEM AND CABLES FOR PROPER OPERATION | Man-hours<br>required - 3.00 |
| Procedure   | Technical requirements  | Fault correction   |                              |
| <p>4. Pull slowly handle 25 located on front side of seat pan.</p> <p>Returns whole system to initial position, for which purpose proceed as follows:</p> <p>(a) pass handle cable with lug through connecting pipe of roller body;</p> <p>(b) bring recess for cable lug in roller to outlet of cable from roller body;</p> <p>(c) insert lug of cable running from handle into recess in roller;</p> <p>(d) secure cover on roller body;</p> <p>(e) disconnect rods from release levers of firing mechanism 2159;</p> <p>(f) rotate cross shaft which controls firing mechanism 2159; having lowered shaft levers;</p> <p>(g) move up levers of cross shaft as high as free travel of vertical shaft lever permits;</p> <p>(h) check control lever of four-link piece for proper locking.</p> | <p>After waist belt locks have opened handle should be free to travel for at least 6 in before disconnection.</p> <p>Handle with cable should remain in hand.</p> <p>Rotation of cross shaft should cause turning of roller connected to shaft, while handle cable should return to initial position.</p> |  |                              |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 2a  | PROCESS PLANT No. 36   | In 26 sheets Sheet 15     |
|--|--|---------------------------|
| CANOPY AND COCKPIT   | CHECKING OF ELECTRIC AND HYDRAULIC CIRCUITS FOR PROPER OPERATION | Man-hours required - 3.00 |
| Procedure  | Technical requirements   | Fault correction          |
| <p>                     Checking Operation of System for Providing Ejector Seats<br/>                     Perform checking in the following sequence:<br/>                     (a) uncouple from cross shaft all connections which control units;<br/>                     (b) remove locks from levers for attachment of shackles connected with canopy control lever;<br/>                     (c) turn out safety screws of lock which closes split yoke;<br/>                     (d) turn safety screws out of firing mechanism 2154;<br/>                     (e) lower canopy control levers down as far as they will go;<br/>                     (f) make sure that lock of split yoke connecting upper and lower portions of firing mechanism 2154 outer yoke has released yoke and the latter can be opened and that shackles have the off pins of levers;<br/>                     (g) return system to initial position.                 </p> |  |                           |

293

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 56  |                  | In 26 sheets<br>Sheet 20    |
|---|---|------------------|-----------------------------|
| CAMRET AND COCK-IT  | CHECKING OF EJECTION SEAT BELTS AND CABLES FOR PROPER OPERATION |                  | See-Items<br>required - 1,2 |
| Procedure   | Technical requirements  | Fault correction |                             |
| <p>(a) Turn safety screws into lock of split yoke and install new locking plates:<br/>                     (1) lock shackles on pins of levers;<br/>                     (2) turn safety screws into firing mechanism 2150</p> <p><u>Checking Explosive Charge of Firing Mechanism 2150 for Proper Operation</u></p> <ol style="list-style-type: none"> <li>1. Load firing mechanism 2150 with special dummy cartridge provided with primer caps</li> <li>2. Connect cable to pin of firing mechanism locking plunger</li> <li>3. Pull locking pin out of locking plunger, which will result in operation of firing mechanism</li> <li>4. Unload firing mechanism and make sure that primer caps have been struck</li> <li>5. Cock and reinstall locking plunger of firing mechanism and reconnect cable</li> </ol> |   |                  |                             |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |                              |
|---|--|--|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 56   |  | In 26 sheets<br>Sheet 21     |
| CHECKLIST AND CHECKOFF  | CHECKING OF EFFECTIVE GEAR WEARS AND CARES FOR PROPER OPERATION  |  | Man-hours<br>required - 3.00 |
| <p style="text-align: center;"><b>Procedure</b></p> <p><u>Installing and Checking Condition of Special Safety Devices Which Lock Separate Units</u></p> <p>For checking use the following procedure:</p> <p>(a) check screw of split yoke lock of firing mechanism 215H;</p> <p>(b) check screw of firing mechanism 215H;</p> <p>(c) check screw of beam drop control lever located on cross beam with journals;</p> <p>(d) check screw of pin fastening carrier on firing mechanism 215H;</p> <p>(e) check screw of cross shaft which controls canopy hinged supports;</p> <p>(f) check screw of firing mechanism 215H;</p> <p>(g) check locking device of cross shaft which opens safety harness locks;</p> <p>(h) check locking device of firing mechanism 215H drive;</p> <p>(i) check locking plate of rods which open yoke of firing mechanism 215H</p> | <p style="text-align: center;"><b>Technical requirements</b></p> <p>After installation safety screws should be turned right loose.</p> <p>Locking plates (one at each side of lock) should fit closely to plate rods, and tabs of plates should be bent on rods.</p> <p><u>REMARKS:</u></p> <p>Locking plates of yoke for attachment of firing mechanism 215H should be used only once. Therefore, it is not allowed to bend tabs of locking plates twice.</p> <p>When performing scheduled or some other maintenance operations which require bending of plate tabs, replace plates with new ones</p> | <p style="text-align: center;"><b>Fault correction</b></p> |                              |

295

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                              |
|---|--|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 55   | In 26 sheets<br>Sheet 22     |
| CANOPY AND COCKPIT  | CHECKING OF EJECTION SEAT UNITS AND CABLES FOR PROPER OPERATION  | Man-hours<br>required - 3.00 |
| <b>Procedure</b>  | <b>Technical requirements</b>  | <b>Fault correction</b>      |
| <p><b>Checking Ejection Seat Units and Canopy for Joint Operation (seat removal)</b></p> <ol style="list-style-type: none"> <li>1. Open canopy and unload firing mechanisms TMC 2500-38 and 2157</li> <li>2. Install ground safety pins in firing mechanisms 2156 and 215P and in sectors of foot grip rods</li> <li>3. Remove at</li> <li>4. Unload ring mechanisms 2154 and 215P</li> <li>5. Remove firing mechanism TCM 2500-38 from aircraft</li> <li>6. Install on aircraft special actuating cylinder filled with AK-10 oil and provided with hose and cock. Connect to rear portion of canopy lifting device for providing starting effort of 150-200 kg</li> <li>7. Turn off special shear screws from the following units: from canopy front grip locks, from upper bushings of canopy rear grip locks,</li> </ol> | <p>This kind of check should be made in the following cases:</p> <ul style="list-style-type: none"> <li>(a) when replacing seat or canopy</li> <li>(b) after removing or replacing arrow plate;</li> <li>(c) when repairing cockpit or making any modifications that may affect operation of seat mechanisms or prevent seat from coming out of cockpit. Removal of ejection seat from cockpit should be made only when cockpit is fully fitted with standard equipment.</li> </ul> <p>To avoid damaging engine control lever during removal of ejection seat move engine control lever fore and aft</p> |                              |

236

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  |   | PROCESS 4-1-67 No. 56   | In 26 sheets Sheet 23     |
|--|---|---|---------------------------|
| CANOPY AND COCKPIT   |   | CHECKING OF SECTION SEAT WIRING AND CIRCUITS FOR PROPER OPERATION | Man-hours required - 3.00 |
| Procedure  | Technical requirements  | Fault correction  |                           |
| <p>From left sector of control shaft for mixed supports and from stoppage locking spring pins on supports for the canopy front grip locks</p> <p>8. Install seat on aircraft</p> <p>9. Lower seat pan into extreme lower position</p> <p>10. Close canopy and check clearance between journal and lower surface of hook of canopy rear grip lock. Do not pressurize cockpit</p> <p>11. Pass hoses from ground installation through connecting pipe for cockpit air conditioning and connect them to cock.</p> <p>Then one of inspectors should occupy ejection seat and take hold of hydraulic actuating cylinder control valve</p> <p>12. Install two auxiliary bolts in canopy rear arch (instead of two operating bolts that have been screwed off) and connect to them dynamometer through cable. Connect other end of dynamometer</p> | <p>Clearance between journal and the lower surface of canopy lock hook should be at least 2 mm (greater size is not limited)</p> <p>Clearance between bosses of journals and canopy carrying panel should be not over 0.2 mm.</p> <p>Right-side and left-side journals are allowed to press canopy locks with up to 2 mm difference</p> |   |                           |

237

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21  |  | PROCESS CHART No. 56   |  | In 40 sheets<br>Sheet 24    |  |
|---|--|--|--|-----------------------------|--|
| CANOPY AND COCKPIT  |  | CHECKING OF EJECTION SEAT USERS AND CABLES FOR PROPER OPERATION  |  | Man-hours<br>required - 3.0 |  |
| Procedure   |  | Technical requirements   |  | Fault correction            |  |
| <p>to hook of crane and apply 150-200 kg effort preliminarily on canopy as read by dynamometer</p> <p>13. Raise slowly seat until its journals come into nests for canopy locks and make certain that canopy locks have operated</p> <p>14. Continue raising seat and make sure that:</p> <p>(a) pin of firing mechanism 215<sup>1</sup> has been pulled out properly;</p> <p>(b) as soon as surface of canopy supports reaches lower level of canopy-carrying panel, levers holding canopy supports start turning and supports open</p> <p>15. Check operation of common connector CPE-2 and make sure that tightening of cables and uncoupling of lower block of ping connector do not cause stresses in aircraft hoses EB-26 and in anti-G suit hose</p> <p>16. Continue raising seat until lower ends of seat guides reach middle rollers</p> |  | <p>The pin should be pulled out of firing mechanism 215<sup>1</sup> after seat travels approximately 10-50 cm</p> <p>Half-opened supports slide along canopy-carrying panel, then they open completely after passing panel and remain under canopy pin</p> |  |                             |  |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |                  |                             |
|--|--|------------------|-----------------------------|
| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 56   |                  | Is 25 sheets<br>Sheet 25    |
| CABINET AND COCKPIT  | CHECKING OF EJECTION SEAT LEVERS AND CABLES FOR PROPER OPERATION   |                  | No hours<br>required - 5.00 |
| Procedure  | Technical requirements   | Fault correction |                             |
| 17. Lower seat and start removing it again from position when seat pan is in upmost position<br>18. Remove seat and install it together with canopy on pyramid; check clearance between stops in two-arm levers of ejection seat and levers on rear grip locks of canopy<br>19. Open manually front and rear grip locks of canopy and separate canopy from ejection seat; place canopy lock system and seat lock system to initial position<br>20. Turn safety screws into front and rear grip locks and place aluminum rivet 3520A-2-6 in front lock of the delay mechanism | After replacing canopy or seat, check clearance between insert of front lock and side of seat support. Clearance should be at least 3 mm<br><br>Turn into front grip lock safety screw E6-0605-216 made of material AI-1.<br>Turn into rear grip lock safety screw E6-0605-801 made of material AI-1 | 299              |                             |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21   |  | PROCESS CHART No. 56   |  | In 26 sheets<br>Sheet 26     |
|--|--|--|--|------------------------------|
| CANOPY AND COCKPIT   |  | CHECKING OF EJECTION SEAT WIRING AND CABLES FOR PROPER OPERATION |  | Man-hours<br>Required - 3.00 |
| Procedure  | Technical requirements   | FAULT CORRECTION   |  |                              |
|  | Install screws on zinc white<br>(prepared on natural drying oil) |  |  |                              |
| Accessories  |  | Tools  |  |                              |
| Device for removing canopy by crane<br>Device for checking ejection seat<br>Device for removing ejection seat by crane |  |  |  |                              |

300

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS CHART No. 57  |   | In 2 sheets<br>Sheet 1     |
|--|---|---|----------------------------|
| CASSETT AND COCKPIT  | CHECKING COCKPIT FOR LEAKAGES   |   | Man-hours<br>required - 25 |
| Procedure  | Technical requirements  | Fault correction  |                            |
| <ol style="list-style-type: none"> <li>Place valve of pressure regulator APL-578 to OFF (BACKFIRE) position</li> <li>Close cockpit air supply valve</li> <li>Connect hoses of ground device 44-76/50-060 to cockpit pipe unions located in landing gear nose strut wall</li> <li>Connect ground air bottle to ground device</li> <li>Close canopy and pressurize cockpit from outside</li> <li>Open valve of ground air bottle and device and watch readings of PFL-20 instrument</li> <li>Build up pressure in cockpit as high as 230-235 mm Hg, after which stop air supply to cockpit by closing valve of ground air bottle and ground device</li> <li>Measure time during which cockpit pressure drops from 230 to 210 mm Hg. Perform this operation 2 or 3 times</li> </ol> | <p>Cockpit pressure rise ratio should not exceed <math>0.1 \text{ kg/cm}^2</math> during 1 min.</p> <p>For calculating cockpit pressure drop time refer to Chart No. 1 57-22A-76-1. Cockpit is considered tight if air leakage is not over 10 kg/hr</p> | <p>In case cockpit air leaks through APL-578 regulator with valve in OFF (BACKFIRE) position, plug outlet pipe of regulator APL-578. If air leakage exceeds 10 kg/hr, it is necessary to trace place of leak.</p> |                            |

301

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |   |                            |
|---|---|---|----------------------------|
| Supplement to Inspection<br>Guide No. 22  |   | PROCESS CHART No. 57  | In 2 sheets<br>Sheet 2     |
| CANNY AND COCKPIT   |   | CHECKING COCKPIT PRESSURE   | Man-hours<br>required - 25 |
| Procedure   | Technical requirements                                      | Fault correction  |                            |
| <p>9. Depressurize cockpit and open canopy by operating outside arm</p> <p>10. Set valve of regulator 475-578 to ON (RELEASE) position and lock with wire TPL-0.8</p> <p>11. Disconnect hose of ground device from cockpit pipe unions, plug and seal pipe unions</p> |   | <p>age slowly (by hissing sound) or with the help of soapy water.</p> <p>Fairleads of rods and cables should be checked first</p> |                            |
| Accessories   | Tools   |   |                            |
| <p>Device for measuring amount of cockpit pressurization</p> <p>Ground bottle with compressed air</p>   | <p>Wrench for cockpit pressurization system pipe unions</p> |   |                            |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROJECT CHART No. 56   |  | In 3 sheets Sheet 1       |
|--|--|--|---------------------------|
| CANOPY AND COCKPIT   | REMOVING FILTER OF AIR-6 PRESSURE CONTROLLER, CLEANING FILTERS AND CHECKING PRESSURES  |  | Man-hours required - 0.30 |
| Procedure  | Technical requirements   | Fault correction   |                           |
| <p>1. Screw off cover and remove filter of pressure controller AI-6. Clean filter with soft hair brush and check filtering element for condition</p> <p>2. Reinstall cover</p> <p>3. Connect hose of 4 lit. bottle provided with pressure gauge (instead of pressure suit) to hose of HML-1 anti-G suit (on upper block of OXI-12 plasma connector)</p> <p>4. Close cockpit air supply valve</p> <p>Note: Testing is allowed with cockpit air supply valve OPEN. N.A. in this case cockpit should be pressurized</p> | <p>Clean filter carefully so as not to damage filtering element. Check to see that no hairs remain on filtering element.</p> <p>Tore paper inside corrugations and in outer ribs, deep dents on paper, expansion of individual corrugations in excess of 4 mm and abridgment of other corrugations, twisting and sharp bends of corrugations are not allowed</p> | <p>If filtering element has any of the above indicated defects, replace it</p> |                           |

303

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21   | PROCESS CHART No. 58  |  | In 3 sheets<br>Sheet 2  |     |                  |       |                    |       |                    |       |                    |  |  |
|--|---|--|---|-----|------------------|-------|--------------------|-------|--------------------|-------|--------------------|--|--|
| GROUP AND COCKPIT  | REMOVING FILTER OF AI-5 PRESSURE CONTROLLER, CLEANING<br>FILTER AND CHECKING PRESSURE   |  | Man-hours<br>required - 0.30                                    |     |                  |       |                    |       |                    |       |                    |  |  |
| Procedure  | Technical Requirements  | Fault correction                           |   |     |                  |       |                    |       |                    |       |                    |  |  |
| <p>5. Install special device with weight on head of AI-5 pressure controller</p> <p>6. Start engine and accelerate it to 65 % normal rating</p> <p>7. Using device create required effort on bottom of pressure controller AI-5 and read pressure value off pressure gauge of device produced by pressure controller AI-5</p> <p>8. After adjusting or replacing pressure controller AI-5 check system</p> | <p>Output pressure should be as follows</p> <table border="1" data-bbox="933 1396 1193 1564"> <tr> <td>Effort, P, on bottom of AI-5 controller, g</td> <td>Output pressure produced by AI-5 controller, kg/cm<sup>2</sup></td> </tr> <tr> <td>351</td> <td>17-33 up to 0.04</td> </tr> <tr> <td>1,053</td> <td>165-205 up to 0.27</td> </tr> <tr> <td>1,755</td> <td>325-365 up to 0.48</td> </tr> <tr> <td>2,457</td> <td>450-475 up to 0.62</td> </tr> </table> <p>There should be no air leaks through connections of pressure controller AI-5</p> | Effort, P, on bottom of AI-5 controller, g | Output pressure produced by AI-5 controller, kg/cm <sup>2</sup> | 351 | 17-33 up to 0.04 | 1,053 | 165-205 up to 0.27 | 1,755 | 325-365 up to 0.48 | 2,457 | 450-475 up to 0.62 | <p>If required output pressure can not be obtained by adjusting pressure controller AI-5, replace the latter</p> <p>In case of leakage, tighten connection or replace gasket</p> |  |
| Effort, P, on bottom of AI-5 controller, g   | Output pressure produced by AI-5 controller, kg/cm <sup>2</sup>   |  |   |     |                  |       |                    |       |                    |       |                    |  |  |
| 351  | 17-33 up to 0.04  |  |   |     |                  |       |                    |       |                    |       |                    |  |  |
| 1,053  | 165-205 up to 0.27  |  |   |     |                  |       |                    |       |                    |       |                    |  |  |
| 1,755  | 325-365 up to 0.48  |  |   |     |                  |       |                    |       |                    |       |                    |  |  |
| 2,457  | 450-475 up to 0.62  |  |   |     |                  |       |                    |       |                    |       |                    |  |  |

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                           |
|---|--|------------------|---------------------------|
| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 50   |                  | In 3 sheets Sheet 3       |
| CANOPY AND COCKPIT  | REMOVING FILTER OF AR-5 PRESSURE CONTROLLER, CLEANING FILTER AND CHECKING PRESSURE |                  | Man-hours required - 0.30 |
| Procedure   | Technical requirements   | Fault correction |                           |
| for tightness with the help of soap suds  |  |                  |                           |
| Accessories   |  | Tools            |                           |
| Bottle (4-lit. capacity) with pressure gauge<br>Special device with weight<br>Brush |  |                  |                           |

305

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |  |                              |
|---|---|--|------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 54  |  | In 1 sheet<br>Sheet 1        |
| CATEGORY AND CONCEPT  | CHECKS FLEXIBLE CASING OF CONTROL CABLE OF VALVE HV-7 AND<br>VALVES HV-7 AND HV-8 FOR JOINTS AND ATTACHMENT   |  | Man-hours<br>required - 6.50 |
| Procedure   | Technical requirements  | Fault correction   |                              |
| <p>1. Wash with clean gasoline joint between cable and HV-7 valve control lever on aircraft control stick</p> <p>2. Check condition and attachment of flexible casing and control cable of HV-7 valve for wear and burrs. To find burrs, hand-feel cable over its entire length. When examining cable pay particular attention to its sharp bends, to places where cable protrudes from flexible casing, and to its lag</p> <p>3. Check HV-7 and HV-8 valves, bell crank and their control rod for attachment; wash them in gasoline and blow off with compressed air</p> <p>4. Lubricate HV-7 valve control cable with oil HV-8 (transformer oil); lubricate cable-to-control lever joint, connections between cable and bell crank and HV-8 valve control rod</p> | <p>Control cable of HV-7 valve should be free from any wear and broken wires (burrs). Flexible casing and cable should be laid without any sharp bends which may result in excessive friction of cable.</p> <p>Flexible casing and HV-7 and HV-8 valves should be securely attached</p> | <p>Replace cable if it has broken wires or is chafed</p> |                              |
| Accessories   | Tools   |  |                              |

305

SECRET/NO FOREIGN DISSEM

Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Order No. 21   | PROCESS CHART No. 60  |   | In 2 sheets<br>Sheet 1       |
|--|---|---|------------------------------|
| FUSELAGE   | REPLACING OIL IN TURBO-COOLER BEARINGS                            |   | Man-hours<br>required - 0.25 |
| Procedure  | Technical Requirements  | Fault correction  |                              |
| <ol style="list-style-type: none"> <li>1. Open cover of turbo-cooler hatch (fastenage right side between frames No. 15 and No. 18)</li> <li>2. Remove locking wire from plugs (two pieces) of turbo-cooler (Fig. 112)</li> <li>3. Screw off one oil filler plug (located at right upper side) of turbo-cooler bearings and fill SP-122-14 oil into hole</li> <li>4. Rotate manually turbo-cooler</li> <li>5. Screw in plug and lock it with wire IX-0.8</li> </ol> | <p>Easy running of rotor indicates that turbo-cooler is sound</p> | <p>If fan of turbo-cooler rotates with difficulty or fails to rotate at all, replace turbo-cooler</p> |                              |
| Accessories  | Tools   |   |                              |
|  | <p>Screwdriver<br/>Pliers<br/>Wrench, 14 X 16</p>                 |   |                              |

307

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Supplement to Inspection  
Guide No. 21

PROCESS CHART No. 60

In 2 sheets  
Sheet 2




FIG. 14. GENERAL VIEW OF T-1350-0001 (THE ARROWS SHOW THE CHARGING HOLE  
PLUG AND THE LOCKING WIRE)

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Document to Inspection<br>Guide No. 77  | PROCESS CHART No. 61   | Is a sheet<br>Sheet 1  |
|---|--|--|
| NAME OF THE STUDIES   | REMOVAL AND INSPECTION OF AIR STRAINER   |  |
| Procedure   | Technical requirements   | Fault correction   |
| 1. Block nose of strainer pipe<br>(strainer is installed in<br>bridge well for right-side wheel of<br>air landing gear strut)<br>2. Holding strainer body turn off<br>nuts, release strainer attachment<br>and remove the strainer. Plug<br>connected pipes or tie them with PVC<br>tape<br>3. Disassemble strainer<br>4. Tear the filtering element of<br>rubber (washers) in clean gasoline<br>or flow with compressed air<br>5. Wash all metal parts of strainer<br>in gasoline and blow them with compressed<br>air<br>6. Inspect parts of strainer<br>7. Assemble and reinstall filter | Remove corrosion of parts<br><br>When mounting strainer see that<br>arrows are directed along air-flow | Removal of corrosion should be<br>made by cleaning parts with grinding<br>cloth No. 180-220<br>Replace all damaged rubber gaskets<br>Restore stripped thread on pipe<br>unions and strainer body. Replace<br>individual parts of strainer or whole<br>strainer |
| Accessories   | Tools<br><br>Filers<br>Wrenches, 11 x 17; 9 x 11; 32 x 36  |  |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 7.  | PROCESS CHART No. 62   |                  | In 3 sheets<br>Sheet 1      |
|---|--|------------------|-----------------------------|
| AIR AND EM-ING SYSTEMS  | CHECKING AIR SYSTEM BOTTLES FOR SECTER ATTACHMENT AND BOTH SYSTEMS FOR TIGHTNESS   |                  | Man-hours<br>required - 1.0 |
| Procedure   | Technical requirements   | Fault correction |                             |
| <ol style="list-style-type: none"> <li>1. Make external inspection of air bottles; make sure that they have proper paint coating</li> <li>2. Inspect attachment fittings of air bottles</li> <li>3. Charge main and emergency air systems with air (Fig. 1A3)</li> <li>4. Check main and emergency air systems for tightness</li> </ol> | <p>When checking systems for tightness observe the following sequence:</p> <ol style="list-style-type: none"> <li>A. Check section of air system between main air bottles and consuming units                             <ul style="list-style-type: none"> <li>To this end:                                     <ol style="list-style-type: none"> <li>(a) charge main air system with air to obtain pressure of 110 - 130 kg/cm<sup>2</sup>;</li> <li>(b) close all valves;</li> <li>(c) wait for 2 hours;</li> <li>(d) air leakage from system should not exceed 5 kg/cm<sup>2</sup>. Checking should be made through the use of pressure gauge 2M-150 of main air system</li> </ol> </li> <li>B. Check landing gear emergency air system                                     <ul style="list-style-type: none"> <li>To this end:   <ol style="list-style-type: none"> <li>(a) charge system (landing gear emergency air bottles) to a pressure of 110-130 kg/cm<sup>2</sup>;</li> <li>(b) close valves for emergency discharging and charging of air system;</li> </ol> </li> </ul> </li> </ul></li></ol> |                  |                             |

310

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Present to Inspection  
Order No. 21

PROCESS CHART No. 62

In 3 sheets  
Sheet 2




FIG. 10. AIR SYSTEM CHARGING CORRECTION MAIN LINE CHARGING VALVE AND EMERGENCY LINE CHARGING VALVE  
 1 - charging connector, 2 - charging valve plug, 3 - plug lock of plug, 4 - main air system charging valve, 5 - emergency air system charging valve, 6 - L.C. emergency extension control valve.

311

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |                             |
|--|--|-----------------------------|
| Supplement to Inspection<br>Guide No. 21 | PROCESS CHART NO. 62   | In 3 sheets<br>Sheet 3      |
| AIR AND IN-FLIGHT SYSTEMS                | CHECKING AIR SYSTEM BOTTLES FOR SECURE ATTACHMENT AND BOTH SYSTEMS FOR TIGHTNESS   | Man-hours<br>required - 1.0 |
| Procedure                                | Technical requirements   | Fault correction            |
|  | (c) air pressure drop in section between emergency air bottles and valves is not allowed in the course of two hours. This check should be performed with pressure gauge 28-150 of emergency air system |                             |
| Accessories                              | Tools  |                             |
| Ground air bottle                        | French<br>Screwdriver<br>Pliers  |                             |

312

SECRET/NO FOREIGN DISSEM



Poor Original





SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |                              |
|--|--|---|------------------------------|
| Supplement to Inspection<br>Guide No. 21               | PROCESS CHART, No. 63  |   | In 2 sheets<br>Sheet 2       |
| AIR AND IN-FLIGHT SYSTEMS                              | CHECKING DE-ICE SYSTEM FOR STRIPPED ALCOHOL THROUGH<br>RETFOLD                       |   | Man-hours<br>required - 0.25 |
| Procedure  | Technical requirements   | Fault correction  |                              |
| 6. Close tightly filler neck cap,<br>lock it and seal. |  |  |                              |
| Accessories  |  | Tools   |                              |
| Wire, 0.5 mm   |  | Pliers  |                              |

31a

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplements to Inspection<br>Guide No. 22  | PROCESS CHART No. 62   | In 3 sheets<br>Sheet 1   |
|--|--|--|
| POWER PLANT  | REMOVAL, INSPECTION AND WASHING OF OIL UNIT FILTER   | Man-hours<br>required - 1.00   |
| Procedure  | Technical requirements   | Fault correction   |
| <ol style="list-style-type: none"> <li>1. Lift up access panel at fuselage starboard side marked "ENGINE AND VENTILATION SYSTEM ACCESSORIES" (ALYKINAM KENTARIN 8 PREPOCHETIM)</li> <li>2. Remove strap from breather connections; remove connections (Fig. 145)</li> <li>3. Make external inspection of oil filter cover and housing for defects</li> <li>4. Unlock and turn off nut with handle bar by turning it counter-clockwise</li> <li>5. Remove filter</li> <li>6. Immediately stop filter with rubber plug C31-131</li> <li>7. Fit plug EK37-517 into oil unit housing instead of oil filter cover</li> <li>8. Remove rubber sealing ring from cover groove and inspect it for condition</li> <li>9. Inspect filtering unit</li> </ol> | <p>Strap and connections should be free of cracks and deformation</p> <p>Oil filter cover handle bar should be locked with 1 mm dia. safety wire. Surfaces of oil filter cover and oil unit housing should be clean</p> <p>Handle bar is not to bind, when rotated</p> <p>Rubber sealing ring should be elastic and free of bites, contraction, swelling or deformation</p> <p>Filtering unit should be clean; no metal chips or any other foreign matter is allowed on gasket discs</p> | <p>Replace connections, if cracks or deformation is detected</p> <p>Weld up cracks developed on strap</p> <p>Wipe contaminated surfaces with waste cloth soaked in gasoline</p> <p>Replace rubber sealing ring, if defective (part 0253001)</p> <p>In case metal chips are detected on filtering unit consult representative of manufacturing plant or repair organization as to further use of filter</p> |

315

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS, CRANE No. 6a   |  | In 3 sheets<br>Sheet 2       |
|---|---|--|------------------------------|
| POWER PLANT   | REMOVAL, INSPECTION AND WASHING OF OIL UNIT FILTER  |  | Man-hours<br>Required - 1.00 |
| Procedure   | Technical requirements  | Fault correction   |                              |
| <p>9. Wash filtering unit surface in gasoline bath</p> <p>10. Dry filtering unit</p> <p>11. Inspect filtering unit</p> <p>12. Remove plugs from oil unit housing (2237-317) and from filter housing (231-231)</p> <p>13. Insert filter into oil unit housing after fitting rubber sealing ring into cover groove</p> <p>14. Screw up nut with handle bar by turning it clockwise. See that rubber sealing ring is installed properly</p> <p>15. Make external inspection of oil filter cover and housing</p> <p>16. Lock oil filter cover handle bar with 1 mm dia. safety wire</p> | <p>Damage to filtering unit gauge is not allowed</p> <p>Do not blow filtering unit with compressed air.</p> <p>When drying filtering unit, take care to see that no dust, dirt, or any other foreign matter gets on filtering unit surface</p> <p>Filtering unit must be clean</p> <p>Biting of rubber sealing ring or its projection from under filter cover flange is not allowed</p> <p>Surfaces of oil filter cover and housing should be clean</p> <p>Wire should prevent oil filter cover handle bar from working loose</p> | <p>Replace filtering unit, if any damage is detected on gauge</p> <p>If ring biting or projection is detected, remove cover and inspect rubber sealing ring for condition</p> <p>Replace ring, if necessary</p> <p>Clean contaminated surfaces with clean waste cloth soaked in gasoline</p> |                              |


316

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |                                      |
|--|---|--------------------------------------|
| Reference to Inspection Guide No. 21   | PROCESS SHEET No. 64  | In 3 sheets Sheet 3                  |
| POWER PLANT  | REPAIR, INSPECTION AND WASHING OF OIL UNIT FILTER               | Man-hours Required - 1.00            |
| Procedure  | Technical requirements  | Fault correction                     |
| 17. Install connections and tighten them.<br>18. Check oil unit for tightness, run starting engine.<br>19. Close access panel "ENGINE" IN HYDRAULIC SYSTEM ACCESSORIES and tighten with screws.              | No leakage is allowed   | Replace seal, if leakage is detected |
|  <p>FIG. 165 ENGINE WEATHER CONNECTIONS<br/>1 - weather connection mounting bracket, 2 - weather connection</p>          |   |                                      |
| Accessories  | Tools   |                                      |
| Container for small-size parts<br>Fuel for gasoline<br>Drain<br>Filter C31-139<br>Clean gasoline E-70<br>Binding wire, dia. 1-3/64 State Standard TOUT 1066-50<br>Clean waste cloth<br>Fig. 165-317; C31-131 | Screwdriver<br>Wrenches BE7-07-SK11, 2 pieces<br>Filers C31-226 |                                      |

317

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 65   | In 2 sheets<br>Sheet 1  |
|---|--|---|
| POWER PLANT   | INSPECTION OF ENGINE CONTROLS  | Man-hours<br>required - 0.30  |
| Procedure   | Technical requirements   | Fault correction  |
| <p>1. Lift up access panel <b>CONTROLS, ENGINE ACCESSORIES (VUPAEHSEK, ATPEHAK AKCTATEM)</b> and remove access panel <b>HYDRAULIC UNITS (IMPOHATETAM)</b></p> <p>2. Wash links and inspect them for condition, including attachment points</p> <p>3. Shift engine control lever throughout entire range from <b>CUT-OFF (CTM)</b> stop to <b>FULL AUGMENTED (HGEEM AKCAK)</b> stop, to see that control lever moves smoothly and that there is no play, where links and engine control bell cranks are connected</p> <p>4. Coat link and bell crank joints with <b>GREASE-221</b> lubricant</p> | <p>Use gasoline for washing. Links and their attachment points should be free of chafing, cracks, deformation, contacts with other components, or other defects.</p> <p>Ruts of coupling bolts, pump levers, and <b>HTI</b> control panel should be properly locked</p> <p>Engine should be easily controlled. No binding is allowed throughout engine control lever travel</p> <p>Apply lubricant <b>GREASE-221</b> in thin layer</p> | <p>Eliminate defects. If locking devices are damaged, replace them</p> <p>Detect cause of binding or excessive play and correct fault</p> |

318

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |                        |                               |                              |
|--|------------------------|-------------------------------|------------------------------|
| Supplement to Inspection<br>Guide No. 71   |                        | PROCESS CHART No. 65          | In 2 sheets<br>Sheet 2       |
| POWER PLANT  |                        | INSPECTION OF ENGINE CONTROLS | Man-hours<br>required - 0.30 |
| Procedure  | Technical requirements | Fault correction              |                              |
| Accessories  |                        | Tools                         |                              |
| Bath for gasoline<br>Brush for washing<br>Clean gasoline E-70; MILITARY-221 lubricant<br>Binding wire, C.B.-552, State Standard<br>TAC 1040-50<br>Center pins 194MS1-1, 5x15<br>Clean waste cloth<br>Inspection lamp<br>Mirror CM-780A-55<br>Lens 1a |                        | Screwdriver<br>Pliers C31-226 |                              |

319

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |   |
|---|--|---|
| Supplement to Inspection<br>Guide No. 71  | PROCESS CP 1 BT No. 66   | In 4 sheets<br>Sheet 1  |
| POWER PLANT   | CHECKING ENGINE CONTROL LEVER FOR POSITIVE LOCKING AT ALL STOPS;<br>OPENING CONTROL LEVER POSITIONS FOR POSITIVE AGREEMENT WITH<br>POSITIONS OF EP-210 REGULATING FUEL PUMP LEVERS AND EFT-10<br>CONTROL PANEL LEVERS  | Man-hours<br>required - 0.25  |
| Procedure   | Technical requirements   | Fault correction  |
| <p>1. Check to see that positions of engine control lever in cockpit at main ratings (Fig. 1A6) agree with positions of EP-210 regulating fuel pump and EFT-10 control panel levers on engines (Fig. 1A7), for which purpose:</p> <p>(a) set engine control lever at CUT-OFF (C/O) stop;</p> <p>(b) set engine control lever at IDLING RATING (KALAZ 113) stop;</p> | <p>Engine control lever should be locked in this position. Clearance between CUT-OFF stop and engine control lever should amount to 1.5-2 mm. Leg of regulating fuel pump should tightly fit to pump CUT-OFF adjusting screw stop.</p> <p>Zero notch on EFT-10 control panel dial should line up with notch on control panel body.</p> <p>Notch on leg of EP-210 regulating fuel pump should be between notches marking IDLING RATING sector on pump dial (first and third notches as from CUT-OFF stop).</p> <p>Figures 11-15° on EFT-10 control panel dial should coincide with notch on panel body.</p> | <p>Adjust engine controls</p> <p>If necessary, adjust positions of locking elements and stops</p> |


320

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |  |                              |
|---|---|--|------------------------------|
| Subject to Inspection<br>Guide No. 21   | PROCESS CHART No. 66  |  | In 4 sheets<br>Sheet 2       |
| POWER PLANT   | CHECKING ENGINE CONTROL LEVER FOR PROPER POSITION AT ALL OPERATING POSITIONS OF EP-218 REGULATING FUEL PUMP LEVER AND EFT-18 CONTROL PANEL DIALS  |  | Man-hours<br>required - 0.25 |
| Procedure   | Technical requirements  | Fault correction   |                              |
| (1) set engine control lever in FULL (EMERGENCY) rating position;<br><br>(2) set engine control lever at HALF (NORMAL) stop;<br><br>(3) set engine control lever in HALF (NORMAL) stop position;<br><br>(4) set engine control lever at FULL (EMERGENCY) stop | Engine control lever should be locked in this position. Dial of EP-218 regulating fuel pump should set at fifth notch.<br>Notch provided on lug of EP-218 regulating fuel pump should set behind sixth notch on pump dial.<br>Figures 67-68 on EFT-18 control panel dial should line up with notch provided on panel body.<br>When pulled back, engine control lever should come up against EMERGENCY STOP, if retainer is released.<br>Notch on lug of EP-218 regulating fuel pump should set behind seventh notch on pump dial.<br>Figures 72-73 on EFT-18 control panel dial should line up with notch provided on panel body.<br>Engine control lever should be locked in this position. Clearance between FULL EMERGENCY STOP and engine control lever should be equal to 1.5-2 mm |  <p>FIG. 14. POSITIONS OF ENGINE CONTROL LEVER</p> |                              |


SECRET/NO FOREIGN DISSEM

Peer Original



SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


|  |   |  |  |                              |
|--|---|--|--|------------------------------|
| Supplement to Inspection<br>Guide No. 21     |   | PROCEDURE SHEET 30.76  |  | In. + sheets<br>Sheet 4      |
| POWER PLANT                                  |   | CHECKING ENGINE CONTROL LEVER FOR PROPER LOCKING AT ALL STOPS;<br>CHECKING CONTROL LEVER POSITIONING FOR PROPER AGREEMENT WITH<br>POSITIONS OF HP-218 REGULATING FUEL PUMP LEVERS AND EFT-16<br>CONTROL PANEL LEVERS |  | End-hours<br>required - 0.25 |
| Procedure                                    | Technical requirements  | Fault correction   |  |                              |
|  | <p>Notch on HP-218 regulating fuel pump lug should set behind seventh notch on pump dial. Clearance between HP-218 pump lug and AUGMENTED (EFT-16) fueling screw stop should be at least 2 mm. EFT-16 control panel lever should tightly fit to FULL AGREEMENT stop, whereas figure 112 on EFT-16 control panel dial must line up with notch provided on panel body</p> |  |  |                              |
| Accessories                                  |   | Tools  |  |                              |
| <p>Inspection lamp<br/>Mirror CA-7604-55</p> |   |  |  |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


|  |  |   |  |                           |
|--|--|---|--|---------------------------|
| Supplement to Inspection<br>guide No. 21   |  | CHECKS CHART No. 67   |  | In 3 sheets<br>Sheet 1    |
| POWER FLAP   |  | CHECKING OPERATION OF JET ENGINE FLAPS CONTROL SYSTEM   |  | Man-hours<br>required = 2 |
| Procedure  |  | Technical requirements  | Fault correction   |                           |
| <p>1. Connect ground power supply source</p> <p>2. Turn on following switches and circuit breakers: MASTER SWITCH (MAGNETIC INTERRUPTER) AFTERBURNER (MAGNETIC) PROTECTIVE (MAGNETIC) (this switch should be set in V position)</p> <p>3. Switch off afterburner blocking system 590 by turning screw H on afterburner control unit 110-151 in BLOCKING OFF (BLOKIROVKA) POSITION position (Fig. 119)</p> <p>4. Connect ground hydraulic unit (at fuselage starboard side)</p> <p>5. Move engine control lever from EASY to FULL AUGMENTED step and check time within which flaps shift from EASY to FULL AUGMENTED position</p> |  | <p>Voltage in aircraft mains should not be below 27.0 V</p> <p>Pressure in hydraulic system should be within 210-10 kg/cm<sup>2</sup></p> <p>Note. During hydraulic system operation, take care to see that there is no leakage in hydraulic cylinders and in hydraulic system piping joints.</p> <p>It should take 2.5 sec. to shift flaps from EASY to FULL AUGMENTED position. Move engine control lever at a rate of 1.5 to 2 sec. Check flaps shifting by observing control ring</p> |  <p>FIG. 119. AFTERBURNER CONTROL UNIT, TYPE KAS-112 (Arrow shows screw "H" which engages one of 590 blocking system when the air is not bled)</p> <p>If flaps shifting time fails to agree with specified value, perform adjustment of synchronizing valves by manipulating respective flow restrictors (Fig. 119)</p> |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |  |
|--|---|--|
| Supplement to Inspection Guide No. 21  | PROCESS CHECK No. 67  | In 3 sheets<br>Sheet 2   |
| POWER PLANT  | OPERATING OPERATION OF JET-ENGINE FLAPS CONTROL SYSTEM  | Man-hours required - 2   |
| <p><b>Procedure</b></p> <p>6. Move engine control lever from FULL AUGMENTED stop to MAXIMUM stop and check time required for flaps to shift between respective positions</p>  <p><b>FIG. 149. SYNCHRONIZING VALVES OF JET-ENGINE CONTROL HYDRAULIC CYLINDERS</b><br/>                 I - actuating cylinder II - hydraulic main<br/>                 III - synchronizing valve<br/>                 IV - actuating valve<br/>                 V and Z - flow restrictors for flap setting<br/>                 W - control valve<br/>                 X and Y - synchronizing rod control<br/>                 U - synchronizing rod control<br/>                 T - synchronizing rod control</p> <p>7. Set screw Z on E10-112 after-<br/>control unit in LOCKING OR</p> | <p><b>Technical requirements</b></p> <p>Flaps should shift from MAXIMUM to FULL AUGMENTED position within 5.5 ± 1.5 sec.</p> <p>To determine flaps shifting time, operate shutters at least three times</p> <p>Check all three actuating rods for synchronous travel. Check is carried out as follows: with actuating rods moving to MAXIMUM position, measure distance between chambs of two other rods and hydraulic cylinder stops, as soon as one of the rods comes up against stop. Distance measured should not exceed 7 mm</p> | <p><b>Fault correction</b></p> <p>Increase in capacity of synchronizing valve flow restrictor J will cause reduction of time required for rods to shift to MAXIMUM position, and vice versa.</p> <p>Increase in capacity of synchronizing valve flow restrictor II will reduce time required for rods to shift to AUGMENTED position, and vice versa.</p> <p>Having finally adjusted rod shifting time, select auxiliary valve flow restrictor III in accordance with graph (Fig. 150).</p> <p>If necessary, adjust actuating rod travel by manipulating screws of synchronizing valves springs, after loosening coupling nuts. Turning screw A in will increase rate of rod movement for opening flaps. Turning screw B in will increase rate of rod travel for closing flaps</p> |

325

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |  |  |
|--|--|--|--|
| Supplement to Inspection Guide No. 71  |  | PS-235 CH-57 No. 67  | In 3 sheets (Sheet 3)  |
| WIRE PLAN  |  | CHECKING OPERATION OF JET FUELLE FLAPS CONTROL SYSTEM  |  |
| <p>Procedure</p> <p>(ENGINE STOPPED) position</p> <p>8. Turn off following switches and circuit breakers: MASTER SWITCH, AFTER-BURNER; set switch PROCESSING in initial position</p> <p>9. Disconnect ground power supply source from aircraft mains</p> <p>10. Disconnect ground hydraulic unit</p> <p>11. Pipe areas stained with AFT-10 oil</p> |  | <p>Technical requirements</p> <p>Oil stains should be removed with cloth soaked in gasoline E-70</p> | <p>Fault correction</p> <p>The graph plots flow capacity in GPM (Gallons Per Minute) on the y-axis (ranging from 400 to 1000) against flow restrictor size in GPM (Gallons Per Minute) on the x-axis (ranging from 80 to 170). Several curves are shown, labeled with valve sizes: 1/2" NPT, 3/4" NPT, 1" NPT, 1 1/4" NPT, 1 1/2" NPT, 2" NPT, and 2 1/2" NPT. The curves show that flow capacity increases with both valve size and flow restrictor size.</p> |
| <p>Accessories</p> <p>Ground power supply source<br/>Tray<br/>Gasoline E-70<br/>Clean cloth<br/>Flow restrictors<br/>Ground hydraulic unit</p>   |  | <p>Tools</p> <p>Screwdriver</p>  |  |

326

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |   |                            |
|--|---|---|----------------------------|
| Supplement to Inspection<br>Guide No. 72   | PROCESS SHEET No. 48  |   | In 32 sheets<br>Sheet 1    |
| POWER PLANT  | INSPECTION OF THE NOZZLE AND ITS TELESCOPIC POINT FOR PROPER<br>ALIGNMENT; RESULTS OF THE FEELER-GAUGE CHECKS<br>AGAINST EXCESSIVE ICG DATA |   | Maximum<br>Required - 2.00 |
| Procedure  | Technical requirements  | Fault correction  |                            |
| 1. Prior to disjoining fuselage,<br>measure clearance II between adjustable<br>jet nozzle and afterburner diffuser<br>(Fig. 151) | Local increase in clearance II<br>is allowed to 4.5 mm (on arc not<br>exceeding 300 mm)   | Use feeler gauge to measure<br>clearance B in telescopic point. Where<br>clearance B is maximum, make notch with<br>pencil on fuselage diffuser. Remove<br>telescopic ring and measure height of<br>diffuser collar with slide gauge<br>(dimension F). Difference between dimen-<br>sions B and F must not be less than 1 mm.<br>If difference is less than 1 mm,<br>find out which of parts (diffuser or<br>jet nozzle) is deformed.<br>For this, turn jet nozzle through<br>180° and measure clearance B, where dif-<br>ference is less than 1 mm (where notch<br>is made on afterburner diffuser) and<br>in diametrically opposite point.<br>If maximum clearance B also turns<br>through 180°, adjustable jet nozzle is<br>deformed. If point where clearance B<br>is maximum remains unchanged after turn-<br>ing of jet nozzle, then diffuser<br>flange is considered deformed. |                            |




FIG. 151. SETTING TELESCOPIC  
RAG  
1 - afterburner diffuser, 2 - variable  
jet nozzle, 3 - clearance I  
4 - point

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


|   |   |   |
|---|---|---|
| Supplement to Inspection Guide No. 71   | PROCESS CHART No. 68  | In 12 sheets Sheet 2  |
| POWER PLANT   | INSTRUCTION OF JET NOZZLE AND ITS TELESCOPIC JOINT FOR PROPER INSTALLATION; CHECKING OF JET NOZZLE FLAPS CHARACTER AGAINST SERVICE LOG DATA | Man-hours required - 2.00   |
| Procedure   | Technical requirements  | Fault correction  |
| <p>FIG. 152. MEASURING PROJECTION OF BOLTS<br/>         1 - afterburner flange; 2 - nozzle nozzle; 3 - telescopic ring; 4 - bolt<br/>         nutlock; 5 - bolt O20308; 6 - washer O20310</p> |   | <p>Straighten deformed flange with the aid of wooden tool (wall and dolly)</p> <p><b>Notes:</b> 1. Ricks on flanges are not allowed<br/>         2. In case difference between dimensions E and B exceeds 1 mm, see that maximum clearance H does not increase (as compared to original clearance), when making subsequent inspections. If clearance is found to be increased, perform operations, detailed above.</p> <p>Prior to installing telescopic ring, check bolts O203080 for projection beyond radius R (Fig. 152). If projection value exceeds 0.3 mm, fit third washer O241130 under bolt, or file bolt face (at thread end) so that projection value does not exceed 0.3 mm.</p> <p>When installing telescopic joint, proceed as follows:<br/>         1. Fit adjustable jet nozzle flange onto rear flange of afterburner diffuser, so that clearance A between flanges is within 2 to 10 mm (Fig. 151). Do not use any levers, likely to cause</p> |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |
|--|--|---|
| Supplement to Inspection Guide No. 21  | PROCEDURE SHEET No. 18   | In 12 sheets<br>Sheet 3   |
| POWER PLANT  | INSPECTION OF THE NOZZLE AND ITS TELESCOPIC JOINT FOR PROPER INSTALLATION; CHECKING OF THE NOZZLE FLAPS DIAPHRAGM ASSEMBLY SERVICE LOG DATA  |   |
| Procedure  | Technical requirements   | Fault correction  |
| <p>2. Bring counting trolley under adjustable jet nozzle and secure nozzle to trolley</p> <p>3. Make external inspection of telescopic ring to see that it is installed properly</p> |  <p>FIG. 153 MAXIMUM CLEARANCE BETWEEN VAPORIZER NOZZLE AND DIFFUSER</p> <p>Arrow (front) groove of telescopic ring should accommodate diffuser rear flange, whereas wide</p> | <p>deformation of above components. Perform measurements by feeler gauge in four points along circumference. Difference in clearances must not exceed 1 mm</p> <p>2. Fit telescopic ring in place</p> <p>3. See that telescopic ring is installed properly by inspecting it thoroughly on circumference</p> <p>4. Fit in bolts securing telescopic ring joint; install gasket without shield and tighten up nuts. Check clearance (see Fig. 151) between ring face and gasket, which should amount to 0.8 mm (at each side). If clearance exceeds 0.8 mm, replace telescopic ring by new one</p> <p>5. Remove telescopic ring coupling bolts and reinstall them along with shield; tighten up bolts and lock them</p> |

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART NO. 68  | In 12 sheets Sheet 4  |
|---|---|---|
| POWER PLANT   | INSPECTION OF JET NOZZLE AND ITS TELESCOPIC JOINT FOR PROPER INSTALLATION; CHECKING OF JET NOZZLE FLAPS TRAVEL AGAINST SERVICE LOG DATA   | Man-hours required - 2.00   |
| Procedure   | Technical requirements  | Fault correction  |
| <p>A. Check free travel of adjustable jet nozzle in telescopic joint. Carry out check on jointed aircraft.</p> <p>5. After jointing aircraft measure size F inside afterburner, in eight points (Fig. 153), with tail pipe in extreme rear position.</p> <p>6. Refer to Service Log to set proper jet nozzle flap diameter values at the following ratings:<br/>                     (a) full supported;<br/>                     (b) minimum supported;<br/>                     (c) maximum rating.</p> | <p>(rear) groove must receive adjustable jet nozzle flange.</p> <p>Free travel along clearance B (Fig. 153) should not be less than 6 mm.</p> <p>Difference in size F measured in two diametrically opposite points should not exceed 5 mm; in horizontal plane size F in 2nd point should exceed that in 7th point by 7 to 9 mm.</p> <p>Maximum size F should amount to about 22 mm.</p> | <p>If sizes F in horizontal plane differ by more than 5 mm or less than 2 mm, adjust afterburner position with the aid of rollers. After adjustment, determine sizes A, B, and clearances between engine and aircraft inner skin in tail cone jointing plane, which should be within values indicated in Fig. 154; measure size F once again.</p> <p>If size F exceeds 22 mm, check telescopic joint clamp for proper installation.</p> |

330

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |  |                              |
|---|---|--|------------------------------|
| Displacement to Inspection<br>Guide No. 21  | PROCEDURE No. 68  |  | Ag 12 sheets<br>Sheet 5      |
| POWER FLAPS   | INSPECTION OF JET NOZZLE AND ITS TELESCOPIC JOINT FOR<br>PROPER INSTALLATION; CHECKING OF JET NOZZLE FLAPS<br>DIAMETER AGAINST SERVICE LOG DATA |  | Man-hours<br>Required - 2.00 |
| Procedure   | Technical requirements  | Fault correction   |                              |
| 7. Use device No. 6360/aa (contained in set for 20 aircraft), to determine actual diameter value of jet nozzle flaps and compare obtained results with Service Log data | Obtained jet nozzle diameter value must not differ from that indicated in Service Log by more than 3 mm   | If actual diameter value differs from that indicated in Service Log by more than 3 mm, adjust jet nozzle flaps diameter to specified value; permissible error is not to exceed 0.2 mm. Adjustment of jet nozzle diameter should be started from FULL AUGMENTED rating since changing of flaps diameter at FULL AUGMENTED rating will entail changing of flaps diameter at MINIMUM AUGMENTED rating<br><br><u>Adjustment of Jet Nozzle Flaps Diameter at FULL AUGMENTED Rating</u><br>1. Set engine control lever at FULL AUGMENTED stop; turn on following switches and circuit breakers: MASTER SWITCH, AIRBORNE; set switch PROCSIDE in X position. Switch off blocking system 800 by turning screw B on HA-121 afterburner control unit in BLOCKING OFF position<br>2. Relieve pressure in hydraulic system |                              |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |  |
|--|---|--|
| Supplement to Inspection Guide No. 22  | PROCESS CHART No. 68  | In 12 sheets<br>Sheet 6  |
| POWER PLANT  | INSPECTION OF JET NOZZLE AND ITS TELESCOPIC JOINT FOR PROPER INSTALLATION; CHECKING OF JET NOZZLE FLAPS | Man-hours required - 2.00  |
| Procedure  | Technical requirements  | Fault correction   |
| <p>FIG. 13. MEASUREMENTS OF CLEARANCES BETWEEN AFTERBURNER AND FLAP ASSEMBLY</p> <p>1 - flange screw control; 2 - setting of hydraulic cylinder; 3 - screw control of afterburner control; 4 - afterburner panel; 5 - rotor body; 6 - flange attachment ring; 7 - bolt with locking cap.</p> | (Empty)   | 3. Slacken hydraulic cylinder shank locking bolts<br>4. Turn hydraulic cylinder rods to obtain required nozzle flap diameter. Turning of hydraulic cylinder rod clockwise (locking forward) will increase flap diameter, and vice versa. One turn of rod will change flap diameter by approximately 2 to 3 mm. To avoid cocking of ring, turning of rods of all three hydraulic cylinders should be performed to the same angle. Adjustment completed, tighten up and lock bolts; turn off switches and circuit breakers<br>5. Check hydraulic cylinder rods for full extension at the beginning of FULL AUGMENTED sector, for which purpose set engine control lever in position at which figures 107-109 on HPT-14 control panel dial line up with notch provided on control panel body. Turn screw E on E14-13R afterburner control unit in BLOCKING OFF position and turn on following switches and circuit breakers: MASTER SWITCH, AFTERBURNER; set switch |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|                                       |                        |   |                           |
|---------------------------------------|------------------------|---|---------------------------|
| Supplement to Inspection Guide No. 71 |                        | PROCESS No. 68  | In 12 sheets<br>Sheet 7   |
| POWER PLANT                           |                        | INSPECTION OF JET NOZZLE AND ITS TELESCOPIC JOINT FOR PROPER INSTALLATION; CHECKING OF JET NOZZLE FLAPS CHARACTER AGENT SERVICE LOG DATA  | Man-hours required - 2.00 |
| Procedure                             | Technical requirements | Fault correction  |                           |
|                                       |                        | <p>POSITIONING in K position. With engine control lever set in this position, hydraulic cylinder rods should come up against mechanical stop</p> <p>(a) In case actuating rods come up against mechanical stop before engine control lever is set in this position, turn screw 19 on rheostat P-1 clockwise to adjust actuating rods so that they come up against mechanical stop, when engine control lever is set in above position</p> <p>(b) Should actuating rods stop when engine control lever is being set in above position, turn on switch EMERGENCY REARREST OF TWO-POSITION JET NOZZLE (ARRAFIROS REARREST 2-DOOR-IMPEDITO COLINA). Extension of actuating rods should not change after above switch is turned on.</p> <p>If extension of actuating rods do change after switch has been manipulated (rods were not set against mechanical stop), turn screw 18 on rheostat P-1 counter-clockwise to adjust full extension of</p> |                           |


333

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |                        |  |                           |
|---|------------------------|--|---------------------------|
| Supplement to Inspection Guide No. 7  |                        | PROCESS CHART, No. 68  | In 12 sheets<br>Sheet 8   |
| POWER FLAP  |                        | INSPECTION OF JET NOZZLE AND ITS TELESCOPIC JOINT FOR PROPER INSTALLATION; CHECKING OF JET NOZZLE FLAPS AGAINST SERVICE LOG DATA   | Man-hours required - 2.00 |
| Procedure   | Technical requirements | Fault correction   |                           |
|   |                        | <p>actuating rods with engine control lever set in specified position. Turn off switch EMERGENCY ENGAGEMENT OF TWO-POSITION JET NOZZLE.</p> <p>After checking and adjusting full extension of actuating rods, turn screws 10 counter-clockwise through 1 to 4° and check to see that actuating rods remain stationary while engine control lever is moved within FULL ADJUSTED sector</p> <p><u>Adjustment of Flaps Diameter at MINIMUM ADJUSTED Rating</u></p> <p>1. Set switch BY in K position, turn screw H on EQ-154 Afterburner control unit in BLOCKING OFF position, and turn on following switches and circuit breakers: MASTER SWITCH, AFTERBURNER. Set engine control lever at MINIMUM ADJUSTED stop</p> <p>2. Adjust flaps diameter to required value by turning adjustment screw of transmitter AP-3A (Fig. 155). Turning of screw clockwise will cause increase in jet nozzle flaps diameter</p> |                           |
| <p>FIG. 155 ENGINE ACCESSORY IS</p> <p>1 - Fuel pump (P-216); 2 - power (EPT-12). ARROW SHOWS ADJUSTING SCREW OF INJA TRANSMITTER</p> |                        |  |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |   |                              |
|--|---|---|------------------------------|
| Supplement to Inspection<br>Guide No. 21 | PROCESS CHART No. 66  |   | In 12 sheets<br>Sheet 9      |
| POWER PLANT                              | INSPECTION OF JET ENGINE AND ITS TRANSMISSION JOINTS FOR<br>EXCESS WEAR/LEAKAGE; CHECKING OF JET ENGINE FLAPS<br>SHUTTER ADJUSTMENT SYSTEM AND DATA |   | Man-hours<br>required - 2.00 |
| Procedure                                | Technical requirements  | Fault correction  |                              |
|  |   | <p>and vice versa. When adjusting flap diameter, see that axial displacement of adjustment screw does not exceed 2 mm to either side, as from initial dimension H (screw projection), indicated in Certificate of transmitter TP-3A.</p> <p>Should it be impossible to adjust flap diameter by displacing screw within specified range, adjustment of flap diameter should be performed in the following manner:</p> <p>(a) set adjustment screw of transmitter TP-3A in initial position H;<br/>                 (b) turn screw M0 on rheostat P-1 to obtain required flap diameter</p> <p><b>WARNING:</b> After adjusting shutter diameter with the aid of screw M0, be sure to check hydraulic cylinder rods for full extension, as detailed in Point 5 (see page 132) with subsequent checking and readjustment of flap diameter at MINIMUM</p> |                              |

135

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |  |                              |
|--|---|--|------------------------------|
| Supplement to Inspection<br>Guide No. 21 | PROCESS CHART No. 68  |  | In 12 sheets<br>Sheet 10     |
| POWER PLANT                              | INSPECTION OF JET NOZZLE AND ITS TELESCOPIC JOINT FOR<br>PROPER INSTALLATION; CHECKING OF JET NOZZLE FLAPS<br>DIAMETER AGAINST SERVICE LOG DATA |  | Man-hours<br>required - 2.00 |
| Procedure                                | Technical requirements  | Fault correction   |                              |
|  |   | <p>                     ADJUSTED rating with the aid<br/>of screw incorporated in<br/>transmitter XP-1A.                 </p> <p> <u>Adjustment of Flaps<br/>Diameter at MAXIMUM Rating</u> </p> <ol style="list-style-type: none"> <li>1. Set engine control lever at<br/>MAXIMUM stop. Turn on MASTER SWITCH</li> <li>2. Manipulate cylinder nuts to<br/>obtain required diameter value.</li> </ol> <p>                     Turning of nut clockwise will<br/>reduce flaps diameter, and vice versa.<br/>One revolution of nut will change flaps<br/>diameter by 2 to 3 mm. To avoid cocking<br/>of ring, turn nuts of all three<br/>cylinders through the same angle.                 </p> <p>                     Adjustment completed, disconnect<br/>ground hydraulic unit and power supply<br/>source from aircraft main, set switches<br/>MASTER SWITCH, AFTERBURNER, PROCESSING<br/>in initial position, set screw N on<br/>afterburner control unit E10-15A<br/>in BLOCKING OF position, and take off<br/>device for measuring flaps diameter<br/>(No. 6350/44)                 </p> |                              |

236

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |  |                              |
|--|--|--|------------------------------|
| Appendix to Inspection<br>guide No. 21 | PROCESS CHART No. 56   |  | In 12 sheets<br>Sheet 11     |
| POWER FLAPS                            | INSPECTION OF JET ENGINE AND ITS TELESCOPIC JOINT FOR<br>PROPER INSTALLATION CHECKS OF JET ENGINE FLAPS<br>DAMAGE AGAINST SERVICE LOG DATA |  | Man-hours<br>required - 2.00 |
| Procedure                              | Technical requirements   | Fault correction   |                              |
|  |  | <p>In the case with engines furnished with non-adjustable jet nozzles, adjust flaps diameter as follows:</p> <p>(a) at <b>ATMOSPHERIC</b> rating - in accordance with Points 2, 3, 4 of Section I;</p> <p>(b) at <b>MAXIMUM</b> rating - in accordance with Section III</p> <p>Having completed adjustment of flaps diameter, fit in pressure gauges for checking <math>P_2</math> and <math>P_4</math>; run engine at <b>MAXIMUM</b> rating and check instrument indications; pressure <math>P_2</math> should not exceed pressure <math>P_4</math> by more than 0.02 kg/cm<sup>2</sup>, whereas exhaust gas temperature must not exceed temperature value obtained at the beginning of engine operation by more than 20°C. Should pressure <math>P_4</math> be in excess of specified value, readjust flaps diameter</p> |                              |

337

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |                        |  |                           |
|---|------------------------|--|---------------------------|
| Supplement to Inspection of JTF No. 71  |                        | PROCESS CHART No. 68   | In 12 sheets<br>Sheet 12  |
| POWER FLAP  |                        | INSPECTION OF JTF NOZZLE AND ITS TELESCOPIC JOINT FOR PROPER INSTALLATION; CHECKING OF JTF NOZZLE FLAPS DAMAGED AGAINST SERVICE LOG DATA | Man-hours required - 2.00 |
| Procedure   | Technical Requirements | Fault correction   |                           |
| Accessories   |                        | Tools  |                           |
| Device for measuring flaps diameter (No. 6350/44, contained in set for 20 aircraft)<br>Washer D243130<br>Pressure gauge with division value of 0.02 kg/cm <sup>2</sup><br>Compressed air cylinder<br>Hydraulic unit |                        | Feeler gauge set H4-19/1<br>Bell<br>Dolly<br>File<br>Slide gauge   |                           |

338

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |   |  |                              |
|--|---|--|------------------------------|
| Inspection<br>Guide No. 21   | PROCESS CHART No. 69  |  | In 2 sheets<br>Sheet 1       |
| POWER PLANT  | INSPECTION OF ENGINE ATTACHMENT FITS  |  | Man-hours<br>required - 0.25 |
| <p><b>Procedure</b></p> <p>1. Lift up access panels ENGINE ATTACHMENT (ENGINE MOUNTING, ENGINE MOUNTS AND HYDRAULIC UNITS, BOLT ACCESSORIES on fuselage starboard and port side)</p> <p>2. Inspect engine attachment brackets and bolt heads for condition through access port ENGINE ATTACHMENT</p> <p>3. Inspect engine-to-airframe attachment links for condition</p> <p>4. Lubricate link articulated joint (translating engine)</p> | <p><b>Technical requirements</b></p> <p>Attachment brackets and bolt heads must be free of cracks or any other defects</p> <p>No cracks, dents, or any other defects are allowed on links. Bolt nuts must be locked.</p> <p>Use wrench to check nuts for proper tightening</p> <p>Check marks applied with red paint to locking nut, tip, and link must be strictly aligned</p> | <p><b>Fault correction</b></p> <p>If cracks are detected on bracket or on bolt head, replace respective parts</p> <p>Replace link; when proceeding so, take care to see that length of newly installed link is equal to length of link replaced.</p> <p>Tighten link locking nuts and apply marks with red paint to link, locking nut, and link tip (opposite to each other)</p> |                              |

339

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |  |  |                              |
|---|--|--|--|------------------------------|
| Supplement to Inspection<br>Guide No. 21  |  | PROCESS CHART No. 69                         |  | In 2 sheets<br>Sheet 2       |
| FOUR FLAP   |  | INSPECTION OF ENGINE ATTACHMENT UNITS        |  | Man-hours<br>required - 0.25 |
| Procedure   |  | Technical requirements                       |  | Fault correction             |
|   |  |  |  |                              |
| Accessories   |  | Tools  |  |                              |
| Paint brush<br>Micro-cassol, red<br>Lubricant, MIL-201<br>Clean waste cloth<br>Inspection lamp<br>Mirror CS-7204-55<br>Lens, IA |  | Screwdriver (for cross slots)<br>Screwdriver |  |                              |

340

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM


| Equipment to Inspection Guide No. 21   | PROCESS CHART No. 70   |                  | In 17 Steps Sheet 1        |
|--|--|------------------|----------------------------|
| POWER PLANT  | REPAIRMENT OF ENGINE   |                  | Man-hours Required - 48.00 |
| Procedure  | Technical requirements   | Fault correction |                            |
| <p><b>A. Engine disassembling</b></p> <p>Prior to disassembling engine, perform normal processing of engine in accordance with recommended procedure. Leave engine in the following sequence:</p> <ol style="list-style-type: none"> <li>1. Close fuel shut-off valve</li> <li>2. Remove tail cone</li> <li>3. Remove hydraulic control unit from adjustable jet nozzle, for which purpose:                     <ol style="list-style-type: none"> <li>(a) detach hydraulic pipelines from hydraulic control unit; detach feed-back transmitter plug connector;</li> <li>(b) unlock and remove six pins holding lines 3 to adjustable jet nozzle using (Fig. 156);</li> <li>(c) remove links 3 from legs and dismantle hydraulic control unit (three cylinders complete with cooling shrouds, meter control ring 10, and load carrying ring 4 complete with six links 3)</li> </ol> </li> <li>4. Disjoint fuselage tail section in accordance with Process Chart No. 38</li> <li>5. Bring trolley under adjustable jet nozzle</li> </ol> | <p>Prior to detaching pipelines operating under pressure, make sure there is no pressure in system.</p> <p>When turning off pipeline nuts, make use of another wrench, to avoid deforming pipelines and loosening unions</p> |                  |                            |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



342

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Replacement to Inspection Guide No. 21  | PROCESS CHART No. 70  |                  | In 17 sheets Sheet 3       |
|---|---|------------------|----------------------------|
| POWER PLANT   | REPLACEMENT OF ENGINE   |                  | Man-hours required - 48.00 |
| Procedure   | Technical requirements  | Fault correction |                            |
| <p>6. Remove telescopic ring and detach jet nozzle from afterburner diffuser. Wrap jet nozzle in two layers of paraffin wax and bind with twine.</p> <p>7. Fit lifting device belts under adjustable jet nozzle, bring it up and place into shipping case after preparing attachment fittings.</p> <p>8. Secure adjustable jet nozzle.</p> <p>9. Couple case with bottom.</p> <p>10. Disconnect all aircraft pipelines from engine, as instructed in routine list (Appendix 1).</p> | <p>After removing adjustable jet nozzle, install hydraulic control unit on jet nozzle; prior to this process external surfaces of flaps and hydraulic control unit.</p> <p>Secure adjustable jet nozzle to supports in two places:</p> <p>(a) first attachment zone is represented by front flange of adjustable jet nozzle, whose collar engages half-ring of case support and is secured by detachable half-ring with the aid of two ringed belts;</p> <p>(b) second zone comprises alidas for securing of afterburner, which hold afterburner on two S-shaped pins of case support.</p> <p>Case is held to bottom by four bolts.</p> <p>Prior to disconnecting pipelines operating under pressure, make sure there is no pressure in system.</p> |                  |                            |


343

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Attachment to Inspection<br>Table No. 21  | PROCESS PLANS No. 70  |   |
|---|---|---|
| ENGINE PLANT  | REPLACEMENT OF ENGINE   |   |
| Procedure   | Technical requirements  | Fault correction  |
| <p>11. Bring trolley under engine</p> <p>12. Disconnect engine attachment unit (Fig. 157) from airframe attachment units, for which purpose:</p> <p>(a) remove superstructure cover on upper frame No. 25, extract bolt using engine upper attachment unit pin and fastener attachment unit; unlock and insert pin;</p> <p>(b) secure engine to trolley;</p> <p>(c) unlock and disconnect from attachment unit on frame No. 28 two links on starboard side and one link at starboard side; disconnect links located on frame No. 28</p> <p>13. Move away engine</p> <p>NOTE: Engine should be fastened to trolley in front some before engine rollers leave aircraft fuselage guide rails</p> | <p>When removing nuts, make use of another wrench to prevent deforming of pipelines and loosening of nuts.</p> <p>To provide for reinstallation of engine without subsequent levelling, do not change length of side attachment unit links, when dismantling engine from aircraft.</p> <p>When moving away engine, take care to see that fuel-cooled oil cooler passed by frame No. 25 with due clearance; see that proper clearances are provided between fuselage structure components and engine (on top and below).</p> | <p>In 47 starts<br/>Sheet 5</p> <p>Man-hours<br/>required - 48,00</p> |

365

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |   |  |                               |  |
|---|--|---|--|-------------------------------|--|
| Supplement to Inspection<br>Guide No. 21  |  | PROCESS CHART No. 70  |  | In 17 sheets<br>Sheet 6       |  |
| POWER PLANT   |  | REPLACEMENT OF ENGINE   |  | Man-hours<br>required - 48.00 |  |
| Procedure   |  | Technical requirements  |  | Fault correction              |  |
| <p>14. Remove the following accessories and units from engine:</p> <ul style="list-style-type: none"> <li>(a) two hydraulic pumps EH-34;</li> <li>(b) two tachometer generators TG-1;</li> <li>(c) thermo-couple set TH-11C;</li> <li>(d) oil pressure transmitter EM-82;</li> <li>(e) two connections with guses, for air discharge from unloading chambers;</li> <li>(f) oil system centrifuge connection (reinstall after mounting engine into fuselage);</li> <li>(g) connection for air supply into cockpit;</li> <li>(h) fuel system pressurization pipe with non-return valve;</li> <li>(i) connection with drain cock for fuel supply into booster pump;</li> <li>(j) fuel system vent pipes;</li> <li>(k) ring on engine inlet flange</li> </ul> |  | <p>Take away engine with due care to avoid brushing of engine accessories against fuselage structure and components or against engine mount; if necessary, change engine position by manipulating trolley adjustment elements</p> <p>When hoisting and installing engine, take care to avoid damaging</p> |  |                               |  |

346

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   |   | PROCESS CHART No. 70       | In. 7 Sheets<br>Sheet 7 |
|---|---|----------------------------|-------------------------|
| POWER PLANT   |   | REPLACEMENT OF ENGINE      |                         |
| Procedure   | Technical requirements  | Fault correction           |                         |
| <p>15. Fit special blanking covers and slip into all pipelines, air intakes, etc., engine accessory unit flanges; and engine intake and exhaust ducts</p> <p>16. Fasten lifting device to engine shipping case support</p> <p>17. Perform processing of engine metal surfaces in accordance with these Chart No. 71</p> <p>18. Secure engine to support</p> <p>19. Secure package containing spare tools for one engine and aircraft ground tools kit to case support</p> | <p>engine pipelines and accessories by lifting device cables</p> <p>Engine attachment is accomplished in two places:</p> <p>(a) at aircraft load-carrying attachment fitting (compressor rear housing) - to two side brackets;</p> <p>(b) at front flange of turbine first stage nozzle assembly casing - to brackets arranged in centre part of engine</p> <p>For reliable attachment of engine to case support, see that support bolts, coupling it to case bottom are securely tightened, and that pins supporting engine are locked</p> |                            |                         |
|   |   | Man-hours required - 48.00 |                         |

SECRET/NO FOREIGN DISSEM

Poor Original





SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>- 10147-21  | PROCESS CHART No. 70  |                  | In 17 sheets<br>Sheet 10      |
|---|---|------------------|-------------------------------|
| ROCK PLANE  | REPLACEMENT OF ENGINE   |                  | Man-hours<br>required - 46.00 |
| Procedure   | Technical requirements  | Fault correction |                               |
| <p>(c) attachment and condition of engine electric wires;</p> <p>(d) presence of plugs in unions for measuring instruments;</p> <p>(e) presence of seals on adjustable elements</p> <p>Remove accessory plugs from engine and fit engine with units and assemblies referred to in Item 14, Section A of present Process Chart</p> <p>5. Check to see whether engine compartment has been properly prepared for engine installation</p> <p>6. Open intake duct surfaces for cleanliness and condition</p> <p>7. Install engine in the reverse order of dismantling</p> | <p>provided, (coating, brackets, flanges, etc.), clearance must be equal to not less than 1 mm</p> <p>Electric wires should be securely fastened and locked; plug connectors should be kept clean</p> <p>Unions serving for taking measurements on ground should be fitted with plugs. Unions for connection of engine instruments taking measurements during engine operation should be fitted with accessory plugs coated with red paint</p> <p>Should any defects be detected on engine, draw up statement to the effect and hand it over to Manufacturer</p> <p>Removal of accessory plugs from engine units and assemblies should be done just before installing units or pipelines connected</p> <p>Engine compartment should be cleaned of dirt, dirt, traces of oil or fuel and foreign objects</p> <p>Oxygen supply system must be filled with nitrogen. Prior to connecting</p> |                  |                               |

350

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 21   |  | PROCESS CHART No. 70  |  | In 17 sheets<br>Sheet 11      |
|--|--|-----------------------|--|-------------------------------|
| FOREFLAT   |  | REPLACEMENT OF ENGINE |  | Man-hours<br>required - 45.00 |
| Procedure  | Technical requirements   | Fault correction      |  |                               |
| <p>8. Bring adjustable jet nozzle mounted on trolley to engine fastened in fuselage</p> <p>9. Fit adjustable jet nozzle flange onto rear flange of afterburner diffuser, so that clearance A (see Fig. 161) in afterburner diffuser flange-to-adjustable jet nozzle flange joint should be within 2 to 10 mm</p> <p>10. Install easy-detachable telescopic coupling ring holding adjustable jet nozzle to diffuser, for which purpose:<br/>(a) fit telescopic ring onto joint;</p> | <p>Aircraft pipelines to engine, see that supply pipes and hoses are free of foreign objects or dirt inside and outside</p> <p>Adjustable jet nozzle attachment rollers should be turned out as indicated on access panel</p> <p>When measuring clearance, do not employ any levers, which are likely to cause deformation either to afterburner diffuser flange or to adjustable jet nozzle flange.</p> <p>Measurement should be carried out with the aid of feeler gauge applied in four points spaced around circumference. Difference in measurements must not exceed 1 mm</p> <p>Secure telescopic ring at left-hand side (looking forward). Narrow groove provided in telescopic ring receives diffuser flange collar; collar of adjustable jet nozzle engages wide groove in ring</p> |                       |  |                               |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 70  | In 17 sheets<br>Sheet 12  |
|---|---|---|
| FOUR PLAT   | REPLACEMENT OF ENGINE   | Man-hours<br>required - 48.00   |
| Procedure   | Technical requirements  | Fault correction  |
| <p>(b) check to see that telescopic ring has been installed properly;</p> <p>(c) fit in bolts securing telescopic ring joint, install gasket without screen and tighten up nuts;</p> <p>(d) remove bolts; reinstall them along with screen; tighten and lock bolts;</p> <p>11. After installing telescopic ring, check axial displacement of adjustable jet nozzle in telescopic joint (with fuselage nose section joined)</p> <p>12. Connect oxygen supply pipeline to engine non-return valve</p> <p>13. Perform joining of aircraft as laid down in Process Chart No. 38. After completing aircraft joining, measure clearance "C" between adjustable jet nozzle and afterburner diffuser (see Fig. 152)</p> <p>14. Perform flushing of pipeline for removal of air locks, as follows:<br/><u>Main Fuel System</u></p> <p>(a) connect ground power supply source</p> | <p>Telescopic ring should connect by hand effort</p> <p>After bolts are fitted in, clearance of 0.8 mm is allowed between ring face and gasket (at both sides, see Fig. 151)</p> <p>Axial displacement of adjustable jet nozzle must not be less than 6 mm (with regard to clearance "C", see Fig. 153)</p> <p>Should it be necessary to check engine and afterburner operation, it is allowed to check engine fitted with adjustable jet nozzle on ground, provided jet nozzle is secured to truss</p> <p>Prior to starting flushing procedure, fill aircraft main and starting fuel tanks</p> <p>Drain processing compound from</p> | <p>If clearance amounts to more than 0.8 mm, replace telescopic ring by new one</p> |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21  | PROCESS REPORT No. 70  | In 17 sheets Sheet 13      |
|--|--|----------------------------|
| POWER PLANT  | REPLACEMENT OF ENGINE  | Man-hours required - 48.00 |
| Procedure  | Technical requirements   | Fault correction           |
| <p>to aircraft mains;</p> <p>(b) remove screw cap from air release union on unit 357C and connect air discharge device 88-530;</p> <p>(c) open fuel shut-off valve and start booster pumps;</p> <p>(d) after completing flushing, switch off booster pumps and reinstall screw cap after replacing rubber sealing ring;</p> <p>(e) use the same procedure for flushing regulating fuel pump RP-210 by connecting device 88-530 to relief valve</p> <p><u>Replacine Supplie Starting Fuel in Starting Electro-Magnetic Valve</u></p> <p>(a) set switch AIRCRAFT GROUND STORAGE BATTERY (APPOWNYATOP BOPPOPO2 APPOPOPO2) in ON (ANNEKED) position;</p> <p>(b) set switch PROCESSING (KOSKOPALLES) (RP) in K position;</p> <p>(c) turn on switch STARTING UNIT (AIPAPATA BAIYORA) (ANC-25);</p> | <p>fuel pipelines through fuel drain union on unit 357C</p> <p>Discontinue flushing procedure as soon as stream of fuel flowing from hose does not contain air bubbles, but only after 8 to 10 lit. of fuel has been drained</p> |                            |

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 22  | PROCESS PART No. 70   |                  | In 17 sheets<br>Sheet 14      |
|---|---|------------------|-------------------------------|
| FOUR PLAT   | REPLACEMENT OF ENGINE   |                  | Man-hours<br>required - 48.00 |
| Procedure   | Technical requirements  | Fault correction |                               |
| <p>(d) turn on switch STARTING IN AIR (STARTER B BOWTIE) (30);</p> <p>(e) discontinue flushing procedure as soon as stream of starting fuel (leaving from aircraft drain valve) contains no more air bubbles;</p> <p>(f) after flushing main and starting fuel pipelines, set switch STARTING IN AIR in initial position;</p> <p>(g) wet areas splashed with fuel by cloth.</p> <p><b>Hydraulic System</b></p> <p>(a) connect ground hydraulic unit;</p> <p>(b) switch off interlocking system RS and SO system by turning screw 1 on afterburner control unit L10-15X in BLOCKING OFF position;</p> <p>(c) turn on switch AFTERBURNER;</p> <p>(d) shift engine control lever 3 to 0 from MANUE stop to FULL AFTERBURN stop and back.</p> <p>While doing so, observe movement of flaps ring. Properly aligned ring will indicate that there are no air locks in hydraulic system.</p> | <p>Oxygen cut-off valve should be closed.</p> <p>Misalignment of flaps ring must not exceed 7 mm. Any difference in hydraulic cylinder rod projection is not allowed.</p> |                  |                               |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                  |                               |
|---|--|------------------|-------------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 70   |                  | In 17 sheets<br>Sheet 15      |
| POWER PLANT   | REPLACEMENT OF ENGINE  |                  | Man-hours<br>required - 48.00 |
| Procedure   | Technical requirements   | Fault correction |                               |
| (e) check time period required for cylinder rods to shift from one position to another in compliance with Process Chart No. 67  | Ring misalignment should be checked as follows: as soon as one of rods sets against stop (with rods moving to MIDDLE position), measure distance between shank of two other rods and stops of respective cylinders. Values obtained will indicate degree of misalignment |                  |                               |
| (2) set all switches and circuit breakers in initial position after flushing of pipelines is completed  |  |                  |                               |
| 15. Depress internal surfaces of engine in compliance with Process Chart No. 71   |  |                  |                               |
| 16. Check operation of adjustable jet nozzle hydraulic control system as instructed in Process Chart No. 67   |  |                  |                               |
| 17. Set time lag valve on afterburner control unit E16-13K, with regard to fuel and adjustable jet nozzle flaps in compliance with data presented in engine Service Log |  |                  |                               |
| 18. Check main flame igniter oxygen supply system, proceeding as follows:   |  |                  |                               |

SECRET/NO FOREIGN DISSEM

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  |  |   |                               |
|--|--|---|-------------------------------|
| Supplement to Inspection Guide No. 21  |  | PROCESS CHECK No. 70  | In 17 sheets<br>Sheet 17      |
| POWER PLANT  |  | REPLACEMENT OF ENGINE   | man-hours<br>required - 28.00 |
| Procedure  | Technical requirements   | Fault correction  |                               |
| (1) set switch CHECK (EM) to CHECKING position and release nitrogen;<br>(2) set switches and circuit breakers in initial positions, detach ground power supply source;<br>(3) charge oxygen bottle<br><br>29. Start engine and check its operation | When releasing nitrogen, check above joints for tightness<br><br>When charging oxygen bottle, observe due care; hands should be clean; take measures to prevent contact with oil<br>Checking should be done on site allotted for the purpose | If bubbles are formed on soap foam, tighten up or recondition joint |                               |
| Accessories  |  | Tools   |                               |
|  |  |   |                               |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                           |
|---|---|------------------|---------------------------|
| Supplement to Inspection<br>Slide No. 22  | PROCESS CHART No. 71  |                  | In 11 sheets<br>Sheet 1   |
| POWER PLANT   | PROCESSING AND REPROCESSING OF ENGINE   |                  | Man-hours<br>required - 6 |
| Procedure   | Technical requirements  | Fault correction |                           |
| <p><b>1. Internal Processing</b></p> <p>1. Perform starting and checking of engine at all ratings including augmented rating</p> <p>2. Process internal surfaces of engine as follows:</p> <p>(a) check to see that processing oil has been tested in laboratory;</p> <p>(b) fill tank for internal processing with oil (Fig. 25B);</p> | <p>Engine starting and checking should be performed on site allotted for the purpose, with aircraft securely fastened</p> <p>Respective certificate will be valid for not more than 7 days from date of issue</p> <p>For internal processing of fuel and oil systems, employ oil KF-8, State Standard TCT 6457-53. Oil properties should comply with requirements of State Standard TCT Specifications. It is strictly prohibited to utilize oil containing traces of water, or reclaimed, or used oil. Insert oil into tank through silk filter. See that no dust, dirt, or foreign particles find their way into tank. Processing oil tank must be fitted with recirculating pump equipped with recirculating valve and filter CF-1 or CF-2 at the outlet</p> |                  |                           |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   |   | PROCESS CHART No. 71                  | In 11 sheets<br>Sheet 2   |
|---|---|---------------------------------------|---------------------------|
| POWER PLANT   |   | PROCESSING AND IMPROCESSING OF ENGINE | Man-hours<br>required - 6 |
| Procedure   | Technical requirements  | Fault correction                      |                           |
| <p>(e) drain oil from engine oil system via oil tank and accessory gear box drain cock;</p> <p>(f) fill oil tank with fresh oil after checking respective Certificate;</p> <p>(g) close fuel shut-off valve;</p> <p>(h) drain fuel via fuel-oil unit drain cock; discharge fuel from drain tank by removing plug;</p> <p>(i) pour at least 3 lit. of oil into starting fuel tank;</p> <p>(j) connect hose running from internal processing tank (Fig. 158) to processing union located on pipe supplying fuel to booster pump EH-1511;</p> <p>(k) use hose of device EH37-515 to connect unions for measuring afterburner fuel pressure with union serving for measuring fuel pressure in pilot fuel manifold;</p> <p>(l) apply nitrogen under pressure of 2 to 4 kg/cm<sup>2</sup> (via filter) to union for measuring oxygen pressure; blow</p> | <p>No draining of oil is required, if engine operation amounts to not more than 10 hours</p> <p>Oil tank should contain 12-15 lit. of oil, as measured by dip stick</p> <p>Oil pressure at inlet to booster pump EH-1511 must be equal to 1.07-1.7 kg/cm<sup>2</sup></p> <p>Prior to connecting processing pipeline, flush it with oil</p> <p>Hose tips should be clean</p> | <p>Wash in clean kerosene</p>         |                           |

559

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Applicant to Inspection  
Guide No. 21

PROCESS CHART No. 72

In 11 sheets  
Sheet 3




FIG. 152. DEVICE FOR ENGINE INTERNAL PROCESSING  
1 - end view, 2 - connection for charging hose.

360

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection<br>Guide No. 91  | PROCESS CHART No. 71  |                  | In 11 sheets<br>Sheet 4   |
|---|---|------------------|---------------------------|
| POWER PLANT   | PROCESSING AND DEPROCESSING OF ENGINE   |                  | Man-hours<br>required - 6 |
| Procedure   | Technical requirements  | Fault correction |                           |
| <p>oxygen system with nitrogen during processing.</p> <p>3. Carry out engine cranking, for which purpose proceed as follows:</p> <p>(a) connect ground power supply source to aircraft mains;</p> <p>(b) turn on following switches and circuit breakers:<br/>                 STORAGE BATTERY, AIRCRAFT, GROUND (2);<br/>                 (set it in ON position);<br/>                 STARTING UNIT (ASC-25); APPENDAGE (ASC-45); DUMPING VALVE (EC) on engine or 2nd series; PROCESSING (NE) (set it in I position);<br/>                 CRANKING (ED) (set it in CRANKING position);</p> <p>(c) disconnect blocking systems IS and ESO by turning screw 8 located on afterburner control unit L10-131;</p> <p>(d) set engine control lever in FULL AUGMENTED position, press button STARTING ON GROUND and keep it pressed for 1 to 2 sec.;</p> | <p>Switch STARTING BY AIR (ASC-10) must be set in OFF position.<br/>                 Switch CRANK (ED) should be set in OPERATING position.</p> <p>Depressing of button STARTING ON GROUND will cause generator to spin engine rotor. Rotors should spin smoothly, without knocking or binding.<br/>                 24 V supply system is employed for</p> |                  |                           |

SECRET/NO FOREIGN DISSEM

Peer Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                           |
|---|---|------------------|---------------------------|
| Supplement to Inspection<br>Guide No. 21  | PROCESS CHART No. 71  |                  | In 11 sheets<br>Sheet 5   |
| POWER PLANT   | PROCESSING AND REPROCESSING OF ENGINE   |                  | Man-hours<br>Required - 6 |
| Procedure   | Technical requirements  | Fault correction |                           |
| <p>(e) crank engine A to 5 times to accomplish processing of internal surfaces</p> <p>2. Set internal processing tank switch in CR position (this should be done, when depressing button STARTING OF CRACKS)</p> <p>B. External Processing</p> <p>1. Stop all open unions with special plugs or plugs made of cellophane film</p> | <p>engine cranking; neither power supply sources, nor starting unit supply line is switched from 2A to 4B V.</p> <p>After cranking engine 5 times in succession, allow starter to cool down for not less than 30 min. before cranking engine again.</p> <p>While cranking engine, shift engine control lever 2 to 3 times from IDLING rating stop to MAXIMUM stop.</p> <p>After final cranking of engine, oil should issue from drain pipes of main and afterburner combustion chambers in full stress</p> <p>External processing or operations or removal of surface corrosion must not be performed during rain or snowfall</p> |                  |                           |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide No. 21   | PROCESS CHART No. 71   | In 11 sheets Sheet 6   |
|---|--|--|
| POWER PLANT   | PROCESSING AND REPROCESSING OF ENGINES   | Man-hours required - 6   |
| Procedure   | Technical requirements   | Fault correction   |
| <p>2. Wipe external surface of engine and afterburner with cloth soaked in clean gasoline. Dry surfaces subject to processing</p> <p>3. Treat external surfaces of metal components void of paint coatings with thin layer of processing compound, including internal surfaces of afterburner</p> | <p>When proceeding so, take care to see that gasoline or processing compound does not get on electric wiring, relief jet of starting fuel control unit incorporated in fuel regulating pump; HP-218, generator ICP-CI-120087, booster coil IFA-114, or adjusting needles.</p> <p>If corroded spots are detected on engine external parts, remove corrosion</p> <p>For external processing of engine non-painted metal parts use neutral petroleum, State Standard TUCI 782-53</p> <p>Petroleum may be substituted by aviation oils EC-20 or EC-22, State Standard TUCI 1013-49, with addition of 4 to 10% paraffin, State Standard TUCI 2465-47.</p> <p>Processing compound should meet requirements of respective State</p> | <p>Clean corroded spots with fine emery cloth treated with oil, polish with paste PW, wash with clean gasoline and coat with processing compound</p> |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |   |
|---|---|---|
| Supplement to Inspection<br>Guide No. 21  | PROCESS PART No. 71   | In all sheets<br>Sheet 7  |
| FORM PLATE  | PROCESSING AND IMPRESSIONS - ENGINE   |   |
| Procedure   | Technical requirements  | Fault correction  |
| <p>4. Arrange 30 silica gel bags on engine. From this number 6 bags must be arranged in diffuser, and 8 - in front housing. Remaining 16 bags should be arranged as follows:</p> <ul style="list-style-type: none"> <li>(a) in the vicinity of engine accessories - 5 bags;</li> <li>(b) on compressor front housing - 6 bags;</li> <li>(c) on compressor rear housing - 2 bags;</li> </ul> | <p>Standard JUCT Specifications so far as its properties are concerned.</p> <p>Use of processing compound is allowed only in case moisture content is equal to zero.</p> <p>It is strictly prohibited to utilize reclaimed or used processing compound.</p> <p>Use brush or atomizer for carrying out processing procedure.</p> <p>For thickening processing compound, petroleum should be preheated to 80-90°C, and aviation oil and caroline mixture - to 60-70°C.</p> <p>Bags should be fastened at both ends. Take care to prevent greasing of bags (place bags on top of paraffined paper).</p> <p>Silica gel should be freshly dried and its moisture content should not exceed 2%.</p> | <p>Remove moisture from processing compound by heating it to temperature of 110-120°C, until no froth is visible on heated oil surface.</p> |

364

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                                |
|---|---|--------------------------------|
| Supplement to Inspection<br>Guide No. 71  | PROCESS CHART No. 71  | In 11 sheets<br>Sheet 8        |
| POWER PLANT   | PACKAGING AND REPROCESSING OF ENGINE  | Man-hours<br>required - 6      |
| <p><b>Procedure</b></p> <p>(d) on turbine housing - 2 bags<br/>                 5. Put blousing cover on diffuser.<br/>                 Fit casing cover or painted plywood<br/>                 blanking cover onto front housing<br/>                 6. Trap engine in two layers of<br/>                 paraffine paper and bind it with twine<br/>                 7. Place 10 silica gel bags on top<br/>                 of paraffine paper (distributing them<br/>                 uniformly on entire engine surface),<br/>                 provide two humidity indicators<br/>                 8. Put cover of silica into engine<br/>                 9. Apply tag to packed engine; fol-<br/>                 lowing data should be indicated on tag:<br/>                 engine No., date of processing and<br/>                 storage expiration date, number of silica<br/>                 gel bags, signatures of person in charge<br/>                 of processing and that of inspector<br/>                 10. Enter date of processing and<br/>                 storage expiration date in engine Ser-<br/>                 vice Log</p> <p><b>Preprocessing of External Surfaces</b></p> <p>1. Wash external parts of engine<br/>                 coated with processing compound with<br/>                 clean gasoline, using brush</p> | <p><b>Technical requirements</b></p> <p>Arrange humidity indicators on<br/>                 engine so that they can be observed<br/>                 through cover film and through case<br/>                 ports<br/>                 Carefully press cover to engine<br/>                 to remove any air</p> | <p><b>Fault correction</b></p> |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |   |                  |                           |
|---|---|------------------|---------------------------|
| Supplement to Inspection<br>Guide No. 71  | PROCESS CHART No. 71  |                  | In 11 sheets<br>Sheet 9   |
| POWER PLANT   | PROCESSING AND DEPRESSURING OF ENGINE   |                  | Man-hours<br>required - 6 |
| Procedure   | Technical requirements  | Fault correction |                           |
| <p>2. Thoroughly wipe washed areas with dry cloth</p> <p>D. <u>Depressure of External Surfaces</u></p> <ol style="list-style-type: none"> <li>1. Drain processing oil from engine accessory gear box and engine tank</li> <li>2. Pour fresh oil into engine tank</li> <li>3. Connect ground power supply source to aircraft main</li> <li>4. Turn on following switches and circuit breakers:                     <ul style="list-style-type: none"> <li>(a) STORAGE BATTERY (B);</li> <li>(b) STARTING UNIT (AGC-25);</li> <li>(c) AFTERBURNER (APC-11);</li> <li>(d) DIVERTER VALVE (10) - for engine of 5th series;</li> <li>(e) CRANKSET (EC) (set it in CRANKING position);</li> </ul> </li> </ol> | <p>Do not allow gasoline or oil to get on electric equipment components, when depressuring engine. Thick processing compound may be removed with the aid of transformer oil heated to temperature of 80-90°C.</p> <p>Exposure of painted surface to gasoline or solvents for more than 2 min. is not allowed.</p> |                  |                           |

366

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |   |                           |
|---|--|---|---------------------------|
| Supplement to Inspection<br>Guide No. 71  | PROCESS CHART No. 71   |   | In 11 sheets<br>Sheet 15  |
| POWER PLANT   | PROCESSING AND REPROCESSING OF RESINS  |   | Man-hours<br>required - 6 |
| Procedure   | Technical requirements   | Fault correction  |                           |
| <p>(f) <b>PROCEEDING (PR)</b> (set it in F position)</p> <p>5. Use hose of device EMT-535 to connect unions for measuring pressure of afterburner fuel with union for measuring fuel pressure in pilot manifold</p> <p>6. Disconnect blocking systems F3 and F40 by turning screw # on afterburner control unit EAP-131</p> <p>7. Open fuel shut-off valve</p> <p>8. Start main fuel booster pumps</p> <p>9. Set engine control lever at FULL AUGMENTED stop, press button STARTING ON GROUND and keep it pressed for 1 to 2 sec.</p> <p>10. Stop main fuel booster pumps and perform engine cranking</p> | <p>As soon as button is depressed, generator should start cranking engine. Motor spinning should not involve any knocks or binding. Deprocessing will be accomplished in 3 to 4 engine crankings. After cranking engine 5 times in succession, allow starter to cool down within not less than 30 min., before cranking engine again</p> | <p>If any defects are found during cranking, immediately discontinue cranking by turning off circuit breaker STARTING UNITS.</p> <p>Do not crank engine again unless defect is eliminated</p> |                           |

369

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   |  |                                       |       |                           |  |
|---|--|---------------------------------------|-------|---------------------------|--|
| Supplement to Inspector<br>Guide 15.22  |  | PROCESS CHART No. 73                  |       | In 11 sheets<br>Sheet 11  |  |
| POWER PLANT   |  | PROCESSING AND REPROCESSING OF ENGINE |       | Man-hours<br>required - 6 |  |
| Procedure   |  | Technical requirements                |       | Fault correction          |  |
| 117. Set switches, circuit breakers<br>and screw <i>Y</i> on E12-112 unit in initial<br>positions |  |                                       |       |                           |  |
| Accessories   |  |                                       | Tools |                           |  |
|   |  |                                       |       |                           |  |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Supplement to Inspection Guide (No.2)  | PROCEDURE PART No. 72  |   | In 1 sheet Sheet 1     |
|--|--|---|------------------------|
| POWER PLANT  | ENGINE TRIALS: CHECKING OF INSTRUMENTS AND GAGES FOR PROPER OPERATION; CHECKING OF SYSTEMS FOR TIGHTNESS |   | Man-hours required - 2 |
| Procedure  | Technical requirement  | Fault correction  |                        |
| 1. Start and subject engine to trials, with afterburner turned on<br><br>2. With engine running, check fuel, oil, and hydraulic systems for condition by observing them through respective access panels on fuselage | Engine performance characteristics should comply with Specifications<br><br>Systems should be airtight   | In the course of engine operation it is allowed to carry out adjustments (see Appendix No.2)<br>Recondition systems, if not tight |                        |
| Accessories  | Tools  |   |                        |
|  |  |   |                        |

SECRET/NO FOREIGN DISSEM

Peer Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

## DETACHABLE CONNECTING LINES OF ENGINE

APPENDIX 1

| Description  | Type of connection     | Description   | Type of connection |
|--|------------------------|---|--------------------|
| <u>Oil System</u>  |                        |   |                    |
| Engine breathing line  | Rubberized canvas hose | Return line of hydraulic fluid from nose flap control hydraulic cylinders | Hipple             |
| <u>Main and Starting Fuel System</u>   |                        |   |                    |
| Main fuel supply line to booster pump, type ICB-1511                               | Flange                 | <u>Flare Ignitor Crown Feeding System</u>                                 |                    |
| Starting fuel supply line to solenoid-operated valve                               | Hipple                 | Supply line of low-pressure oxygen to non-return valve                    | Hipple             |
| <u>Engine Air Bleed System and Pressure Balance Chamber Pressure Relief System</u> |                        |   |                    |
| Air bleed for aircraft hot air needs (at two points)                               | Hipple                 | <u>Electric System of Engine</u>  |                    |
| Air bleed from pressure balance chamber manifold (at two points)                   | Flange                 | Connection ZHP60458E2   |                    |
| Air bleed for shaft blowing  | Telescopic             | Connection ZPT20K458E2 of ZOC-1A transmitter                              |                    |
| <u>Hydraulic System</u>  |                        |   |                    |
| Hydraulic fluid supply line to nose flap control hydraulic cylinders               | Hipple                 | Connection of wires to starter-generator                                  | Bolt               |
| 370  |                        | Starter-generator cooling line  | Flange             |
|  |                        | <u>Drain System</u>   |                    |
|  |                        | Drain lines from two hydraulic pumps EB-34                                | Hipple             |
|  |                        | Fuel drain line from EEB-1511 pump drive                                  | Hipple             |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

| Description   | Type of connection | Type of connection   | Description |
|---|--------------------|--|-------------|
| Fuel drain line from electric contactor of EP-224 unit                    | Ripple             | Fuel drain line from glands of EP-214 and EP-224 unit drives   | Ripple      |
| Fuel drain line from scabination chamber housing                          | Ripple             | Oil drain line from two-speed gear box   | Ripple      |
| Fuel drain line from collector of afterburner diffuser                    | Ripple             | Fuel drain line from starting fuel control unit, electric contactor and regulator drive gland of EP-218 unit | Ripple      |
| Fuel drain line from fuel collector of nozzle diaphragm assembly diffuser | Ripple             |  |             |

Note. All the drain lines with the exception of the fuel drain line from the fuel collector of the afterburner diffuser are connected into a single common leadout pipe.

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

ADJUSTMENT OF ENGINE

APPENDIX 2

In the course of engine operation the following adjustments are allowed:

1. Adjustment of engine starting.
  2. Adjustment of idling r.p.m.
  3. Adjustment of low-pressure rotor maximum r.p.m.
  4. Adjustment of oil pressure.
  5. Adjustment of the limit switch incorporated in the hydraulic decelerator of regulating fuel pump EP-21g.
  6. Adjustment of control unit.
  7. Adjustment of high-pressure rotor maximum r.p.m.
  8. Adjustment of time delays of afterburner control unit EP-43E.
  9. Adjustment of acceleration.
- All the adjusting devices of the engine delivered by the manufacturer should be properly locked.

**WARNINGS:** 1. Prior to carrying out engine adjustment, see to it that the readings of the measuring instruments are precise.

2. To ensure that the adjustment readings are stable, change the positions of the adjusting devices by turning the dial should be necessary to turn an adjusting device out through some angle, first turn it out by the desired angle plus 180°, and then turn it in through 180°.

If the adjusting device has several fixed positions (indicated by clicks, etc.), reserve the basic margin by moving the adjusting device through the number of clicks equivalent to an angle of 180°. Upon completion of the adjusting procedure lock the respective adjusting devices and apply seals.

In the course of engine operation it is allowed to change the position of the following adjusting elements:

- (a) the adjusting screw of the maximum r.p.m. limiter incorporated in regulating fuel pump EP-21g;
- (b) the EP-21g regulating fuel pump maximum r.p.m. stop;
- (c) the flow restrictor of the hydraulic decelerator of regulating fuel pump EP-21g;
- (d) the pressure increase limiter flow restrictors of the 1st and 2nd branches of regulating fuel pump EP-22g;
- (e) the stop of the EP-21g regulating fuel pump lever in the **STOPPED (STOPPED)** positions;
- (f) the adjustment screw of the EP-22g regulating fuel pump electrohydraulic contactor;
- (g) the screw of the starting control unit of regulating fuel pump EP-21g;
- (h) the air jet of the starting control unit;
- (i) the flow restrictor of the afterburner valve of the EP-22g regulating fuel pump;
- (j) the reducing valve of the oil unit;
- (k) the screws of the limit switches of boosters EP-45 (3y-211);

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

(j) regulating needle  $P_2$ ;  
 (k) altitude corrector needle  $P_2$ ;  
 (n) screws  $M_9$  and  $M_10$  of the P-1 rheostat.  
 The positions of other adjustment elements can be adjusted only by the manufacturer's representative. All the adjustments performed should be duly registered in the engine Service Log.

#### Adjustment of Engine Starting

The engine starting system is adjusted with the use of the ground power supply source.

The adjusting elements of the engine starting system are:

1. The screw of the spring incorporated in the starting fuel control unit which controls the first stage of the starting procedure (up to speed  $n_2 = 18$  to 21%).

When the screw is turned out the engine accelerates at the first stage of the starting procedure slowly (the temperature of gases after the turbine decreases), and vice versa.

2. The jet serving for bleeding air from the diaphragm chamber of the starting fuel control unit, which controls the 2nd stage of the starting procedure (the engine develops speed  $n_2$  in excess of 18 - 21%).

An increase in the jet orifice diameter causes the engine to accelerate in the second stage of the starting procedure at a slower rate (the temperature of gases after the turbine decreases), and vice versa.

In case the engine characteristics (the time period required for starting, temperature of gases after the turbine) displayed in the course of the starting procedure come out of the specified performance limits, adjust the starting system in the following manner:

1. Make sure that when the engine control lever is set in IDLING RATING (HARD TAP) position  $I_1$  in index log

of the EP-214 regulating fuel pump lever is located beyond the limits limiting the idling rating zone on the pump dial.

2. Connect the pressure gauge and check the fuel pressure in the starting manifold. The starting fuel pressure should be within  $2.0 \pm 0.2$  kg/cm<sup>2</sup> (without pressurization of the starting fuel tank, and with the voltage in the aircraft storage battery amounting to 25 V). If the actual pressure does not agree with the specified value, carry out the necessary adjustment with the aid of the screw accommodated in the reducing valve of the starting fuel pump. When the screw is turned in, the pressure increases, and vice versa.

3. Mount the pressure gauge (with the scale range from 0 to 100 kg/cm<sup>2</sup>) for assuring fuel pressure in the primary fuel manifold.

4. Start the engine after ascertaining that the electric control equipment and the power supply source function properly.

**Note.** It is allowed to start the engine with manual control of the fuel supply.

5. Run up the engine for 1 to 2 min. at a speed amounting to 88 - 90% of the normal rating.

6. Check the idling r.p.m.: these should be equal to the speed (see Fig. 159) specified for the given barometric pressure.

Adjust the idling r.p.m. if necessary.

7. Check and, whenever necessary, adjust the fuel pressure in the primary fuel manifold with the engine running at idling rating; the pressure should amount to  $21 \pm 1$  kg/cm<sup>2</sup> for engines fitted with the EP-214 pumps (beginning with series K). The adjustment procedure is carried out by the representative of the manufacturer to accomplish adjustment, the screw of the distributing

373

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

valve (12) should be turned by not more than a quarter of a turn relative to the initial position.  
Turning the screw in will cause an increase in the fuel pressure.

8. Stop the engine, remove the air jet, and disconnect the solenoid-operated valve which controls the additional fuel supply at starting; to measure the fuel pressure in the primary fuel manifold mount a pressure gauge (scale range from 0 to 10 kg/cm<sup>2</sup>).

9. Without fitting in place the air jet of the starting fuel control unit and with additional fuel supply disconnected, start the engine; when the engine becomes lopy (fails to accelerate despite the movement of the throttle control lever), manipulate the starting fuel control unit screw to adjust the fuel pressure in the primary manifold. This pressure should equal 4 to 5 kg/cm<sup>2</sup>.

**Note.** Determine the position of the starting fuel control unit adjusting screw by turning it in as far as it will go and noting the number of full revolutions.

10. Fit in the starting fuel control unit air jet (1.0<sup>+0.3</sup><sub>-0.4</sub> to 2.0<sup>+0.2</sup><sub>-0.5</sub> mm in diameter), and connect the solenoid-operated valve controlling the additional fuel supply at starting (if provided). Make sure that the primary fuel manifold is fitted with a pressure gauge (scale range from 0 to 100 kg/cm<sup>2</sup>).

11. Start the engine 2 or 3 times.

**Notes:** 1. The engine should start without becoming lopy and without excessive rise of gas temperature.  
If the engine fails to accelerate after the high-pressure rotor develops a speed amounting to 18 - 21% of the normal rating, as well as in case a flame torch

appears after the turbine, the starting fuel control unit screw should be turned out. If the engine fails to accelerate after the high-pressure rotor develops a speed amounting to 25 - 27% of the normal rating, reduce the diameter of the starting fuel control unit air jet.

2. If surging is experienced at high-pressure rotor speed of about 32% of the normal rating, increase the diameter of the starting fuel control unit air jet.

3. A reduction in the engine acceleration rate is allowed within the high-pressure rotor speed range of approximately 74 to 28% of the normal rating; in this case the total engine starting period (when using the ground power supply fixture) should not be in excess of 50 sec.

12. Check to see that there is a certain interval between the moment when the engine fails to accelerate without temperature rise and the moment of the engine becoming lopy with temperature rise (this interval should be equivalent to not less than three turns of the starting fuel control unit adjusting screw).

**Note.** In case of failure to adjust the engine starting system properly, as well as in case the starting fuel control unit screw can be turned through less than 3 turns, show the starting unit to the manufacturer's representative.

When through with the adjusting procedure, disconnect the pressure gauges, plug the gauge connections and start the engine 2 or 3 times in succession.

13. In the case with engines furnished with equipment for automatic starting, proceed as follows; having adjusted the engine starting system with the use of the ground power supply source, check the starting fuel control unit screw for the number of revolutions through which it can be turned additionally from the initial

374

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

position, using fully charged aircraft storage batteries (or some other power supply source which ensures engine spinning to  $n_0 = 9$  to 11% of the normal rating); the screw should turn through not less than  $3/4$  of a turn to either side. The checkout procedure is as follows:

- (a) turn in the starting fuel control unit screw through  $3/4$  of a turn from the initial position and check the engine starting;
- (b) turn out the starting fuel control unit screw through 1.5 of a turn from the last position and repeat the engine starting check.

If the engine fails to start with the screw set in one of the above positions, as well as in case the starting procedure takes more than 100 seconds after the screw has been turned out through 1.5 of a revolution, readjust the starting system as instructed in the Note to Point 11 of the present Section. After the readjustment check the starting fuel control unit screw again, with the use of the aircraft storage batteries.

The check completed, set the starting fuel control unit screw in the intermediate position.

Adjusting the Idling R.P.M.

Prior to checking and adjusting the idling r.p.m., see that when the engine control lever is in the IDLING RATING position the index lug of the EP-21g regulating fuel pump lever is located between the notches which limit the idling rating zone on the pump dial; there are the first and third notches, as counted from the CUT-OFF (CTM) position.

Checkout and adjustment of the idling r.p.m. should be carried out after the engine has been warmed up during 2 minutes at a speed of at least 28% of the normal rating. Prior to performing the adjustment, check

the idling rating zone by moving the engine control lever in either direction between the first and third notches (as counted from the CUT-OFF position) provided on the EP-21g regulating fuel pump dial. If the idling rating zone upper limit r.p.m. differ from the lower limit r.p.m. by more than 1.5%, consult the Manufacturer's representative as to the further use of the EP-21g pump.

To adjust the idling r.p.m. it is necessary to turn the adjusting head through several clicks, so that the idling r.p.m. become equal to the r.p.m. value indicated in the chart for the given barometric air pressure.

Rotation of the adjusting head clockwise causes the idling r.p.m. to decrease, and vice versa. One turn of the adjusting head results in the change of the idling r.p.m. by about 2%.

Adjustment of the idling r.p.m. should be accomplished with the EP-34-2T pump and RCP-42200GT starter-generator running.

Adjustment of Low-Pressure Rotor Maximum R.P.M.

1. In case the maximum speed of the low-pressure rotor on the properly warmed up engine differs from the specified value of  $100 \pm 0.5\%$  it is necessary to carry out appropriate adjustments.

Note. When adjusting the maximum r.p.m. of the low-pressure rotor make use of an attachment tachometer which reads accurate to  $\pm 0.2\%$  within the 90 - 165% range. If no attachment tachometer is available the aircraft tachometer may be employed; in this case the r.p.m. value at which the adjustment procedure is being carried out should not exceed 100.5%, with due consideration of the actual correction to the instrument readings.

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

2. Prior to starting the engine, check the elements of the control unit for proper position:

(a) Figure 66 should be indicated at control panel EP-21;

(b) the notch on the index lug of regulating fuel pump EP-21 should bear over the sixth notch on the dial.

The maximum r.p.m. should be adjusted by resetting the hydraulic decelerator screw. Turning the screw in causes a reduction in the r.p.m., and vice versa. One revolution of the screw changes the r.p.m. by about 2.2 to 2.7%.

Having completed the adjusting procedure, check the maximum r.p.m. of the engine; to this end set the engine control lever at **MAXIMUM (MAXIMAL)** stop from the 90% r.p.m. position. Repeat this procedure two or three times.

3. Check to see that regulating fuel pump EP-21 does not cause the maximum r.p.m. to exceed the specified value as a result of changes in the fuel flow into the engine; to check, act as follows:

(a) Detach for some time the plug connectors from the solenoid-operated valve and from the limit switch of the afterburner valve incorporated in the EP-22 pump;

(b) check the difference between the maximum r.p.m. when setting the engine control lever at the **MAXIMUM** stop and the **FULL THROTTLED (ПОЛНОЕ ДАВЛЕНИЕ)** stop. The difference between the maximum r.p.m. values for the two settings should not exceed 0.5%.

Note: The maximum r.p.m. values in either case should not exceed 100.5%.

If the difference between the maximum r.p.m. values for the two settings is found to be in excess of 0.5%, replace the feed-back flow restrictor with a new flow restrictor whose capacity is greater by 20 to 30 cu.cm./min.

- Notes:
1. The maximum permissible capacity of the feed-back flow restrictor is 300 cu.cm./min.
  2. After replacement of the feed-back flow restrictor, check the engine acceleration from the idling rating to the maximum rating and variations in the engine r.p.m. at engine ratings amounting to 88 - 100% normal ratings; the r.p.m. variations should be within  $\pm 0.3\%$ .
  3. If turning of the hydraulic decelerator adjusting screw through 2 turns (after carrying out the adjustment procedure discussed in Point 2) fails to bring the maximum r.p.m. (n) to the proper value of  $100 \pm 0.5\%$ , regulating fuel pump EP-21 should be replaced.

Adjustment of Oil Pressure

In case the oil pressure value turns to be beyond the specified range it must be adjusted by means of the rotating shank of the reducing valve incorporated in the oil unit.

If the oil pressure is in excess of the specified value, the shank should be turned out. If the oil pressure is lower than specified, the shank should be turned in. One turn of the adjusting screw changes the pressure by 1 kg/cm<sup>2</sup>.

Note: If the oil pressure drops by more than 0.5 kg/cm<sup>2</sup> below the minimum pressure value, consult the manufacturer's representative as to the possibility of further use of the oil unit.

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

Adjustment of Limit Switch Incorporated in Hydraulic Decelerator of Regulating Fuel Pump EP-214

Check the hydraulic decelerator operating r.p.m. in the following succession:

1. Detach the electric plug connector of the hydraulic decelerator of the EP-214 pump and connect it to the engine via console No. 356 taken from the maintenance kit for 20 aircraft.

2. While smoothly moving the engine control lever in the range between 90° to maximum r.p.m., watch the illumination of the indicator light in console No. 356; the light comes on to indicate that the limit switch of the hydraulic decelerator of the EP-214 regulating fuel pump operates as soon as the speed reaches  $98 \pm 1\%$  normal rating.

If the actual r.p.m. are not within the specified r.p.m. range, operate the adjusting screws of the hydraulic decelerator switch to bring the limit switch operating r.p.m. within the specified range; turning the screw in will increase the r.p.m. at which the limit switch operates and vice versa. One turn of the screw changes these r.p.m. by 3.6%.

When through with the adjustment procedure, disconnect console No. 356 and fit the EP-214 pump hydraulic decelerator connector back in place.

Adjustment of Control Unit

The control unit (Fig. 147) is adjusted with the following methods:

(a) by changing the length of control rod 7;

**NOTE:** When adjusting the length of control rod 7, see to it that the holes of the first row (counting from the shackle) are not open;

(b) by rearranging the shackle of control rod 7 in the slot of lever 2 of the EP-214 pump;

**NOTE:** 1. When adjusting the length of control rod 7 and the position of the rod shackle in the slot of lever 2, set arm II of control panel EP-14 and the lever of regulating fuel pump EP-214 in the CUT-OFF (CUT) position.  
2. The original distance between the centre of bolt 3 which attaches rod 7 to the EP-214 pump lever and the centre of the EP-214 pump shaft should be equal to 55 mm.

When adjusting the control unit, see that the following is provided with regard to the positions of arm II of the EP-14 control panel and lever 2 of the EP-214 regulating fuel pump:

(a) when index lug 4 of the EP-214 regulating fuel pump is set at the CUT-OFF stop, the zero division of the EP-14 control panel dial should line up with the notch on the control panel body;

(b) when figures 57 and 68 on the EP-14 control panel dial are matched with the notch provided on the control panel body, the notch on the EP-214 regulating fuel pump index lug should bear against the sixth notch on the EP-214 regulating fuel pump dial;

(c) when figures 72 and 73 on the EP-14 control panel dial are aligned with the notch on the control panel body, the notch on the EP-214 regulating fuel pump index lug should be beyond the seventh notch on the EP-214 regulating fuel pump dial;

(d) with the EP-14 control panel index lug 13 set against the FULL ADVANCED stop, the notch on the EP-214 regulating fuel pump index lug should be located beyond the seventh notch on the EP-214 regulating fuel pump dial.

When through with the adjusting procedure, check the following:

SECRET/NO FOREIGN

Poor Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

1. The limit switches of the HPT-10 control panel for proper operation (making use of console No. 155, (see the engine at standstill), this performing the check see to it that:

- (a) when figures 67 - 68 on the HPT-10 control panel dial are matched with the notch on the control panel body, cam RA should operate;
- (b) alignment of figures 72 - 73 on the HPT-10 control panel dial with the notch on the control panel body initiates operation of cam NC;
- (c) as soon as figures 95 - 103 on the HPT-10 control panel dial become matched with the notch on the control panel body operation of cam "A" should take place.

**Notes:**

1. The above mentioned positions of the HPT-10 control panel arm and RP-210 regulating fuel pump lever relate to the engines of the 5th series.
2. When checking positions of the HPT-10 control panel arm and the RP-210 regulating fuel pump lever on engines of other series, refer to the appropriate instructions for the given series and supplementary bulletins.

Adjustment of High-Pressure Rotor Maximum R.P.M.

In case the maximum r.p.m. value of the high-pressure rotor in flight exceeds the specified value and reaches more than 103.54, it is necessary to readjust the maximum r.p.m. limiter so as to obtain the value of 103.3 - 0.9.

The adjusting procedure should be carried out as follows:

1. Unlock and turn off the cap fitted over the screw of regulating fuel pump RP-220.

370

2. Adjust the r.p.m. to the specified value by operating the adjusting screw. Turning the screw in increases the maximum r.p.m. of the high-pressure rotor, and vice versa.

**Note:** One turn of the adjusting screw changes the maximum r.p.m. value of the high-pressure rotor by 1.2%.

This may result in decrease of the low-pressure rotor r.p.m.; therefore, determination and adjustment of the low-pressure rotor maximum r.p.m. on the ground should be performed with the jet nozzle flaps fully opened (in the FULL AUGMENTED position); act as follows:

- (a) detach the plug connectors of the solenoid-operated valve serving for engaging the afterburner, and of the electrical contactor incorporated in regulating fuel pump RP-220;

(b) move the engine control lever to the FULL AUGMENTED stop to check the maximum r.p.m. of the low-pressure rotor; if necessary, adjust the r.p.m. to 100 ± 0.5%.

The above adjusting procedure over, attach the plug connectors and make sure that the afterburner becomes engaged properly.

Adjustment of Time Delays of Afterburner Control Box RP-13

Provision is made in the afterburner control box operation for time delays (with regard to the position of the jet nozzle flaps and the rate of fuel supply).

To ensure proper time delays it is necessary to set the slotted screws of the RP-13 afterburner control box in the respective positions. To slow down the rate of gas temperature drop after the turbine, the time delay

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

with regard to the jet nozzle flap position should be increased, whereas the edge delay with regard to the fuel supply rate must be decreased, and vice versa.

- Notes:**
1. Time delays should be changed in succession.
  2. In case impediment to afterburner starting occurs resulting in a double pop, decrease the time delay with regard to the flap position or increase the time delay with regard to the fuel supply rate.

Adjustment of Engine Acceleration

If the engine performance fails to meet the specifications carry out the necessary adjustments:

1. Connect a pressure gauge (with the scale range from 0 to 100 kg/cm<sup>2</sup>) to the respective connection provided on the primary fuel manifold.
2. Measure the fuel pressure in the primary manifold, with the engine running at idling rating; the fuel pressure should amount to  $21 \pm 1$  kg/cm<sup>2</sup> (for regulating fuel pumps EP-21 of I and subsequent series). If the pressure turns to be beyond the specified level, adjust it by means of screw JK incorporated in the distributing valve; the screw should be turned by not more than 1/8 of a turn from the initial position. When the screw is being turned in, the fuel pressure increases (the adjustment procedure in question should be accomplished after consulting the manufacturer's representative, with subsequent checkout of the fuel pressure in the primary fuel manifold during engine starting).
3. Check the time period required for the fuel pressure in the primary fuel manifold (with regard to the first branch of the pressure increase limiter) to increase from  $P_{p.f.m.} = 22$  kg/cm<sup>2</sup> to  $P_{p.f.m.} = 26$  kg/cm<sup>2</sup>; the time period should be equal to not less than 3.0 seconds.

- Notes:**
1. The time period within which the pressure increase takes place should be measured (after setting the engine control lever below the idling rating stop) to pressure  $P_{p.f.m.} = 19 \pm 0.5$  kg/cm<sup>2</sup>.
  2. The flow restrictor of the first branch pressure increase limiter must be characterized by a capacity not smaller than 40 cm<sup>3</sup>/min. The capacities of flow restrictors used must range within it to 100 cm<sup>3</sup>/min.
  3. The initial fuel pressure increase in the primary fuel manifold should not exceed 2.5 kg/cm<sup>2</sup>.
- A.** The time required for pressure increase to take place should be measured with the following method:
- (a) slowly move the engine control lever to the CUT-OFF stop to reduce the fuel pressure in the primary fuel manifold to  $19 \pm 0.5$  kg/cm<sup>2</sup>;
  - (b) smoothly move the engine control lever to the MAXIMUM position and check the period required for pressure increase in the first branch of the pressure increase limiter.




FIG. 15B. TIME ACCEL. EP. vs. BAROMETRIC PRESSURE speed by conventional and hydraulic pumps

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

4. Check the time period within which the engine accelerates from the idling r.p.m. to the 100% r.p.m. This period should meet the limitations set forth in the chart of Fig. 160. The stopwatch should be arrested at  $n_1 = 99\%$ .

**WARNING:** If the acceleration time for the first branch is within the specified limits, whereas the full acceleration time is other than specified, adjust the acceleration time by selecting proper flow restrictors for the second branch of the pressure increase limiter or proper feed-back flow restrictors.

5. Check the time period required for the fuel pressure in the primary fuel manifold to increase, as regards the second branch of the pressure increase limiter. From  $P_{f.p.m.} = 25 \text{ kg/cm}^2$  to  $P_{f.p.m.} = 40 \text{ kg/cm}^2$ , this time period should be within  $4.0 \pm 0.6 \text{ sec.}$  and at least 5.5 sec. for the engines not provided with automatic starting system.

**Notes:** 1. Change-over from the first branch of the pressure increase limiter to the second branch takes place at the primary manifold pressure of  $27 \pm 1 \text{ kg/cm}^2$ . To determine the change-over pressure, insert a flow restrictor of the capacity amounting to  $250 - 300 \text{ cu.cm./min.}$  in the second branch. Having determined the change-over pressure value, re-install the old flow restrictor. The capacity values of the second-branch flow restrictors used, range from 70 to 350 cu.cm./min., the recommended indicated range being 100 to 150 cu.cm./min. 2. If the engine acceleration time by the first and second branches of the pressure increase limiter is within the specified range but the total acceleration time does not meet the Specifications, adjust the acceleration time value by replacing the feed-back flow restrictor with a new one to correct the fault.

280

3. When adjusting the engine acceleration time with regard to the pressure increase limiter, install temporarily a flow restrictor of 250 to 300 cu.cm./min. capacity which is capable of cutting off the pressure increase limiter. Upon completion of the adjusting procedure, re-install the old flow restrictor. Do not use hydraulic decelerator flow restrictors with the capacity range of 50 to 90 cu.cm./min.

6. Check the engine acceleration from the r.p.m. amounting to 85% normal rating to the normal rating or 100%; while checking, measure the acceleration time to 99% normal rating. This time period should be equal to 7 - 10 seconds. If the acceleration time fails to meet the specified value, re-adjust the acceleration time by selecting the proper flow restrictor of the hydraulic decelerator.

**WARNING:** 1. The capacity values of the feed-back flow restrictors should be within 150 to 300 cu.cm./min.

2. When replacing the feed-back flow restrictor with a flow restrictor of lower capacity check the engine maximum r.p.m. as instructed in point 3 of Section "Adjustment of Low-Pressure Rotor Maximum R.P.M."

7. When through with the adjusting procedure, check the engine acceleration:

- (a) from idling r.p.m. to maximum r.p.m.;
- (b) from  $n_1 = 85\%$  normal rating to maximum r.p.m.




**Note:** Upon replacement of flow restrictors during acceleration adjusting operations flush regulating fuel pump 2P-216 with fuel to eliminate probable air locks.

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM



SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

8. Check the acceleration margin by the following method:

- (a) accelerate the engine to the maximum r.p.m. and run it at this speed during 1 minute;
- (b) reduce the engine r.p.m. to the idling rating and run it at this speed during 2 minutes;
- (c) smoothly accelerate the engine to 85% normal rating and check the engine acceleration time to the maximum rating.

The acceleration time measured during the above checking procedure should differ from that measured during the operations under Point 7 (b) by not more than 2 seconds. Should the acceleration time difference be in excess of 2 seconds, consult the Manufacturer's representative as to the possibility of further use of the EP-210 regulating fuel pump.

**Note:** 1. During the engine acceleration margin check, the acceleration time is allowed to differ from that measured under Point 7 (b) above by more than 2 sec. provided it remains within the specified range.

2. Should the engine acceleration in any of the above cases involve an excessive increase in gas temperature after the start-up or purging, discontinue the engine acceleration by placing the engine control lever at the "STOP" stop; then locate and eliminate the fault.

9. Move the engine control lever below the idling r.p.m. zone until the lever reaches the border of the minimum stable r.p.m. zone (determined from the Charts presented in Figs 161 and 162) with flight load applied to booster pump EP-34 and to starter-generator JCP-CI-120000T; then accelerate the engine from this r.p.m. value. If the engine fails to come up to speed from the reduced r.p.m. (this results in unstable operation), re-adjust the distributing valve incorporated in regulating fuel pump EP-210, as instructed above (see Point 7 of the present Section).

If the adjustment proves ineffective, replace type EP-210 regulating fuel pump.

10. Disconnect the pressure gauge which has been installed for measuring fuel pressure in the primary fuel manifold, and obtain the original positions of the pipelines and connections.

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

CONTENTS

|  | Page |   | Page |
|--|------|---|------|
| Preface .....  | 2    | Pressurization System Pipeline<br>for Airtightness .....  | 32   |
| General .....  | 4    | Chart 11. Checking Pressurization Valve in<br>Fuel, Gasoline and Hydraulic<br>Systems with Engine Running. Check-<br>ing Amount of (Pressurization) in<br>Wing Fuel Compartments on Aircraft<br>Beginning with Serial No. 2815..... | 36   |
| Chart 1. Washing Filter in Special Valve<br>Control Pressure Line of Fuel<br>System .....  | 9    | Chart 12. Checking Fire-Fighting System<br>Units and Pipelines for Condition<br>and Attachment .....  | 39   |
| Chart 2. Washing and Inspecting Gasoline<br>System Filter .....  | 11   | Chart 13. Changing AN-10 Hydraulic Fluid in<br>Hydraulic Systems. Replacement of<br>Fine Filtering Elements in<br>Hydraulic System Filters .....  | 42   |
| Chart 3. Washing Wing Tank Filters .....   | 14   | Chart 14. Checking Inner Chambers of Cylindrical<br>Hydraulic Accumulators for Air-<br>tightness .....  | 62   |
| Chart 4. Inspection of Drop Fuel Tank Gauge<br>Filter .....  | 17   | Chart 15. Inspection and Washing of Gauge<br>Filters Installed in Hydraulic<br>Engine Inlet Connections .....   | 64   |
| Chart 5. Inspection of Negative-G Valve and<br>Interior of Fuel Tank No. 3 .....   | 20   | Chart 16. Demounting and Re-mounting Pressuriza-<br>tion Unit of Hydraulic System .....   | 66   |
| Chart 6. Inspection of Float Valves of<br>Tanks Nos 1 and 3 .....  | 23   | Chart 17. Checking Hydraulic Systems for<br>Internal and External Airtightness....  | 68   |
| Chart 7. Drainage of Sediment and Non-<br>Expansible Fuel Remain from Wing<br>Fuel Compartments .....                                    | 26   |   |      |
| Chart 8. Inspection of Bag Fuel Sumps and<br>Lower Section of Fuel Service Tank<br>for Proper Condition and Reliable<br>Attachment ..... | 28   |   |      |
| Chart 9. Demounting Gasoline System Pressu-<br>rization Unit and Dust Filter .....   | 30   |   |      |
| Chart 10. Checking Fuel System, Gasoline<br>System and Hydraulic Reservoir   |      |   |      |

SECRET/NO FOREIGN DISSEM

Peer Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|   | Page |   | Page |
|---|------|---|------|
| Chart 16. Checking Emergency Pump Unit E1-22 for Reliable Operation .....   | 75   | Chart 28. Inspection of Taper Bushing and Outer Surface of Main L.G. Strut Inner Tube .....                                       | 119  |
| Chart 19. Checking H-34 Hydraulic Pumps, Alleron Hydraulic Boosters and Stabilizer Hydraulic Boosters for Reliable Operation .....                            | 79   | Chart 29. Checking L.G. Emergency Extension System for Proper Functioning and Air-tightness .....                                 | 124  |
| Chart 20. Checking Nitrogen Pressure in Spherical Hydraulic Accumulators of Hydraulic Systems .....   | 85   | Chart 30. Checking AMP-10 Hydraulic Fluid Level in L.G. Shock Struts and Rosebeel Shimmy Damper .....                             | 127  |
| Chart 21. Checking Condition of L.G. Main and Rosebeel Shock Struts and Pressure-Charging of Strut Hinge Grease Fittings with Lubricant, Grade HRAE-203 ..... | 87   | Chart 31. Changing AMP-10 Hydraulic Fluid in L.G. Shock Struts and Rosebeel Shimmy Damper .....                                   | 134  |
| Chart 22. Checking Total Play of L.G. Struts, Doors and Pairings .....  | 92   | Chart 32. Check Retraction and Extension of Landing Gear .....  | 141  |
| Chart 23. Checking Clearance Between Stop on Frame No.6 and Upper Arm of Rosebeel Strut .....   | 95   | Chart 33. Checking Clearances Between Stop on Fuel Idle Shaft and Bottom of Main L.G. Shock Strut Inner Tube .....                | 149  |
| Chart 24. Checking Condition of Control Cables Running from Main L.G. Strut Locks to L.G. Door Locks .....  | 97   | Chart 34. Inspection and Lubrication of Wing Attachment Joints. Checking Condition of Pipelines and Electric Wiring Harness ..... | 151  |
| Chart 25. Washing, Inspection and Lubrication of Wheel Doors Attachment Joints and of Wheel Turning Mechanism Control Rod Hinge Joints .....                  | 99   | Chart 35. Inspection and Lubrication of Alleron Attachment Joints. Checking Weight Balance Bolts for Secure Locking .....         | 152  |
| Chart 26. Removal, Washing and Lubrication of Bolts of Rosebeel Shock Strut Universal Joint and Main L.G. Strut Cross-pieces .....                            | 101  | Chart 36. Inspection and Lubrication of Flap Carriages .....  | 160  |
| Chart 27. Checking Wheels, Bearings and Brakes System for Condition .....   | 105  | Chart 37. Inspection of Guiding Rails and Rollers of Flaps. Checking Flaps for Synchronous Extension and Retraction .....         | 163  |
|   |      | Chart 38. Fuselage Disjoints and Re-joining .....   | 166  |
|   |      | Chart 39. Inspection of Passlage Inner Skin;  |      |

SECRET/NO FOREIGN DISSEM

Poor Original

SECRET/NO FOREIGN DISSEM

50X1-HUM

|  | Page |   | Page |
|--|------|---|------|
|  |      | Chart 50. Checking Condition of Canopy Frame, Lubrication of Mechanism for Canopy Inside and Outside Control Handles .....                                    | 254  |
| Chart 40. Inspection of Cone and Anti-Burge Shutter Control Mechanisms .....   | 176  | Chart 51. Checking Cable for Mechanical Opening of Landing Gear Base Strut Independent Extension Lock. Checking Cable Rubber Sealing Boot for Condition ..... | 258  |
| Chart 41. Checking Operation of Drag Chute System .....  | 179  | Chart 52. Checking Condition of Hot Line Thermal Isolation and Joint between Cockpit Supply System Connecting Pipe and Canopy Air Flow Manifold .....         | 260  |
| Chart 42. Checking Attachment Locks and Screws of Fuselage Maintenance Access Covers .....   | 195  | Chart 53. Inspection of Fairleads for Aircraft Control Rods and of Cockpit Sealing Hose .....   | 262  |
| Chart 43. Checking Attachment of Hydraulic Cylinders and Hinge Joints and Airbrakes .....  | 200  | Chart 54. Mounting Ejection Seat on Aircraft's Mounting Canopy and Checking It for Proper Opening and Closing .....   | 265  |
| Chart 44. Checking Condition and Lubrication of Aircraft Control Rods and Bellcranks and Their Attachment Joints. Checking BY-31M (BY-31MC) and BY-45 Hydraulic Boosters for Proper Attachment ..... | 201  | Chart 55. Removal and Mounting Ejection Seat .....  | 267  |
| Chart 45. Checking Play in Rudder, Stabilizer and Aileron Controls .....   | 206  | Chart 56. Checking CX Ejection Seat Units and Cables for Proper Operation .....   | 275  |
| Chart 46. Checking Weight Balancers of Stabilizer and Rudder for Proper Attachment .....   | 219  | Chart 57. Checking Cockpit for Tightness .....  | 301  |
| Chart 47. Lubrication of Stabilizer Beam Bearings and Checking Stabilizer Friction Moment .....  | 221  | Chart 58. Reaming Filter of AK-5 Pressure Controller, Cleaning Filter and Checking Pressure .....   | 303  |
| Chart 48. Checking Operation of Canopy Emergency Ejection System .....   | 222  | Chart 59. Checking Flexible Coating of Control Cable of Valve BY-7 and Valves BY-7 and BY-8 for Condition and Attachment .....                                | 306  |
| Chart 49. Removal of Blind-actuated Ejection Seat from Aircraft, Washing, Inspection and Lubrication of Mechanism Moving Parts and Cables .....  | 226  | Chart 60. Replenishing Oil in Turbo-cooler Bearings .....   | 307  |
|  |      | Chart 61. Washing and Inspection of Air System Strainer .....   | 309  |
|  |      |   | 383  |

SECRET/NO FOREIGN DISSEM

Peer Original



SECRET/NO FOREIGN DISSEM

50X1-HUM

|  | Page |  | Page |
|--|------|--|------|
| Chart 62. Checking Air System Hoses for Secure Attachment and Both Systems for Tightness .....   | 329  | Chart 67. Checking Operation of Jet Nozzle Flaps Control System .....  | 324  |
| Chart 63. Checking Jet-Setting System for Spraying Alcohol through Manifold .....  | 333  | Chart 68. Inspection of Jet Nozzle and its Telescopic Joint for Proper Installation; Checking of Jet Nozzle Flap Diameter Against Service Log Data ..... | 327  |
| Chart 64. Removal, Inspection and Washing of Oil Unit Filter .....   | 335  | Chart 69. Inspection of Engine Attachment Units .....  | 339  |
| Chart 65. Inspection of Engine Controls .....  | 318  | Chart 70. Replacement of Engine .....  | 341  |
| Chart 66. Checking Engine Control Lever for Proper Locking at all Stops; Checking Control Lever Positions for Proper Agreement with Positions of EP-216 Regulating Fuel Pump Levers and H773-16 Control Panel Levers ..... | 320  | Chart 71. Processing and Deprocessing of Engine .....  | 358  |
|  |      | Chart 72. Engine Trial; Checking of Instruments and Units for Proper Operation; Checking of Systems for Tightness .....                                  | 359  |
|  |      | APPENDICES:  |      |
|  |      | 1. Detachable Connecting Lines of Engine ..  | 370  |
|  |      | 2. Adjustment of Engine .....  | 372  |

SECRET/NO FOREIGN DISSEM

Original